


FR-SF
SPINDLE
CONTROLLER
TROUBLE-SHOOTING GUIDE

FR-SF / M32 PARAMETER CROSS REFERENCE TABLE

Parameter No.		FR-SF Parameter	
FR-SF	M-32	Name	Description
21	J81	PG1	Orient 1 st deceleration point.
22	J82	PG2	Orient 2 nd deceleration point.
23	J83	PGC	P Loop gain C axis sync-tap.
24	J84	ZRZ	Orient in position range.
25	J85	OSP	Spindle orient speed.
26	J86	CSP	Creep speed.
27	J87	PST	Position shift.
28	J88	BRC	Not used, set "0".
29	---	---	Not used, set "0".
2A	---	---	Not used, set "0".
2B	---	---	Not used, set "0".
2C	---	---	Not used, set "0".
2D	---	---	Not used, set "0".
2E	---	---	Not used, set "0".
2F	J101 U	OR1	
	J102 L	ORS1	Orient stop control 1.
30	J104 L	ORS2	Orient stop control 2.
31	J105	TSP	Motor maximum speed.
32	J106	ZSP	Zero speed range.
33	J107	CSN	Acceleration time constant.
34	J108	SDR/SDT	Up to speed detect range.
35	K1	TRQ/TLM	Torque limit by TL2.
36	K2	VKP	Speed loop proportional gain.
37	K3	VKI	Speed loop integral gain.
38	K4	TYP	Transition type S to P loop.
39	K5	GRA1	Spindle side: No. of teeth Gear #1.
3A	K6	GRA2	Spindle side: No. of teeth Gear #2.
3B	K7	GRA3	Spindle side: No. of teeth Gear #3.
3C	K8	GRA4	Spindle side: No. of teeth Gear #4.
3D	K9	GRB1	Motor side: No. of teeth Gear #1.
3E	K10	GRB2	Motor side: No. of teeth Gear #2.
3F	K11	GRB3	Motor side: No. of teeth Gear #3.
40	K12	GRB4	Motor side: No. of teeth Gear #4.

SFCA CARD



Appendix 2 Spindle alarm list

No.	Content		No.	Content	
10	Voltage down	PR	40		PR
11			41		PR
12	Memory fault 1	AR	42		PR
13			43		PR
14			44		PR
15	Memory fault 2	PR	45	Controller overheat	PR
16			46	Motor overheat	PR
17	Card fault	PR	47		
20	No signal 1 (PLC)	PR	50		
21	No signal 2 (Spindle EMC)	PR	51		
22	IC MAC012 fault	PR	52	Error excess	PR
23	Speed control error excess	PR	53		
24	Breaker trip/main circuit fault	PR	54		
25	Converter overcurrent/brake fault	PR	55	Emergency stop	
26	Power phase failure	PR	56	Other axis fault	*
27	CPU fault		57		
30			E0	Instantaneous power failure warning	*
31	Overspeed	PR	E1	Overload warning	*
32	Inverter overcurrent/overcurrent	PR	E2		
33	Overvoltage	PR	E3		
34	Data parity check error	PR	E4	Parameter error warning	*
35	Data fault	PR	E5		
36	Data transfer fault	PR	E6		
37	Parameter error	PR	E7	NC emergency stop	

PR: Reset by turning off power supply of NC

AR: Reset by turning off power supply of spindle amplifier

NR: NC reset

*: "Servo OFF" does not occur.

I	Alarm 10 undervoltage	Page 1
II	Alarm 12 memory error 1	Page 1
	Alarm 13 External Clock Error	
III	Alarm 15 memory error 2	Page 1
IV	Alarm 17 PCB error	1
V	Alarm 20 MAC007 error	2
VI	Alarm 21 No signal 2 (spindle encoder)	2
VII	Alarm 22 IC MAC012 error	2
VIII	Alarm 23 Excessive Speed Error	2
XI	Alarm 24 Breaker Trip	
XI	Alarm 25 Inverter Overcurrent	
X	Alarm 26 Power Phase Missing	
XI	Alarm 27 CPU Error	
XII	Alarm 31 Overspeed	
	Alarm 32 Converter Overcurrent	
XIII	Alarm 33 Converter Overvoltage	
XIV	Alarm 34 Data Parity Error	
XIV	Alarm 35 Data Error	
XIV	Alarm 36 Transfer Error	
XV	Alarm 37 Parameter Error	
	Alarm 45 Controller Overheat	
	Alarm 46 Motor Overheat	
	Alarm 52 Overdroop	

Alarm 56 Other Axis Fault
Alarm 57 Option Card Error

Long Accel/decel time

Motor Stalls While Cutting

Motor Will Not Accept Gear Shift Commands

No CW, CCW, or Ready

2-73

I. Alarm 10 undervoltage

- A. ALARM WITH POWER ON
 - 1. INCOMING POWER SHOULD BE 200-230VAC +10/-15% AT THE SPINDLE BREAKER. ALARM WILL OCCUR IF THE INCOMING POWER IS 170VAC OR LESS FOR 15mSEC OR LONGER 2. MEASURE VOLTAGE BETWEEN ACDOWN AND DO24 ON CON21 OF SF-PW. IF THIS IS NOT 5VDC, SF-PW IS DEFECTIVE.
- B. ALARM WHILE RUNNING. CHECK INCOMING POWER DURING ACCEL AND DECEL. IF VOLTAGE DROPS TO 170VAC OR LESS FOR 15mSEC OR MORE, THE INPUT POWER CAPACITY IS NOT SUFFICIENT, AND SHOULD BE INCREASED.
- II. ALARM 12, MEMORY ERROR 1
 - A. CHECK TO SEE THAT ROM'S 1, 2, AND 3 ON SF-CA PCB ARE PROPERLY INSERTED, AND IN THE CORRECT LOCATIONS.
 - B. IF ROMS ARE OK THEN SF-CA PCB IS DEFECTIVE
- III. ALARM 15, MEMORY ERROR 2
 - A. CHECK THAT CONNECTOR CN1A ON BUSLINK PCB IS PROPERLY CONNECTED B. CHECK THAT CAM11 CABLE (USED FOR NC BUSLINK) IS PROPERLY CONNECTED, AND REPLACE IF NECESSARY.
 - C. MAKE SURE ALL GROUND WIRES FROM NC, SPINDLE CONTROLLER, AND MOTOR ARE PROPERLY CONNECTED AND ALL CABLES ARE CORRECTLY SHIELDED.
 - D. IF ALL CONNECTORS AND CABLES ARE OK, REPLACE BUSLINK PCB.
 - E. IF BUSLINK PCB DOES NOT RESOLVE PROBLEM, PROBLEM IS IN EITHER THE MC611 OR MC632 BOARDS ON THE NC SIDE
- IV. ALARM 17 PCB ERROR. MAKE SURE THE SPINDLE CONTACTOR PULLS IN AND OUT PROPERLY
 - IF NOT, COMPONENTS ON MAIN CIRCUIT ARE DEFECTIVE, AND COMPLETE UNIT SHOULD BE EXCHANGED.
 - IF THE SPINDLE CONTACTOR PULLS IN OK, EXCHANGE SF-CA PCB
- V. ALARM 20 MAC007 ERROR
 - A. THE SF-CA PCB IS DEFECTIVE AND SHOULD BE REPLACED.
- VI. ALARM 21 NO SIGNAL 2 (SPINDLE ENCODER)
 - A. CHECK CABLE FROM SPINDLE ENCODER TO SPINDLE CONTROLLER FOR CONTINUITY AND PROPER CONNECTIONS. REPLACE IF NECESSARY.
 - B. MAKE SURE THAT THE ENCODER IS RECEIVING 5VDC FROM THE NC SIDE.
 - C. CHECK THAT PARAMETER #41 IS SET ACCORDING TO PARAMETER SHEET
 - D. CHECK SPINDLE ENCODER TO MAKE SURE ALL SIGNALS (A, B, AND Z PHASES) ARE OK. IF ANY SIGNALS ARE MISSING, REPLACE THE ENCODER.
 - E. IF ABOVE DO NOT RESOLVE PROBLEM, THEN REPLACE SF-TL(OR) PCB.
- VII. ALARM 22 IC MAC012 ERROR. SF-CA CIRCUIT BOARD IS

DEFECTIVE AND MUST BE REPLACED

VIII. ALARM 23 EXCESSIVE SPEED ERROR

- A. CHECK FOR CORRECT PHASE SEQUENCE AND CONTINUITY OF THE U, V, AND W MOTOR LEADS AND REPLACE IF NECESSARY.
- B. CHECK FOR POSSIBLE MOTOR OVERLOAD. REVIEW CUTTING CONDITION AND TOOLING BEING USED.
- C. CHECK THE LED ON THE SF-PW POWER SUPPLY. IF IT IS NOT LIT REPLACE THE POWER SUPPLY
- D. IS AN OPEN LOOP POSSIBLE? IF SO PLG ON THE BACK OF THE MOTOR IS MISSADJUSTED. WHILE CHECKING THE A AND B PHASES FROM PLG, . USE VR1, VR2, VR3, AND VR4 TO SET PROPER GAIN AND OFFSET. IF SIGNALS ARE NO-GOOD AND CANNOT BE ADJUSTED, REPLACE THE PLG CIRCUIT BOARD.
- E. IF AN OPEN LOOP IS NOT POSSIBLE AND THE SPINDLE DOES NOT TURN, THE SPEED FEEDBACK CIRCUIT ON THE SF-CA CARD IS DEFECTIVE AND MUST BE REPLACED

IX. ALARM 24 BREAKER TRIP

ALARM 25 CONVERTER OVERCURRENT

ALARM 32 INVERTER OVERCURRENT ALL RELATED

- A. CHECK INCOMING POWER TO SPINDLE CONTROLLER WITH A SCOPE. DURING ACCELERATION AND DECELERATION THE SINE WAVE SHOULD BE CLEAN AND FREE OF NOISE
- B. CHECK PARAMETERS #01 AND #02 AND SET TO SPECIFICATIONS ON PARAMETER SHEET.
- C. CHECK DIODE STACK IN BASE UNIT FOR OPEN OR SHORTED CONDITIONS. IF BAD, CHECK MAIN FILTER CAPACITORS AND REPLACE AS NECESSARY
- D. IF SPINDLE WILL NOT RUN AT ALL AND ALARM WILL NOT RESET, CHECK THE MAIN POWER TRANSISTORS FOR SHORTS. IN THIS CASE THE COMPLETE UNIT SHOULD BE REPLACED.
- E. IF ALL ABOVE ITEMS ARE OK THE MOTOR NEEDS TO BE REBUILT.

X. ALARM 26 POWER PHASE MISSING

- A. CHECK INCOMING POWER FOR 200-220VAC +10/-15% BETWEEN EACH PHASE. IF PHASE MISSING, CHECK WIRING BACK TO MAIN TRANSFORMER.
- B. CHECK FUSES F1, F2, AND F3 AND REPLACE AS NECESSARY. (FUSES ARE 5 AMPS)

XI. ALARM 27 CPU ERROR, (DIVISION ERROR)

- A. CHECK GEAR RATIO PARAMETERS TO PARAMETER SHEET AND SET ACCORDINGLY
- B. CHECK CONNECTOR CN1A ON BUSLINK PCB FOR SECURE CONNECTION C. CHECK NC BUSLINK CABLE (CAM11) FOR PROPER CONNECTIONS AND REPLACE IF NECESSARY
- D. CHECK PARAMETERS VKP, VKI, AND ORS1 WITH THE PARAMETER SHEET AND SET ACCORDINGLY
- E. IF PARAMETER #1 NOX IS SET TO 2, A SPECIAL MOTOR

IS

USED. CHECK PARAMETER #S 81 TO AF TO THE VALUES ON THE PARAMETER SHEET AND SET THEM ACCORDINGLY.

XII. ALARM 31 OVERSPEED

- A. IF THE REFERENCE SPEED EXCEEDS 115% OF THE MAXIMUM SPEED, CHECK PARAMETER #31 (TSP) WITH THE PARAMETER SHEET
- B. CHECK PLG FEEDBACK SIGNALS FOR CORRECT OFFSET AND GAIN. IF SIGNALS WILL NOT ADJUST, REPLACE THE PLG CIRCUIT BOARD C. IF THE SPINDLE SPEED IS UNSTABLE AND OVERSHOOT OCCURS, CHECK THE WAVEFORMS ACROSS SMO-OM TERMINALS ON THE SF-CA CIRCUIT BOARD. IF UNSTABLE, CHECK PARAMETER NUMBERS 36 AND 37 TO THE PARAMETER SHEET AND SET ACCORDINGLY.
- D. IF ALL OF THE ABOVE ITEMS ARE CORRECT, REPLACE THE SF-CA CIRCUIT BOARD

XIII. ALARM 33 CONVERTER OVERVOLTAGE

- A. CHECK INCOMING VOLTAGE AT THE CIRCUIT BREAKER. IT SHOULD BE LESS THAN 253VAC (230+10%) IF VOLTAGE IS HIGHER, THIS ALARM WILL OCCUR.
- B. CHECK THE INPUT POWER IMPEDANCE. IF TOO HIGH, THIS ALARM WILL OCCUR. IMPEDANCE NEEDS TO BE LOWERED
- C. CHECK RESISTANCE AND PHYSICAL CONDITION OF CONVERTER SIDE POWER TRANSISTORS IN BASE UNIT AND THE FIRING ON THE SF-CA CIRCUIT BOARD. IF DAMAGED, THE COMPLETE UNIT SHOULD BE REPLACED.
- D. IF ALL THE ABOVE ITEMS CHECK OUT, THEN REPLACE THE SF-CA CIRCUIT BOARD.

XIV. ALARM 13 EXTERNAL CLOCK ERROR ALL RELATED
 ALARM 34 DATA PARITY ERROR
 ALARM 35 DATA ERROR
 ALARM 36 TRANSFER ERROR

- A. CHECK CONNECTOR CN1A ON BUSLINK PCB FOR SECURE CONNECTIONS B. CHECK NC BUSLINK (CAM11) CABLE FOR PROPER CONNECTIONS AND REPLACE IF NECESSARY C. MAKE SURE THAT ALL GROUNDS ARE SECURE AND THAT ALL CABLES ARE PROPERLY SHIELDED.
- D. CHECK THE TERMINATING RESISTANCE PLUG ON THE BUSLINK PCB FOR A SECURE CONNECTION AND REPLACE IF NECESSARY
- E. IF THE ABOVE ITEMS ARE CORRECT, THE BUS INTERFACE CIRCUIT ON EITHER THE SPINDLE OR NC SIDE IS DEFECTIVE.

XV. ALARM 37 PARAMETER ERROR

- A. THIS ALARM INDICATES THAT A PARAMETER HAS BEEN SET WITH A VALUE LARGER THAN ITS ALLOWABLE RANGE.

XVI. ALARM 45 CONTROLLER OVERHEAT

- A. PLACE A SHORTING PIN ON PIN 6 (1A AND 1B) OF SF-CA PCB

- 1 IF THE ALARM IS STILL PRESENT, THE ALARM CIRCUIT ON THE SF-CA CARD IS DEFECTIVE

- 2 IF THE ALARM IS RESET THEN

- a. CHECK FANS INSIDE SPINDLE CONTROLLER
 REPLACE IF NECESSARY
- b. CHECK FANS IN ELECTRICAL CABINET

- c. CHECK FOR CONTINUITY ACROSS THS1 AND THS2 IN BASE UNIT. REPLACE IF CIRCUIT IS OPEN.

XVII. ALARM 46 MOTOR OVERHEAT

- A. SHORT OHS1 AND OHS2 WIRES TOGETHER INSIDE THE MOTOR TERMINAL BOX.

- 1. IF ALARM IS STILL PRESENT THE SF-CA BOARD IS DEFECTIVE
- 2. IF THE ALARM CLEARS THEN:
 - a. IF SPINDLE MOTOR IS HOT,
 - 1. CHECK COOLING FAN AND REPLACE IF NOT FUNCTIONING.
 - 2. IF MOTOR IS OVERLOADED, REVIEW THE CUTTING CONDITIONS AND TOOLING BEING USED 3. IF MOTOR IS FREQUENTLY BEING STARTED AND STOPPED, DECREASE FREQUENCY OF STARTS AND STOPS OR INCREASE THE VALUE OF THE ACCELERATION TIME CONSTANT PARAMETER 33 (CSN)
 - B. IF SPINDLE MOTOR IS NOT HOT
 - 1. CHECK FOR CONTINUITY ACROSS OHS1 AND OHS2. IF OPEN REPLACE SENSOR.

XVIII. ALARM 52 OVERDROOP

- A. CHECK PARAMETER #03(PLG) WITH THE VALUE ON THE PARAMETER SHEET AND SET IT ACCORDINGLY
- B. CHECK BITS 8 AND E OF PARAMETER 30(ORS2) WITH THE VALUE ON THE PARAMETER SHEET AND SET ACCORDINGLY.
- C. CHECK ORIENTATION ENCODER FOR PROPER OPERATION AND REPLACE IF NECESSARY D. IF THE ABOVE ITEMS ARE CORRECT, INCREASE THE VALUE OF THE ACCELERATION TIME CONSTANT PARAMETER #33(CSN).

XIX. ALARM 56 OTHER AXIS FAULT

- A. CHECK NC BUSLINK (CAM11) CABLE FOR PROPER CONNECTION TO SPINDLE
 - CN1A---->CAM11 CABLE
 - CN1B---->TERMINATING RESISTANCE
- B. REFER TO SERVO DRIVE MAINTENANCE MANUAL

XX. ALARM 57 OPTION CARD ERROR

- A. INCORRECT OPTION CARD INSTALLED

XXI. LONG ACCEL/DECEL TIME

- A. CHECK PARAMETER #33(CSN)
- B. CHECK PARAMETER #01(NOX) AND #02(MSL)
- C. CHECK THAT ROMS 1, 2, AND 3 ON SF-CA PCB ARE CORRECTLY NUMBERED TO BN# SPECIFICATION SHEET
- D. CHECK THE TORQUE LIMIT COMMANDS PARAMETER #1U(BITS 2 AND 3) ON THE SF-CA PCB ARE NOT BEING TURNED ON.
- E. CHECK THE DRIVE BELTS FROM THE SPINDLE MOTOR

XXII. MOTOR STALLS WHILE CUTTING

- A. CHECK BELTS FROM SPINDLE MOTOR
- B. CHECK ROMS 1,2, AND 3 ON SF-CA PCB ARE CORRECTLY NUMBERED TO BN# SPECIFICATION SHEET

- C. CHECK TORQUE LIMIT COMMANDS, PARAMETER #1U BITS (2 AND 3) THEY SHOULD NOT BE ON
- D. CHECK TORQUE LIMIT PARAMETER #35(TLM) WITH THE PARAMETER SHEET AND SET ACCORDINGLY
- XXIII. MOTOR WILL NOT ACCEPT GEAR SHIFT COMMANDS
 - A. CHECK OUTPUT SIGNAL PARAMETER #4U(STS2) TO MAKE SURE THAT ALL THE OUTPUT BITS TO THE NC ARE PROPERLY SET, DEPENDING ON THE STATUS OF THE SPINDLE CONTROLLER. IF NOT, EXCHANGE THE SF-CA CARD B.
- CHECK EXTERNAL INPUT SIGNAL PARAMETER #1U (BITS 0 AND 1), TO MAKE SURE THAT THE NC SIDE IS GIVING THE PROPER DIRECTION COMMAND TO THE SPINDLE FOR GEARSHIFT XXIV. NO CW, CCW, OR READY

- A. Check external interface mode selection parameter #04(MOD) to the parameter sheet and set accordingly B. Check external input parameter #1U (bits 0 & 1) and parameter #2U (bit 0) for proper bit command from the NC side.
- C. Check external output parameter #3U (bit 0) and parameter #4U (bits 8 & 9) for proper bit outputs from SF-CA PCB. If output bits are not present and input bits are, replace SF-CA PCB

XXV Gear Noise

- A. Check if gear noise occurs when main power is shut off with the motor running. If noise goes away, go to step B. If noise persists. contact your machine tool builder
- B. Does noise persist in open loop? If not go to step C. If it does, adjust CT offsets on SF-CA PCB. Also verify that all parameters are properly set according to the parameter sheet. If these items check out ok, replace the SF-CA circuit board.
- C. Check adjustments of the PLG circuit card on the back of the motor. While checking A & B phase signals from PLG, use VR1, 2, 3, & 4 to set proper gain and offset. If signals are not good, and cannot be adjusted, exchange PLG circuit board and sensor.

XXVI NO LEDS

- A. Check incoming power at RO-SO terminals in the upper right hand corner of base unit. If OK, go to step B. If not, check F1, 2, & 3 (5amp) fuses on main line filter. IF they are blown, refer to the fuse blow explanation
- B. Disconnect SF-CA PCB from SF-PW. Disconnect CON101, 102, 103 from the hinge panel. Reconnect SF-CA to SF-PW. If LEDS come on, refer to transistor module checking procedure in the troubleshooting manual to find the shorted transistor. If the leds do not come on, replace

the SF-PW circuit board.

XXVII Blown Fuses

- A. With main power on
 - 1. Disconnect SF-PW wires from RO-SO terminals in upper right corner of base unit. If fuses do not blow, replace SF-PW
- B. With NC Power on
 - 1. Disconnect MS1 and MS2 wires from base unit located near U, V, & W motor leads. If fuses do not blow, replace motor cooling fan

XXVIII RPM Different than Command

- A. Check all parameters to parameter sheet and set accordingly
- B. Check reference speed status display (letter C) to make sure that the NC side is out-putting the correct speed reference. C. Check the PLG circuit board on the back of the motor for proper adjustment
- D. Check for possible motor overload. Review cutting conditions, and tooling being used E. Check to make sure that the override command is off when checking the RPM display of the SF-CA board. F. If all of the above items are ok, replace the SF-CA circuit board.

XXIX Orientation Problems

- A. If motor rotates at orient speed, but does not stop, then:
 - 1. Check signals coming back from the encoder or mag sensor. If signals are no good, replace the sensor or encoder 2. If the signals in item #1 are ok, check the signals at the orient card and SF-CA circuit card. If the signals are not good, exchange the orient card first and if that does not solve the problem, then replace the SF-CA card
 - 3. If encoder orientation is used, make sure that the encoder is receiving its 5 volt power supply from the NC side. Also make sure that the jumper pin settings on the orient card are correct. 4. Check parameter #41 (OSL) to the parameter sheet and set accordingly.

- B. Orient Procedure is OK, But the Stop State is Abnormal.
 - 1. Check the orientation adjustment procedure on the following pages, depending on the type of orientation that you are using.
 - 2. If item #1 is ok, and cannot be adjusted check for backlash in the gearing on the machine side. 3. If the problem occurs in all gears, or the backlash is normal, replace

the orientation circuit board and then the
SF-CA board in that order.

STATIC CHECK

BI-MOS TRANSISTOR CHECKING PROCEDURE FR-SF

1. PREPARATION

- 1 TURN OFF THE MACHINE MAIN POWER SWITCH OR BREAKER
- 2 TURN OFF THE SPINDLE DRIVE CIRCUIT BREAKER CB-1
- 3 CONNECT TEST LEADS TO THE FIRST SET OF THE TEST POINTS SHOWN BELOW. ATTACH THE PROBE'S GROUND CLIP TO THE CONNECTOR PIN AND THE PROBE ITSELF TO THE CHECK POINT. SET THE OSCILLOSCOPE TO VIEW A NEGATIVE TEN VOLTS DC.
- 4 TURN ON THE MACHINE MAIN BREAKER AND OBSERVE THE VOLTAGE BETWEEN THE TEST POINTS SHOWN AND THEN TURN OFF THE MAIN CIRCUIT BREAKER WITHIN FIVE SECONDS.
(THIS IS BECAUSE THE SF-PW AND/OR SF-CA CARDS COULD BE DESTROYED AGAIN IF THE BASE UNIT IS STILL DEFECTIVE. THIS IS TRUE EVEN WITH CB-1 OFF) DO THE SAME FOR THE SUBSEQUENT POINTS

I N V E R T E R	CH 47	TO	CON 24	PIN 2
	CH 48	TO	CON 24	PIN 6
	CH 49	TO	CON 24	PIN 10
	CH 50	TO	CON 22	PIN 2
	CH 51	TO	CON 22	PIN 2
	CH 52	TO	CON 22	PIN 2
C O N V E R T E R	CH 53	TO	CON 23	PIN 2
	CH 54	TO	CON 23	PIN 6
	CH 55	TO	CON 23	PIN 10
	CH 56	TO	CON 22	PIN 5
	CH 57	TO	CON 22	PIN 5
	CH 58	TO	CON 22	PIN 5

IN EACH OF THESE CASES A -10 VOLT DC DIFFERENCE SHOULD BE SEEN. THIS IS THE STATIC DC BIAS ON THE TRANSISTOR. ANY VARIANCE FROM THIS VOLTAGE INDICATES A PROBLEM WITH THE APPROPRIATE TRANSISTOR OR BIASING CIRCUIT.

CHECKING THE INVERTED (DRIVE) SIDE

1. TURN OFF THE MACHINE MAIN POWER BREAKER OR SWITCH
2. TURN OFF THE SPINDLE DRIVE CIRCUIT BREAKER CB-1
3. ON THE SF-CA CARD, SHORT PIN 6 SIDE 2 A TO B(THIS CANCELS THE CIRCUIT BREAKER TRIP ALARM). PIN 6 IS LOCATED ON THE BOTTOM RIGHT CORNER OF THE SF-CA CARD
4. TURN ON THE MACHINE MAIN BREAKER
5. TURN ON THE CONTROL POWER
6. REWRITE SPINDLE PARAMETER 58 TO 1* (NOTE 2) THE DRIVE MAY COME UP IN ALARM 17. SETTING PARAMETER 58 TO 1 WILL CLEAR THIS ALARM
7. TURN THE CONTROL OFF AND THEN BACK ON (THIS ENABLES THE NEW PARAMETER SETTING)

NOTE 2 TO CHANGE PARAMETER #58 PRESS THE MODE SWITCH UNTILL THE LEFT TWO DIGITS OF THE SIX SEVEN SEGMENT LEDS SHOWS 41. THIS IS THE MODE IN WHICH WE CAN ACCESS PARAMETERS 41 THROUGH 60. PRESS THE DOWN BUTTON UNTILL 58 IS DISPLAYED IN THE LEFT TWO DIGITS. THE DIGIT ON THE RIGHT WILL DISPLAY 0. TO CHANGE THIS TO A ONE, PRESS THE SET SWITCH. THE PARAMETER NUMBER WILL BEGIN FLASHING. USE THE UP AND DOWN BUTTONS TO CHANGE THE VALUE ON THE RIGHT TO WHAT YOU WANT AND PRESS THE SET BUTTON AGAIN.

7. SET THE SPEED COMMAND TO ZERO
8. PUT THE SPINDLE DRIVE IN OPEN LOOP. (SET PARAMETER #0 TO 1 **NOTE 3). DO NOT PRESS THE RESET SWITCH AFTER THIS SETTING, OR PARAMETER #0 WILL RETURN TO ITS ORIGINAL CONDITION, "0".

** NOTE 3

TO REWRITE DATA, USE THE SAME PROCEDURE AS IN NOTE 2. HOWEVER IT IS NOT NECESSARY TO PRESS PB1 (RESET SWITCH) AFTER REWRITING DATA TO SELECT PARAMETER ADDRESS #0, PRESS THE MODE SWITCH UNTILL "E1" APPEARS IN THE TWO POSITIONS ON THE LEFT. THEN PRESS THE 'DOWN' SWITCH ONCE. THE ADDRESS DISPLAY SHOWS "00".

9. CHECK THE SIX BASE WAVEFORMS USING THE OSCILLOSCOPE (READY-ON, SRN OR SRI - ON, THEN CHECK) ***

CH47	TO	CON	24	PIN	2
CH48	TO	CON	24	PIN	6
CH49	TO	CON	24	PIN	10
CH50	TO	CON	22	PIN	2
CH51	TO	CON	22	PIN	2
CH52	TO	CON	22	PIN	2

10. FROM THE CONTROL, COMMAND A SPINDLE SPEED. CHANGE THE SPINDLE SPEED BOTH UP AND DOWN AND WATCH WHAT HAPPENS TO THE WAVEFORM

CONVERTER (BREAK) SIDE

11. CHANGE DISPLAY TO DE-BUG MODE.

SELECT ADDRESS #564

WRITE DOWN THE DATA IN #564

SELECT ADDRESS #5FE

WRITE DOWN THE DATA IN #5FE

CHANGE THE DATA IN #5FE SO THAT THE NEW DATA ARE
EQUAL TO OR GREATER THAN THE DATA IN #564 PLUS C
(IN HEXADECIMAL)

LED 1 SHOULD BE ON INDICATING THE DRIVE IS NOW IN
THE REGENERATIVE STATE

(DO NOT PRESS RESET OTHERWISE THE DATA IN #5FE
WILL BE CHANGED TO THE ORIGINAL DATA.)

12. CHECK THE 6 BASE WAVEFORMS USING THE SCOPE.

(READY ON AND SRN OR SRI ON THEN CHECK THE
FOLLOWING)

TRY CHANGING THE COMANDED SPEED

CH53 TO CON 23 PIN 2

CH54 TO CON 23 PIN 6

CH55 TO CON 23 PIN 10

CH56 TO CON 22 PIN 5

CH57 TO CON 22 PIN 5

CH58 TO CON 22 PIN 5

13. AFTER CHECKING THESE WAVEFORMS, REWRITE PARAMETER
#58 TO "0" AND PRESS THE RESET BUTTON AND REMOVE THE
JUMPER FROM PIN 6 TO 2

****NOTE 4

- 1 SELECTING THE DEBUG MODE. WHEN THE MODE SWITCH IS
PRESSED 11 TIMES, THE DISPLAY CHANGES TO THE DEBUG
MODE 2. SELECTING ADDRESS #564
PROCESS STARTS IN LEAST SIGNIFICANT DIGIT (UNITS)
PRESS DOWN SWITCH FOUR TIMES INCREMENTS LEAST
SIGNIFICANT DIGIT TO 4
PRESS UP SWITCH ONCE MOVES SETABLE DISPLAY TO THE
TENS DIGIT PRESS DOWN SWITCH SIX TIMES
SETS TENS DIGIT DISPLAY TO SIX
PRESS UP SWITCH ONCE
MOVES SETABLE DISPLAY TO HUNDREDS DIGIT
PRESS DOWN SWITCH FIVE TIMES INCREMENTS HUNDREDS
DISPLAY TO FIVE
THIS PROCEDURE SELECTS ADDRESS #564

3. TO READ THE DATA THAT IS IN ADDRESS #564,
PRESS THE SET SWITCH ONCE

(THE ACTUAL DATA THAT WILL BE IN ADDRESS #564 IS UNPREDICTABLE). TO RETURN TO THE ADDRESS MODE, PRESS THE UP OR DOWN SWITCH ONCE

4. TO SELECT ADDRESS #5FE FOLLOW THE SAME PROCEDURE AS SHOWN ABOVE

5. TO CHANGE DATA

PRESS SET ONCE. d_0000 WILL BE DISPLAYED
PRESS SET ONE MORE TIME. THE LEAST SIGNIFICANT
DIGIT IN THE DISPLAY WILL START BLINKING,
INDICATING THAT THIS DIGIT CAN BE CHANGED.

6. THE NEW DATA SET INTO #5FE HAS TO BE EQUAL TO OR
GREATER THAN THE CONTENTS OF #564 IN HEX PLUS C
FOR EXAMPLE, IF #564 IS B3

#5FE > B3+C

#5FE > BF

IN THE ABOVE CASE, ANY VALUE CAN BE SET INTO #5FE,
AS LONG AS IT IS GREATER THAN BF

TO CHANGE THE DATA TO C0 FOR EXAMPLE

PRESS THE UP SWITCH ONCE THE TENS DISPLAY WILL
BLINK PRESS THE DOWN SWITCH 12 TIMES. C WILL BE
DISPLAYED IN THE TENS DISPLAY

PRESS THE SET SWITCH ONCE

DATA INPUT IS NOW COMPLETE AND LED 1 SHOULD BE ON