

ED C

FR-S500

INSTRUCTION MANUAL (BASIC)

FR-S520-0.1K to 3.7K(-R)(-C)

FR-S520-0.1K to 3.7K-NA(R)

FR-S520S-0.1K to 1.5K(-R)

FR-S520S-0.2K to 1.5K-EC(R)

Thank you for choosing this Mitsubishi Transistorized inverter. If this is the first time for you to use the FR-S500 series, please read through this instruction manual (basic) carefully and use the inverter safely. If you are going to use the inverter for higher-level applications, the FR-S500 instruction manual (detailed) [IB(NA)-0600027] is separately available from where you purchased the inverter or your Mitsubishi sales representative.

CONTENTS

1. CONNECTION OF PERIPHERAL DEVICES	2
2. INSTALLATION METHOD	4
3. SPECIFICATIONS OF WIRING AND TERMINALS	5
4. OPERATION/CONTROL	15
5. ADJUSTMENT OF THE FREQUENCY SETTING	
POTENTIOMETER AND INDICATOR	21
6. FUNCTION LIST	25
7. ERRORS AND PROTECTIVE FUNCTIONS	37
8. SPECIFICATIONS	40
9. OUTLINE DRAWINGS	44
Appendix 1 Instructions for Compliance with the European	
Standards	46
Appendix 2 Instructions for compliance with U.S. and Canadian	
Electrical Codes	48

This instruction manual (basic) provides handling information and precautions for use of the equipment.

Please forward this instruction manual (basic) to the end user.

This instruction manual uses the International System of Units (SI). The measuring units in the yard and pound system are indicated in parentheses as reference values.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through this instruction manual (basic) and appended documents carefully and can use the equipment correctly. Do not use the inverter until you have a full knowledge of the equipment, safety information and instructions.

In this instruction manual (basic), the safety instruction levels are classified into "WARNING" and "CAUTION".



Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

1. Electric Shock Prevention

⚠ WARNING

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover removed. Otherwise, you may access the exposed high-voltage terminals or the charging part of the circuitry and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, check for residual voltages with a meter etc. more than 10 minutes after power-off.
- Earth the inverter.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.
- Perform setting dial and key operations with dry hands to prevent an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.
- Do not change the cooling fan while power is on.
 It is dangerous to change the cooling fan while power is on.
- When you have removed the front cover, do not touch the connector above the 3-digit monitor LED display. Doing so can cause an electric shock.

⚠ CAUTION

- Mount the inverter to incombustible material. Mounting it to or near combustible material can cause a fire.
- If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.
- Do not connect a resistor directly to the DC terminals P(+), N(-). This could cause a fire.

3. Injury Prevention

! CAUTION

- Apply only the voltage specified in the instruction manual to each terminal to prevent damage etc.
- Ensure that the cables are connected to the correct terminals. Otherwise, damage etc. may occur.
- Always make sure that polarity is correct to prevent damage etc.
- While power is on and for some time after power-off, do not touch the inverter or brake resistor as they are hot and you may get burnt.

4. Additional instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and installation

A CAUTION

- When carrying products, use correct lifting gear to prevent injury.
- Do not stack the inverter boxes higher than the number recommended.
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the Instruction Manual.
- Do not operate if the inverter is damaged or has parts missing.
- When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the inverter.
- Check the inverter mounting orientation is correct.
- Prevent screws, wire fragments, other conductive bodies, oil or other flammable substances from entering the inverter.
- Do not drop the inverter, or subject it to impact.

♠ CAUTION

• Use the inverter under the following environmental conditions:

Coo the involter dider the fellowing driving invitation diderie.			
Environment	Ambient temperature	-10°C to + 50°C (14°F to 122°F) (non-freezing)	
	Ambient humidity	90%RH or less (non-condensing)	
	Storage temperature	-20°C to +65°C (-4°F to 149°F) *	
	Ambience	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)	
	Altitude, vibration	Maximum 1000m (3280.80feet) above sea level for standard operation. After that derate by 3% for every extra 500m (1640.40feet) up to 2500m (8202.00feet) (91%). 5.9m/s ² or less (conforming to JIS C0911)	

^{*}Temperatures applicable for a short time, e.g. in transit.

(2) Wiring

! CAUTION

- Do not fit capacitive equipment such as power factor correction capacitor, radio noise filter or surge suppressor to the output of the inverter.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the motor.

(3) Trial run

⚠ CAUTION

 Check all parameters, and ensure that the machine will not be damaged by a sudden start-up.

(4) Operation

A WARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after an alarm stop.
- The [STOP] key is valid only when the appropriate function setting has been made. Prepare an emergency stop switch separately.
- Make sure that the start signal is off before resetting the inverter alarm. A
 failure to do so may restart the motor suddenly.
- The load used should be a three-phase induction motor only. Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.

A CAUTION

- The electronic overcurrent protection does not guarantee protection of the motor from overheating.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter.
- Use a noise filter to reduce the effect of electromagnetic interference.
 Otherwise nearby electronic equipment may be affected.
- Take measures to suppress harmonics. Otherwise power harmonics from the inverter may heat/damage the power capacitor and generator.
- When parameter clear or all clear is performed, each parameter returns to the factory setting. Re-set the required parameters before starting operation.
- The inverter can be easily set for high-speed operation. Before changing its setting, fully examine the performances of the motor and machine.
- In addition to the inverter's holding function, install a holding device to ensure safety.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.

(5) Emergency stop

⚠ CAUTION

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.
- (6) Maintenance, inspection and parts replacement

♠ CAUTION

- Do not carry out a megger (insulation resistance) test on the control circuit of the inverter.
- (7) Disposing of the inverter

! CAUTION

- Treat as industrial waste.
- (8) General instructions


Many of the diagrams and drawings in this instruction manual (basic) show the inverter without a cover, or partially open. Never run the inverter in this status. Always replace the cover and follow this instruction manual (basic) when operating the inverter.

Japanese Power Supply Harmonic Suppression Guideline

The "harmonic suppression guideline for household appliances and general-purpose products" issued by the Ministry of International Trade and Industry in September, 1994 applies to the FR-S500 series. By installing the FR-BEL or FR-BAL power factor improving reactor, this product complies with the "harmonic suppression techniques for transistorized inverters (input current 20A or less)" established by the Japan Electrical Manufacturers' Association.

Product Checking and Parts Identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.



 Removal and reinstallation of the front cover Remove the front cover by pulling it toward you in the direction of arrow.

To reinstall, match the cover to the inverter front and install it straight.


 Removal and reinstallation of the wiring cover The cover can be removed easily by pulling it toward you.

To reinstall, fit the cover to the inverter along the guides.



Wiring cover

< Type with RS-485 communication function > When using the RS-485 connector to wire the cable, you can cut off the lug of the wiring cover to wire it. (Cutting off the lug provides protective structure IP10.)



CAUTION

The connector above the operation panel is for manufacturer use. Do not touch it as doing so may cause an electric shock.



CONNECTION OF PERIPHERAL DEVICES

1.1 Basic Configuration



Power supply

Use within the permissible power supply specifications of the inverter. (Refer to page 40.)



No-fuse breaker or earth leakage circuit breaker

The breaker must be selected carefully since an in-rush current flows in the inverter at power-on.



Magnetic contactor

Do not use this magnetic contactor to start and stop the inverter. Doing so will cause the inverter life to be shorter.



Installation of reactors

The reactors must be used when the power factor is to be improved or the inverter is installed near a large power supply system (500kVA or more and wiring distance within 10m (32.81feet)). Make selection carefully.



The inverter life is influenced by ambient temperature. The ambient temperature should be as low as possible within the permissible range. (Refer to page 42.)





Wrong wiring might lead to inverter damage. The control signal lines must be kept fully away from the main circuit to protect them from noise. (Refer to page 5.)



Devices connected to the output

Do not connect a power capacitor, surge suppressor or radio noise filter to the output side.

Earth (Ground) Earth (Ground)

To prevent an electric shock, always ground the motor and inverter.

For reduction of induction noise from the power line of the inverter, it is recommended to wire the ground cable by returning it to the ground terminal of the inverter. (For details of noise reduction techniques, refer to the instruction manual (detailed).)

Selection of peripheral devices (Selection changes with the power supply input specifications of the inverter.)

- FR-S520-0.1K to 3.7K(-R)(-C)
- FR-S520-0.1K to 3.7K-NA(R)

Matar		No-Fuse Breaker	(er Power Power) or Factor Factor Magnetic		Cables (mm ²) (*2)		
Motor Output (kW (HP))	Inverter Type	(NFB*1) or Earth Leakage Circuit Breaker (ELB)	Factor Improving AC Reactor	Factor Improving DC Reactor	Magnetic Contactor (MC)	R, S, T	U, V, W
0.1 (1/8)	FR-S520- 0.1K	30AF/5AT	FR-BAL- 0.4K (*3)	FR-BEL- 0.4K (*3)	S-N10	2	2
0.2 (1/4)	FR-S520- 0.2K	30AF/5AT	FR-BAL- 0.4K (*3)	FR-BEL- 0.4K (*3)	S-N10	2	2
0.4 (1/2)	FR-S520- 0.4K	30AF/5AT	FR-BAL- 0.4K	FR-BEL- 0.4K	S-N10	2	2
0.75 (1)	FR-S520- 0.75K	30AF/10AT	FR-BAL- 0.75K	FR-BEL- 0.75K	S-N10	2	2
1.5 (2)	FR-S520- 1.5K	30AF/15AT	FR-BAL- 1.5K	FR-BEL- 1.5K	S-N10	2	2
2.2	FR-S520- 2.2K	30AF/20AT	FR-BAL- 2.2K	FR-BEL- 2.2K	S-N11, S-N12	2	2
3.7 (5)	FR-S520- 3.7K	30AF/30AT	FR-BAL- 3.7K	FR-BEL- 3.7K	S-N20	3.5	3.5

- FR-S520S-0.1K to 1.5K(-R)
- FR-S520S-0.2K to 1.5K-EC(R)

		No-Fuse Breaker Power Power			Cables (mm ²) (*2)		
Motor Output (kW (HP))	Inverter Type	(NFB*1) or Earth Leakage Circuit Breaker (ELB)	Factor Improving AC Reactor	Factor Improving DC Reactor	Magnetic Contactor (MC)	R, S <l1, n=""></l1,>	U, V, W
0.1 (1/8)	FR-S520S- 0.1K	30AF/5AT	FR-BAL- 0.4K (*3)	FR-BEL- 0.4K (*3)	S-N10	2	2
0.2 (1/4)	FR-S520S- 0.2K	30AF/10AT	FR-BAL- 0.4K (*3)	FR-BEL- 0.4K (*3)	S-N10	2	2
0.4 (1/2)	FR-S520S- 0.4K	30AF/10AT	FR-BAL- 0.75K (*3)	FR-BEL- 0.75K (*3)	S-N20	2	2
0.75 (1)	FR-S520S- 0.75K	30AF/15AT	FR-BAL- 1.5K (*3)	FR-BEL- 1.5K (*3)	S-N20	2	2
1.5 (2)	FR-S520S- 1.5K	30AF/20AT	FR-BAL- 2.2K (*3)	FR-BEL- 2.2K (*3)	S-N21	2	2

^{*1} Choose the NFB type to meet the power supply capacity.


^{*2} The size of the cable indicated assumes the wiring length of 20m (65.62feet).

^{*3} The power factor may be slightly lower.

2. INSTALLATION METHOD


2.1 Installation of the Inverter





Fix the front cover and wiring cover after removing them.

Mounting inside enclosure





When containing two or more inverters, install them in parallel and provide cooling measures.


Leave enough clearances and provide cooling measures.

Install the inverter under the following conditions.











Enough clearances



These clearances are also necessary for changing the cooling fan. (1.5K or more)


• The inverter consists of precision mechanical and electronic parts. Never install or handle it in any of the following conditions as doing so could cause an operation fault or failure.



3. SPECIFICATIONS OF WIRING AND TERMINALS

3.1 Terminal connection diagram (Japanese version)

FR-S520-0.1K to 3.7K (-R) (-C)




Remarks

- *1 Only the type with RS-485 communication function
- *2 Not needed when the setting dial is used for calibration. Used when calibration must be made near the frequency meter for such a reason as a remote frequency meter. However, the frequency meter needle may not deflect to full-scale if the calibration resistor is connected. In this case, use this resistor and setting dial together.
- *3 You can switch between the sink and source logic positions. For details, refer to the instruction manual (detailed).
- *4 When the setting potentiometer is used frequently, use a $2W1k\Omega$ potentiometer.

— CAUTION


Keep the signal cables more than 10cm (3.94inches) away from the power cables.


● FR-S520S-0.1K to 1.5K (-R) (-C)



Remarks

- To ensure safety, connect the power input to the inverter via a magnetic contactor and earth leakage circuit breaker or no-fuse breaker, and use the magnetic contactor to switch power on-off.
- The output is three-phase 200V.





^{*} When automatic torque boost is selected in Pr. 98 "automatic torque boost selection (motor capacity)": 30m (98.43feet) maximum.

CAUTION


• The power supply cables must be connected to R, S, T. If they are connected to U, V, W, the inverter will be damaged. (Phase sequence need not be matched.)

(For use with a single-phase power supply, the power supply cables must be connected to R and S.)

 Connect the motor to U, V, W. Turning on the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

3.2 Terminal connection diagram (North America version)

FR-S520-0.1K to 3.7K-NA (R)




Remarks

- *1 Only the type with RS-485 communication function
- *2 You can switch between the sink and source logic positions. For details, refer to the instruction manual (detailed).
- *3 When the setting potentiometer is used frequently, use a 2W1k Ω potentiometer.

CAUTION

Keep the signal cables more than 10cm (3.94inches) away from the power cables.

3.2.1 Layout and wiring of main circuit terminals



* When automatic torque boost is selected in Pr. 98 "automatic torque boost selection (motor capacity)": 30m (98.43feet) maximum.

CAUTION =

- The power supply cables must be connected to R, S, T. If they are connected to U, V, W, the inverter will be damaged. (Phase sequence need not be matched.)
- Connect the motor to U, V, W.
 Turning on the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

<When single-phase power input is provided for three-phase power input inverter (NA version only)>

· Reduce the output current.

reduce the eatput carrent							
FR-S520-□K-NA inverter	0.1	0.2	0.4	0.75	1.5	2.2	3.7
Rated output current (A)	0.4	0.8	1.5	2.5	4.0	5.0	7.0
Power supply capacity (kVA)	0.4	8.0	1.5	2.5	4.5	5.5	9.0
AC input power (kW)	1.1	6.4	4.5	6.4	11.2	12.9	17.4

 Set m9 (Pr. 637) "current detection filter".
 Setting "801" in the manufacturer setting parameter C8 enables you to set the m9 parameter.

CAUTION =

Parameters other than m9 can also be made to be displayed, but never alter these since they are manufacturer setting parameters.


m9 Setting	Description
0	Single-phase power input
(Factory setting)	Three-phase power input

CAUTION =

Always return the C8 parameter to 0 (factory setting) after you have finished the setting of m9.

3.3 Terminal connection diagram (European version)

● FR-S520S-0.2K to 1.5K-EC (R)



Main circuit terminal, ○ Control circuit input terminal, ● Control circuit output terminal

Remarks


- *1 Only the type with RS-485 communication function
- *2 You can switch between the sink and source logic positions. For details, refer to the instruction manual (detailed).
- *3 When the setting potentiometer is used frequently, use a $2W1k\Omega$ potentiometer.
- The output is three-phase 200V.

CAUTION =

- Keep the signal cables more than 10cm (3.94inches) away from the power cables.
- To ensure safety, connect the power input to the inverter via a magnetic contactor and earth leakage circuit breaker or no-fuse breaker, and use the magnetic contactor to switch power on-off.

3.3.1 Layout and wiring of main circuit terminals

● FR-S520S-0.2K, 0.4K, 0.75K-EC (R)



Screw size: M3.5

Recommended cable size: 2mm² (14 AWG)

Crimping terminal: 2-3.5


Screw tightening torque: 1.2 N·m

Overall wiring length: 100m (328.08feet) maximum *

— CAUTION -

If the wiring length of the 0.2K is 30m (98.43feet) or more, reduce the carrier frequency to $1 \mathrm{kHz}$.

● FR-S520S-1.5K-EC (R)



Screw size: M4

Recommended cable size:2mm² (14 AWG)

Crimping terminal: 2-4

Screw tightening torque: 1.5N·m

P Overall wiring length: 100m (328.08feet) maximum *

Remarks

* When automatic torque boost is selected in Pr. 98 "automatic torque boost selection (motor capacity)": 30m (98.43feet) maximum.

CALITION

- For power input wiring, connect L1 to R/L1 of the terminal block and N to S/L2 of the terminal block.
- Connect the motor to U, V, W.
 Turning on the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.
- Do not connect the power supply to U, V and W.

3.4 Main Circuit

3.4.1 Explanation of main circuit terminals

Symbol	Terminal Name	al Name Description	
R, S, T*	AC power input	Connect to the commercial power supply.	
U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.	
N <->	DC voltage	DC voltage common terminal. Not isolated from the power	
14 <->	common	supply and inverter output.	
		Remove the jumper from across terminals P <+> -P1 and	
	improving DC	connect the optional power factor improving DC reactor (FR-	
	reactor connection	BEL).	
<u>+</u>		For grounding the inverter chassis.	
	Laitii (Gibuliu)	Must be earthed.	

^{*} R, S, <L1, N> terminals for single-phase power input.

- CAUTION

< > Terminal names in parentheses are those of the EC version.

3.5 Control Circuit

3.5.1 Explanation of control circuit terminals


	Symbol		Terminal Name		Description		
	put	STF	Forward rotation start Reverse rotation	Turn on the STF signal to start forward rotation and turn it off to stop. Turn on the STF signal to start reverse rotation		mand is given if STF gnal turn ON at the The terminal function changes with the	
	Contact input	RH RM RL	Multi-speed selection	and turn it off to stop. You can select multiple shorting any of terminals and RL signal. The priorities of the spectommands are in order multi-speed setting (RH,	s RH, RM ed of jog,	setting of input terminal function selection (Pr. 60 to Pr. 63). (*4)	
		SD *1)	REX) and AU. Contact input common (sink) REX) and AU. Common terminal for contact inputs (terminals STF, ST RH, RM, RL) and indicator connection (terminal FM). Isolated from terminals 5 and SE.				
Input signals	External transistor common PC 24VDC power supply (*1) Supply Contact input		24VDC power supply	When connecting the transistor output (open collector output) of a programmable controller (PLC) etc., connect the positive external power supply for transistor output to this terminal to prevent a malfunction due to leakage current. It can be used as a 24V 0.1A DC power supply across PC-SD terminals. Acts as the common terminal of the contact input signals when source logic is selected.			
	10 Frequency setting		Frequency setting power supply				
	Inputting 0 to 5VDC (0 to 10V) provides the maxim output frequency at 5V (10V) and makes input and proportional.		kes input and output				
	Frequency setting	4	Frequency setting (Current signal)	Input 4 to 20mA DC. Far and 60Hz <50Hz for EC permissible input curren approximately. 250Ω. Turn ON signal AU for c Use any of Pr. 60 to Pr. selection) to set the AU	version> at 2 t 30mA. Inpu urrent input. 63 (input ter	0mA. Maximum ut resistance	

Symbol Terminal Name Description				Terminal Name	De	scription		
Input signals		5		Frequency setting input common	Common terminal for the frequency setting signals (terminals 2, 4) and indicator connection (terminal AM). Isolated from terminals SD and SE. Do not connect this terminal to the ground.			
		A B C		Alarm output	1 contact output which indicates that the protective function of the inverter is activated to stop output. 230V 0.3A AC, 30V 0.3A DC. No conduction across B-C (conduction across A-C) when alarm (error) state. Conduction across B-C (no conduction across A-C) when normal. (*6) The terminal function changes with setting of output terminal function conduction (Pr. 64, Pr. 65)			
Output signals	Open collector	R	UN	Inverter running	Low when the inverter output frequency is the starting frequency or higher (factory-set to 0.5Hz and changeable), and High during stop or DC injection brake operation (*2). Permissible load 24V 0.1A DC			
Outp	•	SE		Open collector common	Common terminal for inversional for inversional from terminals 5 a		ninal RUN.	
	Indicator	Pulse	FM <japanese></japanese>	For meter	One selected from output frequency and motor current is output. The output signal is proportional to the	Frequency	load current 1mA	
	Indi	Analog	AM <na, ec=""></na,>	Analog signal output	magnitude of each monitoring item. Factory setting of Frequency Output signal 0 Permissible loa			
Communication			-	RS-485 connector (*3)	Using the parameter unit connection cable (FR-CB201 205), the parameter unit (FR-PU04) can be connected. Communication operation can be performed using RS-		e connected.	

- *1. Do not connect terminals SD and PC each other or to the ground.

 For sink logic, terminal SD acts as the common terminal of contact input. For source logic, terminal PC acts as the common terminal of contact input.
- *2. Low indicates that the open collector output transistor is on (conducts). High indicates that the transistor is off (does not conduct).
- *3. Compatible with only the type having the RS-485 communication function. For details, refer to the separately available instruction manual (detailed).
- *4. RL, RM, RH, RT, AU, STOP, MRS, OH, REX, JOG, RES, X14, X16, (STR) signal selection
- *5. RUN, SU, OL, FU, RY, Y12, Y13, FDN, FUP, RL, LF, ABC signal selection
- *6. For compatibility with the European Directive (Low Voltage Directive), the operating capacity of relay output (A, B, C) should be 30V, 0.3A DC.

3.5.2 Arrangement and wiring of control circuit terminals



^{*}For the bar terminal, refer to the instruction manual (detailed).

3.5.3 Connection to RS-485 connector (only the inverter with RS-485 communication function)

(1) When connecting the parameter unit (FR-PU04)

Use the optional FR-CB2□.

(2) RS-485 communication

Use the RS-485 connector to perform communication operation from a personal computer etc. By connecting the RS-485 connector to a computer such as a personal computer, Factory Automation or other computer, by the communication cable, you can operate/monitor the inverter and read/write the parameter values using user programs. For further details, refer to the instruction manual (detailed).

• Standard with which RS-485 connector conforms: EIA Standard RS-485

• Transmission format : Multi-drop link


Communication speed: Maximum 19200 bps
 Overall extension : 500m (1640.42feet)

= CAUTION =

Do not plug the connector to a computer LAN board, fax modem socket, telephone modular connector etc. As they are different in electrical specifications, the inverter may be damaged.

4. OPERATION/CONTROL

<Control panel>




*RUN indication On: Indicates that forward rotation operation is being performed.


Slow flickering (1.4 s cycle): Indicates reverse rotation.

Fast flickering (0.2 s cycle): Indicates that operation is not being performed but the RUN key was pressed or the start command was given.

<Basic operation> (Factory setting)




4.1 Setting the Frequency to Perform Operation (Example: Performing Operation at 30Hz)



- $\ref{eq:constraint}$ Operation cannot be performed at the set frequency ... Why?
 - © Did you carry out step 4 within 5 seconds after step 3? (Did you press the set) key within 5 seconds after turning the dial?)
- ? Setting of higher than 60Hz cannot be made ... Why?
 - Check to see if the Pr. 1 "maximum frequency" setting is 60Hz.
- ? The frequency does not change by turning the dial ... Why?
 - Check to see if the operation mode selected is the external operation mode.

Remarks





(For an operation example, refer to the instruction manual (detailed).)

4.2 Setting the Parameters

4.2.1 Example: Changing the Pr. 7 setting from "5s" to "10s" (For parameter details, refer to the instruction manual (detailed).)

· Display Operation -1. Confirm the RUN indication and operation 0.0mode indication. • The inverter must be at a stop. • The inverter must be in the PU operation mode. (Press the $\frac{PU}{EXT}$ key.) The parameter 2. Press the (MODE) key to choose number read the parameter setting mode. previously appears. 3. Turn the setting dial () until the desired parameter number appears. Example: Pr. 7 "acceleration time" 4. Press the (SET) key to read the currently set value. Example: "5" (factory setting) appears. 5. Turn the setting dial (2) until the desired value appears. Example: To change setting from "5" to "10" **6.** Press the (SET) key to set the value. Flicker ... Parameter setting complete!!

- By turning the setting dial (), you can read another parameter.
- Press the (SET) key to show the setting again.
- Press the (SET) key twice to show the next parameter.

After parameter setting is complete, press the history or twice to return to the monitor display. To change the setting of another parameter, perform the operation in above steps 3 to 6.

? Error display?

- \mathcal{E}_r ! If write was performed with "1" set in Pr. 77
 - If the operation panel does not have the write precedence (only for the type with RS-485 function)
- ε- ≥ If write was performed during operation
 - If write was performed in the external operation mode


Remarks

- If the setting has not been changed, the value does not flicker and the next parameter number appears.
- Either step 1 or 2 may be carried out first.
- · Convenient usage

You can read the parameter number and set value in order without needing to choose the parameter setting mode in steps 1 and 2 and press the key after showing the desired parameter number.

4.2.2 Example: Changing the Pr. 30 setting from "0" to "1"

(The extended parameters are made valid by setting "1" in Pr. 30 "extended function display selection". Refer to page 27 for the extended function parameter list and to the instruction manual (detailed) for details.)



- By turning the setting dial (), you can read another parameter.
- Press the (SET) key to show the setting again.
- Press the (SET) key twice to show the next parameter.

After parameter setting is complete, press the (MODE) key once to show the alarm history or twice to return to the monitor display. To change the setting of another parameter, perform the operation in above steps 3 to 6.

? Error display?

- ⟨F ∈ r : If the operation panel does not have the write precedence (only for the content of the con the type with RS-485 communication function)
- ⊕ E ∈ ≥ If write was performed during operation
 - If write was performed in the external operation mode

Remarks

If the setting has not been changed, the value does not flicker and the next parameter number appears.

4.3 Clearing the Parameters

POINT

- The clear parameter CLr is an extended parameter. Set "1" in Pr. 30 and turn the dial to show it. (Refer to page 18.)
- The parameters can be cleared by setting "1" in CLr "parameter clear".

Operation -Display. 1. Confirm the RUN indication and operation mode indication. 0.0 The inverter must be at a stop. •The inverter must be in the PU operation mode. (Press the $\left(\frac{PU}{FXT}\right)$ key.) The parameter\ 2. Press the (MODE) key to choose the number read parameter setting mode. previously appears. 3. Turn the setting dial (2) until CLr "clear" appears. The Pr. 30 value must be "1". (Refer to steps 3 to 6 on page 18 for the parameter setting method.) 4. Press the (SET) key to show "0". 5. Turn the setting dial (2) to change it to "1". 6. Press the (SET) key.

Flicker ... Parameter clear complete!!

- By turning the setting dial O, you can read another parameter.
- Press the (SET) key to show Pr. 0 (P []).

CLr Setting	Description			
0	Not executed.			
1	Parameter clear *1			
1	(Calibration parameters C1 to C7 are not cleared.)			
	All clear *2			
10	(All set values including those of calibration parameters			
	C1 to C7 are returned to factory settings.)			

- *1. Parameters are not cleared when "1" is set in Pr. 77 "parameter write disable selection".
 - Pr. 75 "reset selection/PU stop selection", Pr. 38, Pr. 39, Pr. 53, Pr. 60 to Pr. 65, Pr. 99, calibration parameters C1 to C7 and communication parameters n13, 15 are not cleared.
- *2. Pr. 75 "reset selection/PU stop selection" and communication parameter n13 "PU language switching" are not cleared.

4.4 Monitoring the Output Current

output frequency monitor mode.

The output current appears while the SET key is pressed in the monitor mode.

Operation — Display—

1. Press the HODE key to choose the output frequency monitor mode.

2. Independently of whether the inverter is running in any operation mode or at a stop, the output current appears while the SET key is pressed.

3. Release the SET key to return to the

Remarks


When Pr. 52 = "1", the output current is displayed in the monitor mode and the output frequency appears while the (SET) key is pressed.

5. ADJUSTMENT OF THE FREQUENCY SETTING POTENTIOMETER AND INDICATOR

Related parameters

Parameter	Name	Setting Range	Factory Setting <ec version=""></ec>
38	Frequency setting voltage gain frequency	1 to 120Hz	60Hz <50Hz>
39	Frequency setting current gain frequency	1 to 120Hz	60Hz <50Hz>
C2	Frequency setting voltage bias frequency	0 to 60Hz	0Hz
C3	Frequency setting voltage bias	0 to 300%	0%*
C4	Frequency setting voltage gain	0 to 300%	96%*
C5	Frequency setting current bias frequency	0 to 60Hz	0Hz
C6	Frequency setting current bias	0 to 300%	20%*
C7	Frequency setting current gain	0 to 300%	100%*

^{*} Settings may differ because of calibration parameters.



* Pr. 73 "0-5V/0-10V selection" changes the specifications of terminal "2".

POINT

- Bias setting for 0 to 5VDC (0 to 10VDC) input: Use the calibration parameter C2, C3 for setting.
- Gain setting for 0 to 5VDC (0 to 10VDC) input: Use Pr. 38, calibration parameter C4 for setting.
- Bias setting for 4 to 20mADC input: Use calibration parameter C5, C6 for setting.
- Gain setting for 4 to 20mADC input: Use Pr. 39, calibration parameter C7 for setting.

(For 4 to 20mADC input, set "4" in any of Pr. 60 to Pr. 63 (input terminal function selection) and assign AU (current input selection) to any of terminals RH, RM, RL and STR.

5.1 Changing the Output Frequency Setting of the Frequency Setting Potentiometer (Bias and gain of frequency setting voltage (current))

POINT

 Pr. 38, Pr. 39 and calibration parameters "C1 to C7" can be made to be read by setting "1" (extended function parameter valid) in Pr. 30 "extended function display selection".

The bias/gain of the frequency setting voltage (current) may be adjusted in any of the following methods:


1) Changing the highest frequency

- 2) Adjusting the deviation of the highest frequency from the Pr. 38 (Pr. 39) setting.
 - 2)-1 Make adjustment with a voltage applied directly across terminals 2-5 (with a current flowing across terminals 4-5)
 - 2)-2 Make adjustment at any point without a voltage applied across terminals 2-5 (without a current flowing across terminals 4-5) (For the setting method, refer to the instruction manual (detailed).)

Changing example When you want to use the 0 to 5VDC input frequency setting potentiometer to change the 5V-time frequency from 60Hz to 50Hz

POINT

- Pr. 38 is an extended function parameter. Pr. 30 must be set to "1". (Refer to page 18.)
- Change Pr. 38 "frequency setting voltage gain frequency" to 50Hz.
- 1) Changing the highest frequency.



currently set value. (60Hz)

5. Turn the setting dial (1) to change the set value to "50.0". (50Hz)

6. Press the (SET) key to set the value.

Flicker ... Parameter setting complete!!

- By turning the setting dial O, you can read another parameter.
- Press the (SET) key to show the setting again.
- Press the (SET) key twice to show the next parameter.

$\it ?$ The monitor/frequency setting indication cannot be changed to just 50Hz ... Whv?

The calibration parameter C4 "frequency setting voltage gain" value must be set. (Refer to page 23.)

Remarks

To change the value to more than 60Hz <50Hz>, Pr. 1 "maximum frequency" must be set to more than 60Hz <50Hz>.

Changing example Changing the calibrate voltage gain	ation parameter C4 "frequency setting
POINT	
The calibration parameter C4 is an ext set to "1".	ended function parameter. Pr. 30 must be
Adjusting a deviation of the highest fr 2)-1 Making adjustment with a voltage (with a current flowing across ter)	*
Operation —	——Display——
 1. Confirm the RUN indication and operation mode indication. The inverter must be at a stop. The inverter must be in the PU operation mode. (Press the PU key.) 	n
2. Press the hope key to choose the parameter setting mode.	The parameter number read
3. Turn the setting dial () until	previously
"C "appears. Pr. 30 must be set to "1". (For details, refer to steps 3 to 6 on page	\appears. /
4. Press the SET key to show "L" - "	⇒ [:-
When adjusting Pr. 38	
5. Turn the setting dial Ountil the calibration parameter C4 "frequency setting voltage gain"	
appears. 6. Press the (SET) key to show the analog voltage analog-to-digital conversion value (%).	Analog voltage analog-to-digital conversion value (%) across
7. Apply a 5V voltage. (Turn the external potentiometer connected to across terminals 2-5 to the maximum (any position).)	*The value is nearly 100 (%) in the maximum position of the potentiometer.
After performing operation in step 7, do not tou	uch the setting dial until completion of calibration.
8. Press the (SET) key to set the value. (SET)	⇒ 100 ° € Y
Flick	er Parameter setting complete!!

(Adjustment complete) *The value is nearly 100 (%) in

the maximum position of the potentiometer.

- By turning the setting dial (), you can read another parameter.
- Press the (SET) key to return to the "____ -" indication (step 4).
- Press the (SET) key twice to show the next parameter ([]. -).
- ? The frequency meter (indicator) connected to across terminals FM-SD (AM-5) does not indicate just 50Hz ... Why?
 P The calibration parameter C1 "FM (AM) terminal calibration" value must be set. (Refer to
- ? When write is performed, an error ($\mathcal{E} \cap \mathcal{E}$) is displayed.
 - The gain and bias frequency settings are close.

5.2 Adjustment (Calibration) of the Frequency Meter (Indicator)

Changing example Deflecting the meter (Analog indicator) to full-scale (Across FM-SD: 1mA, across AM-5: 5V) at 60Hz

POINT

- The calibration parameters "C1" can be made to be read by setting "1" (extended function parameter valid) in Pr. 30 "extended function display selection".
- Set the value of the calibration parameter C1 "FM (AM) terminal calibration".

Operation-Display 1. Confirm the RUN indication and operation 0.0 mode indication. • The inverter must be at a stop. The parameter 2. Press the (MODE) key to choose the number read $\overline{0}$ parameter setting mode. previously appears. 3. Turn the setting dial (2) to show Pr. 30 must be set to "1". (For details, refer to steps 3 to 6 on page 18.) 4. Press the (SET) key to show 5. Turn the setting dial (2) until the calibration parameter C1 "FM (AM) terminal calibration" appears. 6. Press the (SET) key to enable setting. 7. Press the (RUN) key to start the RUN inverter. (The motor need not be connected.) 8. Turn the setting dial (2) to Analog indicator adjust the indicator needle to the desired position. 800 9. Press the (SET) key.

Flicker ... Parameter setting complete!!

- By turning the setting dial O, you can read another parameter.
- Press the (SET) key to return to the "
 -" indication (step 4).
- Press the (SET) key twice to show the next parameter ([] _ _).

Remarks

- Depending on the set value, it may take some time for the needle to move.
- If "1" is set in Pr. 30 "extended function display selection", the calibration parameter C1 "FM (AM) terminal calibration" can also be set in the external operation mode.

POINT

Setting is complete.

By setting the Pr. 54 "FM (AM) terminal function selection" value, preset Pr. 55 "frequency monitoring reference" or Pr. 56 "current monitoring reference" to the running frequency or current value at which the output signal is 1440 pulses/s (5V). At 1440 pulses/s (5V), the meter generally deflects to full-scale.

6. FUNCTION LIST

6.1 Basic Function Parameter List

Pa- rame- ter	Name		ica- on	Setting Range	Minimum Setting Increments	Factory Setting <ec version=""></ec>	Customer Setting
0	Torque boost	Ç.	0	0 to 15%	0.1%	6%	
1	Maximum frequency	P	1	0 to 120Hz	0.1Hz	60Hz <50Hz>	
2	Minimum frequency	P	<u> </u>	0 to 120Hz	0.1Hz	0Hz	
3	Base frequency	P	3	0 to 120Hz	0.1Hz	60Hz <50Hz>	
4	Multi-speed setting (high speed)	P	4	0 to 120Hz	0.1Hz	60Hz <50Hz>	
5	Multi-speed setting (middle speed)	9	5	0 to 120Hz	0.1Hz	30Hz	
6	Multi-speed setting (low speed)	Q.	6	0 to 120Hz	0.1Hz	10Hz	
7	Acceleration time	Q.	7	0 to 999s	0.1s	5s	
8	Deceleration time	7	8	0 to 999s	0.1s	5s	
9	Electronic thermal O/L relay	9	9	0 to 50A	0.1A	Rated output current	
30	Extended function display selection	P	30	0, 1	1	0	
79	Operation mode selection	9	79	0 to 4, 7, 8	1	0	

Remarks


- The extended function parameters are made valid by setting "1" in Pr. 30 "extended function display selection". (Refer to page 18)
- The decimal places of a value of 100 or more (3 digits or more) cannot be set to be displayed.

6.2 Explanation of the Basic Function Parameters

For details, refer to the instruction manual (detailed) separately available.


Pr. 0 "torque boost"

- Allows the motor torque in the low speed range to be adjusted according to the load.
 Make adjustment when stall prevention is operated when starting.
- When a constant-torque motor is used, set the following value:
 - 0.1K to 0.75K6%



Pr. 1 "maximum frequency", Pr. 2 "minimum frequency"

 Clamp the upper and lower limits of the output frequency.




Pr. 3 "base frequency"

 Set the base frequency (reference frequency at rated motor torque) within the range 0 to 120Hz according to the motor.

Pr. 7 "acceleration time", Pr. 8 "deceleration time"

 As the acceleration time, set the time taken to reach the acceleration/deceleration reference frequency in Pr. 20 from 0Hz, and as the deceleration time, set the time taken to reach 0Hz from the Pr. 20 value.



Pr. 30 "extended function display selection"

 Set this parameter when showing/setting the extended function parameters.

Setting	Description
0	Only basic functions are displayed.
1	All parameters are displayed.

Pr. 4 "multi-speed setting (high speed)" Pr. 5 "multi-speed setting (middle speed)" Pr. 6 "multi-speed setting (low speed)"

 You can select any speed (RH, RM, RL) by simply changing the external contact signal.

	RH	RM	RL
High speed	ON	OFF	OFF
Middle speed	OFF	ON	OFF
Low speed	OFF	OFF	ON

- Each speed (frequency) can be set to any value within the range 0 to 120Hz if the inverter is running.
- The extended functions enable setting of up to 15 speeds.

Pr. 9 "electronic thermal O/L relay"

- You can set a current value for protection of the motor from overheat.
 Normally, set the rated motor current at 50Hz as it is.
- At the setting of 0A, motor protection does not function. (The output transistor protection of the inverter functions.)
- When connecting multiple motors to the inverter, provide external thermal relays to individual motors.
- For the 0.1K to 0.75K, this value is factory-set to 85% of the rated inverter current.

Pr. 79 "operation mode selection"

 The inverter has two different operation modes: operation under control of external signals and operation from the PU (setting dial, RUN key). You can use either or both operation modes.

Setting	Description		
0	PU (setting dial, RUN key) operation or external operation can be selected by the PU key.		
1	Only PU (setting dial, RUN key) operation may be perfe	ormed.	
2	Only external operation may be performed.		
	Running frequency	Start signal	
3	 Setting made by setting dial Multi-speed selection 4 to 20mA (Made valid when AU signal turns on) 	External terminal (STF/STR)	
_	Running frequency	Start signal	
4	External terminal signals (multi-speed, 0 to 5VDC, etc.)	RUN key	
7	PU operation interlock (Switching to PU operation mode is enabled/disabled by turning MRS signal ON/OFF)		
8	Operation mode external signal switching (disabled during operation) Turn X16 signal ON/OFF to choose operation mode.		

6.3 EXTENDED FUNCTION PARAMETER LIST

Setting "1" in Pr. 30 "extended function display selection" makes the extended function parameters valid. (Refer to the separately available instruction manual (detailed).)

		10 (1.10.10.10.10.10.1	separately avaliable instruction manual (details	, ,	
	meter Indica- tion	Name	Outline	Factory Setting <ec version=""></ec>	
For parameters 0 to 9, refer to the basic function parameters.					
10	P 10	DC injection brake operation frequency	Set the timing of switching to DC injection brake (0 to 120Hz), the time to apply DC	3Hz	
11	P ! !	DC injection brake operation time	injection brake (0 to 10s), and the braking torque at DC injection brake start (0 to 15%).	0.5s	
12	P 12	DC injection brake voltage	(Set Pr. 12 to 4% when a constant-torque motor is used.)	6%	
13	P 13	Starting frequency	Frequency which is output by the inverter first at a start and gives great influence to the starting torque. About 1 to 3Hz for vertical lift applications, or up to 5Hz to the maximum. For other than vertical lift applications, factory setting of about 0.5Hz is recommended. 0 to 60Hz	0.5Hz	
14	Р 14	Load pattern selection	 Choose the output frequency and output voltage patterns according to the application (load characteristic). O: For constant-torque loads (when relatively large torque is needed at low to high speeds) 1: For variable-torque loads (for applications where torque is small at low speed, e.g. fans and pumps) 2: For vertical lifts (for elevators at reverse rotation boost of 0%) 3: For vertical lifts (for elevators at forward rotation boost of 0%) 	0	
15	P 15	Jog frequency	Speed command (0 to 120Hz) and	5Hz	
16	P 16	Jog acceleration/ deceleration time	acceleration/deceleration slope (0 to 999s) for jog (inching) operation	0.5s	
17	P 17	RUN key rotation direction selection	The Run key of the operation panel can be used to choose the direction of rotation for operation. O: forward rotation, 1: reverse rotation	0	
19	P 19	Base frequency voltage	Indicates the magnitude of the output voltage at the base frequency (Pr. 3). 888: 95% of power supply voltage: Same as power supply voltage 0 to 500V, 888,	 <888>	
20	P20	Acceleration/ deceleration reference frequency	Indicates the frequency to be referenced for acceleration from or deceleration to 0Hz in the time set in Pr. 7 "acceleration time" or Pr. 8 "deceleration time". 1 to 120Hz	60Hz <50Hz>	

Para	meter			Factory
	Indica- tion	Name	Outline	Setting <ec Version></ec
21	P2 I	Stall prevention function selection	Stall prevention is a function designed to suspend a frequency increase during acceleration or suspend a frequency decrease during deceleration if the preset current (0 to 200%) is exceeded, in order to prevent an overcurrent alarm.	0
22	P22	Stall prevention operation level	Pr. 21 allows you to select whether to use stall prevention or not according to the acceleration/deceleration status. If the Pr. 22 value is set to 170% or more, torque will not be developed. In that case, set "1" in Pr. 21.	150%
23	P23	Stall prevention operation level compensation factor at double speed	Used to reduce the stall prevention level at or above the base frequency. Setting other than "" specifies the current level at 120Hz which is lower than the Pr. 22 value of the stall prevention level at base frequency. 0 to 200%,	
24	P24	Multi-speed setting (speed 4)	Setting other than "" specifies speeds 4 to 7. By combining ON and OFF of the contact signals (RH, RM, RL signals), the running	
25	P25	Multi-speed setting (speed 5)	speed can be changed step-by-step. RH RM RL	
26	P26	Multi-speed setting (speed 6)	Speed 4 OFF ON ON	
27	PZN	Multi-speed setting (speed 7)	Speed 6 ON ON ON ON ON O to 120Hz,	
28	P28	Stall prevention operation reduction starting frequency	You can reduce the stall prevention level in the high frequency range. 0 to 120Hz	60Hz <50Hz>
29	P29	Acceleration/ deceleration pattern	Used to determine the frequency changing pattern at acceleration/deceleration. 0: Linear acceleration/deceleration 1: S-pattern acceleration/deceleration A (e.g. machine tool spindle applications) 2: S-pattern acceleration/deceleration B (e.g. load collapse preventing applications for conveyors and so on)	0
			sic function parameters.	ı
31		Frequency jump 1A	0.44 - 6	
32		Frequency jump 1B	Tool the hoqueries range you mant to evade	
33	<i>Р33</i> Р3Ч	Frequency jump 2A	during constant-speed operation to avoid resonance with a machine.	
35	P35	Frequency jump 2B Frequency jump 3A	o to 120Hz,	
36	P35	Frequency jump 3B	0 10 120112,	
37	P37	Speed display	You can convert the frequency monitor/set frequency of the operation panel into the load speed and display it. Setting 0 shows the output frequency, and setting 0.1 to 999 shows the load speed. (Set the speed for 60Hz operation.) 0, 0.1 to 999	0

Para	meter			Factory
	Indica- tion	Name	Outline	Setting <ec Version></ec
38	P38	Frequency setting voltage gain frequency	You can set as desired the magnitude (slope) of the output frequency to the external frequency setting voltage signal (0 to 5V or 0 to 10V). 1 to 120Hz	60Hz <50Hz>
39	P39	Frequency setting current gain frequency	You can set as desired the magnitude (slope) of the output frequency to the external frequency setting current signal (4 to 20mA). 1 to 120Hz	60Hz <50Hz>
40	P40	Start-time ground fault detection selection	Set whether a ground fault is to be detected or not at a start. 0: Not detected 1: Detected	0 <1>
41	P4 I	Up-to-frequency sensitivity	You can adjust the ON range of the up-to-frequency signal (SU) to be output when the output frequency reaches the running frequency. You can use this function to ensure that the running frequency has been reached or use it as the operation start signal etc. for related equipment. Use Pr. 64 or Pr. 65 to assign the terminal used for SU signal output. 0 to100%	10%
42	P42	Output frequency detection	Set the reference value at which the signal (FU) is output when the output frequency rises to or above a certain value. This function can be used for electromagnetic brake operation, open signal, etc. Use Pr. 64 or Pr. 65 to assign the terminal used for the FU signal. 0 to 120Hz	6Hz
43	P43	Output frequency detection for reverse rotation	Set the reference value at which the signal (FU) is output when the output frequency rises to or above a certain value. This function is valid for reverse operation. 0 to 120Hz,	
44	РЧЧ	Second acceleration/ deceleration time	Second function for the acceleration/ deceleration time set in Pr. 7 or Pr. 8. 0 to 999s	5s
45	PYS	Second deceleration time	Second function for the deceleration time set in Pr. 8. 0 to 999s,	
46	P48	Second torque boost	Second function for the torque boost set in Pr. 0. 0 to 15%,	
47	ργη	Second V/F (base frequency)	Second function for the base frequency set in Pr. 3. 0 to 120Hz,	
48	Р48	Output current detection level	Set the level at which the output current detection signal (Y12) is output. 0 to 200%	150%
49	P49	Output current detection signal delay time	When the output current is at or above the output current detection level (Pr. 48) for longer than this period (Pr. 49), the output current detection signal (Y12) is output. 0 to 10s	0s

Para	meter			Factory
	Indica-	Name	Outline	Setting <ec< th=""></ec<>
	tion			Version>
50	P50	Zero current detection level	Set the level at which the zero current detection signal (Y13) is output. 0 to 200%	5%
51	PS I	Zero current detection time	When the output current is at or below the zero current detection level (Pr. 50) for longer than this period (Pr. 51), the zero current detection signal (Y13) is output. 0.05 to 1s	0.5s
52	P52	Control panel display data selection	You can choose the data displayed on the operation panel. 0: Output frequency 1: Output current 100: Set frequency during stop/output frequency during operation	0
53	P53	Frequency setting operation selection	You can use the setting dial like a potentiometer to perform operation. 0: Setting dial frequency setting mode 1: Setting dial potentiometer mode	0
54	P54	FM (AM) terminal function selection	You can choose the indicator connected to the FM (AM) terminal. 0: Output frequency monitor 1: Output current monitor	0
55	PSS	Frequency monitoring reference	Set the reference value of frequency monitoring. 0 to 120Hz	60Hz <50Hz>
56	P58	Current monitoring reference	Set the reference value of current monitoring. 0 to 50A	Rated output current
57	<i>P51</i>	Restart coasting time	At power restoration after an instantaneous power failure, you can restart the inverter without the motor being stopped (with the motor coasting). The inverter begins to restart after this period (Pr. 57) has elapsed after power restoration. The inverter does not restart by setting "". "O" setting generally does not pose a problem but	
58	P58	Restart cushion time	you can adjust the time (0 to 5s,) according to the magnitude of the load. When the restart coasting time (Pr. 57) has elapsed, the output voltage is risen gradually. Set this cushion time (0 to 60s). Operation may be performed generally at the factory setting, but you can adjust the time according to the magnitude of the load.	1s
59	P59	Remote setting function selection	You can set the remote setting function which is used when the operation panel is away from the control box, for example. 0: Without remote setting function 1: With remote setting function With frequency setting storage function 2: With remote setting function Without frequency setting storage function	0

	ameter Indica- tion	Name	Outline	Factory Setting
60	P60	RL terminal function selection	You can choose the following input signals: 0: RL (multiple low-speed operation command) 1: RM (multiple middle-speed operation command) 0: RL (multiple bigle speed operation command)	0
61	P6 I	RM terminal function selection	 2: RH (multiple high-speed operation command) 3: RT (second function selection) 4: AU (current input selection) 5: STOP (start self-holding selection) 6: MRS (output stop) 	1
62	P62	RH terminal function selection	7: OH (external thermal relay input) 8: REX (15 multi-speed selection) 9: JOG (jog operation selection) 10: RES (reset) 14: X14 (PID control valid terminal)	2
63	P63	STR terminal function selection	16: X16 (PU operation/external operation switching): STR (reverse rotation start (may be assigned to only STR terminal))	
64	P64	RUN terminal function selection	You can choose the following output signals: 0: RUN (inverter running) 1: SU (up-to-frequency) 3: OL (overload warning) 4: FU (output frequency detection) 11: RY (operation ready) 12: Y12 (output current detection)	0
65	P65	A, B, C terminal function selection	13: Y13 (zero current detection) 14: FDN (PID lower limit signal) 15: FUP (PID upper limit signal) 16: RL (PID forward/reverse rotation signal) 98: LF (minor failure output) 99: ABC (alarm output)	99
66	P66	Retry selection	You can choose the retry alarm to be activated when the protective function is activated. 0: OC1 to 3, OV1 to 3, THM, THT, GF, OHT, OLT, PE, OPT 1: OC1 to 3, 2: OV1 to 3, 3: OC1 to 3, OV1 to 3	0
67	P67	Number of retries at alarm occurrence	You can set the number of retries to be made when the protective function is activated. 0: No retry 1 to 10: Without alarm output during retry operation 101 to 110: With alarm output during retry operation	0
68	P68	Retry waiting time	You can set the waiting time from when the protective function is activated until a retry is made. 0.1 to 360s	1s
69	P69	Retry count display erase	You can display the cumulative number of successful restarts made by retries when the protective function is activated. 0: Cumulative count erase	0

	meter		_	Factory
	Indica- tion	Name	Outline	Setting
70	P70	Soft-PWM setting	You can choose whether Soft-PWM control is to be exercised or not. When Soft-PWM is valid, you can change the metallic motor tone into an unoffending complex tone. 0: Soft-PWM invalid 1: Soft-PWM valid	1
71	ደባ ፣	Applied motor	Set the motor to be used. 0: Thermal characteristic for Mitsubishi standard motor 1: Thermal characteristic for Mitsubishi constant-torque motor	0
72	P72	PWM frequency selection	You can change the PWM carrier frequency. Increasing this value reduces the tone, but increases noise and leakage current. The setting is in [kHz]. 0: 0.7kHz, 15: 14.5kHz 0 to 15	1
73	P73	0-5V/0-10V selection	You can set the input voltage specification of terminal "2". 0: For 0 to 5VDC input 1: For 0 to 10VDC input	0
74	PTY	Input filter time constant	Valid for eliminating noise of the frequency setting circuit. A larger set value increases the time constant.	1
75	PNS	Reset selection/PU stop selection	You can choose the function of the RESET key on the operation panel. 0: Reset normally enabled/PU stop key disabled (In other than PU and combined operation modes) 1: Enabled at reset alarm occurrence only/PU stop key disabled (In other than PU and combined operation modes) 14: Reset normally enabled/normally decelerated to stop 15: Enabled at alarm occurrence only/normally decelerated to stop	14
76	P76	Cooling fan operation selection	You can control the operation of the cooling fan built in the inverter. (Operates in power-on status.) 0: The fan normally operates at power-on of the inverter. 1: The fan is normally on during inverter operation. The fan switches on/off according to the temperature during a stop of the inverter whose status is monitored.	1
77	PTT	Parameter write disable selection	You can choose whether to enable or disable parameter write. 0: Write is enabled only during a stop in the PU operation mode 1: Write disabled (except some parameters) 2: Write during operation enabled (external mode and during operation)	0
78	P78	Reverse rotation prevention selection	You can prevent trouble during reverse operation due to false input of the start signal. 0: Both forward rotation and reverse rotation enabled 1: Reverse rotation disabled 2: Forward rotation disabled	0
For	parame	ter 79, reter to the ba	sic function parameters.	

	meter Indica-		Outline	Factory
	tion			Setting
80	P80	Multi-speed setting (speed 8)	Setting other than "" specifies speeds 8 to 15. By combining ON and OFF of the contact	
81	P8 I	Multi-speed setting (speed 9)	signals (RH, RM, RL, REX signals), the running speed can be changed step-by-step.	
82	289	Multi-speed setting (speed 10)	Use Pr. 63 to assign the REX signal. RH RM RL REX	
83	P83	Multi-speed setting (speed 11)	Speed 8 OFF OFF ON Speed 9 OFF OFF ON ON	
84	P84	Multi-speed setting (speed 12)	Speed 10 OFF ON OFF ON Speed 11 OFF ON ON ON	
85	P85	Multi-speed setting (speed 13)	Speed 12 ON OFF OFF ON	
86	P86	Multi-speed setting (speed 14)	Speed 13 ON OFF ON ON Speed 14 ON ON OFF ON	
87	P81	Multi-speed setting (speed 15)	Speed 15 ON ON ON ON ON	
88	P88	PID action selection	Used to choose the operation of PID control. 20: PID reverse action, 21: PID forward action	20
89	P89	PID proportional band	Used to set the proportional band for PID control. 0.1 to 999%,	100%
90	P90	PID integral time	Used to set the integral time for PID control. 0.1 to 999s,	1s
91	P9 I	PID upper limit	Used to set the upper limit value for PID control. 0 to 100%,	
92	P92	PID lower limit	Used to set the lower limit value for PID control. 0 to 100%,	
93	P93	PID action set point for PU operation	Used to set the PID action set point for PU operation. 0 to 100%	0%
94	Р9Ч	PID differential time	Used to set the differential time for PID control. 0.01 to 10s,	
95	P95	Rated motor slip	Used to set the rated motor slip to make slip compensation. 0 to 50%,	
96	P98	Slip compensation time constant	Used to set the response time of slip compensation. 0.01 to 10s	0.5s
97	Pgn	Constant-output region slip compensation selection	Used to choose whether slip compensation is made or not in the constant-output region. 0,	
98	P98	Automatic torque boost selection (Motor capacity)	You can set the motor capacity and exercise automatic torque boost control. "" specifies V/F control. Set the motor capacity used. • The motor capacity should be equal to or one rank lower than the inverter capacity. • The number of motor poles should be 2, 4 or 6. (Only 4 poles for constant-torque motor) • Single-motor operation (one motor run by one inverter) should be performed. • Wiring length from inverter to motor should be within 30m (98.43feet). When using a constant-torque motor, set "1" in Pr. 71. <example> For 1.5kW, set "1.5". 0.1 to 3.7kW,</example>	
99	P99	Motor primary resistance	You can set the motor's primary resistance value. (Normally, this parameter need not be set.) 0 to 50Ω ,	

	oration			
	meter Indica-	Name	Outline	Factory Setting
	tion			
(AV	<i>[</i> 1:900) 1:901)	FM (AM) terminal calibration	You can calibrate the indicator connected to across terminals FM-SD (AM-5).	
(9	<i>€ ∂</i> 902)	Frequency setting voltage bias frequency	You can set as desired the magnitude (slope) of the output frequency to the external frequency setting voltage signal (0 to 5V or 0 to 10V). (Bias frequency) 0 to 60Hz	0Hz
	<i>€ 3</i> 002)	Frequency setting voltage bias	Used to adjust the analog-to-digital converted voltage value of the frequency set in calibration parameter C4. (Bias %) 0 to 300%	0%*
C4 (9	<u>ЕЧ</u> 903)	Frequency setting voltage gain	Used to adjust the analog-to-digital converted voltage value of the frequency set in Pr. 38. (Gain %) 0 to 300%	96%*
C5 (9	<u>ε 5</u> 904)	Frequency setting current bias frequency	You can set as desired the magnitude (slope) of the output frequency to the external frequency setting current signal (4 to 20mA). 0 to 60Hz	0Hz
	<u>(2 6</u> 104)	Frequency setting current bias	Used to adjust the analog-to-digital converted voltage value of the frequency set in calibration parameter C5. (Bias %) 0 to 300%	20%*
	<u>[7</u> 905)	Frequency setting current gain		
C8 (2	<i>[8</i> 269)	Parameter for manufacturer setting. Do not set.		
CLr	ELr	Parameter clear	O: Not executed 1: Initialization of parameters other than calibration values (parameter clear) 10: Initialization of parameters including calibration values (all clear)	0
ECL	ECL	Alarm history clear	0: Not cleared 1: Alarm history clear	0

^{*}Settings may differ because of calibration parameters.

• Parameters which can be read on only the type having the RS-485 communication function. (When the parameter unit (FR-PU04) is used,

operation from the operation panel is not accepted.)

ca Para	nmuni- ition imeter Indica-	Name	Outline	Factory Setting <na, ec<br="">Version></na,>
	tion			VCI 31011>
(331)		Communication station number	Set the station number for communication from the RS-485 connector. 0 to 31: Specify the station number of the inverter.	0
n2 (3	<i>n 2</i> 332)	Communication speed	48: 4800bps 96: 9600bps 192: 19200bps	192
n3 (3	<i>n ∃</i> 333)	Stop bit length	0: Stop bit length 1 bit/data length 8 1: Stop bit length 2 bits/data length 8 10: Stop bit length 1 bit/data length 7 11: Stop bit length 2 bits/data length 7	1
n4 (3	고 목 334)	Parity check presence/absence	O: Absent : With odd parity check : With even parity check	2
	<u>о 5</u> 335)	Number of communication retries	Set the permissible number of retries at occurrence of a data receive error. " " specifies that the inverter does not come to an alarm stop if a communication error occurs. 0 to 10,	1
n6 (3	<u>а Б</u> 336)	Communication check time interval	Set the interval of communication check time. If a no-communication status persists for longer than the permissible time, the inverter will come to an alarm stop. 0: No communication 0.1 to 999s : Check suspended	0s <>
n7	n 7 337)	Wait time setting	Set the waiting time from when data is transmitted to the inverter until response is made. 0 to 150ms: Set in communication data	
n8 (3	<i>n 8</i> 338)	Operation command write	You can choose whether the operation command is given by the computer or external terminal. 0: Command write from computer 1: Command write from external terminal	0
,	<i>n 9</i> 339)	Speed command write	You can choose whether the speed command is given by the computer or external terminal. 0: Command write from computer 1: Command write from external terminal	0
	<i>n 10</i> 340)	Link start mode selection	You can choose the operation mode at power- on or at power restoration after instantaneous power failure. Set "1" to select the computer link operation mode. 0: Mode set in Pr. 79 is established. 1: Started in computer link mode.	0

Communication Parameter Indication		Name	Outline	Factory Setting <na, ec<br="">Version></na,>	
	<i>□ </i> 341)	CR/LF selection	0: Without CR/LF 1: With CR, without LF 2: With CR/LF	1	
(3	n 1∂ 342)	E ² PROM write selection	0: Write to RAM and E ² PROM 1: Write to RAM only	0	
	л 13 (45)	PU display language	0: Japanese 1: English 2: German 3: French 4: Spanish 5: Italian 6: Swedish 7: Finish	0 <1>	
	л 1Ч 990)	PU buzzer sound control	0: Without sound, 1: With sound	1	
	ი /5 991)	PU contrast adjustment	0 (bright) 63 (dark)	58	
	n 15 992)	PU main display screen data selection	O: Selectable between output frequency and output current 100: Set frequency (during stop) Output frequency (during operation)	0	
	n 17 993)	PU disconnection detection/PU setting lock	O: Without PU disconnection error/PU operation valid 1: Error at PU disconnection/PU operation valid 10: Without PU disconnection error/ PU operation invalid	0	

For details of the program, etc., refer to the instruction manual (detailed) separately available.

Remarks

The parameter numbers within parentheses are those for use of the parameter unit (FR-PU04). Pr. stands for a parameter number.

7. ERRORS AND PROTECTIVE FUNCTIONS

7.1 About Errors (Definitions)

When an alarm occurs in the inverter, the protective function is activated to bring the inverter to an alarm stop and the PU display automatically changes to any of the following error (alarm) indications.

For details, refer to the instruction manual (detailed) which is separately available.

(1) Major failures

Control Panel Indication	Function Name	Definition
[][(OC1)	Overcurrent cut-off during acceleration	The inverter output current rose to or above about 200% of the rated inverter current during acceleration.
<i>[][</i>	Overcurrent cut-off during constant speed	The inverter output current rose to or above about 200% of the rated inverter current during constant-speed operation.
[][] (OC3)	Overcurrent cut-off during deceleration	The inverter output current rose to or above about 200% of the rated inverter current during deceleration.
[] _U	Regenerative overvoltage cut-off during acceleration	Excessive regenerative energy or surge voltage occurred during acceleration.
[]u2 (OV2)	Regenerative overvoltage cut-off during constant speed	Excessive regenerative energy or surge voltage occurred during constant speed.
[] _[] 3 (OV3)	Regenerative overvoltage cut-off during deceleration or stop	Excessive regenerative energy or surge voltage occurred during deceleration or stop.
FHI (THM)	Motor overload cut-off (Electronic thermal overcurrent protection) (*1)	Overload or reduced cooling capability during low-speed operation
[H[(THT)	Inverter overload cut-off (Electronic thermal overcurrent protection) (*1)	Current more than 150% of the rated output current flew and overcurrent shut-off did not occur.
F! n (FIN)	Fin overheat	Temperature rise of the heat sink.
[]F (GF)	Start-time output side ground fault overcurrent protection (*2)	Ground fault occurred on the inverter's output side.
ÜHΓ (OHT)	External thermal relay (*3)	External thermal relay provided for protection from overheat was actuated (contact open).
[][[(OLT)	Stall prevention (overload)	Stall prevention was activated to drop the running frequency to 0. (OL appears while stall prevention is activated.)
<i>Ĝ₽ℾ</i> (OPT)	Communication error	 Communication errors occurred consecutively more than the permissible number of retries when the RS-485 connector is used and communication parameter n5 = "". RS-485 communication error occurred. Communication was broken for a period set in communication parameter n6. (Only for the type with RS-485 function.)
<i>₽Е</i> (PE)	Parameter error	Error occurred in the parameter stored.

Control Panel Indication	Function Name	Definition
<i>ዮៃ (</i> PUE)	PU disconnected	PU was disconnected when communication parameter n17 = "1". This function is valid for only the type with RS-485 communication function.
<i>-⊱</i> (RET)	Retry count	Operation could not be resumed properly within the preset number of retries.
[CPU error	Arithmetic operation of the built-in CPU does not end within the predetermined time.

- *1. Resetting the inverter initializes the internal thermal integral data of the electronic overcurrent protection.
- *2. Activated only when "1" is set in Pr. 40 "start-time ground fault detection selection".
- *3. Activated only when any of Pr. 60 to Pr. 63 (input terminal function selection) is set to OH.

(2) Minor failures

Control Panel Indication	Function Name	Definition
Fn (FN)	Fan trouble	The cooling fan built in the inverter failed (stopped).

Remarks

In this product, the cooling fan does not start until the start signal (RUN key, STF, STR signal) turns on. (Refer to Pr. 76 "cooling fan operation selection".)

(3) Warnings

Control Panel Indication	Function Name	Definition		
ÜL (OL)	Stall prevention (overcurrent) (*4)	Current more than 150% of the rated inverter current flew in the motor and operation is being performed to prevent the inverter from resulting in overcurrent shutoff.		
ot (or)	Stall prevention (overvoltage)	Regenerative energy of the motor became excessive and operation is being performed to stop the frequency from decreasing to prevent overvoltage shut-off.		
<i>P</i> 5 (PS)	PU stop (Stopped with PU STOP key)	Pr. 75 "PU stop selection" had been set and a stop was made by pressing the key of the operation panel or parameter unit (FR-PU04) during operation in the external operation mode.		
្រូ _ប (UV)	Undervoltage	Power supply voltage of the inverter dropped.		
Err) کے ہے (Err)	During reset	During inverter reset (RES signal is ON)		

^{* 4.} The stall prevention operation current may be set to any value. It is factoryset to 150%.

(4) Write errors

Control Panel Indication	Function Name	Definition
<i>Er</i> ∤(Er1)	Write disable error	Write was performed with "1" set in Pr. 77. Frequency jump setting range overlapped. Parameter write was performed though the operation panel does not have the write precedence. (Only the type having RS-485 communication function)
<i>E - ∂</i> (Er2)	Write-while-running error/mode designation error	Write was performed during operation. Write was performed in the external operation mode.
£ - ∃ (Er3)	Calibration error	Analog input bias and gain calibration values are too close.

- Major failure: When the protective function is activated, the inverter output is shut-off and an alarm output is provided.
- Minor failure: When the protective function is activated, the output is not shutoff. The minor failure signal can be output by making parameter
 setting. (Set "98" in Pr. 64 or Pr. 65 (output terminal function
 selection).)

7.2 Inverter Reset

Performing any of the following operations resets the inverter. Note that performing reset clears (erases) the internal thermal integral value of the electronic overcurrent protection and the number of retries.

Operation 1	Using the operation panel, perform reset with the (RESET) key.
	(Enabled only when the inverter protective function is activated
	(major failure))

Operation 2 Switch power off once, then on again.

Operation 3 Turn on the reset signal (RES).

(Assign this signal to any of Pr. 60 to Pr. 63.)

8. SPECIFICATIONS

8.1 Ratings

- (1) 3-phase 200V power supply
- Japanese version FR-S520-0.1K to 3.7K(-R)(-C)
- NA version

FR-S520-0.1K to 3.7K-NA(R)

Model FR-S520-□K(-R)(-C)		0.1	0.2	0.4	0.75	1.5	2.2	3.7	
Λ	policable mater conscitu(*1)	kW	0.1	0.2	0.4	0.75	1.5	2.2	3.7
Applicable motor capacity (*1) HP		1/8	1/4	1/2	1	2	3	5	
	Rated capacity (kVA) (*2)		0.3	0.5	1.0	1.6	2.8	4.0	6.6
Output	Rated current (A)		0.8	1.4	2.5	4.1	7.0	10	16.5
Out	Overload capacity (*3)		150%	60s, 20	0% 0.5s	(Invers	e-time c	haracte	ristics)
	Voltage (*4)			Three-	phase 2	00 to 24	0V 50H	z/60Hz	
/	Rated input AC			Throo	nhaca 2	00 to 24	0\/ E 0Ll	-/60U-	
Jpl	voltage/frequency Permissible AC voltage fluctuation		Three-phase 200 to 240V 50Hz/60Hz						
			170 to 264V 50Hz/60Hz						
sup	Permissible AC voltage fluctu	ation			170 to 2	64V 50H	dz/60Hz		
	Permissible AC voltage fluctu Permissible frequency fluctua					:64V 50H thin ±5'			
Power sup		ation	0.4	0.7				5.5	9
Power	Permissible frequency fluctuate Power supply equipment cap	ation acity	0.4	0.7	W	/ithin ±5'	4.0	5.5	Ů
Power	Permissible frequency fluctual Power supply equipment cap (kVA) (*5)	ation acity	0.4 Enclose	0.7 ed type (1.2	/ithin ±5'	% 4.0 tally-enc	5.5	ructure
Power P	Permissible frequency fluctual Power supply equipment cap (kVA) (*5) otective structure (JEM1030)	ation acity	0.4 Enclose	0.7 ed type (1.2 IP20). IP	/ithin ±5'	% 4.0 tally-enc	5.5 losed str	ructure

- *1. The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2. The rated output capacity indicated assumes that the output voltage is 230V.
- *3. The % value of the overload capacity indicates the ratio of the overload current to the inverter's rated output current.

 For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- *4. The maximum output voltage does not exceed the power supply voltage. You can set the maximum output voltage to any value below the power supply voltage.
- *5. The power supply capacity changes with the values of the power supply side impedances (including those of the input reactor and cables).

- (2) Single-phase 200V power supply
- Japanese version FR-S520S-0.1K to 1.5K(-R)
- EC version

FR-S520S-0.2K to 1.5K-EC(R)

Model FR-S520S-□K(-R)			0.1	0.2	0.4	0.75	1.5	
Applicable meter conscitu (*4)		0.1	0.2	0.4	0.75	1.5		
AL	oplicable motor capacity (*1)	HP	1/8	1/4	1/2	1	2	
	Rated capacity (kVA) (*2)		0.3	0.5	1.0	1.6	2.8	
pnd:	Rated current (A)		0.8	1.4	2.5	4.1	7.0	
Output	Overload capacity (*3)		150% 609	s, 200% 0.5	s (Inverse-	time chara	cteristics)	
	Voltage (*4)		Th	Three-phase 200 to 240V 50Hz/60Hz				
ЫŞ	Rated input AC voltage/freque	ency	Single-phase 200 to 240V 50Hz/60Hz					
hpply	Permissible AC voltage fluctua	ation	170 to 264V 50Hz/60Hz					
S	Permissible frequency fluctuation		Within ±5%					
Power	Power supply equipment capacity (kVA) (*5)		0.5	0.9	1.5	2.5	4.4	
Protective structure (JEM1030)			Enclosed type (IP20).					
,				71 \	,	Forced		
Co	Cooling system			Self-cooling				
						cooling		
۸۰	porovimate weight (kg (lbs))		0.5	0.6	0.8	1.0	1.5	
At	Approximate weight (kg (lbs))		(1.1)	(1.32)	(1.76)	(2.2)	(3.3)	

- *1. The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2. The rated output capacity indicated assumes that the output voltage is 230V.
- *3. The % value of the overload capacity indicates the ratio of the overload current to the inverter's rated output current.

 For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- *4. The maximum output voltage does not exceed the power supply voltage. You can set the maximum output voltage to any value below the power supply voltage.
- *5. The power supply capacity changes with the values of the power supply side impedances (including those of the input reactor and cables).

8.2 Common Specifications


<u>o.</u>	<u> </u>		mon ope	Cilications		
				Selectable between Soft-PWM control and high carrier		
	Control method		ethod	frequency PWM control, V/F control or automatic torque boost		
				control selectable.		
	Οι	tput fre	quency range	0.5 to 120Hz (starting frequency variable between 0 and 60Hz)		
	Er.	2011000	v ootting	5VDC input: 1/500 of max. set frequency, 10V, 4 to 20mADC		
	Frequency setting			input: 1/1000 of max. set frequency. Digital input: 0.1Hz (less		
	res	esolution		than 100Hz), 1Hz (100Hz or higher)		
				Analog input: Within $\pm 1\%$ of max. output frequency (25°C \pm 10°C		
	Er/	auono	y accuracy	(77°F ± 18°F))		
	1 10	squeric	y accuracy	Digital input: Within ±0.5% of set output frequency (When setting		
				dial is used)		
	Sta	arting t	orque	150% (at 6Hz) under automatic torque boost control		
	Ac	celerati	on/	0, 0.1 to 999s (may be set individually for acceleration and		
			on time setting	deceleration), linear or S-pattern acceleration/deceleration		
	40			mode selectable.		
	_		Regenerative			
		aking	(*2)	2.2K, 3.7K20%		
	tor	que	DC braking	Operation frequency (0 to 120Hz), operation time (0 to 10s),		
				operation voltage (0 to 15%)		
				Frequency setting signal (0 to 5(10)VDC), 4 to 20mA, digital		
S				setting with dial, start signal, alarm reset, multi-speed		
ij	Inp	Input signal		selection, second function selection, output stop, current input selection, external thermal relay input, start self-holding		
ical				selection, jog signal, PID control valid, PU operation-external		
Scif				operation switching.		
Control specifications				Maximum and minimum frequency settings, frequency jump		
0				operation, external thermal relay input selection, automatic		
ont	Op	eration	al function	restart after instantaneous power failure, forward/reverse		
ŏ				rotation prevention, slip compensation, operation mode		
				selection, PID control, computer link operation (RS-485) (*3)		
				1 open collector signal can be selected from among inverter		
				running, up-to-frequency, frequency detection, overload		
		Runnii	ng status	warning, zero current detection, output current detection, PID		
	a		ig otatao	upper limit, PID lower limit, PID forward/reverse rotation,		
	operation ready, minor failure and alarm. 1 contact of contact, 230V 0.3AAC, 30V 0.3ADC) signal can be selected from output frequency and Japanese current.					
	ıt s		1	contact, 230V 0.3AAC, 30V 0.3ADC) signal can be selected.		
	ıtbı		lonences	1 signal can be selected from output frequency and motor current.		
	Q	For	Japanese			
				Pulse train output (1440 pulses/s, 1mA full scale)		
		meter	NA EC	· · · ·		
			10,1,20			
	Н		1			
	Pr	otective	e/warning	(electronic overcurrent protection), fin overheat, fan failure		
			_	(*4), stall prevention, start-time output side ground fault		
				protection (*5), external thermal relay (*6), PU disconnection		
				(*3), retry count excess, communication error (*3), CPU error,		
				undervoltage (*1)		
	Protective/warning function			(*4), stall prevention, start-time output side ground fault protection (*5), external thermal relay (*6), PU disconnection		


		-10°C to +50°C (14°F to 122°F) (non-freezing)		
	Ambient temperature	(-10°C to +40°C (14°F to 104°F) for totally-enclosed structure		
Ħ		feature)		
Environme				
	Storage temperature -20°C to +65°C (-4°F to +149°F)		-20°C to +65°C (-4°F to +149°F)	
	Atmosphere	Indoors (without corrosive gas, flammable gas, oil mist, dust		
		and dirt etc.)		
	Altitude/vibration	Max. 1000m (3280.80feet) above seal level, 5.9m/s ² or less		
	Allitude/vibration	(conforms to JIS C 0911)		

- *1. When undervoltage occurs, no alarm output is provided but the output is shut off. After power restoration, the inverter may be run as it is. Depending on the running status (e.g. load magnitude), however, overcurrent, regenerative overvoltage or other protection may be activated at power restoration. (In external operation mode.)
- *2. The magnitude of braking torque indicates the short-duration average torque (which changes with the motor loss) developed when the motor alone is decelerated from 60Hz in the shortest period, and is not continuous regenerative torque. Deceleration made from a high speed above the base frequency will reduce the value of average deceleration torque.
- *3. This function is valid for only the type with RS-485 communication function.
- *4. Compatible with only the product having the built-in cooling fan.
- *5. Activated only when "1" is set in Pr. 40 "start-time ground fault detection selection".
- *6. Activated only when external thermal relay input (OH) is selected in any of Pr. 60 to Pr. 63 (input terminal function selection).

9. OUTLINE DRAWINGS

• 0.1K, 0.2K, 0.4K, 0.75K






·3-phase 200V power supply

Capacity	D	D1	D2
0.1K, 0.2K	80.5 (3.17)	10 (0.39)	52 (2.05)
0.4K	112.5 (4.43)	42 (1.65)	52 (2.05)
0.75K	132.5 (5.22)	62 (2.44)	52 (2.05)

·Single-phase 200V power supply

Capacity	D	D1	D2	
0.1K, 0.2K	80.5 (3.17)	10 (0.39)	52 (2.05)	
0.4K	142.5 (5.61)	42 (1.65)	82 (3.23)	
0.75K	162.5 (6.40)	62 (2.44)	82 (3.23)	

(Unit: mm (inches))



·3-phase 200V power supply

Capacity	W	W1	D	D1	D2	D3
1.5K, 2.2K	108 (4.25)	96 (3.78)	135.5 (5.33)	65 (2.56)	52 (2.05)	8 (0.31)
3.7K	170 (6.69)	158 (6.22)	142.5 (5.61)	72 (2.83)	52 (2.05)	5 (0.20)

·Single-phase 200V power supply

Capacity	W	W1	D	D1	D2	D3
1.5K	108 (4.25)	96 (3.78)	155.5 (6.12)	65 (2.56)	72 (2.83)	8 (0.31)

(Unit: mm (inches))

Appendix 1 Instructions for Compliance with the European Standards

(The products conforming to the Low Voltage Directive carry the CE mark.)

(1) EMC Directive

1) Our view of transistorized inverters for the EMC Directive

A transistorized inverter is a component designed for installation in a control box and for use with the other equipment to control the equipment/device. Therefore, we understand that the EMC Directive does not apply directly to transistorized inverters. For this reason, we do not place the CE mark on the transistorized inverters. (The CE mark is placed on inverters in accordance with the Low Voltage Directive.) The European power drive manufacturers' organization (CEMEP) also holds this point of view.

2) Compliance

We understand that the transistorized inverters are not covered directly by the EMC Directive. However, the EMC Directive applies to machines/equipment into which transistorized inverters have been incorporated, and these machines and equipment must carry the CE marks. Hence, we prepared the European Standard-compliant noise filters and the technical information "EMC Installation Guidelines" (information number BCN-A21041-202) so that machines and equipment incorporating transistorized inverters may conform to the EMC Directive more easily.

- 3) Outline of installation method Install an inverter using the following methods:
- * Use the inverter with an European Standard-compliant noise filter.
- * For wiring between the inverter and motor, use shielded cables or run them in a metal piping and ground the cables on the inverter and motor sides with the shortest possible distance.
- * Insert a line noise filter and ferrite core into the power and control lines as required.
 - Full information including the European Standard-compliant noise filter specifications are written in the technical information "EMC Installation Guidelines" (BCN-A21041-202). Please contact your sales representative.

(2) Low Voltage Directive

- 1) Our view of transistorized inverters for the Low Voltage Directive Transistorized inverters are covered by the Low Voltage Directive.
- 2) Compliance

We have self-confirmed our inverters as products compliant to the Low Voltage Directive and place the CE mark on the inverters.

- 3) Outline of instructions
- * Connect the equipment to the earth securely. Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth.
- * Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)
- * Use the cable sizes on pages 7, 9 and 11 under the following conditions.
 - Ambient Temperature: 40°C (104°F) maximum
 - Wire installation: On wall without ducts or conduits

If conditions are different from above, select appropriate wire according to EN60204 ANNEX C TABLE 5.

* Use the no-fuse breaker and magnetic contactor which conform to the EN or IEC Standard.

Design notice: Where residual-current-operated protective device (RCD) is used for protection in case of direct or indirect contact, only RCD of Type B is allowed on the supply side of this Electronic Equipment (EE). Otherwise another protective measure shall be applied such as separetion of the EE from the environment by double or reinforced insulation or isolation of EE and supply system by a transformer. (Extract from EN51078)

- * Use the inverter under the conditions of overvoltage category II and contamination level 2 or higher specified in IEC664.
- * Use the breaker of type B (breaker which can detect both AC and DC). If not, provide double or enhanced insulation between the inverter and other equipment, or put a transformer between the main power supply and inverter.
- * On the input and output of the inverter, use cables of the type and size set forth in EN60204 Appendix C.
- * The operating capacity of the relay outputs (terminal symbols A, B, C) should be 30VDC, 0.3A.
- * The terminals indicated as the control circuit input and output terminals on page 5 are separated safely from the main circuit.
- * Environment

	During operation	In storage	During transportation
Ambient Temperature	-10°C to +50°C	-20°C to +65°C	-20°C to +65°C
	(14°F to 122°F)	(-4°F to +149°F)	(-4°F to +149°F)
Ambient Humidity	90% RH or less	90% RH or less	90% RH or less
Muximum Altitude	1,000m	1,000m	10,000m
	(3280.80feet)	(3280.80feet)	(32808.40feet)

Details are given in the technical information "Low Voltage Directive Conformance Guide" (BCN-A21041-203). Please contact your sales representative.

Appendix 2 Instructions for compliance with U.S. and Canadian Electrical Codes



1. General Precaution

The bus capacitor discharge time is 10 minutes. Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for residual voltage between terminal P (+) and N (-) with a meter etc., to avoid hazard of electrical shock.

2. Environment

Before installation, check that the environment meets following specifications.

Ambient temperature	-10°C to +50°C (14°F to 122°F) (non-freezing)
Ambient humidity	90%RH or less (non-condensing)
Storage temperature (Note 2)	-20°C to +65°C (-4°F to 149°F)
Ambience	Indoors (No Corrosive and flammable gases, oil mist, dust and dirt.)
Altitude vibration	Below 1000m (3280.80feet), 5.9m/s ² or less

3. Installation

The below types of inverter have been approved as products for use in enclosure and approval tests were conducted under the following conditions. Design the enclosure so that the ambient temperature, humidity and ambience of the inverter will satisfy the above specifications.

Branch circuit protection

For installation in United States, branch circuit protection must be provided, in accordance with the National Electrical Code and any applicable local codes. For installation in Canada, branch circuit protection must be provided in accordance with the Canada Electrical Code and any applicable provincial codes.

4. Short circuit ratings

Suitable For Use in A Circuit Capable of Delivering Not More Than 5kA rms Symmetrical Amperes.

5. Motor overload protection

These inverters provide solid state motor overload protection. Set parameter 9 using the following instructions, (Pr. 9 "electronic thermal O/L relay").

<Setting>

- Set the rated current [A] of the motor. (Normally set the rated current at 50Hz.)
- Setting "0" makes the electronic overcurrent protection (motor protective function) invalid. (The inverter's protective function is valid).
- When using a Mitsubishi constant-torque motor, first set "1" in Pr. 71 to choose the 100% continuous torque characteristic in the low-speed range. Then, set the rated motor current in Pr. 9.

— CAUTION —

- When two or more motors are connected to the inverter, they cannot be protected by the electronic overcurrent protection. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic overcurrent protection will be deteriorated.
 - In this cause, use an external thermal relay.
- A special motor cannot be protected by the electronic overcurrent protection.
 Use an external thermal relay.

REVISIONS

*The manual number is given on the bottom left of the back cover.

Drint Data		umber is given on the bottom left of the back cover.
Print Date Mar., 2000	*Manual Number IB(NA)-0600026-A	Revision First edition
Wai., 2000	IB(INA)-0000020-A	First edition