

YASNAC MRC MAINTENANCE MODE OPERATOR'S MANUAL

Before initial operation, read these instructions thoroughly, and retain for future reference.



YASKAWA

TOE-C945-408

CONTENTS

| | | | |
|--|----------|---|------------|
| 1 MAINTENANCE MODE | 3 | 3 SYSTEM VERSION CHECK | 61 |
| 1.1 OPERATION MODES FOR MAINTENANCE | 4 | 3.1 SYSTEM VERSION CHECK | |
| 1.2 ONLINE MODE | 4 | SYSTEM VERSION CHECK DISPLAY | 62 |
| 1.3 SIMULATED ONLINE MODE | 4 | 3.2 BOARD ROM VERSION | 63 |
| 1.4 THERMOSTAT DIAGNOSIS MODE | 5 | 3.3 SERVOPACK ROM VERSION | 63 |
| 1.5 MAINTENANCE MODE (JIG MODE) | 5 | 4 ALARM OF ONLINE MODE AT POWER ON | 66 |
| 1.6 MAINTENANCE MODE (STANDARD MODE) | 5 | 4.1 OUTLINE | 69 |
| 2 SYSTEM SETUP | 7 | 4.2 LIST OF PRE-ONLINE MODE ALARMS | 69 |
| 2.1 SYSTEM SETUP | 8 | 4.3 ALARM DISPLAY | 71 |
| ■SYSTEM SETUP DISPLAY | 9 | ALARMS CAUSED BY HARDWARE ERROR | 71 |
| 2.2 SYSTEM CONFIGURATION | 10 | ALARMS CAUSED BY CMOS ERROR | 80 |
| OUTLINE | 10 | ALARMS CAUSED BY SYSTEM CONFIGURATION ERROR | 82 |
| SYSTEM CONFIGURATION DISPLAY | 11 | OTHER ALARMS | 86 |
| INITIALIZATION | 12 | 5 MCP01 BOARD 7-SEGMENT LED DISPLAY | 87 |
| MODIFICATION | 30 | ■1-DIGIT ERROR CODE DISPLAY | 88 |
| DISPLAY | 35 | ■4-DIGIT CODE REPEATED DISPLAY | 88 |
| OPERATION EXAMPLE | 42 | APPENDIX 1 | |
| 2.3 FILE INITIALIZATION | 52 | PP (PROGRAMMING PENDANT) MAINTENANCE | 93 |
| ■SELECTING FILES TO INITIALIZE | 52 | APPENDIX 2 PP ALARMS | 107 |
| ■INITIALIZING PARAMETER FILES | 53 | APPENDIX 3 | |
| ■INITIALIZING CONDITION FILES | 54 | OP (OPERATION PANEL) MAINTENANCE (OPTION) | 115 |
| ■INITIALIZING NAME FILES | 57 | APPENDIX 4 | |
| ■INITIALIZING SYSTEM DATA FILES | 57 | ADDITIONAL MOUNTING OF CMOS EXTENSION MEMORY | 123 |
| ■INITIALIZING CIO LADDERS | 58 | | |
| ■INITIALIZING OTHER FILES | 58 | | |
| 2.4 INITIALIZATION OF ROM FILES | 60 | | |
| ■SELECTING ROM FILES TO BE INITIALIZED | 60 | | |
| ■INITIALIZING WELDING FILES | 60 | | |

SECTION 1

MAINTENANCE MODE

1

| | |
|--------------------------------------|---|
| 1.1 OPERATION MODES FOR MAINTENANCE | 4 |
| 1.2 ONLINE MODE | 4 |
| 1.3 SIMULATED ONLINE MODE | 4 |
| 1.4 THERMOSTAT DIAGNOSIS MODE | 5 |
| 1.5 MAINTENANCE MODE (JIG MODE) | 5 |
| 1.6 MAINTENANCE MODE (STANDARD MODE) | 5 |

1.1 OPERATION MODES FOR MAINTENANCE

YASNAC MRC has five operation modes, which are selected by the rotary switch on the MCP01 board. Set the switch to the desired position before turning ON power.

Rotary Switch Positions and Operation Modes

| Position | Operation Mode | Remarks |
|----------|----------------------------------|------------------------------|
| 0 | Online mode | |
| 1-3 | Reserved | |
| 4 | Simulated online mode | |
| 5 | Thermostat diagnosis mode | For shipping inspection only |
| 6 | Maintenance mode (Jig mode) | For shipping inspection only |
| 7 | Maintenance mode (Standard mode) | |
| 8-F | Prohibited | |

1.2 ONLINE MODE

Select this mode for normal maintenance. For details of power ON process in this mode, refer to Par. 4, "ALARM OF ONLINE MODE AT POWER ON".

1.3 SIMULATED ONLINE MODE

Select this mode to perform operation check with no manipulator connected to the control panel. Power ON process in this mode is similar to that in standard online mode, except that :

- If an error occurs, the process stops after notifying the error and the next step is started by depressing the **CANCEL** key.
- Communication with the SERVOPACK and encoder is not performed.
- Machine lock status is retained.
- When the servo power is turned ON, contactor is turned ON but the brake and the base lock are not released.

1.4 THERMOSTAT DIAGNOSIS MODE

This mode is used exclusively for hardware diagnosis of the CPU rack at shipping inspection.

1.5 MAINTENANCE MODE (JIG MODE)

1

This mode is used exclusively for board check at shipping inspection. It is similar to standard maintenance mode except that jig-requiring tests can be selected.

1.6 MAINTENANCE MODE (STANDARD MODE)

Select this mode to set up or perform maintenance for the robot system.

Set the rotary switch of the MCP01 board to standard maintenance mode and turn ON power. The maintenance mode language select display appears. (This display does not appear in non-bilingual systems.)

| | | |
|-------------------------------|----------|---------|
| YASNAC-MRC | | |
| MAINTENANCE MODE | | |
| LANGUAGE | JAPANESE | ENGLISH |
| SEL BY ← →/CONFIRM BY <ENTER> | | |

→ Select JAPANESE/
ENGLISH

Depress **ENTER** after selecting either JAPANESE or ENGLISH to assure the language mode.

Notes :

1. When JAPANESE is selected, the display is given in Japanese ; when ENGLISH is selected, it is in English.
2. This display setting is validated only in the maintenance mode and has nothing to do with language 1 or 2 in the online mode.

1.6 MAINTENANCE MODE (STANDARD MODE) (Cont'd)

When the language to be displayed is selected, the following maintenance mode display appears.

| |
|------------------------------|
| MAINTENANCE MODE |
| |
| SETUP SYSTEM |
| SYSTEM VERSION |
| HARDWARE DIAGNOSTICS |
| |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |

In standard maintenance mode, the following functions are available.

- (1) System setup : System configuration
File initialization
ROM file initialization
- (2) System version display : Board ROM version display
SERVOPACK ROM version display
- (3) Hardware diagnosis

Functions (1) and (2) are explained later in this manual.

Using version V1. 600 or later, standard maintenance mode can be started up while having the rotary switch set to 0 (standard online mode) or 4 (simulated online mode) by the following steps.

Start-up Procedure

Turn ON the control power while holding down the **CUSTOMER** key on the Programming Pendant.



Select either JAPANESE or ENGLISH on the language select display.



Enter the manufacturer ID on the user ID input display.



The system starts up in the maintenance mode (standard mode).

If power is turned ON with the rotary switch set to 7, the maintenance mode (standard mode) starts up unconditionally, as it did in former versions.

☆ If a user ID is entered instead of the manufacturer ID, it starts up the customer maintenance mode, in which manufacturer-only functions are masked. For details, refer to the "CUSTOMER MAINTENANCE MODE OPERATION MANUAL" (TOE-C945-404.1).

SECTION 2

SYSTEM SETUP

2

| | | |
|-----|---------------------------------------|----|
| 2.1 | SYSTEM SETUP | 8 |
| ■ | SYSTEM SETUP DISPLAY | 9 |
| 2.2 | SYSTEM CONFIGURATION | 10 |
| | OUTLINE | 10 |
| | SYSTEM CONFIGURATION DISPLAY | 11 |
| | INITIALIZATION | 12 |
| | MODIFICATION | 30 |
| | DISPLAY | 35 |
| | OPERATION EXAMPLE | 42 |
| 2.3 | FILE INITIALIZATION | 52 |
| ■ | SELECTING FILES TO INITIALIZE | 52 |
| ■ | INITIALIZING PARAMETER FILES | 53 |
| ■ | INITIALIZING CONDITION FILES | 54 |
| ■ | INITIALIZING NAME FILES | 57 |
| ■ | INITIALIZING SYSTEM DATA FILES | 57 |
| ■ | INITIALIZING CIO LADDERS | 58 |
| ■ | INITIALIZING OTHER FILES | 58 |
| 2.4 | INITIALIZATION OF ROM FILES | 60 |
| ■ | SELECTING ROM FILES TO BE INITIALIZED | 60 |
| ■ | INITIALIZING WELDING FILES | 60 |

2.1 SYSTEM SETUP

Four system setup functions are provided :

(1) System Configuration

In order to start up the YASNAC MRC, system parameters must be set up according to the robot system configuration. This procedure is called system configuration.

System parameters are automatically set up by selecting menus and entering system specifications on the system configuration display.

(2) File Initialization

Various files can be initialized. (Before initializing files, system configuration must be completed.)

(3) ROM File Initialization

Various ROM files can be initialized. (Before initializing ROM files, system configuration must be completed.)

(4) SYSCON Internal Data Initialization

SYSCON internal data can be initialized. (Before initializing the data, system configuration must be completed.)

■ SYSTEM SETUP DISPLAY

1

Start up standard maintenance mode and select SETUP SYSTEM.

| |
|------------------------------|
| MAINTENANCE MODE |
| SETUP SYSTEM |
| SYSTEM VERSION |
| HARDWARE DIAGNOSTICS |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |

2

2

On the system setup display, move the cursor to the process to be started, then depress **ENTER**.

| |
|---------------------------------|
| SETUP SYSTEM |
| SYSTEM CONFIGURATION |
| INITIALIZE FILES |
| INITIALIZE ROM FILE |
| INITIALIZE SYSCON INTERNAL DATA |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

* If INITIALIZE FILES, INITIALIZE ROM FILE or INITIALIZE SYSCON INTERNAL DATA display does not appear after selecting from the menu, initialize the system configuration.

2.2 SYSTEM CONFIGURATION

OUTLINE

Three system configuration functions are provided :

(1) Initialization

This function automatically sets up system parameters and initializes all files. System configuration settings are stored in CMOS memory. When starting up the YASNAC MRC, initialization of system configuration is required.

(2) Modification

This function modifies system configuration settings.

System parameters are automatically set up in the same way as in initialization.

System configuration must be modified when :

- External axes are added.
- Applications are changed.
- I/O modules are added.
- Sensor boards are added.

(3) Display

System configuration settings can be checked on the display.

System configuration items to be set up are :

- First language
- Second language
- Number of robots, bases, and stations (configuration of controlled axes)
- Contactor connection
- Robots types
- Base axis specifications
- Station axis specifications
- Applications
- CIO ladders
- Application of robots
- I/O modules
- Sensor functions
- Use of sensor boards for robots
- Operation panel
- CMOS memory
- Calendar

SYSTEM CONFIGURATION DISPLAY

When YASNAC MRC starts-up in standard maintenance mode, the display shown below appears.

MAINTENANCE MODE

SETUP SYSTEM
SYSTEM VERSION
HARDWARE DIAGNOSTICS

SEL BY ↑ ↓ / EXEC BY <ENTER>

2

To set up system configuration, select SETUP SYSTEM and depress **ENTER**.

SETUP SYSTEM

SYSTEM CONFIGURATION
INITIALIZE FILES
INITIALIZE ROM FILE

SEL BY ↑ ↓ / EXEC BY <ENTER>
RETURN BY <CANCEL>

→ INITIALIZE FILES and INITIALIZE ROM FILE can be selected only after system configuration is initialized.

When SYSTEM CONFIGURATION is selected in the SETUP SYSTEM display, the following display appears.

SYSTEM CONFIGURATION

INITIALIZE
MODIFY
DISPLAY

SEL BY ↑ ↓ / EXEC BY <ENTER>
RETURN BY <CANCEL>

→ Any other than INITIALIZE can be selected only after execution of initialization.


INITIALIZATION

When setting up system configuration for the first time, initialize it by the following procedure.

On any of the following displays, depress **ENTER** after setting. The display automatically change to the next display.

Depressing **CANCEL** invalidates the settings you have made and the initialization display appears again.

Select "INITIALIZE" in the system configuration display.



* Displayed only when the sensor board is provided.

● LANGUAGE 1 AND 2 DISPLAYS

Select **INITIALIZE** on the system configuration display to call up the following display.

| LANGUAGE 1 | |
|------------|---|
| JAPANESE | * |
| ENGLISH | * |
| * | * |
| * | * |
| * | * |
| * | * |
| * | * |

SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER>
RETURN BY <CANCEL>

→ A list of selectable languages appears.

2

Depress **ENTER** after selecting LANGUAGE 1. The following display appears.

| LANGUAGE 2 | |
|------------|---|
| JAPANESE | * |
| ENGLISH | * |
| * | * |
| * | * |
| * | * |
| * | * |
| * | * |

SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER>
RETURN BY <CANCEL>

→ A list of selectable language appears.

Depress **ENTER** after selecting LANGUAGE 2. The controlled axes configuration display appears.


INITIALIZATION (Cont'd)

● CONTROLLED AXIS DISPLAY

In the controlled axis display, robot model selection and base/station setting are enabled.

The following shows the configuration of the controlled axis display.


Controlled Axis Display Configuration




Note : According to the setting in the axes configuration display, only those marked with * in the above figure that require setting are displayed.

The following shows the configuration of the base/station setting display.

Base/Station Setting Display Configuration



The setting displays of bases 1, 2 and stations 1 to 6 have the following configuration for each controlled axis group. (Common for bases 1, 2 and stations 1 to 6.)



* Omitted when TURN type model is selected in the select machine display.

- Controlled axes configuration
Base 1, base 2 provided/not provided, number of stations
- Contactor connection
Select either contactor 1, 2 or 3 for each group axis.
- Model selection
With base axis :
Select either rectangle-X, -Y, -Z, -XY, -XZ, -YZ or -XYZ.
With station axis :
Select either turn-1 or -2.
For the other models, select either universal-1, -2, -3, -4, -5 or -6.
- Axis type selection
With turn-* :
Selection is not needed (axis type is of turn.)
With rectangle-* :
Select either rectangle-B (ball screw) or rectangle-R & P (rack and pinion).
With universal-* :
Select either rectangle-B (ball screw), rectangle-R & P (rack and pinion) or turn.

INITIALIZATION (Cont'd)

- Specifications

When the type of the relevant axis is of ball screw, set the following items :

Deceleration ratio (numerator)

Deceleration ratio (denominator)

Ball screw pitch [mm/r]

Working range (+) [mm]

Working range (-) [mm]

When the type of the relevant axis is of rack & pinion, set the following items :

Deceleration ratio (numerator)

Deceleration ratio (denominator)

PCD [mm]

Working range (+) [mm]

Working range (-) [mm]

When the type of the relevant axis is of turn, set the following items :

Deceleration ratio (numerator)

Deceleration ratio (denominator)

Working range (+) [deg]

Working range (-) [deg]

Offset (between axes 1 and 2) [mm]

- Motor selection

Select one from the motor model list on the display.

- Motor specifications

Set the following items :

Rotating direction [forward/reverse]

Maximum rotation speed [r/min]

Accel/decel time [sec]

Load inertia ratio

(1) Controlled Axes Configuration Display

| AXES CONFIGURATION | | | | | | | | | |
|---|-----|----|---|---|---|---|---|--|--|
| ROBOT COUNT | 1 | 2 | | | | | | | |
| BASE1 | OFF | ON | | | | | | | |
| BASE2 | OFF | ON | | | | | | | |
| STATION COUNT | 0 | 1 | 2 | 3 | 4 | 5 | 6 | | |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | | | | | | | | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | | | | | | | | | |

→ The cursor position blinks.

Set up the number of robots, use of bases, and the number of stations. Then depress **ENTER** to call up the machine select display. If the group combination which has been made is not possible, an error occurs.

(2) Contactor Connection Display

| CONTACTOR CONNECTION | | | |
|----------------------|------------------|---|---|
| | CONTACTOR NUMBER | | |
| ROBOT1 | 1 | 2 | 3 |
| ROBOT2 | 1 | 2 | 3 |
| BASE1 | 1 | 2 | 3 |
| STATION1 | 1 | 2 | 3 |
| STATION2 | 1 | 2 | 3 |
| STATION3 | 1 | 2 | 3 |

| | | | |
|---|--|--|--|
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | | | |

- The cursor position blinks.
- Contactor No. 2 is set to robot 2 as default value.
- Only existing group axis is displayed.

2

Depress **ENTER** after setting the contactor number connecting each group axis to call up the select machine display (robot).

Note : This display is omitted when the controlled axis is composed of only one robot (without any base or station).

(3) Select Machine Display (Robot)

| MACHINE | | | |
|---------|-----|---|---|
| ROBOT1 | ->* | | |
| K6-C00 | * | * | * |
| K10-C00 | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |

| | | | |
|-------------------------------------|--|--|--|
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> | | | |
| RETURN BY <CANCEL> | | | |

- A robot list (1 or 2 models) stored in ROM is displayed.

Depress **ENTER** after selecting the robot (as well as robot 2).

INITIALIZATION (Cont'd)

(4) Select Machine Display (Base)

| | | | |
|-------------------------------------|----------|-----|---|
| MACHINE | | | |
| BASE1 | | ->* | |
| RECT-X | RECT-XYZ | * | * |
| RECT-Y | * | * | * |
| RECT-Z | * | * | * |
| RECT-XY | * | * | * |
| RECT-XZ | * | * | * |
| RECT-YZ | * | * | * |
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> | | | |
| RETURN BY <CANCEL> | | | |

RECT-X : Rectangle X-axis
type base

RECT-Y : Rectangle Y-axis
type base

RECT-Z : Rectangle Z-axis
type base

RECT-XY : Rectangle XY- axis
type base

RECT-XZ : Rectangle XZ-axis
type base


RECT-YZ : Rectangle YZ-axis
type base

RECT-XYZ: Rectangle XYZ-
axis type base

Depress **ENTER** after selecting the robot model to call up the axis type display. (Do the same for base 2.) If the sum of axes exceeds 21, an error occurs.


Base Type

Rectangle-X




The base axis advance direction coincides with the robot coordinate X-axis.

Rectangle-Y




The base axis advance direction coincides with the robot coordinate Y-axis.

Rectangle-Z




The base axis advance direction coincides with the robot coordinate Z-axis.

Rectangle-XY




The base 1st axis advance direction coincides with the robot coordinate X-axis and the base 2nd axis with the robot coordinate Y-axis.

Rectangle-YZ




The base 1st axis advance direction coincides with the robot coordinate Y-axis and the base 2nd axis with the robot coordinate Z-axis.

Rectangle-XZ



The base 1st axis advance direction coincides with the robot coordinate X-axis and the base 2nd axis with the robot coordinate Z-axis.

Rectangle-XYZ



The base 1st axis advance direction coincides with the robot coordinate X-axis, the base 2nd axis with the robot coordinate Y-axis and the base 3rd axis with the robot coordinate Z-axis.

INITIALIZATION (Cont'd)

(5) Select Machine Display (Station)

| | | | |
|---|---|--------|---|
| MACHINE | | | |
| STATION1 | | ->* | |
| TURN-1 | * | UNIV-1 | * |
| TURN-2 | * | UNIV-2 | * |
| | * | UNIV-3 | * |
| | * | UNIV-4 | * |
| | * | UNIV-5 | * |
| | * | UNIV-6 | * |
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> RETURN BY <CANCEL> | | | |

TURN-1 : Rotation 1-axis
type station

TURN-2 : Rotation 2-axis
type station


UNIV-1 : Universal 1-axis
type station

UNIV-2 : Universal 2-axis
type station


When any mechanism (rectangle axes, etc.) other than "TURN-1" and "TURN-2" is used as a station axis, select "UNIV". However, when "UNIV" is used, interpolation operation (linear, circular) is not supported.

Station Type

Turn-1



Turn-2



When the model is a station, which axis is to be the 1st axis or to be the 2nd axis is determined depending on which axis is located at the bottom most.

For example, in the figure on the left, the rotation table is inclined by the inclination axis ; therefore, the inclination axis is an axis that is mounted at the bottom of the rotation table so that it is to be the 1st axis. The rotation table becomes the 2nd axis.

Depress **ENTER** after selecting "TURN" type for the station, and the mechanism specification setting display appears.

Depress **ENTER** after selecting "UNIV" type for the station, and the axis type select display appears.

If the sum of the axes exceeds 21, an error occurs.

(6) Axis Type Display (Base, Station)

- ① Select RECT-* on the select machine (base) display. The following display appears.

Axis Type Select Display (Rectangle Type)

| | | |
|---|--------|----------|
| AXIS TYPE | | |
| BASE1 -> RECT-XY | | |
| AXIS-NO. 1 | RECT-B | RECT-R&P |
| AXIS-NO. 2 | RECT-B | RECT-R&P |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | | |

- The cursor position blinks.
→ RECT-B : Rectangle axis (ball screw)
RECT-R&P : Rectangle axis (rack & pinion)

2

Select RECT-B for the rectangle axis by ball screw mechanism and RECT-R & B for that by rack & pinion mechanism.

- ② Select TURN-* on the select machine (station) display
③ Select UNIV-* on the select machine (station) display. The following display appears.

Axis Type Select Display (Universal Type)

| | | | |
|---|--------|----------|------|
| AXIS TYPE | | | |
| STATION1 -> UNIV-2 | | | |
| AXIS-NO. 1 | RECT-B | RECT-R&P | TURN |
| AXIS-NO. 2 | RECT-B | RECT-R&P | TURN |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | | | |

- The cursor position blinks.
→ RECT-B : Rectangle axis (ball screw)
RECT-R&P : Rectangle (rack & pinion)
TURN : Rotation axis (When RECT is selected on the select machine display, TURN is not displayed.)

Select RECT-B for the rectangle axis by ball screw mechanism, RECT-R & B for that by rack & pinion mechanism and TURN for that rotation axis.

Depress **ENTER** after selecting the axis type. The mechanical specification display appears.

INITIALIZATION (Cont'd)

(7) Mechanical Specification Display (Base, Station)

Mechanical Specification Display (RECT-B Type)

| | |
|---|-------------|
| MECHANICAL SPEC | |
| STATION1 -> RECT-X | AXIS -> 1 |
| AXIS TYPE -> RECT-B | |
| REDUCTION RATIO (NUMBER) | 1.000 |
| REDUCTION RATIO (DENOM) | 1.000 |
| BALL SCREW PITCH | 10.000 mm/r |
| MOTION RANGE (+) | 0.000 mm |
| MOTION RANGE (-) | 0.000 mm |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | |

→ Model, axis No. and axis type that are currently selected are displayed.

→ The cursor position is displayed inversely.

Deceleration ratio : Set a value for numerator and denominator, respectively.
(Example : Set 1.0 to numerator and 1.0 to denominator for 1/1.)

Ball screw pitch : Set the moving distance for motor one rotation.
(unit : mm/r)

Working range : Set the operation limit position (plus and minus directions)
when the home position is assumed to be 0. (unit : mm)

Mechanical Specification Display (RECT-R & P Type)

| | |
|---|------------|
| MECHANICAL SPEC | |
| STATION1 -> UNIV-2 | AXIS -> 2 |
| AXIS TYPE -> RECT-R&P | |
| REDUCTION RATIO (NUMBER) | 1.000 |
| REDUCTION RATIO (DENOM) | 120.000 |
| PCD | 100.000 mm |
| MOTION RANGE (+) | 0.000 mm |
| MOTION RANGE (-) | 0.000 mm |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | |

→ Model, axis No. and axis type that are currently selected are displayed.

→ The cursor position is displayed inversely.

Deceleration ratio : Set a value for numerator and denominator, respectively.
(Example : Set 1.0 to numerator and 120.0 to denominator for 1/120.)

PCD : Set the pinion diameter. (unit : mm)

Working range : Set the operation limit position (plus and minus directions)
when the home position is assumed to be 0. (unit : mm)


Mechanical Specification Display (Rotation Axis Type)

| | | |
|---|-----------|--|
| MECHANICAL SPEC | | |
| STATION1 -> TURN-2 | AXIS -> 1 | Model, axis No. and axis type that are currently selected are displayed. |
| AXIS TYPE -> TURN | | The cursor position is displayed inversely. |
| REDUCTION RATIO (NUMER) | 1.000 | |
| REDUCTION RATIO (DENOM) | 120.000 | |
| MOTION RANGE (+) | 0.000 deg | |
| MOTION RANGE (-) | 0.000 deg | |
| OFFSET (AXIS#1-#2) | 0.000mm | Displayed on the 1st axis display only when the model is of TURN-2 type. |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> | | |
| CONFIRM BY <ENTER> / RETURN BY <CANCEL> | | |

Deceleration ratio : Set a value for numerator and denominator, respectively.
(Example : Set 1.0 to numerator and 120.0 to denominator for 1/120.)

Working range : Set the operation limit position (plus and minus directions) when the home position is assumed to be 0. (unit : deg.)

Offset : Setting is required only when the model is of TURN-2 type.
Set the distance between the inclination axis (1st axis) and the rotation table (2nd axis). (unit : mm)



Depress **ENTER** after selecting the mechanism specifications to call up the display for the next axis. With the last axis, the motor select display appears.

INITIALIZATION (Cont'd)

(8) Motor Display (Base, Station)

Terminate the mechanical specification display. The following display appears.

| | |
|---|----------------|
| MOTOR | |
| STATION1 → UNIV-2 | AXIS → 1 |
| AXIS TYPE → TURN | |
| USADED-13-YR21 | USAPEM-07-YR42 |
| USASEM-02-YR32 | USAREM-01-YR52 |
| USADED-13-YR41 | USADED-22-YR32 |
| USAREM-02CYR22 | USASEM-08-YR61 |
| USAPEM-07-YR11 | USADED-22-YR41 |
| USAREM-01-YR41 | USASEM-08-YR71 |
| SEL BY ↑ ↓ ← → / SEL NEXT PAGE BY <MORE> CONFIRM BY <ENTER> / RETURN BY <CANCEL> | |

→ The group, machine, axis number, and axis type that are currently selected are displayed.

→ A motor list stored in ROM is displayed.

→ Depress **[MORE]** to display the next model list.

Depress **[ENTER]** after selecting the motor type to call up the motor select display for the next axis. With the last axis, the motor specification setting display appears.

(9) Motor Specification Display (Base, Station)


Select the motor type on the motor select display. The following display appears.

| | |
|--|-----------|
| MOTOR SPEC | |
| STATION1 → UNIV-2 | AXIS → 1 |
| AXIS TYPE → RECT-R&P | |
| MACHINE TYPE → USADED-13-YR21 | |
| ROTATION (FWD : 0 REV : 1) | |
| MOTOR MAX RPM | 2000 rpm |
| ACCELERATION TIME | 0.300 sec |
| INERTIA RATIO | 300 |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> CONFIRM BY <ENTER> / RETURN BY <CANCEL> | |

→ The set values related to the axis that is currently selected are displayed.

→ The cursor position is displayed inversely.

Rotating direction : Set the motor rotating direction at which the current value increases in the plus direction.
(The CCW direction viewed from the load side is to be the forward rotating direction.)



AC SERVOMOTOR

Maximum rotating speed : Set the maximum motor rotating speed. (unit : r/min)

Accel/decel time : Set the value of the time in which the maximum speed is to be reached from the stop status in the range from 0.01 to 1.00 upon operating at the full link speed (100%).

Load inertia ratio : 300 is set with rectangle axis and 0 is set with rotation axis as an initial value. If any of the following faults occurs after verification of movement, take the corrective actions as described below.

<Fault 1> The robot moves unsteadily in the proceeding direction during operation. → Increase the load inertia ratio by 100 to verify the movement.

<Fault 2> Abnormal noise is generated from the motor at stop.
→ Decrease the load inertia ratio by 100 to verify the movement.

Depress **ENTER** after setting the motor specifications to call up the display for the next axis.

With the last axis, the application display appears.

● APPLICATION DISPLAY

Terminate the controlled axis display. The following display appears.

| | |
|-------------------------------------|-----------------|
| APPL | |
| ARC | GENERAL PURPOSE |
| JIG-LESS | CO2-LASER |
| ARC +ARC | LASER CUTTING |
| HANDLING | PAINT |
| SPOT | * |
| SPOT / SPOT | * |
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> | |
| RETURN BY <CANCEL> | |

→ The list of applications is displayed.

→ If the list of applications is not contained on a single page, depress **MORE** to call up the next page of the list.

Depress **ENTER** after selecting applications to call up the following display.

INITIALIZATION (Cont'd)

● CIO LADDER DISPLAY

| CIO LADDER | |
|-------------|-----------------|
| ARC | GENERAL PURPOSE |
| JIG-LESS | CO2-LASER |
| ARC + ARC | LASER CUTTING |
| HANDLING | PAINT |
| SPOT | * |
| SPOT / SPOT | * |

SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER>
RETURN BY <CANCEL>

→ The list of ladders is displayed.

Depress **ENTER** after selecting the CIO ladder, and the following display appears.

● ROBOT APPLICATION OPTION DISPLAY

After selecting the application, the following display appears.

| ROBOT APPL OPTION | | | |
|-------------------|------|----------|--|
| ROBOT1 | | | |
| APPL 1 | USED | NOT USED | |
| APPL 2 | USED | NOT USED | |
| ROBOT2 | | | |
| APPL 1 | USED | NOT USED | |
| APPL 2 | USED | NOT USED | |

SEL ITEM BY ↑ ↓ / SEL OPTION BY ← →
CONFIRM BY <ENTER> / RETURN BY <CANCEL>

→ If the number of applications has been set to 1, APPL 2 is not displayed.

→ If the system has only one robot, ROBOT 2 is not displayed.

Depress **ENTER** after setting. The next display appears.

● IO MODULE DISPLAY

| IO MODULES | |
|------------|---------|
| SLOT-1 | DIO-16 |
| SLOT-2 | DIO-32 |
| SLOT-3 | NONE |
| SLOT-4 | NONE |
| SLOT-5 | MEW01-1 |

CONFIRM BY <ENTER> / RETURN BY <CANCEL>

| Board | Display |
|-------|---------|
| MIO01 | DIO-××× |
| MIO02 | DIO-××× |
| MIO03 | DIO-××× |
| MIO04 | DIO-××× |

↑
Number indicates point of contacts.

Verify that the display matches the I/O module implementation, then depress **ENTER** to call up the following display. Automatic setup may or may not be available depending on the I/O module settings. If not, "AUTOMATIC SETTING IMPOSSIBLE" is displayed.

● SENSOR FUNCTION DISPLAY

| | |
|---------------------------------------|-----------|
| SENSOR FUNCTION | |
| SENSOR BOARD 1 | → COM-ARC |
| SENSOR BOARD 2 | → NONE |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

→ If sensor boards are mounted, their functions are displayed.

2

Verify that the display matches the sensor board implementation, then depress **ENTER** to call up the following display.

● ROBOT SENSOR OPTION DISPLAY

Depress **ENTER** on the sensor function display. The following display appears only when the sensor board is mounted.

| | | |
|---------------------------------------|------|----------|
| ROBOT SENSOR OPTION | | |
| ROBOT1 | | |
| SENSOR BOARD 1 | USED | NOT USED |
| SENSOR BOARD 2 | USED | NOT USED |
| ROBOT2 | | |
| SENSOR BOARD 1 | USED | NOT USED |
| SENSOR BOARD 2 | USED | NOT USED |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | | |

→ Not displayed unless sensor board 2 exists.

→ Not displayed unless robot 2 exists.

Depress **ENTER** after setting. The following display appears.

INITIALIZATION (Cont'd)

● OP DISPLAY

| | | |
|---|-------------|---------------|
| OP | | |
| IF02 | -> ON | → *1 |
| OP | -> ON | → *2 |
| LANGUAGE 1 | -> JAPANESE | → *3 |
| LANGUAGE 2 | -> ENGLISH | |
| OP | USED | NOT USED → *4 |
| SEL ITEM BY ← → /CONFIRM BY <ENTER> RETURN BY <CANCEL> | | |

*1 OFF when MIF02 board does not exist.

*2 OFF when OP is not connected.

*3 The language incorporated into ROM of the operation panel is displayed only when the OP is connected.

*4 Displayed only when OP is connected.

Verify that the display matches the MIF02 board and OP implementation, then depress **ENTER** to call up the following display.

To disconnect the OP from the system, select NOT USED.

Note : If the languages that have been selected on the first and second language select displays (Par. 3.1) are not stored in OP ROM, an OP language collation error is output.

● CMOS MEMORY DISPLAY

| | |
|---------------------------------------|----------|
| CMOS MEMORY | |
| AVAILABLE | -> 256KB |
| HW CAPACITY | -> 256KB |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

| CMOS Memory Mounted Status | Capacity |
|----------------------------|----------|
| Standard | 256 kB |
| MMM01-2 Board Added | 1 MB |
| MMM01-3 Board Added | 2 MB |
| MMM01-4 Board Added | 3 MB |

Depress **ENTER** after verifying that the display is the same as CMOS memory mounted status. The following display appears.

● CALENDAR DISPLAY

| | |
|--|------------|
| CALENDAR | |
| DATE | 1994.01.01 |
| CLOCK | 12.34 |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> CONFIRM BY <ENTER> / RETURN BY <CANCEL> | |

→ Year, Month, Day
→ Hour, Minute

2

If the display differs from the actual date or time, depress **MODIFY** to be in the input mode and correct it. Since the calendar is already set when the display is proper, correction is not needed. Depress **ENTER** to call up the following display.

● VERIFICATION DISPLAY

| | |
|---------------------------------|--|
| SYSTEM CONFIGURATION | |
| EXEC INITIALIZATION | |
| ARE YOU SURE? YES NO | |
| SEL BY ← → / CONFIRM BY <ENTER> | |

Move the cursor to YES and depress **ENTER** to initialize the contents of CMOS memory and return to the system configuration display. If NO is selected, the contents of CMOS memory are left unmodified.

| | |
|--|--|
| SYSTEM CONFIGURATION | |
| INITIALIZE MODIFY DISPLAY | |
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> | |

The procedure above completes initialization. Reset the rotary switch to 0 and turn power OFF to ON again.

MODIFICATION

To change part of system configuration after execution of initialization, select **MODIFY**. Succeeding displays are the same as those that appeared in initialization procedure, except that current settings are displayed are on the former.

| | |
|------------------------------|--|
| SYSTEM CONFIGURATION | |
| INITIALIZE | |
| MODIFY | |
| DISPLAY | |
| SEL BY ↑ ↓ / EXEC BY <ENTER> | |
| RETURN BY <CANCEL> | |

→ **MODIFY** and **DISPLAY** can be selected only after initialization.

For modifying the system configuration, select **MODIFY** on the system configuration display.

| | |
|------------------------------|--------------------|
| MODIFY | |
| LANGUAGE | CUSTOMER OPTION |
| CONTROLLED AXES | CUSTOMER MECHANISM |
| APPL | * |
| IO MODULES | * |
| SENSOR FUNCTION | * |
| OP | * |
| * | * |
| SEL BY ↑ ↓ / EXEC BY <ENTER> | |
| RETURN BY <CANCEL> | |

Depress **ENTER** after selecting the item. Each item modification display appears.

(1) Changing Languages

Language 1 and 2 can be changed on the language displays. The displays are the same as those appeared in initialization procedure.

(2) Changing Controlled Axes

To change controlled axes, perform the same procedure as that of initialization.

- * Note that all the robot, base, and station parameters (of all controlled axes groups) are initialized by the procedure.

- * When the controlled axes configuration is changed because of addition of base or station axes, the job data internal form is also changed. Therefore, job data initialization is required.


Initialize the job data following the above-mentioned changing operation.

- * When a set value such as working range is changed after addition of base or station axes, job data does not have to be initialized again since the controlled axes configuration does not change.

(3) Changing Application

Application setting is changed in the following procedures.

- * The displays are the same as those appeared in initialization procedure.



Changing application settings will not initialize CIO ladders. Initialize CIO ladders on the file initialization display if necessary.

(4) Changing I/O Modules


The displays are the same as that which appeared in initialization procedure, except that after **ENTER** is depressed a message appears asking change. Return YES to the message and depress **ENTER** to start automatic setting of the CIO parameters according to the current hardware implementation.

If the parameters could not be set up, "AUTOMATIC SETUP IMPOSSIBLE" is displayed.

MODIFICATION (Cont'd)

(5) Modifying Sensor Function

The displays are the same as those appeared in initialization procedure.



(6) Modifying OP Setting

The display is the same as those appeared in initialization procedure, except that after **ENTER** is depressed a message appears asking modification.

Return YES to the message and depress **ENTER** to start automatic setting of the system parameters according to the current hardware implementation.

(7) Modifying Customer Option

Select CUSTOMER OPTION on the modification display. The following display appears.

| | | |
|---|----------|----------|
| CUSTOMER OPTION | | |
| REMOTE FUNCTION | | |
| IO | USED | NOT USED |
| COMMAND | USED | NOT USED |
| PP/PBOX | USED | NOT USED |
| ARC WELDING | STANDARD | ENHANCED |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → EXEC BY <ENTER> / RETURN BY <CANCEL> | | |

→ Displayed only when ARC WELDING is selected. (Including arc+arc and jig-less)

2

Depress **ENTER** after setting is modified. The verification message is displayed as shown below.

| | | |
|---------------------------------|----------|----------|
| CUSTOMER OPTION | | |
| REMOTE FUNCTION | | |
| IO | USED | NOT USED |
| COMMAND | USED | NOT USED |
| PP/PBOX | USED | NOT USED |
| ARC WELDING | STANDARD | ENHANCED |
| INITIALIZE RELATED FILES | | |
| ARE YOU SURE? | YES | NO |
| SEL BY ← → / CONFIRM BY <ENTER> | | |

Depress **ENTER** after selecting YES in the verification message. The system parameter is changed according to the setting status of the display.

Note : Only when the arc welding function setting is modified, the welding starting condition file and ending condition file are initialized.

When the COM-ARC function is validated, the arc welding function cannot be set to ENHANCED.

MODIFICATION (Cont'd)

(8) Modifying Customer Mechanism

Select CUSTOMER MECHANISM on the modification display. The following display appears.

| | |
|------------------------------|--|
| CUSTOMER MECHANISM | |
| ROBOT1 | |
| ROBOT2 | |
| | |
| | |
| | |
| SEL BY ↑ ↓ / EXEC BY <ENTER> | |
| RETURN BY <CANCEL> | |

→ Selectable only for models containing customer mechanism such as K506-C30.

Select the ROBOT 1 or ROBOT 2. The following display appears.

| | |
|---|------------|
| T-AXIS OFFSET | |
| ROBOT1 → K506-C30 | |
| OFFSET (X-DIRECTION) | 0.000 mm |
| OFFSET (Y-DIRECTION) | 260.000 mm |
| OFFSET (ANGLE) | 0.000 deg |
| | |
| SEL ITEM BY ↑ ↓ / INPUT MODE BY <ALTER> | |
| RETURN BY <CANCEL> | |

Select the item to be modified by using or and input the value to be in the numerical input mode.

Depress after inputting the data. The data is set and the mode changes to previous mode.

DISPLAY

To display the system configuration status, select DISPLAY on the system configuration display.

| | |
|------------------------------|--|
| SYSTEM CONFIGURATION | |
| INITIALIZE | |
| MODIFY | |
| DISPLAY | |
| SEL BY ↑ ↓ / EXEC BY <ENTER> | |
| RETURN BY <CANCEL> | |

→ MODIFY and DISPLAY can be selected only after execution of initialization.

2

| | |
|------------------------------|--------------------|
| DISPLAY | |
| LANGUAGE | CUSTOMER OPTION |
| CONTROLLED AXES | CUSTOMER MECHANISM |
| APPL | |
| IO MODULES | |
| SENSOR FUNCTION | |
| OP | |
| CMOS MEMORY | |
| SEL BY ↑ ↓ / EXEC BY <ENTER> | |
| RETURN BY <CANCEL> | |

Depress **ENTER** after selecting an item. The display of each item appears.

● Language Display

| | |
|--------------------|-------------|
| LANGUAGE | |
| LANGUAGE 1 | -> ENGLISH |
| LANGUAGE 2 | -> JAPANESE |
| RETURN BY <CANCEL> | |

DISPLAY (Cont'd)

● Controlled Axes Display

The controlled axes setting status can be displayed on the following display.

| |
|------------------------------|
| CONTROLLED AXES |
| CONTACTOR |
| ROBOT |
| BASE |
| STATION |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

Depress **ENTER** after selecting a group. The display of each group appears.

(1) Contactor Connection Display

The displays are the same as those appeared in initialization procedure.

(2) Robot Setting Status Display

| | |
|--------------------|------------|
| ROBOT | |
| ROBOT1 | -> K10-A00 |
| ROBOT2 | -> NONE |
| RETURN BY <CANCEL> | |

→ The model that is currently set is displayed

(3) Base Setting Status Display

| | |
|-------------------------------------|-----------|
| BASE | |
| BASE1 | -> RECT-X |
| BASE2 | -> NONE |
| SEL BY ↑ ↓ / DISP DETAIL BY <ENTER> | |
| RETURN BY <CANCEL> | |

→ The model that is currently set is displayed.
(The cursor position is displayed inversely.)

(4) Display of Station Setting Status

| STATION | |
|----------|-----------|
| STATION1 | -> TURN-1 |
| STATION2 | -> NONE |
| STATION3 | -> NONE |
| STATION4 | -> NONE |
| STATION5 | -> NONE |
| STATION6 | -> NONE |

SEL BY ↑ ↓ / DISP DETAIL BY <ENTER>
RETURN BY <CANCEL>

→ The model being set is displayed. (The cursor position is displayed inversely.)

2

Select a station number to call up the following display.

| STATION | |
|------------|-------------|
| STATION1 | -> UNIV-2 |
| AXIS-NO. 1 | -> RECT-R&P |
| AXIS-NO. 2 | -> TURN |
| AXIS-NO. 3 | -> NONE |
| AXIS-NO. 4 | -> NONE |
| AXIS-NO. 5 | -> NONE |
| AXIS-NO. 6 | -> NONE |
| AXIS-NO. 7 | -> NONE |
| AXIS-NO. 8 | -> NONE |

SEL BY ↑ ↓ / DISP DETAIL BY <ENTER>
RETURN BY <CANCEL>

→ The axis type being set is displayed. (The cursor position is displayed inversely.)

Select an axis to call up the following display.

| | |
|-----------------|-------------|
| AXIS SPEC | |
| STATION1 | -> UNIV-2 |
| AXIS TYPE | -> RECT-R&P |
| MECHANICAL SPEC | |
| MOTOR SPEC | |

SEL BY ↑ ↓ / DISP DETAIL BY <ENTER>
RETURN BY <CANCEL>

Depress **ENTER** after selecting the mechanical specification on the axis specification display. The following display appears.

DISPLAY (Cont'd)

Mechanical Specification Display

| | |
|--------------------------|-----------|
| MECHANICAL SPEC | |
| STATION1 -> UNIV-2 | AXIS -> 1 |
| AXIS TYPE -> RECT-R&P | |
| REDUCTION RATIO (NUMBER) | 1.000 |
| REDUCTION RATIO (DENOM) | 120.000 |
| PCD | 0.000 mm |
| MOTION RANGE (+) | 0.000 mm |
| MOTION RANGE (-) | 0.000 mm |
| RETURN BY <CANCEL> | |

→ The currently set value is displayed.

Depress **ENTER** after selecting the motor specification on the axis specification display. The following display appears.

Motor Specification Display

| | |
|--------------------------------|-----------|
| MOTOR SPEC | |
| STATION1 -> UNIV-2 | AXIS -> 1 |
| AXIS TYPE -> RECT-R&P | |
| MACHINE TYPE -> USADED-13-YR21 | |
| ROTATION (FWD : 0 REV : 1) | 0 |
| MOTOR MAX RPM | 3000 rpm |
| ACCELERATION TIME | 0.300 sec |
| INERTIA RATIO | 300 |
| RETURN BY <CANCEL> | |

→ The currently set value is displayed.

● Application Display

The application setting status can be observed on the application display.

| | |
|---------------------------|--|
| SENSOR FUNCTION | |
| SENSOR BOARD 1-> COM-ARC | |
| SENSOR BOARD 2-> NONE | |
| ROBOT1 | |
| SENSOR BOARD 1-> USED | |
| SENSOR BOARD 2-> NOT USED | |
| ROBOT2 | |
| SENSOR BOARD 1-> NOT USED | |
| SENSOR BOARD 2-> USED | |
| RETURN BY <CANCEL> | |

→ Not displayed unless application 2 exists.

→ Not displayed unless robot 2 exists.

Depress **CANCEL** to return to the display.

● I/O Module

The I/O module setting status can be observed on the I/O module display.

| I/O MODULES | |
|-------------|---------|
| SLOT 1 | DIO-16 |
| SLOT 2 | DIO-32 |
| SLOT 3 | NONE |
| SLOT 4 | NONE |
| SLOT 5 | MEW01-1 |

RETURN BY <CANCEL>

→ The current parameter setting status is displayed.

2

Depress **CANCEL** to return to the display.

● Sensor Function Display

The sensor function setting status can be displayed on the sensor function display.

| SENSOR FUNCTION | |
|---------------------------|--|
| SENSOR BOARD 1-> COM-ARC | |
| SENSOR BOARD 2-> NONE | |
| ROBOT 1 | |
| SENSOR BOARD 1-> USED | |
| SENSOR BOARD 2-> NOT USED | |
| ROBOT 2 | |
| SENSOR BOARD 1-> NOT USED | |
| SENSOR BOARD 2-> USED | |

RETURN BY <CANCEL>

→ Not displayed unless robot 2 exists.

→ Not displayed unless application 2 exists.

DISPLAY (Cont'd)

● OP

The OP setting status can be displayed on the OP display.

| | | |
|--------------------|---------------|------|
| OP | | |
| IF02 | -> ON | → *1 |
| OP | -> ON | → *2 |
| LANGUAGE 1 | -> JAPANESE | → *3 |
| LANGUAGE 2 | -> ENGLISH | |
| OP | USED NOT USED | → *4 |
| RETURN BY <CANCEL> | | |

*1 OFF when M1F02 board does not exist.

*2 OFF when OP is not connected.

*3 The language incorporated into ROM of the operation panel is displayed only when OP is connected.

*4 Displayed only when OP is connected.

Depress **CANCEL** to return to the display.

● CMOS Memory

The CMOS memory setting status can be observed on the CMOS memory display.

| | |
|--------------------|----------|
| CMOS MEMORY | |
| AVAILABLE | -> 256KB |
| HW CAPACITY | -> 256KB |
| RETURN BY <CANCEL> | |

Depress **CANCEL** to return to the display.

● Customer Option

The customer option setting status can be observed on the customer option display.

| | | |
|--------------------|----------|----------|
| CUSTOMER OPTION | | |
| REMOTE FUNCTION | | |
| IO | USED | NOT USED |
| COMMAND | USED | NOT USED |
| PP/PBOX | USED | NOT USED |
| ARC WELDING | STANDARD | ENHANCED |
| RETURN BY <CANCEL> | | |

Depress **CANCEL** to return to the display.

● Customer Mechanism

The customer mechanism setting status can be observed on the customer mechanism display.

OPERATION EXAMPLE

Initializing a Cooperative System

In the example below, robot 1 is assigned to K30-A411 (K50SX) for holding work-pieces and robot 2 to K6-A301 (K6S) for are welding.

1

Set the rotary switch to 7 and turn ON power. The following display appears.

| | | |
|-------------------------------|----------|---------|
| YASNAC-MRC | | |
| MAINTENANCE MODE | | |
| LANGUAGE | JAPANESE | ENGLISH |
| SEL BY ← →/CONFIRM BY <ENTER> | | |

Select either JAPANESE or ENGLISH and depress **ENTER** .
The following display appears.

2

Maintenance Mode Display

| | |
|----------------------------|--|
| MAINTENANCE MODE | |
| SETUP SYSTEM | |
| SYSTEM VERSION | |
| HARDWARE DIAGNOSTICS | |
| SEL BY ↑ ↓/EXEC BY <ENTER> | |

Select SETUP SYSTEM to call up the following display.

3

System Setup Display

| |
|---------------------------|
| SETUP SYSTEM |
| SYSTEM CONFIGURATION |
| INITIALIZE FILES |
| INITIALIZE ROM FILE |
| SEL BY ↑↓/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

2

Select SYSTEM CONFIGURATION to call up the following display.

4

System Configuration Display

| |
|---------------------------|
| SYSTEM CONFIGURATION |
| INITIALIZE |
| MODIFY |
| DISPLAY |
| SEL BY ↑↓/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

When INITIALIZE is selected, the language 1 display appears.

OPERATION EXAMPLE (Cont'd)

5

1st Language/2nd Language Display

When "INITIALIZE" is selected in the system configuration display, the following display appears.

| LANGUAGE 1 | |
|------------|---|
| JAPANESE | * |
| ENGLISH | * |
| * | * |
| * | * |
| * | * |
| * | * |
| * | * |

| |
|--------------------------------|
| SEL BY ↑ ↓ ← →/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ The list of selectable languages is displayed.

Depress **ENTER** after selecting LANGUAGE 1 to call up the following display.

| LANGUAGE 2 | |
|------------|---|
| JAPANESE | * |
| ENGLISH | * |
| * | * |
| * | * |
| * | * |
| * | * |
| * | * |

| |
|--------------------------------|
| SEL BY ↑ ↓ ← →/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ The list of selectable languages is displayed.

Depress **ENTER** after selecting LANGUAGE 2 to call up the following display.

6

Controlled Axes Configuration Display

| AXES CONFIGURATION | | |
|--|---------------|----|
| ROBOT COUNT | 1 | 2 |
| BASE1 | OFF | ON |
| BASE2 | OFF | ON |
| STATION COUNT | 0 1 2 3 4 5 6 | |
| SEL ITEM BY ↑ ↓ / SEL OPTION BY ← → | | |
| CONFIRM BY <ENTER> / ABORT BY <CANCEL> | | |

Set ROBOT COUNT to "2" (BASE-1 and -2 : "OFF", STATION COUNT : "0") and depress **ENTER** to call up the following display.

7

Contactor Connection Display

| CONTACTOR CONNECTION | | | |
|---------------------------------|------------------|---|---|
| | CONTACTOR NUMBER | | |
| ROBOT1 | 1 | 2 | 3 |
| ROBOT2 | 1 | 2 | 3 |
| SEL BY ↑ ↓ / CONFIRM BY <ENTER> | | | |
| RETURN BY <CANCEL> | | | |

Set ROBOT 1 to CONTACTOR 1 and ROBOT 2 to CONTACTOR 2 on the default display, and depress **ENTER**. The machine display of ROBOT 1 appears.

2

DISPLAY (Cont'd)

8

Machine Display (ROBOT 1, ROBOT 2)

| | | | |
|---------|---|------|---|
| MACHINE | | | |
| ROBOT1 | | -> * | |
| K6-A30 | * | * | * |
| K30-A41 | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |

SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER>
RETURN BY <CANCEL>

Select the model "K30-A41" for ROBOT 1, and depress **ENTER**. The ROBOT 2 machine display appears.

| | | | |
|---------|---|------|---|
| MACHINE | | | |
| ROBOT2 | | -> * | |
| K6-A30 | * | * | * |
| K30-A41 | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |
| * | * | * | * |

SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER>
RETURN BY <CANCEL>

Select the model "K6-A30" for ROBOT 2 and depress **ENTER**. The following display appears.

9**Application Display**

| | |
|-------------------------------------|-----------------|
| APPL | |
| ARC | GENERAL PURPOSE |
| JIG-LESS | CO2-LASER |
| ARC+ARC | LASER CUTTING |
| HANDLING | PAINT |
| SPOT | * |
| SPOT/SPOT | * |
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> | |
| RETURN BY <CANCEL> | |

Depress **ENTER** after selecting JIG-LESS. The following display appears.

10**CIO Ladder Display**

| | |
|-------------------------------------|-----------------|
| CIO LADDER | |
| ARC | GENERAL PURPOSE |
| JIG-LESS | CO2-LASER |
| ARC+ARC | LASER CUTTING |
| HANDLING | PAINT |
| SPOT | * |
| SPOT/SPOT | * |
| SEL BY ↑ ↓ ← → / CONFIRM BY <ENTER> | |
| RETURN BY <CANCEL> | |

Depress **ENTER** after selecting JIG-LESS for CIO ladder application. The following display appears.

DISPLAY (Cont'd)

11

Robot Application Option Display

| ROBOT APPL OPTION | | | |
|-------------------|--------|------|----------|
| ROBOT1 | | | |
| | APPL 1 | USED | NOT USED |
| ROBOT2 | | | |
| | APPL 1 | USED | NOT USED |

SEL ITEM BY ↑ ↓ / SEL OPTION BY ← →
CONFIRM BY <ENTER> / RETURN BY <CANCEL>

Set application 1 of robot 1 to NOT USED, application 1 of robot 2 to USED, and depress **ENTER**. The following display appears.

12

IO Module Display

| IO MODULES | |
|------------|---------|
| SLOT-1 | DIO16 |
| SLOT-2 | DIO32 |
| SLOT-3 | NONE |
| SLOT-4 | NONE |
| SLOT-5 | MEW01-1 |

CONFIRM BY <ENTER> / RETURN BY <CANCEL>

Verify that the display matches the I/O module implementation, then depress **ENTER**. The following display appears.

13**Sensor Function Display**

| | |
|---------------------------------------|--|
| SENSOR FUNCTION | |
| SENSOR BOARD 1 -> NONE | |
| SENSOR BOARD 2 -> NONE | |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

2

Verify that the display matches sensor board implementation, then depress **ENTER**.
The following display appears.

14**OP Display**

| | |
|---------------------------------------|--------|
| OP | |
| IF02 | -> OFF |
| OP | -> OFF |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

Verify that the display matches the IF02 board and OP connection, then depress **ENTER**. The following display appears.

DISPLAY (Cont'd)

15

CMOS Memory Display

| | |
|---------------------------------------|----------|
| CMOS MEMORY | |
| AVAILABLE | -> 256KB |
| HW CAPACITY | -> 256KB |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

Verify that the display matches the CMOS memory implementation, then depress **ENTER**. The following display appears.

16

Calendar Display

| | |
|---------------------------------------|------------|
| CALENDAR | |
| DATE | 1994:01:01 |
| CLOCK | 12.34 |
| SEL ITEM BY ↑↓/INPUT MODE BY <ALTER> | |
| CONFIRM BY <ENTER>/RETURN BY <CANCEL> | |

Depress **ENTER** after setting date and time. The following display appears.

17**System Configuration Execution Check Display**

| | |
|---|--|
| SYSTEM CONFIGURATION | |
| EXEC INITIALIZATION | |
| ARE YOU SURE? <input checked="" type="checkbox"/> YES <input type="checkbox"/> NO | |
| SEL BY ← →/CONFIRM BY <ENTER> | |

2

Depress **ENTER** after selecting "YES". The CMOS memory contents are initialized and the following display appears.

18**System Configuration Display**

| |
|----------------------------|
| SYSTEM CONFIGURATION |
| INITIALIZE |
| MODIFY |
| DISPLAY |
| SEL BY ↑ ↓/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

The above procedures complete initialization.

19

Turn the power OFF to ON.

2.3 FILE INITIALIZATION

■ SELECTING FILES TO INITIALIZE

Select files to initialize on the file initialization display before starting initialization.

- (1) To initialize parameter files, refer to "Initializing Parameter Files".
- (2) To initialize condition files, refer to "Initializing Condition Files".
- (3) To initialize name files, refer to "Initializing Name Files".
- (4) To initialize system data files, refer to "Initializing System Data Files".
- (5) To initialize CIO ladders, refer to "Initializing CIO Ladders".
- (6) To initialize other resources, refer to "Initializing Other Files".
- (7) If either ALL FILES or JOB DATA are selected, a message appears asking to initialize them. After selecting YES, they will be initialized.

| INITIALIZE FILES |
|------------------------------|
| ALL FILES |
| PARAMETER FILES |
| CONDITION FILES |
| NAME FILES |
| SYSTEM DATA FILES |
| JOB DATA |
| CIO LADDER |
| OTHER FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

When the job data are initialized, the following files are also initialized.

- Position variable data
- User coordinate files
- Robot calibration files
- Tool calibration files

■ INITIALIZING PARAMETER FILES

By selecting PARAMETER FILES on the file initialization display, the parameter file selection display appears.

| PARAMETER FILES | | |
|-----------------|-----|-----|
| ALL FILES | SD | CM |
| RC | CIO | SE |
| RO | FD | VC |
| SV | AP | RSM |
| SVM | RS | OBS |
| SC | SP | |

SEL BY ↑ ↓ ← → / EXEC BY <ENTER>
RETURN BY <CANCEL>

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

2

INITIALIZING CONDITION FILES

Select **CONDITION FILES** on the file initialization display to call up the condition file select display.

- (1) If any of **ALL FILES**, **TOOL FILE**, **USER COORDINATE FILE**, **WEAVING FILE** or **WRIST WEAVING AMPLITUDE FILE** is selected, a message appears asking to initialize it. After selecting **YES**, the selected files will be initialized.
- (2) If **OTHER FILE** is selected, the condition file select display (other files) appears.

| |
|--|
| CONDITION FILES |
| ALL FILES |
| TOOL FILE |
| USER COORDINATE FILE |
| WEAVING FILE |
| WRIST WEAVING AMPLITUDE FILE |
| OTHER FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> |

Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting **YES**, depress **ENTER**. Then the selected files will be initialized.

If **OTHER FILE** are selected on the condition file select display, the condition file select display (other files) shown below appears.

- (1) If either **ALL FILES** or **CUTTING CONDITION FILE** is selected, a message appears asking to initialize it. After selecting **YES**, the selected files will be initialized.
- (2) If other options are selected, the corresponding file select display appears.

| |
|--|
| CONDITION FILES |
| ALL FILES |
| WELDING FILES |
| COM-ARC FILE |
| CUTTING CONDITION FILE |
| CO2 LASER FILE |
| PAINT FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> |

Selectable only at arc application

Selectable only at COM-ARC setting

Selectable only at laser cutting application

Selectable only at CO2 laser application

Selectable only at painting application

1

Initializing Welding Files

Select **WELDING FILES** on the condition file select display to call up the welding file select display.

| |
|--|
| WELDING FILES |
| ALL FILES |
| WELD MACHINE CHARACTERISTICS FILE |
| WELD MACHINE CHARACTERISTICS INIT FILE |
| ARC START CONDITION FILE |
| ARC QUIT CONDITION FILE |
| ARC CONDITION AUXILIARY FILE |
| MULTI-LAYER WELD CONDITION FILE |
| SEL BY ↑↓/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

Note : Multi-layer welding condition file is initialized only when CMOS extension memory is mounted.

2**2**

Initializing COM-ARC Files

Select **COM-ARC FILE** on the condition file select display to call up the COM-ARC file select display.

| |
|-----------------------------|
| COM-ARC FILE |
| ALL FILES |
| COM-ARC CONDITION FILE |
| COM-ARC DATA FILE |
| PHASE OFFSET DATA FILE-1 |
| PHASE OFFSET DATA FILE-2 |
| PATH CORRECT CONDITION FILE |
| SEL BY ↑↓/EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

INITIALIZING CONDITION FILES (Cont'd)

3

Initializing CO2 Laser File

Select CO2 LASER FILE on the condition file select display to call up the CO2 laser file select display.

| |
|---------------------------------|
| CO2 LASER FILE |
| ALL FILES |
| LASER PROCESSING CONDITION FILE |
| PIERCING CONDITION FILE |
| ULTRA PIERCING CONDITION FILE |
| CUTTING CONDITION FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

4

Initializing Paint File

Select PAINT FILE on the condition file select display to call up the paint file select display.

| |
|------------------------------|
| PAINT FILE |
| ALL FILES |
| PAINT GUN FILE |
| PAINT CONDITION FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

■ INITIALIZING NAME FILES

Select NAME FILES on the file initializing display to call up the name file select display.

| |
|-----------------------------------|
| NAME FILES |
| ALL FILES |
| RESERVE JOB NAME FILE |
| UNIVERSAL IN/OUT SIGNAL NAME FILE |
| USER VARIABLE NAME FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

2

■ INITIALIZING SYSTEM DATA FILES

Select SYSTEM DATA FILES on the file initialization display to call up the system data file select display.

| |
|------------------------------|
| SYSTEM DATA FILES |
| ALL FILES |
| SERVO MONITOR SIGNAL FILE |
| HOME CALIBRATION FILE |
| SPECIFIED POINT FILE |
| ROBOT CALIBRATION FILE |
| TOOL CALIBRATION FILE |
| OPERATION ORIGIN FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

■ INITIALIZING CIO LADDERS

Select CIO LADDER on the file initialization display to call up the CIO ladder select display.

- (1) A list of applications is displayed on which the current selected application is displayed inversely.
- (2) If the list is not contained on a single page, "DEPRESS MORE FOR NEXT PAGE" is displayed.

| CIO LADDER | |
|------------|-----------------|
| ARC | GENERAL PURPOSE |
| JIG-LESS | CO2-LASER |
| ARC+ARC | LASER CUTTING |
| HANDLING | PAINT |
| SPOT | * |
| SPOT/SPOT | * |

| |
|---|
| SEL BY ↑ ↓ / CONFIRM BY <ENTER> RETURN BY <CANCEL> |
|---|

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

■ INITIALIZING OTHER FILES

Select OTHER FILE on the file initialization display to call up the other file select display.

1

Select the files to initialize.

| OTHER FILE |
|-------------------------------|
| VISION FILE |
| CONVEYOR CHARACTERISTICS FILE |
| INTERRUPT JOB TABLE |

| |
|--|
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> |
|--|

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

Initializing Vision Files

Select VISION FILE on the other file select displays to call up the vision file select display.

| |
|------------------------------|
| VISION FILE |
| ALL FILES |
| TEMPLATE FILE |
| SITUATION FILE |
| CALIBRATION FILE |
| USER COORDINATE FILE |
| IMAGE DATA FILE |
| LINE FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

2.4 INITIALIZATION OF ROM FILES

■ SELECTING ROM FILES TO BE INITIALIZED

Select files to be initialized on the ROM file initialization display and depress **ENTER**.

- (1) To initialize WELDING FILES, refer to "Initializing Welding Files".
- (2) If ALL FILES are selected, a message appears asking to initialize them. After selecting YES, the selected files will be initialized.

| |
|--|
| INITIALIZE ROM FILE |
| ALL FILES |
| WELDING FILES |
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

■ INITIALIZING WELDING FILES

Select WELDING FILES on the ROM file initialization display to call up the welding file select display.

| |
|--|
| WELDING FILES |
| ALL FILES |
| ARC START CONDITION GUIDE FILE |
| ARC QUIT CONDITION GUIDE FILE |
| SEL BY ↑ ↓ / EXEC BY <ENTER> RETURN BY <CANCEL> |

→ Move the cursor to the files to initialize then depress **ENTER**. A message appears asking to initialize them. After selecting YES, depress **ENTER**. Then the selected files will be initialized.

SECTION 3

SYSTEM VERSION CHECK

3

| | |
|------------------------------|----|
| 3.1 SYSTEM VERSION CHECK | 62 |
| SYSTEM VERSION CHECK DISPLAY | 62 |
| 3.2 BOARD ROM VERSION | 63 |
| 3.3 SERVOPACK ROM VERSION | 63 |

3.1 SYSTEM VERSION CHECK

ROM versions of boards of the system and the SERVOPACKs can be displayed on the system version check displays.

(1) Board ROM Version Check

Versions of board ROM chips mounted on the system are displayed.

(2) SERVOPACK ROM Version Check

Versions of SERVOPACK ROM chips mounted on the system are displayed.

SYSTEM VERSION CHECK DISPLAY

1

Start up in maintenance mode and select SYSTEM VERSION.

| |
|------------------------------|
| MAINTENANCE MODE |
| SETUP SYSTEM |
| SYSTEM VERSION |
| HARDWARE DIAGNOSTICS |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |

→ Select processing by using
↑ or ↓ and depress
ENTER.

2

On the system version check display, move the cursor to the processing to be displayed and depress ENTER.

| |
|------------------------------|
| SYSTEM VERSION |
| BOARDS VERSION |
| SERVO-PACK VERSION |
| SEL BY ↑ ↓ / EXEC BY <ENTER> |
| RETURN BY <CANCEL> |

→ Select processing by using
↑ or ↓ and depress
ENTER.

3.2 BOARD ROM VERSION

Select BOARD ROM VERSION on the system version check display to call up the board ROM version display.

| BOARDS VERSION | | |
|--------------------|--------------------|--------------|
| PRM ->1. 00 | | |
| CP02->12. 34 | SV#1->12. 34/5. 67 | PP ->1. 23 |
| RSRV | SV#2->NONE | OP ->12. 34 |
| SL#1 | SV#3->NG | IF02->12. 34 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| C001->12. 34 | SV#7 | |
| IF01->12. 34 | RSRV | |
| RETURN BY <CANCEL> | | |

Version of parameter ROM is displayed.

Version of board ROMs are displayed.

| | |
|----------|---------------------|
| ->XX. XX | ROM version |
| ->NG | Communication error |
| ->NONE | No board |
| -> ? | Error on CP02 board |
| Blank | Parameter not set |

* For SV, a ROM version is displayed in a format of DSP/monitor CPU.

3.3 SERVOPACK ROM VERSION

Select SERVO-PACK VERSION on the system version check display to call up the SERVOPACK ROM version display.

| SERVO-PACK VERSION | | |
|--------------------|--------------|--------------|
| SV#1-1->000 | SV#1-2->000 | SV#1-3->000 |
| SV#2-1->000 | SV#2-2->000 | SV#2-3->000 |
| SV#3-1->NG | SV#3-2->001 | SV#3-3->NG |
| SV#4-1->NONE | SV#4-2->NONE | SV#4-3->NONE |
| SV#5-1 | SV#5-2 | SV#5-3 |
| SV#6-1 | SV#6-2 | SV#6-3 |
| SV#7-1 | SV#7-2 | SV#7-3 |
| RETURN BY <CANCEL> | | |

Versions of SERVOPACK ROMs are displayed.

| | |
|--------|---------------------|
| ->xxx* | ROM version |
| ->NG | Communication error |
| ->NONE | No board |
| -> ? | Error on CP02 board |
| Blank | Parameter not set |

* xxx = 000 to 999

SECTION 4

ALARM OF ONLINE MODE AT POWER ON

4


| | |
|---|----|
| 4.1 OUTLINE | 66 |
| 4.2 LIST OF PRE-ONLINE MODE ALARMS | 69 |
| 4.3 ALARM DISPLAY | 71 |
| ALARMS CAUSED BY HARDWARE ERROR | 71 |
| ALARMS CAUSED BY CMOS ERROR | 80 |
| ALARMS CAUSED BY SYSTEM CONFIGURATION ERROR | 82 |
| OTHER ALARMS | 86 |


4.1 OUTLINE

If the MRC system starts up in standard or simulated online mode, the following procedure is executed immediately after power is turned ON. Provided that the entire procedure is completed normally, the system gets ready in either online mode.


If an error occurs during the startup procedure, an alarm display appears and the system stops. (In simulated online mode, the procedure can be restarted by depressing **CANCEL**.)

Standard/Forced Online Mode Startup Procedure





4.1 OUTLINE (Cont'd)



4.2 LIST OF PRE-ONLINE MODE ALARMS

1 : Alarms Caused by Hardware Error

| No. | Name | Process | Corrective Action |
|-----|--------------------------------|---------|--|
| 10 | CPU BOARD INSERTION ERROR | × | Visual check |
| 20 | CPU COMMUNICATION ERROR | × | Visual check |
| 30 | ROM ERROR | × | Visual check |
| 40 | LOCAL RAM ERROR | × | Visual check |
| 50 | RTC ERROR | × | Visual check |
| 60 | ABUS COMMON RAM ERROR | × | Visual check |
| 70 | DBUS 2PORT RAM ERROR | × | Visual check |
| 80 | SBUS 2PORT RAM ERROR | × | Visual check |
| 90 | I/O MODULE COMMUNICATION ERROR | × | Visual check and parameter correction |
| 100 | IAMP COMMUNICATION ERROR | × | Visual check |
| 110 | IAMP PARAM MODIFICATION ERROR | × | Visual check |
| 120 | ENCODER COMMUNICATION ERROR | × | Visual check |
| 130 | ENCODER OVER SPEED | × | Visual check |
| 131 | ENCODER ABS DATA ERROR | × | Visual check |
| 132 | ENCODER BACKUP ERROR* | △* | Battery replacement and home position registration |
| 133 | ENCODER CHECKSUM ERROR | △* | Battery replacement and home position registration |
| 134 | ENCODER BATTERY ERROR † | ○† | Battery replacement |
| 135 | ENCODER OVER HEAT ‡ | ○‡ | Encoder cooling |

× : Operation halts.

△ : Changed to online mode after alarm is reset.

○ : Message displayed at any time after changed to online mode.

2 : Alarms Caused by CMOS Data Error

| No. | Name | Process | Corrective Action |
|-----|---------------------------|---------|---------------------------------------|
| 200 | PARAM ERROR | × | Re-initialization in maintenance mode |
| 210 | SYSTEM CONFIG DATA ERROR | × | Re-initialization in maintenance mode |
| 220 | JOB MANAGEMENT DATA ERROR | × | Re-initialization in maintenance mode |
| 230 | CIO LADDER ERROR | × | Re-initialization in maintenance mode |

4.2 LIST OF PRE-ONLINE MODE ALARMS (Cont'd)

3 : Alarms Caused by System Configuration Error

| No. | Name | Process | Corrective Action |
|-----|---------------------------------|---------|---------------------------------------|
| 300 | SYSTEM CONFIG DATA VERIFY ERROR | × | Re-initialization in maintenance mode |
| 310 | CMOS MEMORY SIZE VERIFY ERROR | × | Re-initialization in maintenance mode |
| 320 | I/O MODULE VERIFY ERROR | × | Re-initialization in maintenance mode |
| 330 | INVALID PARAM | × | Parameter value correction |
| 340 | SERVOPACK TYPE VERIFY ERROR | × | Parameter value correction |
| 350 | ENCODER TYPE VERIFY ERROR | × | Parameter value correction |
| 360 | APPLICATION VERIFY ERROR | × | Re-initialization in maintenance mode |
| 370 | SENSOR FUNCTION VERIFY ERROR | × | Re-initialization in maintenance mode |

4 : Other Alarms

| No. | Name | Process | Corrective Action |
|-----|--------------------------|---------|-------------------|
| 400 | PARAM TRANSMISSION ERROR | × | Visual check |
| 410 | MODE CHANGE ERROR | × | Visual check |

If an alarm occurs, it is displayed on the PP display.

Alarms occurring during startup procedure are recorded in offline alarm history in the same way as alarms occurring during operations in online mode.

- * If **CANCEL** is depressed after any of the following alarms occur, the encoder of the axis where the alarm occurred is reset, home positioning completion status is reset to 0, and online mode is started.

132 ENCODER BACKUP ERROR
133 ENCODER CHECKSUM ERROR

- † If the following alarm occurs, the encoder of the axis where the alarm occurred is unconditionally alarm-masked. After transition to online mode, "ENCODER BATTERY ERROR [axis-number]" is displayed continuously.

134 ENCODER BATTERY ERROR

- ‡ If the following alarm occurs, the encoder of the axis where the alarm occurred is unconditionally alarm-masked. After transition to online mode, "ENCODER OVER HEAT [axis-number]" is displayed continuously.
In order to prevent further overheating, playback operation is prohibited by interlocking.

135 ENCODE OVER HEAT

4.3 ALARM DISPLAY

Count-down Display

| |
|-------------------------------|
| YASNAC-MRC |
| PERFORMING SYSTEM DIAGNOSTICS |
| COUNT -> 999 |
| |
| |

ALARMS CAUSED BY HARDWARE ERROR

4

Alarm 10 Display

| | | |
|---------------------------|--------------|------|
| ALARM 10 | | |
| CPU BOARD INSERTION ERROR | | |
| CP02 -> OK | SV#1 -> OK | PP |
| RSRV | SV#2 -> NONE | OP |
| SL#1 | SV#3 | IF02 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| CP01 -> OK | SV#7 | |
| IF01 -> OK | RSRV | |
| | | |

OK : Normal
NONE : No board inserted

Explanation : CPU board presence check error

Action to be taken : Check status of insertion of the board marked NONE.
Replace ROM of the board marked NONE.
Replace the board marked NONE.

ALARMS CAUSED BY HARDWARE ERROR (Cont'd)

Alarm 20 Display

| | | | |
|-------------------------|------------|------|---------------------------|
| ALARM 20 | | | |
| CPU COMMUNICATION ERROR | | | |
| CP02 -> OK | SV#1 -> OK | PP | OK : Normal NG : Error |
| RSRV | SV#2 -> NG | OP | |
| SL#1 | SV#3 | IF02 | |
| SL#2 | SV#4 | RSRV | |
| RSRV | SV#5 | RSRV | |
| RSRV | SV#6 | RSRV | |
| CP01 -> OK | SV#7 | | |
| IF01 -> OK | RSRV | | |

Explanation : CPU communication test error

Action to be taken : Check status of insertion of the board marked NONE.

Replace ROM of the board marked NONE.

Replace the board marked NONE.

Alarm 30 Display

| | | | |
|------------|------------|------|---------------------------|
| ALARM 30 | | | |
| ROM ERROR | | | |
| CP02 -> OK | SV#1 -> OK | PP | OK : Normal NG : Error |
| RSRV | SV#2 -> NG | OP | |
| SL#1 | SV#3 | IF02 | |
| SL#2 | SV#4 | RSRV | |
| RSRV | SV#5 | RSRV | |
| RSRV | SV#6 | RSRV | |
| CP01 -> OK | SV#7 | | |
| IF01 -> OK | RSRV | | |

Explanation : ROM total value check error

Action to be taken : Replace the ROM of the board marked NG.

Alarm 40 Display

| | | |
|-------------------|------------|------|
| ALARM 40 | | |
| RAM ERROR (LOCAL) | | |
| CP02 -> OK | SV#1 -> OK | PP |
| RSRV | SV#2 -> NG | OP |
| SL#1 | SV#3 | IF02 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| CP01 -> OK | SV#7 | |
| IF01 -> OK | RSRV | |

OK : Normal
NG : Error

Explanation : Local RAM test error

Action to be taken : Replace the board marked NG.

Alarm 50 Display

| | | |
|------------|------------|------|
| ALARM 50 | | |
| RTC ERROR | | |
| CP02 -> OK | SV#1 -> OK | PP |
| RSRV | SV#2 -> NG | OP |
| SL#1 | SV#3 | IF02 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| CP01 -> OK | SV#7 | |
| IF01 -> OK | RSRV | |

OK : Normal
NG : Error

Explanation : RTC test error

Action to be taken : Replace the board marked NG.

ALARMS CAUSED BY HARDWARE ERROR (Cont'd)

Alarm 60 Display

```

ALARM 60
  RAM ERROR (A-BUS COMMON)
  CP02 -> OK
  RSRV
  SL#1
  SL#2
  RSRV
  RSRV
  CP01 -> OK
  IF01 -> OK

```

OK : Normal
NG : Error

Explanation : A-bus common RAM error

Action to be taken : Check inserted status of CP01/CP02/IF01/SL boards.
Replace the CP01/CP02/IF01/SL boards.

Alarm 70 Display

```

ALARM 70
RAM ERROR (D-BUS 2-PORT)
CP02 -> OK          SV#1 -> OK
CP02 -> OK          SV#2 -> OK
CP02                SV#3
CP02                SV#4
CP02                SV#5
CP02                SV#6
CP02                SV#7
CP02                RSRV

```

OK : Normal
NG : Error

Explanation : D-bus 2-port RAM test error

Action to be taken : Check inserted status of CP02/SV boards.
Replace the CP02/SV boards.

Alarm 80 Display

| | |
|--------------------------|------------|
| ALARM 80 | |
| RAM ERROR (S-BUS 2-PORT) | |
| CP01 -> OK | IF02 -> OK |
| CP01 | RSRV |
| CP01 | RSRV |
| CP01 | RSRV |

OK : Normal
NG : Error

Explanation : S-bus 2-port RAM error

Action to be taken : Check inserted status of CP01 board/board marked NG.
Replace the CP01 board/board marked NG.

Alarm 90 Display

| | |
|-------------------------------|--|
| ALARM 90 | |
| IO MODULE COMMUNICATION ERROR | |
| SLOT-1 -> OK | |
| SLOT-2 -> OK | |
| SLOT-3 | |
| SLOT-4 | |
| SLOT-5 -> NG | |
| RY -> NG | |
| PBOX -> OK | |

OK : Normal
NG : Error

Explanation : I/O module communication test error

Action to be taken : Check inserted status of the module marked NG.
Replace the module marked NG.

ALARMS CAUSED BY HARDWARE ERROR (Cont'd)

Alarm 100 Display

ALARM 100

IAMP COMMUNICATION ERROR

| | | |
|--------------|--------------|--------------|
| SV#1-1 -> OK | SV#1-2 -> OK | SV#1-3 -> NG |
| SV#2-1 -> OK | SV#2-2 -> OK | SV#2-3 -> NG |
| SV#3-1 | SV#3-2 | SV#3-3 |
| SV#4-1 | SV#4-2 | SV#4-3 |
| SV#5-1 | SV#5-2 | SV#5-3 |
| SV#6-1 | SV#6-2 | SV#6-3 |
| SV#7-1 | SV#7-2 | SV#7-3 |

OK : Normal

NG : Error

SV#X-X : Y-axis of SV#X-board

Explanation : Current amplifier communication test error

Action to be taken : Check cable connection between the SV board and
SERVOPACK (of the axis marked NG).

Replace the SV board or SERVOPACK (of the axis marked NG).

Alarm 110 Display

ALARM 110

IAMP PARAM MODIFICATION ERROR

| | | |
|--------------|--------------|--------------|
| SV#1-1 -> OK | SV#1-2 -> OK | SV#1-3 -> NG |
| SV#2-1 -> OK | SV#2-2 -> OK | SV#2-3 -> NG |
| SV#3-1 | SV#3-2 | SV#3-3 |
| SV#4-1 | SV#4-2 | SV#4-3 |
| SV#5-1 | SV#5-2 | SV#5-3 |
| SV#6-1 | SV#6-2 | SV#6-3 |
| SV#7-1 | SV#7-2 | SV#7-3 |

OK : Normal

NG : Error

Explanation : Current amplifier parameter modification error

Action to be taken : Check cable connection between the SV board and
SERVOPACK (of the axis marked NG).

Replace the SV board or SERVOPACK (of the axis marked NG).

Alarm 120 Display

| | |
|-----------------------------|--------------------|
| ALARM 120 | |
| ENCODER COMMUNICATION ERROR | |
| ROBOT1 | -> S L U R B T |
| ROBOT2 | -> S L U R B T A B |
| BASE1 | -> 1 |
| BASE2 | -> 1 |
| STATION1 | -> 1 2 3 |
| STATION2 | -> 1 |
| STATION3 | -> 1 |
| STATION4 | -> 1 |

Inverted display : Error

Explanation : Encoder communication error

Action to be taken : Check cable connection between the SV board and
SERVOPACK (of the axis marked NG).

Replace the SV board or SERVOPACK (of the axis marked NG).

4

Alarm 130 Display

| | |
|-------------------|--------------------|
| ALARM 130 | |
| ENCODER OVERSPEED | |
| ROBOT1 | -> S L U R B T |
| ROBOT2 | -> S L U R B T A B |
| BASE1 | -> 1 |
| BASE2 | -> 1 |
| STATION1 | -> 1 2 3 |
| STATION2 | -> 1 |
| STATION3 | -> 1 |
| STATION4 | -> 1 |

Inverted display : Error

Explanation : Encoder error

Action to be taken : Replace the encoder (of inverted axis).

ALARMS CAUSED BY HARDWARE ERROR (Cont'd)

Alarm 131 Display

```
ALARM 131
ENCODER ABSO DATA ERROR
ROBOT1  -> S L U R B T
ROBOT2  -> S L U R B T A B
BASE1   -> 1
BASE2   -> 1
STATION1 -> 1 2 3
STATION2 -> 1
STATION3 -> 1
STATION4 -> 1

RESET ALARM BY <CANCEL>
```

Inverted display : Error

Explanation : Encoder error

Action to be taken : Replace the encoder (of inverted axis).

Alarm 132 Display

```
ALARM 132
ENCODER BACK-UP ERROR
ROBOT1  -> S L U R B T
ROBOT2  -> S L U R B T A B
BASE1   -> 1
BASE2   -> 1
STATION1 -> 1 2 3
STATION2 -> 1
STATION3 -> 1
STATION4 -> 1

RESET ALARM BY <CANCEL>
```

Inverted display : Error

Explanation : Encoder error

Action to be taken : Replace the battery and register home position.

Alarm 133 Display

| | |
|-------------------------|--------------------|
| ALARM 133 | |
| ENCODER CHECKSUM ERROR | |
| ROBOT1 | -> S L U R B T |
| ROBOT2 | -> S L U R B T A B |
| BASE1 | -> 1 |
| BASE2 | -> 1 |
| STATION1 | -> 1 2 3 |
| STATION2 | -> 1 |
| STATION3 | -> 1 |
| STATION4 | -> 1 |
| RESET ALARM BY <CANCEL> | |

Inverted display : Error

Explanation : Encoder error

Action to be taken : Replace the battery and register home position.

ALARMS CAUSED BY CMOS ERROR

Alarm 200 Display

ALARM 200
FAULT (PARAMETER)

SC : SYSTEM MATCHING PARAMETER

Explanation : Parameter sum check error
Action to be taken : Initialize the parameter again.

Alarm 210 Display

ALARM 210
FAULT (SYSTEM CONFIG-DATA)

Explanation : System configuration data sum check error
Action to be taken : Initialize the system configuration again.

Alarm 220 Display

| |
|--|
| ALARM 220 FAULT (JOB MANAGEMENT DATA) |
| |

Explanation : Job management data sum check error.
Action to be taken : Initialize the job again.

Alarm 230 Display

| |
|---------------------------------|
| ALARM 230 FAULT (CIO LADDER) |
| |

Explanation : CIO ladder sum check error
Action to be taken : Initialize the CIO ladder again.

ALARMS CAUSED BY SYSTEM CONFIGURATION ERROR

Alarm 300 Display

ALARM 300
VERIFY ERROR (SYSTEM CONFIG-DATA)

Explanation : System configuration data verification test error
Action to be taken : Initialize the system configuration again.

Alarm 310 Display

ALARM 310
VERIFY ERROR (CMOS MEMORY SIZE)

Explanation : CMOS memory capacity verification error
(System configuration setting differs from hardware mounted status.)
Action to be taken : Verify the extension CMOS board mounted status.

Alarm 320 Display

ALARM 320
VERIFY ERROR (I/O MODULE)

SLOT-1 -> OK
SLOT-2 -> OK
SLOT-3
SLOT-4
SLOT-5 -> NG

OK : Matched
NONE : Not matched

Explanation : I/O module verification error

(System configuration setting differs from hardware mounted status.)

Action to be taken : Verify the type of the module marked NG.

Alarm 330 Display

ALARM 330
ILLEGAL PARAMETER

Explanation : Parameter value error

(CIO, RC×G, SV×G, SV1D, SV2D, SVM parameters)

Action to be taken : Correct parameter value.

ALARMS CAUSED BY SYSTEM CONFIGURATION ERROR (Cont'd)

Alarm 340 Display

ALARM 340

VERIFY ERROR (SERVOPACK TYPE)

| | | |
|--------------|--------------|--------------|
| SV#1-1 -> OK | SV#1-2 -> OK | SV#1-3 -> NG |
| SV#2-1 -> OK | SV#2-2 -> OK | SV#2-3 -> NG |
| SV#3-1 | SV#3-2 | SV#3-3 |
| SV#4-1 | SV#4-2 | SV#4-3 |
| SV#5-1 | SV#5-2 | SV#5-3 |
| SV#6-1 | SV#6-2 | SV#6-3 |
| SV#7-1 | SV#7-2 | SV#7-3 |

OK : Matched

NONE : Not matched

Explanation : SERVOPACK type verification error

(Parameter setting differs from hardware mounted status.)

Action to be taken : Correct parameter value.

Alarm 350 Display

ALARM 350

VERIFY ERROR (ENCODER TYPE)

| | | | | | | | | |
|----------|----|---|---|---|---|---|---|---|
| ROBOT1 | -> | S | L | U | R | B | T | |
| ROBOT2 | -> | S | L | U | R | T | A | B |
| BASE1 | -> | 1 | | | | | | |
| BASE2 | -> | 1 | | | | | | |
| STATION1 | -> | 1 | 2 | 3 | | | | |
| STATION2 | -> | 1 | | | | | | |
| STATION3 | -> | 1 | | | | | | |
| STATION4 | -> | 1 | | | | | | |

Inverted axis : Error

Explanation : Encoder type verification error

(Parameter setting differs from hardware mounted status.)

Action to be taken : Correct parameter value.

Alarm 360 Display

ALARM 360
VERIFY ERROR (APPLICATION)

Explanation : Application setting verification error
Action to be taken : Correct parameter value.

Alarm 370 Display

ALARM 370
VERIFY ERROR (SENSOR FUNCTION)

SENSOR BOARD 1 -> OK
SENSOR BOARD 2 -> NG

OK : Matched
NG : Not matched

Explanation : Sensor function verification error
(System configuration setting differs from hardware mounted status.)
Action to be taken : Verify the type of the board marked NG.

OTHER ALARMS

Alarm 400 Display

| | | |
|-------------------------------------|------------|------|
| ALARM 400 | | |
| PARAMETER TRANSMISSION ERROR | | |
| CP02 -> OK | SV#1 -> OK | PP |
| RSRV | SV#2 -> NG | OP |
| SL#1 | SV#3 | IF02 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| CP01 -> OK | SV#7 | |
| IF01 -> OK | RSRV | |

OK : Completed normally

NG : Transmission error

Explanation : Parameter transmission error

Alarm 410 Display

| | | |
|--------------------------|------------|------|
| ALARM 410 | | |
| MODE CHANGE ERROR | | |
| CP02 -> OK | SV#1 -> OK | PP |
| RSRV | SV#2 -> NG | OP |
| SL#1 | SV#3 | IF02 |
| SL#2 | SV#4 | RSRV |
| RSRV | SV#5 | RSRV |
| RSRV | SV#6 | RSRV |
| CP01 -> OK | SV#7 | |
| IF01 -> OK | RSRV | |

OK : Completed normally

NONE : Mode change error

Explanation : Mode change error

SECTION 5

MCP01 BOARD 7-SEGMENT LED DISPLAY

5

| | |
|---------------------------------|----|
| ■ 1-DIGIT ERROR CODE DISPLAY | 88 |
| ■ 4-DIGIT CODE REPEATED DISPLAY | 88 |

While the MRC system is functioning properly, the 7-segment LEDs of the MCP01 (SYSCON) board display nothing. If an error occurs, the LEDs indicate the code of the error.

■ 1-DIGIT ERROR CODE DISPLAY

| Display | Meaning |
|----------|--|
| .8. | MCP01 or SROMS error (MCP01 or SROMS board is defective.) |
| (Period) | NMI occurred during NINDY monitor operation. (MCP01, MCP02, MIF01, or MSV01 board is defective or not inserted properly.) |
| 0 | MIF01 (CIO) board error (MIF01 board is defective or not inserted properly.) |
| I to F | Communication error between MCP01 and programming pendant |

Details of Communication Error between MCP01 and Programming Pendant

| Display | Meaning |
|---------|--|
| 1 | System alarm |
| 2 | Data transmission buffer overflow |
| 3 | Data receiving buffer overflow |
| 4 | Data receiving time-over |
| 5 | SIO receiving alarm (overflow, flaming, parity error) |
| 6 | SIO receiving alarm (data transmission disabled) |
| 7 | Receiving data BCC alarm |
| 9 | Programming Pendant software watchdog alarm |
| a | Receiving data command length error |
| d | Denial response from programming pendant (BCC alarm detection at programming pendant) |
| E | Failed data transmission establishment other than at power ON |
| F | Failed data transmission establishment at program pendant alarm occurrence / power setup |

■ 4-DIGIT CODE REPEATED DISPLAY

If a non-maskable interrupt (NMI) occurs, a 4-digit interrupt code (listed on the next page) is displayed repeatedly.

Example : If a watchdog timer error (whose alarm code is 0906) occurs on the MCP01 board, it is indicated as :

0 → 9 → 0 → 6 → . → 0 → 9 → 0 → 6 → . repeat

| Return Code | Meaning |
|-------------|-----------------|
| F000 | Power lost * |
| F001 | Watchdog error |
| F002 | Access error |
| F003 | A-bus error |
| F004 | Other CPU error |

* In thermostat diagnosis mode (rotary switch position 5), return codes from all CPUs at the time of occurrence are displayed on the result display.

| Display | Meaning |
|---------|------------------------------|
| 0900's | Watchdog timer error (A-bus) |
| 0900 | MCP02 |
| 0901 | Reserved |
| 0902 | SL#1 |
| 0903 | SL#2 |
| 0904 | Reserved |
| 0905 | Reserved |
| 0906 | MCP01 |
| 0907 | MIF01 |
| 0910's | Watchdog timer error (D-bus) |
| 0910 | MSV#1 |
| 0911 | MSV#2 |
| 0912 | MSV#3 |
| 0913 | MSV#4 |
| 0914 | MSV#5 |
| 0915 | MSV#6 |
| 0916 | MSV#7 |
| 0917 | Reserved |
| 0920's | Watchdog timer error (S-bus) |
| 0920 | MIF02 |
| 0930's | Access error (A-bus) |
| 0930 | MCP02 |
| 0931 | Reserved |
| 0932 | SL#1 |
| 0933 | SL#2 |
| 0934 | Reserved |
| 0935 | Reserved |
| 0936 | MCP01 |
| 0937 | MIF01 |
| 0940's | A-bus error |
| 0940 | MCP02 |
| 0941 | Reserved |
| 0942 | SL#1 |
| 0943 | SL#2 |
| 0944 | Reserved |
| 0945 | Reserved |
| 0946 | MCP01 |
| 0947 | MIF01 |

(Cont'd)

■ 4-DIGIT CODE REPEATED DISPLAY (Cont'd)

(Cont'd)

| Display | Meaning |
|---------|--|
| 0950's | CPU hang-up error (A-bus) |
| 0950 | MCP02 |
| 0951 | Reserved |
| 0952 | MSL#1 |
| 0953 | MSV#2 |
| 0954 | Reserved |
| 0955 | Reserved |
| 0956 | MCP01 |
| 0957 | MIF01 |
| 0960's | CPU hang-up error (D-bus) |
| 0960 | MSV#1 |
| 0961 | MSV#2 |
| 0962 | MSV#3 |
| 0963 | MSV#4 |
| 0964 | MSV#5 |
| 0965 | MSV#6 |
| 0966 | MSV#7 |
| 0967 | Reserved |
| 0970's | CPU hang-up error (S-bus) |
| 0970 | MIF02 |
| 0999's | |
| 0999 | NMI (non-maskable interrupt) factor judgement disabled |

Action to be Taken when 7-segment LEDs of MCP01 Board Light

- Refer to the maintenance procedure and verify that :
 - All boards in the CPU rack are inserted in proper slots,
 - All boards in the I/O rack are inserted in proper slots,
 - Cables between boards are connected properly, and
 - ROMs are properly inserted into all boards in the CPU rack. (Make sure of this particularly after replacing ROMs.)
- ↓
- If all these connections are perfect, proceed to the steps below.
- ↓
- Remove from the rack the boards that correspond to the code displayed on the 7-segment LED and insert it again.
 - (The board contact is probably faulty.)
- ↓
- Proceed to the next step if the same error occurs after restarting the system. (Do it in other steps.)
- ↓
- Remove other boards from the rack and insert them again.
 - Because of the hardware configuration, faulty contact with a board may be indicated by another board's error code.
- ↓
- Start up in maintenance mode.
 - If the system is not started, observe the procedure of "Action to be Taken when Startup in Maintenance Mode Failed" explained below.
- ↓
- Select the system version check display in maintenance mode. Confirm that there is a ROM version display for all the mounted boards. If any board is omitted, replace that board.
 - The board is probably defective.
- ↓
- Replace the board that corresponds to the code displayed on the 7-segment LED.
 - (The board is probably defective.)
- ↓
- Replace other boards.
 - Because of the hardware configuration, failure of a board may be indicated by another board's error code.
- ↓
- Contact your YASKAWA representative.

Action to be Taken when Startup in Maintenance Mode Failed



- Leaving the MCP01 and MIF01 boards only, remove all boards (MCP02, MSL01, MSL02 and MSV) from the rack and turn ON power.
 - If startup in maintenance mode fails again, the MCP01 or MIF01 board probably has a connection failure or is defective.
 - ↓
 - If the system has been started up, insert the removed boards one by one each time checking if the system can be started.
 - The board that has been inserted before failure in startup in maintenance mode probably has a connection failure or is defective.
- * The system can be started up in maintenance mode with no other boards except boards MCP01 and MIF01.

APPENDIX 1

PP (PROGRAMMING PENDANT) MAINTENANCE

| | |
|-------------------------|-----|
| 1.1 FUNCTION OUTLINE | 94 |
| 1.2 SECTION DIAGNOSIS | 96 |
| 1.3 SYSTEM DIAGNOSIS | 104 |
| 1.4 DIAGNOSIS MENU TREE | 105 |

1.1 FUNCTION OUTLINE

Software diagnosis can be conducted by key operations on the programming pendant. Turn OFF power to the robot. Holding down both  and  turn ON power to the MRC. The system starts up in maintenance mode and the display appears as shown below.

| | |
|-----------------------------------|---------|
| PP MAINTENANCE MODE | Ver 2.9 |
| [LANGUAGE] | |
| 1. JAPANESE | |
| 2. ENGLISH | |
| SELECT BY <↑↓>/CONFIRM BY <ENTER> | |
| PLEASE SELECT LANGUAGE | |


Select a display language. For the display screens in the following explanation, English has been selected.

There are two diagnosis procedures.

- Section diagnosis : Selected test is conducted. (Manual diagnosis)
- System diagnosis : The entire system is diagnosed automatically.

| | |
|------------------------|---------|
| PP MAINTENANCE | Ver 2.9 |
| 1. SECTION DIAGNOSTICS | |
| 2. SYSTEM DIAGNOSTICS | |
| ★OPERATION★ | |
| ↑↓: SELECT MENU | |
| CONFIRM BY <ENTER> | |
| ABORT BY <CANCEL> | |
| PLEASE SELECT FUNCTION | |

Display on the programming pendant screen consists of the following four areas.



(1) Status Display Area

Diagnosis type and the programmable ROM version are displayed.

(2) General-purpose Area

Necessary information of the ongoing diagnosis test is displayed. The name of the test is displayed in the upper left of the area.

(3) Message Area

Error messages and other interactive system messages are displayed. These messages are automatically scrolled in the horizontal direction. This motion is indicative of normal function of the programming pendant.

(4) Operation Instruction Area

Possible operations are suggested here.

1.2 SECTION DIAGNOSIS

SECTION DIAGNOSIS

Select section diagnosis to call up the menu shown below. The ->> mark after a test name means that there are submenus for that test.

| | | |
|------------------------|-----------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| 1. ROM TEST | | |
| 2. RAM TEST | | |
| 3. KEY TEST | | |
| 4. LED TEST ->> | | |
| 5. LCD TEST ->> | | |
| 6. BELL TEST | | |
| 7. SIO TEST | | |
| PLEASE SELECT FUNCTION | | |
| ABORT BY <CANCEL> | | |

Select 1. ROM TEST to call up the display shown below and start ROM test. If an error occurs, an error message appears on the message area and diagnosis process stops. Replace the PROM. This test is repeated until the **CANCEL** key is depressed.

| | | |
|--------------------------|-----------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| ROM TEST | Try = 760 | Err = 0 |
| TOTAL VALUE = 0 | | |
| EXECUTING ROM TEST . . . | | |
| ABORT BY <CANCEL> | | |

Select 2. RAM TEST to call up the display shown below and start RAM test. If an error occurs, an error message appears on the message line. Replace the CPU board. This test is repeated until the **CANCEL** key is depressed.

| | | |
|--------------------------|------------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| RAM TEST | Try = 18.5 | Err = 0 |
| RAM ADDRESS = 0 : 5800 | | |
| EXECUTING RAM TEST . . . | | |
| ABORT BY <CANCEL> | | |

Select 3. KEY TEST to call up the display shown below.

When one key on the programming pendant is depressed, the corresponding bit of the corresponding group is set to "1" and displayed inversely. Correspondence between the bits and the keys is shown in the keyboard matrix below. If the bit remains "0" after the corresponding key is depressed, the key is defective. Replace the keyboard chip. Depressing the **CANCEL** key returns to the preceding display.

| | | |
|----------------------|----------------------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| KEY TEST | Try = 0 | Err = 0 |
| KEY-GRP0 : 1000-0000 | KEY-GRP4 : 0000-0000 | |
| KEY-GRP1 : 0000-0000 | KEY-GRP5 : 0000-0000 | |
| KEY-GRP2 : 0000-0000 | KEY-GRP6 : 0000-0000 | |
| KEY-GRP3 : 0000-0000 | KEY-GRP7 : 0000-0000 | |
| DEPRESS KEY . . . | | |
| RETURN BY <CANCEL> | | |

1.2 SECTION DIAGNOSIS (Cont'd)

Keyboard Matrix Configuration

| Bit Group | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|--------------|---------------|-----------------|------------|----------------|----------------|---------------|------------|------------|
| GRP0 | * | HOLD RELEASE | ENABLE | MAN SPD SLW | ▲ | F · 3 | F · 2 | F · 1 |
| GRP1 | | HIGH SPD | COORD | MAN SPD FST | MORE | CUS- TOMER | F · 5 | F · 4 |
| GRP2 | | DELETE | INSERT | MODIFY | FUNC | SELECT | EDIT | DISP |
| GRP3 | FWD | BWD | T+ (z+) | B+ (y+) | R+ (x+) | U+ (z+) | L+ (y+) | S+ (x+) |
| GRP4 | TEST START | ENTER | T- (z-) | B- (y-) | R- (x-) | U- (z-) | L- (y-) | S- (x-) |
| GRP5 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| GPR6 | ↑ | ← | OPEN | DSP CHG | — | . | 9 | 8 |
| GRP7 | ↓ | → | POS LV1 | PLAY SPD | MOTION TYPE | CANCEL | | |

Select 4. LED TEST to call up the display shown below.

| | |
|--|---------|
| PP MAINTENANCE [SECTION] | Ver 2.9 |
| 1. LED TEST (INDIVIDUAL MODE) 2. LED TEST (SIMULTANEOUS MODE) | |
| PLEASE SELECT FUNCTION | |
| ABORT BY <CANCEL> | |

LED test has two modes :

1. Individual mode
2. Simultaneous mode

Select 1. LED TEST (INDIVIDUAL MODE) to call up the display shown below. The LEDs light one by one. As one LED lights, the corresponding bit of the corresponding group is set to "1" and is displayed inversely. Correspondence between the bits and the LEDs is shown in the keyboard matrix below. If the bit remains "0" after the corresponding LED lights, the LED is defective. Replace the keyboard chip. This test is repeated until the **CANCEL** key is depressed.

| | |
|--------------------------|----------------------|
| PP MAINTENANCE [SECTION] | Ver 2.9 |
| LED TEST | Try = 4 Err = 0 |
| LED-GRP0 : 0000 | LED-GRP3 : 0000 |
| LED-GRP1 : 0000 | LED-GRP4 : 0010 |
| LED-GRP2 : 0000 | |
| EXECUTING LED TEST . . . | |
| ABORT BY <CANCEL> | |

1.2 SECTION DIAGNOSIS (Cont'd)

Select 2. LED TEST (SIMULTANEOUS MODE) to call up the display shown below. All the LEDs start blinking at once. If there is any LED that does not blink, replace the keyboard chip. The LEDs continue blinking until the **CANCEL** key is depressed.

| | | |
|--------------------------|-----------------|---------|
| PP MAINTENANCE [SECTION] | | Ver 2.9 |
| LED TEST | Try = 4 | Err = 0 |
| LED-GRP0 : 1111 | LED-GRP3 : 1111 | |
| LED-GRP1 : 1111 | LED-GRP4 : 1111 | |
| LED-GRP2 : 1111 | | |
| EXECUTING LED TEST . . . | | |
| ABORT BY <CANCEL> | | |

LED Matrix Configuration

| Bit Group | b3 | b2 | b1 | b0 |
|--------------|-----------------|--------|-------------|-------------|
| GRP0 | COORD | | | |
| | USER | TOOL | WLD/CYL | JOINT |
| GRP1 | MAN SPD | | | |
| | INCH | SLW | MED | FST |
| GRP2 | HOLD RELEASE | | ENABLE | NOT USED |
| GRP3 | MODIFY | INSERT | DELETE | |
| GRP4 | DSP CHG | OPEN | PLAY SPD | POS LV1 |


Select 5. LCD TEST to call up the display shown below.

| | |
|--|---------|
| PP MAINTENANCE [SECTION] | Ver 2.9 |
| 1. LCD TEST 2. LIGHT TEST 3. FONT TEST | |
| PLEASE SELECT FUNCTION | |
| ABORT BY <CANCEL> | |

LCD test has three options.

1. Pinhole test
2. Back light test
3. Font test

Select 1. PINHOLE TEST to call up the display shown below, the entire display starts blinking. If there is any unevenness or small holes in the display, the liquid crystal display is defective. Replace the LCD. To return to the preceding display, depress the **CANCEL** key.



1.2 SECTION DIAGNOSIS (Cont'd)

Select 2. BACK LIGHT TEST to call up the display shown below, and at the same time the back light starts blinking. If the back light does not blink, replace it. Darken the room to check the blinking. To return to the preceding display, depress the **CANCEL** key.

| | | |
|--|-----------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| LIGHT TEST | Try = 381 | Err = 0 |
| <p>Make sure that BACK-LIGHT turn on and off</p> | | |
| BLINKING BACK-LIGHT | | |
| ABORT BY <CANCEL> | | |

Select 3. FONT TEST to call up the display shown below, where characters of various fonts are displayed repeatedly. If nothing is displayed after selecting font test, replace the font ROM. To return to the preceding display, depress the **CANCEL** key.

PP MAINTENANCE [SECTION] Ver 2.9

LCD TEST Try = 0 Err = 0

ゝ。。。・。；？！'`~"-_ \ √
ゞ〃全∕○- - - △ ~ || | " ""
) □ [] {} ◇ 《》 「 」 【 】 +- ±
■ ÷ = ≠ < > ≤ ≥ ∞ ∴ ♂ ♀ ° ™ ¥ \$ ¢ £
& * % @ § ☆ ★ ○ ● ◎ ◆ ◻ ▣ ▲ ▼ ✕ 〒
← ↑ ↓ =

EXECUTING FONT TEST . . .

ABORT BY <CANCEL>

Select 6. BELL TEST to call up the display shown below, and at the same time the bell starts ringing. The bell sound continues until the **CANCEL** key is depressed. If the bell does not sound, replace the CPU board. To return to the preceding display, depress the **CANCEL** key.

| | | |
|---------------------------|-----------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| BELL TEST | Try = 0 | Err = 0 |
| EXECUTING BELL TEST . . . | | |
| ABORT BY <CANCEL> | | |

Select 7. SIO (SYSTEM I/O) TEST to call up the display shown below and starts the SIO test. If an error occurs, an error message appears on the message area. Replace the CPU board, this test is repeated until the **CANCEL** key is depressed.

| | | |
|--------------------------|-----------|---------|
| PP MAINTENANCE | [SECTION] | Ver 2.9 |
| SIO TEST | Try = 1 | Err = 0 |
| SEND DATA : | | |
| RECEIVE DATA : | | |
| EXECUTING SIO TEST . . . | | |
| ABORT BY <CANCEL> | | |


Exclusive-use cables are needed for this test. If this diagnosis is executed without connecting the exclusive-use cable, an error occurs.

1.3 SYSTEM DIAGNOSIS


SYSTEM DIAGNOSIS

Select 2. SYSTEM DIAGNOSTICS to start overall diagnosis on the system. It takes about two minutes to complete the whole procedure of system diagnosis. System diagnosis is repeated until the **CANCEL** key is depressed. If an error occurs, an error message appears on the message area and diagnosis process stops.

Flow of diagnosis is shown below.



1.4 DIAGNOSIS MENU TREE



APPENDIX 2

PP ALARMS

| | |
|--|-----|
| 2.1 PROGRAMMING PENDANT ALARMS | 108 |
| WHAT IS PP ALARM ? | 108 |
| 2.2 CONTENTS OF PP ALARM | 108 |
| 2.3 ACTION TO BE TAKEN FOR PP ALARM 20 | 110 |
| 2.4 ERROR CODE DISPLAY ON 7-SEGMENT LEDS OF MCP01 BOARD | 111 |
| 2.5 ACTION TO BE TAKEN FOR PP ALARM 21 | 114 |


2.1 PROGRAMMING PENDANT ALARMS

WHAT IS PP ALARM ?

Alarms displayed on the program pendant (hereinafter called PP) when some failure occurs in the YASNAC MRC system.

2.2 CONTENTS OF PP ALARM

DISPLAY OF PP



List of Code Nos.


| Code No. | Message | Contents | Factor Source | Corrective Action or Possible Factor |
|----------|-------------|---|---------------|---|
| 0010 | None | PP ROM error | Hardware | <Corrective action> Replace PP. |
| 0011 | None | PP RAM error | | |
| 0020 | None | 1. Breakdown at MRC side 2. Transmission shut off between PP and MRC | Hardware | <Corrective action> Refer to the APPENDIX Par. 2.3 "Action to be Taken for PP ALARM 20". |
| 0021 | None | Breakdown at PP side | Hardware | <Corrective action> Refer to the APPENDIX Par. 2.5 "Action to be Taken for PP ALARM 21". |
| 2000 | None | Receiving data error | Hardware | Noise between PP and MRC |
| 2001 | None | Parity error | | |
| 2002 | None | Overflow error | | |
| 2004 | None | Framing error | | |
| 2010 | None | SIO data transmission error | Software | Software program error Note : For error codes 5000 to 5005, 99 in the message WIN-NO : 99 is numeric data. |
| 2100 | None | Receiving buffer full | | |
| 2101 | None | Transmitting buffer full | | |
| 3000 | None | Display command buffer full | | |
| 3001 | None | Display buffer full | | |
| 5000 | WIN-NO : 99 | Display data length error | | |
| 5001 | WIN-NO : 99 | Limit over | | |
| 5002 | WIN-NO : 99 | Data overlapped definition | | |
| 5003 | WIN-NO : 99 | Display No. alarm | | |
| 5004 | WIN-NO : 99 | Window No. alarm | | |
| 5005 | WIN-NO : 99 | Data quantity alarm | | |

2.3 ACTION TO BE TAKEN FOR PP ALARM 20

"PP ALARM 20" displayed on the program pendant means that communication with the PP has broken because of an error on the MRC side. The error may be hardware error (defective boards, etc.) or software crash caused either by hardware or software error.

Observe the procedure to investigate the cause of PP ALARM 20.

→ Refer to the precaution in Par. 2.5 "ACTION TO BE TAKEN FOR PP ALARM 21".



2.4 ERROR CODE DISPLAY ON 7-SEGMENT LEDS OF MCP01 BOARD

While the MRC system is functioning properly, the 7-segment LEDs of the MCP01 (SYSCON) board display nothing. If an error occurs, the LEDs indicate the code of the error.

- 1-digit error code display
- 4-digit code repeated display

If a non-maskable interrupt (NMI) occurs, a 4-digit interrupt code (listed on the next page) is displayed repeatedly.

| Display | Meaning |
|----------|--|
| .8. | MCP01 or SROMS error (MCP01 or SROMS board is defective.) |
| (Period) | NMI occurred during NINDY monitor operation. (MCP01, MCP02, MIF01, or MSV01 board is defective or not inserted properly.) |
| 0 | MIF01 (CIO) board error (MIF01 board is defective or not inserted properly.) |
| 1 to F | Communication error between MCP01 and Programming Pendant |

Example : If a watchdog timer error (whose alarm code is 0906) occurs on the MCP01 board, it is indicated as : 0 → 9 → 0 → 6 → . → 0 → 9 → 0 → 6 → repeat

Details of Communication Error between MCP01 and Programming Pendant

| Display | Meaning |
|---------|--|
| 1 | System alarm |
| 2 | Data transmission buffer over flow |
| 3 | Data receiving buffer overflow |
| 4 | Data receiving time-over |
| 5 | SIO receiving alarm (overrun, flaming, parity error) |
| 6 | SIO receiving alarm (data transmission disabled) |
| 7 | Receiving data BCC alarm |
| 9 | Programming Pendant software watchdog alarm |
| a | Receiving data command length error |
| d | Denial response from programming pendant (BCC alarm detection at programming pendant) |
| E | Failed data transmission establishment other than at power ON |
| F | Failed data transmission establishment at program pendant alarm occurrence / power setup |

2.4 ERROR CODE DISPLAY ON 7-SEGMENT LEDS OF MCP01 BOARD (Cont'd)

| Display | Meaning |
|---------|------------------------------|
| 0900's | Watchdog timer error (A-bus) |
| 0900 | MCP02 |
| 0901 | Reserved |
| 0902 | MSL#1 |
| 0903 | MSL#2 |
| 0904 | Reserved |
| 0905 | Reserved |
| 0906 | MCP01 |
| 0907 | MIF01 |
| 0910's | Watchdog timer error (D-bus) |
| 0910 | MSV#1 |
| 0911 | MSV#2 |
| 0912 | MSV#3 |
| 0913 | MSV#4 |
| 0914 | MSV#5 |
| 0915 | MSV#6 |
| 0916 | MSV#7 |
| 0917 | Reserved |
| 0920's | Watchdog timer error (S-bus) |
| 0920 | MIV02 |
| 0930's | Access error (A-bus) |
| 0930 | MCP02 |
| 0931 | Reserved |
| 0932 | MSL#1 |
| 0933 | MSL#2 |
| 0934 | Reserved |
| 0935 | Reserved |
| 0936 | MCP01 |
| 0937 | MIF01 |
| 0940's | A-bus error |
| 0940 | MCP02 |
| 0941 | Reserved |
| 0942 | MSL#1 |
| 0943 | MSL#2 |
| 0944 | Reserved |
| 0945 | Reserved |
| 0946 | MCP01 |
| 0947 | MIF01 |


(Cont'd)

(Cont'd)

| Display | Meaning |
|---------|--|
| 0950's | CPU hang-up error (A-bus) |
| 0950 | MCP02 |
| 0951 | Reserved |
| 0952 | MSL#1 |
| 0953 | MSL#2 |
| 0954 | Reserved |
| 0955 | Reserved |
| 0956 | MCP01 |
| 0957 | MIF01 |
| 0960's | CPU hang-up error (D-bus) |
| 0960 | MSV#1 |
| 0961 | MSV#2 |
| 0962 | MSV#3 |
| 0963 | MSV#4 |
| 0964 | MSV#5 |
| 0965 | MSV#6 |
| 0966 | MSV#7 |
| 0967 | Reserved |
| 0970's | CPU hang-up error (S-bus) |
| 0970 | MIF02 |
| 0999 | NMI (non-maskable interrupt) factor judgement disabled |

2.5 ACTION TO BE TAKEN FOR PP ALARM 21

The block diagram of the hardware around the PP is shown below.



<Cause>

The most common cause is failure of the PP (JZNC-MPP10).
Also possible are wiring and board errors related to the PP.

<Corrective Action>

Replace PP.



Check wiring.



Replace each board.

Note : If the 24 V power supply line is shorted because of improper connection of I/O signal lines (MIO board, etc.), PP ALARM 20 or 21 may occur.
Check the I/O signal line connection.

APPENDIX 3

OP (OPERATION PANEL) MAINTENANCE (OPTION)

| | |
|--|-----|
| 3.1 OUTLINE | 116 |
| 3.2 OP MAINTENANCE MODE START-UP PROCEDURE | 117 |
| 3.3 SYSTEM DIAGNOSTICS | 118 |
| 3.4 SECTION DIAGNOSTICS | 119 |
| 3.5 NOTES | 121 |

3.1 OUTLINE

The following functions are available in the OP maintenance mode.

List of OP Maintenance Mode Functions

■ **SYSTEM DIAGNOSTICS**

(Full-automatic diagnosis for whole OP)


■ **SECTION DIAGNOSTICS**

- ROM TEST
- LOCAL RAM TEST
- VIDEO RAM (CHARACTER) TEST
- VIDEO RAM (GRAPHIC) TEST
- RTC TEST
- WATCHDOG TIMER TEST
- CHARACTER GENERATOR ROM (YE) TEST
- CHARACTER GENERATOR ROM (JIS) TEST
- CRT CONTRAST TEST
- SERIAL PORT TEST
- FLAT KEY & LED TEST
- FULL KEYBOARD TEST
- PRINTER I/F TEST

■ **DISPLAY TEST PATTERN**

Checkered pattern displayed at an interval of 16 dots on the whole display.
(CRT assembly adjustment function)

3.2 OP MAINTENANCE MODE START-UP PROCEDURE

Holding down both  and **MORE** keys, turn ON the control power. The system starts up in OP maintenance mode and the display appears as shown below.

YASNAC MRC
OP MAINTENANCE MODE
ROM VERSION -> V2.0
SYSTEM DIAGNOSTICS
SECTION DIAGNOSTICS
DISPLAY TEST PATTERN


→ ROM version displayed

PUSH ↑ ↓ TO SELECT/PUSH <ENTER> TO EXEC

Maintenance Mode Display

3.3 SYSTEM DIAGNOSTICS

To start system diagnosis in OP maintenance mode, move the cursor to SYSTEM DIAGNOSTICS and depress **ENTER**. The display shown below appears and total diagnosis on OP hardware starts. It takes about three minutes to complete the whole procedure of system diagnosis.



System Diagnostics Execution Display

The system diagnosis procedure sequentially executes all tests except flat key and LED tests, full keyboard test, and printer interface test. Individual tests are listed in the next section. They can be carried out separately in section diagnosis.

3.4 SECTION DIAGNOSTICS

To start section diagnosis is OP maintenance mode, move the cursor to SECTION DIAGNOSTICS and depress **ENTER**. The display shown below appears.


```
SECTION DIAGNOSTICS  
  
ROM TEST  
LOCAL RAM TEST  
VIDEO RAM (CHARACTOR) TEST  
VIDEO RAM (GRAPHIC) TEST  
RTC TEST  
WATCH DOG TIMER TEST  
CHARACTER GENERATOR ROM (YE) TEST  
CHARACTER GENERATOR ROM (JIS) TEST  
CRT CONTRAST TEST  
SERIAL PORT TEST  
FLAT KEY & LED TEST  
LED TEST  
FULL KEYBOARD TEST  
PRINTER I/F TEST  
  
PUSH ↑ ↓ TO SELECT/PUSH <ENTER> TO EXEC  
PUSH <CANCEL> TO RETURN
```

Section Diagnosis Display

Select an item by using **↑** or **↓** and depress **ENTER**. The display shown on the next page appears and the diagnosis of the selected item starts.

Section diagnosis is repeated until **CANCEL** is depressed. If an error occurs, an error display appears.

3.4 SECTION DIAGNOSTICS (Cont'd)



Section Diagnosis Execution Display

The following test requires manual input from the keyboard and visual check.

- Character generation ROM (YE) display test.
 - Starting with the first YE code (Japanese 00), 16 lines that consist of 16 characters each are displayed on the grid. Check visually.
- Character generation ROM (JIS) display test
 - Starting with the first JIS code (Japanese 2120), 16 lines that consist of 16 characters each are displayed on the grid. Check visually.
- CRT contrast adjustment test
 - Contrast is intensified and weakened alternately at an interval of one second. Check visually.
- Flat key and LED test
 - Status of input from flat keys is displayed on the CRT display. If there is a LED corresponding to a depressed key, the LED lights. Depressing the key again turns OFF the LED.
- Full keyboard test
 - At present, no test is conducted. (To be used in the future.)
- Printer interface test
 - At present, no test is conducted. (To be used in the future.)

3.5 NOTES

Notes :

1. While VRAM (character/graphic) test is ongoing, flickering image of unintelligible data appears on the display.
This is a normal event caused by access to VRAM.
2. During watchdog timer test, a watchdog timer error is deliberately generated to sound the buzzer. This is the normal course of the test.
3. Connect the serial port test tool before starting system diagnosis, or a serial port test error occurs. This error also occurs if serial port test is conducted in section diagnosis without the tool. Be sure to connect the test tool before starting serial port test.

APPENDIX 4

ADDITIONAL MOUNTING OF CMOS EXTENSION MEMORY

Additional Mounting of CMOS Extension Memory

To mount the CMOS extension memory (MMM01 board) additionally to the controller in use, follow the procedure described below.

• Procedure

1. Save the standard system CMOS data into a floppy disk by FC1 or FC2 emulator.

• Precautions

CMOS batch file (CMOS. HEX) and user memory batch memory (JOB. HEX) cannot be loaded to use in the system where the MMM01 board is mounted to extend the memory.

For CMOS data excluding parameters must be saved in an individual file. At that time, use **BATCH** key.

Save the parameters in the all-parameter batch file.

→ Refer to the following page.

2. Start up in maintenance mode.
3. Verify the configuration status (language, controlled axes, application) on the system configuration display.
(→ Because the same setting is needed again in step 6.)
4. Mount the MMM01 board on the MIF01 board with the control power supply OFF.
5. Start up in maintenance mode.
6. Select the system configuration to execute "initialization".
(Verify the capacity displayed on the CMOS memory display.)

| Board | Displayed Capacity |
|-----------------|--------------------|
| Standard | 256 kB |
| MMM01-2 Mounted | 1 MB |
| MMM01-3 Mounted | 2 MB |
| MMM01-4 Mounted | 4 MB |

7. Start up in online mode.
8. Load the CMOS data saved in step 1 from the floppy disk by FC1 or FC2 emulator.
9. Turn ON the power supply to complete the procedure.

Files to be Saved and File Names after Saving

| Data to be Saved | | | File Names after Saving | | Function Mode | | Customer Mode | |
|----------------------------|--|--|-------------------------|------|---------------|------|---------------|------|
| | | | | | Save | Load | Save | Load |
| ⑦ CMOS (memory) batch save | | | Loading prohibited | | ○ | | ○ | ○ |
| ③ User memory batch save, | | | Loading prohibited | | ○ | | ○ | ○ |
| ① Job | Single job | | Job name | .JBI | ○ | ○ | ○ | ○ |
| | Related job (job + conditions) | | Job name | .JBR | ○ | ○ | ○ | ○ |
| ② Condition Data | Weaving condition data | | WEAV | .CND | ○ | ○ | ○ | ○ |
| | Tool data | | TOOL | .CND | ○ | ○ | ○ | ○ |
| | User coordinate data | | UFRAME | .CND | ○ | ○ | ○ | ○ |
| | Welding starting condition data | | ARCSRT | .CND | ○ | ○ | ○ | ○ |
| | Welding quit condition data | | ARCEND | .CND | ○ | ○ | ○ | ○ |
| | COM-ARC2 condition data | | COMSRT | .CND | ○ | ○ | ○ | ○ |
| | COM-ARC2 data | | COMARC2 | .CND | ○ | ○ | ○ | ○ |
| | Locus correction condition data | | SENSCOR | .CND | ○ | ○ | ○ | ○ |
| General-purpose Data | ☆Variable data | | VAR | .DAT | ○ | ○ | ○ | ○ |
| | ☆Welding condition auxiliary data | | ARCSUP | .DAT | ○ | ○ | ○ | ○ |
| | ☆Phase compensated-value data | | PC1PC2 | .DAT | ○ | ○ | ○ | ○ |
| ④ All-parameter Batch Save | | | ALL | .PRM | ○ | | ○ | ○ |
| ④ Parameter | Robot conformity parameter | | RC | .PRM | ○ | | ○ | ○ |
| | System definition parameter | | SD | .PRM | ○ | | ○ | ○ |
| | Coordinate home position (A) parameter | | RO | .PRM | ○ | | ○ | ○ |
| | System conformity parameter | | SC | .PRM | ○ | | ○ | ○ |
| | Parameter for CIO | | CIO | .PRM | ○ | | ○ | ○ |
| | Function definition parameter | | FD | .PRM | ○ | | ○ | ○ |
| | ☆Parameter for each application | | AP | .PRM | ○ | | ○ | ○ |
| | ☆Transmission (general-purpose) parameter | | RS | .PRM | ○ | | ○ | ○ |
| | ☆Transmission (data link) parameter | | CM | .PRM | ○ | | ○ | ○ |
| | ☆Parameter for printer | | SP | .PRM | ○ | | ○ | ○ |
| | ☆Parameter for sensor | | SE | .PRM | ○ | | ○ | ○ |
| | ☆Parameter for vision | | VC | .PRM | ○ | | ○ | ○ |
| | ☆Servo parameter | | SV | .PRM | ○ | | ○ | ○ |
| | ☆Servomotor parameter | | SVM | .PRM | ○ | | ○ | ○ |
| ⑤ I/O Data | | | CIOPRG | .LST | ○ | | ○ | ○ |
| | | | IONAME | .DAT | ○ | | ○ | ○ |
| ⑥ Customer Data | Reserved job name | | RJNAME | .DAT | ○ | | ○ | ○ |
| | SV monitor signal | | SVMON | .DAT | ○ | ○ | ○ | ○ |
| | Variable name | | VARNAME | .DAT | ○ | | ○ | ○ |
| | Data of calibration between robots | | RBCALIB | .DAT | ○ | | ○ | ○ |
| | Welder characteristic data | | WELDER | .DAT | ○ | | ○ | ○ |
| | Welder characteristic user definition data | | WELDUDEF | .DAT | ○ | | ○ | ○ |
| | Second home position | | HOME2 | .DAT | ○ | ○ | ○ | ○ |
| | ☆Alarm history data | | ALMHIST | .DAT | ○ | | ○ | ○ |
| | ☆Home positioning data | | ABSO | .DAT | ○ | | ○ | ○ |
| | ☆Welding condition guide data | | ARCGUIDE | .DAT | ○ | | ○ | ○ |
| | ☆System information | | SYSTEM | .SYS | ○ | | ○ | |

Note : Data marked with ☆ are not displayed unless scroll operation is performed.

○ : Enabled

YASNAC MRC MAINTENANCE MODE OPERATOR'S MANUAL

TOKYO OFFICE Ohtemachi Bldg, 1-6-1 Ohtemachi, Chiyoda-ku, Tokyo, 100 Japan
Phone (03) 3284-9111 Telex YASKAWA J33530 Fax (03) 3284-9034

MOTOMAN INC.

805 Liberty Lane West Carrollton, OH. 45449, U.S.A
Phone (513) 847-6200 Fax (513) 847-6277
24 Hour Service Hotline (513) 847-3200

YASKAWA ELECTRIC EUROPE GmbH

Am Kronberger Hang 2, 65824 Schwalbach, Germany
Phone (49) 6196-569-300 Fax (49) 6196-888-301

Motoman Robotics AB

Box 130 S-38500, Torsås, Sweden
Phone 0486-10575 Fax 0486-11410

Motoman Robotec GmbH

Kammerfeldstraße 1, 85391 Allershausen, Germany
Phone 08166-900 Fax 08166-9039

YASKAWA ELECTRIC KOREA CORPORATION

8th Floor Seoul Center Bldg, 91-1, Sogong-Dong, Chung-ku, Seoul, Korea 100-070
Phone (02)776-7844 Fax (02)753-2639

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.

Head Office : CPF Bldg, 79 Robinson Road # 13-05, Singapore 0106, SINGAPORE
Phone 221-7530 Telex (87) 24890 YASKAWA RS Fax 224-5854

Service Center : 221 Henderson Road, # 07-20 Henderson Building Singapore 0315, SINGAPORE
Phone 276-7407 Fax 276-7406

YATEC ENGINEERING CORPORATION

Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan
Phone (02) 563-0010 Fax (02) 567-4677

SHANGHAI OFFICE Room No. 8B Wan Zhong Building 1303 Yan An Road (West), Shanghai 200050, CHINA
Phone (86) 212-1015 Fax (86) 212-1015

TAIPEI OFFICE Shen Hsiang Tang Sung Chiang Building 10F 146 Sung Chiang Road, Taipei, Taiwan
Phone (02) 563-0010 Fax (02) 567-4677



YASKAWA

YASKAWA ELECTRIC CORPORATION

TOE-C945-408

© Printed in Japan October 1995 95-10 0.2TA