

Regulator Valve Body

Disassembly/Inspection/Reassembly

NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air.
- Blow out all passages.
- Replace valve body as an assembly if any parts are worn or damaged.
- Check all valves for free movement. If any fail to slide freely, see Valve Body Repair on page 14-114.


1. Hold the regulator spring cap in place while removing the lock bolt. Once the bolt is removed, release the spring cap slowly.

CAUTION: The regulator spring cap can pop out when the lock bolt is removed.

2. Reassembly is in the reverse order of disassembly.

NOTE:

- Coat all parts with ATF.
- Align the hole in the regulator spring cap with the hole in the valve body, press the spring cap into the body and tighten the lock bolt.



SPRING SPECIFICATIONS

Unit: mm (in)

No.	Spring	Standard (New)			
		Wire Dia.	O.D.	Free Length	No. of Coils
①	Stator reaction spring	6.5 (0.256)	26.4 (1.039)*	30.3 (1.193)	1.9
②	Regulator valve spring A	1.8 (0.071)	14.7 (0.579)	86.5 (3.406)	16.5
③	Regulator valve spring B	1.7 (0.067)	6.0 (0.236)*	43.0 (1.693)	13.5
④	Lock-up shift valve spring	0.9 (0.035)	7.6 (0.299)	73.7 (2.902)	32.0
⑤	Cooler relief valve spring	1.1 (0.043)	8.4 (0.331)	46.8 (1.843)	17.0

*: Inside Diameter