



Pressure Plate, Clutch Disc

Removal

1. Install the special tools as shown.



2. To prevent warping, unscrew the pressure plate mounting bolts in a crisscross pattern in several steps, then remove the pressure plate and the clutch disc.
3. Remove the release bearing from the pressure plate.



Pressure Plate


Inspection

1. Inspect the pressure plate surface for wear, cracks, and burning.
2. Inspect the fingers of the diaphragm spring for wear at the release bearing contact area.
3. Inspect for warpage using a straight edge and feeler gauge.

NOTE: Measure across the pressure plate at three points.

Standard (New): 0.03 mm (0.001 in) max.

Service Limit: 0.15 mm (0.006 in)



- If the warpage exceeds the service limit, replace the pressure plate.