

# Electrical Troubleshooting

## Troubleshooting Flowchart (cont'd)

Self-diagnosis **D4** indicator light blinks six times.

Connect the Test Harness between the PCM and connectors (14-48 and 49).

Turn the ignition switch ON.

Shift to **R** position.

Measure the voltage between the A13 and A3/A4 terminals.

Is there voltage? YES

Repair open in GRN/RED wire between the E13 terminal and the A/T gear position switch.

Shift to **N** or **P** position.

Measure the voltage between the B7 and A3/A4 terminals.

Is there voltage? YES



Repair open in LT GRN wire between the B7 terminal and the A/T gear position indicator.

To page 14-59

Possible Cause
• Disconnected A/T gear position switch connector
• Open in A/T gear position switch wire
• Faulty A/T gear position switch

NOTE: Code 6 is caused when the PCM receives an input for any gear.


NOTE: The section A of the Test Harness with the Test Harness Adapter corresponds to the E (26P) connector of the PCM.





From page 14-58

NOTE: The section A of the Test Harness with the Test Harness Adapter corresponds to the E (26P) connector of the PCM.



(cont'd)