

Troubleshooting

Flowchart — Recirculation Control Motor


Recirculation function does not work properly.

Remove the glove box lower panel (see page 21-54).

Disconnect the 4P connector from the recirculation control motor.

Turn the ignition switch ON.

Measure voltage between the BLK/YEL wire terminal (+) and body ground (-).



Is there battery voltage?

NO

Repair open in the BLK/YEL wire between the No. 19 (7.5A) fuse in the under-dash fuse/relay box and the recirculation control motor.

YES

Turn the ignition switch OFF.

Test the recirculation control motor (see page 21-63).

Is the recirculation control motor OK?

NO

Remove the recirculation control motor (see page 21-63).

YES

Check the recirculation control linkage and doors for smooth movement.

Remove the heater control panel (see page 21-13).

Disconnect the 22P connector from the heater control panel.

Do the recirculation control linkage and doors move smoothly?

NO

Repair the recirculation control linkage or doors.


YES

Replace the recirculation control motor.

To page 21-25



From page 21-24



Check each wire for continuity between the recirculation control motor and the heater control panel:

- BLU/ORN wire
- BLU/GRN wire

Is there continuity?

NO

Repair any open in the wire(s) between the recirculation control motor and the heater control panel.

YES

Check each wire for continuity between the recirculation control motor and body ground:

- BLU/ORN wire
- BLU/GRN wire

Is there continuity?

YES

Repair any short in the wire(s) between the recirculation control motor and the heater control panel.

NO

Substitute a known-good heater control panel and recheck. If symptom/indication goes away, replace the original heater control panel.