



MODEL NO.: MS75




User Manual

Multifunctional Speaker



Remote Control Key Illustration



- Button Function Operation Instructions**
- 1. LED MODE:** Short press to switch the LED lights. Long press to turn the LED light on or off.
 - 2. ACCOMPANY:** Short press to turn it on or off. Accompany Mode can reduce or partially eliminate the vocals in the song. (Not available in AUX/TF/USB mode.)
 - 3. MIC PRIORITY:** Short press to turn it on or off. Once this feature is activated, the volume of the music will automatically decrease when speaking into the microphone. The music volume will automatically recover in 1-2 seconds after stopping speaking. In this mode, you can switch between original sound mode and singer mode. The auto-tune function in this mode automatically adjusts the pitch of the audio signal to correct pitch problems in singing. Long press to switch between two EQ modes: indoor mode (displayed as ECO)-enhanced bass effect; Outdoor mode (displayed as ECT)-enhanced mid and treble effect. If the volume is too low, the effect may not be very noticeable.
 - 4. MIC MODE:** Short press to switch different modes: Bluetooth mode, USB mode, TF card mode, AUX mode. Long press to enter/exit TWS function. (Please refer to the Function Operation Guide for detailed instructions.)
 - 5. LIVE:** Short press for the previous song in USB/TF card mode, and long press for fast rewind; short press also for the previous song in Bluetooth mode.
 - 6. PREV:** Short press for the previous song in USB/TF card mode, and long press for fast forward; short press also for the previous song in Bluetooth mode.
 - 7. NEXT:** Short press for the next song in USB/TF card mode, and long press for fast forward; short press also for the next song in Bluetooth mode.
 - 8. PLAY/PAUSE:** Short press to play/pause in USB/TF card mode; short press for mute in AUX mode; short press is also for play/pause in Bluetooth mode. Long press can disconnect actively the Bluetooth connection with the phone.
 - 9. MIC:** Insert a 6.35mm wired microphone or the microphone with a 6.35mm receiver.
 - 10. EARPHONE:** 3.5mm earphone input jack.
 - 11. LIVE:** Use a live streaming cable (3.5mm) to connect your speakers to your phone for live streaming. Audio mixing can be blocked to ensure you can hear yourself clearly.
 - 12. AUX:** Use a 3.5mm AUX cable to connect external devices. Plug one end into your phone, tablet, or computer, and the other end into the speaker's AUX input to play audio.
 - 13. MASTER:** Main volume adjustment.
 - 14. ECHO:** Microphone reverb effect adjustment.
 - 15. MIC VOL:** Microphone volume adjustment.
 - 16. TF CARD PORT:** Insert a TF card (up to 64GB) with music files in MP3/AAC/WAV/FLAC/APE/WMA format, then it will automatically play the songs from the TF card.
 - 17. USB PORT:** Insert a USB card (up to 64GB) with music files in MP3/AAC/WAV/FLAC/APE/WMA format, then it will automatically play the songs from the USB.
 - 18. CHARGING PORT:** Plug one end of a Type-C charging cable into this port, and the other end into a USB power adapter or power bank. (5V=1A)
 - 19. POWER ON/OFF**
 - 20. CHARGING INDICATOR LIGHT:** Red when charging, blue when fully charged.

Remote Control Key Function Instructions

- 1. REC:** Before recording, insert a TF card/USB drive, and connect a wired or wireless microphone. Long press to start recording. After recording, turn off the microphone before exiting recording mode).
- 2. Appause:** (Sound card effect)
- 3. Ciggle:** (sound card effect)
- 4. Yell:** (sound card effect)
- 5. Laughter:** (sound card effect)
- 6. Single Cycle:** Short press to play a single song in a loop.
- 7. PREV:** Short press to play previous song.
- 8. VOL-:** Short press to decrease the volume.
- 9. ACCOMPANY:** Short press to turn it on or off. Accompany Mode can reduce or partially eliminate the vocals in the song. (Not available in AUX/TWS mode.)
- 10. Fast Forward:** Short press can fast-forward the song while playing music.
- 11. Mute:** Short press to mute, press again to restore volume.
- 12. Gunshot:** (sound card effect)
- 13. Boos:** (sound card effect)
- 14. Whistling:** (sound card effect)
- 15. Crow:** (sound card effect)
- 16. All Cycles:** Short press to loop all songs.
- 17. VOL+:** Short press to increase the volume.
- 18. NEXT:** Short press for next song.
- 19. PLAY/PAUSE:** Short press to pause/continue playback.
- 20. Mode:** Short press to switch different modes: Bluetooth mode, USB mode, TF card mode, AUX mode. (Default Bluetooth mode at power on, you can only switch the mode after inserting the USB disk or TF card)
- 21. Number key:** Press the "0-9" number keys to quickly select the song you want. If you want to play the 3rd song, press the number 3 first. The display shows "0003", and the third song is played after 3 seconds; To play the 12th song, press the number button 1 first, and then press the number key 2 (you must have this song in the folder to select it). After that, the 12th song will be played, and the other songs you want will be selected similar. (Note: it only works when playing music from USB and TF Card).
- 22. Fast Backward:** Short press to fast-backward the song while playing music.

Function Operation Guide

- #### Bluetooth Connect
- Turn on the power switch or repeatedly press the MODE button to enter Bluetooth mode.
 - Open Bluetooth on your phone or other devices, search for "MS75", and click to connect. Once connected, open your music app on the phone and start playback.
Note: Ensure your phone's volume is turned on and set to an appropriate level.
- #### TWS Pairing Method (Two MS75 speakers are required)
- Connect one of the speakers to your device via Bluetooth.
 - Long press the "MODE" button on the other speaker. After hearing a prompt sound, the speaker will enter TWS mode, and both speakers will play music simultaneously.
 - Long press the "MODE" button on either speaker again to exit TWS mode.
- #### Mode Switch
- To switch to TF, USB, or AUX mode, please ensure the corresponding device (TF card/USB drive/AUX cable) is properly inserted.
 - Switch to Bluetooth mode on your phone or other device is connected via Bluetooth.
 - Short press the "Play/Pause" button to play/pause playback, and use the "Prev/Next" buttons to switch between songs. (In all modes)
- #### REC Function (Only applicable to USB mode/TF mode)
- Before recording, insert a TF card/USB drive, and connect a wired or wireless microphone.
 - Long press to start/exit recording.
 - After recording: turn off the microphone before exiting recording mode.
- #### Karaoke Machine Troubleshooting Guide:
- ##### 1. No Sound from Microphone
- Possible Causes:** Microphone is turned off or has low battery / Volume is muted or set too low / Wireless microphone pairing failed / loose connection (for wired microphones) / The signal receiver inside the microphone is damaged.
- Ensure the microphone is turned on. Replace or recharge batteries.
 - Check the microphone volume and adjust it.
 - Turn off the microphone and reconnect.
 - Contact customer service through Amazon to replace the microphone.
- ##### 2. Bluetooth Connection Issues
- Possible Causes:** Too far out of range / Bluetooth version incompatibility / Multiple devices causing interference / The Bluetooth module inside the machine is damaged.
- Solutions:**
- Shorten Distance:** Keep the device within 10 meters of the karaoke machine.
 - Re-pair:** Delete old pairings from your phone/tablet and reconnect.
 - Disable Nearby Devices:** Turn off other Bluetooth devices (headphones, speakers).

Karaoke Machine Troubleshooting Guide

Universal Checklist-----1

A. Unit Will Not Charge / No Power-----2

B. Microphone Issues-----3

C. Bluetooth Connection Failed-----4

D. Recording Function Not Working / No Background Music in Recording-----5

E. TWS Connection Issues-----6

F. Unit Will Not Turn On-----7

G. Remote Control Not Working-----7

H. Excessive Echo or Reverb Effect-----8

I. Songs Not Playing from USB Drive or TF Card-----8

Need More Help? We're Here for You-----9

First Steps - Universal Checklist

Please perform the following checks before proceeding. Most issues can be resolved here.

- > **Power:**
 - This machine requires a USB-A power adapter (not included).
 - Do not use a fast charger. Please use a 5V/1A power adapter (max 10W).
 - Ensure the adapter is firmly plugged into a wall outlet and into the machine's Type-C charging port (not the USB port). The adapter's indicator light should be on.
- > **Volume Control:**
 - Check that the Master Volume and Microphone Volume knobs on the machine are turned up, not set to the minimum level.
- > **Connections:**
 - Re-seat all cables (audio cable, Type-C cable) by unplugging and plugging them back in to ensure a secure connection.
- > **Source Device:**
 - Ensure the volume on your phone, tablet, or TV is turned up and not muted.
- **Microphone:**
 - For standard mics: Install brand new AA batteries. Low battery power is the most common cause of microphone issues.
 - For rechargeable mics: Remove the insulating film from the battery compartment before first use and ensure the mic is fully charged.
- > **TV Settings:**
 - If using TV output, use your TV remote to switch the Input/Source to the correct HDMI or AV channel.

A. Unit Will Not Charge / No Power

Symptom: The machine shows no signs of power or does not charge when plugged in.

Solutions:

1. **Confirm the Correct Charging Port**
 - Ensure you are plugging into the Type-C charging port on the main unit.
 - Do NOT use the USB port. The USB port is only for playing music from a flash drive.
2. **Use the Correct Power Adapter & Cable**
 - This device does not support fast charging. Please use a 5V/1A (max. 10W) USB-A power adapter for charging.
 - CRITICAL: Do NOT use a fast charger (e.g., from a modern smartphone). This may prevent charging.
 - Tip: Try a different, lower-power adapter if available (e.g., from an older phone or tablet).
3. **Check the Charging Indicators**
 - When properly connected and charging, the charging indicator light should turn SOLID RED.
 - When fully charged, the light will turn SOLID BLUE.
4. **Other Possible Causes & Advanced Checks**
 - If the above steps do not resolve the issue, please check the following:
5. **Power Source: Test the wall outlet with another device to ensure it is working.**
6. **Cable & Adapter: Try a different USB-A to Type-C cable and a different 5V/1A power adapter to rule out a faulty accessory.**
7. **Physical Port Damage: Inspect the machine's Type-C port for any visible debris or damage. Gently clean the port with a dry, soft brush if necessary.**
8. **Battery Protection: If the battery was completely drained, leave the unit plugged into a correct charger for at least 1 hour to see if it revives.**

B. Microphone Issues

Symptom: Microphone has no sound, static noise, feedback/howling, or keeps disconnecting.

Solutions:

1. Power: Replace Batteries or Fully Charge

For battery-powered mics: Install brand new AA batteries. Low power is the most common cause of all microphone issues.

For rechargeable mics: Connect the microphone to a power source using its charging cable and ensure it is fully charged before use.

2. Positioning: Avoid Feedback & Howling

Do not point the microphone directly at or place it too close to the speaker. This is the primary cause of feedback (a loud, high-pitched squeal).

→ Tip: If feedback occurs, simply reduce the microphone volume or move further from the speaker.

3. Interference: Avoid Signal Obstacles

Keep the Karaoke machine away from potential sources of wireless interference, such as: Wi-Fi routers, Microwave ovens, Other Bluetooth devices (e.g., mice, keyboards)

→ Tip: This helps prevent dropouts and static for both wired and wireless microphones.

C. Bluetooth Connection Failed

Symptom: Cannot find the device "[Karaoke Machine Model Name]" in your phone's Bluetooth list, or pairing is unsuccessful.

Solutions:

1. Enter Pairing Mode on the Machine

Ensure the Karaoke machine is in Bluetooth pairing mode. The indicator light is usually rapidly blinking in this mode. (Refer to your model's manual for exact instructions).

2. Reduce Distance & Eliminate Interference

Bring your phone or tablet within 1 meter (3 feet) of the Karaoke machine. Move away from strong wireless interference sources like Wi-Fi routers, microwave ovens, or crowded USB ports.

3. Restart & Re-search on Your Phone

Turn your phone's Bluetooth OFF and then ON again to refresh its search function. On your phone, search for new Bluetooth devices and select "[Karaoke Machine Model Name]" to pair.

4. Clear Old Connection Records

On your phone, go to Bluetooth settings, find the old "[Karaoke Machine Model Name]" entry in the list of paired devices, and select "Forget" or "Unpair". Try the pairing process again from the beginning.

5. Other Possible Causes & Advanced Checks

Device Compatibility: Ensure the audio source (phone/tablet) supports the standard Bluetooth Audio protocol (A2DP). Most modern devices do.

Multiple Connections: The machine might already be connected to another device. Disconnect from or turn off Bluetooth on the previous device.

Phone Software: A simple restart of your phone can resolve many temporary Bluetooth software glitches.

System Settings: Ensure you are not in your phone's "Airplane Mode" and that the Bluetooth audio volume on your phone is turned up.

D. Recording Function Not Working / No Background Music in Recording

Symptom: The recording feature cannot be activated, or when recording, the background music is not captured in the recording file (only the microphone vocals are recorded).

Solutions & Explanations:

1. Check Playback Mode (The Most Common Reason)

The recording function is only available in USB Flash Drive or TF Card playback mode.

→ It CANNOT be activated or used while in Bluetooth mode. Please switch your audio source to a USB drive or TF card.

2. Understanding Music Copyright Protection

This is a universal limitation, not a defect of your specific machine. Due to international music copyright laws and content protection technologies, all karaoke machines on the market are designed to only record the microphone's vocal input. They intentionally cannot record the background music (the instrumental track) to prevent unauthorized distribution of copyrighted material.

→ This is a legal and technical design standard across the industry, not a malfunction.

3. Other Checks & Tips

USB/TF Card Format: Ensure your USB drive or TF card is formatted to a compatible file system.

File Location: After recording, your audio file (containing only your voice) will be saved onto the USB drive or TF card. Please check the root folder.

Microphone is Essential: The recording function requires a microphone to be connected and working. It will not record if no microphone audio is detected.

E. TWS Connection Issues (Only applicable to models with TWS function)

Symptom:

1. Unable to pair two units for TWS (True Wireless Stereo) mode.
2. After enabling TWS, microphone audio only comes from one speaker (the main unit).

Solutions & Explanations:

1. Confirm Your Model Supports TWS

Please first verify that your specific model supports the TWS function. Not all models have this feature. Check the product's model name on the box or the unit itself, and refer to the product's manual or the Amazon detail page for specifications.

2. Correct TWS Pairing Procedure

- Turn on the Main Speaker and connect your device (e.g., phone) to play music.
- Turn on the Secondary Speaker. Press and hold the TWS button on the Secondary Speaker (refer to your model's manual to identify this button) until you hear a prompt tone.
- The speakers will automatically pair. A confirmation tone will sound, indicating a successful TWS connection.
- To disconnect, simply press and hold the TWS button again until you hear a prompt tone. The speakers will return to independent mode.

3. Why the Microphone Audio Only Comes from the Main Speaker

This is normal operation and not a malfunction. All audio inputs (Microphones, Guitar, etc.) are processed by the Main Speaker only. In TWS mode, the Main Speaker transmits only the background music signal wirelessly to the Secondary Speaker.

Therefore, your microphone voice will always output from the Main Speaker, while the music plays in stereo across both speakers. This is a standard design for most TWS karaoke systems.

4. Advanced Troubleshooting

Reset: If pairing fails, power off both units completely, then power them back on and try the pairing procedure again.

Distance: Keep the two speakers within 3-5 feet (1-1.5 meters) of each other during the initial pairing process.

Interference: Move away from other strong wireless signals (Wi-Fi routers, etc.) that could disrupt the TWS connection.

F. Unit Will Not Turn On

Symptom: After pressing the power button, the unit shows no signs of life (no lights, no sound, no display).

Solutions:

1. **Charge the Battery (First and Most Important Step)**
Connect the unit to a correct 5V/1A power adapter using the Type-C port. Let it charge for at least 30 minutes. A solid red charging indicator light should appear. After charging, try turning the unit on again.

2. **Check the Operating Environment**

Ensure the ambient temperature is between 0°C to 40°C (32°F to 104°F). If the unit is too hot (e.g., left in a car in the sun), let it cool down to room temperature before attempting to use or charge it. If the unit is too cold, warm it up to room temperature.

3. **Inspect the Power Button**

Press the power button firmly and repeatedly several times to check for any sticking or unusual feeling. Listen for any faint clicking sounds from the button that might indicate an internal issue.

G. Remote Control Not Working (Note: This section only applies to models that include a remote control.)

Symptom: The remote control has no effect on the main unit. Buttons on the main unit's control panel work normally.

Solutions:

1. **Replace the Batteries (First Step)**
Install two brand new AAA batteries. Ensure the batteries are inserted in the correct polarity (+ and -) as shown in the battery compartment.

2. **Ensure a Clear Line of Sight**

The remote uses Infrared (IR) technology and requires a clear path to the unit's IR sensor (usually located on the front or top panel). Remove any objects blocking the path between the remote and the machine.

3. **Check the Remote's Functionality**

Use the buttons on the main unit's control panel. If they work, but the remote does not, the issue is likely with the remote itself.

4. **Other Checks**

Distance: Make sure you are using the remote within a reasonable distance (typically within 5-6 meters / 16-20 feet) of the machine.

H. Excessive Echo or Reverb Effect

Symptom: Singing voice sounds unnaturally hollow, distant, or has a prolonged "tail" that makes audio unclear. (Note: This is different from a sharp, high-pitched feedback squeal).

Solutions:

1. **Adjust the Sound Effects Settings (Primary Solution)**

Locate the "ECHO" or "REVERB" control buttons on your machine's control panel. Press the "-" (minus) button to reduce the effect level.
→ Recommended Starting Point: Adjust the level to between 30% and 50% for a clearer vocal sound with just a hint of ambience.
If the sound is still too muddy, try slightly reducing the Microphone Volume as well.

2. **Optimize Your Room Environment (Additional Tip)**

Large, empty rooms with hard surfaces (e.g., bare walls, tile floors, large windows) can exaggerate reverb effects.
→ Simple Improvements: Adding soft materials like curtains, area rugs, or upholstered furniture can help absorb sound and improve clarity.

I. Songs Not Playing from USB Drive or TF Card

Symptom: The player does not recognize your files, fails to start playback, or shows an "Unsupported" error when using a USB flash drive or TF card.

Solutions:

1. **Check File Format:** Use MP3/AAC/WAV/FLAC/APE/WMA files only (bitrates 320kbps).

2. **Reformat Storage:** Format USB/TF card to FAT32/exFAT.

3. **Simplify Folders:** Place songs in the root directory, not nested folders.

4. **Other Checks:**

Test the Device: Try a different USB drive or TF card to rule out a faulty storage device.

Check File Integrity: Ensure the audio files are not corrupted. Try playing them on your computer first.

Need More Help? We're Here for You.

If you have diligently followed all the steps in this guide but your issue remains unresolved, our dedicated support team is ready to assist you.

Choose Your Preferred Contact Method:

→Option 1: Direct Email Support

Email: Service07@ppmtc.online

Please Include your Order Number, Model Name, and Purchase Platform in your first email.

→Option 2: Contact us Through Your Purchase Platform

You can also message us directly through the platform where you made your purchase (e.g., contact the seller support team through your Amazon).

This is often the fastest way to get help with order-related issues.

→Option 3: Connect with us on Facebook

Facebook: LongLin



Message us on Facebook for quick assistance and support.

Please provide your Order Number, Model Name, and Purchase Platform in your message.

Our Service Hours: 9:00 AM - 9:00 PM PST, Monday - Friday

(We strive to respond to all inquiries within 12 business hours)