

Chantal® Classic Teakettle Use & Care

SL37-19 & SL37-19CP

Important: Hand wash only. Read all instructions before using your new teakettle. Save these instructions.

We hope that you enjoy your new Chantal teakettle. While doing so please remember the following:

How to Clean and Maintain the Chantal Teakettle

- Before first use, wash the inside and outside with hot soapy water, rinse and dry.
- **DO NOT** leave water in teakettle when not in use.
- To prevent mineral deposits, occasionally make a solution of ¼ cup white vinegar with 2 cups of water and simmer for 20 minutes.

**Wear an
Oven Mitt when
Kettle is Hot!**



⚠ WARNINGS AND INSTRUCTIONS:



- **DO NOT** overfill the teakettle. Overfilling the teakettle can cause boiling water to be forced out of the spout. **BURN INJURIES COULD RESULT.** The water level should always be below the spout on the inside of the teakettle. (see drawing)
- After the water boils, turn off the heat and allow the teakettle to stand for 15 seconds before flipping/pulling the whistle open (wearing an oven mitt) and then pouring the water. **ALWAYS POINT THE SPOUT AWAY FROM YOU WHEN BOILING WATER OR OPENING THE SPOUT.**
- Always use a burner on the back row of the stove to keep it out of the reach of small children. Use a burner smaller in diameter than the kettle. This may prevent excess heat from making the handle too hot to touch.
- Teakettle handle and whistle may get hot. **ALWAYS WEAR OVEN MITTS WHEN HANDLING TEAKETTLE OR FLIPPING THE WHISTLE LEVER OPEN** to prevent possible burn injury.
- **DO NOT LEAVE A HEATING TEAKETTLE UNATTENDED.** Forgotten teakettles boil dry. **DO NOT RELY ON THE WHISTLE** to remind you about an unattended teakettle. This whistle may occasionally not sound.
- Steam escaping from the lid or spout can burn you. **DO NOT** open the lid until water has cooled, or wear an oven mitt to protect your hand.
- **NEVER LET WATER IN THE TEAKETTLE BOIL DRY.** Leaving a dry teakettle on a hot burner can melt or separate the bottom plate of the teakettle. This could damage the teakettle and burner and could be a possible source of fire.
- If water has been boiled dry from the teakettle and the bottom disc has melted or separated, **TURN OFF HEAT** and do not remove the teakettle until it has cooled. Do not reuse a teakettle that has boiled dry and the aluminum has melted or the copper disc has separated from the teakettle.



GAS STOVE RECOMMENDATION:

When using a teakettle on a gas stove be sure to place it directly on the center of the burner. Always use a pot holder. If placed off-center on the burner flames may rise up to the whistle and can melt the plastic whistle casing in some instances. **BURN INJURIES COULD RESULT.**

For more helpful information about your Chantal teakettle (including warranties and replacement parts) refer to our website at www.chantal.com or you may call 800-365-4354 and request printed information.



0120_ClassicTKU&C.pdf

P.O. Box 30131 • Austin, TX 78755 USA
Ph: 1-800-365-4354 • www.chantal.com
© 2020 Chantal Corp. • All Rights Reserved.

This information comprises intellectual property of Chantal Corp. The unauthorized use or reproduction of this content without the express written consent of Chantal is prohibited.