

Turini 200

Pitching Instructions



Flysheet First Pitching

1. Assemble the three poles and lay them parallel on the ground. One pole will be shorter than the other two.
2. Open out flysheet and position in required direction
3. Locate pole sleeves on the flysheet and insert poles. The poles are colour coded to the pole sleeves.
4. On one side, locate the end of each pole into the corresponding eyelets on pole anchor straps.
5. On opposite side, push poles into an arch and locate pole ends into the corresponding eyelets on pole anchor straps.
6. Tighten the tension straps at the base of each pole.
7. Clip all flysheet pole clips to tent poles.
8. Peg out adjustable pegging points at both corners of one end of tent using pin-pegs supplied.
9. Pull flysheet taut, away from pegged points, until tent takes shape. Peg the two adjustable pegging points on the opposite end of the tent.
10. Peg down poles through metal rings and remaining flysheet pegging points.
11. Peg out ALL guy lines.

Inner

1. Open out inner(s) and position doorway to correspond with the flysheet.
2. Starting from the rear corners of the tent, attach the elasticated hooks on the groundsheet to corresponding rings on the flysheet anchor straps. Suspend the inner by attaching elastic loops of inner tent with clips on inside of flysheet.
3. To fit porch groundsheet clip the groundsheet's hooks to metal rings at base of flysheet. Secure the toggles through the rings at top of groundsheet.

Tension Band System

1. If necessary, insert tension bands through corresponding access points in inner tent (ceiling and sidewall). Connect the straps into the side-release buckles.
2. Adjust the tension of the TBS straps until the slack is taken out
3. Tension band pockets are provided for storage when not in use.



Vango's patented Tension Band System ensures that your tent performs in adverse weather conditions, especially strong changeable winds. In calm conditions the system can be disconnected if desired.

When tensioned, the bands brace the pole and prevent sideways movement, as shown in the diagram above. The buckles should be adjusted so that slack is removed, do not overtension the system as this may deform the poles.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER

or

AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.

UK Consumer Hotline: 0844 811 0535

E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute.

Calls from mobile phones, cable networks or public payphones will generally cost more.