



# Aeotec Radiator Thermostat

(Z-Wave Thermostat)



## **Aeotec Radiator Thermostat Engineering Specifications and Advanced Functions**

With the Aeotec Radiator Thermostat you get many functions. It regulates the room temperature to your comfort. For the best use it is equipped with FLiRS (Frequently Listening Receiver Slave) and reacts immediately to incoming commands of the Z-Wave controller. Furthermore the device is able to be connected to an external Z-Wave temperature sensor. Because of that the thermostat refers to the temperature of the external sensor, which can be placed in the middle of the room.

The display of the thermostat has a background light and has a big LCD screen. Besides you can also lock the local buttons as a child protection.

The multicolor LED of the central button allows a intuitive usability because the User is invited to follow the instruction based on the blinking LED of the middle butto.

The TRV can either be used as heating thermostat or as a actuator depending on the configuration of the device. The measured temperature or the position of the actuator of the thermostat are transferred to the Z-Wave gateway.

### **1. Library and Command Classes**

**1.1 SDK:** 6.71.01

#### **1.2 Library**

- **Product ID** = 0x0015
- **Product Type** = 0x0002
- **Hardware** = ZM5202
- **Library Type** = Enhanced 232 Slave
- **Z-WAVE Device Type / Role** = Thermostat - HVAC / Listening Sleeping Slave
- Security supported
  - S0 Security
  - S2 Security Unauthenticated

### **2. Supported Command Classes**

Command Class Association Group Info  
Command Class Association V2  
Command Class Basic  
Command Class Battery  
Command Class Configuration  
Command Class Device Reset Locally  
Command Class Firmware Update Md V3  
Command Class Manufacturer Specific  
Command Class Notification V8  
Command Class Powerlevel  
Command Class Protection  
Command Class Security  
Command Class Security 2  
Command Class Sensor Multilevel V5  
Command Class Supervision  
Command Class Switch Multilevel  
Command Class Thermostat Mode V3  
Command Class Thermostat Setpoint V3  
Command Class Transport Service V2  
Command Class Version V2  
Command Class Z-Wave+ Info V2


### 3 Association Group Information










Aeotec TRV supports only 1 Association Group used to report lifeline to the Z-Wave Controller.

#### Group 1 - Lifeline

Supported Nodes 1

#### 4. Supported Button Triggers.




Button	Interaction	Result/Behavior
	Press once	Decrease room temperature by 0,5°C
	Press and hold	Decrease room temperature by 0,5°C lower every 0,5 seconds or until the lowest temperature is set
	Press once	Increase room temperature by 0,5°C
	Press and hold	Increase room temperature by 0,5°C and raise every 0,5 seconds or until the highest temperature is set
	Push once	<ul style="list-style-type: none"><li>- Confirm action which is displayed in the LED</li><li>- Switch in the Boost mode (Quick Heat)</li><li>- Quit Boost mode, if currently active</li></ul>
	Hold for 3 seconds	The LCD shows Z-Wave Node ID
	Hold for 5 seconds	Exclusion Mode
	Hold while unpowered and insert batteries	Factory Reset
	Hold both simultaneously for 3 seconds	Sets or clear child protection

## 5. Boost LED Indicator



Color	State	Meaning
	Blinking	OTA Update is in process
	Lights constantly for 5 seconds	A task has failed
	Permanently on	An error occurred
	Blinking	User conformation is required to start a task
	Lights constantly for 5 seconds	A task was completed successfully

## 6. LCD Icons



**Wrench:** Lights up if mechanical tasks are ongoing



**Antenna:**

Displays the Radiator Thermostat network state.



Segment visible: rf-link established

Segment turnoff: rf-link lost

**ID:** Lights up if the Display shows the Z-Wave NodeID



**Battery:** Lights up if less than 15% battery is remaining



**Lock:** Light up if child protection is set



**Degree Celsius:** Displayed if the LCD shows a setpoint temperature



## **7. Child protection.**

If you have children who may press the buttons of Radiator Thermostat, you can enable child protection which will disable manual control of Radiator Thermostat.

Press and hold plus ( + ) and minus ( - ) button simultaneously for 3 seconds to toggle enable/disable child protection.

Note: If child lock is enabled, this icon will appear:

If the Radiator Thermostat is set into the highest protection level it is no longer possible to operate the device locally.

## **8. Altering the operating states.**

You can manually control some of Radiator Thermostats functions using its buttons.

### 1. Off-Mode

- Press and hold the minus ( - ) button until OFF is displayed.

### 2. Boost-Mode

- Push the boost button.
- Alternatively, press and hold the plus ( + ) button until ON is displayed.

### 3. Heating-Mode

- If the operating state is not heating mode.
- Press the plus ( + ) or minus ( - ) button will bring the device in heating mode.

## **9. Display NodeID.**

If you forget what Node ID your Radiator Thermostat is, and your Z-Wave controller does not provide a good method to locate it, you can display the NodeID by:

- Press and hold the boost button for 3 seconds to display the NodeID.

## **10. Manually Reset your device.**

If you find that your Z-Wave controller is no longer functional or working, you can manually reset Radiator Thermostat using these steps:

1. Remove batteries.
2. Press and hold the Boost button.
3. While still holding Boost button insert batteries.
4. The LCD will show "RES" icon.
5. Release the Boost button.
6. Now press the Boost Button to initiate a manual factory reset.

## **11. Manually Reset your Radiator Thermostat.**

If you find that your Z-Wave controller is no longer functional or working, you can manually reset Radiator Thermostat using these steps:

1. Remove batteries.
2. Press and hold the Boost button.
3. While still holding Boost button insert batteries.
4. The LCD will show "RES" icon.
5. Release the Boost button.
6. Now press the Boost Button to initiate a manual factory reset.

## 12. Configuration Command Class

### Parameter 1: LCD invert

Inverts the LCD orientation.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Normal orientation
1	LCD content inverted

### Parameter 2: LCD Timeout

Configures the timeout of the LCD.

Size: 1 Byte, Default Value: 0

Setting	Description
0	LCD always on
5 - 30	LCD timeout in seconds

### Parameter 3: Backlight

Enables or disables the LCD-Backlight.

Size: 1 Byte, Default Value: 1

Setting	Description
0	Backlight disabled
1	Backlight enabled

### Parameter 4: Battery report

Enables or disables unsolicited battery reporting once a day.

Size: 1 Byte, Default Value: 1

Setting	Description
0	Battery reporting disabled
1	Battery reporting enabled

### Parameter 5: Measured temperature report

Reports the measured room temperature on change.

Size: 1 Byte, Default Value: 5

Setting	Description
0	Reporting disabled
1 - 50	Reporting Delta in 1/10 Celcius

### Parameter 6: Valve percentage report

Reports the valve percentage on change.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Reporting disabled
1 - 100	Reporting Delta in percent

**Parameter 7: Window open detection**

Configures the sensitivity of the window open detection.

Size: 1 Byte, Default Value: 2

Setting	Description
0	Detection disabled
1 - 3	Sensitivity level

**Parameter 8: Measured temperature offset**

Configures an offset for the measured temperature. Set the offset to -128 (0x80) if measured temperature is provided externally.

Size: 1 Byte, Default Value: 0

Setting	Description
0 - 50	Offset in 1/10 Celcius (0°C - 5°C)
128	Temperature is supplied externally
206 - 255	Offset in 1/10 Celcius (-5°C - 0,1°C)