

XL – Talking Watch Calendar (4–Button) Instructions

Functions in Normal Time Mode:

- Press “S1” to activate voice saying time.
- Press “S3” to activate voice saying day, date and year.
- Press “S4” to turn alarm on and off.
- Press “S2” to hear alarm status and alarm time (if on).

Setting Instructions for Analog Time:

Note: If there is a plastic stopper between the crown and watch case, please remove and push down crown in to start analog time.

- *Gently pull crown out until you feel a click
- *Turn crown to set hour and minute hands
- *Push crown back in to set time

Setting Instructions for Talking Time, Date, Alarm and Chime:

To activate setting mode, press and hold “S4” for 3 seconds. Once you hear “chime on” you will know you are in setting mode.
Press button “S4” to navigate through the different functions to set. Once you reach the desired function, then use button “S2” to adjust.
For example, to set the time, press “S4” until you hear “Time Hour Setting”, then press “S2” to move to the desired hour.
Press “S4” again to hear “Time Minute Setting”, then press “S2” to move to the desired minute. This same process is used to set chime, alarm, date and time functions.
To exit setting mode, press “S3” to return to normal time mode.

Sleep Mode:

Hold “S1” for 3 seconds to turn off voice function and place in “sleep” mode.
To activate voice again, just hold “S1” for 3 seconds.

