



The catalog of products for the visually impaired and hard of hearing
1-800-468-4789 (Toll Free, Monday – Friday 9am-5pm Eastern Time)

One Button, Dual Voice Analog Watches: Setting Instructions **101097 / 101098**

This watch should arrive in sleep mode, with all talking features turned off. To turn the talking features on, press and hold the top right (TR) button for 5 seconds until you hear a beep. To turn the talking features off, repeat this process.

This watch has one protruding button, two recessed buttons and one stem.

Buttons:

TR = Top Right button (Near the “2”)

BR = Bottom Right button (Near the “4”)

BL = Bottom Left button (Near the “8”)



TR - This is the protruding button. It is located at the top right of the face, at the 2 o'clock position. This button, when pressed, will tell you the time.

BR - This is a recessed button at the bottom right of the face, at the 4 o'clock position. This is the Setting button. It also turns the hourly chime on and off.

BL - This is a recessed button at the bottom left of the face, at the 8 o'clock position. This is the Mode button. It also turns the alarm on and off.

To Set the Analog time

The analog time and the talking time run independently of each other and therefore need to be set separately.

- To set the analog time, pull the stem out (at the 3 o'clock position). There may be a red battery saver tab that needs to be removed before setting the time.
- Turn the stem to the correct time.
- Once the correct time is displayed, push the stem back in.

To Set the Talking Features

- This watch has the following talking features:
 - Talking time, choice of male or female voice, talking alarm with choice of 3 alarm sounds, 12 or 24 hour time. It also has an hourly chime.

- To change any of these features, use a ball point pen tip or the end of a paperclip to access the BL (bottom left) recessed button. This is the Mode button.
 - Press and hold the recessed Mode button until you hear “Alarm Sound Setting”
 - As you continue to press the Mode button, you will scroll through the setting options in the following order:
 - Alarm sound setting, alarm hour setting, alarm minute setting, time hour setting, time minute setting, and 12 hour setting.
 - Scroll through the mode settings to find the function you need to change.
 - Once you reach the function you need to change, use the paperclip tip to push the BR recessed button repeatedly and find your selection.
 - For example, **to change the time**, push and hold BL to access the mode settings, and then push the Mode button 4 times to reach “Time Hour Setting.” Push the bottom right recessed Setting button to scroll through to the necessary hour. When you hear a beep, the hour has been set. Then go back to the mode button. Push and hold it to access Mode, then push it 5 times to reach “Time Minute Setting.” Go to the BR recessed Setting button to scroll through to the correct minutes.

To Change Between the Male and Female Voice

- Press and hold the TR (top right) button for 5 seconds to put the watch into sleep mode. You will hear the watch beep when it is in sleep mode.
- Press and hold the TR button again to take the watch out of sleep mode. When the watch comes out of sleep mode, it will have the opposite voice. Press the TR button again to hear which voice you want. Each time you press the TR button, it will change voice. Confirm your choice by pressing the BR button. You may hear Chime Off when you do this. This is OK.

To Hear The Talking Time

- Press the protruding TR (top right) button near the 2 o'clock position. The current time will be spoken.

To Turn the Alarm On or Off

- Press the BL Mode button quickly (without holding it.) You will hear “Alarm On” or “Alarm Off.” To change this setting (to Off or On,) quickly press the BL button again. Pressing the Mode button quickly 1 time will tell you if the alarm is on or off. Pressing it quickly a second time will change that setting.

To Turn the Hourly Chime On or Off

- Press the BR Setting button quickly (without holding it.) You will hear “Chime On” or “Chime Off.” To change this setting (to Off or On,) quickly press the BR button again. Pressing the Setting button quickly 1 time will tell you if the chime is on or off. Pressing it quickly a second time will change that setting.

Batteries

- NOTE: Only a professional, qualified jeweler should change these batteries.
- Watches require one battery for both the talking and analog features, **CR2016**
- *Battery life is NOT warranted by LS&S.*