
















HARDWARE


1  Cam Lock 20 Pcs	2  Klix Cam 20 Pcs	3  Housing Cap (Long) 11 Pcs	4  Housing Cap (Short) 9 Pcs	5  Adjustable Glide 4 Pcs	6  3" L-Bracket With 6 Hole 6 Pcs	7  Screw #6 x 5/8" 36 Pcs	8  M4 x 65 Allen-Key 1 Pc	9  Ø8mm Hole Plug 7 Pcs
--	--	---	---	--	---	--	--	--

COMPONENTS

A  Side Panel x 2	B  Desk Top	C  Back Panel
--	--	---

KLIX CAM INSTRUCTIONS


1  Line up Cam Lock, turn clockwise.	2  Insert the cam with the arrow pointing towards the hole in the edge.	3  Insert the Cam Lock into Klix Cam. Turn Klix Cam to lock.
--	--	---



IMPORTANT !!


- Place all wooden parts on a clean, smooth surface to prevent the parts from being scratched.
- Check that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten any screws or bolts until the unit is completely assembled.
- Keep all hardware parts out of reach of children.

1



Attach Desk Top(C) and Back Panel(D) to Side Panel(B) by using Cam Lock(1) and Klix Cam(2).


2



Attach L-Bracket(6) to Side Panel(B) and Desk Top(C) as shown. Tighten Screws(7) securely.


Screw Adjustable Glide(5) into bottom of Side Panel(B).

3



Insert the Hole Plug (9) to Top edge of Side Panel (B) and Back Panel (C) which the hole are not in use.

4



Attach Housing Cap (3,4) to all Klix Cam(2) by pushing neck through center of cam.