

victor ITV2 (DSC PowerSeries Neo) Integration User Guide

Part Number: 8200-1147-94 C0

Notice

The information in this manual was current when published. The manufacturer reserves the right to revise and improve its products. All specifications are therefore subject to change without notice.

Copyright

Under copyright laws, the contents of this manual may not be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of Tyco Security Products. © 2016 Tyco Security Products. All Rights Reserved.

American Dynamics

6600 Congress Avenue

Boca Raton, FL 33487 U.S.A.

Customer Service

Thank you for using American Dynamics products. We support our products through an extensive worldwide network of dealers. The dealer through whom you originally purchased this product is your point of contact if you need service or support. Our dealers are empowered to provide the very best in customer service and support. Dealers should contact American Dynamics at (800) 507-6268 or (561) 912-6259 or on the Web at www.americandynamics.net.

Trademarks

Windows[®] is a registered trademark of Microsoft Corporation. $PS/2^{®}$ is a registered trademark of International Business Machines Corporation.

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco Security Products will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco Security Products. are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

Introduction

ITV2 Overview	
Features	
Versions Supported	
Installation	
Installation Overview	5
Pre-Installation Tasks	
Qualified Hardware and Firmware	
Software Requirements	5
Installing ITV2	
Starting Services	
Uninstalling ITV2	7
Administration	
vistor late medica Information	0
victor Integration Information	
Associations	
Reports	
Events	
Maps	9
Configurations	
ITV2 Configuration File	11
Auto Synchronization	
CommandTimeout	
BatchCount	11
RetryCount	
Heartbeat Interval	
Enable Context Logging	
Enable Raw Data Logs Enable Additional Panel Event Logs	
Firmware Server IP	
Firmware Server Port	
Time Sync Interval	
Firmware Download Status Check Interval	
Max Thread Count	
Configuring DSC PowerSeries NEO Panel Hardware using the Keypad	
Accessing Detailed Hardware Information	
Adding ITV2 Panels	24



Fields of the ITV2 Panel Editor	26
Editing ITV2 Panels	30
Viewing and Editing ITV2 Partitions	33
Fields of the Partition Editor	33
Viewing and Editing ITV2 Zones	38
Fields of the ITV2 Zone Editor	39
Viewing and Editing Virtual Zones	42
Viewing and Editing ITV2 Outputs	42
Fields of ITV2 Output Editor	43
Configuring the Alarm Filter	45
Fields of the Alarm Filter Editor	45
Configuring ITV2 Actions	45
Configuring ITV2 Alerts	47
Operation	
·	
Health Dashboard	
Reports	
Dynamics Views	
Manual Actions	
Creating and Applying Template	
Synchronizing the Panel	
Manual Actions Performed Using Virtual Keypad	
Global Arming and Disarming Partitions in the Panel	
Arming and Disarming Partitions	
Performing System Tests in the ITV2 Partition	
Bypassing and Resetting Zones	
Activating and Deactivating Command Outputs	
Downloading Panel Firmware	66
Troubleshooting	
Alert Types	71
Health Status	75

Introduction

ITV2 Overview

ITV2 integration provides advanced, seamless integration between victor unified systems and DSC Intrusion panels. This integration allows users of **victor Unified Client** to monitor and configure their DSC PowerSeries NEO Panel, alarms and personnel from the victor environment.

This document provides information about the ITV2 Integration from within the victor environment. All the features and functionality explained here are with respect to the victor platform.

Product Components

- The victor Unified Client application is configured with ITV2 objects.
- ITV2 Objects: Physical or logical ITV2 entities within the victor environment. Following are the ITV2 objects:
 - Panel: Panel refers to the DSC PowerSeries NEO Panel Hardware which is connected to one or more keypads, sensors and detectors.


Note

DSC Power series Neo panel functions in the victor unified client platform integrated with ITV2 integration and uses the ITV2 protocol for communication.

- Partition: ITV2 Partition refers to a area defined in the panel. DSC PowerSeries NEO Panel supports a maximum of 8 partitions.
- **Zone**: ITV2 Zone refers to the physical interface or sensors in the DSC PowerSeries NEO Panel hardware. DSC PowerSeries NEO Panel supports a maximum of 128 zones, which can include a maximum of 32 virtual zones.
- Virtual Zone: Virtual Zone is used by the third party hardware devices to report alarms to a central monitoring station using DSC NEO panels. DSC PowerSeries NEO Panel supports a maximum of 32 virtual zones.
- Output: The Output object refers to an event or input to a relay on the ITV2 Panel. DSC PowerSeries NEO Panel supports a maximum of 164 outputs.
- Users: DSC PowerSeries Neo Panel can support a maximum of 1000 Users...
- ITV2 Server Component: The heart of the integration, facilitates and maintains communication with the ITV2 devices and auto-creates partitions, zones, outputs and virtual zones based on the panel capabilities.

After installing the driver, all the relevant ITV2 object editors are available from victor's intrusion ribbon bar.





Features

The objective of the ITV2 Integration is to provide a standard, single interface between DSC Neo alarm panel and American Dynamics' victor - Video Management product.

ITV2 Integration supports:

- DSC PowerSeries NEO Panels
- TCP/IP communication
- Synchronization of the following objects from the Panel:
 - Partition.
 - · Zones.
 - · Output.
 - Virtual Zones.
- Synchronization of the following objects to the Panel:
 - · Partition.
 - · Zones.
 - · Output.
- The following actions to control the ITV2 objects:
 - Partition: Arm or Disarm.
 - · Zone: Bypass or Reset.
 - · Output: Activate or Deactivate.
- · Remote firmware download
- Create and Apply **Templates** for the panel
- Alarm Filtering, Virtual Keypad
- victor Roles and Object Association
- victor Client-side Event Management
- Devices on victor Maps and Health Dashboard

Versions Supported

The victor ITV2 Integration supports firmware versions:

- Keypad: v01.10.01.51/v01.11.01.13/v1.20.01.29
- Communicator: TL280/TL280R/TL2803G: v04.11.04.31/v5.00.04.27/ v05.20.01.29
- DSC NEO Panel UA621 REV03: v01.12.01.13/v01.14.01.10/v1.20.01.31/ v1.21.01.01/v01.30.01.08

Note

The Communication mode supported by the ITV2 Integration is Network (TCP/IP).



TABLE 1. Versions Supported

Hardware Version	Hardware Model	Firmware Version Supported
UA621 REV03	HS2016/HS2032/HS2064/H S2128	v01.12.01.13/v01.14.01.10/ v1.20.01.31/v1.21.01.01/ v01.30.01.08
UA601 Rev03	TL280/TL280R /TL2803G	v04.11.04.31
UA628 Rev03	HS2LCD	v01.10.01.51/v01.11.01.13/v 1.20.01.29
UA685 Rev01	TL280/TL280R /TL2803G	v5.00.04.27/ v05.20.01.29

Installation

Installation Overview

Like the victor system, the ITV2 Integration has client and server components. You must install the client components on every computer that runs **victor Unified Client** applications and install the server components on the **victor Application Server**.

Pre-Installation Tasks

Before installing the ITV2 Intrusion Integration, ensure the following:

On the victor Application Server:

- · You must have appropriate Windows permissions.
- You must be a member in the local Administrators group, or have equivalent privileges.
- victor Application Server must be installed with the ITV2 Intrusion Integration.

On the Clients:

- · You must have appropriate Windows permissions.
- You must be a member in the local Administrators group, or have equivalent privileges.
- · victor client must be installed.

Qualified Hardware and Firmware

The ITV2 Integration has the same hardware, software, and disk space requirements as C•CURE 9000. If the target computer can install victor Application Server, then it satisfies ITV2 Intrusion Integration requirements.

Supported ITV2 Intrusion Integration Panels are:

· DSC PowerSeries NEO Panel

The ITV2 Intrusion Integration requires the following firmware:

- Keypad: v01.10.01.51/v01.11.01.13/v1.20.01.29
- Communicator: TL280/TL280R/TL2803G: v04.11.04.31/v5.00.04.27/ v05.20.01.29
- DSC NEO Panel UA621 REV03: v01.12.01.13/v01.14.01.10/v1.20.01.31/ v1.21.01.01/ v01.30.01.08

Software Requirements

- C·CURE 9000 Standalone: v2.4, 2.41, 2.42, 2.5, and 2.51
- victor Application Server: v4.6, 4.7, 4.7.1, 4.8, 4.8SP1 and 4.8.1
- victor unified client: v4.6, 4.7, 4.7.1, 4.8, 4.8SP1 and 4.8.1



Installing ITV2

Note

Note: You must install the ITV2 Intrusion Integration in the same folder as victor. If the correct version of victor is not installed, a message prompting you to install the correct version is displayed.

Procedure 4-1 Installing ITV2 on victor Application Server

All services are stopped during installation and

Step	Action
1	Close all rupping programs and stop all continue
•	Close all running programs and stop all services.
2	Navigate to http://www.americandynamics.net and download the appropriate version of the ITV2 Software Driver.
3	Double-click the ITV2 _Integration.exe file. The Install Wizard begins and the Welcome to ITV2 Intrusion Integration window appears.
4	Click Next and follow the Install Wizard.
5	Read the The End User License Agreement EULA and select the I accept the terms in the license agreement button, then click Next .
6	Click Install . The program begins to install. After completion, the InstallShield Wizard Complete window appears.
7	Click Finish to complete the installation.
8	Restart the system installation. After installation, a new group called Intrusion is created in the Setup tab.

Starting Services

installation.

9

Procedure 4-2 Configuring the Server Services

Step Action

Restart services on victor Application Server that may have been stopped during

- 1 Launch the Server Configuration Application:
 - a From the Windows Start menu, click All Programs and then click Tyco.
 - b Right-click Server Configuration and then click Run as Administrator. Server Configuration Application page opens.
- 2 Restart the CrossFire Services:
 - a On the Server Configuration Application page, click to open the Services tab.
 - **b** In the **Framework Services** area, click the **Stop** button beside Crossfire Framework Service to stop all services. Wait for the status to change to **Stopped**.
 - c Click the Start button beside Crossfire Framework Service and wait for the status to change to Running.

- d Click the **Start** button beside **Crossfire Server Component Framework Service** and wait for the status to change to **Running**.
- e In the Extension Services area, locate the ITV2 Driver Service. Select the Enabled check box and then click the Start button. The status of the ITV2 Driver Service changes to Running.

Uninstalling ITV2

Procedure 4-3 Uninstalling ITV2

Step	Action
1	Close all running programs.
2	Open the Windows Control Panel and click Programs and Features.
3	Right-click ITV2 and click Uninstall. The ITV2 Setup Wizard dialog box opens.
4	Click Next . The ITV2 Setup dialog box opens. This setup wizard allows you to remove the ITV2 Driver Service.
5	Click Next. The Ready to remove ITV2 Driver Service dialog box appears.
6	Click Remove.
7	(Optional) Click the check box for Drop the DSC Driver Service database tables to remove the ITV2 tables from the database. The Completed the DSC Driver Service Setup Wizard appears.
8	Click Finish. The Setup Successful dialog box appears.
9	Click Close.



Administration

victor Integration Information

Roles

victor **Roles** support ITV2 Integration device privileges, therefore all context menu actions associated with the devices are added to existing victor **Roles** which can be edited accordingly. For more information on **Roles**, refer to the *victor Unified Client Configuration and User Guide*.

Associations

victor's **Object Association** supports ITV2 Integration objects. **Object Association** refers to linking unrelated victor objects with the intent of enabling incident building capability. For more information on **Object Associations**, refer to the *victor Unified Client Configuration and User Guide*.

Reports

victor's **Reports** selection tool and **Find in Journal** feature support ITV2 Integration objects. For more information on **Reports** and the **Find in Journal** feature, refer to the *victor Unified Client Configuration and User Guide*.

Events

victor **Events** supports ITV2 Integration objects support allowing you to detect, monitor and record specific activities on the system. For further information on **Events**, refer to the *victor Unified Client Configuration and User Guide*.

Maps

victor **Maps** and **Find on Map** features support ITV2 Integration objects. For more information on **Maps** and the **Find on Map** feature, refer to the *victor Unified Client Configuration and User Guide* are available on the American Dynamics website http://www.americandynamics.net.



Configurations

ITV2 Configuration File

The driver configuration file, ITV2Configuration.xml is located in Tyco\CrossFire\ServerComponents. You can configure the following:

Note

Restart the driver after changing the configuration file.

Auto Synchronization

The default value is FALSE. When Auto Synchronization is FALSE, the panel will not start synchronizing after coming online with victor, it will only display the troule status and push time and date into the panel. If Auto Synchronization is set to TRUE, then synchronization starts immediately after the panel comes online.

CommandTimeout

It is the duration the ITV2 integration waits for a response to a command sent to the Panel. The default value is 10000 milliseconds.

BatchCount

It is the number of panels that can synchronize simultaneously. The default value is 10, which means that a maximum of 10 panels can synchronize simultaneously. You can change this value depending on the system configuration.

RetryCount

The default value is 3, which means that the driver will try a maximum of 3 times if it does not receive the required response for a command from the panel.

Heartbeat Interval

The default value is 20000 milliseconds, which means that the driver sends heartbeat to the panel once in every 20 seconds. You can configure this value to a maximum of 29000 milliseconds.

Enable Context Logging

The default value is FALSE, if it is set to TRUE, then the sequence number exchanges between the Driver and the Panel is captured in the CrossFire log.

Enable Raw Data Logs

The default value is FALSE, if it is set to TRUE then the raw data/byte stream exchanges between the Driver and the Panel is captured in the CrossFire log.

Enable Additional Panel Event Logs

The default value is FALSE, if it is set to TRUE then the Keypad access events are logged in the Activity Viewer.

For Example: *6 access by User "User1"



Firmware Server IP

This is the FTP server IP used for firmware upgrade.

Firmware Server Port

This is the FTP server port used for firmware upgrade.

Time Sync Interval

This is used to synchronize the time between the Driver and Panel. The default value is 60 minutes, which means that the time-date push from Driver to Panel happens once in every 60 minutes. You can configure this value.

Firmware Download Status Check Interval

After firmware download is initiated from the Driver, the status of the firmware download is checked periodically base on the value set for this variable.

Max Thread Count

The default value is 10, which means that a maximum of 10 threads are used for all the panels. You can configure this value depending on the system configuration.



Configuring DSC PowerSeries NEO Panel Hardware using the Keypad

ITV2 Integration supports DSC PowerSeries NEO Panels. This section provides instructions to perform basic configurations in the DSC PowerSeries NEO Panel that enable it to communicate with the Unified server.

The ITV2 Integration supports the following firmware versions:

- o Keypad: v01.10.01.51/v01.11.01.13/v1.20.01.29
- o Communicator TL280/TL280R/TL2803G: v04.11.04.31/v5.00.04.27/ v05.20.01.29
- o DSC NEO Panel UA621 REV03: v01.12.01.13/v01.14.01.10/v1.20.01.31/ v1.21.01.01/ v 01.30.01.08

Note

The Communication mode supported by the Integration is Network (TCP/ IP).

Following basic configurations must be performed in the DSC PowerSeries NEO Panel to connect it to victor:

Procedure	Configurations	Subsection
Procedure 1	Enabling the Alternate Communicator	
Procedure 2	Configuring the Communicator	
Procedure 3	Viewing the Panel Account Number	Subsection 651


Procedure	Configurations	Subsection
Procedure 4	Enabling the DSC PowerSeries NEO Panel over Ethernet	Subsection 663
Procedure 5	Configuring the ITV2 Server IP Address	Subsection 693
Procedure 6	Configuring the Port Number	Subsection 694
Procedure 7	Configuring the Panel IP Address	Subsection 001
Procedure 8	Viewing the Remote Panel Account Code	Subsection 652
Procedure 9	Enabling TCP Communication	Subsection 664

Procedure 5-1 Enabling the Alternate Communicator

Step Action


1 Using DSC PowerSeries NEO Panel Keypad, press [*] [8].

Enter Your Installers Code message appears on the keypad, as shown in the following figure:



2 Enter the Installer Code using the keypad. The default Installer code is **5555**.


Select <000> Program Labels message appears, as shown in the following figure:



- 3 Press [382] using the keypad.
- 4 Use the (>) to scroll to subsection [5].




Com Opt3 <5> Alternate Comm message appears, as shown in the following figure:



- 5 Verify if Alternate Comm option is **Y**. If not, select **Y** using [*] button on the keypad.
 - **Note:** Press [*] to toggle between **Y** and **N**.
- 6 Press (>) to save the modified value.
- 7 Press # to exit the subsection.
- **8** Press [401].
- **9** Use the (>) to scroll to go to subsection [7].

Toggle <7> AltCom DLS Enb message appears, as shown in the following figure:




- 10 Verify if Alternate Comm option is **Y**. If not, select **Y** using [*] button on the keypad.
 - **Note:** Press [*] to toggle between **Y** and **N**.
- 11 Press > to save the modified value.
- Press # to exist the subsection and section.

- End -


Procedure 5-2 Configuring the Communicator

Step Action

1 Press [*] [8].




Enter the Installer Code. Default Installer code is 5555.Select <000> Program Labels message appears, as shown in the following figure:




3 Press [851]

Select <851> Alt Comm Prog message appears, as shown in the following figure:



4 Press # to exit the subsection. The **Enter Subsection** message appears:



- End -

Procedure 5-3 Viewing the Panel Account Number (subsection 651)

The Panel account number is the local panel encryption key of the panel. The first 8 digits of this code are used as a Remote Encryption Key in the integration.

The account number is a 12 digit number which is unique to the panel and cannot be modified.

To view the Panel account number, continue from Step 4 of "Configuring the Communicator" on page 15. and then perform the following procedure.


Step Action


1 Press subsection [651] using the keypad.

Note


If using communicator firmware version 5.xx, then press subsection [422].

The first 6 digits of the panel account number appears on the keypad. Scroll using the button to view the complete panel account number.





3 Press # to exit the subsection.Enter Subsection message appears, as shown in the following figure:



- End -

Procedure 5-4 Enabling the DSC PowerSeries NEO Panel over Ethernet (subsection 663)


Step Action

1 Press subsection [663].

Note

If using communicator firmware version 5.xx, then press subsection [425].

Verify if bit 3 and 5 are enabled. Options 3 and 5 need to be enabled for DSC PowerSeries Panel over Ethernet.




3 If not enabled, press 3 and 5 once.

Note

When you press 3, the bit is **ON**, and if you press 3 again it is **OFF**. All other bits need to be OFF.

4 Press # to exit the subsection.



- End -

Procedure 5-5 Configuring the ITV2 Server IP Address (subsection 693)


1 Press subsection [693].

Note

If using communicator firmware version 5.xx, then press subsection [428].

2 Enter the IP Address.

For example, if the IP address is 10.2.3.4, enter 010 002 003 004. In the following figure, only 010 is shown:



3 Press # to exit the subsection.

Procedure 5-6 Configuring the Port Number (subsection 694)

The configured port is used as the alarm port for ITV2 Integration. The port number starts from 3072 equivalent to 0C00 in hexadecimal value.

Note

To enter the hexadecimal value, press [*] to use keypad as alphabet and again press [*] to use as number. For example, to enter 0C12: press 0 [*] 3 [*] 2.

Step Action


1 Press subsection [694].

Note

If using communicator firmware version 5.xx, then press subsection [429].



2 Enter the port number in the hexadecimal format.




3 Press # to exit subsection.

Procedure 5-7 Configuring the Panel IP Address (subsection 001)

Step Action

- 4 Press subsection [001].
- 5 Enter the IP Address. For example, if the IP address is 10.2.3.4 enter 010 002 003 004. This is the IP Address of the panel.



6 Press # to exit subsection.

Note


In the instance of a DHCP, the IP address will automatically be allocated in sub-section 992.

Note

Power recycle the panel after network reconfiguration and installation.


7 Enter the installer code using the keypad. Default installer code is 5555.

Select <000> Program Labels message is displayed, as shown in the following figure.



- 8 Press [382] using the keypad.
- **9** Use the (>) to scroll to subsection [5].


Com Opt3 <5> Alternate Comm message appears, as shown in the following figure:



- 10 Verify if Alternate Comm option is **Y**. If not, select **Y** using [*] button in the keypad.
 - **Note**: Press [*] to toggle between **Y** and **N**.
- 11 Press (>) to save the modified value.
- 12 Press # to exit subsection.
- Press [401] using the keypad.
- 14 Use the (>) to scroll to subsection [7].



Toggle <7> AltCom DLS Enb message appears, as shown in the following figure:



- 15 Verify if **Alternate Comm** option is **Y**. If not, select **Y** using [*] button in the keypad.
 - **Note**: Press [*] to toggle between Y and N.
- **16** Press (>) to save the modified value.
- 17 Press # to exit subsection and section.


Procedure 5-8 Viewing the Remote Panel Account Code (subsection 652)


The remote account code is the remote encryption key of the panel. The code is used as the local encryption key for the integration and cannot be modified.

Step Action 18 Enter the subsection [652] using the keypad. Note

If using communicator firmware version 5.xx, then press subsection [423].

The first 4 digits of the remote account code appears. Scroll using the > button to view the complete the panel account number.






20 Press # to exit the subsection.

Procedure 5-9 Enabling TCP Communication (subsection 664)

Step	Action
21	Press subsection [664].
Note	

If using communicator firmware version 5.xx, then press subsection [426].

Verify if bit 3 is enabled. Option 3 needs to be enabled for TCP Communication.



23 If not enabled, press 3

Note

When you press 3, the bit is **ON**, and if you press 3 once again it is **OFF**. All other bits need to be **OFF**.

24 Press # to exit the subsection.

Accessing Detailed Hardware Information

Detailed hardware information is available for all configured ITV2 Integration devices within victor.

Follow the steps to access detailed hardware information:

- 1 On the **Setup** tab, select the relevant ITV2 object.
- 2 Select Show All.
- 3 Right-click the object you want information about and then click **Edit**.

Adding ITV2 Panels

Before adding **Partitions** and **Zone**, you should configure new DSC PowerSeries NEO Panels using the **ITV2 Panel** editor.


Note

Panel Account Number, **Encryption Key**, **Access Code**, and **Installer Code** are assigned and provided with the DSC NEO Panel hardware.

Procedure 5-10 Adding New ITV2 Panels

Step	Action
1	Select Intrusion from the Setup tab.
2	Select ITV2 from the drop-down list.
3	Select New.

- **4** Edit the fields of the ITV2 Panel. For more information, see Fields of the ITV2 Panel Editor.
- 5 Click Save and Close.



After adding the ITV2 panel you must synchronize the panels. For more information, see Synchronizing the Panel on page 54



Fields of the ITV2 Panel Editor

General Section

Property	Description
Name	Enter a unique name to identify the ITV2 Panel.
	The name of the panel can be alphanumeric and up to 100 characters long.
	Ensure that the name is unique, else an error message is displayed.
Description	(Optional) Enter a description for the panel.
Enabled	Select the check box to establish the communication between the victor and the ITV2 Panel.
	If the Panel is disabled, the communication between victor and the Panel is disabled.

Configuration Section

Panel Type Select a panel type from the available options: NEO (default) None Panel account number Enter the assigned account number of the ITV2 Panel. Panel account number is unique to a panel and provided with the D NEO Panel hardware.	
Panel account number of the ITV2 Panel. Panel account number bundles are panel and provided with the D	
Panel Enter the assigned account number of the ITV2 Panel. account number Panel account number is unique to a panel and provided with the D	
account number Panel account number is unique to a panel and provided with the D	
number Panel account number is unique to a panel and provided with the D	
NEO I and hardware.	SC
The account number must be 12 characters and numeric only, else error message is displayed.	an
For more information on how to view the Panel account number, se "Configuring DSC PowerSeries NEO Panel Hardware using the Keypad" on page 12.	е
Access Enter the access code.	
The access code is the master code of the panel used to authentical operations in the panel, such as: User Level tasks, Event Level tasks and System Level tasks.	
The access code is assigned and provided with the Panel hardware You can modify the Access code in the panel keypad only. For more information on how to modify the access code, see "Configuring DS PowerSeries NEO Panel Hardware using the Keypad" on page 12.)
The Access code must have only numeric values and can be four, s or eight digits long.	ix
NOTE: If you modify the access code in the DSC NEO Panel, the sa should be configured in victor or else the events and schedule actio will fail to work, as expected.	
Connection Type The connection type used to select the mode of communication. By default, the connection type is TCP.	
Host IP Enter the TCP/IP address of the unified server.	
Address The IP address must be in the IPv4 format. For example, 191.2.3.4	

Alarm Port	Enter the port number used for communication.
	The Alarm Port is used for communication between the Unified server and the DSC NEO panel.
	The port number can be four, six or eight digits long.
	NOTE : If multiple Panels are in use, there should be an unique Alarm port number for each panel, else an error message is displayed.
Installer Code	Enter the Installer Code of the panel, which is assigned and provided with the Panel hardware.
	The Installer Code is used to authenticate the panel configuration tasks performed in the programing mode.
	You can modify the Installer Code in the panel using keypad only.
	For more information on how to modify the installer code, see Configuring DSC PowerSeries NEO Panel Hardware using the Keypad on page 12.
Encryption	Select the check box to enable the encryption.
	The encryption key is used to authenticate the handshake between ITV2 and unified server.
	The encryption key is assigned and provided with the DSC PowerSeries NEO Panel hardware.
	For more information on how to modify the encryption key, see Configuring DSC PowerSeries NEO Panel Hardware using the Keypad on page 12
Local	This field is enabled only if the Encryption check box is enabled.
Encryption Key	Enter the local encryption key.
	The local encryption key is 8 characters code, which is configured in the DSC PowerSeries NEO Panel.
	Enter the eight character code four times.
	For more information on how to modify the Local Encryption key in the DSC NEO Panel, see Configuring DSC PowerSeries NEO Panel Hardware using the Keypad on page 12
Remote	This field is enabled only if the Encryption check box is enabled.
Encryption Key	Enter the remote encryption key.
	The remote encryption key is the first 8 digit of the Panel Account number.
	Enter the first eight digit of the account number four times.
	For example, if the account code is 123456789012, you have to enter the first eight digit (12345678) four times.
	To view the account number, see Configuring DSC PowerSeries NEO Panel Hardware using the Keypad on page 12
Time Zone	Click to display the Object Selector. Select a time zone from the Object Selector window and click OK . The panel synchronizes based on the selected time zone.



Note

Ensure that the installer code and access code set in the configuration tab is same as that mentioned in the Panel section [006]. If they are not same, the Panel is locked after performing the number of tries configured in the Panel section [012].

Late to Open Control Section

Property	Description
Late to Open	Late to Open Control is used to schedule the monitoring period.
Control	Select this check box to enable the Late to Open Control.
Hour (Sunday to	Enter the time in hour when the panel should be disarmed
Saturday)	This field is enabled, if Late to Open Control is enabled.
	The valid range is from 00:00 – 23:59 hours.
	For example - 16.00
Minute (Sunday	Enter the time in minute when the panel should be disarmed.
to Saturday)	This field is enabled, if Late to Open Control is enabled.
	The valid range is from 00 – 59 minutes.
	For example - 00.15

Panel Information Section

Expander	Information
Panel Information	Device software version
	Protocol Version
	Last Synced time
	Max Zones
	Max Users
	Max Partitions
	Max Outputs

Status Section

Property	Description
Online Status	Indicates the online status of the Panel.
Synchronization Status	Indicates the synchronization status of the Panel.
Firmware Download Status	Indicates the firmware download status of the Panel.
System Trouble	Indicates the system trouble status of the Panel.
Communication Trouble	Indicates the communication trouble status of the Panel.
Wireless Device Trouble	Indicates the wireless device trouble status of the Panel.
Wired Module Trouble	Indicates the wired module trouble status of the Panel.

User Section

Property	Description
User Index	Indicates the number to identify the user. The number is incremental when you create a new row in the table and cannot be modified.
User Name	Click to display the Object Selector. Select a user from the Object Selector window and click OK . The selected user is mapped to a panel.
	Refer to Mapping Users to a Panel and Removing a User from a Panel for procedural information regarding users and panels.

Virtual Zone Configuration Section

Property	Description
Virtual Zone Index	Indicates the number to identify the virtual zone. The number is incremental when you create a new row in the table and cannot be modified.
Zone Name	Click to display the Object Selector. Select a zone from the Object Selector window and click OK . The selected zone is mapped to a virtual zone.

Associations Section

Use the **Object Selector** in this section to associate other hardware devices with the ITV2 Panel (maximum of 5).

Note

- Ensure the following before performing **Write Assignment** operation:
 - Partition is not in an Alarm or Armed state.
 - Keypad is not in programming mode.
- Ensure you Save and Close after every Write Assignment operation.
- After performing a Write Assignment operation if the message Function unavailable/Panel is busy appears, perform Sync to Panel. This ensures that the configuration communicates to the Panel.
- The sync status of the panel changes to **Synchronizing-Synchronized** after every write operation.
- The user in Index 1 is the Master User in the Panel, therefore the modification of the Primary User is not allowed through the integration.
- In the User tab, Index 1 will be reserved for the Primary User, which cannot be edited or removed.

Troubleshooting

If the Panel does not come online and cannot establish a connection, verify the following areas are operational:

 Verify the physical connection between the Panel and the server is working by performing the following:



- Ping the IP Address of the Panel configured in section [851] [001] and/or [851]-[992]. Verify the IP Address is pinging on the network.
- Use 'netstat' to check the connection is established with the alarm port.
- Any other application such as DLS should not be connected to the Panel.
- Verify if CrossFire services, the server, and the ITV2 driver are running.
- · Verify if Panel Account number, Alarm port, Access code, Installer code, Encryption key, and Host IP Address is entered correctly.
- Verify the configuration of the ITV2 Panel hardware.
- Verify that the Auto Synchronization option is not enabled in the ITV2Configuration.xml file if you intend to make offline changes to the panel. The Auto Synchronization option will override any modifications performed when the panel is offline. For example, if you have modified the zone, output, or user assignment in the Partition editor when the panel is offine, Auto **Synchronization** overrides all the configurations when the panel comes online.

Note

Verify the Installer Code and the Access Code are the same as the Panel section [006]. If this is set differently, it will lock the Panel after X number of attempts for Y duration that was configured in Panel section [012].

- End -

After adding the ITV2 panels you must synchronize the panel. For more information see Synchronizing the Panel on page 54.

Editing ITV2 Panels

You can make the following changes:

Procedure	Changes
Procedure 11	Modify Parameters in ITV2 Panel
Procedure 12	Map Users to Panel
Procedure 13	Remove a User from a Panel
Procedure 14	Configure a Virtual Zone
Procedure 15	Remove a Virtual Zone

Procedure 5-11 Modifying Parameters in ITV2 Panel

Step	Action	
1	Select ITV2 Panel from the Setup tab.	
•	Colort New from the draw down list	

- 2 Select **New** from the drop-down list.
- 3 Select Show All.
- 4 Right-click the panel you want to edit.
- 5 Select Edit and make the required changes.

6 Click Save and Close.

- End -

For information about fields in the ITV2 panel, see Fields of the ITV2 Panel Editor.

Procedure 5-12 Mapping Users to a Panel

Step	Action
1	On the Device List , select the ITV2 Panel you want to edit, and click the Users drop-down menu.
2	Click to create a new User. A new row is created and the User index is incremented by 1.
3	Click on the newly created blank row. The Object Selector appears.
4	Select the user to map to the panel and click OK .
5	Click 💾 to save and close the Panel editor.

Note

The Personnel feature in victor accepts the same PIN for multiple personnel. However, the Panel only accepts a unique access code for every user. It is therefore recommended to use one-to-one Personnel User mapping.

The user in Index 1 is the Master User in the Panel and thus the modification of the Primary User is not allowed through the integration. Changing the PIN and User attributes in Personnel will also be reflected in the User Access Code and configuration of the Panel respectively.

No personnel will be created in victor and mapped with the Primary User, which is linked to the Master code, in the Panel.

- End -

Procedure 5-13 Removing a User from a Panel

Step	Action
1	On the Device List , select the ITV2 Panel you want to edit and click the Users drop-down menu.
2	Select a User row that you want to remove and click 🛜.
3	Save and close the Panel editor.
	- End -



Procedure 5-14 Configuring a Virtual Zone

In the ITV2 Panel, click the Virtual Zone Configuration drop-down menu. Click to create a new virtual zone. A new row is created and the Virtual Zone Index is incremented by 1. Click on the newly created blank row under the Virtual Zones column. The Object Selector appears. Select the virtual zone you want to associate with the Panel and then click OK. Click and wait until the status of the panel has changed from Synchronizing to Synchronized. Click to save and close the Panel editor. The zone is mapped to the Virtual Zone and appears in the Device List. The normal zone is changed to a virtual zone.

- End -

Procedure 5-15 Removing a Virtual Zone

Step	Action
1	In the ITV2 Panel, click the Virtual Zone Configuration drop-down list.
2	Select the row corresponding to the virtual zone you want to remove and click on the row in the table is removed and the virtual zone is changed to a normal zone.
3	Click 📙 to save and close the Panel editor.
	- End -

Viewing and Editing ITV2 Partitions

You cannot create **Partitions** directly from victor. Depending on your victor role assignment, you can view or edit partitions from the **Setup** tab.

Procedure 5-16 Viewing and Editing ITV2 Partitions

Step	Action
1	Select ITV2 Partition from the Setup tab.
2	Select ITV2 Partitions from the drop-down list.
3	Select Show All. A list displays all available partitions.
4	Right-click the Partition and select Edit .
5	Click Save and Close after completion of edits.
Note	

During synchronization, you cannot modify the details in the ITV2 Panel editor.

Fields of the Partition Editor


The following sections are used to edit different portions of the ITV2 Partition:



General Section


Property	Value
Partition Number	Displays the Partition number of the Panel and is auto-generated during Panel synchronization. (Read only)
Account Number	Displays the Account code of the Partition and is auto-generated during Panel synchronization. (Read only)
Account Code	You can modify the account code of the partition used for authenticating the partition manual actions.
	The account code can be 1 to 4 digits long. For example, 1234.
Entry Delay	Enter the entry delay time in seconds.
1	The maximum delay can be up to 999 seconds.
	An entry delay is the amount of time the security system waits before triggering the alarm when certain doors are opened.
Entry Delay 2	If you want to have additional exit delay, enter the entry delay time in seconds.
	The maximum delay can be up to 999 seconds.
Exit Delay 1	Enter the exit delay time in seconds.
	The maximum delay can be up to 999 seconds.
	The time duration that exists, after the code is entered till the system begins to monitor is called an exit delay. This delay is set to give time to exit from the building after arming the system from inside.

Zone Assignment Section



Property	Value
Unassigned Zone	Lists all unassigned zones.
Assigned Zone	Lists all assigned zones.
Add	Used to add unassigned zones to assigned zones.
Remove	Used to move assigned zones back to the unassigned list.
Reset	Resets assignments to the default value.
Write Assignments	Reflects the changes in the DSC panel hardware.


Output Assignment Section



Property	Value
Unassigned Outputs	Lists all unassigned outputs.
Assigned Outputs	Lists all assigned outputs.
Add	Used to add unassigned outputs to assigned outputs.
Remove	Used to move assigned outputs back to the unassigned list.
Reset	Resets assignments to the default value.
Write Assignments	Reflects the changes in the DSC panel hardware.

User Assignment Section





Property	Value
Unassigned Users	Lists all unassigned users.
Assigned Users	Lists all assigned users.
Add	Used to add unassigned users to assigned users.
Remove	Used to move assigned users back to the unassigned list.
Reset	Resets assignments to the default value.
Write Assignments	Reflects the changes in the DSC panel hardware.



Note

Ensure the following before performing Write Assignment operation:

- The Partition is not in an Alarm or Armed state.
- The keypad is not in programming mode.
- Ensure you Save and Close after every Write Assignment operation.
- After a **Write Assignment** operation, if 'Function unavailable/Panel is busy' message appears, perform Sync to Panel. This ensures that the configuration is saved in the Panel.
- The sync status of the panel changes to **Synchronizing-Synchronized** after every write operation.

Status Section

Property	Value
Armed	Indicates the arm state of the partition.
State	Following options are available:
	Disarmed
	Stay Armed
	Away arm with No Entry Delay
	Night Armed
	Quick Armed
	User Armed
	Instant Stay Armed
	Stay Armed with No Entry Delay
	Global Stay Armed
	Global Away Armed
	Customized Armed
	Away Armed With No Entry delay
	Night Armed with No Entry Delay
Ready State	Indicates if the partition is ready for arming or not.
	Following options are available:
	• Ready
	Not Ready

Alarm in	Indicates if the alarms are in memory or not.
Memory Status	Following options are available:
	Alarm in Memory
	No Alarms in Memory
Alarm State	Indicates the state of the alarm.
	Following options are available:
	Normal
	• Alarm

Associations Section

Use the **Object Selector** in this section to associate other hardware devices with the ITV2 Panel.



Viewing and Editing ITV2 Zones

You can create zones only in the Panel. Depending on your victor role assignment, you can view or edit zones from the Intrusion ribbon on the **Setup** tab.

Procedure 5-17 Viewing and Editing ITV2 Zones

Step	Action
1	On the Setup tab, select ITV2 Zone .
2	Select ITV2 Zones from the drop down.
3	Select Show All. All available zones are displayed.
4	If you need to edit a zone, right-click the zone and click Edit .
5	Click Save and Close to save your changes.

Fields of the ITV2 Zone Editor

General Section




Property	Description
Name	Enter a unique name to identify the ITV2 Zone. If the name is not unique, an error message is displayed.
	The name of the panel can be alphanumeric and can have a maximum of 100 characters.
Description	Enter a description for the zone.
Enabled	Select the check box to establish the communication between the victor and the ITV2 Zone.
	If the Zone is disabled, the communication between victor and the Zone is disabled.

Configuration Section



Property	Value
Zone number	The Zone number is auto-generated during Panel synchronization.
Zone Definition	You can modify the zone type after you pull the zones from the Panel to victor.

Attributes Section




Attribute	Description
Audible	Select to enable the audio of the panel.



Steady/Pulsed	Use to select a type of beep.
	Following options are available:
	Steady
	Pulsed
Chime	Select to enable the chime.
	Chime indicates the user to open the zone with a beep or other configured sound, instead of alarm when the partition is not armed.
Bypass	Select to enable the bypass.
Force	Select to enable the force.
	Force is used for arming a partition even if zone is having trouble and not ready for arm.
Swinger Shutdown	Used to set the number of alerts per day. All alerts after the set limit are suppressed
Transmission	Select to enable the transmission delay.
delay	This is used to delay in transmitting the alert to the monitoring station.
Burglary Verified	Select to enable Burglary alarm verification.
Normally Closed Loop	Select to enable the normally closed loop connection type.
Single End of Line Register	Select to enable the single end of line register connection type.
Double End of Line Register	Select to enable the double end of line register connection type.
Fast Loop	Select to enable the fast loop response.
Response	This is used for loop response time for mail panel zones.
Two Way	Select to enable the two way audio.
Audio	If the central station is capable, the system (provided that it has an audio module) will allow audio verification to occur.
	This can be one or two way conversation with the any user in the site.
Holdup	Select to enable the hold up verified option.
Verified	Hold-up is used to alarm for the panic situation. Hold-up zone can be bypassed only through Master access code.

Status Section



Property	Description
Alarm	Indicates the status of the alarm in the Zone.
Status	Possible values are:
	• Alarm
	Normal
	• Unknown
Fault	Indicates whether the zone is faulty or not.
Status	Possible values are:
	• Fault
	No Fault
Bypass	Indicates whether the zone is bypassed or not.
Status	Possible values are:
	• Bypassed
	Not Bypassed
Tamper	Indicates whether the zone is tampered or not.
Status	Possible values are:
	Tamper
	Not in Tamper
Open	Indicates whether the zone is opened or closed.
Close Status	Possible values are:
	• Open
	• Close

Associations Section

Use the Object Selector in this section to associate other hardware devices with the ITV2 (maximum of 5).

Note

Bypass/Reset of the zones does not work if any partition is in Arm/Alarm on the panel.





Viewing and Editing Virtual Zones

Virtual zones are used by the third party hardware devices such as the iSTAR, apC, etc. to report alarms to central Activity Viewer using DSC NEO Panels. The DSC NEO Panel supports up to 32 virtual zones.

Note

You should map one virtual zone with only one device action, but one device action can be mapped to multiple virtual zones. For example, Camera 1 is mapped to Virtual Zone 1 and Virtual Zone 2.

Once the virtual zones are configured, all the virtual zones appear in victor's **Device List**.

Note

Virtual zones are configured in section [560] in the programming mode of the panel.

The ITV2 Virtual Zone editor is used to configure details such as: name, description, definition, and attributes. You can also view the Open Close status of the zone from this editor.

Procedure 5-18 Accessing and Editing the ITV2 Virtual Zone in the Device List

On the Device List, click , the Virtual Zone icon. The configured virtual zones appear in the Device List. Right-click the virtual zone you want to access and click Edit. The ITV2 Virtual Zone editor opens. Refer to Configuration Section on page 39 and the Attributes Section on page 39 for more information.

Procedure 5-19 Accessing and Editing the ITV2 Virtual Zone in a Dynamic View

Step	Action
1	On the Build tab, select ITV2 Virtual Zone and click Show All . A list of all configured virtual zones appears.
2	Right-click the virtual zone you want to access and click Edit . The ITV2 Virtual Zone editor opens. Refer to Configuration Section on page 39 and the Attributes Section on page 39 for more information.

Viewing and Editing ITV2 Outputs

You cannot create outputs directly from victor. Depending on your victor role assignment, you can view or edit outputs from the Intrusion ribbon on the **Setup** tab.

Procedure 5-20 Viewing and Editing ITV2 Outputs

Step Action

- 1 Select ITV2 Outputs from the Setup tab.
- 2 Select **Show All**. All available outputs are listed.
- Right-click the panel and click **Edit**.
- 4 Click Save and Close to save your changes.

Fields of ITV2 Output Editor


General Section



Property	Description	
Name	Enter a unique name to identify the ITV2 Output. If the name is not unique, an error message is displayed.	
	The name of the panel can be alphanumeric and can have a maximum of 100 characters.	
Description	Enter a description for the output.	
Enabled	Select the check box to establish the communication between the victor and the ITV2 Panel.	
	If the Output is disabled, the communication between victor and the Output is disabled.	



Configuration Section



Property	Value	
Output Number	Displays the number assigned to the Output that is used to identify the Output.	
	The Output number is auto-generated during Panel synchronization and cannot be modified.	
Output Type	Displays the type of Output.	
	The output type is auto-generated during Panel synchronization and can be modified.	
	Based on the output type, the attributes are displayed.	
Zone Follower	This field is enabled only if the output type is Zone Follower.	
	Select the zone from the list.	
	Use this option to monitor a specific zone.	
Attributes	Attributes are displayed based on the output type.	
	Select an attribute to enable it.	
	For more information on available attributes for each output type, refer to the DSC NEO Panel User Manual.	

Status Section



Property	Value
Active Status	Indicates whether the output is Active or Inactive

Associations Section

Use the **Object Selector** in this section to associate other hardware devices with the ITV2 Panel (maximum of 5).

Configuring the Alarm Filter

Alarm Filter is used to filter certain group of alarms for assigned panels.

Procedure 5-21 Configuring the Alarm Filter

Step	Action
1	Select Alarm Filter from the Setup tab.
2	Select New from the drop down.
3	Complete the fields to configure the Alarm Filter.
4	Click Save and Close.

Fields of the Alarm Filter Editor

General Section

Property	Value
Name	Enter the name of the Alarm Filter.
Description Enter the description about the Alarm Filter.	
Enabled	Select the check box to enable the Alarm Filter.

Alarm Assignment Section

Property	Value		
Туре	Select ITV2 from the list.		
Options	If required, select the following in the Option section:		
	 Send to Activity Viewer, if you want to send the alarm message to the Activity Viewer. 		
	Send to Journal, if you want to journal the message.		
Filter Configuration	Select the events and click Add to include the events for filtering.		
	 Select the events and click Remove to exclude the events from filtering. 		
	Click Reset to reset the events to the default setting.		
Filter Assignment	Select the panel that you want to assign for alarm filter.		
	2 Click Add to add the panel.		
	OR		
	To remove a panel, click Remove .		


- End -

Configuring ITV2 Actions

ITV2 Integration **Actions** are available for the following objects:



- ITV2 Panel
- ITV2 Partition
- ITV2 Zone
- ITV2 Output
- ITV2 Virtual Zone



Procedure 5-22 Configuring ITV2 Actions


Step **Action** 1 Select ITV2 Action from the Setup tab. 2 Select New. Enter Name and Description for the ITV2 Integration Action. 3 In the ITV2 Device field, select to add device. The Object Selector displays. 4 5 Select desired object and click **OK**. 6 Repeat steps 1 to 5 as required. Select desired action from the ITV2 Device Action drop-down list. 7 8 Click Save and Close. Note If you want to remove the device, select the device check box to be removed and click 🚨

- End -

Configuring ITV2 Alerts

The Event Setup editor can be used to configure alerts.

For further information on Events, refer to the victor Unified Client Configuration User Guide.



Refer to Alert Types on page 71 to view a complete list of Alert Types supported by victor.

- End -


Procedure 5-23 Configuring Schedule Actions for ITV2

Step Action

- Select Event/Schedule Setup from the Build tab. The Event/Schedule Setup page opens.
- 2 Double click the Device node and use the object selector and select Type as **Schedules**.




3 Select the required **Schedule** from the list. You must have created the schedule to select it. Refer to the *victor Unified Client Configuration User Guide* for more information about **Creating Schedule**.




4 Selected **Schedule** is displayed in the Device node.



- 5 Select \(\frac{1}{2} \) in Device node to add **Alerts**.
- 6 Select **Schedule Start Time** and **Schedule End Time** check box from the **Select Alert** window.



7 Click **Add Alerts**. The **Schedule Start Time** and **Schedule End Time** is displayed in the **Alerts** node.



- 8 Select 15 in the Alerts node to add actions.
- 9 Select **ITV2 Action** from the object selector. You should have already created ITV2 Integration Action to select it. See <u>Configuring ITV2 Actions</u> on page 45.



- 10 Repeat as required.
- 11 Click Save and Close.


Note

Partitions disabled in the Panel will not update any status in C•CURE 9000.

- End -

Health Dashboard


Health status of all ITV2 objects is annunciated in victor's Health Dashboard as follows:



Refer to Health Status for a full list of supported health statuses.

Reports

Gives information of all the ITV2 actions performed during a selected time interval. To view the Reports, click **Reports and data visualization** and then click **New**. Go to the **Ad hoc** tab and select **Journal ITV2 Messages** from the Activity Type drop-down.



For more information on reporting within victor, refer to the *victor Unified Client Configuration and Administration Guide*.



Dynamics Views

All configured ITV2 Panels, Zones, Areas and Outputs are displayed in victor's object list views (dynamic views), you can right-click an object and perform manual actions on configured objects.

Manual Actions

The following message appears in the monitoring station if any partition is in alarm and armed:



8/19/2015 2:44:08 PM

Function is unavailable. Check if partition is in alarm/ armed on Panel 'Panel 1'

Following manual actions can be performed from within victor client:

Manual Actions

Creating and Applying Template

- 1. Creating a Template
- 2. Applying a Template

Synchronizing the Panel

- 3. Synchronizing from the Panel
- 4. Synchronizing to the Panel

Manual Actions Performed Using Virtual Keypad

- 5. Arming the Partition Using Virtual Keypad
- 6. Disarming the Partition Using Virtual Keypad
- 7. Bypassing the Zone Using Virtual Keypad
- 8. Resetting the Zone Using Virtual Keypad
- 9. Activating the Command Output Using Virtual Keypad
- 10. Deactivating the Command Output Using Virtual Keypad
- 11. Viewing Troubles in the Panel Using Virtual Keypad
- 12. Viewing Alarms in the Panel Using Virtual Keypad

Global Arming or Disarming Partitions in the Panel

- 13. Performing ITV2 Panel Manual Actions
 - a. Performing Global Away Arm from Panel
 - b. Performing Global Stay Arm from Panel
 - c. Performing Disarm from Panel

Arming and Disarm Partitions

14. Arming and Disarming the Partition

Performing System Tests in the ITV2 Partition

15. Performing System Test

Manual Actions

Bypassing and Resetting Zones

- 16. Bypassing the Zone
- 17. Resetting the Zone

Activating and Deactivating Command Outputs

- 18. Activating the Command Output
- 19. Deactivating the Command Output


Creating and Applying Template

Procedure 6-1 Creating a Template

Creating a template saves time because you do not have to re-enter the same information again. Follow the steps to create a template:

Step Action

- 1 In the Setup tab go to ITV2 Panel and click Show All.
- The ITV2 Panel tab appears. Right-click the ITV2 Panel and select Create Template.



3 Export Template Form window appears. Enter a template name and click Create.



- End -



Procedure 6-2 Applying a Template

Step Action

- 1 In the Setup tab go to ITV2 Panel and click Show All.
- The ITV2 Panel tab appears. Right-click the ITV2 Panel and select Apply Template.
- 3 Import Operation window appears. Select Import, select a template and then click OK.



The configurations are applied to the Panel.

Note

Only if the Personnel exists, the user code and attribute, and the user partition assignment is written to the Panel.

- End -

Synchronizing the Panel

Procedure 6-3 Synchronizing from the Panel

Step Action

- 1. Open the victor **Device List** in the victor Unified Client application.
- 2. Right -click the panel and select **Synchronize from Panel**.

- End -

Procedure 6-4 Synchronizing to the Panel

Step Action

- 1 Open the victor device list in the victor Unified Client application.
- 2 Right-click the panel and select Synchronize to Panel.

- End -

Troubleshooting Tips

If the synchronization has stopped or failed:

- Check the physical connection between the panel and the server:
 - In the command prompt, type "ping <IP address>" (for example "ping 191.20.4.5") and verify the connection.
 - Telnet to the command port number and the IP address.
 - Utilize the 'netstat' command to find problems in the network.
- Ensure the user is not inside programming mode while the driver is attempting to write to the panel.
- · Verify if the ITV2 driver and the server is up and running.
- Verify if the alternate communication is enabled in the DSC NEO Panel by using the section number 382 and option 5 and section 407 and option 7.
- Verify if any faulty hardware is connected to the panel.

- End -

Manual Actions Performed Using Virtual Keypad

ITV2 Virtual Keypad allows you to view the list of Partitions, Zones, Output, Troubles, and Alarms in the DSC NEO Panel. Ensure the panel is online and synchronized prior to accessing the virtual keypad. It is recommended that you open only one Virtual Keypad at a time.

The following actions can be completed using the Virtual Keypad:

- · Arm or Disarm a partition
- Bypass or Reset a Zone
- · Activate or Deactivate an output

Procedure 6-5 Arming the Partition Using Virtual Keypad

Ensure that the status of the partition is **Ready**. You cannot arm the partition if the status is **Not Ready** or Unknown.

Step Action

- 1 Right-click the Panel and select **Virtual Keypad**.
- 2 In the Virtual Keypad, click Partitions. All available Partitions appear.



- 3 Select the partition that you want to arm. Use the up and down arrow to move up and down.
- 4 Click Arm. The status of the partition is updated in the panel and is displayed in the Activity Viewer.
- 5 Click X to exit.

Note

You cannot arm the partition when the zones of the partition are in trouble.

- End -

Procedure 6-6 Disarming the Partition Using Virtual Keypad

1 Right-click the Panel and select Virtual Keypad. 2 In the Virtual Keypad, click Partitions. All available Partitions appear. 3 Select the partition that you want to disarm. Use the up and down arrow to move up and down. 4 Click Disarm. The status of the partition is updated in the panel and is displayed in the Activity Viewer. 5 Click to exit.

Procedure 6-7 Bypassing the Zone Using Virtual Keypad

Step	Action
1	Right-click the Panel and select Virtual Keypad .
2	In the Virtual Keypad , click Zones . All available Zones are listed.
3	Select the zone that you want to bypass. Use the up and down arrow to move up and down.
4	Click Bypass. The status of the zone is updated in the panel and is displayed in the Activity Viewer.
5	Click X to exit.
	- End -

Procedure 6-8 Resetting the Zone Using Virtual Keypad

Step	Action	_		

1 Right-click the Panel and select Virtual Keypad.

56 victor/ITV2 Integration

- 2 In the Virtual Keypad, click Zones. All available zones appear.
- 3 Select the zone that you want to reset. Use the up and down arrow to move up and down.
- 4 Click Reset The status of the zone is updated in the panel and is displayed in the **Activity Viewer**.
- 5 Click X to exit.

- End -

Procedure 6-9 Activating the Command Output Using Virtual Keypad

1 Right-click the Panel and select Virtual Keypad. 2 In the Virtual Keypad, click Output. All available command outputs appear. 3 Select the command output that you want to activate. Use the up and down arrow to move up and down. 4 Click Activate The status of the command output is updated in the panel and is displayed in the Activity Viewer. 5 Click to exit. - End -

Procedure 6-10 Deactivating the Command Output Using Virtual Keypad

Step	Action
1	Right-click the Panel and select Virtual Keypad .
2	In the Virtual Keypad , click γ Output. All available command outputs appear.
3	Select the command output that you want to deactivate. Use the up and down arrow to move up and down.
4	Click Deactivate. The status of the command output is updated in the panel and is displayed in the Activity Viewer .
5	Click X to exit.

Procedure 6-11 Viewing Troubles in the Panel Using Virtual Keypad

Step	Action		
1	Right-click the Panel and select Virtual Keypad .		
2	In the Virtual Keypad , click 🚺 Troubles . All available troubles in the panel appear.		



3 Click X to exit.

- End -

Procedure 6-12 Viewing Alarms in the Panel Using Virtual Keypad

Step	Action	
1	Right-click the Panel and select Virtual Keypad .	
2	In the Virtual Keypad , click dee Alarms . All available troubles in the panel appear.	
3	Click X to exit.	
Note		
Partitio	ons disabled in the panel will not update any status in victor.	
	- End -	

Global Arming and Disarming Partitions in the Panel

You can arm or disarm all the partitions together from the panel. You can perform the following manual actions from the ITV2 Panel:

• **Global Away Arm**: Arms all the Partitions in the panel. This option is used to arm all the sensors associated to a panel.

For example; the motion sensors, doors, and windows associated to a panel will be armed.

• **Global Stay Arm**: Arms only the perimeter of the system in the panel. This option is used to bypass the interior motion sensors and arms only the perimeter associated to a panel.

For example, the doors and windows will be armed bypassing interior sensors.

· Global Disarm: Disarms all the partition in a Panel.

Ensure the following, before performing the global arm or disarm actions:


- The ITV2 is Online.
- Partitions are ready with no trouble and no alarm.
- **Zones** are closed with no fault, no alarm and no tamper.

Note

You cannot arm a partition when the status of the zones of the partition are in Trouble.

Procedure 6-13 Performing ITV2 Panel Manual Actions


Step	Action
1	On the Build tab, select ITV2 Panel and click Show All .
2	Right-click the ITV2 Panel you want to perform the manual action.
3	Choose one of the manual actions:



a If you want to arm all the partitions in the panel select **Global Away Arm**.

b If you want to arm all the partitions, except for the interior sensors in the panel, select **Global Stay Arm**.

Refresh ITV2 Panel



c If you want to disarm all the partitions in the panel select **Global Disarm**.



4 The Access Code Operations dialog box appears. Enter the Access Code and click OK.



The status of the Partition in the Panel changes to the manual action performed.



Arming and Disarming Partitions

You can arm and disarm individual partitions from the ITV2 Partition.

- · Arm: Arms the selected Partition.
- Disarm: Disarms the selected Partition.

Table 6-1, "Arm Types for ITV2," on page 61 lists all the available arm types:

Table 6-1 Arm Types for ITV2

Arm Type	Description
Stay Arm	Select this check box to enable Stay Arm option. Stay Arm option is used to arm only the doors, windows and bypass the interiors. For example; motion detectors. If this option is enabled, all motion sensors are disabled and the entry and exit delay is enabled.
User Arm	Select this check box to enable User Arm option.
Away Arm with No Entry Delay	Select this check box to enable Away Arm with No Entry Delay option. Away Arm with No Entry Delay option is used to arm the Partition without any entry delay.
Quick Arm	Select this check box to enable Quick Arm option Quick Arm option is used when you want to exit the armed zone, to avoid disarming and then re-arming the zone.
Night Arm	Select this check box to enable Night Arm option. Night Arm option is used to arm the zones except for the devices that is set as Night zone.
Stay Arm with No Entry Delay	Select this check box to enable Stay Arm with No Entry Delay option. Stay Arm with No Entry Delay option is used to arm the zones, except the motion detectors, without any entry delay. If this option is enabled, all motion sensors are disabled and the entry and exit delay is disabled.
Away Arm	Select this check box to enable away Arm option. Away Arm option is used to arm the zones, except the motion detectors, without any entry delay. If this option is enabled, all motion sensors are disabled and the entry and exit delay is disabled.
Instant Stay Arm	Select this check box to enable instant stay Arm option. Instant Stay Arm option is used to instantly arm the zones, except the interiors.
Disarm	Select this check box to enable disarm option. Disarm option is used to disarm the Partition.

Note

You cannot arm the **Partition** when the **Zones** of the **Partition** are in trouble. For instance, if you arm a partition and do not receive any notification of the arms status, then there may be a zone associated with that partition that is in trouble.


Ensure the following, before performing the manual actions:



- The ITV2 is Online.
- The ITV2 has Synchronized successfully.
- The **Partition** is in the Ready status to be armed.

Procedure 6-14 Arming and Disarming Partitions:

1 Right-click the partition and select Arm/Disarm.



The Partition Operation Form window opens, select an Operation Mode, enter the Access Code and then click OK:



Access Code is mandatory for **User Arm**, **Away Arm with No Entry Delay**, and **Stay Arm With No Entry Delay**.

- For **Arm**, the status is changed to **Armed** and if there is any alarm in the partition, the beep is silenced in the partition.
- For **Disarm** the status is changed to **Disarmed**.

Note

- For reporting purposes, arming without a user Access Code will be displayed as Special User.
- The Partition should not be in alarm or armed state.
- Stay Arm, Quick Arm, Night Arm, Instant Stay Arm, and Away Arm do not a
 require access code to operate. It will always appear as Armed by Special
 User in the Monitoring Station even if you enter the access code.
- Access Code is mandatory for User Arm, Away Arm with No Entry Delay, and Stay Arm with No Entry Delay.

- End -

Performing System Tests in the ITV2 Partition

System tests are performed to ensure that the system is functioning as intended.


The **System Test** option tests the following:

- System Bell Output
- · Keypad lights
- · Panel standby battery

Ensure the ITV2 is online before performing the manual actions.

Procedure 6-15 Performing System Test

1 Right-click the Partition object and then click **System Test.**



2 Enter the Access Code and click OK.

During the System Test all keypad sounders and sirens are activated for two seconds. All keypad lights are turned ON, and the **Ready**, **Armed**, and **Trouble** LEDs flash.

- End -




Bypassing and Resetting Zones

You can bypass and reset **Zones** directly from the victor **Device List**.

Procedure 6-16 Bypassing the Zone

Step Action

1 Right-click the zone object and select **Bypass**.




2 The selected **Zone** is bypassed and the status changes to **Bypassed**.

- End -

Procedure 6-17 Resetting the Zone

Step Action

1 Right-click the zone object and select **Reset**.



64

2 The selected zone is reset and the status changes to **Not Bypassed**.

Note

Bypassing or Resetting of zones does not work if a Partition is in Arm or Alarm state on the Panel.

- End -


Activating and Deactivating Command Outputs

Command outputs are activated and deactivated directly from the victor **Device List**.

Procedure 6-18 Activating the Command Output

Step Action

1 Right-click the command output object and select Activate Command Output.



2 Enter the Access Code and click **OK**. The selected command output is active and the status changes to **Active**.


- End -

Procedure 6-19 Deactivating the Command Output

Step Action

1 Right-click the command output object and select **Deactivate Command Output**.





2 Enter the Access Code and click **OK**. The selected command output is deactivated and the status changes to **Inactive**.

- End -

Downloading Panel Firmware


Ensure the following before you download the firmware:

- The Panel is online and synchronized.
- · Panel is not armed.
- · No AC trouble is present.
- · No low battery trouble is present.
- No FTC trouble is present.
- · Every alarm in memory has been viewed.
- No events are being communicated.

Procedure 6-20 Downloading Panel Firmware

Step Action

1 Right-click the Panel and select Firmware Download.



2 Enter the **User Name** and **Password**. On successful login, victor interacts with the TFTP API.TFTP API checks for the latest firmware version in the TFTP server. If the latest firmware is available, a firmware download begins from the TFTP server to the DSC NEO Panel. It will take approximately one hour to complete the Firmware download.

Note

Contact DSC support team for valid login credentials.

- 3 After the Firmware is downloaded, a **Firmware Update Available** message is displayed in the Panel LCD screen.
- **4** Accept the firmware update by performing the following commands in the Panel:
 - i. Press [*] [6].
 - ii. Enter the Access Code.
 - iii. Scroll and select the Authorize Update option.



Note

- 1 Do not stop the driver while firmware download is in progress.
- 2 If the firmware download fails or you do not see any status, try to access the TFTP server. If you are not able to access the server, contact the DSC support team.
- 3 If the **User Name** and **Password** are not correct, contact the DSC support team.
- 4 Ensure the configuration file points to the Production TFTP server.
- 5 After upgrading to the latest version of the firmware, you must synchronize from the Panel.
- 6 After a successful firmware download, it takes about 30 minutes to update the status.
- 7 If the firmware download fails, it takes around 60 to 90 minutes to update the status.
- 8 Verify section [851] sub-section [664] post-upgrade. The value should be 3.

Troubleshooting

Problem: Panel does not come online and cannot establish connection.

Solution:

- 1 Check the physical connection between the panel and the server:
 - In the command prompt, type ping <IP address> and verify the connection. In this instance, <IP address> is the IP address of the Panel configured in the section [851]-[001] and/or [851]-[992].

For example: ping 191.20.4.5

- Use netstat to check if the connection is established with the alarm port.
- Ensure no other application, such as DLS, is connected to the Panel.
- 2 Verify if the **CrossFire Service**, server and ITV2 driver are up and running.
- Verify if Panel Account Number, Alarm Port, Access Code, Installer Code, Encryption Key, and Host IP address is provided correctly.
- 4 Verify the configuration in the DSC NEO Panel hardware.

Problem: Synchronization has stopped or failed.

Solution:

- 1 Verify if the ITV2 driver and the server is up and running.
- Verify if the alternate communication is enabled in the ITV2 Panel.
- Werify using the section number 382 and option 5 and Section 401 and option 7.
- **4** Verify if any faulty hardware is connected to the Panel.

Problem: Unable to bypass a zone.

Solution:

Check if the Bypass attribute is enabled in the ITV2 Zone - Attribute Tab.

Problem: Exported .csv file does not have required data.

When you export the data using the **Selection Export** option, the .csv file does not have any required data.

Solution:

It is recommended to use .xml format to export the data.

Problem: User cannot be viewed from CCURE client.

User exists in Panel but cannot be viewed from C•CURE client after synchronizing from Panel:

Solution:

Ensure the length of the Personnel PIN in C•CURE and user access code in the Panel is equal.

Problem: Personnel PIN and User access code are different.

Personnel PIN in C•CURE and user access code in panel are different for the same user.

Solution:



The PIN access code mismatch occurs if you change the PIN length or the user access code length of a Panel or C•CURE that is in use. C•CURE adds 2-4 zeros on the left side of the 4 digit PIN and Panel adds 2-4 digits on the right side of the access code. This creates a mismatch.

To prevent the mismatch, either synchronize to the Panel or synchronize from the Panel based on the correct PIN requirement.

Appendix A: Alert Types

The **Event Configuration** editor is used to configure **Alerts** for ITV2 objects. The following tables detail the supported **Alert Types** supported for ITV2 Objects within victor:

Table 7-1 Alert Types for ITV2 Panels

Panel Alert Type	Value
Online Status	Online
	Offline
	Disabled
	Unknown
Synchronization Status	Synchronizing
	Synchronized
	Synchronization Failed
Firmware Download Status	Not Started
	Initiate
	Downloading
	File Lost
	Timeout
	• Success
	Failure
	Aborted
	Send SMS Fail
	Legacy Success
	Retire



System Trouble	Fire Trouble
	• AC Loss
	Configuration Trouble
	Module Battery Charger Trouble
	Module Battery Missing Trouble
	Module Low Battery Trouble
	Module Supervisory Trouble
	Module Bus Low Voltage
	Module Aux Trouble
	Ground Fault
	Module Tamper
	Output Fault
	Device Delinquency
	Density Low Sensitivity
	Device Internal Fault
	Service Request Trouble
	Time Date Trouble
	System Trouble
	Device Tamper
	Normal
	Carbon Monoxide Trouble
	Device Fault
Communication Trouble	Communication Trouble
	Fail to Communicate
	Ethernet Trouble
	GSM Trouble
	Printer Offline
	Telephone Line Monitoring Trouble
	GSIP Receiving Trouble
	SIM Lock Trouble
	All Receiver Not Available Status
	All Receiver Supervision Trouble
Sensor Trouble	RF Jam Trouble
	RF transmitter Low Battery
Relay Trouble	Bell Trouble
	Normal

Table 7-2 Alert Types for ITV2 Partitions

Partition Alert Type	Value
Armed State	Away Armed with No Entry Delay
	Away Armed
	Disarmed
	Night Armed
	Night Armed with No Entry Delay
	Quick Armed
	Stay Armed'
	Stay Armed with No Entry Delay
	User Armed
	• Unknown
Ready State	Ready
	Not Ready
	• Unknown
Alarm in Memory State	Alarms in Memory
	No Alarms in Memory
	• Unknown
Alarm State	• Alarm
	Normal
	• Unknown
Trouble State	Troubles Present
	No Trouble Present
	• Unknown
Zone Bypassed State	Zone Bypassed
	No Zone Bypassed
	Unknown

Table 7-3 Alert Types for ITV2 Zones

Partition Alert Type	Value
Bypass State	Bypassed
	Not Bypassed
	• Unknown
Fault State	• Fault
	No Fault
	• Unknown
Open Close State	• Open
	• Close
	• Unknown



Tamper State	Tamper
	Not in Tamper
	• Unknown
Alarm State	• Alarm
	Alarm Restore
	• Unknown

Appendix B: Health Status

Supported Health status annunciations for each ITV2 object type are as follows:

Table 7-4 Health status for ITV2 Panels

Panel Status	Health Status
Online	Normal
Disabled	
Synchronizing	
Synchronized	
Start Synchronization	
Offline	Device Alert
Synchronization Failed	
Unknown	Unknown

Table 7-5 Health status for ITV2 Partitions

Partition Status	Health Status
Arm/Disarm	Normal
No Alarm in Memory	
No Alarm	
Ready	
No Trouble	
No Zone Bypassed	
Alarm in Memory	Device Alert
• Alarm	
Not Ready	
Trouble	
Zone Bypassed	
Unknown	Unknown



Table 7-6 Health status for ITV2 Zones

Zone Status	Value
No Fault	Normal
• Reset	
No Tamper	
Alarm Restore	
• Close	
• Bypass	Device Alert
• Fault	
Tamper	
• Alarm	
• Open	

Table 7-7 Health status for ITV2 Outputs

Output Status	Value
Active	Normal
Inactive	