

10-8. FUNCTIONS OF DIP SWITCH AND JUMPER WIRE

Each function is controlled by the dip switch and the jumper wire on control P.C. board.

SW1 and SW2 are equipped only for service parts.

Model setting and capacity setting are memorized in the nonvolatile memory of the control P.C. board of the unit.

(Marks in the table below) Jumper wire (○ : Short × : Open)

Jumper wire	Functions	Setting by the dip switch and jumper wire	Remarks																																																																																						
SW1	Model settings	<table><tr><th>MODELS</th><th>Service board</th></tr><tr><td>PLA-A-AA PLA-A-AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr></table>	MODELS	Service board	PLA-A-AA PLA-A-AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																							
MODELS	Service board																																																																																								
PLA-A-AA PLA-A-AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
SW2	Capacity settings	<table><tr><th>MODELS</th><th>Service board</th></tr><tr><td>PLA-A12AA PLA-A12AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr><tr><td>PLA-A18AA PLA-A18AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr><tr><td>PLA-A24AA PLA-A24AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr><tr><td>PLA-A30AA PLA-A30AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr><tr><td>PLA-A36AA PLA-A36AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr><tr><td>PLA-A42AA PLA-A42AA₁</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table></td></tr></table>	MODELS	Service board	PLA-A12AA PLA-A12AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	PLA-A18AA PLA-A18AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	PLA-A24AA PLA-A24AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	PLA-A30AA PLA-A30AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	PLA-A36AA PLA-A36AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	PLA-A42AA PLA-A42AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF	
MODELS	Service board																																																																																								
PLA-A12AA PLA-A12AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
PLA-A18AA PLA-A18AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
PLA-A24AA PLA-A24AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
PLA-A30AA PLA-A30AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
PLA-A36AA PLA-A36AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
PLA-A42AA PLA-A42AA ₁	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>ON</td></tr><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td>OFF</td></tr></table>	1	2	3	4	5	ON						OFF																																																																												
1	2	3	4	5	ON																																																																																				
					OFF																																																																																				
J41 J42	Pair number setting with wireless remote controller	<table><tr><th rowspan="2">Wireless remote controller setting</th><th colspan="2">Control PCB setting</th></tr><tr><th>J41</th><th>J42</th></tr><tr><td>0</td><td>○</td><td>○</td></tr><tr><td>1</td><td>×</td><td>○</td></tr><tr><td>2</td><td>○</td><td>×</td></tr><tr><td>3 ~ 9</td><td>×</td><td>×</td></tr></table>	Wireless remote controller setting	Control PCB setting		J41	J42	0	○	○	1	×	○	2	○	×	3 ~ 9	×	×	<Initial setting> Wireless remote controller: 0 Control PCB: ○ (for both J41 and J42) 4 pair number settings are supported. The pair number settings of the wireless remote controller and indoor control PCB (J41/J42) are given in the table on the left. ('×' in the table indicates the jumper wire is disconnected.)																																																																					
Wireless remote controller setting	Control PCB setting																																																																																								
	J41	J42																																																																																							
0	○	○																																																																																							
1	×	○																																																																																							
2	○	×																																																																																							
3 ~ 9	×	×																																																																																							
JP1	Unit type setting	<table><tr><th>Model</th><th>JP1</th></tr><tr><td>Without TH5</td><td>○</td></tr><tr><td>With TH5</td><td>×</td></tr></table>	Model	JP1	Without TH5	○	With TH5	×	There is no jumper (JP1) because these models have the cond./eva. temperature thermistor (TH5).																																																																																
Model	JP1																																																																																								
Without TH5	○																																																																																								
With TH5	×																																																																																								
JP3	Indoor controller board type setting	<table><tr><th>Indoor controller board type</th><th>JP3</th></tr><tr><td>For product</td><td>×</td></tr><tr><td>Service parts</td><td>○</td></tr></table>	Indoor controller board type	JP3	For product	×	Service parts	○																																																																																	
Indoor controller board type	JP3																																																																																								
For product	×																																																																																								
Service parts	○																																																																																								