

# Midea Service Manual

## All Easy Pro



For 6,000 - 36,000 BTU Systems



### Units Covered In This Manual

BTUH	VOLTAGE/ PHASE	HIGH WALL SPLIT
6,000	208/230-1	MSESU-H06B-2A
9,000	208/230-1	MSESU-H09B-2A
12,000	208/230-1	MSESU-H12B-2A
18,000	208/230-1	MSESU-H18B-2A
9,000	115-1	MSEES-H09B-1A
12,000	115-1	MSEES-H12B-1A
6,000	208/230-1	MSEHU-H06B-2A
9,000	208/230-1	MSEHU-H09B-2A
12,000	208/230-1	MSEHU-H12B-2A
18,000	208/230-1	MSEHU-H18B-2A
24,000	208/230-1	MSEHU-H24B-2A
30,000	208/230-1	MSEHU-H30B-2A
33,000	208/230-1	MSEHU-H33B-2A
36,000	208/230-1	MSEHU-H36B-2A



A2L

# Table of Contents

<b>Safety Precautions</b> .....	<b>3</b>	Outdoor Unit Point Check Function .....	42
<b>Specifications</b> .....	<b>8</b>	Complain Record Form.....	44
Model Reference .....	8	Engineering Mode Entry and Setting Methods .....	46
Pipe Length And The Drop Height .....	9	Information Inquiry .....	46
Refrigerant Cycle Diagrams .....	10	Error Code Of Engineer Mode .....	47
Electrical Wiring Diagrams .....	13	Advanced Function Parameter Definitions .....	49
<b>Product Features</b> .....	<b>27</b>	Error Diagnosis and Troubleshooting Without Error Code .....	50
Display Function.....	27	Remote maintenance .....	50
Safety Features.....	27	Remote Troubleshooting .....	51
Basic Functions .....	28	Field Troubleshooting .....	53
<b>Maintenance</b> .....	<b>33</b>	Quick Maintenance by Error Code.....	55
First Time Installation Check.....	33	Troubleshooting by Error Code.....	57
Refrigerant Recharge.....	34	<b>Appendix</b> .....	<b>93</b>
Re-Installation .....	35	Temperature Sensor Resistance Value Table for TP (°C --K).....	93
<b>Troubleshooting</b> .....	<b>39</b>	Other Temperature Sensors Resistance Value Table (°C – K) ...	94
Safety Caution.....	39	Pressure On Service Port.....	95
Indoor Unit Diagnostic Guide.....	40	Cooling Chart (R454B): .....	95
Indoor Unit Diagnostic Codes .....	40	Heating chart (R454B):.....	96
Error Display (Outdoor Unit with auxiliary board) .....	41	System Pressure Table-R454B .....	97

# Safety Precautions

To prevent personal injury, property, or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections for guidance. Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or property, or, in extreme cases, death.

## **WARNING**

**WARNING** indicates a potentially hazardous situation that if not avoided could result in serious personal injury or death.

## **CAUTION**

**CAUTION** indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

### **NOTE**

A property-damage-only hazard, meaning no personal injury is possible.

### **IMPORTANT**

Is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

### **IMPORTANT**

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Consult local building codes and the current editions of the National Electrical Code (NEC) NFPA 70.

### **IMPORTANT**

In Canada, refer to the current editions of the Canadian Electrical Code CSA C22.1. Follow the safety information.

## **WARNING**

### **IN CASE OF ACCIDENTS OR EMERGENCIES**

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke are detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries comes into contact with skin or clothing, immediately rinse or wash the affected area thoroughly with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.

## **CAUTION**

- Clean and ventilate the unit at regular intervals when operating it near a stove or similar devices.

- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

## **WARNING**

### **PRE-INSTALLATION AND INSTALLATION**

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized service center.

## **CAUTION**

- While unpacking, be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

## **WARNING**

### **OPERATION AND MAINTENANCE**

- Do not use defective or undersized circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter, as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- Avoid direct skin contact with water drained from the unit.
- Use a firm stool or step ladder according to the manufacturer's procedures when cleaning or maintaining the unit.

## **CAUTION**

- Do not install or operate the unit for an extended time in areas of high humidity or in an environment directly exposed to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand or in an insecure location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge

created by the outdoor unit will negatively impact the environment or nearby residences.

- Do not expose skin directly to the air discharged by the unit for prolonged periods.
- Ensure the unit does not operate in areas with water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people be used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

## **WARNING**

### **USING FLAMMABLE REFRIGERANT**

#### 1. Installation (Space)

- That the installation of pipe work shall be kept to a minimum.
- That pipe work shall be protected from physical damage.
- Where refrigerant pipes shall comply with national gas regulations.
- That mechanical connections shall be accessible for maintenance purposes.
- In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
- When disposing of the used product, it must be based on national regulations, and properly processed.

#### 2. Servicing

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a currently valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely following an industry-recognized assessment specification.

#### 3. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of a person competent in the use of flammable refrigerants.

#### 4. Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

#### 5. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance, or an operating electric heater).

#### 6. Be careful that foreign matter(oil, water,etc) does not enter the piping. Also, when storing the piping, securely seal the opening by pinching, taping, etc.

#### 7. Do not pierce or burn.

#### 8. Be aware that refrigerants may not contain an odor.

#### 9. All working procedures that affect safety means shall only be carried out by competent technicians.

#### 10. Appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

#### 11. The appliance shall be stored to prevent mechanical damage from occurring.

#### 12. Joints shall be tested with detection equipment with a capability of 5 g/year of refrigerant or better, with the

equipment in standstill and under operation or pressure of at least these standstill or operation conditions after installation. Detachable joints shall NOT be used in the indoor side of the unit (brazed, welded joints could be used).

#### 13. When a FLAMMABLE REFRIGERANT is used, the requirements for installation space of the appliance and /or ventilation requirements are determined according to

- the mass charge amount (M) used in the appliance,
- the installation location,
- the type of ventilation of the location of the appliance.
- piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and comply with national and local codes and standards, such as ASHRAE 15, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection before being covered or enclosed.
- that protection devices, piping, and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris;
- that piping in refrigeration systems shall be so designed and installed to minimize the likelihood of hydraulic shock damaging the system;
- that steel pipes and components shall be protected against corrosion with a rustproof coating before applying any insulation;
- that precautions shall be taken to avoid excessive vibration or pulsation;
- the minimum floor area of the room shall be mentioned in the form of a table or a single figure without reference to a formula;
- after completion of field piping for split systems, the field pipe work shall be pressure tested with an inert gas and then vacuum tested before refrigerant charging, according to the following requirements:
- The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system, cannot be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.
- The test pressure after removal of the pressure source shall be maintained for at least 1h with no decrease of pressure indicated by the test gauge, with test gauge resolution not exceeding 5% of the test pressure.
- During the evacuation test, after achieving a vacuum level specified in the manual or less, the refrigeration system shall be isolated from the vacuum pump, and the pressure shall not rise above 1500 microns within 10 min. The vacuum pressure level shall be specified in the manual. It shall be the lesser of 500 microns or the value required for compliance with national and local codes and standards, which may vary between residential, commercial, and industrial buildings.
- Field-made refrigerant joints indoors shall be tightness tested according to the following requirements: The

test method shall have a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure. No leak shall be detected.

- correct the minimum room area of the space Amin by multiplying by the altitude adjustment factor (AF) factor in the table below based on for building site ground level altitude (Halt) in meters.

<b>Halt</b>	0	200	400	600	800	1,000	1,200	1,400	1,600
<b>AF</b>	1.00	1.00	1.00	1.00	1.02	1.05	1.07	1.10	1.12
<b>Halt</b>	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	
<b>AF</b>	1.15	1.18	1.21	1.25	1.28	1.32	1.36	1.40	

- Warning: keep any required ventilation openings clear of obstruction;
- Any servicing shall be performed only as recommended by the manufacturer

#### 14. Qualification of workers

Any maintenance, service, and repair operations must require the qualification of the working personnel. Every working procedure that affects safety means shall only be carried out by competent people that joined the training and achieved competence shall be documented by a certificate. The training of these procedures is carried out by national training organizations or manufacturers that are accredited to teach the relevant national competency standards that may be set in legislation. All training shall follow the ANNEX HH requirements of UL 60335-2- 40 4th Edition.

Examples for such working procedures are:

- breaking into the refrigerating circuit;
- opening of sealed components;
- opening of ventilated enclosures.

### Information servicing (For flammable materials)

#### 1. Checks of the area

- Before beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with before conducting work on the system.

#### 2. Work procedure

- Work shall be undertaken under a controlled procedure to minimise the risk of a flammable gas or vapour being present while the work is being performed.

#### 3 . General work area

- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

#### 4. Checking for the presence of refrigerant

- The area should be checked with an appropriate refrigerant detector before and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e., no sparking, adequately sealed, or intrinsically safe.

#### 5. Presence of a fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have

a dry powder or CO2 fire extinguisher adjacent to the charging area.

#### 6. No ignition sources

- No person carrying out work on a refrigeration system that involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing, and disposal, during which flammable refrigerant can be released to the surrounding space.
- Before work takes place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- NO SMOKING signs shall be displayed.

#### 7. Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

#### 8. Checks on the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- the actual refrigerant charge is per the room size within which the refrigerant-containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuits shall be checked for the presence of refrigerant.
- marking on the equipment continues to be visible and legible; marking and illegible signs shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance that may corrode refrigerant-containing components, unless the components are constructed of materials that are inherently resistant to being corroded or are suitably protected against being so corroded.

#### 9. Checks on electrical devices

Repair and maintenance of electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately, but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. **Initial safety checks shall include:**

- that capacitors are discharged: this shall be done safely to avoid the possibility of sparking;
- that there are no live electrical components and wiring

exposed while charging, recovering, or purging the system;

- that there is continuity of earth bonding.

#### **10. Sealed electrical components shall be replaced**

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon before any removal of sealed covers, etc.

If it is necessary to have an electrical supply to the equipment during service, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, an excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
  - Ensure that the apparatus is mounted securely.
  - Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall follow the manufacturer's specifications.

#### **11. Intrinsically safe components must be replaced**

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating. Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

#### **NOTE**

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated before working on them.

#### **12. Cabling**

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

#### **13. Detection of flammable refrigerants**

Under no circumstances shall potential sources of ignition be used in the search for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for refrigerant systems. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of

the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

#### **NOTE**

Examples of leak-detection fluids are

- bubble method,
- fluorescent method agents.
  - If a leak is suspected, all naked flames shall be removed/extinguished.
  - If leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (using shut-off valves) in a part of the system remote from the leak. See the following instructions for the removal of refrigerant.

#### **14. Removal and evacuation**

When breaking into the refrigerant circuit to make repairs - or for any other purpose conventional procedures shall be used. However, for flammable refrigerants best practice must be followed since flammability is a consideration.

The following procedure shall be adhered to:

- safely remove refrigerant following local and national regulations;
- evacuate;
- purge the circuit with inert gas (optional for A2L);
- evacuate (optional for A2L);
- continuously flush or purge with inert gas when using a flame to open the circuit; and open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to the atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

#### **15. Charging procedures**

In addition to conventional charging procedures, the following requirements shall be followed:

- Works shall be undertaken with appropriate tools only (In case of uncertainty, please consult the manufacturer of the tools for use with flammable refrigerants) Ensure that contamination of different refrigerants does not

occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.

- Ensure that the refrigeration system is earthed before charging the system with refrigerant.
- Label the system when charging is complete (if not already). Extreme care shall be taken not to overfill the refrigeration system.
- Before recharging the system, it shall be pressure tested with oxygen-free nitrogen (OFN). The system shall be leak tested on completion of charging but before commissioning. A follow-up leak test shall be carried out before leaving the site.

#### **16. Decommissioning**

Before carrying out this procedure, the technician must be completely familiar with the equipment and all its details. It is recommended good practice that all refrigerants are recovered safely. Before the task is carried out, an oil and refrigerant sample shall be taken in case analysis is required before the re-use of recovered refrigerant. Electrical power must be available before the task commences.

- a. Become familiar with the equipment and its operation.
- b. Isolate system electrically
- c. Before attempting the procedure ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being used correctly;
  - the recovery process is supervised at all times by a competent person;
  - recovery equipment and cylinders conform to the appropriate standards.
- d. Pump down the refrigerant system, if possible.
- e. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f. Make sure that the cylinder is situated on the scales before recovery takes place.
- g. Start the recovery machine and operate following instructions.
- h. Do not overfill cylinders (no more than 80 % volume liquid charge)
- i. Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from the site promptly and all isolation valves on the equipment are closed off.
- k. Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

#### **17. Labelling**

Equipment shall be labeled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

#### **18. Recovery**

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valves and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units especially not in cylinders. If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

#### **19. Transportation, marking, and storage for units that employ flammable refrigerants**

- a. **General** - The following information is provided for units that employ FLAMMABLE REFRIGERANTS.
- b. **Transport of equipment containing flammable refrigerants** - Attention is drawn to the fact that additional transportation regulations may exist concerning equipment containing flammable gas. The maximum number of pieces of equipment or the configuration of the equipment permitted to be transported together will be determined by the applicable transport regulations.
  - Cylinders shall be kept upright.
- c. **Marking of equipment using signs** - Signs for similar appliances used in a work area are generally addressed by local regulations and give the minimum requirements for the provision of safety and/or health signs for a work location. All required signs are to be maintained, and employers should ensure that employees receive suitable and sufficient instruction and training on the meaning of appropriate safety signs and the actions that need to be taken in connection with these signs. The effectiveness of signs should not be diminished

by too many signs being placed together.  
Any pictograms used should be as simple as possible and contain only essential details.

- d. **Disposal of equipment using flammable refrigerants** See national regulations.
- e. **Storage of equipment/appliances** - The storage of the appliance should be following the applicable regulations or instructions, whichever is more stringent.

- f. **Storage of packed (unsold) equipment** - Storage package protection should be constructed in such a way that mechanical damage to the equipment inside the package will not cause a leak of the REFRIGERANT CHARGE.  
The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.

# Specifications

## Model Reference

Indoor Unit Model	Outdoor Unit Model	Capacity (Btu/h)	Power Supply
MSEES-H09B-1A	MO1ES-H09B-1A	9K Mid Tier	115V~, 60Hz, 1Phase
MSEES-H12B-1A	MO1ES-H12B-1A	12K Mid Tier	
MSESU-H06B-2A	MO1SS-H06B-2A	6K High End Tier	208/230V~, 60Hz, 1Phase
MSESU-H09B-2A	MO1SS-H09B-2A	9K High End Tier	
MSESU-H12B-2A	MO1SS-H12B-2A	12K High End Tier	
MSESU-H18B-2A	MO1SS-H18B-2A	18K High End Tier	
MSEHU-H06B-2A	MO1HS-H06B-2A	6K High Tier	
MSEHU-H09B-2A	MO1HS-H09B-2A	9K High Tier	
MSEHU-H12B-2A	MO1HS-H12B-2A	12K High Tier	
MSEHU-H18B-2A	MO1HS-H18B-2A	18K High Tier	
MSEHU-H24B-2A	MO1HS-H24B-2A	24K High Tier	
MSEHU-H33B-2A	MO1HS-H33B-2A	33K High Tier	
MSEHU-H09B-2A	MO1ES-H09B-2A	9K Mid Tier	
MSEHU-H12B-2A	MO1ES-H12B-2A	12K Mid Tier	
MSEHU-H18B-2A	MO1ES-H18B-2A	18K Mid Tier	
MSEHU-H24B-2A	MO1ES-H24B-2A	24K Mid Tier	


# Pipe Length And The Drop Height

The length and elevation of the connection pipe are shown in the table below. If the pipe length exceeds the maximum pipe length, additional refrigerant should be charged to ensure nominal cooling/heating capacity.

Capacity(Btu/h)	Standard Length	Max Pipe Length	Max Elevation	Additional Refrigerant
≤15k	24.6 ft. (7.5 m)	82.0 ft. (25 m)	49.2 ft. (15 m)	0.16 oz./ft. (15 g/m)
18k		98.4 ft. (30 m)	65.6 ft. (20 m)	
18k High Tier Series/ 24k/30k/33k		164 ft. (50 m)	82 ft. (25 m)	0.32 oz./ft. (30 g/m)
36k		213 ft. (65 m)	98.4 ft. (30 m)	


If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas pipe can prevent this.

- An oil trap should be installed every 20 ft. (6 m) of vertical suction line riser (<36000 Btu/h unit).
- An oil trap should be installed every 32.8 ft. (10 m) of vertical suction line riser (≥36000 Btu/h unit).




# Refrigerant Cycle Diagrams


MO1ES-H09B-1A, MO1ES-H12B-1A, MO1HS-H06B-2A, MO1HS-H09B-2A, MO1ES-H09B-2A, MO1ES-H12B-2A, MO1HS-H12B-2A




MO1SS-H06B-2A, MO1SS-H09B-2A, MO1SS-H12B-2A




MO1HS-H18B-2A, MO1ES-H18B-2A




MO1SS-H18B-2A, MO1HS-H24B-2A, MO1BS-H30B-2A




MO1ES-H24B-2A



MO1HS-H33B-2A






## Electrical Wiring Diagrams

### Indoor Unit Wiring Diagram


Indoor Unit	
IDU Model	IDU Wiring Diagram
MSEES-H09B-1A	16022000040252 page 14
MSEES-H12B-1A	
MSEHU-H06B-2A	
MSEHU-H09B-2A	
MSEHU-H12B-2A	
MSESU-H06B-2A	
MSESU-H09B-2A	
MSESU-H12B-2A	
MSESU-H18B-2A	
MSEHU-H18B-2A	
MSEHU-H24B-2A	
MSEEU-H30B-2A	
MSEHU-H33B-2A	
MSEEU-H36B-2A	



## Outdoor Unit Wiring Diagram And Printed Circuit Board Diagrams

ODU Model	ODU Wiring Diagram	ODU Printed Circuit Board
MO1ES-H09B-1A	16022000040956 page 17	17122000062141 page 23
MO1ES-H12B-1A		
MO1HS-H06B-2A	16022000040311 page 16	17122000057661 page 22
MO1ES-H09B-2A		
MO1ES-H12B-2A		
MO1HS-H09B-2A		
MO1HS-H12B-2A		
MO1SS-H06B-2A	16022000041381 page 19	17122000057814 page 24
MO1SS-H09B-2A		
MO1SS-H12B-2A		
MO1ES-H18B-2A	16022000040313 page 18	17122000048066 page 25
MO1HS-H18B-2A		17122000048064 page 25
MO1ES-H24B-2A		
MO1SS-H18B-2A	16022000040331 page 20	17122300007152 page 26
MO1HS-H24B-2A		
MO1BS-H30B-2A		
MO1HS-H33B-2A		
MO1BS-H36B-2A	16022000040650 page 21	


# WIRING DIAGRAM



CN1A INPUT	230V AC	
CN17 OUTPUT	230V AC	
CN60 OUTPUT	230V AC	
CN15 OUTPUT	230V AC	
CN31 OUTPUT	0~12V DC	T3 OUTDOOR COIL TEMP SENSOR
CN21/CN6 OUTPUT	0~5V DC	T4 OUTDOOR AMBIENT TEMP SENSOR
CN50/CN7 OUTPUT	0~310V AC	TP COMP DISCHARGE TEMP SENSOR


16022000040311

# WIRING DIAGRAM



16022000040956


# WIRING DIAGRAM




CN2/7/8	INPUT	230V	AC	
CN16	OUTPUT	230V	AC	
CN60	OUTPUT	230V	AC	
CN19	OUTPUT	230V	AC	
CN18	OUTPUT	0~12V	DC	T3 OUTDOOR COIL TEMP SENSOR
CN23/CN17	OUTPUT	0~5V	DC	T4 OUTDOOR AMBIENT TEMP SENSOR
CN414	OUTPUT	0~310V	AC	TP COMP DISCHARGE TEMP SENSOR
CN27/CN28/CN29	OUTPUT	0~310V	AC	


16022000040313

# WIRING DIAGRAM




16022000041381





16022000040650

Outdoor unit printed circuit board diagram: 17122000057661




Port	Description	Parameter	
CN50	Port for compressor	0-310V/AC	
CN6	Port for test board	5V/DC	
CN31	Power output for electronic expansion valve	12V/DC	
CN7	Power output for DC fan	0-310V/AC	
CN21	Power output for condenser (T3), ambient (T4) and discharge (Tp) temperature sensors	5V/DC	
CN17	Power output for compressor heater	240V/AC	
CN60	Power output for 4-way valve	240V/AC	
CN15	Power output for chassis heater	240V/AC	
CN1A	CN16	Port for communication cable S	
	CN2	Port for live wire	240V/AC
	CN1	Port for neutral wire	
	CN3	Port for earth wire	

**NOTE**

This section is for reference only. Please take practicality as standard.


Outdoor unit printed circuit board diagram: 17122000062141



Port	Description	Parameter
CN6	Port for test board	5V/DC
CN31	Power output for EEV	12V/DC
CN7	Port for DC fan	0-310V/AC
CN21	Power output for condenser (T3), ambient (T4) and discharge (Tp) temperature sensors	5V/DC
CN17	Power output for compressor heater	230V/AC
CN60	Power output for 4-way valve	230V/AC
CN15	Power output for chassis heater	230V/AC
CN1A	Port for power cable (E,N,L,S)	
CN4_2	Connection ports for reactor	115V/AC
CN4_3		
CN50	Port for Compressor	0-310V/AC

**NOTE**

This section is for reference only. Please take practicality as standard.




Port	Description	Parameter
U, V, W	Port for compressor	0-310V/AC
CN6	Port for test board	5V/DC
CN21	Power output for condenser (T3), ambient (T4) and discharge (Tp) temperature sensors	5V/DC
CN31	Power output for EEV	12V/DC
CN61	Power output for 4-way valve	12V/AC
CN60	Power output for crankcase heater	230V/AC
CN15	Power output for chassis heater	230V/AC
CN16	Power input of communication cable S	230V/AC
CN3	Power input of live wire	230V/AC
CN9	Power input of neutral wire	230V/AC
CN1	Port for earth wire	
CN4/CN5	Ports for reactor	0-310V/AC

**NOTE**

This section is for reference only. Please take practicality as standard.

Outdoor unit printed circuit board diagram: 17122000048064\_17122000048066




Port	Description	Parameter
CN23	Port for test board	5V/DC
CN414	Port for DC fan	0-310V/AC
CN18	Power output for electronic expansion valve	12V/DC
CN17	Power output for condenser (T3), ambient (T4) and discharge (Tp) temperature sensors	5V/DC
CN16	Power output for compressor heater	230V/AC
CN19	Power output for chassis heater	230V/AC
CN5	Power output for AC fan	230V/AC
CN60	Power output for 4-way valve	230V/AC
CN21	Port for compressor	0-310V/AC

**NOTE**

This section is for reference only. Please take practicality as standard.

Outdoor unit printed circuit board diagram: 17122300007152



MJV-180W/BP3<24Tmini+13T+1306+SLIMDIP+PSS30S71F6>.D1.WP2-1

Port	Description	Parameter
CN1, CN13, CN14, CN22, CN16, CN17, CN3, CN44, CN53	Power output for electronic expansion valve	12V/DC
CN29	Port for high-pressure and low-pressure switches	Input: 5V/ DC
CN26	Power output for condenser(T3), ambient (T4) and discharge(TP) temperature sensors	5V/DC
CN28	Power output for evaporator (T2B) temperature sensor of IDU A-F	5V/DC
CN30	Port for compressor top high temperature protector	Input: 5V/ DC
CN49/CN6	Port for Hi-pressure and low-pressure sensors	5V 17122300007152/ DC
CN9	Power output for EVI temperature sensors (T5-T8)	5V/DC
CN27	Communication port with key board	5V/DC
CN45	Port for DR module (Test port)	5V/DC

Port	Description	Parameter
CN43	Communication ports to indoor unit (S for A-F)	Input: 0~230V/ AC
CN11,12	Power input for this PCB	230V/AC
CN24	Power output for chassis heater	230V/AC
CN37	Power output for 4-way valve 1	230V/AC
CN25	Power output for 4-way valve 2	230V/AC
CN38	Power output for compressor heater	230V/AC
CN42	Power output for 4-way valve 3	230V/AC
U, V, W	Output for compressor	0-310V/AC
CN32/CN10	Output for DC fan	0-310V/AC

**NOTE**

This section is for reference only. Please take practicality as standard.

# Product Features

## Display Function

Unit display functions



(A)



(B)



(C)

Display	Function	
ECO	ECO function (available on select units only)	
	When Wireless Control feature is activated (some units)	
	Temperature value	Temperature
	on (3s)	Timer ON is set. Activation of , Fresh, Swing, Turbo, ECO, Breeze away, ECO intelligent or Silence
	OF (3s)	Timer OFF is set. Cancellation of Fresh, Swing, Turbo, ECO, Breeze away, ECO intelligent or Silent
	dF	Defrost
	CL	Active Clean (For Inverter split type) or self-cleaning (For Fixed-speed type)
	FP	Heating in room temperature under 8°C

### NOTE

Please select the display function according to your purchase product.

## Safety Features

### The compressor has a three-minute delay at restart

Compressor functions are delayed for up to ten seconds upon the first startup of the unit and are delayed for up to three minutes upon subsequent unit restarts.

### Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds a certain level for a period of time, the compressor ceases operation.

### Automatic shutoff based on fan speed

If the indoor fan speed registers below 200RPM or over 2100RPM for an extended period of time, the unit ceases operation and the corresponding error code is displayed on the indoor unit.

### Inverter module protection

The inverter module has an automatic shutoff mechanism based on the unit's current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit, and the unit ceases operation.

### Indoor fan delayed operation

- When the unit starts, the louver is automatically activated, and the indoor fan will operate after a period of setting time or when the louver is in place.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

### Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner continues operation and displays the corresponding error code, allowing for emergency use.
- When more than one temperature sensor is malfunctioning, the air conditioner ceases operation.

# Basic Functions

## Abbreviation

Unit element abbreviations

Abbreviation	Element
T1	Indoor room temperature
T2	Coil temperature of evaporator
T3	Coil temperature of condenser
T4	Outdoor ambient temperature
Tsc	Adjusted setting temperature
TP	Compressor discharge temperature
CDIFTEMP	Cooling shutdown temperature
HDIFTEMP2	Heating shutdown temperature
TCDI1	Enter defrost temperature
TCDE1	Exit defrost temperature1
TCDE2	Exit defrost temperature2 (maintain for a period of time )
TIMING_ DEFROST_ TIME	Enter defrost time

In this manual, such as CDIFTEMP, HDIFTEMP2, TCDE1, TCDE2, TIMING\_DEFROST\_TIME...etc., they are well-setting parameter of EEPROM.

## Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled, and no temperature setting is displayed.
- The indoor fan speed can be set to 1%~100% or auto.
- The louver operations are identical to those in cooling mode.
- Auto fan: In fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 75°F (24°C). (Tsc = 75°F (24°C))

## Cooling Mode

### Compressor Control

Reach the configured temperature:

1. When the compressor runs continuously for 120 minutes.
  - If the following conditions are satisfied, the compressor ceases operation.
  - Calculated frequency(fb) is less than minimum limit frequency (FminC).
  - Compressor runs at FminC more than 10 minutes
  - T1 is lower than or equal to (Tsc-CDIFTEMP- 1°F (0.5°C))

### NOTE

CDIFTEMP is EEPROM setting parameter. It is 4°F (2°C) usually.

2. When the compressor runs continuously for more than 120 minutes.
  - If the following conditions are satisfied, the compressor ceases operation.
  - Calculated frequency(fb) is less than minimum limit frequency (FminC).
  - Compressor runs at FminC more than 10 minutes.
  - T1 is lower than or equal to (Tsc-CDIFTEMP).

### NOTE

CDIFTEMP is EEPROM setting parameter. It is 4°F (2°C) usually.

3. If one of the following conditions is satisfied, do not judge the protective time.

- Compressor running frequency (fr) is more than test frequency (TestFre).
- Compressor running frequency is equal to test frequency, T4 is more than 15°C(59°F) or T4 fault.
- Change setting temperature.
- Turn on/off turbo or sleep function
- Various frequency limit shutdown occurs.

### Indoor Fan Control


1. In cooling mode, the indoor fan operates continuously. The fan speed can be set to 1%-100%, or auto.

2. Auto fan

For DC fan motor units:

- Descent curve
  - When T1-Tsc is lower than 6°F (3.5°C), fan speed reduces to 80%;
  - When T1-Tsc is lower than 2°F(1°C), fan speed reduces to 60%;
  - When T1-Tsc is lower than 1°F (0.5°C), fan speed reduces to 40%;
  - When T1-Tsc is lower than 0°F (0°C), fan speed reduces to 20%;
  - When T1-Tsc is lower than -1°F (-0.5°C), fan speed reduces to 1%.
- Rise curve
  - When T1-Tsc is higher than or equal to 0°F (0°C), fan speed increases to 20%;
  - When T1-Tsc is higher than or equal to 1°F (0.5°C), fan speed increases to 40%;
  - When T1-Tsc is higher than or equal to 2°F (1°C), fan speed increases to 60%;
  - When T1-Tsc is higher than or equal to 3°F (1.5°C), fan speed increases to 80%;
  - When T1-Tsc is higher than or equal to 7°F (4°C), fan speed increases to 100%.


For AC fan motor units:



### Outdoor Fan Control


- The outdoor unit will be run at different fan speed according to T4 and compressor running frequency.
- For different outdoor units, the fan speeds are different.

### Condenser Temperature Protection



When the condenser temperature exceeds a configured value, the compressor ceases operation.

### Evaporator Temperature Protection



- Off: Compressor stops.
- Decrease: Decrease the running frequency to a lower level per 1 minute.
- Hold: Keep the current frequency.
- Resume: No limitation for frequency.

### Heating Mode (Heat Pump Units)

#### Compressor Control

1. Reach the configured temperature
  - If the following conditions are satisfied, the compressor ceases operation.
    - Calculated frequency(fb) is less than minimum limit frequency (FminH).
    - Compressor runs at FminH more than 10 minutes.
    - T1 is higher than or equal to Tsc+ HDIFTEMP2.


### NOTE

CDIFTEMP is EEPROM setting parameter. It is 4°F (2°C) usually.

- If one of the following conditions is satisfied, do not judge protective time.
    - Compressor running frequency (fr) is more than test frequency (TestFre).
    - When compressor running frequency is equal to test frequency, T4 is more than 59°F (15°C) or T4 fault.
    - Change setting temperature.
    - Turn on/off turbo or sleep function.
2. When the current is higher than the predefined safe value, surge protection is activated, causing the compressor to cease operations.

### Indoor Fan Control:

1. In heating mode, the indoor fan operates continuously. The fan speed can be set to 1%-100% or mute. And the anti-cold wind function has priority.
  - Anti-cold air function
    - The indoor fan is controlled by the indoor temperature T1 and indoor unit coil temperature T2.



$T1 \geq 66^{\circ}\text{F}(19^{\circ}\text{C})$	$\Delta\text{TE1}=0$
$59^{\circ}\text{F}(15^{\circ}\text{C}) \leq T1 < 66^{\circ}\text{F}(19^{\circ}\text{C})$	$\Delta\text{TE1}=66^{\circ}\text{F}-T1(19^{\circ}\text{C}-T1)$
$T1 < 59^{\circ}\text{F}(15^{\circ}\text{C})$	$\Delta\text{TE1}=7^{\circ}\text{F}(4^{\circ}\text{C})$

#### 2. Auto fan

For DC fan motor units:


- Rise curve
  - When T1-Tsc is higher than -3°F (-1.5°C), fan speed reduces to 80%;
  - When T1-Tsc is higher than 0°F (0°C), fan speed reduces to 60%;
  - When T1-Tsc is higher than 1°F (0.5°C), fan speed reduces to 40%;
  - When T1-Tsc is higher than 2°F (1°C), fan speed reduces to 20%.
- Descent curve
  - When T1-Tsc is lower than or equal to 1°F (0.5°C), fan speed increases to 40%;
  - When T1-Tsc is lower than or equal to 0°F (0°C), fan speed increases to 60%;
  - When T1-Tsc is lower than or equal to -3°F (-1.5°C), fan speed increases to 80%.

speed increases to 80%;

- When T1-Tsc is lower than or equal to -5°F (-3°C), fan speed increases to 100%.

For AC fan motor units:

T1-Tsc



#### Outdoor Fan Control:

- The outdoor unit will be run at different fan speed according to T4 and compressor running frequency.
- For different outdoor units, the fan speeds are different.

#### Defrosting mode

- If any one of the following conditions is satisfied, AC will enter the defrosting mode.

After the compressor starts up and keeps running, take the lowest temp of T3 (from the period 7th minutes to 12nd minutes) as T30.

Condition 1: If the compressor cumulate running time is up to 29 minutes and  $T3 < TCDI1$  and  $T3 \leq T30 - T30SUBT30ONE$  and  $T4 < -22^\circ\text{C}(\text{DEFROST\_T4\_ADD})$

Condition 2: If the compressor cumulate running time is up to 35 minutes and  $T3 < TCDI2$  and  $T3 \leq T30 - T30SUBT30TWO$  and  $T4 < -22^\circ\text{C}(\text{DEFROST\_T4\_ADD})$

Condition 3: If the compressor cumulate running time is up to 29 minutes and  $T3 < -24 (TCDI3\_ADD)$  for 3 minutes and  $T4 > -22^\circ\text{C}(\text{DEFROST\_T4\_ADD})$

Condition 4: For the model active this condition If the compressor cumulate running time is up to 120 minutes and  $T3 < -15^\circ\text{C}$  and  $T4 < -22^\circ\text{C}$

Condition 5: This is just for the first time defrost after power on condition, on the scenario when first time defrost or power off and power back or turn on from standby need to check the ice accumulate situation (the defrost time reckon reset), when compressor cumulate running time is up to 30 minutes  $T4 - T3 > (0.5T4 + KDELTT\_ADD)$  and  $T3 < TCDIN5\_ADD$ ,  $T4 < -22^\circ\text{C}$ ,


Condition 6: For the model active this condition If the compressor cumulate running time is up to  $\text{TIMING\_DEFROST\_TIME}$  (Hour) and  $T4 \leq -22^\circ\text{C} (\text{DEFROST\_T4\_ADD})$ , the T4 without malfunction

Condition 7: When T3 or T4 lower that  $-3^\circ\text{C}$  (last for 30 seconds) cumulate running for  $(\text{EE\_TIME\_DEFROST7\_ADD})$  minutes with  $Ts - T1 \leq 5^\circ\text{C}$  (not need based on T30 keep running with minimum 10th minutes)

Condition 8: When T3 or T4 lower that  $-3^\circ\text{C}$  (last for 30 seconds) cumulate running for  $(\text{EE\_TIME\_DEFROST7\_ADD} + 30)$  minutes (not need based on T30 keep running with minimum 10th minutes)

- In defrosting mode, the compressor continues to run, the indoor and outdoor motor will cease operation, the defrost light of the indoor unit will turn on, and the "dF" symbol is displayed.
- Condition 1~5, If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
  - T3 rises above TCDE1.
  - T3 maintained above TCDE2 for 80 seconds.
  - Unit runs for 15 minutes consecutively in defrosting mode.
- Condition 6, if any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
  - Unit runs for 10 minutes consecutively in defrosting mode.
  - T3 rises above  $50^\circ\text{F} (10^\circ\text{C})$ .
- Condition 7~8, If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
  - T3 rises above  $\text{TCDE1} + 4^\circ\text{C} / 7^\circ\text{F}$ .
  - T3 maintained above  $\text{TCDE2} + 4^\circ\text{C} / 7^\circ\text{F}$  for 80 seconds.
  - Unit runs for 15 minutes consecutively in defrosting mode.


#### Evaporator Coil Temperature Protection



- Off: Compressor stops.
- Decrease: Decrease the running frequency to the lower level per 20 seconds.
- Hold: Keep the current frequency.
- Resume: No limitation for frequency.

#### Auto-mode

This mode can be selected with the remote controller, and the temperature setting can be adjusted between  $60^\circ\text{F} \sim 86^\circ\text{F}$  ( $16^\circ\text{C} \sim 30^\circ\text{C}$ ).



- If the setting temperature is modified, the machine selects a new running function.

### Drying Mode

- In drying mode, AC operates the same as the auto fan in cooling mode.
- All protections are activated and operate the same as they do in cooling mode.
- Low Room Temperature Protection

If the room temperature is lower than 50°F/10°C, the compressor ceases operations and does not resume until the room temperature exceeds 54°F/12°C.

### Forced operation function

- Forced cooling mode:

The compressor and outdoor fan continue to run, and the indoor fan runs at breeze speed. After running for 30 minutes, the AC will switch to auto mode with a preset temperature of 76°F (24°C).

- Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of 76°F (24°C).

- The unit exits forced operation when it receives the following signals:
  - Switch on
  - Switch off
  - Timer on
  - Timer off
  - Sleep mode
  - Follow me
  - Changes in:
    - mode
    - fan speed
    - setting temperature
  - Forced defrosting mode:
    - Press AUTO/COOL button continuously for 5s under forced cooling mode to enter this mode.
    - Indoor fan will stop, defrosting lamp will light on.
    - Quit this mode and turn off the unit when:
      - quit normal defrosting
      - turn off by RC

- Press AUTO/COOL button continuously for 5s again

### Timer Function

- The timing range is 24 hours.
- Timer on. The machine will turn on automatically when reaching the setting time.
- Timer off. The machine will turn off automatically when reaching the setting time.
- Timer on/off. The machine will turn on automatically when reaching the setting "on" time and then turn off automatically when reaching the setting "off" time.
- Timer off/on. The machine will turn off automatically when reaching the setting "off" time and then turn on automatically when reaching the setting "on" time.
- The timer function will not change the AC operation mode. Suppose AC is off now; it will not start up first after setting the "timer off" function. And when reaching the setting time, the timer LED will be off, and the AC running mode has not been changed.
- The setting time is relative.
- The AC will quit the timer function when it malfunctions.

### Sleep Function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
  - When cooling, the temperature rises 1.8°F/1°C (to not higher than 86°F/30°C) every hour. After 2 hours, the temperature stops rising, and the indoor fan is fixed at low speed.
  - When heating, the temperature decreases 1.8°F/1°C (to not lower than 60.8°F/16°C) every hour. After 2 hours, the temperature stops decreasing, and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- The operating time for sleep mode is 8 hours, after which, the unit exits this mode.
- The timer setting is available in this mode.

### Auto-Restart Function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings and, in the case of a sudden power failure, will restore those settings automatically within 3 minutes after power returns.
- When this function is turned on, the indoor unit display window appears "CL". After 20 to 130 minutes, the unit will turn off automatically and cancel the Active Clean function.

### Follow Me

- If you press "Follow Me" on the remote, the indoor unit will beep. This indicates the follow me function is active.
- Once active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the unit's temperature setting.
- If the unit does not receive a signal for 7 minutes or you press "Follow Me," the function turns off. The unit regulates temperature based on its own sensor and settings.

### 8°C Heating (Optional)

In heating mode, the temperature can be set to as low as 46.4°F/8°C, preventing the indoor area from freezing if unoccupied during severe cold weather.

### Silence (Optional)


Press "Silence" on the remote control to enable the SILENCE function. While this function is active, the indoor unit will run at a faint breeze (1% fan speed), which reduces noise to the lowest possible level.

### Eco Function (Multi-Zone Systems Do Not Have This Function)

- Used to enter the energy-efficient mode.
  - Under cooling mode, press the ECO button, the remote controller will adjust the temperature automatically to 75°F/24°C, fan speed of Auto to save energy (but only if the set temperature is less than 75°F/24°C). If the set temperature is more than 75°F/24°C and 86°F/30°C, press the ECO button, the fan speed will change to Auto, and the set temperature will remain unchanged.
- When AC receives signals, such as switch off, Turbo operation, Silence operation, Self clean operation, Forced cooling operation, mode setting, Sleeping mode, or adjusting the set temperature to less than 76°F/24°C, it will quit the ECO operation.
- Operation time in ECO mode is 8 hours. After 8 hours, the AC quits this mode.
- When there's any one temperature sensor in malfunction, the AC will quit ECO mode.
- Indoor fan will run at auto fan when entering the ECO mode. The setting temperature and setting fan speed can be changed through the remote controller signal.

### Electrical Energy Consumption Control Function (Multi-Zone Systems Do Not Have This Function)

Press the "Gear" button on the remote controller to enter the energy efficient mode in a sequence of following:



Turn off the unit or activate ECO, sleep, Super cool, 8°C Heating, Silence, or self-clean function will quit this function.

### Breeze Away function (Optional)

This feature avoids direct airflow blowing on the body and makes you feel indulged in silky coolness.

### NOTE

This feature is available under cooling mode, fan-only mode, and drying mode.

### Wireless Control (Optional)

- Wireless control allows you to control your air conditioner using your mobile phone and a Wireless connection.
- For the USB device access, replacement, and maintenance operations must be carried out by professional staff.


# Maintenance

## First Time Installation Check

Air and moisture trapped in the refrigerant system affect the performance of the air conditioner by:

- Increasing pressure in the system.
- Increasing the operating current.
- Decreasing the cooling or heating efficiency.
- Congesting the capillary tubing due to ice build-up in the refrigerant circuit.

### Air purging with vacuum pump



### Procedure:

1. Tighten the flare nuts of the indoor and outdoor units and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
  - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
    - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
    - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
  - b. If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
6. Wait for 5 minutes, then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check for gas leakage.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
  - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
  - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the caps of the 2- and 3-way valves.


- Corroding the refrigerant system.

To prevent air and moisture from affecting the air conditioner's performance, the indoor unit, as well as the pipes between the indoor and outdoor units, must be leak-tested and evacuated.

### Leak test (soap water method)

Use a soft brush to apply soapy water or a neutral liquid detergent onto the indoor unit connections and outdoor unit connections. If there is a gas leakage, bubbles will form on the connection.

# Refrigerant Recharge




## Procedure:

1. Close both 2- and 3-way valves.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
4. If the refrigerant is R410A/R32, invert the cylinder to ensure a complete liquid charge.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with the push pin Handle Lo to the service port of the 3-way valve.
6. Place the charging cylinder on an electronic scale and record the starting weight.
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to the chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately.
10. Mount the caps of the service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
12. Check for gas leakage.

# Re-Installation

## Indoor Unit


### Collecting the refrigerant into the outdoor unit



#### Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the charge hose with the push pin of Handle Lo to the 3-way valve's gas service port.
3. Open the Handle Lo manifold valve to purge air from the charge hose for 5 seconds and then close it quickly.
4. Close the 2-way valve.
5. Operate the air conditioner in cooling mode. Cease operations when the gauge reaches 0.1 MPa (14.5 Psi).
6. Close the 3-way valve so that the gauge rests between 0.3 MPa (43.5 Psi) and 0.5 MPa (72.5 Psi).
7. Disconnect the charge set and mount the caps of the service port and 2- and 3-way valves.
8. Use a torque wrench to tighten the caps to a torque of 18 N.m.
9. Check for gas leakage.


## Air purging with vacuum pump



### Procedure:

1. Tighten the flare nuts of the indoor and outdoor units and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
  - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
    - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
    - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
      - If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
  - b. Wait for 5 minutes, then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check for gas leakage.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
  - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
  - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the caps of the 2- and 3-way valves.


## Outdoor Unit Evacuation for the whole system



### Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the vacuum pump to the 3-way valve's service port.
3. Evacuate the system for approximately one hour. Confirm that the compound meter indicates  $-0.1$  MPa (14.5Psi).
4. Close the valve (Low side) on the charge set and turn off the vacuum pump.
5. Wait for 5 minutes, then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check for gas leakage.
6. Disconnect the charge hose from the vacuum pump.
7. Mount the caps of the service port and 2- and 3-way valves.
8. Use a torque wrench to tighten the caps to a torque of 18 N.m.

## Refrigerant charging



### Procedure:

1. Close both 2- and 3-way valves.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
4. If the refrigerant is R410A/R32, invert the cylinder to ensure a complete liquid charge.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with the push pin Handle Lo to the service port of the 3-way valve.
6. Place the charging cylinder on an electronic scale and record the starting weight.
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to the chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately.
10. Mount the caps of the service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
12. Check for gas leakage.

### NOTE

1. Mechanical connectors used indoors shall comply with local regulations.
2. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.

# Troubleshooting


## Safety Caution

### **WARNING**

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock. While checking indoor/outdoor PCBs, please equip yourself with antistatic gloves or wrist strap to avoid damage to the board.

### **WARNING**

Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.



### **NOTE**

If using the inverter test tool for maintenance, remove the big handle, take out the detection cable, take out the female end of the cable, and connect the inverter test tool. After the maintenance is completed, insert the female end back into the port.

### **NOTE**

This picture is for reference only. Actual appearance may vary.

# Indoor Unit Diagnostic Guide

When the indoor unit encounters a recognized error, the operation lamp will flash in a corresponding series, the timer lamp may turn on or begin flashing, and an error code will be displayed. These error codes are described in the following table:

## Indoor Unit Diagnostic Codes

Display	Error Information	Solution
dF	Defrost	Normal Display, not error code
CL	Active clean	
FP	Heating in room temperature under 8°C	
FC	Forced cooling	
AP	AP mode of WIFI connection	
CP	Remote switched off	
EH00	IDU EEPROM malfunction	page 57
EH0A	IDU EEPROM parameter error	page 57
EL01	IDU & ODU communication error	page 59
EH02	Zero-crossing signal detection error	page 61
EH03	IDU fan speed out of control	page 62
ECS1	ODU EEPROM parameter error	page 58
ECS2	ODU coil temp. sensor (T3) error	page 67
ECS3	ODU ambient temp. sensor (T4) error	
ECS4	COMP. discharge temp. sensor (TP) error	
ECS6	IDU coil outlet temp. sensor (T2B) error(Multi-zone)	
EH60	IDU room temp. sensor (T1) error	page 66
EH61	IDU evaporator coil temp. sensor (T2) error	
EC07	ODU fan speed is out of control	page 64
EH06	IDU main control board and display board communication error	page 69
FHCC	Refrigerant sensor error	page 71
EHCI	Refrigerant sensor detects leakage	page 71
EHCI2	Refrigerant sensor is out of range and leakage is detected	page 72
EHCI3	Refrigerant sensor is out of range	page 71
ECCI	The other IDU refrigerant sensor detects leakage (Multi-zone)	page 88
EL0C	System lacks refrigerant	page 68
PC00	ODU IPM module protection	page 73
PC01	ODU voltage protection	page 75
PC02	Compressor top (or IPM) temp. protection	page 76
PC03	Pressure protection (low or high pressure) (for some models)	page 77
PC04	Inverter compressor drive error	page 73
PC0L	Low ambient temperature protection(for some models)	page 79
----	IDUs mode conflict (Multi-zone)	page 79


### For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

### Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.

**88 flash frequency:**



**Error Display (Outdoor Unit with auxiliary board)**

Display	Malfunction or Protection	Solution
dF	Defrost	Normal Display, not error code
FC	Forced cooling	
EC51	ODU EEPROM parameter error	page 57
EL01	IDU & ODU communication error	page 59
PC40	Communication error between outdoor main chip and compressor driven chip	page 82
PC08	ODU overcurrent protection	page 70
PC10	ODU low AC voltage protection	page 75
PC11	ODU main control board DC bus high voltage protection	
PC12	ODU main control board DC bus low voltage protection/341 MCE error	
PC00	ODU IPM module protection	page 73
PC0F	PFC module protection	page 81
EC71	Over current failure of ODU DC fan motor	page 64
EC72	Lack phase failure of ODU DC fan motor	page 84
EC07	ODU fan speed out of control	page 62
PC42	Compressor start failure of outdoor unit	page 70
PC43	ODU compressor lack phase protection	page 85
PC44	ODU zero speed protection	page 70
PC45	ODU IR chip drive failure	page 79
PC46	Compressor speed has been out of control	page 70
PC49	Compressor overcurrent failure	
PC30	System high pressure protection	page 77
PC31	System low pressure protection	
PC0A	High temperature protection of condenser	page 80
PC06	Discharge temperature protection of compressor	page 83
LC06	High temperature protection of Inverter module (IPM)	page 76
PC02	Compressor top (or IPM) temp. protection	
PH90	High temperature protection of evaporator	page 86
PH91	Low temperature protection of evaporator	page 87
EC52	ODU coil temp. sensor (T3) error	page 67
EC53	ODU ambient temp. sensor (T4) error	
EC54	COMP. discharge temp. sensor (TP) error	
EC50	Open or short circuit of outdoor unit temperature sensor(T3,T4,TP)	
PC0L	Low ambient temperature protection(for some models)	page 79

## Outdoor Unit Point Check Function

- A check switch is included on the auxiliary board.
- Push SW1 to check the unit's status while running. The digital display shows the following codes each time the SW1 is pushed.

Number of Presses	Display	Remark		
00	Normal display	Display running frequency, running state or malfunction code		
01	Indoor unit capacity demand code	S communication models display "--"		
02	Amendatory capacity demand code			
03	The frequency after the capacity requirement transfer			
04	The frequency after the frequency limit			
05	The frequency of sending to 341 chip			
06	Indoor unit evaporator temperature	If the temp. is lower than -9 degree, the digital display tube will show "-9".If the temp. is higher than 70 degree, the digital display tube will show "70".		
07	Condenser pipe temp.(T3)			
08	Outdoor ambient temp.(T4)			
09	Compressor discharge temp.(TP)	The display value is between 0~199°C. If the temp. is lower than 0°C, the digital display tube will show "0".If the temp. is higher than 99°C,light the decimal point of the high digit tube. (For example, the digital display tube show "0.5",so 0.5 multiplied by 10 to become 5, then added to 100 to become 105°C.)		
10	AD value of current	The display value is hex number. For example, the digital display tube shows "Cd", so $C*161+d*160=12*16+13=205$ , it means AD value is 205.		
11	AD value of voltage			
12	Indoor unit running mode code	Standby:0,Cooling:1, Heating:2, Fan only: 3, Drying:4, Forced cooling:6, Defrosting:7		
13	Outdoor unit running mode code	Standby:0,Cooling:1, Heating:2, Fan only: 3, Drying:4, Forced cooling:6, Defrosting:7		
14	EXV open angle	Actual data/4. If the value is higher than 99, light the decimal point of the high digit tube. For example, the digital display tube show "2.0",so 2.0 multiplied by 10 to become 20, then added to 100 to become 120,it means the EXV open angle is $120 \times 4 = 480p.$ )		
15	Frequency limit symbol	Bit7	Frequency limit caused by IGBT radiator	The display value is hex number. For example, the digital display tube show 2A, the corresponding binary is 101010, so Bit5=1, Bit3=1, and Bit1=1 It means frequency limit caused by T2, T3 and current.
		Bit6	Frequency limit caused by PFC	
		Bit5	Frequency limit caused by high temperature of T2.	
		Bit4	Frequency limit caused by low temperature of T2.	
		Bit3	Frequency limit caused by T3.	
		Bit2	Frequency limit caused by TP.	
		Bit1	Frequency limit caused by current	
Bit0	Frequency limit caused by voltage			
16	DC fan motor speed	0:off 1:Turbo 2:High 3:Medium 4:Low 5: Breeze 6: Super breeze 7:other		
17	IGBT radiator temp.	The display value is between 0~130 degree. If the temp. is lower than 0°C, the digital display tube will show "0".If the temp. is higher than 99 degree, light the decimal point of the high digit tube. (For example, the digital display tube show "0.5",so 0.5 multiplied by 10 to become 5, then added to 100 to become 105°C.)		
18	Indoor unit number	The indoor unit can communicate with outdoor unit well.		

Number of Presses	Display	Remark
19	Evaporator pipe temp. T2 of 1# indoor unit	S communication models display "--"
20	Evaporator pipe temp. T2 of 2# indoor unit	
21	Evaporator pipe temp. T2 of 3# indoor unit	
22	1# Indoor unit capacity demand code	
23	2# Indoor unit capacity demand code	
24	3# Indoor unit capacity demand code	
25	Room temp. T1 of 1# indoor unit	
26	Room temp. T1 of 2# indoor unit	
27	Average room temp. T1	If the temp. is lower than 0 degree, the digital display tube will show "0". If the temp. is higher than 70 degree, the digital display tube will show "70". If the indoor unit is not connected, the digital display tube will show: "--"
28	Reason of stop	
29	Evaporator pipe temp. T2B of 1# indoor unit	S communication models display "--"
30	Evaporator pipe temp. T2B of 2# indoor unit	

# Complain Record Form

## Complain Record Form

Request No.:

Date:

Installation Date:

Service Date:

Customer Information			
Name		Telephone No.	
Home Address			
Email			
Product Information			
Indoor Unit Model		Outdoor Unit Model	
Serial No. of indoor unit			
Serial No. of outdoor unit			
Working Mode	<input type="checkbox"/> Cooling <input type="checkbox"/> Heating <input type="checkbox"/> Fan only <input type="checkbox"/> Dry		
Setting temperature	_____°C / °F	Fan speed	<input type="checkbox"/> Turbo <input type="checkbox"/> High <input type="checkbox"/> Medium <input type="checkbox"/> Low <input type="checkbox"/> Auto
Temperature of air inlet	_____°C / °F	Temperature of air outlet	_____°C / °F
Installation / Condition Information			
Indoor temperature	_____°C / °F	Indoor humidity	_____ %RH
Outdoor temperature	_____°C / °F	Outdoor humidity	_____ %RH
Length of Connecting pipe		Pipe diameter	Gas pipe:      Liquid pipe:
Length of Wiring		wire diameter	
System Running Pressure	_____MPa   or   _____Bar   or   _____PSI		
Room size (L*W*H)			
Photo of Installation of Indoor unit (Photo #1)		Photo of Installation of Outdoor unit (Photo #2)	
Failure Description			
Error Code of Indoor unit		Code of Outdoor PCB	
Unit does not start			
Remote control does not work			
Indoor display shows nothing			
No cooling or heating at all			
Less cooling or heating			
Unit starts but stops shortly			
High noise			
High vibration			

Parameter Checking information by Remote controller			
Displaying code	Displaying code meaning	Display value	Display value meaning
T1	Room temperature		
T2	Indoor coil temperature		
T3	Outdoor coil temperature		
T4	Ambient temperature		
TP	Discharge temperature		
FT	Targeted Frequency		
Fr	Actual Frequency		
dL	Compressor current		
Uo	Outdoor AC voltage		
Sn	Indoor capacity test	/	N/A
--	Reserve	/	N/A
Pr	Outdoor fan speed		
Lr	EXV opening steps		
ir	Indoor fan speed		
HU	Indoor humidity		
TT	Adjusted setting temperature		
DT	Reserve	/	N/A
iF	Reserve	/	N/A
nA	Reserve	/	N/A
oT	GA algorithm frequency		

Approval from Manufacturer	
<input type="checkbox"/> Approved	
<input type="checkbox"/> More Proof needed	
<input type="checkbox"/> Rejected	

# Engineering Mode Entry and Setting Methods

## Information Inquiry

To enter the engineering mode, and check the data of the system (data checking mode), Please take the following steps:

1. Make sure that the AC is on standby status, or working normally in a non-locked condition.
2. Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
3. Press the "Up" or "Down" button to choose a different channel number that you want to check (from 0-30) on the remote controller, and then the display will show the parameter value.

Channel	Code	Meaning	Remark
0		Error code	Refer to next list of error code Empty means no error
1	T1	Room temperature	Actual data, °C
2	T2	Indoor coil temperature	Actual data, °C
3	T3	Outdoor coil temperature	Actual data, °C
4	T4	Ambient temperature	Actual data, °C
5	TP	Discharge temperature	Actual data, °C
6	FT	Targeted frequency	Actual data
7	Fr	Actual frequency	Actual data
8	dL	Running current	3.2A=3
9	Rc	AC voltage	
10	Ln	Reserved	
11	od	Indoor operating mode	0-Off; 1-Cooling; 2-Heating; 3-Fan only; 4-Drying; 5- Auto; 7-defrosting; 12-Active clean
12	Pr	Outdoor fan speed	Actual data/8
13	Lr	EXV opening steps	Actual data/8
14	Ir	Indoor fan speed	Actual data/8
15	Hu	Humidity (if a sensor there)	Actual data, %
16	TT	Set temperature including compensation	Actual data, °C
17	nR	Reserved	
18	nR	Reserved	
19	Uo	Outdoor DC bus voltage	
20	oT	Target Frequency calculated by indoor	Without limitation
21~30	nR	Reserved	

Please note that:

- The Channel number indicates a certain parameter value (Check the table below).
- The indoor unit display will show the code for 2s, and then the parameter value.
- In the engineering mode, the other keys or operations are invalid except for the following buttons "Power", "Up", "Down", and "Ok".
- In order to exit from the engineering mode, press "Power" + "Fan" buttons together for 2s to quit Checking and back to the home screen.
- The engineering mode will be exited if there is no valid input data for the 60s.

## Error Code Of Engineer Mode

Display	Error Information
E400	IDU EEPROM malfunction
E40A	Indoor EEPROM parameter error
E401	IDU & ODU communication error
E402	Zero-crossing signal detection error
E431	DC voltage is too low of indoor DC fan motor (with DC fan driver board)
E432	DC voltage is too high of indoor DC fan motor (with DC fan driver board)
E403	IDU fan speed out of control
E451	ODU EEPROM parameter error
E452	ODU coil temp. sensor (T3) error
E453	ODU ambient temp. sensor (T4) error
E454	COMP. discharge temp. sensor (TP) error
E455	ODU IPM module temp. sensor (TH) error
E456	Evaporator coil outlet temperature sensor T2B is in open circuit or short circuit (Multi-zone)
E460	IDU room temp. sensor (T1) error
E461	Evaporator coil temperature sensor T2 is in open circuit or short circuit
E407	ODU fan speed out of control
E40b	IDU main control board and display board communication error
E4C1	Refrigerant sensor detects leakage
F4A2	Communication error between indoor unit and refrigerant sensor
F4A3	Refrigerant sensor internal error
F4A4	Refrigerant sensor permanent error
F4A5	Refrigerant sensor self-check failed
F4A6	Refrigerant sensor low voltage error
F4CC	Refrigerant sensor error
E4C2	Refrigerant sensor is out of range and leakage is detected
E4C3	Refrigerant sensor is out of range
E4C1	Other IDU refrigerant sensor detects leakage (Multi-zone)
E40C	System lacks refrigerant
F40P	Wireless module self-test failure
F409	Indoor and outdoor mismatch malfunction
P400	ODU IPM module protection
P410	ODU low AC voltage protection
P411	ODU main control board DC bus high voltage protection
P412	ODU main control board DC bus low voltage protection/341 MCE error
P402	Compressor top (or IPM) temp. protection
P440	Communication error between outdoor main chip and compressor driven chip
P441	Compressor current sampling circuit failure
P442	Compressor start failure of outdoor unit
P443	ODU compressor lack phase protection
P444	ODU zero speed protection

## Error Code Of Engineer Mode (continued)

Display	Error Information
P <sub>C</sub> 45	ODU IR chip drive failure
P <sub>C</sub> 46	Compressor speed has been out of control
P <sub>C</sub> 49	Compressor overcurrent failure
P <sub>C</sub> 06	Discharge temperature protection of compressor
P <sub>C</sub> 08	ODU Current protection
P <sub>H</sub> 09	Anti-cold air in heating mode
P <sub>C</sub> 0F	PFC module protection
P <sub>C</sub> 30	System overpressure protection
P <sub>C</sub> 31	System pressure is too low protection
P <sub>C</sub> 03	Pressure protection(low or high pressure)
P <sub>C</sub> 0L	Outdoor low temp. protection
P <sub>H</sub> 90	High temperature protection of evaporator
P <sub>H</sub> 91	Low temperature protection of evaporator
P <sub>C</sub> 0A	High temperature protection of condenser
P <sub>H</sub> 0C	Indoor unit humidity sensor malfunction
L <sub>H</sub> 00	Evaporator temp. freq.limited(L0)
L <sub>C</sub> 01	Condenser coil temp. (T3) freq. limited
L <sub>C</sub> 02	ODU exhaust temp. (TP) freq. limited
L <sub>C</sub> 05	Voltage freq. limited
L <sub>C</sub> 03	Current freq. limited
L <sub>C</sub> 06	IPM module temp. freq. limited
L <sub>H</sub> 07	Remote control frequency limitation in effect
----	IDUs mode conflict(Multi-zone)
rr	No fault or protection

### Advanced Function Setting

To enter the engineering mode, and check the advanced function settings, please take the following steps:

#### If you want to check the current functions set value (Presetting Page):

1. Firstly, you need to disconnect the power supply from the unit and wait for 1 minute.
2. Then connect the power supply again to the unit (the unit should be under the standby state).
3. Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
4. Press "Up" or "Down" button to choose different channel number that you want to check (from 0-30) on the remote controller.
5. Then Press the "Power" button for 2s until the remote controller screen shows "Ch".
6. Press "OK" button to query the current function set value while the remote controller shows "CH", and the function set value will be shown on the indoor unit display.

#### If you want to change the current functions set value:

1. Firstly, you need to disconnect the power supply from the unit and wait for 1 minute.
2. Then connect the power supply again to the unit (the unit should be under the standby state).
3. Press "Power" + "Fan" buttons together for 7s until the remote controller screen shows "0", and "Auto, Cool, Dry, Heat, Battery" icons will be displayed at the same time.
4. Press the "Up" or "Down" button to choose different channel number that you want to change (from 0-30) on the remote controller.
5. Then Press the "Power" button for 2s until the remote controller screen shows "Ch".

6. Press the "Up" or "Down" button to choose the desired set value from the screen of the remote control.
7. Then Press "OK" to send the new set value to the indoor unit, and the indoor unit will display "CS", which means that the new set value is uploaded successfully.
8. Finally, disconnect the power supply from the unit, and wait for 10 minutes, then connect it again.

**Please note that:**

1. The Channel number indicates a certain function, and each number will be shown on the indoor unit screen indicates the current function set value (Check the table below).
2. In the engineering mode, the other keys or operations are invalid except for the following buttons "Power", "Up", "Down", and "Ok".
3. To set a new set value successfully, you need to finish the steps (from 2 to 7) within 1 minute only.
4. The engineering mode will be exited if there is no valid input data for the 60s.
5. To exit from the engineering mode, please follow the following steps:
  - Press the "Power" button for 2s press until the remote controller screen shows "0".
  - Then Press "Power" + "Fan" buttons together for 2s to quit the engineering mode and back to the home screen.

**Advanced Function Parameter Definitions**

Channel	Function	Parameter Value Meaning	Remark
0	Capacity setting (Btu/h)	1-100K	The actual range is determined by the remote controller
1	Auto-restart function	0 – Inactive 1 – Active	
2	Fan control when Ts reached	1- Fan stop 2 - Fan runs at lowest RPM 3 - Fan runs at setting RPM 4 - Fan stops for 4 mins and runs for 1min 5 - Fan stops for 8 mins and runs for 1min 6 - Fan stops for 16 mins and runs for 1min 7 - Fan stops for 24 mins and runs for 1min 8 - Fan stops for 48 mins and runs for 1min 9 - Fan stops for 15 mins and runs for 2.5min 10 - Fan stops for 30 mins and runs for 2.5min 11 - Fan stops for 60 mins and runs for 2.5min 12 - Fan runs at setting RPM, but stop if choose Automatic speed 13 - Fan runs at the lowest speed, but stop if choose Automatic speed	
3	Mode lock	CH–Cooling and heating (all modes) HH–Heating only (Heating + Fan only) CC–Cooling only (Cooling + Drying + Fan only) nU–Cooling and heating without Auto	Remote controller will change as well.
4	Lowest setting temperature	16-24	Remote controller will change as well.
5	Highest setting temperature	25-30	Remote controller will change as well.
6	Mode priority selection for multi units	H – Heating first C – Cooling first A – Master unit	
7	/	Nothing to set	
8	/	Nothing to set	
9	/	Nothing to set	
10	/	Nothing to set	
11	Min. frequency limitation in cooling mode	10, 11, 12, ..., 49, 50, -- (Cancel)	
12	Min. frequency limitation in heating mode	10, 11, 12, ..., 49, 50, -- (Cancel)	

## Advanced Function Parameter Definitions (continued)

Channel	Function	Parameter Value Meaning	Remark
13	Max frequency selection in T4 limitation of Zone6	20, 21, 22, ..., 149, 150, -- (Cancel)	
14	/	Nothing to set	
15	Frequency selection of outdoor forced-operation	10, 11, 12, ..., 249, 250, -- (Cancel)	
16	One button reset	rS – Reset	
17	nA	Nothing to set	
18	Capacity setting (kW)	23,26,32,35,51,72,120,-- (Cancel)	
19	Max. frequency selection in cooling mode	40, 41, 42, ..., 83, 84, -- (Cancel)	
20	Max. frequency selection in heating mode	40, 41, 42, ..., 83, 84, -- (Cancel)	Without limitation
21	Cooling temperature compensation	-3.0, -2.5, -2.0, ..., 3.0, 3.5, -- (Cancel)	
22	Heating temperature compensation	-6.5, -6.0, -5.5, ..., 0.5, 1.0, 1.5, ..., 7.0, 7.5, -- (Cancel)	
23	Max. fan speed selection in cooling	-41, -40, -39, ..., 19, 20, -- (Cancel)	
24	Min. fan speed selection in cooling	-41, -40, -39, ..., 19, 20, -- (Cancel)	
25	Max. fan selection in heating	-41, -40, -39, ..., 19, 20, -- (Cancel)	
26	Min. fan speed selection in heating	-41, -40, -39, ..., 19, 20, -- (Cancel)	
27	Reserved	Nothing to set	
28	Anti-cold air Stop Fan Temperature	16~28	Remote control will change as well.
29	Reserved	Nothing to set	
30	Reserved	Nothing to set	

## Error Diagnosis and Troubleshooting Without Error Code

### **WARNING**

Be sure to turn off the unit before any maintenance to prevent damage or injury.

#### Remote maintenance

**SUGGESTION:** When troubles occur, please check the following points with customers before field maintenance.

## Remote Troubleshooting

1.Remote Maintenance	Electrical Circuit						Refrigerant Circuit							
Possible causes of trouble	Power failure	The main power tripped	Loose connections	Faulty transformer	The voltage is too high or too low	The remote control is powered off	Broken remote control	Dirty air filter	Dirty condenser fins	The setting temperature is higher/lower than the room's(cooling/heating)	The ambient temperature is too high/low when the mode is cooling/heating	Fan mode	SILENCE function is activated(optional function)	Frosting and defrosting frequently
Unit will not start	☆	☆	☆	☆										
The power switch is on but fans will not start			☆	☆	☆									
The temperature on the display board cannot be set						☆	☆							
Unit is on but the wind is not cold(hot)										☆	☆	☆		
Unit runs, but shortly stops					☆					☆	☆			
The unit starts up and stops frequently					☆						☆			☆
Unit runs continuously but insufficient cooling(heating)								☆	☆	☆	☆		☆	
Cool cannot change to heat														
Unit is noisy														
Test method / remedy	Test voltage	Close the power switch	Inspect connections - tighten	Change the transformer	Test voltage	Replace the battery of the remote control	Replace the remote control	Clean or replace	Clean	Adjust the setting temperature	Turn the AC later	Adjust to cool mode	Turn off SILENCE function.	Turn the AC later

## Remote Troubleshooting (continued)

1.Remote Maintenance	Others					
Possible causes of trouble	Heavy load condition	Loosen hold down bolts and / or screws	Bad airproof	The air inlet or outlet of either unit is blocked	Interference from cell phone towers and remote boosters	Shipping plates remain attached
Unit will not start						
The power switch is on but fans will not start					☆	
The temperature on the display board cannot be set						
Unit is on but the wind is not cold(hot)						
Unit runs, but shortly stops						
The unit starts up and stops frequently				☆		
Unit runs continuously but insufficient cooling(heating)	☆		☆	☆		
Cool can not change to heat						
Unit is noisy		☆				☆
Test method / remedy	Check heat load	Tighten bolts or screws	Close all the windows and doors	Remove the obstacles	Reconnect the power or press ON/OFF button on remote control to restart operation	Remove them

## Field Troubleshooting

2.Field Maintenance	Refrigerant Circuit													Others									
Possible causes of trouble	Compressor stuck	Shortage of refrigerant	Restricted liquid line	Dirty air filter	Dirty evaporator coil	Insufficient air through evaporator coil	Overcharge of refrigerant	Dirty or partially blocked condenser	Air or incompressible gas in refrigerant cycle	Short cycling of condensing air	High temperature condensing medium	Insufficient condensing medium	Broken compressor internal parts	Inefficient compressor	Expansion valve obstructed	Expansion valve or capillary tube closed completely	Leaking power element on expansion valve	Poor installation of feeler bulb	Heavy load condition	Loosen hold down bolts and / or screws	Shipping plates remain attached	Poor choices of capacity	Contact of piping with other piping or external plate
Unit will not start																							
Compressor will not start but fans run	☆																						
Compressor and condenser (outdoor) fan will not start																							
Evaporator (indoor) fan will not start																							
Condenser (Outdoor) fan will not start																							
Unit runs, but shortly stops		☆	☆				☆	☆							☆	☆							
Compressor short-cycles due to overload		☆					☆	☆															
High discharge pressure							☆	☆	☆	☆	☆												
Low discharge pressure		☆											☆										
High suction pressure							☆						☆				☆	☆					
Low suction pressure		☆	☆	☆	☆	☆							☆	☆	☆	☆							
Unit runs continuously but insufficient cooling		☆	☆	☆	☆	☆		☆	☆	☆			☆				☆				☆		
Too cool																							
Compressor is noisy							☆						☆						☆	☆		☆	
Horizontal louver can not revolve																							
Test method / remedy	Replace the compressor	Leak test	Replace restricted part	Clean or replace	Clean coil	Check fan	Change charged refrigerant volume	Clean condenser or remove obstacle	Purge, evacuate and recharge	Remove obstruction to air flow	Remove obstruction in air or water flow	Remove obstruction in air or water flow	Replace compressor	Test compressor efficiency	Replace valve	Replace valve	Replace valve	Fix feeler bulb	Check heat load	Tighten bolts or screws	Remove them	Choose AC of larger capacity or add the number of AC	Rectify piping so as not to contact each other or with external plate

## Field Troubleshooting (continued)

2.Field Maintenance	Electrical Circuit														
Possible causes of trouble	Power failure	Blown fuse or varistor	Loose connections	Shorted or broken wires	Safety device opens	Faulty thermostat / room temperature sensor	Wrong setting place of temperature sensor	Faulty transformer	Shorted or open capacitor	Faulty magnetic contactor for compressor	Faulty magnetic contactor for fan	Low voltage	Faulty stepping motor	Shorted or grounded compressor	Shorted or grounded fan motor
Unit will not start	☆	☆	☆	☆	☆			☆							
Compressor will not start but fans run				☆		☆			☆	☆				☆	
Compressor and condenser (outdoor) fan will not start				☆		☆				☆					
Evaporator (indoor) fan will not start				☆					☆		☆				☆
Condenser (Outdoor) fan will not start				☆		☆			☆		☆				☆
Unit runs, but shortly stops										☆		☆			
Compressor short-cycles due to overload										☆		☆			
High discharge pressure															
Low discharge pressure															
High suction pressure															
Low suction pressure															
Unit runs continuously but insufficient cooling															
Too cool					☆	☆									
Compressor is noisy															
Horizontal louver can not revolve			☆	☆									☆		
Test method / remedy	Test voltage	Inspect fuse type & size	Inspect connections - tighten	Test circuits with tester	Test continuity of safety device	Test continuity of thermostat / sensor & wiring	Place the temperature sensor at the central of the air inlet grille	Check control circuit with tester	Check capacitor with tester	Test continuity of coil & contacts	Test continuity of coil & contacts	Test voltage	Replace the stepping motor	Check resistance with multimeter	Check resistance with multimeter

# Quick Maintenance by Error Code

If you do not have the time to test which specific parts are faulty, you can directly change the required parts according to the error code.

You can find the parts to be replaced by the error code in the following table.

Part requiring replacement	Error Code									
	EH00/ EH0A	EL01	EH02	EH03	EH60	EH61	EH06	EL0C	ECS6	FHCC
Indoor PCB	√	√	√	√	√	√	√	√	x	√
Outdoor PCB	x	√	x	x	x	x	x	x	√	x
Display board	x	x	x	x	x	x		x	x	x
Indoor fan motor	x	x	x	√	x	x	x	x	x	x
T1 sensor	x	x	x	x	√	x	x	x	x	x
T2 Sensor	x	x	x	x	x	√	x	√	x	x
T2B Sensor	x	x	x	x	x	x	x	x	√	x
Refrigerant sensor	x	x	x	x	x	x	x	x	x	√
Reactor	x	√	x	x	x	x	x	x	x	x
Compressor	x	x	x	x	x	x	x	x	x	√
Additional refrigerant	x	x	x	x	x	x	x	√	x	x

Part requiring replacement	Error Code									
	ECS3	ECS2	ECS4	ECS1	EC07	PC00	PC01	PC02	PC03	PC04
Outdoor PCB	√	√	√	√	√	√	√	√	√	√
Indoor fan motor	x	x	x	x	x	x	x	x	x	x
Outdoor fan motor	x	x	x	x	√	√	x	√	x	√
T3 Sensor	x	√	x	x	x	x	x	x	x	x
T4 Sensor	√	x	x	x	x	x	x	x	x	x
TP Sensor	x	x	√	x	x	x	x	x	x	x
Reactor	x	x	x	x	x	x	√	x	x	x
Compressor	x	x	x	x	x	√	x	x	x	√
IPM module board	x	x	x	x	x	√	√	√	x	√
High pressure protector	x	x	x	x	x	x	x	√	x	x
Low pressure protector	x	x	x	x	x	x	x	x	√	x
Additional refrigerant	x	x	x	x	x	x	x	x	√	x

Part requiring replacement	Error Code				
	PC06	PC08/44/49	PC0A	PC0F	PC40
Outdoor PCB	√	√	√	√	√
Outdoor fan motor	x	√	√	x	x
T3 Sensor	x	x		x	x
TP Sensor	√	x	x	x	x
Pressure sensor	x	x	x	x	x
Reactor	x	√	x	√	x
Compressor	x	x	x	x	x
IPM module board	x	√	x	x	√
High pressure valve assy	√	x	x	x	x
High pressure protector	x	x	x	x	x
Low pressure protector	x	x	x	x	x
Additional refrigerant	√	x	√	x	x
Electric control box	x	x	x	x	√

Part requiring replacement	Error Code				
	PC41	PC43	PC 10/ 11/ 12	PC30	PC31
Outdoor PCB	√	√	√	√	√
Outdoor fan motor	x	x	x	√	x
T3 Sensor	x	x	x	x	x
TP Sensor	x	x	x	x	x
Pressure sensor	x	x	x	x	x
Reactor	x	x	√	x	x
Compressor	x	√	x	x	x
IPM module board	x	x	√	x	x
High pressure valve assy	x	x	x	x	x
High pressure protector	x	x	x	√	x
Low pressure protector	x	x	x	x	√
Additional refrigerant	x	x	x	x	√

# Troubleshooting by Error Code


## **EH00/EH0A (IDU EEPROM malfunction or IDU EEPROM parameter error) diagnosis and solution**

Description: Indoor PCB main chip does not receive feedback from EEPROM chip.

Recommended parts to prepare:


- Indoor PCB

Troubleshooting and repair:



Remarks:

**EEPROM:** A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. The location of the EEPROM chip on the indoor PCB is shown in the following image:



### **NOTE:**


These pictures are only for reference, actual appearance may vary.

## EC51 (ODU EEPROM parameter error) diagnosis and solution

Description: Outdoor PCB main chip does not receive feedback from EEPROM chip. Indoor PCB


- Outdoor PCB

Troubleshooting and repair:



Remarks:

**EEPROM:** A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. The location of the EEPROM chip on the outdoor PCB is shown in the following image:



These pictures are only for reference, actual appearance may vary.


## EL01 (Indoor and Outdoor Unit Communication Error Diagnosis and Solution)

Description: The indoor unit cannot communicate with the outdoor unit

Recommended parts to prepare:


- Indoor PCB
- Outdoor PCB
- Short-circuited component

Troubleshooting and repair:




**Remarks:**

- Use a multimeter to test the DC voltage between the 2 port (or S or L2 port) and the 3 port (or N or S port) of the outdoor unit. The red pin of the multimeter connects with the port (or S or L2 port) while the black pin is for the 3 port (or N or S port).
- When AC is operating normally, the voltage is moving alternately between positive values and negative values
- If the outdoor unit has malfunctioned, the voltage has always been the positive value.
- If the indoor unit malfunctions, the voltage has always been a certain value.



- Use a multimeter to test the resistance of the reactor that does not connect with the capacitor.
- The normal value should be around zero ohms. Otherwise, the reactor must have malfunctioned.



**NOTE**

The picture and the value are only for reference; actual condition and specific value may vary.


## **Eh02 (Zero crossing detection error) diagnosis and solution**

**Description:** When the PCB does not receive zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.

**Recommended parts to prepare:**

- Connection wires
- Indoor main PCB

**Troubleshooting and repair:**



### **NOTE:**

Zero crossing detection error is only valid for the unit with AC fan motor, for other models, this error is invalid.


### EH03 (The Indoor fan speed is operating outside of normal range) diagnosis and solution

**Description:** When indoor fan speed keeps too low or too high for a certain time, the LED displays the failure code and the AC turns off.

#### Recommended parts to prepare:

- Connection wires
- Fan assembly
- Fan motor
- Indoor main PCB

#### Troubleshooting and repair:



**Index:**

**1. Indoor or Outdoor DC Fan Motor (control chip is in the fan motor)**


Power on and when the unit is on standby, measure the voltage of pin1-pin3, and pin4-pin3 in the fan motor connector. If the voltage value is not in the range shown in the table below, the PCB must have problems and need to be replaced.

- DC motor voltage input and output (voltage: 220-240V~):

No.	Color	Signal	Voltage
1	Red	VS/VM	192 V~380 V
2	---	---	---
3	Black	GND	0 V
4	White	VCC	14-17.5 V
5	Yellow	VSP	0~5.6 V
6	Blue	FG	14-17.5 V


- DC motor voltage input and output (voltage: 115V~):

No.	Color	Signal	Voltage
1	Red	VS/VM	140V~190 V
2	---	---	---
3	Black	GND	0 V
4	White	VCC	14-17.5 V
5	Yellow	VSP	0~5.6 V
6	Blue	FG	14-17.5 V



**2. Indoor AC Motor**

Power on and set the unit running in fan mode at high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V(208~240V power supply) or 50V (115V power supply), the PCB must has problems and need to be replaced.




## EC07/EC71 (The outdoor fan speed is operating outside of normal range or Over current failure of ODU DC fan motor) diagnosis and solution

**Description:** When outdoor fan speed keeps too low or too high for a certain time, the LED displays the failure code and the AC turns off.

### Recommended parts to prepare:

- Connection wires
- Fan assembly
- Fan motor
- Outdoor main PCB


### Troubleshooting and repair:



**Index:**

**1. Outdoor DC Fan Motor (control chip is in outdoor PCB)**


Release the UVW connector. Measure the resistance of U-V, U-W, and V-W. If the resistance is not equal, the fan motor must have problems and needs to be replaced. Otherwise, the PCB must have problems and needs to be replaced.



**2. DC Fan Motor (control chip is in the fan motor, single fan)**

Power on and when the unit is on standby, measure the voltage of pin1-pin3, pin4-pin3 in the fan motor connector. If the value of the voltage is not in the range shown in the table below, the PCB must have problems and needs to be replaced.

No.	Color	Signal	Voltage
1	Red	VS/VM	192 V~380 V
2	---	---	---
3	Black	GND	0 V
4	White	VCC	13.5-16.5 V
5	Yellow	VSP	0~6.5 V
6	Blue	FG	13.5-16.5 V





## EH60/EH61 (Open circuit or short circuit of indoor temperature sensor (T1, T2)) diagnosis and solution

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays failure.

Recommended parts to prepare:

- Connection wires
- Sensors
- PCB

Troubleshooting and repair:



### NOTE

This picture and the value on the display are only for reference, actual appearance and value may vary.



## EC52/EC53/EC54/EC56/EC50 (Open circuit or short circuit of outdoor temperature sensor (T3, T4, TP, T2B)) diagnosis and solution

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure code.

Recommended parts to prepare:

- Connection wires
- Sensors
- Outdoor main PCB

Troubleshooting and repair:



For certain models, the outdoor unit uses a combination sensor; T3, T4, and TP are the same sensor. This picture and the value are only for reference; actual appearance and value may vary.


### ELOC (System lacks refrigerant Diagnosis and Solution)

**Description:** Judging the abnormality of the refrigeration system according to the number of compressor stops and the changes in operating parameters caused by excessive exhaust temperature.

**Recommended parts to prepare:**

- Indoor PCB
- Additional refrigerant

**Troubleshooting and repair:**




## **EH0b (IDU main control board and display board communication error) diagnosis and solution**

Description: Indoor PCB does not receive feedback from the display board.

Recommended parts to prepare:

- Connection wires
- Indoor PCB
- Display board

Troubleshooting and repair:




**PC08 (Current overload protection) / PC42 (Compressor start failure of outdoor unit) / PC44 (ODU zero speed protection) / PC46 (Compressor speed has been out of control) / PC49 (Compressor overcurrent failure) diagnosis and solution**

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Recommended parts to prepare:

- Connection wires
- Reactor
- Outdoor fan
- Outdoor PCB

Troubleshooting and repair:




### FHCC (Refrigerant sensor error) or EHC3 (Refrigerant sensor is out of range) diagnosis and solution

**Description:** The indoor unit receives fault signal for 10 seconds or indoor unit does not receive feedback from the refrigerant sensor for 150 seconds.

#### Recommended parts to prepare:

- Connection wires
- Sensors
- Indoor main PCB

#### Troubleshooting and repair:



### EHC1 (Refrigerant sensor detects leakage) or diagnosis and solution

#### Description:


The refrigerant sensor detects a concentration higher than or equal to 10%\*LFL for 10 seconds, or the refrigerant sensor detects a concentration higher than or equal to 20%\*LFL, or the multi-model receives the refrigerant leakage protection fault sent by the outdoor unit.

Multi-zone: Only the buzzer of the indoor unit that detects refrigerant leakage continues to sound the alarm, the shortest sound is 10 seconds, and the longest sound is 5 minutes (you can press any key such as remote control or wire control, APP and so on to eliminate the alarm), and the other non-refrigerant leakage fault indoor unit only displays "ECC1", but the buzzer does not sound.

#### Recommended parts to prepare:

- Additional refrigerant

#### Troubleshooting and repair:




## EHC2 (Refrigerant sensor is out of range and leakage is detected) diagnosis and solution

Description: Indoor unit receives fault signal and LFL is more than or equal to 0.

Recommended parts to prepare:

- Connection wires
- Sensors
- Indoor main PCB
- Additional refrigerant

Troubleshooting and repair:



# PC00 (ODU IPM module protection)/PC04 (Inverter compressor drive error) Diagnosis and Solution


**Description:** When the voltage signal the IPM sends to the compressor drive chip is abnormal, the display LED shows "PC00" and the AC turn off.

Or an abnormal inverter compressor drive is detected by a special detection circuit, including communication signal detection, voltage detection, compressor rotation speed signal detection and so on.


## Recommended parts to prepare:

- Connection wires
- IPM module board
- Outdoor fan assembly
- Compressor
- Outdoor PCB

## Troubleshooting and repair:



Continued on the next page.




**PC01 (ODU voltage protection)/PC10 (ODU low AC voltage protection)/PC11 (ODU main control board DC bus high voltage protection)/PC12 (ODU main control board DC bus low voltage protection/341 MCE error) diagnosis and solution**

**Description:** Abnormal voltage increases or decreases are detected by checking the specified voltage detection circuit.

**Recommended parts to prepare:**

- Power supply wires
- IPM module board
- PCB
- Reactor

**Troubleshooting and repair:**




## PC02/LC06 (Compressor top(or IPM) temp. protection/Refrigerant sensor error) diagnosis and solution

Description: If the temperature of IPM module is higher than a certain value, the LED displays the failure code.

Recommended parts to prepare:

- Connection wires
- Outdoor PCB
- Refrigerant sensor

Troubleshooting and repair:




### PC03/PC30/PC31 (Pressure protection (low or high pressure) diagnosis and solution

**Description:** The outdoor pressure switch cut off the system because the high pressure is higher than 4.4 MPa or the outdoor pressure switch cut off the system because the low pressure is lower than 0.13 MPa, the LED displays the failure code.


**Recommended parts to prepare:**

- Connection wires
- Outdoor PCB
- Refrigerant
- Pressure switch
- Outdoor fan

**Troubleshooting and repair:**



Continued from the previous page.



### IDUs mode conflict (match with multi outdoor unit)

**Description:** The indoor units cannot work in cooling mode and heating mode at the same time. Heating mode has priority.

- Suppose Indoor unit A is working in cooling mode or fan mode, and Indoor unit B is set to heating mode, then A will change to off, and B will work in heating mode.
- Suppose Indoor unit A is working in heating mode, and Indoor unit B is set to cooling mode or fan mode, then B will change to stand by, and A will remain in no change.

	Cooling Mode	Heating Mode	Fan	Off
Cooling Mode	No	Yes	No	No
Heating Mode	Yes	No	Yes	No
Fan	No	Yes	No	No
Off	No	No	No	No

### NOTE

No: No mode conflict

Yes: Mode conflict

### PC0L (Low ambient temperature protection)

**Description:** It is a protection function. When the compressor is off, the outdoor ambient temperature (T4) is lower than -31°F (-35°C) for 10 seconds, the AC will stop and display the failure code.

When the compressor is on, the outdoor ambient temperature (T4) is lower than -40°F (-40°C) for 10 seconds, the AC will stop and display the failure code.

When the outdoor ambient temperature (T4) is no lower than -25.6°F (-32°C) for 10 seconds, the unit will exit protection.


### PC45 (ODU IR chip drive failure) diagnosis and solution

**Description:** When the IR chip detects its own parameter error, the LED displays the failure code when powered on.

**Recommended parts to prepare:**

- Inverter module PCB.

**Troubleshooting and repair:**




## PC0A (High temperature protection of condenser) diagnosis and solution

**Description:** The unit will stop when condenser temperature is higher than 149°F (65°C), and runs again when it is less than 125.6°F (52°C).

### Recommended parts to prepare:

- Connection wires
- Condenser temperature sensor
- Outdoor fan
- Outdoor main PCB
- Refrigerant

### Troubleshooting and repair:



### PC0F (PFC module protection) diagnosis and solution


**Description:** When the voltage signal that IPM send to compressor drive chip is abnormal, the LED displays the failure code and the AC turns off.

#### Recommended parts to prepare:

- Connection wires
- Inductance
- Outdoor main PCB
- PFC module

#### Troubleshooting and repair:

At first test the resistance between every two ports of U, V, W of IPM and P, N. If any result of them is 0 or close to 0, the IPM is defective. Otherwise, please follow the procedure below:




### PC40 (Communication error between outdoor main chip and compressor driven chip) diagnosis and solution

Description: The main PCB cannot detect the IPM board.

Recommended parts to prepare:

- Connection wires
- IPM board
- Outdoor main PCB
- Electric control box

Troubleshooting and repair:




## PC06 (Discharge temperature protection of compressor) diagnosis and solution

**Description:** If the compressor discharge temperature exceeds a certain level for nine seconds, the compressor ceases operation, the LED displays the failure code

### Recommended parts to prepare:

- Connection wires
- Discharge temperature sensor
- Additional refrigerant
- Outdoor main PCB

### Troubleshooting and repair:



### NOTE:

For certain models, the outdoor unit uses a combination sensor; T3, T4, and TP are the same sensor. This picture and the value are only for reference; actual appearance and value may vary.


## EC72 (Lack phase failure of ODU DC fan motor) diagnosis and solution

**Description:** When the three-phase sampling current of the DC motor is abnormal, especially when the current of one or more phases is always small and almost 0, the LED displays the failure code.

**Recommended parts to prepare:**

- Connection wire
- Fan motor
- Outdoor PCB

**Troubleshooting and repair:**




### PC43 (ODU compressor lack phase protection) diagnosis and solution

**Description:** When the three-phase sampling current of the compressor is abnormal, especially when the current of one or more phases is always small and almost 0, the LED displays the failure code

**Recommended parts to prepare:**

- Connection wire
- Compressor
- Outdoor PCB

**Troubleshooting and repair:**




## PH90 (High temperature protection of evaporator diagnosis and solution)

**Description:** When evaporator coil temperature is more than 140°F (60°C) in heating mode, the unit stops. It starts again only when the evaporator coil temperature is less than 125.6 °F (52°C).

### Recommended parts to prepare:

- Connection wires
- Evaporator coil temperature sensor (T2)
- Indoor fan
- Indoor main PCB

### Troubleshooting and repair:




### PH91 (Low temperature protection of evaporator diagnosis and solution)

**Description:** When evaporator coil temperature is lower than 32°F (0°C) in cooling mode or drying mode, the unit stops. It starts again only when the evaporator coil temperature is more than 41°F (5°C).

#### Recommended parts to prepare:

- Connection wires
- Evaporator coil temperature sensor (T2)
- Indoor main PCB

#### Troubleshooting and repair:




# Check Procedures

## Temperature Sensor Check

### **WARNING**

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock. Operate after the compressor and coil have returned to normal temperature in case of injury.

1. Disconnect the temperature sensor from the PCB (Refer to Indoor Disassembly and Outdoor Disassembly).
2. Measure the resistance value of the sensor using a multimeter.
3. Check the corresponding temperature sensor resistance value table in the Appendix.




### **NOTE**

This picture and the value on the display are only for reference, actual appearance and value may vary.

### **Compressor Check**

1. Disconnect the compressor power cord from the outdoor PCB (Refer to Outdoor Unit Disassembly).
2. Measure the resistance value of each winding using a multimeter.
3. Check the resistance value of each winding in the following table.



Resistance Value	KSK89D53UEZ	KSK89D29UEZD	KSN98D22UFZ	KSK103D33UEZ3 KSK103D33UEZ3(MD) KBK103D33UEZ3	KSK103D32UEZ31 KSK75D32UEZD31	KTN150D30UFZA KTN150D30SFZA
Blue-Red	2.35±5%Ω (at 20°C/68°F)	1.99±5%Ω (at 20°C/68°F)	1.57±5%Ω (at 20°C/68°F)	2.13±5%Ω (at 20°C/68°F)	4.06±5%Ω (at 20°C/68°F)	1.02±5%Ω (at 20°C/68°F)
Blue-Black						
Red-Black						


Resistance Value	KSM135D23UFZ	KTN110D42UFZ	KSN140D21UFZ	KTM140D78UFZ3	KTF235D22UMT ATF235D22TMT KTF250D22UMT	KTM240D46UKT2
Blue-Red	1.72±5%Ω (at 20°C/68°F)	1.82±5%Ω (at 20°C/68°F)	1.28±5%Ω (at 20°C/68°F)	1.5±5%Ω (at 20°C/68°F)	0.75±5%Ω (at 20°C/68°F)	1.04±5%Ω (at 20°C/68°F)
Blue-Black						
Red-Black						

Resistance Value	KSN140D58UFZ	KTM240D43UKT	KSN98D64UFZ3	ASN140D35TFZ	KTF420D62UNT	ASN108D22TEZ
Blue-Red	1.86±5%Ω (at 20°C/68°F)	1.03±5%Ω (at 20°C/68°F)	2.7±5%Ω (at 20°C/68°F)	0.83±5%Ω (at 20°C/68°F)	0.86±5%Ω (at 20°C/68°F)	1.76±5%Ω (at 20°C/68°F)
Blue-Black						
Red-Black						

Resistance Value	KTM240D63SKT2	KTM240D57UMT	DTN210D32UFZ	KSN140D33UFZB3	KTM110D79UFZA3	GSD098XKUF7JV6B
Blue-Red	1.19±5%Ω (at 20°C/68°F)	0.62±5%Ω (at 20°C/68°F)	1.7±5%Ω (at 20°C/68°F)	1.68±5%Ω (at 20°C/68°F)	1.88±5%Ω (at 20°C/68°F)	2.83±5%Ω (at 20°C/68°F)
Blue-Black						
Red-Black						

Resistance Value	KSK75D33UEZD3	DTN210D54UEZ3	DTN250D53UFZ3	KSN103D42UEZ31	GTD141RKRF8JV8B	ATD186RKSF8JV8
Blue-Red	2.14±5%Ω (at 20°C/68°F)	2.53±5%Ω (at 20°C/68°F)	1.97±5%Ω (at 20°C/68°F)	2.35±5%Ω (at 20°C/68°F)	1.765±5%Ω (at 20°C/68°F)	1.64±5%Ω (at 20°C/68°F)
Blue-Black						
Red-Black						

Resistance Value	KTM29000D27UKT3	KSN98D13UEZ32	KSN140D43SFZ31	KTM180D68UMT	
Blue-Red	0.9±5%Ω (at 20°C/68°F)	3.15±5%Ω (at 20°C/68°F)	1.81±5%Ω (at 20°C/68°F)	1.91±5%Ω (at 20°C/68°F)	
Blue-Black					
Red-Black					



**NOTE**

This picture and the value on the display are only for reference, actual appearance and value may vary.

**IPM Continuity Check**

**⚠ WARNING**

**Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.**


1. Turn off the outdoor unit and disconnect the power supply.
2. Discharge electrolytic capacitors and ensure all energy-storage units have been discharged.
3. Disassemble the outdoor PCB or disassemble the IPM board.
4. Measure the resistance value between P and U (V, W, N); U (V, W) and N.

Digital tester		Resistance value	Digital tester		Resistance value
(+)Red	(-)Black		(+)Red	(-)Black	
P	N	∞ (Several M±5%Ω)	U	N	∞ (Several M±5%Ω)
	U		V		
	V		W		
	W		-		

Or test the conductivity of IPM with diode mode.

Needle-type Tester		Normal Value	Needle-type Tester		Normal Value
Red	Black		Red	Black	
P	U	Open-circuit	N	U	0.3-0.5V
	V			V	
	W			W	

Needle-type Tester		Normal Value	Needle-type Tester		Normal Value
Black	Red		Black	Red	
P	U	0.3-0.5V	N	U	Open-circuit
	V			V	
	W			W	




**NOTE**


This picture and the value on the display are only for reference, actual appearance and value may vary.

#### 4-way Valve Check

1. Power on, use a digital tester to measure the voltage. When the unit operates in cooling, it is 0V. When the unit operates in heating, it is about 230VAC.  
If the value of the voltage is not in the range, the PCB must have problems and needs to be replaced.



2. Turn off the power, and use a digital tester to measure the resistance. The value should be  $1.8\sim 2.5\text{ K}\pm 5\%\Omega$ .




## EXV Check

### **WARNING**

Electricity remains in capacitors even when the power supply is off.  
Ensure the capacitors are fully discharged before troubleshooting.

1. Disconnect the connector from the outdoor PCB.
2. Measure the resistance value of each winding using a multimeter.
3. Check the resistance value of each winding in the following table.



Color Of Lead Winding	Normal Value
Red- Blue	About 50Ω
Red - Yellow	
Brown-Orange	
Brown-White	

# Appendix

Temperature Sensor Resistance Value Table for TP (°C --K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			


## Other Temperature Sensors Resistance Value Table (°C – K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.342	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.587	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.170	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.090	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.276	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.708	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.369	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.244	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.316	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.573	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.588	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.824	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.199	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.202	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.327	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.564	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.906	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.346	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.878	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.495	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.193	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.566	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.809	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.718	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.689	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.718	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.801	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.934	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.116	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.342	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.618	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.263	59	138	2.44677	99	210	0.64862	139	282	0.22231

# Pressure On Service Port


Cooling Chart (R454B):

°F (°C)	ODU(DB)		0	5	15	45	75	85	95	105	115	120
	IDU(DB/WB)		(-17)	(-15)	(-9.44)	(7.22)	(23.89)	(29.44)	(35)	(40.56)	(46.11)	(48.89)
<b>BAR</b>	70/59 (21.11/15)		5.9	6.0	6.7	7.3	7.5	7.2	7.4	7.9	9.2	9.7
	75/63 (23.89/17.22)		6.1	6.2	7.2	7.9	7.9	7.6	7.9	8.3	9.8	10.2
	80/67 (26.67/19.44)		6.5	6.6	7.8	8.7	8.5	8.2	8.3	8.8	10.2	10.8
	90/73 (32.22/22.78)		7.1	7.2	8.8	9.6	9.4	8.7	9.2	9.7	11.3	11.9
<b>PSI</b>	70/59 (21.11/15)		85	86	97	106	109	104	108	114	134	140
	75/63 (23.89/17.22)		89	90	105	114	114	110	115	121	142	148
	80/67 (26.67/19.44)		94	95	113	126	123	118	121	127	148	157
	90/73 (32.22/22.78)		102	104	127	139	136	126	133	140	164	172
<b>MPa</b>	70/59 (21.11/15)		0.59	0.60	0.67	0.73	0.75	0.72	0.74	0.79	0.92	0.97
	75/63 (23.89/17.22)		0.61	0.62	0.72	0.79	0.79	0.76	0.79	0.83	0.98	1.02
	80/67 (26.67/19.44)		0.65	0.66	0.78	0.87	0.85	0.82	0.83	0.88	1.02	1.08
	90/73 (32.22/22.78)		0.71	0.72	0.88	0.96	0.94	0.87	0.92	0.97	1.13	1.19



Heating chart (R454B):

°F (°C)	ODU(DB/WB)		57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/-10.56)	0/- (-17)	-17 (-27)
	IDU(DB)								
<b>BAR</b>	55(12.78)		27.7	26.1	23.1	20.9	19.0	16.9	15.1
	65(18.33)		29.8	27.5	24.3	23.2	21.3	18.7	17.4
	75(23.89)		31.0	28.8	25.4	24.0	22.8	19.6	18.3
<b>PSI</b>	55(12.78)		402	378	335	303	275	245	218
	65(18.33)		432	398	352	337	309	271	252
	75(23.89)		449	418	368	348	330	284	265
<b>MPa</b>	55(12.78)		2.77	2.61	2.31	2.09	1.90	1.69	1.51
	65(18.33)		2.98	2.75	2.43	2.32	2.13	1.87	1.74
	75(23.89)		3.10	2.88	2.54	2.40	2.28	1.96	1.83



## System Pressure Table-R454B

Pressure			Temperature		Pressure			Temperature	
Kpa	bar	PSI	°C	°F	Kpa	bar	PSI	°C	°F
58.196	0.58	8.44	-60	-76	935.23	9.35	135.64	8	46.4
61.517	0.62	8.92	-59	-74.2	963.75	9.64	139.78	9	48.2
64.988	0.65	9.43	-58	-72.4	992.93	9.93	144.01	10	50
68.615	0.69	9.95	-57	-70.6	1,022.8	10.23	148.34	11	51.8
72.402	0.72	10.50	-56	-68.8	1,053.3	10.53	152.76	12	53.6
76.354	0.76	11.07	-55	-67	1,084.5	10.85	157.29	13	55.4
80.478	0.80	11.67	-54	-65.2	1,116.4	11.16	161.91	14	57.2
84.776	0.85	12.30	-53	-63.4	1149	11.49	166.64	15	59
89.256	0.89	12.95	-52	-61.6	1,182.3	11.82	171.47	16	60.8
93.923	0.94	13.62	-51	-59.8	1,216.3	12.16	176.40	17	62.6
98.781	0.99	14.33	-50	-58	1,251.1	12.51	181.45	18	64.4
103.84	1.04	15.06	-49	-56.2	1,286.6	12.87	186.60	19	66.2
109.1	1.09	15.82	-48	-54.4	1,322.8	13.23	191.85	20	68
114.56	1.15	16.61	-47	-52.6	1,359.9	13.60	197.23	21	69.8
120.25	1.20	17.44	-46	-50.8	1,397.7	13.98	202.71	22	71.6
126.15	1.26	18.30	-45	-49	1,436.3	14.36	208.31	23	73.4
132.28	1.32	19.18	-44	-47.2	1,475.7	14.76	214.02	24	75.2
138.64	1.39	20.11	-43	-45.4	1,515.9	15.16	219.85	25	77
145.24	1.45	21.06	-42	-43.6	1557	15.57	225.82	26	78.8
152.09	1.52	22.06	-41	-41.8	1,598.9	15.99	231.89	27	80.6
159.18	1.59	23.09	-40	-40	1,641.6	16.42	238.09	28	82.4
166.54	1.67	24.15	-39	-38.2	1,685.2	16.85	244.41	29	84.2
174.15	1.74	25.26	-38	-36.4	1,729.7	17.30	250.86	30	86
182.04	1.82	26.40	-37	-34.6	1775	17.75	257.43	31	87.8
190.2	1.90	27.59	-36	-32.8	1,821.3	18.21	264.15	32	89.6
198.65	1.99	28.81	-35	-31	1,868.4	18.68	270.98	33	91.4
207.39	2.07	30.08	-34	-29.2	1,916.5	19.17	277.95	34	93.2
216.42	2.16	31.39	-33	-27.4	1,965.6	19.66	285.08	35	95
225.76	2.26	32.74	-32	-25.6	2,015.5	20.16	292.31	36	96.8
235.41	2.35	34.14	-31	-23.8	2,066.5	20.67	299.71	37	98.6
245.37	2.45	35.59	-30	-22	2,118.4	21.18	307.24	38	100.4
255.67	2.56	37.08	-29	-20.2	2,171.3	21.71	314.91	39	102.2
266.29	2.66	38.62	-28	-18.4	2,225.2	22.25	322.73	40	104
277.25	2.77	40.21	-27	-16.6	2,280.2	22.80	330.70	41	105.8
288.56	2.89	41.85	-26	-14.8	2,336.1	23.36	338.81	42	107.6
300.22	3.00	43.54	-25	-13	2,393.2	23.93	347.09	43	109.4
312.24	3.12	45.28	-24	-11.2	2,451.3	24.51	355.52	44	111.2
324.63	3.25	47.08	-23	-9.4	2,510.4	25.10	364.09	45	113
337.39	3.37	48.93	-22	-7.6	2,570.7	25.71	372.84	46	114.8
350.54	3.51	50.84	-21	-5.8	2,632.1	26.32	381.74	47	116.6
364.08	3.64	52.80	-20	-4	2,694.7	26.95	390.82	48	118.4
378.02	3.78	54.83	-19	-2.2	2,758.3	27.58	400.04	49	120.2
392.37	3.92	56.91	-18	-0.4	2,823.2	28.23	409.46	50	122
407.13	4.07	59.05	-17	1.4	2,889.3	28.89	419.04	51	123.8
422.31	4.22	61.25	-16	3.2	2,956.5	29.57	428.79	52	125.6

System Pressure Table-R454B (continued)

Pressure			Temperature		Pressure			Temperature	
Kpa	bar	PSI	°C	°F	Kpa	bar	PSI	°C	°F
437.92	4.38	63.51	-15	5	3025	30.25	438.72	53	127.4
453.98	4.54	65.84	-14	6.8	3,094.7	30.95	448.83	54	129.2
470.47	4.70	68.23	-13	8.6	3,165.7	31.66	459.13	55	131
487.43	4.87	70.69	-12	10.4	3,238.1	32.38	469.63	56	132.8
504.84	5.05	73.22	-11	12.2	3,311.7	33.12	480.30	57	134.6
522.73	5.23	75.81	-10	14	3,386.7	33.87	491.18	58	136.4
541.1	5.41	78.48	-9	15.8	3,463	34.63	502.25	59	138.2
559.95	5.60	81.21	-8	17.6	3,540.7	35.41	513.52	60	140
579.31	5.79	84.02	-7	19.4	3,619.9	36.20	525.00	61	141.8
599.16	5.99	86.90	-6	21.2	3,700.5	37.01	536.69	62	143.6
619.54	6.20	89.85	-5	23	3,782.7	37.83	548.61	63	145.4
640.43	6.40	92.88	-4	24.8	3,866.3	38.66	560.74	64	147.2
661.86	6.62	95.99	-3	26.6	3,951.5	39.52	573.10	65	149
683.82	6.84	99.18	-2	28.4	4,038.3	40.38	585.69	66	150.8
706.34	7.06	102.44	-1	30.2	4,126.8	41.27	598.52	67	152.6
729.41	7.29	105.79	0	32	4,217	42.17	611.60	68	154.4
753.06	7.53	109.22	1	33.8	4,309	43.09	624.95	69	156.2
777.28	7.77	112.73	2	35.6	4,402.9	44.03	638.56	70	158
802.08	8.02	116.33	3	37.4	4,498.7	44.99	652.46	71	159.8
827.48	8.27	120.01	4	39.2	4,596.5	45.97	666.64	72	161.6
853.49	8.53	123.78	5	41	4,696.5	46.97	681.15	73	163.4
880.11	8.80	127.64	6	42.8	4,798.9	47.99	696.00	74	165.2
907.35	9.07	131.60	7	44.6	4,904.1	49.04	711.25	75	167

**This Page Is Left Blank Intentionally**



## **Important!**

### **Product Warranty Information**

The Warranty Registration below is a requirement to print a warranty certificate. You're not mandated to register your products to enjoy the Midea Standard Warranty; however, registration is highly recommended. Registering your warranty within 60 days ensures easy access to support and service when needed.

The design and specifications may change without prior notice in order to enhance the product. For detailed information, please consult your sales agency or the manufacturer. Any updates to the manual will be posted on the service website, so be sure to check for the latest version.

#### **United States**



<https://www.mideacomfort.us/registration.html>

#### **Canada**



<https://www.mideacomfortna.ca/registration.html>