FUJIFILM

DIGITAL CAMERA



FF210002

Owner's Manual



Thank you for your purchase of this product. Be sure that you have read this manual and understood its contents before using the camera. Keep the manual where it will be read by all who use the product.

For the Latest Information

The latest versions of the manuals are available from:

https://fujifilm-dsc.com/en/manual/



The website can be accessed not only from your computer but also from smartphones and tablets. It also contains information on the software license.



For information on firmware updates, visit: https://fujifilm-x.com/support/download/firmware/cameras/

Chapter Index

Menu List	iv
1 Before You Begin	1
2 First Steps	37
3 Basic Photography and Playback	55
4 Movie Recording and Playback	63
5 Taking Photographs	71
6 The Shooting Menus	125
7 Playback and the Playback Menu	213
8 Network/USB Setting Menus	241
9 The Setup Menus	243
10 Shortcuts	285
11 Peripherals and Optional Accessories	307
12 Technical Notes	337

iii



Menu List

Camera menu options are listed below.

Shooting Menus

Adjust settings when shooting photos or movies.



See page 125 for details.

Photo Menus



Name of the still literal state of the photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

I.Q.	IMAGE QUALITY SETTING	
	IMAGE SIZE	126
	IMAGE QUALITY	127
	RAW RECORDING	128
1⁄4	SELECT JPEG/HEIF	129
V4	FILM SIMULATION	130
	MONOCHROMATIC COLOR	132
	GRAIN EFFECT	132
	COLOR CHROME EFFECT	133
	COLOR CHROME FX BLUE	133
	WHITE BALANCE	134
	DYNAMIC RANGE	138
2⁄4	D RANGE PRIORITY	138
2/4	TONE CURVE	139
	COLOR	139
	SHARPNESS	139
	HIGH ISO NR	140

I.Q.	IMAGE QUALITY SETTING	
	CLARITY	140
	LONG EXPOSURE NR	140
	LENS MODULATION OPTIMIZER	141
3/4	COLOR SPACE	141
	PIXEL MAPPING	141
	EDIT/SAVE CUSTOM SETTING	142
	AUTO UPDATE CUSTOM SETTING	142
	CUSTOM MODE SETTING	142
4 ⁄4	MOUNT ADAPTOR SETTING	143

	AF MF	AF/MF SETTING	
		FOCUS AREA	146
		FOCUS MODE	146
		AF MODE	146
	11/2	AF-C CUSTOM SETTINGS	147
	1/3	STORE AF MODE BY ORIENTATION	151
		AF POINT DISPLAY [1]	151
		NUMBER OF FOCUS POINTS	151
		PRE-AF	152
I		♣ AF ILLUMINATOR	152
		TACE/EYE DETECTION SETTING	153
		SUBJECT DETECTION SETTING	155
	2 /3	AF+MF	157
	2 /3	MF ASSIST	158
		FOCUS CHECK	158
		INTERLOCK SPOT AE & FOCUS AREA	159
		INSTANT AF SETTING	159
		DEPTH-OF-FIELD SCALE	159
	3∕₃	RELEASE/FOCUS PRIORITY	160
	J /3	AF RANGE LIMITER	161
		TOUCH SCREEN MODE	162

Ò	SHOOTING SETTING	
	FILTER SETTING	164
	SPORTS FINDER MODE	164
	PRE-SHOT ES 🔁	165
	SELF-TIMER	166
1/3	SAVE SELF-TIMER SETTING	167
	SELF-TIMER LAMP	167
	INTERVAL TIMER SHOOTING	168
	INTERVAL TIMER SHOOTING	169
	EXPOSURE SMOOTHING	103
	AE BKT SETTING	170
	FILM SIMULATION BKT	170
	FOCUS BKT SETTING	170
24	PHOTOMETRY	170
2 / ₃	SHUTTER TYPE	171
	FLICKER REDUCTION	172
	FLICKERLESS S.S. SETTING	172
	IS MODE	173
	ISO	173
3 / ₃	COOLING FAN SETTING	173
	★ WIRELESS COMMUNICATION	174

FLASH SETTING	
FLASH FUNCTION SETTING	175
RED EYE REMOVAL	175
TTL-LOCK MODE	176
LED LIGHT SETTING	176
COMMANDER SETTING	177
CH SETTING	177

ĺ	™ MOVIE SETTING	
	MOVIE MODE	178
	HIGH SPEED REC	178
	MEDIA REC SETTING	178
	S MODE S MODE	178
	S MODE BOOST ■ 15	178
	AUDIO SETTING	179

Movie Menus



Name of the still literal was a second with both the still literal was a second with the second was a second was a second with the second was a second with the second was a second was a second with the second was a second with the second was a second was a second with the second was a second was a second with the second was a second was a second was a second with the second was a second was a second with the second was a second was a second with the second was a second was a second was a second with the second was a second w photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

,22	MOVIE SETTING	
	MOVIE SETTING LIST	182
	SHOOTING MODE	182
	MOVIE MODE	183
1/3	HIGH SPEED REC	184
I/3	MEDIA REC SETTING	185
	HDMI OUTPUT SETTING	189
	FIX MOVIE CROP MAGNIFICATION	190
	F-Log/HLG RECORDING	191
	DATA LEVEL SETTING	192
	₽ PHOTOMETRY	192
	₽ FLICKERLESS S.S. SETTING	192
2/3	₽ IS MODE	193
2/3	№ IS MODE BOOST	193
	₽ ISO	194
	ZEBRA SETTING	194
	ZEBRA LEVEL	194
	MOVIE OPTIMIZED CONTROL 👄 🖢	195
	TALLY LIGHT	195
	COOLING FAN SETTING	196
3/3	₽ EDIT/SAVE CUSTOM SETTING	196
J 3	AUTO UPDATE CUSTOM SETTING	196
	CUSTOM MODE SETTING	196
	★ WIRELESS COMMUNICATION	196

I.Q.	IMAGE QUALITY SETTING	
	FILM SIMULATION	197
	MONOCHROMATIC COLOR	197
	₩ WHITE BALANCE	198
1/2	₽ DYNAMIC RANGE	198
VZ	TONE CURVE	198
	₽ COLOR	198
	SHARPNESS	199
	🗯 HIGH ISO NR	199
2 /2	INTERFRAME NR	199
	PERIPHERAL LIGHT CORRECTION	200
	MOUNT ADAPTOR SETTING	200

AF MF	AF/MF SETTING	
	FOCUS AREA	201
	FOCUS MODE	201
	♣ AF MODE	202
	♣ AF-C CUSTOM SETTING	202
1/2	📤 🕰 AF ILLUMINATOR	203
	♣ 🔁 FACE/EYE DETECTION SETTING	203
	SUBJECT DETECTION SETTING	203
	♣ AF+MF	203
	MF ASSIST	204
	₽ FOCUS CHECK	204
	🗖 🕰 INSTANT AF SETTING	204
2 /2	Ď 🕰 DEPTH-OF-FIELD SCALE	204
	🗗 🕰 AF RANGE LIMITER	204
	TOUCH SCREEN MODE	205
	FOCUS CHECK LOCK	206

AUDIO SETTING	
INTERNAL MIC LEVEL ADJUSTMENT	207
EXTERNAL MIC LEVEL ADJUSTMENT	207
MIC JACK SETTING	208
MIC LEVEL LIMITER	208
WIND FILTER	208
LOW CUT FILTER	208
HEADPHONES VOLUME	208
XLR MIC ADAPTER SETTING	209
TIME CODE SETTING	
TIME CODE DISPLAY	210
START TIME SETTING	210
COUNT UP SETTING	211
DROP FRAME	211
HDMI TIME CODE OUTPUT	212

The Playback Menu

Adjust playback settings.



See page 219 for details.

Þ	PLAY BACK MENU	
	SWITCH SLOT	219
	RAW CONVERSION	220
	HEIF TO JPEG/TIFF CONVERSION	222
1 /3	ERASE	223
I/3	SIMULTANEOUS DELETE	225
	CROP	225
	RESIZE	226
	PROTECT	227

PLAY BACK MENU	
IMAGE ROTATE	228
VOICE MEMO SETTING	229
RATING	230
СОРУ	231
TRANSFER IMAGE TO SMARTPHONE	232
■ WIRELESS COMMUNICATION	234
SLIDE SHOW	234
PHOTOBOOK ASSIST	235
PRINT ORDER (DPOF)	237
instax PRINTER PRINT	238
DISP ASPECT	239
	IMAGE ROTATE VOICE MEMO SETTING RATING COPY TRANSFER IMAGE TO SMARTPHONE THE WIRELESS COMMUNICATION SLIDE SHOW PHOTOBOOK ASSIST PRINT ORDER (DPOF) instax PRINTER PRINT

Setup Menus

Adjust basic camera settings.



See page 243 for details.

۶	USER SETTING	
	FORMAT	244
	♠ AREA SETTING	245
	DATE/TIME	245
1/2	TIME DIFFERENCE	246
V/2	■9 言語/LANG.	247
	MY MENU SETTING	247
	MY MENU SETTING	247
	SENSOR CLEANING	248
	BATTERY AGE	248
2/2	RESET	249
	REGULATORY	249
۶	SOUND SETTING	
	AF BEEP VOL.	250
	SELF-TIMER BEEP VOL.	250
	OPERATION VOL.	251
1/5	MS EF ELECTRONIC SHUTTER VOLUME	251
V2	MS EF ELECTRONIC SHUTTER SOUND	251
	ES ELECTRONIC SHUTTER VOLUME	252
	ES ELECTRONIC SHUTTER SOUND	252
	PLAYBACK VOLUME	252
2/2	4ch AUDIO PLAYBACK	253

۶	SCREEN SETTING	
		254
	EVF BRIGHTNESS	254
	EVF COLOR	254
	EVF COLOR ADJUSTMENT	255
1/4		256
		256
		256
		257
		257
	PREVIEW EXP./WB IN MANUAL MODE	258
	NATURAL LIVE VIEW	258
٠.	F-Log VIEW ASSIST	259
2/4		259
	FRAMING GUIDELINE	260
	AUTOROTATE PB	261
	FOCUS SCALE UNITS	261
	APERTURE UNIT FOR CINEMA LENS	261
	DUAL DISPLAY SETTING	262
	DISP. CUSTOM SETTING	262
3/	LARGE INDICATORS MODE(EVF)	263
3/4	LARGE INDICATORS MODE(LCD)	263
	LARGE INDICATORS DISP. SETTING	264
	INFORMATION CONTRAST ADJ.	264
	LOCATION INFO	265
	SUB MONITOR SETTING	265
4/4	SUB MONITOR BACKGROUND COLOR	266
4/4	🗖 Q MENU BACKGROUND	267
	Renu Background	267

۶	BUTTON/DIAL SETTING	
	FOCUS LEVER SETTING	268
	➡ EDIT/SAVE QUICK MENU	269
	₽ EDIT/SAVE QUICK MENU	269
	FUNCTION (Fn) SETTING	269
1 /3	POWER ZOOM LENS FUNCTION (Fn) SETTING	269
	SELECTOR BUTTON SETTING	269
	COMMAND DIAL SETTING	270
	S.S OPERATION	270
	COMMAND DIAL DIRECTION	270
	SHUTTER AF	271
	SHUTTER AE	271
2 / ₃	SHOOT WITHOUT LENS	271
4/3	SHOOT WITHOUT CARD	272
	LENS ZOOM/FOCUS SETTING	272
	AE/AF-LOCK MODE	274
	AWB-LOCK MODE	274
	► ISO BUTTON SETTING	275
3 /3	TOUCH SCREEN SETTING	276
	LOCK	278

2 POWER MANAGEMENT	
AUTO POWER OFF	279
PERFORMANCE	279
EVF/LCD BOOST SETTING	280
AUTO POWER OFF TEMP.	280
☑ SAVE DATA SETTING	
FRAME NO.	281
EDIT FILE NAME	282
CARD SLOT SETTING	282
SELECT SLOT(SEQUENTIAL)	282
SELECT FOLDER	283
COPYRIGHT INFO	283
DEFAULT CAPTION	284
GEOTAGGING	284

The Network/USB Settings Menu

Adjust camera network and USB settings. For more information, visit:

https://fujifilm-dsc.com/en/manual/x-h2s_connection/

Table of Contents Introduction......ji For the Latest Information.....ii Menu List.....iv Shooting Menus.....iv The Playback Menu.....viii Setup Menus.....ix The Network/USB Settings Menu....x Supplied Accessoriesxxiii About This Manual.....xxiv Symbols and Conventionsxxiv Terminologyxxiv **Before You Begin** Parts of the Camera..... The Serial Number Plate..... The Memory Card Slot Cover (Detachable)......6 The Focus Stick (Focus Lever) 7 The WB Button..... The Mode Dial......8 The DRIVE Button......9 The Indicator Lamp......11 The LCD Monitor......12 Focusing the Viewfinder......13 Camera Displays14 The Flectronic Viewfinder......14 The LCD Monitor......16 Choosing a Display Mode......18 Adjusting Display Brightness......20 The DISP/BACK Button.....21 The Dual Display......22

Customizing the Standard Display	23
Virtual Horizon	
The Secondary LCD Monitor	26
Using the Menus	28
The Menus	28
Selecting a Menu Tab	30
Touch Screen Mode	31
Shooting Touch Controls	
Playback Touch Controls	36
2 First Steps	37
Attaching the Strap	38
Attaching a Lens	39
Inserting the Battery	
Inserting Memory Cards	
Using Two Cards	
Compatible Memory Cards	
Charging the Battery	
Turning the Camera On and Off	
Checking the Battery Level	
Basic Setup	
Choosing a Different Language	
Changing the Time and Date	54
Basic Photography and Playback	55
Taking Photographs (Mode P)	56
Viewing Pictures	59
HDMI Output	60
Deleting Pictures	62
4 Movie Recording and Playback	63
Recording Movies	
Recording Movies	
Adjusting Movie Settings	
Viewing Movies	69

5 Taking Photographs	71
P, S, A, and M Modes	72
Mode P: Program AE	72
Mode S: Shutter-Priority AE	
Mode A: Aperture-Priority AE	76
Mode M: Manual Exposure	78
FILTER	82
Custom Modes	83
Autofocus	91
Focus Mode	
Autofocus Options (AF Mode)	
Focus-Point Selection	96
Manual Focus	
Checking Focus	
Sensitivity	
AUTO	
Metering	
Exposure Compensation	
Focus/Exposure Lock	
Other Controls	
Continuous Shooting (Burst Mode)	
Bracketing	
ISO BKT	
WE WHITE BALANCE BKT	
BKT Bracketing	
HDR	
Panoramas	
Multiple Exposures	123
6 The Shooting Menus	125
IMAGE QUALITY SETTING (Still Photography)	126
IMAGE SIZE	
IMAGE QUALITY	
RAW RECORDING	
SELECT JPEG/HEIF	
FILM SIMULATION	

	MONOCHROMATIC COLOR	132	_
	GRAIN EFFECT		
	COLOR CHROME EFFECT	133	3
	COLOR CHROME FX BLUE	133	3
	WHITE BALANCE	134	ļ
	DYNAMIC RANGE	138	3
	D RANGE PRIORITY	138	3
	TONE CURVE	139)
	COLOR	139)
	SHARPNESS	139)
	HIGH ISO NR	140)
	CLARITY	140)
	LONG EXPOSURE NR	140)
	LENS MODULATION OPTIMIZER	141	
	COLOR SPACE	141	ı
	PIXEL MAPPING	141	ı
	EDIT/SAVE CUSTOM SETTING	142)
	AUTO UPDATE CUSTOM SETTING	142)
	☆ CUSTOM MODE SETTING		
	MOUNT ADAPTOR SETTING	143	3
٩F	/MF SETTING (Still Photography)	146	,
	FOCUS AREA	146	
	FOCUS MODE	146	
	AF MODE		
	AF-C CUSTOM SETTINGS	147	7
	STORE AF MODE BY ORIENTATION		
	AF POINT DISPLAY [1]	151	ı
	NUMBER OF FOCUS POINTS	151	ı
	PRE-AF	152)
	▲ AF ILLUMINATOR		
	PACE/EYE DETECTION SETTING	153	3
	SUBJECT DETECTION SETTING	155)
	AF+MF	157	7
	MF ASSIST	158	3
	FOCUS CHECK	158	3
	INTERLOCK SPOT AE & FOCUS AREA	159)

	159
Ď₽ DEPTH-OF-FIELD SCALE	159
RELEASE/FOCUS PRIORITY	160
♣ AF RANGE LIMITER	
TOUCH SCREEN MODE	162
SHOOTING SETTING (Still Photography)	
FILTER SETTING	
SPORTS FINDER MODE	
PRE-SHOT ES 🏚	165
SELF-TIMER	166
SAVE SELF-TIMER SETTING	167
SELF-TIMER LAMP	
INTERVAL TIMER SHOOTING	
INTERVAL TIMER SHOOTING EXPOSURE SMOOTHING	
AE BKT SETTING	170
FILM SIMULATION BKT	170
FOCUS BKT SETTING	
PHOTOMETRY	170
SHUTTER TYPE	
FLICKER REDUCTION	
FLICKERLESS S.S. SETTING	
IS MODE	
ISO	
COOLING FAN SETTING	
★ WIRELESS COMMUNICATION	
FLASH SETTING (Still Photography)	
FLASH FUNCTION SETTING	
RED EYE REMOVAL	
TTL-LOCK MODE	
LED LIGHT SETTING	
COMMANDER SETTING	
CH SETTING	
MOVIE SETTING (Still Photography)	
MOVIE MODE	
HIGH SPEED REC	
MEDIA REC SETTING	178

S MODE	178
₽ IS MODE BOOST	178
AUDIO SETTING	179
MOVIE SETTING (Movie Recording)	182
MOVIE SETTING LIST	182
SHOOTING MODE	182
MOVIE MODE	183
HIGH SPEED REC	
MEDIA REC SETTING	
HDMI OUTPUT SETTING	189
FIX MOVIE CROP MAGNIFICATION	
F-Log/HLG RECORDING	
DATA LEVEL SETTING	
₽ PHOTOMETRY	192
₽ FLICKERLESS S.S. SETTING	
IS MODE	
₽ ISO	
ZEBRA SETTING	
ZEBRA LEVEL	
MOVIE OPTIMIZED CONTROL	
TALLY LIGHT	
COOLING FAN SETTING	
₽ EDIT/SAVE CUSTOM SETTING	
AUTO UPDATE CUSTOM SETTING	
CUSTOM MODE SETTING	
₩ WIRELESS COMMUNICATION	
IMAGE QUALITY SETTING (Movie Recording)	
FILM SIMULATION	
MONOCHROMATIC COLOR	
WHITE BALANCE	
₽ DYNAMIC RANGE	
TONE CURVE	
COLOR	
SHARPNESS	
₽ HIGH ISO NR	199

	INTERFRAME NR	
	PERIPHERAL LIGHT CORRECTION	200
	▲ MOUNT ADAPTOR SETTING	200
Αl	F/MF SETTING (Movie Recording)	201
	FOCUS AREA	201
	FOCUS MODE	201
	AF MODE	
	AF-C CUSTOM SETTING	202
	♣ AF ILLUMINATOR	
	FACE/EYE DETECTION SETTING	
	SUBJECT DETECTION SETTING	203
	₽ AF+MF	203
	₩ MF ASSIST	
	FOCUS CHECK	
	■ INSTANT AF SETTING	
	□ 😭 DEPTH-OF-FIELD SCALE	
	♣ AF RANGE LIMITER	204
	TOUCH SCREEN MODE	
	FOCUS CHECK LOCK	206
A۱	UDIO SETTING (Movie Recording)	
	INTERNAL MIC LEVEL ADJUSTMENT	207
	EXTERNAL MIC LEVEL ADJUSTMENT	
	MIC JACK SETTING	
	MIC LEVEL LIMITER	208
	WIND FILTER	208
	LOW CUT FILTER	
	HEADPHONES VOLUME	
	XLR MIC ADAPTER SETTING	
ΤI	IME CODE SETTING (Movie Recording)	
	TIME CODE DISPLAY	
	START TIME SETTING	
	COUNT UP SETTING	
	DROP FRAME	
	HDMI TIME CODE OUTPUT	212

Playback and the Playback Menu	213
The Playback Display	214
The DISP/BACK Button	215
Viewing Pictures	217
Playback Zoom	218
Multi-Frame Playback	218
The Playback Menu	219
SWITCH SLOT	219
RAW CONVERSION	
HEIF TO JPEG/TIFF CONVERSION	222
ERASE	
SIMULTANEOUS DELETE	225
CROP	225
RESIZE	226
PROTECT	227
IMAGE ROTATE	
VOICE MEMO SETTING	
RATING	
COPY	
TRANSFER IMAGE TO SMARTPHONE	
★ WIRELESS COMMUNICATION	
SLIDE SHOW	
PHOTOBOOK ASSIST	
PRINT ORDER (DPOF)	
instax PRINTER PRINT	
DISP ASPECT	239
R Network/USB Setting Menus	241
Network/USB Setting Menus	242
9 The Setup Menus	243
USER SETTING	244
FORMAT	
AREA SETTING	
DATE/TIME	
TIME DIFFERENCE	

■9 言語/LANG	247
MY MENU SETTING	247
MY MENU SETTING	
SENSOR CLEANING	248
BATTERY AGE	248
RESET	249
REGULATORY	
SOUND SETTING	
AF BEEP VOL.	250
SELF-TIMER BEEP VOL.	25(
OPERATION VOL	
MS EF ELECTRONIC SHUTTER VOLUME.	251
MS EF ELECTRONIC SHUTTER SOUND	251
ES ELECTRONIC SHUTTER VOLUME	252
ES ELECTRONIC SHUTTER SOUND	252
PLAYBACK VOLUME	252
4ch AUDIO PLAYBACK	253
SCREEN SETTING	254
VIEW MODE SETTING	254
EVF BRIGHTNESS	254
EVF COLOR	254
EVF COLOR ADJUSTMENT	255
LCD BRIGHTNESS	256
LCD COLOR	
LCD COLOR ADJUSTMENT	256
IMAGE DISP	
AUTOROTATE DISPLAYS	
PREVIEW EXP./WB IN MANUAL MODE	
NATURAL LIVE VIEW	
F-Log VIEW ASSIST	
ELECTRONIC LEVEL SETTING	
FRAMING GUIDELINE	260
AUTOROTATE PB	
FOCUS SCALE UNITS	261
APERTURE UNIT FOR CINEMA LENS	261
DUAL DISPLAY SETTING	263

	DISP. CUSTOM SETTING	
	LARGE INDICATORS MODE(EVF)	263
	LARGE INDICATORS MODE(LCD)	263
	LARGE INDICATORS DISP. SETTING	264
	INFORMATION CONTRAST ADJ	264
	LOCATION INFO	265
	SUB MONITOR SETTING	
	SUB MONITOR BACKGROUND COLOR	266
	₫ Q MENU BACKGROUND	267
	₽ Q MENU BACKGROUND	267
31	JTTON/DIAL SETTING	.268
	FOCUS LEVER SETTING	268
	▲ EDIT/SAVE QUICK MENU	
	EDIT/SAVE QUICK MENU	
	FUNCTION (Fn) SETTING	
	POWER ZOOM LENS FUNCTION (Fn) SETTING	
	SELECTOR BUTTON SETTING	
	COMMAND DIAL SETTING	
	S.S OPERATION	
	COMMAND DIAL DIRECTION	
	SHUTTER AF	
	SHUTTER AE	
	SHOOT WITHOUT LENS	
	SHOOT WITHOUT CARD	
	LENS ZOOM/FOCUS SETTING	
	AE/AF-LOCK MODE	
	AWB-LOCK MODE	
	▶ ISO BUTTON SETTING	
	TOUCH SCREEN SETTING	276
	LOCK	
P	OWER MANAGEMENT	
	AUTO POWER OFF	
	PERFORMANCE	
	EVF/LCD BOOST SETTING	
	AUTO POWER OFF TEMP.	280

	SAVE DATA SETTING	281
	FRAME NO	281
	EDIT FILE NAME	282
	CARD SLOT SETTING	282
	SELECT SLOT(SEQUENTIAL)	282
	SELECT FOLDER	283
	COPYRIGHT INFO	283
	DEFAULT CAPTION	284
	GEOTAGGING	284
1	Shortcuts	285
	Shortcut Options	286
	MY MENU	
	MY MENU SETTING	287
	The Quick Menu	
	The Quick Menu Display	
	Viewing and Changing Settings	
	Editing the Quick Menu	
	Function Controls	
	The Function Buttons	
	Touch-Function Gestures	
	Lens Function Buttons	304
1	Peripherals and Optional Accessories	307
	Lenses	308
	Lens Parts	308
	Lens Care	309
	Removing Lens Caps	309
	Attaching Lens Hoods	
	Lenses with Aperture Rings	311
	Lenses with No Aperture Rings	312
	Lenses with O.I.S. Switches	312
	Manual Focus Lenses	313
	Power Zoom Lenses	314

	315
Flash Settings	316
EF-X8	317
SYNC TERMINAL	319
SHOE MOUNT FLASH	320
COMMANDER(OPTICAL)	323
Vertical Battery Grips	327
Attaching the Vertical Battery Grip	328
Inserting and Removing Batteries	329
Charging the Batteries	331
File Transmitters	332
Attaching the File Transmitter	333
Inserting and Removing Batteries	333
Charging the Batteries	333
Cooling Fans	334
Attaching a Cooling Fan	334
Using the Fan	336
1) Technical Notes	337
Accessories from Fujifilm	338
Software for Use with Your Camera	
Smartphone Apps	
RAW FILE CONVERTER EX powered by SILKYPIX	
Capture One Express for Fujifilm	
	342
Capture One for Fujifilm	
Capture One for FujifilmFUJIFILM Tether Shooting Plug-in (Exclusively for L	ightroom) 342
Capture One for FujifilmFUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire	ightroom) 342 342
Capture One for Fujifilm	ightroom) 342 342 343
Capture One for FujifilmFUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire	ightroom) 342 342 343 344
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care	ightroom) 342 343 344 355
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care Cleaning the Image Sensor	ightroom)342 343 344 355 356
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care Cleaning the Image Sensor Firmware Updates	ightroom)342 343 344 355 356
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care Cleaning the Image Sensor Firmware Updates Checking the Firmware Version	ightroom)342 343 344 355 356 357
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care Cleaning the Image Sensor Firmware Updates Checking the Firmware Version Troubleshooting	ightroom)342 343 355 356 357 358
Capture One for Fujifilm FUJIFILM Tether Shooting Plug-in (Exclusively for L FUJIFILM X Acquire FUJIFILM X RAW STUDIO For Your Safety Product Care Cleaning the Image Sensor Firmware Updates Checking the Firmware Version	ightroom)342 343 355 356 357 358 358

Supplied Accessories

The following are included with the camera:

NP-W235 rechargeable battery



Tor reasons of safety, the battery is not charged at shipment. The camera will not function if the battery is not charged; be sure to charge the battery before use (## 46).

- AC-5VJ AC power adapter
- Plug adapter
- USB cable (approx. 0.6 m/2 ft.)
- Body cap (comes attached to camera)
- Shoulder strap
- Cable protector
- Hot shoe cover (comes attached to hot shoe)
- Sync terminal cap (comes attached to camera)
- File transmitter/vertical battery grip connector cover (comes attached to camera)
- Cooling fan connector cover (comes attached to camera)
- Basic Manual



- The plug adapter supplied varies with the country or region.
 - For information on compatible computer software, see "Software for Use with Your Camera" (341).

About This Manual

This manual contains instructions for your FUJIFILM X-H2S digital camera. Be sure you have read and understood its contents before proceeding.

Symbols and Conventions

The following symbols are used in this manual:



Information that should be read to prevent damage to the product.



Additional information that may be helpful when using the product.



Pages on which related information may be found.


Menus and other text in the displays are shown in **bold**. Illustrations are for explanatory purposes only; drawings may be simplified, while photographs are not necessarily taken with the model of camera described in this manual.

Terminology

The optional SD, SDHC, SDXC, and Type B CFexpress memory cards the camera uses to store pictures are referred to as "memory cards". The electronic viewfinder may be referred to as the "EVF" and the LCD monitor as the "LCD". Smartphones and tablets are referred to as "smartphones".




Parts of the Camera




1 ISO button105, 295	(19) Lens relea
② WB button7, 295	20 Fn2 butto
③ Fn1 button295	21) AF-assist
4 Secondary LCD monitor26	Self-timer
5 <i>Microphone</i>	Tally light
6 Hot shoe316	22 Front com
7 Diopter adjustment control13	23 ON/OFF SV
8 Dial lock release56, 64	24 Shutter bu
9 Mode dial8	25 ⊙ (movie
10 Strap eyelet38	26 Hot shoe
1 HDMI connector cover	27 Body cap.
(12) Microphone jack cover	28 HDMI cor
13 Headphone jack cover	29 Micropho
14 Speaker	30 Headpho
15) USB connector cover	31) USB conn
16 Sync terminal319	(32) Hole to sc
17) Fn3 button295	33) Hole to sc
18 Lens signal contacts	-
- "	

9	Lens release button	39
0	Fn2 button	295
1	AF-assist illuminator	152
	Self-timer lamp	166
	Tally light	195
	Front command dial	. 10, 270
3	ON/OFF switch	50
4)	Shutter button	58
5	● (movie recording) button	. 64, 295
	Hot shoe cover	
7	Body cap	39
8	HDMI connector (Type A)	60
9	Microphone jack (ø3.5mm)	67
0	Headphone jack (ø3.5mm)	208
1	USB connector (Type-C)	46
2	Hole to screw USB cable	
3	Hole to screw cable protector	
-	,	



34)	DRIVE button9
	₩ (delete) button62
35	▶ (playback) button59
	Eye sensor19
	Electronic viewfinder (EVF)
	14, 18, 20, 31
38	Eye cup (lockable)13
	VIEW MODE button18
40	Secondary monitor backlight button27
41)	Focus stick (focus lever)7, 97, 268
42	AFON button110, 295
43	Rear command dial 10, 217, 270
44)	Indicator lamp 11, 195
	Tally light195
45	Remote release connector cover81
46	Memory card slot cover latch42

47)	Memory card slot cover (detachable)
	6, 42
48	Battery-chamber cover latch40
49	Battery-chamber cover40
50	Selector buttons7
	MENU/OK button28
<u>52</u>	DISP (display)/ BACK button21, 215
	❸ (Bluetooth) button
53	Q (quick menu) button289
<u>54</u>)	AEL (exposure lock) button 110, 295
55)	Tripod mount
56	LCD monitor12, 16, 18
	Touch screen31, 162, 205
57)	File transmitter/vertical battery grip
	connector cover328




_	
	Remote release connector (@2.5mm)81
59	Memory card slot 2
	(for SD memory cards)42
60	Serial number plate6
61	Memory card slot 1
	(for Type B CFexpress cards)42
62	Battery latch41

63 Battery chamber	40
64 Cooling fan connector cover	334
65 Cooling fan connector	334
66 Hole to screw cooling fan	334
67 File transmitter/vertical battery grip	
connector	328

The Cable Protector-

Attach the protector as shown to prevent accidental disconnection.

- ① Slide the protector over the USB connector cover so that the cover passes through the slot in the protector.
- (2) Tighten the lock screw.
- (3) Connect the cable and pass it through the protector as shown.



The Serial Number Plate


Do not remove the serial number plate, which provides the CMIIT ID, serial number, and other important information.



Serial number plate


The Memory Card Slot Cover (Detachable)

The memory card slot cover can be removed by lowering the interior latch. Remove the cover for ease of access when a camera rig is attached or in other situations that make it difficult to open or close the cover.



The Focus Stick (Focus Lever)

Tilt or press the focus stick to select the focus area. The focus stick can also be used to navigate the menus.



To choose the role played by the focus stick, press and hold the center of the stick or use BUTTON/DIAL SETTING > FOCUS LEVER SETTING.

The Selector

Press the selector up (\triangle), right (\triangleright), down $(\mathbf{\nabla})$, or left $(\mathbf{\triangleleft})$ to highlight items. The up, right, down, and left buttons also double as function buttons Fn4 through Fn7.



The WB Button

Press the WB button to access white balance settings.



The Mode Dial


To select a shooting mode, rotate the dial until the icon for the desired mode aligns with the index.



Mode	Description	
1 P (PROGRAM AE)	Aperture and shutter speed can be adjusted using program shift.	72
2 S (SHUTTER PRIORITY AE)	Select for full control over camera	74
A (APERTURE PRIORITY AE)	settings, including aperture (M and A)	76
M (MANUAL)	and/or shutter speed (M and S).	78
③ C1/C2/C3/C4/C5/C6/C7	Take pictures using previously-stored	83
(CUSTOM 1/2/3/4/5/6/7)	settings.	0.0
4 FILTER (FILTER)	Take photos with filter effects.	82
(MOVIE)	Record movies.	64

The DRIVE Button

Pressing the **DRIVE** button displays drivemode menu, where you can choose from the following the drive modes.



Mode			Mode	
	Ò	Single frame	WB	WHITE BALANCE BKT
	Ð	High-speed burst	BKT	Bracketing
	HCROP	High-speed burst (1.25× crop)	HDR	HDR
	وق	Low-speed burst		Panorama
	<u>ISO</u>	ISO BKT		Multiple Exposure

The Command Dials

The rear and front command dials are used for the operations below.

		Front command dial	Rear command dial
Shooting ¹	P	Choose the desired combination of shutter speed and aperture (program shift).	Adjust exposure compensa- tion.
	S	Choose a shutter speed.	
	A	Adjust aperture. 2	
	М	Choose a shutter speed.	Adjust aperture. 2
	FILTER	Program shift.	Adjust exposure compensation.
Menus		Select menu tabs or page through menus.	Highlight menu items.
Q Menu		Select items in the quick menu.	Adjust settings in the quick menu.
Playback		View other pictures.	Zoom in or out (full-frame playback).Zoom in or out (multi-frame playback).

- 1 Can be changed using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.
- 2 Applies if the lens has no aperture ring or if an aperture ring with an "A" position is in the A position.



The rotation direction for the command dials can be selected using BUTTON/DIAL SETTING > COMMAND DIAL DIRECTION

The Indicator Lamp

Camera status is shown by the indicator lamp.



Indicator lamp	Camera status	
Glows green	Focus locked.	
Blinks green	Focus or slow shutter speed warning. Pictures can be taken.	
	• Camera on: Recording pictures, or picture displayed for con-	
Blinks green and	firmation after being taken with option other than OFF	
3	selected for SCREEN SETTING > IMAGE DISP. (ad-	
orange	ditional pictures can be taken).	
	• Camera off: Uploading pictures to a smartphone or tablet.*	
Glows orange	Recording pictures. No additional pictures can be taken at	
Glows oralige	this time.	
Blinks orange	Flash charging; flash will not fire when picture is taken.	
Blinks red	Lens or memory error.	


^{*} Displayed only if pictures are selected for upload.




- Warnings may also appear in the display.
 - The indicator lamp remains off while your eye is to the viewfinder.
 - The **MOVIE SETTING** > **TALLY LIGHT** option can be used to choose the lamp (indicator or AF-assist) that lights during movie recording and whether the lamp blinks or remains steady.

The LCD Monitor

You can adjust the angle of the LCD monitor when framing shots, but be careful not to trap your fingers or other objects.






- ① Do not apply excessive force to the hinge when rotating the LCD monitor, as this could damage the hinge.
 - Be careful that the corners of the monitor do not contact the camera body, as this could leave marks.
- The LCD monitor also functions as a touch screen that can be used for:
 - Touch photography (32)
 - Focus area selection (■ 31)
 - Function selection (34)
 - Movie optimized control → (□ 33)
 - Playback (III 36)

The Eye Cup

To remove the eye cup, hold the buttons on either side and slide eye cup up.



Focusing the Viewfinder

If the indicators displayed in the viewfinder are blurred, put your eye to the viewfinder and rotate the diopter adjustment control until the display is in sharp focus.

To focus the viewfinder:

- (1) Lift the diopter adjustment control.
- (2) Rotate the control to adjust viewfinder focus.
- (3) Return the control to its original position and lock it in place.







Lift the control before use. Failure to observe this precaution could cause product malfunction.

Camera Displays

This section lists the indicators that may be displayed during shooting.

For illustrative purposes, displays are shown with all indicators lit.


The Electronic Viewfinder 5 **12 13** 5 PXY V FLog 1h12m36s 📭 🗵 9999 🕮 N HEF ஃங்ESட்டை ≱ ∰ Vario ProResHQ 🚌 **i** 100 12/31/2022 12:10 AMC (55) 54) 53) AREA (52) (51)-(49) -30 800ST 48 (47)->TC:00:00:00:00 38 37 36 MF () AF-S 49 49 49

1	<i>Crop factor190</i>	30	Boost mode	2	280
2	IS mode ² 173	31)	Power supply		.48
3	Flash (TTL) mode320	32	Histogram		.24
4	Flash compensation320	33	Battery level		.51
(5)	Self-timer indicator166		Sensitivity		
6	Continuous mode111	35	Exposure compensation	i	108
7	Shutter type171	36	Aperture	73, 76,	78
8	AF+MF indicator ² 157	37)	Distance indicator ²	i	102
9	Bluetooth ON/OFF	38	Shutter speed	73, 74,	78
10	White balance 134	39	TTL lock	176, 3	300
11	AWB lock274	40	AE lock	110, 2	274
12	Film simulation130	41)	Metering	i	107
13	F-Log/HLG recording191	42	Shooting mode		.72
14)	<i>Dynamic range</i> 138		Focus mode ²		
15)	D-range priority138	44)	Focus indicator ²		.93
16	Movie mode 64, 183	45	Manual focus indicator ²	92, 1	100
17)	High-speed recording indicator 184	46	AF lock	110, 2	274
18)	Recording time available/	47)	Time code		210
	elapsed recording time64	48	Microphone input channel	181, 2	209
19	<i>Card slot options</i> 44, 282	49	Recording level ²		207
20	Number of available frames 1369		Exposure indicator		
21)	Image size126	(51)	Virtual horizon		.25
22	File format	(52)	Focus frame	96, 1	109
23	Image quality127	53	Image transfer status		
24)	HEIF format129	54)	Location data download status.	2	284
25	Date and time52, 54, 245	(55)	Movie compression	i	186
26	Touch screen mode31, 162	56	Depth-of-field preview	77, 1	102
27)	Cooling fan settings173, 196	57	Proxy setting (ProRes only)	i	188
28	Temperature warning 43, 368		Focus check		
29	Control lock ³ 278				

¹ Shows "9999" if there is space for over 9999 frames.

² Not displayed when **ON** is selected for **☑ SCREEN SET-UP** > **LARGE INDICATORS MODE(EVF)**.

³ Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.



(1)	<i>Crop factor190</i>	(31)	Touch zoom ³	35
(2)	Location data download status284	\sim	Temperature warning	
(3)	Focus check		Control lock ⁴	
(4)	Depth-of-field preview77, 102	\sim	Battery level	
(5)	Proxy setting (ProRes only)188		Power supply	
(6)	Movie compression186	\sim	Sensitivity	
(7)	Image transfer status		Histogram	
(8)	Bluetooth ON/OFF	38)	Exposure compensation	108
(9)	Movie mode 64, 183		Distance indicator ²	
(10)	High-speed recording indicator184	$\overline{}$	Aperture	
\sim	Focus frame		Time code	
12	Recording time available/	42	Shutter speed	73, 74, 78
	elapsed recording time64	43	TTL lock	176, 300
13	Date and time52, 54, 245		AE lock	
14)	<i>Card slot options44, 282</i>	45	Metering	107
	Number of available frames 1		Shooting mode	72
16	Image size126	47)	Focus mode ²	92
17)	File format186	48	Focus indicator ²	93
18	Image quality127	49	Manual focus indicator ²	92, 100
19	HEIF format129	50	AF lock	110, 274
20	Cooling fan settings173, 196	51)	Microphone input channel	181, 209
21)	Touch screen mode ³ 31, 162	(52)	AF+MF indicator ²	157
22	AWB lock274	(53)	Shutter type	171
23)	White balance134	(54)	Recording level ²	207
24)	Film simulation130	(55)	Continuous mode	111
25)	F-Log/HLG recording191	(56)	Self-timer indicator	166
26	<i>Dynamic range</i> 138	(57)	Exposure indicator	78, 108
27)	<i>D-range priority</i> 138	(58)	Flash (TTL) mode	320
(28)	Movie optimized control ³ 33	(59)	Flash compensation	320
	Virtual horizon25	60	IS mode ²	173
(30)	Danet manda 200			

- 1 Shows "9999" if there is space for over 9999 frames.
- 2 Not displayed when **ON** is selected for **☑ SCREEN SET-UP** > **LARGE INDICATORS MODE(LCD)**.
- 3 Camera functions can also be accessed via touch controls.
- 4 Displayed when controls have been locked by pressing and holding the **MENU/OK** button. Control lock can be ended by pressing and holding the **MENU/OK** button again.

Choosing a Display Mode

Press the **VIEW MODE** button to cycle through the following display modes. You can choose separate display modes for shooting and playback.



SHOOTING

Option	Description
SERSOR EYE SENSOR	Putting your eye to the viewfinder turns the viewfinder on and the LCD monitor off; taking your eye away turns the viewfinder off and LCD monitor on.
LCD ONLY	LCD monitor on, viewfinder off.
EVF ONLY	Viewfinder on, LCD monitor off.
EVF ONLY + SERICION	Putting your eye to the viewfinder turns the viewfinder on; taking it away turns the viewfinder off. The LCD monitor remains off.
STEER EYE SENSOR + LCD IMAGE DISP.	Putting your eye to the viewfinder during shooting turns the viewfinder on, but the LCD monitor is used for the display of images once you remove your eye from the viewfinder after shooting. The options selected for E SCREEN SET-UP > IMAGE DISP. apply to display in the LCD monitor.

PLAYBACK


Option	Description
SENSOR EYE SENSOR	Putting your eye to the viewfinder turns the viewfinder on and the LCD monitor off; taking your eye away turns the viewfinder off and LCD monitor on.
LCD ONLY	LCD monitor on, viewfinder off.
EVF ONLY	Viewfinder on, LCD monitor off.



- ◆ Use **SCREEN SET-UP** > **VIEW MODE SETTING** in the setup menu to choose a display mode for the EVF and LCD monitor.
 - EVF/LCD SWITCH can be assigned to a function button and the button then used to switch between the EVF ONLY and LCD ONLY displays.

The Eye Sensor-

The eye sensor may respond to objects other than your eye or to light shining directly on the sensor.



Adjusting Display Brightness

The brightness and saturation of the viewfinder and LCD monitor can be adjusted using the items in the SCREEN SET-UP menu. Choose EVF BRIGHTNESS or EVF COLOR to adjust viewfinder brightness or saturation, LCD BRIGHTNESS or LCD COLOR to do the same for the LCD monitor.

Display Rotation

When **ON** is selected for **SCREEN SET-UP** > **AUTOROTATE DISPLAYS**, the indicators in the viewfinder and LCD monitor automatically rotate to match camera orientation.

The DISP/BACK Button


The DISP/BACK button controls the display of indicators in the viewfinder and LCD monitor.



Noticators for the EVF and LCD must be selected separately. To choose the EVF display, place your eye to the viewfinder while using the DISP/BACK button.




Viewfinder



(manual focus mode only)

LCD Monitor



The Dual Display

The dual display consists of a large full-frame window and a smaller close-up of the focus area.

Customizing the Standard Display

To choose the items shown in the standard indicator display:

- Display standard indicators.
 Use the DISP/BACK button to display standard indicators.
- 2 Select DISP. CUSTOM SETTING. Select SCREEN SET-UP > DISP. CUSTOM SETTING in the setup menu.
- 3 Choose items.
 Highlight items and press MENU/OK to select or deselect.

ltem	Default		ltem	Default	
item	STILL	MOVIE	item	STILL	MOVIE
FRAMING GUIDELINE			DUAL IS MODE	✓	✓
FOCUS FRAME	✓	V	TOUCH SCREEN MODE	V	✓
AF DISTANCE INDICATOR			WHITE BALANCE	V	✓
MF DISTANCE INDICATOR	✓	V	FILM SIMULATION	V	✓
HISTOGRAM			DYNAMIC RANGE	V	✓
LIVE VIEW HIGHLIGHT ALERT			BOOST MODE	V	✓
SHOOTING MODE	✓	V	COOLING FAN SETTING	V	✓
APERTURE/S-SPEED/ISO	✓	V	FRAMES REMAINING	V	-
INFORMATION BACKGROUND	✓	✓	IMAGE SIZE/QUALITY	V	-
Expo. Comp. (Digit)			MOVIE MODE & REC. TIME	-	✓
Expo. Comp. (Scale)	✓	✓	IMAGE TRANSFER ORDER	V	✓
FOCUS MODE	✓	✓	MIC LEVEL	-	✓
PHOTOMETRY	✓	✓	GUIDANCE MESSAGE	V	✓
SHUTTER TYPE	✓	-	BATTERY LEVEL	V	✓
FLASH	✓	-	FRAMING OUTLINE		
CONTINUOUS MODE	✓	-			•


- 4 Press DISP/BACK to save changes.
- 5 Press DISP/BACK as needed to exit the menus and return to the shooting display.

-Framing Outline

Enable **FRAMING OUTLINE** to make the borders of the frame easier to see against dark backgrounds.

-Histograms -

Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.




- **Optimal exposure**: Pixels are distributed in an even curve throughout the tone range.
- **Overexposed**: Pixels are clustered on the right side of the graph.
- **Underexposed**: Pixels are clustered on the left side of the graph.

To view separate RGB histograms and a display showing areas of the frame that will be overexposed at current settings superimposed on the view through the lens, press the function button to which **HISTOGRAM** is assigned (**269**, 295).


- 1 Overexposed areas blink
- RGB histograms






Virtual Horizon

Check whether the camera is level. The display type can be chosen using SCREEN SET-UP > ELECTRONIC LEVEL SETTING. Use the virtual horizon to level the camera when mounting it on a tripod or the like.



- OFF: The virtual horizon is not displayed.
- 2D: A white line shows the amount the camera is tilted left or right. The line turns green when the camera is level. The line may vanish if the camera is tilted forward or back.
- **3D**: The display shows whether the camera is tilted left or right and forward or back.



The Secondary LCD Monitor

Among the settings that can be viewed in the secondary LCD monitor are shutter speed, aperture, and ISO sensitivity. Different settings are displayed in still photography and movie modes.




Secondary LCD monitor

Default Settings

By default, the secondary LCD monitor displays the settings listed below.

The settings displayed can be selected using SCREEN SET-UP > SUB MONITOR SETTING.

Still Photography Mode



Default		
① SHUTTER SPEED	(5) FILM SIMULATION	
② APERTURE	WHITE BALANCE	
③ EXPO. COMP.	① IMAGE SIZE	
4 ISO	SHOOTING MODE	

Movie Mode



Default	
① MOVIE MODE	(5) FILM SIMULATION
② REC. TIME	WHITE BALANCE
③ EXPO. COMP.	CARD SLOT OPTIONS
(4) ISO	BATTERY LEVEL

The Secondary Monitor Backlight Button

To turn on the secondary LCD monitor backlight when you find the secondary LCD monitor too dark to read, press the secondary monitor backlight button. Press the button again to turn the backlight off.




-Background Color-

The background color (black or white) for the secondary LCD monitor can be selected using the **SCREEN SET-UP** > **SUB MONITOR BACKGROUND COLOR** option in the **2** (setup) menu. Note that the background is displayed in white whenever the secondary LCD monitor backlight is on.

Using the Menus

To display the menus, press MENU/OK.



The Menus

Different menus are displayed during still photography, movie recording, and playback.

Still Photography (All Modes Except 🕿)

Pressing **MENU/OK** during still photography displays the photomenus.








In modes C1 through C7, photo menus will be displayed if C STILL is selected for the chosen bank using either MIMAGE QUALITY SETTING > M CUSTOM MODE SETTING in the photo menus or MOVIE SETTING > M CUSTOM MODE SETTING in the movie menus (■ 83).

Movie Recording (♣2/Movie Mode)

Pressing MENU/OK in movie mode displays the movie menus.







In modes C1 through C7, photo menus will be displayed if MOVIE is selected for the chosen bank using either IMAGE QUALITY SETTING > → CUSTOM MODE SETTING in the photo menus or MOVIE SETTING > → CUSTOM MODE SETTING in the movie menus (IMAGE)

Playback

Pressing MENU/OK during playback displays the playback menu.







Selecting a Menu Tab

To navigate the menus:

1 Press MENU/OK to display the menus.





Press the focus stick (focus lever) left to highlight the tab for the current menu.



- 3 Press the focus stick up or down to highlight the tab containing the desired item.
- 4 Press the focus stick right to place the cursor in the menu.
- Use the front command dial to select menu tabs or page through menus and the rear command dial to highlight menu items.




Touch Screen Mode

The LCD monitor also functions as a touch screen.


Shooting Touch Controls

To enable touch controls, select ON for BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > **★** TOUCH SCREEN SETTING.



EVF

The LCD monitor can be used to select the focus area while pictures are being framed in the electronic viewfinder (EVF). Use BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > EVE TOUCH SCREEN AREA SETTINGS to choose the area of the monitor employed for touch controls.



- FACE/EYE DETECTION SETTING, you can choose the face used for focus
 - You can choose the type of subject on which the camera preferential-Iv focuses when **SUBJECT DETECTION ON** is selected for **MAF/MF** SETTING > SUBJECT DETECTION SETTING.

LCD Monitor

The operation performed can be selected by tapping the touch screen mode indicator in the display. Touch controls can be used for the following operations:




Mode	Description
TOUCH SHOOTING	Tap your subject in the display to focus and release the shutter. In burst mode, pictures will be taken while you keep your finger on the display.
AF AF OFF	 If SINGLE AF is selected for focus mode, the camera will focus when you tap your subject in the display. Focus locks at the current distance until you tap the AF OFF icon. If CONTINUOUS AF is selected for focus mode, the camera will initiate focus when you tap your subject in the display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the AF OFF icon. When MANUAL FOCUS is selected for focus mode, you can tap the display to focus on the selected subject using autofocus.
AREA AREA	Tap to select a point for focus or zoom. The focus frame will move to the selected point.
OFF OFF	Touch controls disabled.

- ① Different touch controls are used during focus zoom (■ 163).
- To disable touch controls and hide the touch screen mode indicator, select OFF for BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > ★ TOUCH SCREEN SETTING.
 - Touch control settings can be adjusted using MAF/MF SETTING > TOUCH SCREEN MODE. For information on the touch controls available during movie recording, see "Movie Recording (MATOUCH SCREEN MODE; 205)".

MOVIE OPTIMIZED CONTROL

Selecting ON for □ MOVIE SETTING > MOVIE OPTIMIZED CONTROL - or tapping the movie-optimized mode button in the shooting display optimizes the command dials and touch controls for movie recording. This can be used to prevent camera sounds being recorded with movie footage.



Movie-optimized mode button

- SHUTTER SPEED
- APERTURE
- FXPOSURE COMPENSATION
- ISO
- INTERNAL MIC LEVEL ADJUSTMENT/EXTERNAL MIC LEVEL ADJUSTMENT
- WIND FILTER
- HEADPHONES VOLUME
- FII M SIMULATION
- WHITE BALANCE
- IS MODE
 - IS MODE BOOST
 - FOCUS MODE




- Enabling movie-optimized controls disables the aperture ring.
 - When movie-optimized control is enabled, the movie-optimized mode button can be used to change shooting settings or disable movie-optimized control.

Touch Function

Functions can be assigned to the following flick gestures in much the same way as function buttons (295):

• Flick up: T-Fn1 • Flick left: T-Fn2 • Flick right: T-Fn3 • Flick down: T-Fn4





 In some cases, touch-function flick gestures display a menu; tap to select the desired option.




• Touch-function gestures are disabled by default. To enable touch-function gestures, select **ON** for **☑ BUTTON/DIAL SETTING** > TOUCH SCREEN SETTING > IIII TOUCH FUNCTION.

Touch Zoom

If the lens supports touch zoom, you can zoom in and out by touching the display. Tap the touch zoom button in the display to enable touch zoom.

Touch zoom is controlled using the buttons in the display.



Button	Description	
Touch zoom	Enable touch zoom.	
Zoom in	Zoom in or out. Touch and hold to zoom in or out at a constant	
w Zoom out	speed.	
Rocker switch	Swipe to choose a zoom position. Touch and hold to zoom in or out at a speed corresponding where you put your finger.	
× Disable	Disable touch zoom.	

Playback Touch Controls

When ON is selected for BUTTON/DIAL SETTING > TOUCH **SCREEN SETTING** > **TOUCH SCREEN SETTING**, touch controls can be used for the following playback operations:

• Swipe: Swipe a finger across the display to view other images.



• Pinch-out: Place two fingers on the display and spread them apart to zoom in.



• Pinch-in: Place two fingers on the display and slide them together to zoom out.



Pictures can be zoomed out until the entire image is visible but no further

 Double-tap: Tap the display twice to zoom in on the focus point.



• Drag: View other areas of the image during playback zoom.









Attaching the Strap

Attach the strap.

Attach the strap to the two strap eyelets as shown below.





① To avoid dropping the camera, be sure the strap is correctly secured.

Attaching a Lens

The camera can be used with lenses for the FUJIFILM X-mount.

Remove the body cap from the camera and the rear cap from the lens. Place the lens on mount, keeping the marks on the lens and camera aligned (1), and then rotate the lens until it clicks into place ((2)).



- When attaching lenses, ensure that dust or other foreign matter does not enter the camera
 - Be careful not to touch the camera's internal parts.
 - Rotate the lens until it clicks securely into place.
 - Do not press the lens release button while attaching the lens.

-Removing Lenses-

To remove the lens, turn the camera off, then press the lens release button (1) and rotate the lens as shown ((2)).



To prevent dust accumulating on the lens or inside the camera, replace the lens caps and camera body cap when the lens is not attached



Lenses and Other Optional Accessories

The camera can be used with lenses and accessories for the FUJIFILM X-mount.

- ① Observe the following precautions when attaching or removing (exchanging) lenses.
 - Check that the lenses are free of dust and other foreign matter.
 - Do not change lenses in direct sunlight or under another bright light source. Light focused into the interior of the camera could cause it to malfunction.
 - Attach the lens caps before exchanging lenses.
 - See the manual provided with the lens for information on use.

Inserting the Battery

Insert the battery in the camera as described below.

1 Open the battery-chamber cover. Slide the battery-chamber cover latch as shown and open the bat-

tery-chamber cover.

- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could damage image files or memory cards
 - Do not use excessive force when handling the battery-chamber cover.






Insert the battery as shown.

- Insert the battery in the orientation shown. Do not use force or attempt to insert the battery upside down or backwards.
 - Confirm that the battery is securely latched.



3 Close the battery-chamber cover. Close and latch the cover.




 If the cover does not close, check that the battery is in the correct orientation. Do not attempt to force the cover shut.



Removing the Battery-

Before removing the battery, turn the camera off and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown



The battery may become hot when used in high-temperature environments. Observe caution when removing the battery.

Inserting Memory Cards

Pictures are stored on memory cards (sold separately).

- The camera is equipped with two memory card slots. Use Slot 1 with CFexpress cards and Slot 2 with SD, SDHC, or SDXC cards.
 - 1 Open the memory card slot cover.
 Unlatch and open the cover.




- ① Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.
- 2 Insert the memory card. Holding the card in the orientation shown, slide it in until it clicks into place at the back of the slot. Close and latch the memory card slot cover.



Be sure card is in the correct orientation; do not insert at an angle or use force.

Removing Memory Cards-

Turn the camera off and open the memory card slot cover. Eject the card by pressing it in with a finger and then slowly releasing it; the card can then be removed by hand.





- Press the center of the card.
 - Suddenly removing your finger from the card could cause the card to fall from the slot. Remove your finger slowly.
 - If the camera displays a ! icon, the memory card may be hot to the touch. Wait for the card to cool before removing it.

Using Two Cards


The camera can be used with two cards, one in each of its two slots. At default settings, photos are saved to the card in the second slot only when the card in the first slot is full. This can be changed using SAVE DATA SET-UP > CARD SLOT SETTING.

Option	Description	Display
SEQUENTIAL (default)	The card in the second slot is used only when the card in the first slot is full. If the second slot is selected for SAVE DATA SET-UP > SELECT SLOT(SEQUENTIAL) , recording will start on the card in the second slot and switch to the first slot when the card in the second slot is full.	12
BACKUP	Each picture is recorded twice, once to each card.	1 2
SEPARATE	RAW pictures are recorded to the card in the first slot and JPEG or HEIF pictures to the card in the second slot. This setting takes effect only when FINE + RAW or NORMAL + RAW is selected for IMAGE QUALITY SETTING > IMAGE QUALITY.	RAW+JPEG RAW+HEIF


The card used to store movies can be selected using **MOVIE SETTING** > **MEDIA REC SETTING**.

Compatible Memory Cards

- The camera can be used with SD, SDHC, SDXC, and CFexpress Type B memory cards. Both the UHS-I and UHS-II bus interfaces are supported.
- CFexpress or UHS-II memory cards are recommended for highspeed burst photography.
- The types of memory cards suitable for movie recording vary with the settings selected (1994).
- A list of supported memory cards is available on the Fujifilm website. For details, visit:
 - https://fujifilm-x.com/support/compatibility/cameras/.



 Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.




- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than memory cards may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels or other objects to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of memory card.
- Formatting a memory card in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals. Renaming the files on the camera can cause problems during playback.


Charging the Battery

For reasons of safety, the battery is not charged at shipment. The camera will not function if the battery is not charged; be sure to charge the battery before use. Before charging the battery, turn the camera off.


- An NP-W235 rechargeable battery is supplied with the camera.
 - Charging takes about 180 minutes.
- 1 Attach the plug adapter to the AC power adapter.

Attach the plug adapter as shown, making sure that it is fully inserted and clicks into place on the AC power adapter terminals.






• The shape of the plug adapter varies with the country of sale.



Charge the battery.

Connect the camera to the supplied AC power adapter using the supplied USB cable. Then plug the AC power adapter into an indoor power outlet.



- Connect the cable to the camera's USB connector (Type-C).
 - Be sure the connectors are fully inserted.

-Charge Status-

The indicator lamp shows battery charge status as follows:

Indicator lamp	Battery status
On	Battery charging
Off	Charging complete
Blinks	Charging error





- The supplied AC power adapter is compatible with power supplies of 100 to 240 V (a plug adapter may be needed for overseas use).
 - Do not use the AC power adapter or USB cable with other devices, as this could cause malfunction.
 - Do not affix labels or other objects to the battery. Failure to observe this precaution could make it impossible to remove the battery from the camera
 - Do not short the battery terminals. The battery could overheat.
 - Read the cautions in "The Battery and Power Supply".
 - Use only genuine Fujifilm rechargeable batteries designated for use in this camera. Failure to observe this precaution could result in product malfunction
 - Do not remove the labels from the battery or attempt to split or peel the outer casing.
 - The battery gradually loses its charge when not in use. Charge the battery one or two days before use.
 - If the battery fails to hold a charge, it has reached the end of its charging life and must be replaced.
 - Unplug the AC power adapter from the power outlet when it is not in use.
 - If the battery is left for long periods without charging, you may find that its quality degrades or that it no longer holds a charge. Charge the battery regularly.
 - Remove dirt from the battery terminals with a clean, dry cloth. Failure to observe this precaution could prevent the battery from charging.
 - Note that charging times increase at low or high temperatures.
 - Selecting **ON** for **Bluetooth/SMARTPHONE SETTING** > **Bluetooth ON/OFF** in the network/USB settings menu increases the drain on the battery.




 If the camera is turned on during charging, charging will end and the USB connection will instead be used to power the camera. The battery level will begin to gradually decline



• The camera will display a "power supply" icon when powered via USB.

Charging via Computer

The camera can be charged via USB. USB charging is available with computers with a manufacturer-approved operating system and USB interface.



Leave the computer on during charging.


- The battery will not charge while the camera is on.
 - Connect the supplied USB cable.
 - Connect the camera directly to the computer; do not use a USB hub or keyboard.
 - Charging stops if the computer enters sleep mode. To resume charging, activate the computer and disconnect and reconnect the USB cable.
 - Charging may not be supported depending on the model of computer, computer settings, and the computer's current state.
 - The battery takes about 600 minutes to charge with a charging input of 5 V/500 mA.



Turning the Camera On and Off

Use the **ON/OFF** switch to turn the camera on and off.

Slide the switch to **0N** to turn the camera on, or to **0FF** to turn the camera off.



- Fingerprints and other marks on the lens or viewfinder can affect pictures or the view through the viewfinder. Keep the lens and viewfinder clean.
- Pressing the **b** button during shooting starts playback.
 - Press the shutter button halfway to return to shooting mode.
 - The camera will turn off automatically if no operations are performed for the length of time selected for **☑ POWER MANAGEMENT** > **AUTO POWER OFF**. To reactivate the camera after it has turned off automatically, press the shutter button halfway or turn the **ON/OFF** switch to **OFF** and then back to **ON**.



Checking the Battery Level

After turning the camera on, check the battery level in the display.

Battery level is shown as follows:




Indicator	Description	
411111	Battery partially discharged.	
(IIII)	Battery about 80% full.	
	Battery about 60% full.	
—	Battery about 40% full.	
	Battery about 20% full.	
(red)	Low battery. Charge as soon as possible.	
(blinks red)	Battery exhausted. Turn camera off and recharge battery.	

Basic Setup

When you turn the camera on for the first time, you can choose a language and set the camera clock. Follow the steps below when turning the camera on for the first time.


1 Turn the camera on.

A language-selection dialog will be displayed.



2 Choose a language.

Highlight a language and press MENU/OK.



? Choose a time zone.

When prompted, highlight the current time zone and daylight savings time setting using the focus stick (focus lever) and press MENU/OK.





To skip this step, press DISP/BACK.

4 Set the clock.



5 View information on the smartphone app.

- The camera will display a QR code you can scan with your smartphone to open a website where you can download the smartphone app.
- Press MENU/OK to exit to the shooting display.



- Use the smartphone app to download pictures from the camera or control the camera remotely.
- 6 Format the memory card (244).
 - Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device.
- If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.

Choosing a Different Language

To change the language:

- 1 Display language options.
 Select ☑ USER SETTING > 配言語/LANG..
- 2 Choose a language. Highlight the desired option and press MENU/OK.

Changing the Time and Date

To set the camera clock:


- 1 Display DATE/TIME options. Select USER SETTING > DATE/TIME.
- 2 Set the clock.
 Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. Press MENU/OK to set the clock.

Basic Photography and Playback

Taking Photographs (Mode P)

This section describes how to take pictures using program AE (mode P). See pages 72–81 for information on S, A, and M modes.

1 Rotate the mode dial to P.



- Rotate the mode dial only after pressing the dial lock release to release the dial.
- **2** Confirm that **P** appears in the display.



3 Ready the camera.

 Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



 To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and AF-assist illuminator.



4 Frame the picture.


-Lenses with Zoom Rings-

Use the zoom ring to frame the picture in the display. Rotate the ring left to zoom out, right to zoom in.



5 Focus.

Press the shutter button halfway to set focus and exposure.



- If the camera is able to focus, the focus frame and focus indicator will glow green.
- If the camera is unable to focus, the focus frame will turn red, !AF will be displayed, and the focus indicator will blink white.

 - If the subject is poorly lit, the AF-assist illuminator may light to assist the focus operation.
 - Focus and exposure will lock when the shutter button is pressed halfway. Focus and exposure remain locked while the button is kept in this position (AF/AE lock).
 - The camera will focus on subjects at any distance in the macro and standard focus ranges for the lens.

6 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.



Viewing Pictures

Pictures can be viewed in the viewfinder or LCD monitor.

To view pictures full frame, press **▶**.



Additional pictures can be viewed by pressing the focus stick (focus lever) left or right or rotating the front command dial. Press the focus stick or rotate the dial right to view pictures in the order recorded, left to view pictures in reverse order. Keep the focus stick pressed to scroll rapidly to the desired frame.



Pictures taken using other cameras are marked with a ## ("gift image") icon to warn that they may not display correctly and that playback zoom may not be available.

Two Memory Cards

If two memory cards are inserted, you can press and hold the **D** button to choose a card for playback. You can also select a card using the **PLAY BACK MENU** > **SWITCH SLOT** option.


HDMI Output

Camera shooting and playback displays can be output to HDMI devices.

Connecting to HDMI Devices

Connect the camera to TVs or other HDMI devices using a third-party HDMI cable.

- 1 Turn the camera off.
- 2 Connect the cable as shown below.



- 3 Configure the device for HDMI input as described in the documentation supplied with the device.
- 4 Turn the camera on. The contents of the camera display will be shown on the HDMI device. The camera display turns off in playback mode (61).
- Making sure the connectors are fully inserted.
 - Use an HDMI cable no more than 1.5 m (4.9 ft.) long.

Shooting

Display live view or movie footage on a TV or save it to an external recorder that supports HDMI input.

Playback

To start playback, press the camera **b** button. The camera monitor turns off and pictures and movies are output to the HDMI device. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.




Some televisions may briefly display a black screen when movie playback begins.

Deleting Pictures

Use the 面 button to delete pictures.

- ① Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.
 - 1 With a picture displayed full frame, press the fi button and select **FRAME**.



- Press the focus stick (focus lever) left or right to scroll through pictures and press MENU/OK to delete (a confirmation dialog is not displayed). Repeat to delete additional pictures.
- Protected pictures cannot be deleted. Remove protection from any pictures you wish to delete (1227).
 - Pictures can also be deleted from the menus using the PLAY BACK MENU > ERASE option (■ 223).

Movie Recording and Playback



Recording Movies

Record movies with sound.

Recording Movies

Movies can be recorded by pressing the ⊙ (movie recording) button or rotating the mode dial to 🕰 (movie).

The (Movie Recording) Button

Use the

(movie recording) button to quickly and easily record movies while in still photography mode.




The camera automatically selects **CONTINUOUS AF** for focus mode.

1 Press • to start recording.



- A recording indicator (●) is displayed while recording is in progress.
- The time remaining is shown by a countdown display, while another display counts up to show the recording time.




Time remaining

Press ● again to end recording. Recording ends automatically when the maximum length is reached or the memory card is full.


🕿 (Movie) Mode

For more control over camera settings, rotate the mode dial to movie) and record movies using the shutter button.

1 Rotate the mode dial to 🕰 (movie).



- Rotate the mode dial only after pressing the dial lock release to release the dial.
- 2 Press the shutter button to start recording.
 - A recording indicator (
) is displayed while recording is in progress.
 - The time remaining is shown by a countdown display, while another display counts up to show the recording time.



Time remaining

3 Press the shutter button again to end recording. Recording ends automatically when the maximum length is reached or the memory card is full.




- Record ProRes movies to CFexpress cards.
- Movies with a bit rate of 720 Mpbs can be recorded to CFexpress cards or to cards with a Video Speed Class of V90 or better.
- Movies with a bit rate of 360 Mpbs can be recorded to CFexpress cards or to cards with a Video Speed Class of V60 or better.
- Movies with a bit rate of 100 or 200 Mbps can be recorded to CFexpress cards or to cards with a UHS Speed Class of 3 or better.
- Sound is recorded via the built-in microphone or an optional external microphone. Do not cover the microphone during recording.
- Note that the microphone may pick up lens noise and other sounds made by the camera during recording.
- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.
- The indicator lamp lights while recording is in progress (the MOVIE SETTING > TALLY LIGHT option can be used to choose the lamp—indicator or AF-assist—that lights during movie recording and whether the lamp blinks or remains steady). During recording, you can change exposure compensation by up to ±2 EV and adjust zoom using the zoom ring on the lens (if available).
 - While recording is in progress, you can:
 - Adjust sensitivity
 - Refocus using any of the following methods:
 - Press the shutter button halfway
 - Press a function button to which **AF-ON** is assigned
 - · Use touch screen controls
 - Display a histogram or artificial horizon by pressing the button to which HISTOGRAM or ELECTRONIC LEVEL SWITCH has been assigned
 - Recording may be unavailable at some settings, while in other cases settings may not apply during recording.
 - To choose the focus area for movie recording, select MAF/MF SETTING > FOCUS AREA and use the focus stick (focus lever) and rear command dial (■ 96).

-Temperature Warnings-

The camera automatically turns off to protect itself when its temperature or the temperature of the battery rises. If a temperature warning is displayed, image noise may increase. Turn the camera off and wait for it to cool before turning it on again.

-Using an External Microphone

Sound can be recorded with external microphones that connect using jacks 3.5 mm in diameter; microphones that require plug-in power cannot be used. See the microphone manual for details.



XLR Microphone Adapters

The camera can be used with TEAC TASCAM CA-XLR2d-F XLR microphone adapters. For more information, visit the TASCAM website.

https://tascam.jp/int/product/ca-xlr2d/#CA-XLR2d_Website

Adjusting Movie Settings

Movie settings can be adjusted from the movie menus or using the **MOVIE SETTING** item in the photo menus (**1**28).

- Use the MOVIE SETTING item in the photo menus to quickly adjust settings when recording movies via the • (movie recording) button (178).
- The movie menus contain options for use when recording movies via the shutter button in # (movie) mode (# 182).
- Settings such as frame rate and frame size can be adjusted using MOVIE MODE.
- Use MEDIA REC SETTING for such tasks as choosing the file type, bit rate, and the destination card slot.
- MODE in the movie menus. Regardless of the option selected, the camera will automatically switch to CONTINUOUS AF when FACE DETECTION ON or SUBJECT DETECTION ON is chosen for MAF/MF SETTING > PACE/EYE DETECTION SETTING or SUBJECT DETECTION SETTING. Note, however, that choosing MANUAL FOCUS when FACE DETECTION ON or SUBJECT **DETECTION ON** is selected disables face and subject detection.
- ① Changes made using the **MOVIE SETTING** item in the photo menus also apply to the movie menus. Changes made in one set of menus automatically apply in the other.

Depth of Field

Choose low f-numbers to soften background details. Aperture can be adiusted when the mode dial is set to **A** (aperture-priority AE) or **M** (manual).


Viewing Movies

View movies on the camera.

In full-frame playback, movies are identified by a 🔁 icon. Press the focus stick (focus lever) down to start movie playback.



The following operations can be performed while a movie is displayed:



Focus stick		Playback in	Playback	
(focus lever)	Full-frame playback	progress (🔼)	paused (🚻)	
Up	_	End playback		
Down	Start playback	Pause playback	Start/resume playback	
Left/right	View other pictures	Adjust speed	Single frame rewind/ advance	

Progress is shown in the display during playback.



① Do not cover the speaker during playback.



- Press MENU/OK to pause playback and display volume controls. Press the focus stick (focus lever) up or down to adjust the volume; press MENU/OK again to resume playback. Volume can also be adjusted using SOUND SET-UP > PLAYBACK VOLUME.
 - To view movies on a television connected via HDMI instead of in the camera monitor, press the **b** button (**60**).

-Playback Speed-

Press the focus stick (focus lever) left or right to adjust playback speed during playback. Speed is shown by the number of arrows (▶ or ◄).

Arrows






P, S, A, and M Modes

P, S, A, and M modes give you varying degrees of control over shutter speed and aperture.


Mode P: Program AE

Let the camera choose shutter speed and aperture for optimal exposure. Other values that produce the same exposure can be selected with program shift.

Rotate the mode dial to P.




P will appear in the display.



- oxdot If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "---".
 - Rotate the mode dial only after pressing the dial lock release to release the dial

Program Shift-

If desired, you can rotate the front command dial to select other combinations of shutter speed and aperture without altering exposure (program shift).




- Program shift is not available in any of the following circumstances:

 - In movie mode
- To cancel program shift, turn the camera off.

Mode S: Shutter-Priority AE

Choose a shutter speed and let the camera adjust aperture for optimal exposure.

1 Rotate the mode dial to S.



S will appear in the display.



2 Rotate the front command dial to choose a shutter speed.



- The roles played by the front command dial can be changed using BUTTON/DIAL SETTING > COMMAND DIAL SETTING.
- If the correct exposure cannot be achieved at the selected shutter speed, aperture will be displayed in red.
 - If the subject is outside the metering range of the camera, the aperture display will show "---".
 - Rotate the mode dial only after pressing the dial lock release to release the dial.




- Shutter speed can be adjusted while the AFON button is pressed or the shutter button is pressed halfway.
 - At shutter speeds slower than 1 second, a count-down timer will be displayed while the exposure is in progress.
 - To reduce "noise" (mottling) in long time-exposures, select **ON** for **MAGE QUALITY SETTING > LONG EXPOSURE NR.** Note that this may increase the time needed to record images after shooting.
 - The picture will go out of focus if the camera is moved during a long time-exposure; use of a tripod is recommended.

Mode A: Aperture-Priority AE

Choose an aperture and let the camera adjust shutter speed for optimal exposure.

Rotate the mode dial to A.



A will appear in the display.



7 Rotate the lens aperture ring to choose an aperture.



- If the lens is not equipped with an aperture ring or if the aperture ring is in the A position, aperture can be adjusted by rotating the front command dial.
 - The roles played by the front command dial can be changed using **BUTTON/DIAL SETTING** > **COMMAND DIAL SETTING**.
- If the correct exposure cannot be achieved at the selected aperture, shutter speed will be displayed in red.
 - If the subject is outside the metering range of the camera, the shutter speed display will show "---".
 - Rotate the mode dial only after pressing the dial lock release to release the dial
- Nerture can be adjusted even while the shutter button is pressed halfwav.

Previewing Depth of Field-


When **PREVIEW DEPTH OF FIELD** is assigned to a function button, pressing the button displays a sicon and stops aperture down to the selected setting, allowing depth of field to be previewed in the display.



Mode M: Manual Exposure

In manual mode, the user controls both shutter speed and aperture. Shots can be deliberately overexposed (brighter) or underexposed (darker), opening the door for a variety of individual creative expression. The amount the picture would be under- or over-exposed at current settings is shown by the exposure indicator; adjust shutter speed and aperture until the desired exposure is reached.

1 Rotate the mode dial to M.



M will appear in the display.



2 Rotate the front command dial to choose a shutter speed and the lens aperture ring to choose an aperture.






- The manual exposure display includes an exposure indicator that shows the amount the picture would be under- or over-exposed at current settings.
 - If the lens is not equipped with an aperture ring or if the aperture ring is in the A position, aperture can be adjusted by rotating the rear command dial
 - The roles played by the front and rear command dials can be changed using BUTTON/DIAL SETTING > COMMAND DIAL SETTING.
- Rotate the mode dial only after pressing the dial lock release to release the dial

BULB

Select a shutter speed of **BULB** for long time-exposures in which you open and close the shutter manually. Use of a tripod is recommended to prevent the camera moving during the exposure.


1 Set shutter speed to **BULB**.



- Press the shutter button all the way down.
 - The shutter will remain open for up to 60 minutes while the shutter button is pressed.
 - The display shows the time elapsed since the exposure started.
 - Releasing the shutter button closes the shutter, ending the exposure. Processing will begin, and the camera will display the processing time remaining.
- Bulb photography is not available in drive modes other than STILL IMAGE or when the electronic shutter is selected for SHOOTING SETTING > SHUTTER TYPE.
- Selecting an aperture of **A** fixes shutter speed at 30 s.

Using a Remote Release

A remote release can be used for long time-exposures. When using an optional RR-100 remote release or an electronic release from third-party suppliers, connect it to the camera's remote release connector.



Exposure Preview

To preview exposure in the LCD monitor, select **PREVIEW EXP./WB** for **■ SCREEN SET-UP > PREVIEW EXP./WB IN MANUAL MODE**.




Select an option other than **PREVIEW EXP./WB** when using the flash or on other occasions on which exposure may change when the picture is taken.

FILTER

Take photos with filter effects.

1 Rotate the mode dial to FILTER.




2 Choose a filter via SHOOTING SETTING > FILTER SETTING.

Filter	Description	
₩ TOY CAMERA	Choose for a retro toy camera effect.	
MINIATURE	The tops and bottoms of pictures are blurred for a diorama effect.	
🙉 POP COLOR	Create high-contrast images with saturated colors.	
#KEY HIGH-KEY	Create bright, low-contrast images.	
LOW-KEY	Create uniformly dark tones with few areas of emphasized highlights.	
See DYNAMIC TONE	Dynamic tone expression is used for a fantasy effect.	
ஓ SOFT FOCUS	Create a look that is evenly soft throughout the whole image.	
A PARTIAL COLOR (RED)	Areas of the image that are the selected color are recorded in that color. All other areas of the image are recorded in black-and-white.	
A PARTIAL COLOR (ORANGE)		
A PARTIAL COLOR (YELLOW)		
A PARTIAL COLOR (GREEN)		
A PARTIAL COLOR (BLUE)		
A PARTIAL COLOR (PURPLE)		

① Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness or hue.

Custom Modes

Rotate the mode dial to any of modes C1 (CUSTOM 1) through C7 (CUSTOM 7) to take pictures using previously-saved shooting menu settings.



Mode Selection: Still Photography or Movie

Choose whether the selected custom settings bank (C1 through C7) is for still photography (STILL) or movie recording (MOVIE).

- 1 Navigate to MIMAGE QUALITY SETTING in the photo menus, highlight CUSTOM MODE SETTING, and press MENU/OK.
 - You can also use MOVIE SETTING > CUSTOM MODE SETTING in the movie menus.
- 2 Highlight the desired custom settings bank and press MENU/OK.



3 Highlight ★ STILL or ★ MOVIE and press MENU/OK.

The selected custom settings bank can now be used for still photography or movie recording.



Saving Current Settings

Save current settings in a custom settings bank.

- 1 Navigate to IMAGE QUALITY SETTING in the photo menus, highlight EDIT/SAVE CUSTOM SETTING, and press MENU/OK.
 - To save settings for movie recording, navigate to MOVIE SETTING in the movie menus and select BEDIT/SAVE CUSTOM SETTING.
- 2 Highlight a destination bank for current settings (C1 through C7) and press MENU/OK.



3 Highlight SAVE CURRENT SETTINGS and press MENU/OK.



4 Highlight OK and press MENU/OK. Current settings will be saved to the selected bank.



Editing Custom Settings

Edit existing custom settings banks.

- Navigate to MIMAGE QUALITY SETTING in the photo menus, highlight EDIT/SAVE CUSTOM SETTING, and press MENU/OK.
 - To save settings for movie recording, navigate to MOVIE SETTING in the movie menus and select EDIT/SAVE CUSTOM SETTING
- 2 Highlight the desired custom settings bank and press MENU/OK.



3 Highlight EDIT/CHECK and press MENU/OK.



4 The camera will display a list of shooting menu items; highlight an item you wish to edit and press MENU/OK. Adjust the selected item as desired.



5 Press MENU/OK to save the changes and return to the shooting menu list.

Adjust additional items as desired.

- If DISABLE is selected for In IMAGE QUALITY SETTING > AUTO UPDATE CUSTOM SETTING in the photo menu or for Image MOVIE SETTING > Image AUTO UPDATE CUSTOM SETTING in the movie menu, red dots will appear next to the edited items but the changes will not be saved automatically.
 - \bullet To save the changes for selected items, highlight the items in the list and press ${\bf Q}$
 - To save changes for all items, return to Step 3 and select SAVE THE CHANGES. To cancel all changes and restore the previous settings, select RESET THE CHANGES.
 - If you copy an item marked by a red dot, the item will be copied with the changes intact.

Copying Custom Settings

Copy custom settings from one bank to another, overwriting the settings in the destination bank. If the source bank has been renamed, the name will also be copied to the destination bank.

- Navigate to MIMAGE QUALITY SETTING in the photo menus, highlight EDIT/SAVE CUSTOM SETTING, and press MENU/OK.
 - To copy settings for a movie custom settings bank, navigate to ☐ MOVIE SETTING in the movie menus and select ☐ EDIT/ SAVE CUSTOM SETTING.
- 2 Highlight the source bank and press MENU/OK.



3 Highlight COPY and press MENU/OK.



4 Highlight the destination bank (C1 through C7) and press MENU/OK. A confirmation dialog will be displayed.



Any changes to custom settings in the destination bank will be overwritten.

5 Highlight OK and press MENU/OK. The selected settings will be copied to the destination bank, overwriting any existing settings.





Resetting Custom Settings

Reset selected custom settings banks.

- 1 Select
 ☐ IMAGE QUALITY SETTING > EDIT/SAVE CUSTOM **SETTING** in the shooting menu and press **MENU/OK**.
 - This assumes that you wish to reset settings for still photography. To reset movie settings, navigate to **MOVIE SETTING** in the movie menus and select **EDIT/SAVE CUSTOM SETTING**.
- **)** Highlight the desired custom settings bank and press MENU/OK.



3 Highlight RESET CUSTOM SETTING and press MENU/OK.

A confirmation dialog will be displayed.

4 Highlight OK and press MENU/OK. The selected bank will be reset.





Renaming Custom Settings Banks

Rename selected custom settings banks.

- 1 Select ☑ IMAGE QUALITY SETTING > EDIT/SAVE CUSTOM SETTING in the shooting menu and press MENU/OK.
 - This assumes that you wish to rename settings for still photography. To rename movie settings, navigate to ☐ MOVIE SETTING in the movie menus and select ☐ EDIT/SAVE CUSTOM SETTING.
- 2 Highlight the desired custom settings bank and press MENU/OK.



3 Highlight EDIT CUSTOM NAME and press MENU/OK.




4 Enter a new name for the custom settings bank and select SET.

The selected bank will be renamed.

Autofocus

Take pictures using autofocus.

- 1 Select single or continuous AF for MAF/MF SETTING > FOCUS MODE in the shooting menu (□ 92).
- 2 Use MAF/MF SETTING > AF MODE to choose an AF mode (1994).
- 3 Select MAF/MF SETTING > FOCUS AREA and choose the position and size of the focus frame (■ 96).



4 Take pictures.


Focus Mode

Choose how the camera focuses.

- 1 Press MENU/OK to display the menus.
- 2 Select AF/MF SETTING > FOCUS MODE in the shooting menu.
- **3** Choose from the following options:

Mode	Description	
MFI MANUAL FOCUS	Focus manually using the lens focus ring. Choose for manual control of focus or in situations in which the camera is unable to focus using autofocus (E 100).	
(ONTINUOUS AF	Focus is continually adjusted to reflect changes in the distance to the subject while the shutter button is pressed halfway. Use for subjects that are in motion.	
	Focus locks while the shutter button is pressed halfway. Choose for stationary subjects.	

- Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.
 - If ON is selected for AF/MF SETTING > PRE-AF, focus will be adjusted continuously in modes III and III even when the shutter button is not pressed.



Autofocus Options (AF Mode)

Focus can be adapted to a variety of subjects by changing the combination of settings selected for focus and AF modes.

- 1 Press MENU/OK and go to the shooting menu.
- 2 Select M AF/MF SETTING > AF MODE.
- 3 Choose an AF mode.

How the camera focuses depends on the focus mode.

Focus Mode FS (SINGLE AF)

Option	Description	Sample image
SINGLE POINT	Camera focuses on subject in selected focus point. Use for pinpoint focus on selected subject.	
ZONE	Camera focuses on subject in selected focus zone. Focus zones include multiple focus points, making it easier to focus on subjects in motion.	
[] WIDE	Camera focuses automatically on high-contrast subjects; display shows areas in focus.	
ALL ALL	Rotate the rear command dial in t play (🗐 97, 98) to cycle through order: • SINGLE POINT, 🗓 ZO	AF modes in the following

Focus Mode FFC (CONTINUOUS AF)

Option	<u>Description</u>	Sample image
SINGLE POINT	Focus tracks subject at selected focus point. Use for subjects moving toward or away from camera.	
ZONE	Camera tracks focus in selected fo- cus zone. Use for subjects that are moving fairly predictably.	
[] Tracking	Focus tracks subjects moving through wide area of frame.	
ALL	Rotate the rear command dial in t play (🗐 97, 98) to cycle through order: • SINGLE POINT, 🗉 ZO	AF modes in the following

Focus-Point Selection


Choose a focus point for autofocus.

Viewing the Focus-Point Display

- 1 Press MENU/OK and go to the shooting menu.
- 2 Select MAF/MF SETTING > FOCUS AREA to view the focus-point display.
- **3** Use the focus stick (focus lever) and rear command dial to choose a focus area.
- The focus point can also be selected using touch controls (🗐 31).

Selecting a Focus Point

Use the focus stick (focus lever) to choose the focus point and the rear command dial to choose the size of the focus frame. The procedure varies with the option selected for AF mode



	Focus stick		Rear command dial	DISP/BACK button
AF mode	-0-			
	Tilt	Press	Rotate	
•			Choose from 6	
ت		Select highlighted focus point	frame sizes	
п	Select focus point		Choose from 3	Select center
111			frame sizes	focus point
		point	_	




- Manual focus-point selection is not available when □ WIDE/ **TRACKING** is selected in focus mode FS.
 - If ALL is selected for AF mode, you can rotate the rear command dial in the focus-point selection display to cycle through AF modes in the following order: • SINGLE POINT (6 frame sizes), • ZONE (3 frame sizes), and either **WIDE** (focus mode **MS**) or **TI TRACKING** (focus mode FG).

The Focus-Point Display

The focus-point display varies with the option selected for AF mode.



 \bigcirc Focus frames are shown by small squares (\square), focus zones by the large squares.



-Autofocus-

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below.

- Very shiny subjects such as mirrors or car bodies.
- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background.
- Subjects positioned in front of or behind a high-contrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

Checking Focus-

To zoom in on the current focus area for precise focus, press the center of the focus stick (focus lever). Press up to two times more to zoom in further and a fourth time to cancel zoom.







Normal display

Focus zoom



- ◆ In focus mode 🖭, zoom can be adjusted by rotating the rear command dial.
 - In focus mode Fig. select SINGLE POINT for AF MODE.
 - Focus zoom is not available in focus mode

 or when

 AF/MF **SETTING** > **PRE-AF** is on.
 - Use **BUTTON/DIAL SETTING** > **FOCUS LEVER SETTING** to change the function performed by the center of the focus stick (focus lever).

 BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING can also be used to assign focus zoom to other controls.

Manual Focus

Adjust focus manually.

1 Select MANUAL FOCUS for MAF/MF SETTING > FOCUS MODE.



2 Focus manually using the lens focus ring. Rotate the ring left to reduce the focus distance, right to increase.



- 3 Take pictures.
- Use BUTTON/DIAL SETTING > LENS ZOOM/FOCUS SETTING to reverse the direction of rotation of the focus ring.
 - Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.

Quick Focus

- To use autofocus to focus on the subject in the selected focus area, press
 the button to which focus lock or AF-ON has been assigned (the size of
 the focus area can be chosen with the rear command dial).
- In manual focus mode, you can use this feature to quickly focus on a chosen subject using either single or continuous AF according to the option chosen for AF/MF SETTING > INSTANT AF SETTING.


Checking Focus

A variety of options are available for checking focus in manual focus mode.

The Manual Focus Indicator

The white line indicates the distance to the subject in the focus area (in meters or feet according to the option selected for SCREEN SET-UP > FOCUS SCALE UNITS in the setup menu), the blue bar the depth of field, or in other words the distance in front of and behind the subject that appears to be in focus.







- If both AF DISTANCE INDICATOR and MF DISTANCE INDICATOR are selected in the SCREEN SET-UP > DISP. CUSTOM SETTING list, the manual focus indicator can also be viewed using the depthof-field indicator in the standard display. Use the **DISP/BACK** button to display standard indicators.
 - Use the MAF/MF SETTING > DEPTH-OF-FIELD SCALE option to choose how depth of field is displayed. Choose FILM FORMAT **BASIS** to help you make practical assessments of depth of field for pictures that will be viewed as prints and the like, PIXEL BASIS to help you assess depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.

Focus Zoom

If ON is selected for AF/MF SETTING > FOCUS CHECK, the camera will automatically zoom in on the selected focus area when the focus ring is rotated. Press the center of the focus stick (focus lever) to exit zoom.



- Use the focus stick (focus lever) to choose another focus area.
 - If OFF or FOCUS PEAK HIGHLIGHT is selected for I AF/MF SETTING > MF ASSIST, zoom can be adjusted by rotating the rear command dial. Zoom cannot be adjusted when **DIGITAL SPLIT IMAGE** or **DIGITAL** MICROPRISM is selected


MF Assist

Use AF/MF SETTING > MF ASSIST to choose a focus check option.

The following options are available:

- DIGITAL SPLIT IMAGE: Displays a split image in the center of the frame. Frame the subject in the split-image area and rotate the focus ring until the four parts of the split image are correctly aligned.
- DIGITAL MICROPRISM: A grid pattern that emphasizes blur is displayed when the subject is out of focus, disappearing to be replaced by a sharp image when the subject is in focus.
- FOCUS PEAK HIGHLIGHT: Highlights high-contrast outlines. Rotate the focus ring until the subject is highlighted.










Sensitivity

Adjust the camera's sensitivity to light.

To view sensitivity settings, press the ISO button.



Option	Description
AUTO1 AUTO2 AUTO3	Sensitivity is automatically adjusted in response to shooting conditions according to combination of standard and maximum sensitivity and minimum shutter speed chosen for SHOOTING SETTING > ISO . Choose from AUTO1 , AUTO2 , and AUTO3 (11 106).
160-12800	Adjust sensitivity manually. Selected value is shown in display.
L (80/100/125) H (25600/51200)	Choose for special situations. Note that mottling may appear in pictures taken at H , while L reduces dynamic range.



Sensitivity is not reset when the camera is turned off.

-Adjusting Sensitivity-

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.

AUTO

Choose the base sensitivity, maximum sensitivity, and minimum shutter speed for AUTO1, AUTO2, and AUTO3.

		Default		
ltem	Options	AUT01	AUTO2	AUT03
DEFAULT SENSITIVITY	160-12800	160		
MAX. SENSITIVITY	400-12800	800 3200 12800		12800
MIN. SHUTTER SPEED	1/500-1/4 SEC, AUTO	AUTO		

The camera automatically chooses a sensitivity between the default and maximum values; sensitivity is only raised above the default value if the shutter speed required for optimal exposure would be slower than the value selected for MIN. SHUTTER SPEED.



- If the value selected for **DEFAULT SENSITIVITY** is higher than that selected for MAX. SENSITIVITY, DEFAULT SENSITIVITY will be set to the value selected for MAX. SENSITIVITY
 - The camera may select shutter speeds slower than MIN. SHUTTER **SPEED** if pictures would still be underexposed at the value selected for MAX. SENSITIVITY.
 - If AUTO is selected for MIN. SHUTTER SPEED, the camera will automatically adjust the minimum shutter speed according to the focal length of the lens (the setting remains the same whether image stabilization is on or off).

Metering

Choose how the camera meters exposure.

■ SHOOTING SETTING > PHOTOMETRY offers a choice of the following metering options:

① The selected option will only take effect if OFF is selected for ② FACE/ EYE DETECTION SETTING and SUBJECT DETECTION SETTING in the ☐ AF/MF SETTING menu.

Mode	Description
[⊠] MULTI	The camera instantly determines exposure based on an analysis of composition, color, and brightness distribution. Recommended in most situations.
[⊚] Center- Weighted	The camera meters the entire frame but assigns the greatest weight to the area at the center.
[•] SPOT	The camera meters lighting conditions in an area equivalent to 2% of the frame. Recommended with backlit subjects and in other cases in which the background is much brighter or darker than the main subject.
[] AVERAGE	Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white.


To meter the subject in the selected focus area, choose **ON** for **M AF/ MF SETTING** > **INTERLOCK SPOT AE & FOCUS AREA** (**1** 159).



Exposure Compensation

Adjust exposure.

Rotate the rear command dial to adjust exposure.





- The command dial used in this role can be chosen using
 BUTTON/ **DIAL SETTING > COMMAND DIAL SETTING.**
 - In manual mode, exposure can be adjusted by rotating the front or rear command dial after pressing a control to which WHEN SET TO M (ON/OFF SWITCH) is assigned.




- The amount of compensation available varies with the shooting mode.
 - Exposure compensation can be previewed in the shooting display, although the display may not accurately reflect its effects if:
 - the exposure compensation amount exceeds ±3 EV,
 - R200 200% or R400 400% is selected for DYNAMIC RANGE, or
 - **STRONG** or **WEAK** is selected for **D RANGE PRIORITY**.

Exposure compensation can still be previewed in the viewfinder or LCD monitor by pressing the shutter button halfway. In movie mode, the display may not accurately reflect the effects of exposure compensation during F-log recording or when 200 200% or 400% is selected for **DYNAMIC RANGE**. An accurate preview can be obtained by selecting mode M and adjusting exposure directly.

Focus/Exposure Lock

Focus and exposure lock when the shutter button is pressed halfway.

1 Position the subject in the focus frame and press the shutter button halfway to lock focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).



- 2 Press the button all the way down.
- Focus and exposure lock via the shutter button is only available when ON is selected for ■ BUTTON/DIAL SETTING > SHUTTER AF, SHUTTER AE.

Other Controls

Focus and exposure can also be locked using the AEL and AFON buttons. At default settings, you can use the **AEL** button to lock exposure without locking focus. If the AFON button is assigned AF LOCK ONLY, it can similarly be used to lock focus without locking exposure.



AEL button (exposure lock)

- While the assigned control is pressed, pressing the shutter button halfway will not end the lock.
- If AE&AF ON/OFF SWITCH is selected for BUTTON/DIAL SETTING > AE/ AF-LOCK MODE, the lock can only be ended by pressing the control a second time.



AFON button




- The focus lever (focus stick) can be used to reposition the focus point during exposure lock.
 - The **AEL** and **AFON** buttons can be assigned other roles using **BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING.** Exposure and focus lock can also be assigned to other buttons (12) 298).

Continuous Shooting (Burst Mode)

Capture motion in a series of pictures.

1 Press the **DRIVE** button to display drive mode options.



2 If A CH HIGH SPEED BURST, CH HIGH SPEED BURST (1.25X CROP), or CL LOW SPEED BURST is selected, the camera will take pictures continuously while the shutter-release button is pressed.

Shooting ends when the shutter button is released or the memory card is full.

- If file numbering reaches 9999 before shooting is complete, the remaining pictures will be recorded to a new folder.
 - Shooting ends when the memory card is full; the camera will record all photos shot to that point. Burst shooting may not begin if the space available on the memory card is insufficient.
 - Frame rates may slow as more shots are taken.
 - Frame rate varies with the scene, shutter speed, sensitivity, and focus mode.
 - Depending on shooting conditions, frame rates may slow or the flash may not fire.
 - Recording times may increase during burst shooting.
 - The choice of burst modes varies with the option selected for SHOOTING SETTING > SHUTTER TYPE.

-Exposure-

To vary exposure with each shot, select **OFF** for **BUTTON/DIAL SETTING > SHUTTER AE.**




Depending on such factors as aperture, sensitivity, and exposure compensation, exposure may not be adjusted automatically.

E

Bracketing

Automatically vary settings over a series of pictures.

1 Press the **DRIVE** button to display drive mode options.



Press the focus stick (focus lever) up or down to highlight one of the following:

Option		Option	
ISO BKT	114	BKT Bracketing	115
WBI WHITE BALANCE BKT	114		

- **3** Press the focus stick left or right to highlight the desired bracketing settings.
- 4 Press MENU/OK to select.
- 5 Take pictures.

ISO ISO BKT

Select a bracketing amount $(\pm \frac{1}{3}, \pm \frac{2}{3}, \text{ or } \pm 1)$ in the drive mode display. Each time the shutter is released, the camera will take a picture at the current sensitivity and process it to create two additional copies, one with sensitivity raised and the other with sensitivity lowered by the selected amount.

WBI WHITE BALANCE BKT

Select a bracketing amount $(\pm 1, \pm 2, \text{ or } \pm 3)$ in the drive mode display. Each time the shutter is released, the camera takes one shot and processes it to create three copies: one at the current white balanced setting, one with fine-tuning increased by the selected amount, and another with fine-tuning decreased by the selected amount.

BKT Bracketing

n AE BKT

Use SHOOTING SETTING > AE BKT SETTING to choose the bracketing amount, bracketing order, and number of shots. The camera will take the specified number of shots in sequence: one using the metered value for exposure and the others over- or under-exposed by multiples of the selected bracketing amount.



Regardless of the bracketing amount, exposure will not exceed the limits of the exposure metering system.

🖫 FILM SIMULATION BKT

Each time the shutter is released, the camera takes one shot and processes it to create copies with different film simulation settings, chosen using **SHOOTING SETTING** > **FILM SIMULATION BKT**.

DRI DYNAMIC RANGE BKT

Each time the shutter button is pressed, the camera takes three shots with different dynamic ranges: 100% for the first, 200% for the second, and 400% for the third.



While dynamic range bracketing is in effect, sensitivity will be restricted to a minimum of ISO 640; the sensitivity previously in effect is restored when bracketing ends.

FOCUS BKT

Each time the shutter button is pressed, the camera takes a series of photos, varying focus with each shot. The SHOOTING SETTING > FOCUS BKT SETTING item offers a choice of MANUAL and **AUTO** bracketing.



- Do not adjust zoom during shooting.
 - Use of a tripod is recommended.


MANUAL

In MANUAL mode, you choose the following.

Option	Description	
FRAMES	hoose the number of shots.	
STEP	Choose the amount focus changes with each shot.	
INTERVAL	Choose the interval between shots.	

Focus and FRAMES/STEP

The relation between focus and the options chosen for **FRAMES** and **STEP** is shown in the illustration



- Focus proceeds from the starting position toward infinity.
- Small **STEP** values translate to small changes in focus, larger values to larger changes.
- Regardless of the option chosen for **FRAMES**, shooting ends when focus reaches infinity.

AUTO

In AUTO mode, the camera calculates FRAMES and STEP automatically.

- 1 Select SHOOTING SETTING in the shooting menu, highlight FOCUS BKT SETTING, and press MENU/OK.
- 2 Select AUTO and choose an INTERVAL. The view through the lens will be displayed.
- 3 Focus on the nearest end of the subject and press MENU/OK.
 The selected focus distance appears as A on the focus distance indicator.



The same focus range can be chosen by focusing on the farthest end of the subject first.

4 Focus on the farthest end of the subject and press DISP/BACK.
The selected focus distance (B) and focus range (A to B) appear on the focus distance indicator.



Instead of pressing the **DISP/BACK** button, you can press **MENU/OK** and select **A** again.


5 Take photographs. The camera will calculate values for FRAMES and STEP automatically. The number of frames will appear in the display.



HDR

Each time the shutter button is pressed, the camera takes three shots, varying exposure each time, and combines them into a single picture. The resulting photograph preserves details in highlights and shadows.

1 Press the **DRIVE** button to display drive mode options and select **HDR**.



2 Choose the amount the brightnesses of the exposures vary.

Option	Description		
HDR AUTO	Dynamic range is automatically set to a value of from 200%		
HUN AUTO	to 800%.		
HDR200	Dynamic range is set to 200%.		
HDR400	Dynamic range is set to 400%.		
HDR800	Dynamic range is set to 800%.		
HDR800+	Camera settings are adjusted for maximum variation in dy-		
	namic range.		

3 Take photographs.
The camera will create a combined image.

- Keep the camera steady.
 - The desired results may not be achieved in the subject moves or the composition or lighting changes during shooting.
 - The picture will be cropped a very small amount and the resolution will drop slightly.
 - Mottling may appear in pictures taken at higher values. Choose a value according to the scene.
 - "Extended" sensitivity values are not supported.
 - Depending on the options selected for HDR and sensitivity, pictures may not be taken at the selected shutter speed.
 - The flash does not fire.




Name of the HDR images are indicated by a Image are indicated by a Images are indicated by a Image are indicate


Panoramas

Follow an on-screen guide to create a panorama.

1 Press the **DRIVE** button to display drive mode options and select **PANORAMA**.



- 2 To select the size of the angle through which you will pan the camera while shooting, press the focus stick (focus lever) left. Highlight a size and press MENU/OK.
- 3 Press the focus stick right to view a choice of pan directions. Highlight a pan direction and press MENU/OK.
- **4** Press the shutter button all the way down to start recording. There is no need to keep the shutter button pressed during recording.
- 5 Pan the camera in the direction shown by the arrow. Shooting ends automatically when the camera is panned to the end of the guides and the panorama is complete.



For Best Results


- Move the camera slowly in a small circle at a steady speed
- Keep the camera parallel or at right angles to the horizon and be sure to pan only in the direction shown by the guides
- Try panning at a different speed if the desired results are not achieved
- Prop your elbows against your sides
- Use a tripod
- For best results, use a lens with a focal length of 35 mm or less (50 mm or less in 35 mm format).
- If the shutter button is pressed all the way down before the panorama is complete, shooting will end and no panorama may be recorded.
 - The last part of the panorama may not be recorded if shooting ends before the panorama is complete.
 - Panoramas are created from multiple frames, and the camera may in some cases be unable to stitch the frames together perfectly.
 - Panoramas may be blurred if the subject is poorly lit.
 - Shooting may be interrupted if the camera is panned too quickly or too slowly. Panning the camera in a direction other than that shown cancels shooting.
 - The camera may in some cases record a greater or lesser angle than selected.
 - The desired results may not be achieved with:
 - Moving subjects
 - Subjects close to the camera
 - Unvarying subjects such as the sky or a field of grass
 - Subjects that are in constant motion, such as waves and waterfalls
 - Subjects that undergo marked changes in brightness
 - If ON is selected for BUTTON/DIAL SETTING > SHUTTER AE, exposure for the entire panorama is determined by the first frame.

-Viewing Panoramas-

With the panorama displayed full frame, press the focus stick (focus lever) down to start panorama playback. Vertical panoramas will scroll vertically, horizontal panoramas horizontally.







- In full-frame playback, you can use the rear command dial to zoom panoramas in or out.
- Panorama playback is controlled using the focus stick.


Focus stick (focus lever)	Full-frame playback	Panorama playback	Panorama playback paused
Up	_	End pla	ayback
Down	Start playback	Pause playback	Resume playback
Left/right	View other pictures	Choose pan direction	Scroll panorama manually

Multiple Exposures

Create a photograph that combines multiple exposures.



1 Press the **DRIVE** button to display the drive mode options and select **MULTIPLE EXPOSURE**.



2 Choose a blend mode.

Option	Description
	The camera adds the exposures together. You may need to lower exposure compensation depending on the number of shots.
AVERAGE	The camera automatically optimizes exposure for the final picture. The background in series shot without changing the composition will be optimally exposed.
BRIGHT	The camera compares the exposures and chooses only the brightest pixel at each location. Colors may be mixed depending on their brightness and hue.
	The camera compares the exposures and chooses only the darkest pixel at each location. Colors may be mixed depending on their brightness and hue.

3 Take the first shot.

4 Press MENU/OK. The first shot will be shown superimposed on the view through the lens and you will be prompted to take the second shot.



- To return to the previous step and retake the first shot, press the focus stick (focus lever) left.
 - To save the first shot and exit without creating a multiple exposure, press DISP/BACK.
- 5 Take the second shot, using the first frame as a guide.



6 Press MENU/OK. The combined exposures will be displayed as a guide to composing the next shot.



- To return to the previous step and retake the second shot, press the focus stick left
 - To end shooting and create a multiple exposure from the shots taken to this point, press DISP/BACK.
- 7 Make additional exposures. Each photograph can contain up to nine exposures.
- **R** Press **DISP/BACK** to end shooting. The camera will create the combined image and multiple exposure shooting will end.

The Shooting Menus



IMAGE QUALITY SETTING (Still Photography)

Adjust image quality settings for still photography.

To display image quality settings, press MENU/OK in the photo shooting display and select the (IMAGE QUALITY SETTING) tab.





The options available vary with the shooting mode selected.

IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded.

Option	lmage size	Option	lmage size
3:2	6240 × 4160	1:1	4160 × 4160
1 6:9	6240 × 3512		
Option	lmage size	Option	lmage size
M 3:2	4416 × 2944	M 1:1	2944 × 2944
M 16:9	4416 × 2488		
	•		
Option	lmage size	Option	lmage size

Option	lmage size	Option	lmage size
S 3:2	3120 × 2080	§ 1:1	2080×2080
§ 16:9	3120 × 1760		

The following options are available in SPORTS FINDER MODE and when 1.25X CROP is selected in burst mode:

Option	lmage size	Option	lmage size
M 3:2	4992×3328	M 1:1	3328×3328
M 16:9	4992×2808		



NAGE SIZE is not reset when the camera is turned off or another shooting mode is selected.

IMAGE QUALITY

Choose a file format and compression ratio.

Option	Description
FINE	Low compression ratios are used for higher-quality images.
NORMAL	Higher compression ratios are used to increase the number of
NORMAL	images that can be stored.
FINE + RAW	Record both RAW and fine-quality JPEG or HEIF images.
NORMAL + RAW	Record both RAW and normal-quality JPEG or HEIF images.
RAW	Record RAW images only.

The Function Buttons

To toggle RAW image quality on or off for a single shot, assign **RAW** to a function button (🗎 295). Press the button once to select the option in the right column, again to return to the original setting (left column).

Option currently selected for	Option selected by pressing function
IMAGE QUALITY	button to which RAW is assigned
FINE	FINE + RAW
NORMAL	NORMAL + RAW
FINE + RAW	FINE
NORMAL + RAW	NORMAL
RAW	FINE

RAW RECORDING

Choose whether to compress RAW images.

Option	Description	
UNCOMPRESSED	RAW images are not compressed.	
LOSSLESS COMPRESSED	RAW images are compressed using a reversible algorithm that reduces file size with no loss of image data. The images can be viewed in Capture One Express for Fujifilm ¹ , Capture One for Fujifilm ¹ , Capture One ¹ , RAW FILE CONVERTER EX powered by SILKYPIX ² , FUJIFILM X RAW STUDIO, or other software that supports "lossless" RAW compression. Quality is the same as UNCOMPRESSED , but the resulting files are anywhere from about 30 to 90 percent of their uncompressed size.	
COMPRESSED	RAW images are compressed using a "lossy", non-reversible algorithm. Quality is about the same as UNCOMPRESSED , but the resulting files are anywhere from about 25 to 35 percent of their uncompressed size.	

¹ For information on when support will be available, visit: https://www.captureone.com/

² For information on when support will be available, visit: https://fujifilm-x.com/support/compatibility/software/raw-file-converter-ex-poweredby-silkypix/

SELECT JPEG/HEIF

Choose whether pictures are recorded in JPEG or HEIF.

Option	Description
JPEG	Pictures are recorded in the widely-supported JPEG format.
HEIL	Pictures are recorded in HEIF, a format with excellent compression but limited options for viewing and sharing.

- JPEG is automatically selected in place of HEIF during filter-effect, panorama, multiple-exposure, and HDR photography.
 - Selecting **HEIF** disables **CLARITY** and sets **COLOR SPACE** to **sRGB**.
 - HEIF pictures are stored on the memory card as files with the extension ".HIF". Before the pictures can be viewed on a computer, the extension must be changed to ".HEIC". This occurs automatically when HEIF pictures are uploaded from the camera to a computer via USB.

FILM SIMULATION

Simulate the effects of different kinds of film, including blackand-white (with or without color filters). Choose a palette according to your subject and creative intent.

Option	Description
STD PROVIA/STANDARD	ldeal for a wide range of subjects.
Velvia/VIVID	Vibrant reproduction, ideal for landscape and nature.
S ASTIA/SOFT	Softer color and contrast for a more subdued look.
CC CLASSIC CHROME	Soft color and enhanced shadow contrast for a calm look.
NH PRO Neg. Hi	ldeal for portrait with slightly enhanced contrast.
Ñ≣ PRO Neg. Std	ldeal for portrait with soft gradations and skin tones.
ÑՇ CLASSIC Neg.	Enhanced color with hard tonality to increase image depth.
NOSTALGIC Neg.	Amber tinted highlights and rich shadow tone for printed photo look.
E ETERNA/CINEMA	Soft color and rich shadow tone suitable for film look movie.
EB ETERNA BLEACH BYPASS	Unique color with low saturation and high contrast. Suitable for still and movie.
ACROS	Shoot in Black and White In rich details with sharpness. Available with yellow (Ye), red (R), and green (G) filters, which deepen shades of gray corresponding to hues complementary to the selected color. At ACROS+Ye FILTER: Slightly enhances contrast and darkens skies. AR ACROS+R FILTER: Enhances contrast and darkens skies considerably.

Option	Description
□ MONOCHROME	Shoots in black and white. Available with yellow (Ye), red (R), and green (G) filters, which deepen shades of gray corresponding to hues complementary to the selected color. • 實 MONOCHROME+Ye FILTER: Slightly enhances contrast and darkens skies. • 宣 MONOCHROME+R FILTER: Enhances contrast and darkens skies considerably.
SEPIA SEPIA	Shoots in sepia tone.



- Film simulation options can be combined with tone and sharpness settings.
 - Film simulation settings can also be accessed via shortcuts (🕮 286).
 - For more information, visit: https://fujifilm-x.com/global/tag/the-world-of-film-simulation/?post_type=xstories

MONOCHROMATIC COLOR

Add a reddish or bluish tinge (warm or cool color cast) to the ACROS and MONOCHROME monochrome film simulations. Color can be adjusted on the WARM-COOL and G (Green)-M (Magenta) axes.



GRAIN EFFECT

Add a film grain effect.

ROUGHNESS

Option	Description
STRONG	Choose for rougher grains.
WEAK	Choose for smoother grains.
OFF	Turn the effect off.

SIZE

Option	Description	
LARGE	Choose for coarser grains.	
SMALL	Choose for finer grains.	

COLOR CHROME EFFECT

Increase the range of tones available for rendering colors that tend to be highly saturated, such as reds, yellows, and greens.

Option	Description	
STRONG	hoose for a strong effect.	
WEAK	Choose for a weak effect.	
OFF	Turn the effect off.	

COLOR CHROME FX BLUE

Increase the range of tones available for rendering blues.

Option	Description	
STRONG	hoose for a strong effect.	
WEAK	Choose for a weak effect.	
OFF	Turn the effect off.	

WHITE BALANCE

For natural colors, choose a white balance option that matches the light source.

Option	Description	
AUTO WHITE PRIORITY	White balance is adjusted automatically. Choose for whiter whites in scenes lit by incandescent bulbs.	
AUTO	White balance is adjusted automatically.	
AUTO AMBIENCE PRIORITY	White balance is adjusted automatically. Choose for warmer whites in scenes lit by incandescent bulbs.	
□ CUSTOM 1		
Q₂ CUSTOM 2	Measure a value for white balance.	
Q₃ CUSTOM 3		
COLOR TEMPERATURE	Choose a color temperature.	
* DAYLIGHT	For subjects in direct sunlight.	
★ SHADE	For subjects in the shade.	
岩 FLUORESCENT LIGHT-1	Use under "daylight" fluorescent lights.	
∺ FLUORESCENT LIGHT-2	Use under "warm white" fluorescent lights.	
岩 FLUORESCENT LIGHT-3	Use under "cool white" fluorescent lights.	
-A- INCANDESCENT	Use under incandescent lighting.	
UNDERWATER	Reduces the blue cast typically associated with underwater lighting.	

- In conditions in which **AUTO** fails to produce the desired results—for example, under certain types of lighting or in close-ups of portrait subjects—use custom white balance or choose a white balance option suited to the light source.
 - White balance is adjusted for flash lighting only in AUTO, W AUTO WHITE PRIORITY, AUTO AMBIENCE PRIORITY, and modes. Turn the flash off using other white balance options.
 - White balance options can also be accessed via shortcuts (1 286).

Fine-Tuning White Balance


Pressing MENU/OK after selecting a white balance option displays a fine-tuning dialog; use the focus stick (focus lever) to fine-tune white balance.



- To exit without fine-tuning white balance, press DISP/BACK after selecting a white balance option.
 - You cannot tilt the focus stick diagonally when fine-tuning white balance.

Custom White Balance

Choose Ω_1 , Ω_2 , or Ω_3 to adjust white balance for unusual lighting conditions using a white object as a reference (colored objects can also be used to lend photos a color cast). A white balance target will be displayed; position and size



the target so that it is filled by the reference object and press the shutter button all the way down to measure white balance (to select the most recent custom value and exit without measuring white balance, press DISP/BACK, or press MENU/OK to select the most recent value and display the fine-tuning dialog).

- If "COMPLETED!" is displayed, press MENU/OK to set white balance to the measured value
- If "UNDER" is displayed, raise exposure compensation and try again.
- If "OVER" is displayed, lower exposure compensation and try again.



IX: Color Temperature

Adjust white balance to match the color temperature of the light source.



Color temperature can be adjusted to make pictures "warmer" or "colder" or deliberately produce colors that differ radically from those in real life.

1 Select K in the white balance menu. The option currently selected for color temperature will be displayed.



2 Edit the color temperature using the focus stick (focus lever) and press MENU/OK.

A fine-tuning dialog will be displayed.



- You can also adjust color temperature in increments of 10 K by rotating the rear command dial.
 - Choose from values of from 2500 to 10000 K
 - To exit without fine-tuning white balance, press **DISP/BACK** after choosing a color temperature.
- 3 Highlight a fine-tuning amount using the focus stick.
- 4 Press MENU/OK. The changes will be applied. The selected color temperature will appear in the display.



Color Temperature

Color temperature is an objective measure of the color of a light source, expressed in Kelvin (K). Light sources with a color temperature close to that of direct sunlight appear white; light sources with a lower color temperature have a yellow or red cast, while those with a higher color temperature are tinged with blue.

DYNAMIC RANGE

Adjust dynamic range. Wide dynamic ranges reduce loss of detail in highlights for more natural results with high-contrast or backlit scenes.

Option		Description
AUTO	₽ <mark>100 100</mark> %	Choose for increased contrast.
AUIU	R200 200%	‡
₽ <mark>400 400</mark> %		Reduce loss of detail in highlights.

- Mottling may appear in pictures taken at higher values. Choose a value according to the scene.
- If AUTO is selected, the camera will automatically choose either 100 100% or 200 200% according to the subject and shooting conditions. Shutter speed and aperture will be displayed when the shutter button is pressed halfway.
 - 200 200% is available at sensitivities of from ISO 320 to ISO 12800, **400%** at sensitivities of from ISO 640 to 12800

D RANGE PRIORITY

Reduce loss of detail in highlights and shadows for natural-looking results when photographing high-contrast scenes.

Option	Description	
AUTO	Contrast is adjusted automatically in response to lighting con-	
AUIU	ditions.	
STRONG	Adjust dynamic range by a large amount for very high-contrast	
	scenes.	
WEAK	Adjust dynamic range by a smaller amount for moderately	
WEAR	high-contrast scenes.	
OFF	Contrast reduction off.	

- **♦ WEAK** is available at sensitivities of from ISO 320 to ISO 12800, **STRONG** at sensitivities of from ISO 640 to 12800
 - When an option other than **OFF** is selected, **TONE CURVE**, and **DYNAMIC RANGE** will be adjusted automatically; if you wish to adjust these settings manually, choose OFF.

TONE CURVE

With reference to a tone curve, adjust the appearance of highlights or shadows, making them harsher or softer. Choose higher values to make shadows and highlights harsher, lower values to make them softer.



Option	Description
HIGHLIGHTS	-2 to +4
SHADOWS	-2 to +4


COLOR

Adjust color density.



SHARPNESS

Sharpen or soften outlines.



HIGH ISO NR

Reduce noise in pictures taken at high sensitivities. Choose higher values to reduce noise and smooth outlines, lower values to leave outlines visible.



CLARITY

Increase definition while altering tones in highlights and shadows as little as possible. Choose higher values for increased definition, lower values for a softer effect.



The additional processing required at settings other than 0 increases the time need to save each shot

LONG EXPOSURE NR

Select **ON** to reduce mottling in long time-exposures.

Options		
ON	OFF	



The additional processing required when **ON** is selected increases save times.

LENS MODULATION OPTIMIZER

Select ON to improve definition by adjusting for diffraction and the slight loss of focus at the periphery of the lens.

Options	
ON	OFF

COLOR SPACE

Choose the gamut of colors available for color reproduction.

Option	Description	
sRGB	Recommended in most situations.	
Adobe RGB	For commercial printing.	

PIXEL MAPPING

Use this option if you notice bright spots in your pictures.

- 1 Press MENU/OK in the shooting display and select the ID IMAGE **QUALITY SETTING** tab.
- Highlight PIXEL MAPPING and press MENU/OK to perform pixel mapping.
- Results are not quaranteed.
 - Be sure the battery is fully charged before beginning pixel mapping.
 - Pixel mapping is not available when the camera temperature is elevated.
 - Processing may take a few seconds.

EDIT/SAVE CUSTOM SETTING

Save custom camera settings for commonly-encountered situations. Saved settings can be recalled by rotating the mode dial to positions (1 (CUSTOM 1) through (7 (CUSTOM 7) (83).

AUTO UPDATE CUSTOM SETTING

Choose whether changes to saved custom settings apply automatically.

Option	Description	
	Changes to custom settings banks CUSTOM 1 through CUSTOM 7 apply automatically.	
	Changes do not apply automatically. Any changes to custom settings must be applied manually (🗎 85).	

CUSTOM MODE SETTING

Choose whether the current custom settings bank is to be used for still photography or movie recording (\$\equiv\$ 83).

™ MOUNT ADAPTOR SETTING

Adjust settings for lenses attached via a mount adapter. The camera can store settings for multiple lenses (LENS 1 through LENS 6).

- OISTORTION CORRECTION, COLOR SHADING CORRECTION, and
 OHECOTOR SHADING CORRECTION.
 PERIPHERAL ILLUMINATION CORRECTION are available with lenses connected via an M mount adapter.
 - Any changes made using this item also apply in movie mode (EE 200).

FOCAL LENGTH SETTING

Enter the lens's true focal length.



DISTORTION CORRECTION


Choose from STRONG, MEDIUM, or WEAK options to correct BARREL or **PINCUSHION** distortion.



COLOR SHADING CORRECTION

Color (shading) variations between the center and edges of the frame can be adjusted separately for each corner.


To use color shading correction, follow the steps below.



- 1 Rotate the rear command dial to choose a corner. The selected corner is indicated by a triangle.
- 2 Use the focus stick (focus lever) to adjust shading until there is no visible difference in color between the selected corner and the center of the image.
 - Press the focus stick left or right to adjust colors on the cyan-red axis.
 - Press the focus stick up or down to adjust colors on the blue-yellow axis.
- To determine the amount required, adjust color shading correction while taking photos of blue sky or a sheet of gray paper.

PERIPHERAL ILLUMINATION CORRECTION

Choose from values between -5 and +5. Choosing positive values increases peripheral illumination, while choosing negative values reduces peripheral illumination. Positive values are recommended for vintage lenses, negative val-



ues to create the effect of images taken with an antique lens or a pinhole camera.



To determine the amount required, adjust peripheral illumination correction while taking photos of blue sky or a sheet of gray paper.

EDIT LENS NAME

Change the lens name.



AF/MF SETTING (Still Photography)

Adjust focus settings for still photography.

To display AF/MF settings, press MENU/OK in the photo shooting display and select the M (AF/MF SETTING) tab.





The options available vary with the shooting mode selected.

FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom (96).

FOCUS MODE

Choose how the camera focuses (\$\equiv 92\$).

AF MODE

Choose how the camera focuses in modes FS and FC (1994).

AF-C CUSTOM SETTINGS

Select focus-tracking options for CONTINUOUS AF focus mode. Choose from Sets 1 (SET 1) through 5 (SET 5) according to your subject or select SET 6 CUSTOM for custom focus-tracking options.



Option	Description
SET 1 MULTI PURPOSE	A standard tracking option that works well with the typical range of moving subjects.
SET 2 IGNORE OBSTACLES & CONTINUE TO TRACK SUBJECT	The focus system attempts to track the chosen subject. Choose with subjects that are hard to keep in the focus area or if other objects are likely to enter the focus area with the subject.
SET 3 FOR ACCELERATING/ DECELERATING SUBJECT	The focus system attempts to compensate for subject acceleration or deceleration. Choose for subjects prone to rapid changes in velocity.
SET 4 FOR SUDDENLY APPEARING SUBJECT	The focus system attempts to focus quickly on subjects entering the focus area. Choose for subjects that appear abruptly or when rapidly switching subjects.
SET 5 FOR ERRATICALLY MOVING & ACCEL./DECEL. SUBJECT	Choose for hard-to-track subjects prone not only to sudden changes in velocity but also to large movements front to back and left to right.
SET 6 CUSTOM	Adjust TRACKING SENSITIVITY, SPEED TRACKING SENSITIVITY, and ZONE AREA SWITCHING to suit your preferences based on the values for Sets 1–5 (148, 150).

Focus Tracking Options

The individual parameters that are part of a focus tracking set are described below.

TRACKING SENSITIVITY

This parameter determines how long the camera waits to switch focus when an object enters the focus area behind or in front of the current subject. The higher the value, the longer the camera will wait.



Options				
0	1	2	3	4

- ① The higher the value, the longer it takes the camera to refocus when you attempt to switch subjects.
 - The lower the value, the more likely the camera is to switch focus from your subject to other objects in the focus area.

SPEED TRACKING SENSITIVITY

This parameter determines how sensitive the tracking system is to changes in subject velocity. The higher the value, the greater the precision with which the system attempts to respond to sudden movement.



Options		
0	1	2



The higher the value, the more difficulty the camera will have focusing in situations in which autofocus does not perform well, such as when the subject is highly reflective or low in contrast.

ZONE AREA SWITCHING

This parameter determines the focus area given priority in zone AF.



Option	Description
FRONT	Zone AF assigns priority to the subjects closest to the camera.
	The camera locks focus on the subject at the center of the zone and then switches focus areas as necessary to track it.
CENTER	Zone AF assigns priority to subjects in the center of the zone.

This option takes effect only when **ZONE** is selected for AF mode.

-Set Values-

Parameter values for the different sets are listed below.

	TRACKING SENSITIVITY	SPEED TRACKING SENSITIVITY	ZONE AREA SWITCHING
SET 1	2	0	AUTO
SET 2	3	0	CENTER
SET 3	2	2	AUTO
SET 4	0	1	FRONT
SET 5	3	2	AUTO

Custom Focus Tracking Options

Follow the steps below to adjust settings for Set 6.

1 Select AF-C CUSTOM SETTINGS > SET 6 CUSTOM.



- 2 Highlight items using the focus stick (focus lever) and rotate the front command dial to change. To reset settings to their original values, press m.
- 3 Press DISP/BACK when settings are complete.

STORE AF MODE BY ORIENTATION

Choose whether the AF mode used when the camera is in portrait orientation is stored separately from that used when the camera is in landscape orientation.

Option	Description	
OFF	The same settings are used in both orientations.	
FOCUS AREA ONLY The focus area for each orientation can be selected se		
ON	The focus mode and focus area can be selected separately.	

AF POINT DISPLAY 🔟 🔲

Choose whether individual focus frames are displayed when **ZONE** or **WIDE/TRACKING** is selected for **MAF/MF SETTING** > **AF MODE**.

Options		
ON	OFF	

NUMBER OF FOCUS POINTS

Choose the number of focus points available for focus-point selection in manual focus mode or when **SINGLE POINT** is selected for **AF MODE**.

	Option	Description
117 POINTS (9 × 13)	Choose from 117 focus points arranged in a 9- by 13-point	
	11/ PUINI3 (3 × 13)	grid.
425 POINTS (17 × 25)	Choose from 425 focus points arranged in a 17- by 25-point	
	423 PUINTS (17 × 23)	grid.

PRE-AF

If **ON** is selected, the camera will continue to adjust focus even when the shutter button is not pressed halfway. The camera adjusts focus continuously, allowing it to focus faster when the shutter button is pressed halfway. Choosing this option helps prevent missed shots.

Options		
ON	OFF	

① Choosing **ON** increases the drain on the battery.

📥 📽 AF ILLUMINATOR

If **ON** is selected, the AF-assist illuminator will light to assist autofocus.

Options		
ON	OFF	

- The camera may be unable to focus using the AF-assist illuminator in some cases.
 - If the camera is unable to focus, try increasing the distance to the subject.
 - Avoid shining the AF-assist illuminator directly into your subject's eyes.
- Any changes made using this item also apply in movie mode (🕮 203).

If the camera detects human faces, it will assign them priority over the background and adjust settings appropriately for portraits when setting focus and exposure. You can also choose whether the camera focuses on the left or right eye when face detection is on.



Option	Description
	Adjust settings for Intelligent Face Detection. You can also adjust
	eye detection settings.
	• 🙎 EYE OFF: Intelligent Face Detection only.
	• [S] EYE AUTO: The camera automatically chooses which eye
FACE DETECTION	to focus on when a face is detected.
ON	• ●R RIGHT EYE PRIORITY : The camera focuses preferential-
UN	ly on the right eye of subjects detected using Intelligent Face
	Detection.
	• L● LEFT EYE PRIORITY: The camera focuses preferential-
	ly on the left eye of subjects detected using Intelligent Face
	Detection.
OFF	Intelligent Face Detection and eye priority off.



- If the subject moves as the shutter button is pressed, the face may not be in the area indicated by the green border when the picture is taken.
 - In some modes, the camera may set exposure for the frame as a whole rather than the portrait subject.
 - Enabling Intelligent Face Detection via FACE DETECTION ON automatically selects **OFF** for **SUBJECT DETECTION SETTING**.



- A single face detected in or near the focus area will be marked with a white frame
 - If multiple faces are detected in the focus area, the camera will select one automatically.
 - You can choose a different subject by tapping the display to reposition the focus area. The focus stick (focus lever) can also be used if **WIDE** is selected for **AF MODE**.
 - When **DIRECT AF POINT SELECTION** or **EDIT FOCUS AREA** is chosen for BUTTON/DIAL SETTING > FOCUS LEVER SETTING > **TILT** :, you can also switch subjects using the focus stick (focus lever) or (during viewfinder photography) touch controls (2 31).
 - When the camera is focused on an eye, you can switch from one eve to the other using a function button to which RIGHT/LEFT EYE **SWITCH** has been assigned.
 - If the selected subject leaves the frame, the camera will wait a set time for its return and consequently the white frame may sometimes appear in locations where no face is seen.
 - Depending on shooting conditions, face selection may be suspended at the close of burst shooting.
 - Faces can be detected with the camera in vertical or horizontal orientation.
 - If the camera is unable to detect the subject's eyes because they are hidden by hair, glasses, or other objects, the camera will instead focus on faces.
 - Face/eye detection options can also be accessed via shortcuts (286).

SUBJECT DETECTION SETTING

Choose whether the camera prioritizes subjects of a selected type, such as animals or vehicles, when setting focus.

Option	Description		
	Select one of the subject types listed below to enable subject		
	detection.		
	■ ★ ANIMAL: The camera detects and tracks focus on dogs and		
	cats.		
	 BIRD: The camera detects and tracks focus on birds. 		
• 😝 AUTOMOBILE: The camera detects and tracks for			
SUBJECT	the body or front ends of cars, primarily those of types used		
DETECTION ON	for motor sports.		
	• 56 MOTORCYCLE&BIKE: The camera detects and tracks		
	focus on the riders of motorcycles and bicycles.		
	• 🏲 AIRPLANE: The camera detects and tracks focus on the		
	cockpits, noses, or bodies of airplanes.		
	• 🖵 TRAIN: The camera detects and tracks focus on the driver		
	compartments or front ends of trains.		
OFF	Subject detection off.		



Enabling subject detection via **SUBJECT DETECTION ON** automatically selects **OFF** for **P FACE/EYE DETECTION SETTING**.



- A single subject of the chosen type detected in or near the focus area will be marked with a white frame
 - If multiple subjects are detected in the focus area, the camera will select one automatically.
 - You can choose a different subject by tapping the display to reposition the focus area. The focus stick (focus lever) can also be used if **WIDE** is selected for **AF MODE**.
 - When DIRECT AF POINT SELECTION or EDIT FOCUS AREA is chosen for BUTTON/DIAL SETTING > FOCUS LEVER SETTING > **TILT** :, you can also switch subjects using the focus stick (focus lever) or (during viewfinder photography) touch controls (2 31).
 - If the selected subject leaves the frame, the camera will wait a set time for its return and consequently the white frame may sometimes appear in locations where no subject of the chosen type is seen.
 - Depending on shooting conditions, subject detection may be suspended at the close of burst shooting.
 - Subjects can be detected with the camera in vertical or horizontal orientation.
 - Subject detection options can also be accessed via shortcuts (**286**).

AF+MF

If ON is selected and focus has been locked (whether by pressing the shutter button halfway or by other means), focus lock can be ended and focus adjusted manually by rotating the focus ring.

Options ON **OFF**

- Lenses with a focus distance indicator must be set to manual focus mode (MF) before this option can be used. Selecting MF disables the focus distance indicator
 - If the lens is equipped with a focus distance indicator, set the focus ring to the center, as the camera may fail to focus if the ring is set to infinity or the minimum focus distance.
- The previously-selected focus mode will be restored if no operations are performed for a set period after the focus ring is rotated.
 - DIGITAL SPLIT IMAGE and DIGITAL MICROPRISM focus assist options selected via **MF ASSIST** cannot be used

AF + MF Focus Zoom

Selecting ON for MAF/MF SETTING > FOCUS CHECK when SINGLE **POINT** is chosen for **AF MODE** lets you zoom in on the current focus area by rotating the focus ring. The zoom ratio can be selected using the rear command dial

MF ASSIST

Choose how focus is displayed in manual focus mode.

Option	Description	
DIGITAL SPLIT IMAGE	Displays a black-and-white (MONOCHROME) or color (COLOR) split image in the center of the frame. Frame the subject in the split-image area and rotate the focus ring until the four parts of the split image are correctly aligned.	
DIGITAL MICROPRISM	A grid pattern that emphasizes blur is displayed when the subject is out of focus, disappearing to be replaced by a sharp image when the subject is in focus.	
FOCUS PEAK HIGHLIGHT	The camera heightens high-contrast outlines. Choose a color and peaking level.	
OFF	Focus is displayed normally (focus peaking, digital split image, and digital microprism are not available).	

FOCUS CHECK

If ON is selected, the display will automatically zoom in on the selected focus area when the focus ring is rotated in manual focus mode.





- Press the focus stick (focus lever) to cancel focus zoom.
 - The zoom position is centered on the current focus area and changes when the focus area is changed.

INTERLOCK SPOT AE & FOCUS AREA

Select ON to meter the current focus frame when SINGLE AF or **CONTINUOUS AF** is selected for **FOCUS MODE**.

Options	
ON	OFF

INSTANT AF SETTING

Chooses how the camera focuses when a button to which focus lock or AF-ON is assigned is pressed with MANUAL FOCUS selected for **FOCUS MODE**.

Option	Description	
AF-S	The camera focuses when the button is pressed.	
AF-C The camera focuses while the button is pressed.		



Any changes made using this item also apply in movie mode (🕮 204).

☆☆ DEPTH-OF-FIELD SCALE

Choose the basis for the depth-of-field scale.

Option	Description
PIXEL BASIS	Provides a precision reference for use when assessing depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.
	Provides a practical reference for use when assessing depth of field for pictures that will be viewed at lower resolutions, for example as prints.




Any changes made using this item also apply in movie mode (🕮 204).

RELEASE/FOCUS PRIORITY

Choose how the camera focuses when the shutter button is pressed all the way down with SINGLE AF or CONTINUOUS AF selected for FOCUS MODE.

Option	Description	
DELEVE	Shutter response is prioritized over focus. Pictures can be taken when the camera is not in focus.	
FOULTS	Focus is prioritized over shutter response. Pictures can be only taken when the camera is in focus.	



📩 📽 AF RANGE LIMITER

Limit the range of available focus distances for increased focus speed.

Option	Description	
OFF	Focus limiter disabled.	
CUSTOM	Limit focus to a range of distances defined by a minimum and maximum. • OK: Limit focus to the selected range. • SET: Choose two objects and limit focus to the distance between them.	
PRESET1	Limit focus to a preset range.	
PRESET2		

- Choosing a focus range that includes distances shorter than the minimum focus distance of the lens disables the focus limiter.
 - The values listed and displayed for the focus limiter may differ from the actual focus distance.
 - Focus range can be set independently on lenses equipped with focus range selectors. Be sure that the option selected in the camera menus overlaps with that chosen with the lens.
- The following additional operations can be performed when CUSTOM is selected:
 - You can tap objects in the touch screen display to choose the focus range.
 - Instead of tapping an object in the display, you set the maximum focus distance to infinity by rotating the focus ring.
 - Any changes made using this item also apply in movie mode (204).

TOUCH SCREEN MODE

Choose the shooting operations performed using touch controls.

Mode	Description	
TOUCH SHOOTING	Tap your subject in the display to focus and release the shutter. In burst mode, pictures will be taken while you keep your finger on the display.	
AF AF OFF	 In focus mode (SINGLE AF), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the AF OFF icon. In focus mode (CONTINUOUS AF), the camera initiates focus when you tap your subject display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the AF OFF icon. In manual focus mode (MANUAL FOCUS), you can tap the display to focus on the selected subject using autofocus. 	
AREA AREA	Tap to select a point for focus or zoom. The focus frame will move to the selected point.	
OFF OFF	Touch controls disabled.	




To disable touch controls and hide the touch screen mode indicator, select OFF for ■ BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN SETTING.

Touch Controls for Focus Zoom

Different touch controls are used during focus zoom (focus check enabled).

Central Area


Tapping the center of the display performs the operations below.



Mode	Operation performed
TOUCH SHOOTING	SINGLE AF/MANUAL FOCUS: Take a picture
AF	SINGLE AF: AF
AF	MANUAL FOCUS: Instant AF
AREA	SINGLE AF: AF
AREA	MANUAL FOCUS: Instant AF
OFF	SINGLE AF/MANUAL FOCUS: OFF

Other Areas

Tapping other areas simply scrolls the display, whether during still photography or movie recording and regardless of the option selected for touch screen mode.





SHOOTING SETTING (Still Photography)

Adjust shooting options for still photography.

To display shooting settings, press MENU/OK in the photo shooting display and select the (SHOOTING SETTING) tab.



The options available vary with the shooting mode selected.



FILTER SETTING

Choose the filter used when the mode dial is rotated to FILTER (2 82).

SPORTS FINDER MODE

Take pictures using the crop in the center of the display. Choose this option for pictures of athletes, birds, and other moving subjects.



Option	Description
ON	Pictures are taken using a 1.25× crop, reducing the picture angle by an amount equivalent to increasing lens focal length by 1.25×; the crop is shown by a frame in the display.
OFF	The 1.25× crop is disabled.



- The I IMAGE QUALITY SETTING > IMAGE SIZE item in the shooting menu is fixed at M.
 - The sports finder is not available in modes that offer an electronic shutter.

PRE-SHOT ES A

To reduce the lag between your pressing the shutter button all the way down and the resulting picture being recorded to the memory card, the camera starts shooting with the electronic shutter when the shutter button is pressed halfway and saves a series shots starting just before the shutter button is pressed the rest of the way down.

Options		
ON	OFF	

- Pre-shot photography is available only when **ESELECTRONIC SHUTTER** is selected in **CH** (high speed burst) drive mode (171).
 - Flash photography is disabled.

SELF-TIMER

Choose a shutter release delay.

Option	Description	
☼ 2 SEC	The shutter is released two seconds after the shutter button is pressed. Use to reduce blur caused by the camera moving when the shutter button is pressed. The self-timer lamp blinks as the timer count	
	down.	
	The shutter is released ten seconds after the shutter button is pressed.	
€% 10 SEC	Use for photographs in which you wish to appear yourself. The	
	self-timer lamp blinks immediately before the picture is taken.	
OFF	Self-timer off.	

If an option other than OFF is selected, the timer will start when the shutter button is pressed all the way down. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press DISP/BACK.





- Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.
 - The self-timer turns off automatically when the camera is turned off.

SAVE SELF-TIMER SETTING

If **ON** is selected, the chosen self-timer setting will remain in effect after a picture is taken or the camera is turned off.

Options	
ON OFF	

SELF-TIMER LAMP

If **ON** is selected, the self-timer lamp will light during self-timer photography. Select **OFF** when shooting night scenes or in other situations in which you would prefer that the lamp remain unlit.

Options		
ON	OFF	

INTERVAL TIMER SHOOTING

Configure the camera to take photos automatically at a preset interval.



2 Use the focus stick (focus lever) to choose the interval and number of shots. Press MENU/OK to proceed.



3 Use the focus stick to choose the starting time and then press MENU/OK. Shooting will start automatically.



- ① Interval timer photography cannot be used at a shutter speed of "bulb" or with multiple exposure photography. In burst mode, only one picture will be taken each time the shutter is released.
- Use of a tripod is recommended.
 - We recommend using an AC-5VJ AC power adapter.
 - The display turns off between shots and lights a few seconds before the next shot is taken.
 - The display can be activated at any time by pressing the shutter button.
 - To continue shooting until the number of shots taken equals the number of exposures remaining at the time interval-timer photography started, set the number of shots to ∞ .

INTERVAL TIMER SHOOTING EXPOSURE SMOOTHING

Select **ON** to automatically adjust exposure during interval-timer photography to prevent it changing dramatically between shots.

Options		
ON	OFF	



- Large changes in subject brightness may make exposure appear erratic. We recommend that you choose shorter values for INTERVAL TIMER SHOOTING > INTERVAL with subjects that brighten or dim dramatically during shooting.
 - In manual mode (mode M), exposure smoothing is only available if an AUTO option is selected for ISO.

AE BKT SETTING

Adjust exposure bracketing settings.

Option	Description		
FRAMES/STEP SETTING	Choose the number of shots in the bracketing sequence and the amount exposure is varied with each shot. • FRAMES: Choose the number of shots in the bracketing sequence. • STEP: Choose the amount exposure is varied with each shot.		
1 FRAME/CONTINUOUS	 1 FRAME: The shots in the bracketing sequence are taken one at a time. CONTINUOUS: The shots in the bracketing sequence are taken in a single burst. 		
SEQUENCE SETTING	Choose the order in which the shots are taken.		

FILM SIMULATION BKT

Choose the three film simulation types used for film simulation bracketing (1998).

FOCUS BKT SETTING

Choose from **AUTO** and **MANUAL** focus bracketing modes (116).

PHOTOMETRY

Choose how the camera meters exposure (112 107).

SHUTTER TYPE

Choose the shutter type. Choose the electronic shutter to mute the shutter sound.

Option	Description		
MS MECHANICAL SHUTTER	Take pictures with the mechanical shutter.		
ES ELECTRONIC SHUTTER	Take pictures with the electronic shutter.		
EF E-FRONT CURTAIN Shutter	Take pictures with the electronic front curtain shutter.		
M·E MECHANICAL +	The camera chooses the mechanical or electronic		
ELECTRONIC	shutter according to shooting conditions.		
EF E-FRONT +	The camera chooses the mechanical or electronic		
MECHANICAL	front curtain shutter according to shooting conditions.		
FFE E-FRONT +	The camera chooses the mechanical, electronic, or		
MECHANICAL + ELECTRONIC	electronic front curtain shutter according to shooting		
MICHANICAL T ELECTRONIC	conditions.		

If EFE-FRONT CURTAIN SHUTTER is selected, MS MECHANICAL **SHUTTER** will automatically take effect at high shutter speeds.

- When using the electronic shutter, note the following:
 - Distortion may be visible in shots of moving subjects.
 - Distortion may also be visible in hand-held shots taken at high shutter speeds; use of a tripod is recommended.
 - Banding and fog may occur in shots taken under fluorescent lights or other flickering or erratic illumination.
 - When taking pictures with the shutter muted (\$\equiv 252\$), respect your subjects' image rights and right to privacy.
 - When using the electronic front-curtain shutter, note the following:
 - Faster shutter speeds are more likely to result in uneven exposure and loss of resolution in out-of-focus areas of the frame.
- The following restrictions apply when the electronic shutter is used:
 - Sensitivity is restricted to values of ISO 12800–160
 - · Long exposure noise reduction has no effect

FLICKER REDUCTION

Reduce flicker in pictures and the display when shooting under fluorescent lighting and other similar light sources.

Option	Description		
ALL FRAMES	Flicker reduction is applied to all frames continuous		
	shooting frame rate reduces.		
	Flicker measurement is taken prior to the first frame only		
FIRST FRAME	and the same reduction amount is applied to all subse-		
	quent frames that flicker may occur.		
OFF	Flicker reduction disabled.		



- Flicker reduction increases the time needed to record pictures.
 - Flicker reduction is not available during movie recording.

FLICKERLESS S.S. SETTING

Select ON to allow shutter speed to be fine-tuned to reduce flicker caused by LED lighting and the like.

Options		
ON	OFF	



This option takes effect only in modes **S** and **M**.

IS MODE

Turn image stabilization on or off.

Option	Description
CONTINUOUS	Image stabilization on.
SHOOTING ONLY	Image stabilization enabled only when the shutter button is released (or, if CONTINUOUS AF is selected for AF / MF SETTING > FOCUS MODE , while the shutter button is pressed halfway).
OFF	Image stabilization off; 🐠 appears in the display.



- The setting selected with the lens image stabilization switch, if any, takes priority over the setting chosen with IS MODE.
 - Note that vibration or camera sounds may be noticeable as image stabilization takes effect.

ISO

Adjust the camera's sensitivity to light (105).

📩 📽 COOLING FAN SETTING

Adjust settings for optional cooling fans (\$\equiv 334)\$.

Option	Description
AUTO1	The fan turns on automatically as required when camera
AUTUT	temperature rises and runs at slow speed.
	The fan turns on automatically as required when camera
AUTO2	temperature rises and runs at high speed. The increased
	fan noise may be audible in movies.
LOW	Run the fan continuously at low speed.
HIGH	Run the fan continuously at high speed. The increased fan
пічп	noise may be audible in movies.
OFF	Turn the fan off.

☆☆ WIRELESS COMMUNICATION

Connect to smartphones running the latest version of apps. The smartphone can then be used to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera



For more information, visit: https://app.fujifilm-dsc.com/



FLASH SETTING (Still Photography)

Adjust flash-related settings for still photography.

To display flash settings, press MENU/OK in the photo shooting display and select the [3] (FLASH SETTING) tab.



FLASH FUNCTION SETTING

Choose a flash control mode, flash mode, or sync mode or adjust the flash level. The options available vary with the flash.



For more information on flash settings, see "External Flash Units" (\$\square\$ 315) in "Peripherals and Optional Accessories".



RED EYE REMOVAL

Remove red-eye effects caused by the flash.

Option	Description	
FLASH	Flash red-eye reduction only.	
OFF	Flash red-eye reduction and digital red-eye removal off.	



Flash red-eye reduction can be used in TTL flash control mode.

TTL-LOCK MODE

Instead of adjusting flash level with each shot, TTL flash control can be locked for consistent results across a series of photographs.

Option	Description	
TOCK WITH LAST FLASH	Flash output is locked at the value metered for the most recent photo.	
	The camera emits a series of pre-flashes and locks flash output at the metered value.	



- To use TTL lock, assign **TTL-LOCK** to a camera control and then use the control to enable or disable TTL lock (#295).
 - Flash compensation can be adjusted while TTL lock is in effect.
 - Selecting LOCK WITH LAST FLASH displays an error message if no previously metered value exists.

LED LIGHT SETTING

Choose whether to use the flash unit's LED video light (if available) as a catchlight or AF-assist illuminator when taking photos.

Option	Role of LED video light in still photography
CATCHLIGHT	Catchlight
AF ASSIST	AF-assist illuminator
AF ASSIST+CATCHLIGHT	AF-assist illuminator and catchlight
OFF	None



In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu

COMMANDER SETTING

Choose groups when using the camera flash unit as a commander for Fujifilm optical wireless remote flash control. This option is available when the camera is used with clip-on flash units that support Fujifilm optical wireless flash control.

Options			
Gr A Gr B Gr C OFF			



In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu.

CH SETTING

Choose the channel used for communication between the commander and remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.

Options				
CH1 CH2 CH3 CH4				



MOVIE SETTING (Still Photography)

Adjust options for movies shot during still photography using the • (movie recording) button.

To display movie settings, press MENU/OK in the photo shooting display and select the **(MOVIE SETTING)** tab.



The options available vary with the shooting mode selected.



MOVIE MODE

This item is also found in the movie menus (11 183). Changes here also apply to the item in the movie menus.

HIGH SPEED REC

This item is also found in the movie menus (1991 184). Changes here also apply to the item in the movie menus.

MEDIA REC SETTING

This item is also found in the movie menus (11 185). Changes here also apply to the item in the movie menus.

S IS MODE

This item is also found in the movie menus (193). Changes here also apply to the item in the movie menus.

S IS MODE BOOST

This item is also found in the movie menus (\$\equiv\$ 193). Changes here also apply to the item in the movie menus.

AUDIO SETTING

Adjust audio-related settings for movie recording.

INTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in microphone.

Option	Description		
AUTO	The camera adjusts the recording level automatically.		
MANUAL	Adjust the recording level manually. Press the focus stick (focus lever) right to choose from 25 recording levels.		
OFF	Turn the built-in microphone off.		

EXTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for external microphones.

Option	Description		
AUTO	The camera adjusts the recording level automatically.		
	Adjust the recording level manually. Press the focus stick (focus lever) right to choose from 25 recording levels.		
OFF	Disable recording using external microphones.		

MIC JACK SETTING

Specify the type of hardware connected to the microphone jack.

Option	Description
MIC	Choose this option for direct connection to an external micro-
MIC	phone.
LINE	Choose this option for external audio devices connected via
LINE	line output.

MIC LEVEL LIMITER

Reduces distortion caused by input that exceeds the limits of the microphone's audio circuits.

Options		
ON OFF		

WIND FILTER

Choose whether to enable wind noise reduction during movie recording.

Options		
ON	OFF	

LOW CUT FILTER

Choose whether to enable the low-cut filter, reducing low-frequency noise during movie recording.

Options		
ON	OFF	

HEADPHONES VOLUME

Adjust the headphone volume.

Option	Description		
0	Mute output to the headphones.		
1—10	Choose a volume of from 1 to 10.		

XLR MIC ADAPTER SETTING

Adjust microphone input channel settings and the like for use with XLR microphone adapters.

Option	Description			
MIC INPUT CHANNEL	Record four-channel (quadraphonic) sound with the help of the camera's built-in microphone, or two-channel (stereo) sound using only a microphone connected via the XLR microphone adapter. • 4ch XLR+CAMERA: Record four-channel sound with the help of the camera's built-in microphone. • 2ch XLR ONLY: Record two-channel sound using only an external microphone connected via the XLR microphone adapter.			
4ch AUDIO MONITORING	Choose the source of sound output to headphones or other audio monitors during movie recording. • XLR: Monitor sound from external microphones connected via the XLR microphone adapter. • CAMERA: Monitor sound from camera's built-in microphone.			
HDMI 4ch AUDIO OUTPUT	Choose source of audio output to the HDMl connector. • XLR: Audio from external microphones connected via the XLR microphone adapter is output to the HDMl connector. • CAMERA: Audio from camera's built-in microphone is output to the HDMl connector.			




- If an external microphone is connected to the camera's microphone jack, audio will be recorded not via the camera's built-in microphone but via the external microphone instead.
 - Four-channel recording is available only when MOV is selected for movie file format



MOVIE SETTING (Movie Recording)

Adjust movie-recording options.

To display options for movie recording, press MENU/OK in the movie shooting display and select the **(MOVIE SETTING)** tab.



MOVIE SETTING LIST

View current movie recording settings.



These options can also be viewed by pressing the **DISP/BACK** button while the movie quick menu is displayed.

SHOOTING MODE

Choose a shooting mode for movies.

Options				
PROGRAM AE	SHUTTER	APERTURE	MANUAL	
	PRIORITY AE	PRIORITY AE	MANUAL	

MOVIE MODE

Before shooting movies, choose the frame rate and the frame size and aspect ratio.



- 1 In the shooting menu, select MOVIE SETTING, then highlight MOVIE MODE and press MENU/OK.
- 2 Press the focus stick (focus lever) up or down to highlight the desired frame size and aspect ratio (1) and press the stick right.
 - Choose 3:2 for 6.2 K movies with an aspect ratio of 3:2.
 - Choose **213 16:9** or **DCI 17:9** for 4K movies with aspect ratios of 16 or 17 to 9.
 - Choose 16:9 or 17:9 for Full HD movies with aspect ratios of 16 or 17 to 9.
- 3 Press the focus stick (focus lever) up or down to highlight a frame rate (2) and press the stick right.

Options					
23.98P	24P	25P	29.97P	50P	59.94P

The choice of frame rates varies with the movie mode.

HIGH SPEED REC

Record high-frame-rate movies. High-frame-rate movies can be played back in slow motion, giving you time to view fast-moving subjects or details too fleeting for the naked eye. Select ON to choose the recording and playback rates separately.



Choose **ON HDMI ONLY** to record footage only to external recorders connected via HDMI. Note that this option does not support playback frame-rate selection.

Frame Size

Options				
AK 16:9 DG 17:9 HD 16:9 HD 17:9				

Playback

Options					
23.98P	24P	25P	29.97P	50P	59.94P

Recording

Options			
100P	120P	200P	240P



- High-speed movies are recorded with no sound.
 - The footage recorded to the memory card is compressed with the goal of maintaining the selected bit rate.
 - The options available for playback rate vary with the option selected for rate of recording.

MEDIA REC SETTING

Choose movie file settings, including destination, file type, bit rate, and proxy video.

MEDIA REC SETTING

Choose movie file settings, including destination, file type, and compression.

Destination

Choose save options and save and output destinations for movies.

Option	Description
0	Movies are recorded only to the memory card in Slot 1.
2	Movies are recorded only to the memory card in Slot 2.
	Footage is recorded to the memory card in Slot 1 until the card
□→ 2	fills. Any additional footage will then automatically be record-
	ed to the card in Slot 2.
0+2	Each movie is recorded twice, once to each card.
HDMI	Movies are recorded only to devices connected via HDMI.

The current movie mode applies to both copies; settings for backup copies cannot be adjusted separately.

File Type and Compression

Choose the movie file type and compression.

Option	Description
MOV/H.264 420 ALL-I	A highly-portable compressed format. Footage is recorded at a depth of 8 bits using All-I interframe compression and 4:2:0 chroma sub-sampling.
MOV/H.264 420 Long GOP	A highly-portable compressed format. Footage is recorded at a depth of 8 bits using Long GOP interframe compression and 4:2:0 chroma sub-sampling.
MP4/H.264 Long GOP 420	A format suitable for movies that will be uploaded to the web.
MOV/H.265 420 ALL-I	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using All-I interframe compression and 4:2:0 chroma sub-sampling.
MOV/H.265 420 Long GOP	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using Long GOP interframe compression and 4:2:0 chroma sub-sampling.
MOV/H.265 422 ALL-I	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using All-I interframe compression and 4:2:2 chroma sub-sampling.
MOV/H.265 422 Long GOP	A format with a higher compression ratio than H.264. Footage is recorded at a depth of 10 bits using Long GOP interframe compression and 4:2:2 chroma sub-sampling.
MOV/ProRes 422 HQ *	Record movies in ProRes 422 HQ format.
MOV/ProRes 422 *	Record movies in ProRes 422 format.
MOV/ProRes 422 LT *	Record movies in ProRes 422 LT format.

^{*} Available only when \blacksquare is selected as the destination.



- The ProRes format is intended for the footage will be edited on a computer or the like.
 - 4:2:2 chroma sub-sampling is used for footage output to external devices connected via HDMI; H.264 footage is output at a bit depth of 8 bits and footage in other formats at a depth of 10 bits.
 - All-I compresses each frame separately. Files are larger, but the fact that the data for each frame are saved separately makes this a good choice for footage that will be further processed.
 - Long GOP balances good image quality with high compression. Files are smaller, making it a good choice for longer movies.
 - The options available for file type and compression vary with the options selected for MOVIE MODE, HIGH SPEED REC, and F-Log/HLG RECORDING.

Bit Rate

Choose the movie bit rate.

Options				
50Mbps	100Mbps	200Mbps	360Mbps	720Mbps



- The options available for bit rate vary with the settings chosen for high-speed movie recording and compression.
 - The bit rate for ProRes movies is set automatically according to the format chosen and the frame size and rate. For more information, visit the Apple website.

PROXY SETTING (ONLY WHEN REC ProRes)

Choose whether the camera simultaneously records a duplicate "proxy" video with movies shot in ProRes format.

Option	Description
ON (H264)	Record proxy videos in H.264 format.
ON (ProRes Proxy)	Record proxy videos in ProRes Proxy format.
OFF	Proxy recording disabled.



- Deleting the original footage from the camera also deletes the proxy video. The original and proxy videos cannot be deleted separately.
 - When deleting movies from camera memory cards using a computer, be sure to delete both the originals and the proxies.

HDMI OUTPUT SETTING

Adjust settings for use when the shooting display is output to an HDMI device.

HDMI OUTPUT INFO DISPLAY

If **ON** is selected, HDMI devices to which the camera is connected will mirror the information in the camera display.

Options	
ON	OFF

HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

Options	
ON	OFF

RAW OUTPUT SETTING

Choose whether to output RAW footage to external recorders connected via HDMI.

Option	Description
RAW OUTPUT SETTING ATOMOS	Output RAW footage to ATOMOS video recorders.
RAW OUTPUT SETTING Blackmagic	Output RAW footage to Blackmagic Design video recorders.
OFF	Do not output RAW footage to external recorders.



- RAW footage output to external devices is not saved to the memory cards inserted in the camera
 - In-camera image enhancements are not applied to the **RAW** output.
 - ISO sensitivity is restricted to values between ISO 1000 and ISO 12800.
 - Footage with a frame size of 4848 × 2728 (4.8 K) is recorded using a 1.29× crop.
 - Footage output to external devices is generated from the original RAW data and its quality, which varies with device specifications, may not be equal to that achieved as the end result of post-production or the like
 - Focus zoom is not available when **RAW** is selected for HDMI output.
 - RAW footage output via HDMI to incompatible devices will not display correctly but will instead will display as a mosaic.
 - RAW output is disabled in some movie and high-speed recording modes

FIX MOVIE CROP MAGNIFICATION

Fix the movie crop ratio at 1.38:1. This makes it easier to match crops after changing movie settings.

Options	
ON	OFF

F-Log/HLG RECORDING

Choose the destination for F-Log and HLG (Hybrid Log-Gamma) movies shot while the camera is connected to an HDMI device.

Option	Description
	The footage is processed using film simulation and both
NUMI	saved to the memory card and output to the HDMI device.
F-Log EM F-Log	The footage is recorded to the memory card and output to
F-LOG WM F-LOG	the HDMI device in F-Log format.
F-Log2 F-Log2	The footage is recorded to the memory card and output to
F-LOGZ	the HDMI device in F-Log format.
HLG HDMI HLG	The footage is recorded to the memory card and output to
	the HDMI device in HLG format.

- F-Log and F-Log2 offer gentle gamma curves with wide gamuts suitable for further processing post-production. Sensitivity is restricted to values between ISO 640 and ISO 12800 (F-Log) or between ISO 1250 and ISO 12800 (F-Log2).
 - The **HLG** (Hybrid Log-Gamma) recording format conforms to the international ITU-R BT2100 standard. When viewed on HLG-compatible displays, high-quality HLG footage faithfully captures high-contrast scenes and vivid colors. Sensitivity is restricted to values between ISO 1000 and ISO 12800.
 - Film simulation () footage is recorded using the option selected for **MAGE QUALITY SETTING > FILM SIMULATION** in the shooting menu

DATA LEVEL SETTING

Choose a signal range for movie recording.

Option	Description
VIDEO RANGE	The signal range for 8-bit movies is limited to 16–235 and that
VIDEO RANGE	for 10-bit movies to 64–940.
FULL RANGE	The signal ranges for 8-bit and 10-bit movies are respectively
	0–255 and 0–1023.

PHOTOMETRY

Options are the same as those for still photography, but settings must be adjusted separately (12 107).

FLICKERLESS S.S. SETTING

Options are the same as those for still photography, but settings must be adjusted separately (1991) 172).

Options	
ON	OFF

S IS MODE

Turn image stabilization on or off.

Option	Description
IBIS/OIS	Enable in-body (IBIS) and optical (OIS) image stabilization.
כוטוא/כוטו	IBIS is used with lenses that do not support OIS.
	Enable in-body (IBIS), optical (OIS), and digital (DIS) image
IBIS/OIS + DIS	stabilization. The crop is adjusted according to the option
	selected for MOVIE MODE .
OFF	Image stabilization off; 🍅 appears in the display.



- The setting selected with the lens image stabilization switch, if any, takes priority over the setting chosen with the IS mode.
 - Note that vibration or camera sounds may be noticeable as image stabilization takes effect

🞥 IS MODE BOOST

Choose the image stabilization level.

Option	Description					
ON	Suitable for hand-held shooting with no panning.					
OFF	Suitable for hand-held shooting with panning.					



Assigning **IS MODE BOOST** to a function button allows the image stabilization level to be changed while recording is in progress (\$\equiv 295\$).

№ ISO

Adjust the camera's sensitivity to light.

Option	Description
	Choose for special situations. Note that dynamic range may be reduced and that pictures may be mottled.
160-12800	Adjust sensitivity manually. Selected value is shown in display.
AUTO	Sensitivity is automatically adjusted in response to shooting conditions.

ZEBRA SETTING

Highlights that may be overexposed are shown by zebra stripes in the movie mode display.

Option	Description					
ZEBRA RIGHT	/// Right-slanting stripes.					
ZEBRA LEFT	Left-slanting stripes.					
OFF	Stripes off.					

ZEBRA LEVEL

Choose the brightness threshold for the zebra stripe display.

Options										
50	55	60	65	70	75	80	85	90	95	100

MOVIE OPTIMIZED CONTROL

Select **ON** to allow movie settings to be adjusted using only the command dials and touch-screen controls. You may find this helpful in preventing the sounds of camera controls being recorded with movies (E 33).

Options				
ON	OFF			

TALLY LIGHT

Choose the lamp (indicator or AF-assist) that lights during movie recording and whether the lamp blinks or remains steady.





Indicator lamp

AF-assist illuminator

Option	Description
FRONT OFF REAR	The indicator lamp lights during movie recording.
FRONT OFF REAR <u>a</u>	The indicator lamp blinks during movie recording.
FRONT <u> </u>	The indicator and AF-assist lamps light during movie recording.
FRONT REAR OFF	The AF-assist lamp lights during movie recording.
FRONT <u>o</u> Rear <u>o</u>	The indicator and AF-assist lamps blink during movie recording.
FRONT <u>o</u> Rear off	The AF-assist lamp blinks during movie recording.
FRONT OFF REAR OFF	The indicator and AF-assist lamps remain off during movie recording.

☆ ☆ COOLING FAN SETTING

This item is also found in the photo menus (11) 173).

EDIT/SAVE CUSTOM SETTING

Options are the same as those for still photography, but settings must be adjusted separately (1998).

AUTO UPDATE CUSTOM SETTING

This item is also found in the photo menus (11) 142).

☆☆ CUSTOM MODE SETTING

Choose whether the current custom settings bank is to be used for still photography or movie recording (\$\equiv\$ 83).

☆☆ WIRELESS COMMUNICATION

This item is also found in the photo menus (174).



IMAGE QUALITY SETTING (Movie Recording)

Adjust image quality settings for movies.

To display image quality settings, press MENU/OK in the movie shooting display and select the (IMAGE QUALITY SETTING) tab.





The options available vary with the shooting mode selected.

FILM SIMULATION

Options are the same as those for still photography, but settings must be adjusted separately (130).

MONOCHROMATIC COLOR

Options are the same as those for still photography, but settings must be adjusted separately (1991).

W WHITE BALANCE

Options are the same as those for still photography, but settings must be adjusted separately (134).

M DYNAMIC RANGE

Choose a dynamic range for movie recording.

Option	Description
₽ <mark>100</mark> 100%	
₽ <mark>200</mark> 200%	See "DYNAMIC RANGE" (🕮 138).
₽ <mark>400</mark> 400%]



- ♦ AUTO (automatic dynamic range control) is not available during movie recording.
 - R200 200% is available at sensitivities of from ISO 320 to ISO 12800. **400 400%** at sensitivities of from ISO 640 to 12800.
 - This item is available when The is selected for MOVIE **SETTING** > **F-Log/HLG RECORDING**.

TONE CURVE

Options are the same as those for still photography, but settings must be adjusted separately (1991).

COLOR

Options are the same as those for still photography, but settings must be adjusted separately (139).

SHARPNESS

Options are the same as those for still photography, but settings must be adjusted separately (139).

HIGH ISO NR

Options are the same as those for still photography, but settings must be adjusted separately (1140).

INTERFRAME NR

Select AUTO to automatically adjust interframe noise reduction according to shooting conditions.

Options				
AUTO	OFF			



May occur with moving subjects or if the camera is moved during shooting.

PERIPHERAL LIGHT CORRECTION

Select ON to enable peripheral illumination correction during movie recording.



- If **ON** is selected when a lens that does not transmit data to the camera is attached, peripheral illumination will be adjusted according to the option selected for **I**IMAGE QUALITY SETTING > → MOUNT ADAPTOR SETTING > PERIPHERAL ILLUMINATION CORRECTION in the shooting menu (# 145).
 - Select **OFF** if you notice banding in movies recorded using this option

This item is also found in the photo menus (1991). Changes to one apply to the other.



AF/MF SETTING (Movie Recording)

Adjust focus settings for movies.

To display AF/MF settings, press MENU/OK in the movie shooting display and select the M (AF/MF SETTING) tab.





The options available vary with the shooting mode selected.

🗯 FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom (96).



The focus area for movie recording cannot be resized.

FOCUS MODE

Choose the focus mode for movie recording.

Option	Description					
MF MANUAL FOCUS	Focus manually.					
IF :□ CONTINUOUS AF	The camera focuses using AF-C.					
⊞ -5 SINGLE AF	The camera focuses using AF-S.					

AF MODE

Choose how the camera selects the focus point for movie recording.


Option	Description					
MULTI	The camera selects the focus area automatically.					
AREA	The camera focuses on the subject in the selected focus area.					

AF-C CUSTOM SETTING

Select focus-tracking options when recording movies with CONTINUOUS AF selected for Procus MODE.

TRACKING SENSITIVITY

Choose how long the camera waits to switch focus when an object enters the focus area behind or in front of the current subject. See "TRACKING SENSITIVITY" (148).



- The higher the value, the longer it takes the camera to refocus when you attempt to switch subjects.
 - The lower the value, the more likely the camera is to switch focus from your subject to other objects in the focus area.

AF SPEED

Adjust the autofocus response speed. Choose higher values for faster response times, lower values for slower response times.

	Options									
-5	-4	-3	-2	-1	0	+1	+2	+3	+4	+5

AF ILLUMINATOR

This item is also found in the photo menus (152). Changes to one apply to the other.

FACE/EYE DETECTION SETTING

Enable or disable Intelligent Face Detection when recording movies.

Option	Description	
FACE DETECTION ON	See "♥ FACE/EYE DETECTION SETTING" (■ 153).	
OFF	Intelligent Face Detection and eye priority off.	

If SINGLE AF is chosen for FOCUS MODE when FACE DETECTION ON is selected for MAF/MF SETTING > PACE/EYE DETECTION SETTING, the camera will automatically switch to CONTINUOUS AF. Selecting MANUAL FOCUS when FACE DETECTION ON is selected for PACE/EYE DETECTION SETTING disables Intelligent Face Detection.

SUBJECT DETECTION SETTING

Options are the same as those for still photography, but settings must be adjusted separately (1998) 155).

If SINGLE AF is chosen for FOCUS MODE when SUBJECT DETECTION ON is selected for ■ AF/MF SETTING > SUBJECT DETECTION SETTING, the camera will automatically switch to CONTINUOUS AF.

AF+MF

Select **ON** to enable manual focus in **SINGLE AF** and **CONTINUOUS AF** modes. Manual focus can be suspended by pressing the **AFON** button.

Options	
ON	OFF

MF ASSIST

Choose how focus is displayed when MANUAL FOCUS is selected for FOCUS MODE.

Option	Description	
	The camera heightens high-contrast outlines. Choose a	
rocos r LAK midnilidini	color and peaking level.	
OFF	Focus is displayed normally (focus peaking is not available).	

FOCUS CHECK

Options are the same as those for still photography, but settings must be adjusted separately (158).

This item is also found in the photo menus (1991). Changes to one apply to the other.



Instant AF is disabled during movie recording. Use instant AF to focus before recording begins.

DEPTH-OF-FIELD SCALE

This item is also found in the photo menus (\$\equiv 159\$). Changes to one apply to the other.

AF RANGE LIMITER

This item is also found in the photo menus (161). Changes to one apply to the other.

TOUCH SCREEN MODE

Choose the shooting operations performed using touch controls.

Mode	Description	
Mode		
	Tapping the display focuses the camera on the selected point.	
	Use the shutter button to start and stop recording.	
	• When SINGLE AF is selected for FOCUS MODE , you can	
	refocus at any time by tapping your subject in the display.	
	• When CONTINUOUS AF is chosen for FOCUS MODE , the	
AF AF	camera will continuously adjust focus for changes in the dis-	
	tance to the subject at point selected by tapping the display.	
	• When MANUAL FOCUS is selected for FOCUS MODE , the	
	camera will focus using autofocus if you tap the display before	
	recording begins; during recording, you can tap the display	
	again to move the focus area to a new location.	
Tap to position the focus area. <i>Use the shutter button</i>		
	and stop recording.	
	• When SINGLE AF is selected for FOCUS MODE , you can	
	reposition the focus area at any time by tapping your subject	
	in the display. To focus, use the button to which AF-ON is as-	
AREA AREA	signed.	
	• When CONTINUOUS AF is chosen for FOCUS MODE , the	
	camera will continuously adjust focus for changes in the dis-	
	tance to the subject at point selected by tapping the display.	
	• When MANUAL FOCUS is selected for FOCUS MODE,	
	you can tap the display to position the focus area over your	
	subject.	
_	subject.	
OFF OFF	Touch controls disabled.	




To disable touch controls and hide the touch screen mode indicator, select OFF for ☑ BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN SETTING.

-Touch Controls for Focus Zoom-

Different touch controls are used during focus zoom (focus check enabled).

Central Area


Tapping the center of the display performs the operations below.



Mode	Operation performed
AF	SINGLE AF: AF
Ar	MANUAL FOCUS: Instant AF
	SINGLE AF: AF
AREA	MANUAL FOCUS: Instant AF
OFF	SINGLE AF/MANUAL FOCUS: OFF

Other Areas

Tapping other areas simply scrolls the display, whether during still photography or movie recording and regardless of the option selected for touch screen mode.



FOCUS CHECK LOCK

Choose whether focus zoom remains in effect once movie recording begins.

Options	
ON OFF	



AUDIO SETTING (Movie Recording)

Adjust settings for audio recorded during filming.

To display audio settings, press MENU/OK in the movie shooting display and select the ▲ (AUDIO SETTING) tab.



INTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in microphone.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Press the focus stick (focus lever) right to choose from 25 recording levels.
OFF	Turn the built-in microphone off.

EXTERNAL MIC LEVEL ADJUSTMENT

Adjust the recording level for external microphones.

Option	Description
AUTO	The camera adjusts the recording level automatically.
MANUAL	Adjust the recording level manually. Press the focus stick (focus lever) right to choose from 25 recording levels.
OFF	Disable recording using external microphones.

MIC JACK SETTING

Specify the type of hardware connected to the microphone jack.

Option	Description
MIC	Choose this option for direct connection to an external micro-
MIC	phone.
LINE	Choose this option for external audio devices connected via
	line output.

MIC LEVEL LIMITER

Reduces distortion caused by input that exceeds the limits of the microphone's audio circuits.

Options	
ON	OFF

WIND FILTER

Choose whether to enable wind noise reduction during movie recording.

Options	
ON	OFF

LOW CUT FILTER

Choose whether to enable the low-cut filter, reducing low-frequency noise during movie recording.

Options	
ON	OFF

HEADPHONES VOLUME

Adjust the headphone volume.

Option	Description	
0	Mute output to the headphones.	
1—10	Choose a volume of from 1 to 10.	

XLR MIC ADAPTER SETTING

Adjust microphone input channel settings and the like for use with XLR microphone adapters.

Option	Description
MIC INPUT CHANNEL	Record four-channel (quadraphonic) sound with the help of the camera's built-in microphone, or two-channel (stereo) sound using only a microphone connected via the XLR microphone adapter. • 4ch XLR+CAMERA: Record four-channel sound with the help of the camera's built-in microphone. • 2ch XLR ONLY: Record two-channel sound using only an external microphone connected via the XLR microphone adapter.
4ch AUDIO MONITORING	Choose the source of sound output to headphones or other audio monitors during movie recording. • XLR: Monitor sound from external microphones connected via the XLR microphone adapter. • CAMERA: Monitor sound from camera's built-in microphone.
HDMI 4ch AUDIO OUTPUT	 Choose source of audio output to the HDMl connector. XLR: Audio from external microphones connected via the XLR microphone adapter is output to the HDMl connector. CAMERA: Audio from camera's built-in microphone is output to the HDMl connector.



- If an external microphone is connected to the camera's microphone jack, audio will be recorded not via the camera's built-in microphone but via the external microphone instead.
 - Four-channel recording is available only when MOV is selected for movie file format



TIME CODE SETTING (Movie Recording)

Adjust time code (hour, minute, second, and frame number) display settings for movie recording.

To display time code settings, press MENU/OK in the movie shooting display and select the (TIME CODE SETTING) tab.



TIME CODE DISPLAY

Select **ON** to display time codes during movie recording and playback.

Options	
ON	OFF

START TIME SETTING

Choose the time code starting time.

Option	Description
	Highlight this option and press the focus stick (focus lever) right to choose a start time manually.
CURRENT TIME	Set the start time to the current time.
RESET	Set the start time to 00:00:00.

COUNT UP SETTING

Choose whether time is clocked continuously or only during movie recording.

Option	Description	
REC RUN	Time is clocked only during movie recording.	
FREE RUN	Time is clocked continuously.	

DROP FRAME

At frame rates of 59.94P, and 29.97P, a discrepancy will gradually develop between the time code (measured in seconds) and the actual recording time (measured in fractions of a second). Choose whether the camera drops frames as necessary to match the recording time to the time code.

Option	Description	
ON	The camera drops frames as necessary to maintain a strict	
UN	match between the time code and the actual recording time.	
OFF	Frames are not dropped.	



The time code display varies with the option selected.





• Selecting a frame rate of 23.98P disables frame drop.

HDMI TIME CODE OUTPUT

Choose whether time codes are output to HDMI devices.


Options	
ON	OFF

Playback and the Playback Menu

The Playback Display

This section lists the indicators that may be displayed during playback.


For illustrative purposes, displays are shown with all indicators lit.



The DISP/BACK Button


The **DISP/BACK** button controls the display of indicators during playback.






-Viewing Photo Information-

The photo information display changes each time the focus stick (focus lever) is pressed up.





Zooming in on the Focus Point


Press the center of the focus stick (focus lever) to zoom in on the focus point. Press again to return to full-frame playback.



Viewing Pictures

Read this section for information on playback zoom and multi-frame playback.

Use the rear command dial to go from full-frame playback to playback zoom or multi-frame playback.



Full-frame playback



Multi-frame playback









Hundred-frame view



Playback zoom







Medium zoom





Maximum zoom



Playback Zoom

Rotate the rear command dial right to zoom in on the current picture, left to zoom out. To exit zoom, press DISP/BACK or MENU/OK.



- The maximum zoom ratio varies with the option selected for **Ⅲ** IMAGE QUALITY SETTING > IMAGE SIZE.
 - Playback zoom is not available with cropped or resized copies saved at a size of 640.

-Scroll-

When the picture is zoomed in, the focus stick (focus lever) can be used to view areas of the image not currently visible in the display.



Navigation window

Multi-Frame Playback

To change the number of images displayed, rotate the rear command dial left when a picture is displayed full frame.



- Use the focus stick (focus lever) to highlight images and press MENU/OK to view the highlighted image full frame.
 - In the nine- and hundred-frame displays, press the focus stick up or down to view more pictures.



The Playback Menu

Adjust playback settings.

The playback menu is displayed when you press MENU/OK in playback mode.



SWITCH SLOT

Choose the card from which images will be played back.



Note: If two memory cards are inserted, you can press and hold the ▶ button to choose a card for playback.

RAW CONVERSION

Even if you don't have a computer, you can use the camera to modify RAW pictures and save them in other formats.

Saving RAW Pictures in Another Format

- 1 Display a RAW picture.
- 2 Highlight RAW CONVERSION in the playback menu.
- 3 Press MENU/OK.
 A list of settings will be displayed.



- 4 Press the focus stick (focus lever) up or down to highlight a setting.
- 5 Press the focus stick right to display options.



- 6 Press the focus stick up or down to highlight the desired option.
- 7 Press MENU/OK to select the highlighted option. The settings list shown in Step 3 will be displayed. Repeat Steps 4 to 7 to adjust additional settings.
- 8 Press the Q button.
 A preview of the copy will be displayed.
- 9 Press MENU/OK. The copy will be saved.
- RAW conversion options can also be displayed by pressing the **Q** button when a RAW pictures is displayed during playback.

The settings that can be adjusted when converting pictures from RAW to another format are:

Setting	Description
DEFLECT CHANTING COMP	Create a copy using the settings in effect at the time
REFLECT SHOOTING COND.	the photo was taken.
FILE TYPE	Choose a file format.
IMAGE SIZE	Choose an image size.
IMAGE QUALITY	Adjust image quality.
PUSH/PULL PROCESSING	Adjust exposure.
DYNAMIC RANGE	Enhance details in highlights for natural contrast.
	Reduce loss of detail in highlights and shadows
D RANGE PRIORITY	for natural-looking results when photographing
	high-contrast scenes.
FILM SIMULATION	Simulate the effects of different types of film.
	Choose a monochrome tint for photographs tak-
MONOCHROMATIC COLOR	en using FILM SIMULATION > AT ACROS and
	B MONOCHROME.
GRAIN EFFECT	Add a film grain effect.
	Increase the range of tones available for rendering
COLOR CHROME EFFECT	colors that tend to be highly saturated, such as reds,
	yellows, and greens.
COLOR CHROME FX BLUE	Increase the range of tones available for rendering
COLON CHROME IX DEGL	blues.
WHITE BALANCE	Adjust white balance.
WB SHIFT	Fine-tune white balance.
TONE CURVE	Adjust highlights and shadows.
COLOR	Adjust color density.
SHARPNESS	Sharpen or soften outlines.
HIGH ISO NR	Process the copy to reduce mottling.
CLARITY	Increase definition.
LENS MODULATION OPTIMIZER	Improve definition by adjusting for diffraction and
LENS MODULATION OF HMIZER	the slight loss of focus at the periphery of the lens.
COLOR SPACE	Choose the color space used for color reproduction.
HDR MODE	Reduce loss of detail in highlights and shadows.

① Some settings may be unavailable depending on the options chosen when the picture was taken.

HEIF TO JPEG/TIFF CONVERSION

Convert HEIF pictures to JPEG or TIFF.

SELECT IMAGES

Select HEIF pictures for conversion.

FILE FORMAT

Choose a format for the converted pictures.

Options		
JPEG	TIFF 8bit	TIFF 16bit

SELECT SLOT TO RECORD

Choose the memory card to which the converted pictures will be saved.

Options	
SLOT 1	SLOT 2

ERASE

Delete individual pictures, multiple selected pictures, or all pictures.

Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.

Option	Description
FRAME	Delete pictures one at a time.
SELECTED FRAMES	Delete multiple selected pictures.
ALL FRAMES	Delete all unprotected pictures.

FRAME

- 1 Select FRAME for ERASE in the playback menu.
- **2** Press the focus stick (focus lever) left or right to scroll through pictures and press **MENU/OK** to delete.
- A confirmation dialog is not displayed before pictures are deleted; be sure the correct picture is selected before pressing **MENU/OK**.
 - Additional pictures can be deleted by pressing MENU/OK. Press the focus stick left or right to scroll through pictures and press MENU/OK to delete.

SELECTED FRAMES

- 1 Select **SELECTED FRAMES** for **ERASE** in the playback menu.
- 2 Highlight pictures and press MENU/OK to select.
 - Selected pictures are indicated by check marks (
 - To deselect a highlighted picture, press MENU/OK again.
- 3 When the operation is complete, press DISP/BACK to display a confirmation dialog.
- 4 Highlight OK and press MENU/OK to delete the selected pictures.
- Pictures in photobooks or printer orders are shown by **1**.

ALL FRAMES

- 1 Select ALL FRAMES for ERASE in the playback menu.
- **2** A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK** to delete all unprotected pictures.
- Pressing **DISP/BACK** cancels deletion; note that any pictures deleted before the button was pressed cannot be recovered.
 - If a message appears stating that the selected images are part of a DPOF print order, press MENU/OK to delete the pictures.

SIMULTANEOUS DELETE

Taking photos with **SEPARATE** selected for **SAVE DATA SET-UP** > **CARD SLOT SETTING** creates two copies. Choose whether deleting the RAW image will also delete the JPEG or HEIF copy.

	Option	Description
	ON	Deleting the RAW image from the card in Slot 1 also deletes the
	UN	JPEG or HEIF copy from the card in Slot 2.
OFF		Deleting the RAW image from the card in Slot 1 does not delete
	UFF	the JPEG or HEIF copy from the card in Slot 2.

CROP

Create a cropped copy of the current picture.

- 1 Display the desired picture.
- **>** Select **CROP** in the playback menu.
- 3 Use the rear command dial to zoom in and out and press the focus stick (focus lever) up, down, left, or right to scroll the picture until the desired portion is displayed.
- 4 Press MENU/OK to display a confirmation dialog.
- 5 Press MENU/OK again to save the cropped copy to a separate file.
- The higher the zoom ratio, the smaller the number of pixels in the cropped copy.
 - If the size of the final copy will be 640, YES will be displayed in yellow.
 - All copies have an aspect ratio of 3:2.

RESIZE


Create a small copy of the current picture.

- 1 Display the desired picture.
- 2 Select **RESIZE** in the playback menu.
- 3 Highlight a size and press MENU/OK to display a confirmation dialog.
- 4 Press MENU/OK again to save the resized copy to a separate file.
- The sizes available vary with the size of the original image.

PROTECT

Protect pictures from accidental deletion. Highlight one of the following options and press MENU/OK.

Option	Description
FRAME	Protect selected pictures. Press the focus stick (focus lever) left or right to view pictures and press MENU/OK to select or deselect.
	Press DISP/BACK when the operation is complete. Protect all pictures.
RESET ALL	Remove protection from all pictures.





- Protecting images currently selected for upload to paired smartphones or tablets removes upload marking.
 - Protection can also be added or removed by pressing the Fn1 button during playback.

IMAGE ROTATE

Rotate pictures.

- 1 Select ON for **☑** SCREEN SET-UP > AUTOROTATE PB.
- 2 Display the desired picture.
- 3 Select IMAGE ROTATE in the playback menu.
- 4 Press the focus stick (focus lever) down to rotate the picture 90° clockwise, up to rotate it 90° counterclockwise.
- 5 Press MENU/OK. The picture will automatically be displayed in the selected orientation whenever it is played back on the camera.
- Protected pictures cannot be rotated. Remove protection before rotating pictures.
 - The camera may not be able to rotate pictures created with other devices. Pictures rotated on the camera will not be rotated when viewed on a computer or on other cameras.
 - Pictures taken with SCREEN SET-UP > AUTOROTATE PB are automatically displayed in the correct orientation during playback.

VOICE MEMO SETTING

Add a voice memo to the current photograph.

- 1 Select ON for VOICE MEMO SETTING in the playback menu.
- 2 Display a photo to which you wish to add a voice memo.
- **3** Press and hold the **AFON** button to record a voice memo. Recording ends after 30 s or when you release the button.
- The new memo will be recorded over any existing memos.
 - Voice memos cannot be added to protected pictures.
 - Deleting the picture also deletes the memo.

-Playing Voice Memos-

Pictures with voice memos are indicated by 🗣 icons during playback.

- To play the memo, press the **AFON** button.
- A progress bar will be displayed while the memo plays back.
- Volume can be adjusted by pressing MENU/OK to pause playback and then
 pressing the focus stick (focus lever) up or down to adjust the volume.
 Press MENU/OK again to resume playback. Volume can also be adjusted using SOUND SET-UP > PLAYBACK VOLUME.

RATING

Rate pictures using stars.

- 1 Select **RATING** in the playback menu.
- 2 Rotate the front command dial to choose a picture and the rear command dial to choose a rating of from 0 to 5 stars ("★").
- The focus stick (focus lever) can be used in place of the front command dial to choose a picture.
 - The rating dialog can also be displayed by pressing the AEL button in single-frame, nine-frame, or hundred-frame playback.
 - Use touch controls to zoom in or out.
 - Ratings cannot be applied to:
 - Protected pictures
 - Movies
 - "Gift" pictures (pictures taken with other cameras)

COPY

Copy pictures between the cards in the first and second slots.

- 1 Select COPY in the playback menu.
- 2 Highlight one of the following options.

Option	Description	
SLOT1 → SLOT2	Copy pictures from the card in the first slot to the card in the second slot.	
,	the second slot.	
CLOTA -> CLOTA	Copy pictures from the card in the second slot to the card	
JL012 -y JL011	in the first slot.	

- 3 Press the focus stick (focus lever) right.
- 4 Highlight one of the following options and press MENU/OK.

Option	Description	
	Copy selected pictures. Press the focus stick left or right to	
FRANL	view pictures and press MENU/OK to copy the current picture.	
ALL FRAMES	Copy all pictures.	

- Copying ends when the destination is full.
 - If you attempt to copy a file over 4 GB in size to a memory card with a capacity of 32 GB or less, copying will end and the file will not be copied.

TRANSFER IMAGE TO SMARTPHONE

Select photos for upload to a paired smartphone or tablet via Bluetooth.

- For information on pairing the camera with a smartphone or tablet, visit: https://fujifilm-dsc.com/en/manual/x-h2s_connection/
 - 1 Select TRANSFER IMAGE TO SMARTPHONE > SELECT IMAGE & TRANSFER.
 - Select **RESET** to remove "upload to smartphone" marking from all pictures before proceeding.
 - 2 Mark pictures for upload. Highlight pictures and press MENU/OK to mark them for upload.
 - To switch to the memory card in the other slot or display only pictures that meet selected criteria, press DISP/BACK before marking begins.
 - To select all pictures, press the Q button.
 - Selecting any two pictures with the AEL button also selects all pictures between them.
 - 3 Press DISP/BACK and select START TRANSFER.

The selected pictures will be uploaded.





Filtering Pictures/Choosing a Slot-

To switch to the memory card in the other slot or display only pictures that meet selected criteria, press **DISP/BACK** in the picture-selection dialog.

- To display only pictures that meet selected criteria, choose FILTERING.
- To switch to the memory card in the other slot. choose SWITCH MEMORY CARD SLOT.







- Image transfer orders can contain a maximum of 999 pictures.
 - The following cannot be selected for upload:
 - Protected pictures
 - Movies
 - RAW images
 - "Gift" pictures (pictures taken with other cameras)
 - If ON is selected for both IMAGE TRANSFER WHILE POWER OFF and Bluetooth/SMARTPHONE SETTING > Bluetooth ON/OFF in the network/USB settings menu, upload to the paired device will continue even while the camera is off.
 - When □ SMARTPHONETRANSFER ORDER is selected for □ BUTTON/ **DIAL SETTING** > ISO BUTTON SETTING, the picture-selection dialog can be displayed by pressing the **ISO** button.

☆ ☆ WIRELESS COMMUNICATION

Connect to smartphones running the latest apps. The smartphone can then be used to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera



- For downloads and other information, visit: https://app.fujifilm-dsc.com/
 - If **? WIRELESS COMMUNICATION** is selected for **☑ BUTTON**/ **DIAL SETTING** > **ISO BUTTON SETTING**, you can connect to the smartphone using the ISO button.

SLIDE SHOW

View pictures in an automated slide show. Press MENU/OK to start and press the focus stick (focus lever) right or left to skip ahead or back. Press DISP/BACK at any time during the show to view onscreen help. The show can be ended at any time by pressing MENU/OK.



The camera will not turn off automatically while a slide show is in progress

PHOTOBOOK ASSIST

Create books from your favorite photos.

Creating a Photobook

- 1 Select NEW BOOK for Delay BACK MENU > PHOTOBOOK ASSIST.
- 2 Scroll through the images and press the focus stick (focus lever) up to select or deselect. Press MENU/OK to exit when the book is complete.
 - Neither photographs 60 or smaller nor movies can be selected for photobooks.
 - The first picture selected becomes the cover image. Press the focus stick down to select the current image for the cover instead.
- 3 Highlight COMPLETE PHOTOBOOK and press MENU/OK (to select all photos for the book, choose SELECT ALL). The new book will be added to the list in the photobook assist menu.
- Books can contain up to 300 pictures.
 - Books that contain no photos are automatically deleted.

Viewing Photobooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the focus stick (focus lever) left or right to scroll through the pictures.

Editing and Deleting Photobooks

Display the photobook and press **MENU/OK**. The following options will be displayed; select the desired option and follow the onscreen instructions.


- EDIT: Edit the book as described in "Creating a Photobook".
- ERASE: Delete the book.

PRINT ORDER (DPOF)

Create a digital "print order" for DPOF-compatible printers.

- 1 Select PLAY BACK MENU > PRINT ORDER (DPOF).
- **)** Select WITH DATE to print the date of recording on pictures, WITHOUT DATE to print pictures without dates, or **RESET ALL** to remove all pictures from the print order before proceeding.
- 3 Display a picture you wish to include in or remove from the print order.
- 4 Press the focus stick (focus lever) up or down to choose the number of copies (up to 99).

To remove a picture from the order, press the focus stick down until the number of copies is 0.



- Repeat steps 3–4 to complete the print order.
- 5 The total number of prints is displayed in the monitor. Press MENU/OK to exit.
- during playback.
 - Print orders can contain a maximum of 999 pictures from a single memory card.
 - If a memory card is inserted containing a print order created by another camera, you will need to delete the order before creating as described above

instax PRINTER PRINT

To print pictures to optional Fujifilm instax SHARE printers, first select instax PRINTER CONNECTION SETTING in the network/ USB settings menu and enter the instax SHARE printer name (SSID) and password, then follow the steps below.

- 1 Turn the printer on.
- 2 Select PLAY BACK MENU > instax PRINTER PRINT. The camera will connect to the printer.




3 Use the focus stick (focus lever) to display the picture you want to print, then press MENU/OK. The picture will be sent to the printer and printing will start.



- Pictures taken with other cameras cannot be printed.
 - The area printed is smaller than the area visible in the LCD monitor
 - The displays may vary depending on the printer connected.

DISP ASPECT

Choose the aspect ratio used for the display of still pictures on High Definition (HD) devices (this option is available only when an HDMI cable is connected).



Options		
16:9	3:2	

Choose **16:9** to display photos with an aspect ratio of 3:2 full screen. The pictures will be displayed full screen with tops and bottoms cropped out.

MEMO





Network/USB Setting Menus

Adjust camera network and USB settings.

For more information on the network/USB settings menu, visit: https://fujifilm-dsc.com/en/manual/x-h2s_connection/

The Setup Menus



USER SETTING

Adjust basic camera settings.

To access basic camera settings, press MENU/OK, select the (SET UP) tab, and choose USER SETTING.



FORMAT

To format a memory card:

- 1 Select **☑ USER SETTING** > **FORMAT** in the **☑** (**SET UP**) tab.
- 2 Highlight the slot containing the card you wish to format and press MENU/OK.
- 3 A confirmation dialog will be displayed. To format the memory card, highlight OK and press MENU/OK.
 - To exit without formatting the memory card, select **CANCEL** or press **DISP/BACK**.



- All data—including protected pictures—will be deleted from the memory card. Be sure important files have been copied to a computer or other storage device.
 - Do not open the battery-chamber cover during formatting.
- Format options can also be displayed by pressing the selector down (♥) while holding the m (delete) button.

AREA SETTING

Adjust settings for your current time zone.

AREA SETTING

Choose your time zone from a map.

DAYLIGHT SAVINGS

Turn daylight saving time on or off.

Option	Description
ON	Daylight saving time on.
OFF	Daylight saving time off.

DATE/TIME

To set the camera clock:

- 1 Select **USER SETTING** > **DATE/TIME** in the **(SET UP)** tab.
- 2 Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the focus stick up or down.
- **3** Press **MENU/OK** to set the clock.

TIME DIFFERENCE

Switch the camera clock instantly from your home time zone to the local time at your destination when traveling. To specify the difference between your local and home time zone:

- - 1 Highlight + LOCAL and press MENU/OK.
 - 2 Use the focus stick (focus lever) to choose the local time zone. Press MENU/OK when settings are complete.
 - Select **ON** to enable daylight saving time.

To set the camera clock to local time, highlight ← LOCAL and press MENU/OK. To set the clock to the time in your home time zone, select ♠ HOME.



If ← LOCAL is selected, ← will be displayed in yellow for about three seconds when the camera is turned on.

■● 言語/LANG.

Choose a language.

MY MENU SETTING

Edit the items listed in the **(MY MENU)** tab, a personalized custom menu of frequently-used photo menu options (**()** 287).

MY MENU SETTING

Edit the items listed in the **(MY MENU)** tab, a personalized custom menu of frequently-used movie menu options (**E)** 287).

SENSOR CLEANING

Remove dust from the camera image sensor.

Option	Description	
OK	Clean the sensor immediately.	
WHEN SWITCHED ON	Sensor cleaning will be performed when the camera is turned on.	
WHEN SWITCHED OFF	Sensor cleaning will be performed when the camera tu	



Dust that cannot be removed using sensor cleaning can be removed using a blower (## 356).

BATTERY AGE

Check battery age. Age is expressed as a number between 0 and 4. The higher the number, the older the battery.



The older the battery, the faster it loses its charge. We recommend that batteries be replaced as they wear out.

RESET

Reset shooting or setup menu options to default values.

1 Highlight the desired option and press MENU/OK.

Option	Description		
	Reset all photo menu settings other than custom white		
STILL MENU RESET	balance and custom settings banks created using EDIT/		
	SAVE CUSTOM SETTING to default values.		
	Reset all movie menu settings other than custom white		
MOVIE MENU RESET	T balance and custom settings banks created using EDIT SAVE CUSTOM SETTING to default values.		
	Reset all setup menu settings other than DATE/TIME ,		
SET-UP RESET	♠ AREA SETTING, TIME DIFFERENCE, and		
	COPYRIGHT INFO to default values.		
INITIALIZE	Reset all settings.		

2 A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK**.

REGULATORY

To view electronic copies of the product model number, and other certificates, select **Z** USER SETTING > REGULATORY in the setup menu.



SOUND SETTING

Make changes to camera sounds.

To access sound settings, press MENU/OK, select the (SET UP) tab, and choose SOUND SET-UP.



AF BEEP VOL.

Choose the volume of the beep that sounds when the camera focuses. The beep can be muted by selecting **4OFF**.



SELF-TIMER BEEP VOL.

Choose the volume of the beep that sounds while the self-timer is active. The beep can be muted by selecting **•(OFF**.



OPERATION VOL.

Adjust the volume of the sounds produced when camera controls are operated. Choose **••OFF** to disable control sounds.

Options		
•(•••) (high) •(•• (medium) •(• (low) •(0FF (mute)		

MSEF ELECTRONIC SHUTTER VOLUME

Adjust the volume of the sounds produced by the mechanical or electronic front-curtain shutter.

Options			
•(•1) (high)	■ (medium)	■ (low)	■ (OFF (mute)

MS EF ELECTRONIC SHUTTER SOUND

Choose the sound made by the mechanical or electronic front-curtain shutter.

Options		
♪ 1 SOUND 1	♪ 2 SOUND 2	♪ 3 SOUND 3

ES ELECTRONIC SHUTTER VOLUME

Adjust the volume of the sounds produced by the electronic shutter. Choose **4OFF** to disable the shutter sound.

Options		
-(-1) (high) -(-1) (medium) -(-1) (low) -(OFF (mute)		

ES ELECTRONIC SHUTTER SOUND

Choose the sound made by the electronic shutter.

Options		
♪ 1 SOUND 1	♪ 2 SOUND 2	♪ 3 SOUND 3

PLAYBACK VOLUME

Adjust the volume for movie playback.



4ch AUDIO PLAYBACK

Adjust audio settings for use when viewing 4ch movies.

Option	Description	
XLR	The camera plays audio recorded via external micro- phones connected via the XLR microphone adapter.	
	The camera plays audio recorded via the camera's built-in microphone or external microphones connected via the microphone jack.	

You can also switch sources while viewing the playback display by pressing the center of the focus stick (focus lever).



SCREEN SETTING

Make changes to display settings.

To access display settings, press MENU/OK, select the (SET UP) tab, and choose SCREEN SET-UP.



VIEW MODE SETTING

Adjust settings for eye sensor, EVF (electronic viewfinder), or LCD monitor view modes (18).

EVF BRIGHTNESS

Adjust the brightness of the display in the electronic viewfinder.

Option	Description
	The camera automatically adjusts brightness around a selected level in response to changes in ambient lighting conditions.
ΜΔΝΙΙΔΙ	Adjust brightness manually; choose from options between -7 and $+5$.

EVF COLOR

Adjust the saturation of the display in the electronic viewfinder.



EVF COLOR ADJUSTMENT

Adjust the color of the display in the electronic viewfinder.

1 Adjust colors using the focus stick (focus lever).



2 Press MENU/OK.

LCD BRIGHTNESS

Adjust monitor brightness.



LCD COLOR

Adjust monitor saturation.



LCD COLOR ADJUSTMENT

Adjust the color of the display in the LCD monitor.

- 1 Adjust colors using the focus stick (focus lever).
- 2 Press MENU/OK.

IMAGE DISP.

Choose how long images are displayed after shooting.

Option	Description
CONTINUOUS	Pictures are displayed until the MENU/OK button is pressed or the shutter button is pressed halfway. To zoom in on the active focus point, press the center of the focus stick (focus lever); press again to cancel zoom.
1.5 SEC	Pictures are displayed for the selected time or until the shutter
0.5 SEC	button is pressed halfway.
OFF	Pictures are not displayed after shooting.



- Colors may differ slightly from those in the final image.
 - "Noise" mottling may be visible at high sensitivities.

AUTOROTATE DISPLAYS

Choose whether the indicators in the viewfinder and LCD monitor rotate to match camera orientation.

Options	
ON OFF	

PREVIEW EXP./WB IN MANUAL MODE

Choose whether to enable exposure and/or white balance preview in manual exposure mode.

Option	Description
PREVIEW EXP./WB	Enable exposure and white balance preview.
	Preview white balance only. Choose this option in situations in
PREVIEW WB	which exposure is likely to change during shooting, as may be
	the case when you use a flash during daylight.
	Disable exposure and white balance preview. Choose this op-
UFF	tion in situations in which both exposure and white balance
	are likely to change during shooting, as may be the case when
	you use a flash with an incandescent monitoring lamp.

NATURAL LIVE VIEW

Choose whether the effects of film simulation, white balance, and other settings are visible in the monitor.

Option	Description
ON	The effects of camera settings are not visible in the monitor, but shadows in low-contrast, back-lit scenes and other hard-to-see subjects more visible. Colors and tone will differ from those in the final picture. The display will however be adjusted to show the effects of monochrome and sepia settings.
UFF	The effects of film simulation, white balance, and other settings can be previewed in the monitor.

F-Log VIEW ASSIST

Select **ON** to display a tone-corrected preview (equivalent to BT.709) when recording or viewing F-log movies.


Options	
ON	OFF

ELECTRONIC LEVEL SETTING

Adjust settings for use when taking pictures using the virtual horizon display (1992).

FRAMING GUIDELINE

Choose a framing grid for shooting mode.



Framing guides are not shown at default settings but can be displayed using SCREEN SET-UP > DISP. CUSTOM SETTING (1992) 23).

AUTOROTATE PB

Choose **ON** to automatically rotate "tall" (portrait-orientation) pictures during playback.

Options	
ON	OFF

FOCUS SCALE UNITS

Choose the units used for the focus distance indicator.

Options	
METERS	FEET

APERTURE UNIT FOR CINEMA LENS

Choose whether the camera displays aperture as a T-number (used for movie camera lenses) or an f/-number (used for still camera lenses) when an optional FUJINON MKX-series lens is attached. For information on using cinema lenses, see the documentation provided with the lens.

Option	Description
T NUMBER	A measure of lens aperture commonly used by cinematogra- phers. Lens transmittance is taken into account to better cal-
	culate exposure.
ENIIMRED	A measure of lens aperture commonly used by photographers.
	Lens transmittance is assumed to be 100%, meaning that the
	same aperture may produce different exposures depending on
	the lens.

DUAL DISPLAY SETTING

Choose the content of the two windows in the dual display.

Option	Description
	The right (small) window shows a close-up of the focus area, while the left (large) window shows the entire frame.
	The right (small) window shows the entire frame, while the left (large) window shows a close-up of the focus area.

DISP. CUSTOM SETTING

Choose the items shown in the standard indicator display (12) 23).

LARGE INDICATORS MODE(EVF)

Select **ON** to display large indicators in the electronic viewfinder. The indicators displayed can be selected using **ESCREEN SET-UP** > **LARGE INDICATORS DISP. SETTING.**







- ① Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(EVF)** (15).
- If LARGE INDICATORS MODE is assigned to a function button, the button can be used to toggle LARGE INDICATORS MODE on (ON) and off (OFF) (■ 295).

LARGE INDICATORS MODE(LCD)

Select **ON** to display large indicators in the LCD monitor. The indicators displayed can be selected using **SCREEN SET-UP** > **LARGE INDICATORS DISP. SETTING.**





- ① Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(LCD)** (17).
- If LARGE INDICATORS MODE is assigned to a function button, the button can be used to toggle LARGE INDICATORS MODE on (ON) and off (OFF) (■ 295).

LARGE INDICATORS DISP. SETTING

Choose the indicators displayed when ON is selected for ■ SCREEN SET-UP > LARGE INDICATORS MODE(EVF) or LARGE INDICATORS MODE(LCD).



Option	Description
① Expo. DISP.	Choose the items listed at the bottom of the display. Selected items are indicated by check marks (☑); to deselect, highlight the check marks and press MENU/OK.
② ⅓ Scale	Select ON to display the exposure indicator.
③L1, L2, L3, L4	Choose up to four large icons for display on the left side of the screen.
④ R1, R2, R3, R4	Choose up to four large icons for display on the right side of the screen.

INFORMATION CONTRAST ADJ.

Adjust display contrast.

Option	Description
HIGH CONTRAST	High contrast.
STANDARD	Normal contrast.
LOW CONTRAST	Low contrast.
DARK AMBIENT LIGHTING	Contrast adjusted for dim ambient lighting.

LOCATION INFO

Select **ON** to display location info downloaded from a smart-phone.

Options	
ON	OFF

SUB MONITOR SETTING

Choose the indicators displayed in the secondary LCD monitor. Separate displays are available for still photography and movie recording.

- 1 Select **Z** SCREEN SET-UP > SUB MONITOR SETTING in the setup menu.
- 2 Highlight STILL MODE or MOVIE MODE and press MENU/OK.
- 3 Highlight the indicator you wish to change and press MENU/OK.



4 Highlight the indicator you wish to display and press MENU/OK.



Choose from:

- SHUTTER SPEED
- APERTURE
- EXPO. COMP.
- ISO
- MOVIE MODE
- FRAMES REM.
- REC TIME
- SHOOTING MODE
- PHOTOMETRY
- DRIVE MODE
- FOCUS MODE

- WHITE BALANCE
- IMAGE SIZE
- IMAGE OUALITY
- BATTFRY I FVFI
- CARD SLOT OPTIONS
- SHUTTER TYPE
- FII M SIMULATION
- DYNAMIC RANGE
- CONNECTION STATUS
- NONE
- 5 Repeat Steps 3 and 4 to change additional indicators.

SUB MONITOR BACKGROUND COLOR

Adjusting the background color of the secondary LCD monitor according to lighting conditions makes the display easier to read.

Option	Description	
BLACK	Recommended for use with dark ambient lighting.	
WHITE	Recommended for use with bright ambient lighting.	



The background is displayed in white when the secondary LCD monitor backlight is on.

Q MENU BACKGROUND

Choose the background color used for the quick menu when it is displayed during still photography.

Options	
TRANSPARENT	BLACK

PORTON OF THE PROPERTY OF THE

Choose the background color used for the quick menu when it is displayed during movie recording.

Options	
TRANSPARENT BLACK	

BUTTON/DIAL SETTING

Access options for camera controls.

To access control options, press MENU/OK, select the ☑ (SET UP) tab, and choose BUTTON/DIAL SETTING.



FOCUS LEVER SETTING

Choose the functions performed by pressing the center of the focus stick (focus lever) or by pressing the stick up, down, left, or right.

PUSH

Option	Description	
OFF	Pressing the center of the stick has no effect.	
EDIT FOCUS AREA	Press the center of the stick to choose the focus area size. If FACE/EYE DETECTION SETTING or SUBJECT DETECTION SETTING is on, you can instead position the focus frame over the desired face, eye, animal, or object.	
ZOOM	Press the center of the stick to zoom in on the active focus area (1999).	
RESET TO CENTER	Press the center of the stick to select the center focus area.	

TILT 🌣

Option	Description
OFF	Pressing the stick up, down, left, or right has no effect.
DIRECT AF POINT SELECTION	Choose the focus area without leaving the shooting display.
	Press the stick up, down, left, or right to view a focus-area display and choose the focus area.

☆ EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu during still photography (289).

EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu when filming movies (289).

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons (\$\equiv 295\$).

POWER ZOOM LENS FUNCTION (Fn) SETTING

Choose the roles played by the function buttons available on some power zoom lenses (304).

SELECTOR BUTTON SETTING

Choose the roles played by the up, down, left, and right buttons on the selector.

Option	Description	
Fn BUTTON	The selector buttons serve as function buttons.	
FOCUS AREA	The selector buttons can be used to position the focus area.	



Selecting **FOCUS AREA** prevents you accessing the functions assigned to the function buttons

COMMAND DIAL SETTING

Choose whether to reverse the roles played by the front and rear command dials in each of the following modes.

Option	Description
Р	Reverse the dials used for program shift and exposure compen-
r	sation in mode P (program AE).
Reverse the dials used for shutter-speed selection and	
3	compensation in mode S (shutter-priority AE).
Α	Reverse the dials used for aperture selection and exposure
A	compensation in mode A (aperture-priority AE).
М	Reverse the dials used for shutter-speed and aperture selection
	in mode M (manual).

S.S OPERATION

Select **OFF** to disable shutter-speed fine-tuning using the command dials.

Options	
ON	OFF

COMMAND DIAL DIRECTION

Choose the direction in which the command dials are rotated to choose values. Settings for the front and rear command dials can be adjusted separately.

Option	n Description	
+	Rotate the dial right for higher values or to move to the next item.	
+	Rotate the dial left for higher values or to move to the next item.	

SHUTTER AF

Choose whether the camera focuses when the shutter button is pressed halfway.

Option	Description	
AF-S	 ON: Focus locks when the shutter button is pressed halfway. OFF: No focus operation is performed when the shutter button is pressed halfway. 	
AF-C	 ON: The camera focuses while the shutter button is pressed halfway. OFF: No focus operation is performed when the shutter button is pressed halfway. 	

SHUTTER AE

If **ON** is selected, exposure will lock while the shutter button is pressed halfway. The setting for focus mode CONTINUOUS AF (AF-C) can be adjusted separately from that for modes **SINGLE** AF (AF-S) and MANUAL FOCUS.

Options	
ON	OFF



Select **OFF** to allow the camera to adjust exposure before each shot taken in burst mode

SHOOT WITHOUT LENS

Choose ON to enable the shutter release when no lens is attached.

Options		
ON	OFF	

SHOOT WITHOUT CARD

Choose whether the shutter can be released without a memory card inserted in the camera.

Option	Description
ON	When no memory card is inserted, the shutter can be released to test camera function and the shooting and setup menus can be displayed.
	The shutter is disabled if no memory card is inserted, preventing accidental loss of pictures taken without a memory card.

LENS ZOOM/FOCUS SETTING

Adjust settings for lenses with focus rings or power zoom.

FOCUS RING ROTATE

Choose the direction in which the focus ring is rotated to increase the focus distance.

Options		
C CW (clockwise)	↑ CCW (counterclockwise)	

FOCUS RING OPERATION

Choose how the camera adjusts focus in response to the movement of the focus ring.

Option	Description
NONLINEAR	Focus is adjusted at the same rate as the ring is rotated.
	Focus is adjusted linearly according to the amount the ring is rotated, but the focusing speed is unaffected by the speed the ring is rotated.

ME CONSTANT SPEED FOCUS (Fn)

Choose the rate at which the focus distance changes when adjusted using function buttons during manual focus. The higher the number, the higher the rate.

Options							
1(SLOW)	2	3	4	5	6	7	8(FAST)

CONSTANT SPEED ZOOM (Fn)

Choose the rate at which power zoom lenses can be zoomed in or out using function buttons. The higher the number, the higher the rate.

Options							
1(SLOW)	2	3	4	5	6	7	8(FAST)

CONSTANT SPEED ZOOM/FOCUS (Fn) OPERATION

Choose whether the function buttons need only be pressed once to start and stop power focus or power zoom.

Option	Description
START/STOP	The operation starts when the button is pressed and stops when
SWITCH	it is pressed a second time.
ACTIVE WHILE	The operation continues while the button is pressed and stops
PRESSING	when the button is released.

ZOOM RING ROTATE

Choose whether to reverse the rotation of the zoom ring on power zoom lenses.

Options	
C CW (clockwise)	• CCW (counterclockwise)

ZOOM/FOCUS CONTROL RING

Choose role played by the zoom/focus control ring on power zoom lenses.

Options	
ZOOM	FOCUS

AE/AF-LOCK MODE

This option determines the behavior of the button to which exposure and/or focus lock is assigned.

Option	Description
AE&AF ON WHEN PRESSING	Exposure and/or focus will lock while the button is pressed.
	Exposure and/or focus will lock when the button is pressed and remain locked until it is pressed again.

AWB-LOCK MODE

Choose the behavior of function buttons assigned auto white balance (AWB) lock. Auto white balance lock is used to lock white balance at the value metered by the camera when MINITE PRIORITY, AUTO, or MINITE AMBIENCE PRIORITY is selected for white balance.

Option	Description		
AWB ON WHEN	Auto white balance locks while the button is pressed.		
PRESSING	Auto Write Balance locks Write the Battorn's pressed.		
AWB ON/OFF	Press the button once to lock auto white balance and again to end		
SWITCH	the lock.		

▶ ISO BUTTON SETTING

Choose the role performed by the ISO button during playback.

Option	Description
■ SMARTPHONE	Pressing the button displays a dialog where pictures can be se-
TRANSFER ORDER	lected for upload to a smartphone (🗐 232).
FTP FTP	Pressing the button marks the current picture for upload to an
TRANSFER ORDER	
	Pressing the button marks the current picture for priority upload to an FTP server. The picture will be moved to the head of the upload queue.
	The button can be used for wireless connections.

THE FTP TRANSFER ORDER and FIFE FTP PRIORITY TRANSFER ORDER can only be used when an optional FT-XH file transmitter is connected.

TOUCH SCREEN SETTING

Enable or disable touch-screen controls.

★ TOUCH SCREEN SETTING

Option	Description
ON	The LCD monitor functions as a touch screen during shooting.
OFF	Touch controls disabled.

DOUBLE TAP SETTING

Option	Description		
ON	Tap the LCD monitor twice to zoom in on your subject during shooting.		
OFF	Touch zoom disabled.		

TOUCH FUNCTION

Option	Description	
ON	Enable touch-function gestures.	
OFF	Disable touch-function gestures.	

TOUCH ZOOM

Option	Description
ON	If the lens supports touch zoom, you can zoom in and out by touching the LCD monitor (\blacksquare 35).
OFF	Touch zoom disabled.

► TOUCH SCREEN SETTING

0pti	on	Description		
ON	l	The LCD monitor functions as a touch screen during playback.		
OF	F	Touch controls disabled.		

EVF TOUCH SCREEN AREA SETTINGS

Select the area of the LCD monitor used for touch controls while the viewfinder is active. The area used for touch controls can be selected from:

Option	Description
	All.
	Right half.
	Top right quarter.
	Bottom right quarter.
	Left half.
	Top left quarter.
	Bottom left quarter.
OFF	Touch controls disabled.

LOCK

Lock selected controls to prevent unintended operation.

Option	Description			
LOCK SETTING	Choose from the following: • UNLOCK: Reset lock options. • ALL FUNCTION: Lock all controls in the FUNCTION SELECTION list. • SELECTED FUNCTION: Lock only the controls selected in the FUNCTION SELECTION list.			
FUNCTION SELECTION	Choose the controls locked when SELECTED FUNCTION is chosen for LOCK SETTING .			



The controls selected using **SELECTED FUNCTION** can be locked at any time during shooting by pressing and holding MENU/OK. To unlock the controls, press and hold the button again.



POWER MANAGEMENT

Adjust power management settings.

To access power management settings, press MENU/OK, select the (SET UP) tab, and choose POWER MANAGEMENT.



AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually.

Options					
5 MIN	2 MIN	1 MIN	30 SEC	15 SEC	OFF

PERFORMANCE

Select **BOOST** to improve focus and viewfinder display performance.

Option	Description
BOOST	Boost camera focus and viewfinder display performance.
роозі	The battery drains faster than when is NORMAL selected.
NORMAL	Choose for standard focus and viewfinder display perfor-
NUNNAL	mance and battery endurance.
ECONOMY	Limit autofocus and viewfinder performance. This option
ECONOMY	offers better battery endurance than does NORMAL .

EVF/LCD BOOST SETTING

Adjust the behavior of the EVF and LCD monitor when **BOOST** is selected for **PERFORMANCE**.

Option	Description
EVF/LCD LOW LIGHT	Display brightness is adjusted to make subjects in shad-
PRIORITY	ows easier to see. Motion blur may cause ghosting.
EVF/LCD RESOLUTION	Display resolution is increased to make details easier to
PRIORITY	see.
EVF FRAME RATE	The refresh rate for the EVF is increased, smoothing mo-
PRIORITY (120P)	tion.
EVF FRAME RATE	The refresh rate for the EVF is increased beyond EVF
PRIORITY (240P EQUIV.)	FRAME RATE PRIORITY (120P) smoothing motion
THIOTHIT (ZTOI EQUIV.)	still further. The EVF may darken.

AUTO POWER OFF TEMP.

If its temperature rises beyond a certain point, the camera will first display a message and then, if the temperature rise continues, automatically end shooting and power down. Choose the temperature at which the camera turns off automatically.

Option	Description
STANDARD	The camera turns off automatically when its temperature reaches the STANDARD value.
HIGH	Shooting can continue at temperatures higher than the STANDARD value, extending the time available to record movies and the like. Because remaining in contact with the camera at these high temperatures could result in low-temperature burns, this option should only be used after mounting the camera on a tripod or taking other steps to avoid prolonged contact with the camera.



SAVE DATA SETTING


Make changes to file management settings.

To access file management settings, press MENU/OK, select the (SET UP) tab, and choose SAVE DATA SET-UP.



FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown. FRAME NO. controls whether file num-



bering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.

Option	Description			
	Numbering continues from the last file number used or the first			
CONTINUOUS	available file number, whichever is higher. Choose this option to			
	reduce the number of pictures with duplicate file names.			
RENEW	Numbering is reset to 0001 after formatting or when a new			
	memory card is inserted.			



- If the frame number reaches 999-9999, the shutter release will be disabled. Turn the camera off and insert a formatted memory card before resuming shooting.
 - Selecting **ZUSER SETTING** > **RESET** sets **FRAME NO.** to **CONTINUOUS** but does not reset the file number.
 - Frame numbers for pictures taken with other cameras may differ.

EDIT FILE NAME

Change the file name prefix. sRGB images use a four-letter prefix (default "DSCF"), Adobe RGB images a three-letter prefix ("DSF") preceded by an underscore.

Option	Default prefix	Sample file name
sRGB	DSCF	ABCD0001
AdobeRGB	_DSF	_ABC0001

CARD SLOT SETTING

Choose the role played by the card in the second slot.

Option	Description
SEQUENTIAL	The card in the second slot is used only when the card in the
SEQUENTIAL	first slot is full.
BACKUP	Each picture is recorded twice, once to each card.
	RAW pictures will be saved to the card in the first slot and JPEG
SEPARATE	or HEIF pictures to the card in the second slot. This option only
SEPARAIE	takes effect when FINE+RAW or NORMAL+RAW is selected
	for IMAGE QUALITY SETTING > IMAGE QUALITY .

SELECT SLOT(SEQUENTIAL)

Choose the card that is recorded to first when **SEQUENTIAL** is selected for **CARD SLOT SETTING**.

Options		
SLOT 1	SLOT 2	

SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

Option	Description
SELECT FOLDER	To choose the folder in which subsequent pictures will be stored, press the focus stick (focus lever) up or down to highlight an existing folder and press MENU/OK .
CREATE FOLDER	Enter a five-character folder name. The new folder will be created with the next picture you take and subsequent pictures will be stored in that folder.

COPYRIGHT INFO

Copyright information, in the form of Exif tags, can be added to new images as they are taken. Changes to copyright information are reflected only in images taken after the changes are made.

Option	Description	
DISP COPYRIGHT INFO	View the current copyright information.	
ENTER AUTHOR'S INFO	Enter the creator's name.	
ENTER COPYRIGHT INFO	Enter the name of the copyright holder.	
Delete the current copyright information. This change a		
DELETE COPYRIGHT INFO only to images taken after this option is selected; co		
	information recorded with existing images is not affected.	

DEFAULT CAPTION

Choose the caption applied to new photos and movies.

DISPLAY

View the current caption.

EDIT

Enter a caption.

ERASE

Delete the current caption.

GEOTAGGING

If **ON** is selected, location data downloaded from a smartphone will be embedded in pictures as they are taken.

Options	
ON	OFF

Shortcuts



Customize camera controls to suit your style or situation.

Frequently-used options can be added to the Q menu or a custom "my" menu or assigned to a function button or touch-function gesture for direct access:

Shortcut Option	Description	
"My menu"	Add frequently-used options to this custom menu, which can be viewed by pressing MENU/OK and selecting the M ("MY MENU") tab.	287
The Quick Menu	The ${\bf Q}$ menu is displayed by pressing the ${\bf Q}$ button. Use the ${\bf Q}$ menu to view or change the options selected for frequently-used menu items.	289
The function buttons	Use the function buttons for direct access to selected features.	295
Touch-function gestures	Use touch function button flick gestures (T-Fn1 , T-Fn2 , T-Fn3 , and T-Fn4) for direct access to selected features.	301
Lens function buttons	Use the function buttons on the lens (if any) for direct access to selected features.	304



Access a personalized menu of frequently-used options.

To display "my menu", press MENU/OK in the shooting display and select the MENU) tab.



The tab is only available if options have been assigned to MY MENU.

MY MENU SETTING

To choose the items listed in the **M** (MY MENU) tab:

- 1 In the setup menu, select ☑ USER SETTING > MY MENU SETTING or MY MENU SETTING.
 - To reorder items, select **RANK ITEMS**. To delete items, select **REMOVE ITEMS**.
- 2 Press the focus stick (focus lever) up or down to highlight ADD ITEMS and press MENU/OK. Options that can be added to "my menu" are highlighted in blue.





ltems currently in "my menu" are indicated by check marks.

3 Choose a position for the item and press MENU/OK. The item will be added to "my menu".



- 4 Press MENU/OK to return to the edit display.
- **5** Repeat Steps 3 and 4 until all the desired items have been added.
- My menu" can contain up to 16 items.




The Quick Menu

Use the quick menu for quick access to selected options. To view the quick menu, press the **Q** button.

The Quick Menu Display


The quick menu offers different options in photo and movie modes. At default settings, it contains the following items:

Still photography



Default		
① SHOOTING MODE	HIGHLIGHT TONE	
② FOCUS MODE	10 SHADOW TONE	
③ AF MODE	① COLOR	
4 DYNAMIC RANGE	12 SHARPNESS	
5 HIGH ISO NR	③ SELF-TIMER	
6 IMAGE SIZE	[®] FACE/EYE DETECTION SETTING	
7 IMAGE QUALITY	15 SUBJECT DETECTION SETTING	
8 FILM SIMULATION	16 EVF/LCD BRIGHTNESS	

The quick menu shows the options currently selected for items 2–16, which can be changed.




Default		
1 SHOOTING MODE	(5) APERTURE (MOVIE OPTIMIZED	
	CONTROL ••)	
② SHUTTER SPEED	⑥ 😭 ISO	
3 MOVIE MODE RESOLUTION/	① MOVIE MODE FRAME RATE	
ASPECT RATIO		
④ ₩ WHITE BALANCE		
	TEMP. (WHEN K SELECTED)	

The quick menu shows the options currently selected for items (2)–(8), which can be changed.


Viewing and Changing Settings

1 Press **Q** to display the quick menu during shooting.



2 Use the focus stick (focus lever) to highlight items and rotate the rear command dial to change.






- To jump to the **EDIT/SAVE CUSTOM SETTING** menu, press and hold the **Q** button when the quick menu is displayed.
- 3 Press **Q** to exit when settings are complete.
- The quick menu can also be edited using touch controls.
 - Using BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING, you can assign the **Q** button roles normally reserved for the function buttons or assign the **Q** button's default role to a function button (■ 295).
 - To disable the Q (quick menu) button, select NONE for BUTTON/ DIAL SETTING > FUNCTION (Fn) SETTING > Q BUTTON SETTING.

Editing the Quick Menu

To choose the items displayed in the quick menu:

1 Press and hold the **Q** button during shooting.



- The camera displays the photo quick menu during still photography and the movie quick menu when in movie mode.
- 2 The current quick menu will be displayed; use the focus stick (focus lever) to highlight the item you wish to change and press MENU/OK.
- 3 Highlight the item you wish to change and press **MENU/OK**. The following can be assigned to the quick menu.
- The quick menus can also be edited using **BUTTON/DIAL SETTING** >
 EDIT/SAVE QUICK MENU or **BUTT/SAVE QUICK MENU**.

Available Items (Still Photography)

Choose from:

- IMAGE SIZE
- IMAGE OUALITY
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME EX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- WHITE BALANCE COLOR TEMP (WHEN K SELECTED)
- HIGHLIGHT TONE
- SHADOW TONE
- COLOR
- SHARPNESS
- CLARITY
- HIGH ISO NR
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE/FYE DETECTION SETTING

- SUBJECT DETECTION SETTING
- MF ASSIST
- TOUCH SCREEN MODE
- SELF-TIMER
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- ISO
- FLASH FUNCTION SETTING
- FI ASH COMPENSATION
- MOVIE MODE RESOLUTION/ASPECT RATIO
- MOVIE MODE FRAME RATE
- BIT RATE
- 🚅 IS MODE
- IS MODE BOOST
- INTERNAL/EXTERNAL MIC LEVEL **ADJUSTMENT**
- FVF/I CD BRIGHTNESS
- FVF/I CD COLOR
- NONF



To disable the function button, choose **NONE**.

Available Items (Movies)

- FII M SIMULATION
- DYNAMIC RANGE
- WHITE BALANCE
- WHITE BALANCE COLOR TEMP. (WHEN K SELECTED)
- HIGHLIGHT TONE
- SHADOW TONE
- COLOR
- SHARPNESS
- HIGH ISO NR
- 🖭 FACE/EYE DETECTION SETTING
- SUBJECT DETECTION SETTING
- MF ASSIST
- TOUCH SCREEN MODE
- PHOTOMETRY
- MOVIF ISO
- MOVIE MODE RESOLUTION/ASPECT RATIO

- MOVIE MODE FRAME RATE
- BIT RATE
- HIGH SPEED REC
- FOCUS MODE
- MOVIF AF MODE
- FIX MOVIE CROP MAGNIFICATION
- 🚅 IS MODE
- S MODE BOOST
- SHUTTER SPEED
- APERTURE
- (MOVIF OPTIMIZED CONTROL ← L) INTERNAL/EXTERNAL MIC LEVEL
- **ADJUSTMENT**
- EVF/LCD BRIGHTNESS
- EVF/LCD COLOR
- NONF



To disable the function button, choose **NONE**.



Function Controls

Assign a role to each function button or touch-function gesture for quick access to the selected feature.


The Function Buttons

Assign a role to the function buttons for quick access to the selected feature.

Function Button Defaults


The default assignments are:

Back-of-Camera Function Buttons




Function buttons	Default
1 AFON button	AF-ON
② AEL (exposure lock) button	AE LOCK ONLY
③ Q (quick menu) button	QUICK MENU

Front-of-Camera Function Buttons



Function buttons	Default
1 ISO button	ISO
② VIEW MODE button	VIEW MODE SETTING
③ WB button	WHITE BALANCE
④ ● (movie recording) button	MOVIE RECORDING RELEASE
⑤ Fn1 button	FACE DETECTION ON/OFF
6 Fn2 button	ELECTRONIC LEVEL SWITCH
7 Fn3 button	FOCUS MODE

The Selector



Function buttons	Default
① Fn4 button	PHOTOMETRY
② Fn6 button	SHUTTER TYPE
③ Fn7 button	PERFORMANCE
④ Fn5 button	FILM SIMULATION

Assigning Roles to the Function Buttons

The roles played by the function buttons can be selected using the BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING option in the setup menu.

- ₩ WHEN SETTO M (ON/OFF SWITCH) SHUTTER TYPE
- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT **ES ₽**
- SFI F-TIMFR
- AF BKT SFTTING
- FOCUS BKT SETTING
- PHOTOMETRY

- FLICKER REDUCTION
- FLICKERLESS S.S. SFTTING
- ISO
- IS MODE
- WIRELESS COMMUNICATION
 - FLASH FUNCTION SETTING
 - TTI-LOCK
 - MODFLING FLASH
- MOVIE RECORDING RELEASE
 - HIGH SPEED REC
 - FIX MOVIF CROP MAGNIFICATION
- IS MODE BOOST
 - 7FBRA SFTTING
 - COOLING FAN SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- 4ch AUDIO PI AYBACK
- MOVIF OPTIMIZED CONTROL
- VIEW MODE SETTING
- FVF/I CD SWITCH
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
- I ARGE INDICATORS MODE
- F-Log VIEW ASSIST
 - COMMAND DIAL LOCK

- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W)
- ME CONSTANT SPEED FOCUS (N) AUTO IMAGE TRANSFER ORDER
- MF CONSTANT SPEED FOCUS (F)
- AF LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK
- AF-ON

- AWB LOCK ONLY
- LOCK SETTING
- PERFORMANCE

 - Bluetooth ON/OFF
 - QUICK MENU
 - PLAYBACK
 - NONE



To disable the function button, choose **NONE**.

AF-ON

Controls to which AF-ON is assigned can be used for autofocus.

MODELING FLASH

If MODELING FLASH is selected when a compatible shoe-mounted flash unit is attached, you can press the control to test-fire the flash and check for shadows and the like (modeling flash).

TTL-LOCK

If TTL-LOCK is selected, you can press the control to lock flash output according to the option selected for **I** FLASH SETTING > TTL-LOCK MODE (**I** 176).

RECALL CUSTOM 1 SETTING

Controls to which **RECALL CUSTOM 1 SETTING** has been assigned can be pressed to temporarily recall the settings saved to position **C1** (CUSTOM 1) on the mode dial. Pressing the button a second time restores the previous settings.

Touch-Function Gestures


Assign roles to touch-function gestures (T-Fn1, T-Fn2, T-Fn3, or T-Fn4) for quick access to selected features.



Touch-function gestures are disabled by default. To enable touch-function gestures, select **ON** for **BUTTON/DIAL SETTING** > **TOUCH** SCREEN SETTING > III TOUCH FUNCTION.

Touch-Function Gesture Defaults

The default assignments for the different gestures are:



Touch-Function Gestures	Default
1 T-Fn1 (flick up)	HISTOGRAM
② T-Fn2 (flick left)	PREVIEW DEPTH OF FIELD
③ T-Fn3 (flick right)	LARGE INDICATORS MODE
④ T-Fn4 (flick down)	ZEBRA SETTING

Assigning Roles to Touch-Function Gestures

The roles played by touch-function gestures can be selected using the **BUTTON/DIAL SETTING** > **FUNCTION** (**Fn**) **SETTING** option in the setup menu.

- IMAGE SIZE
- IMAGE QUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME EFFECT
- COLOR CHROME FX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRF-SHOT **FS** ₽
- SFI F-TIMER
- AF BKT SFTTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION

- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- WIRELESS COMMUNICATION
- FLASH FUNCTION SETTING
- TTI-LOCK
- MODELING FLASH
- HIGH SPEED REC
- FIX MOVIF CROP MAGNIFICATION
 - S MODE BOOST
 - 7FBRA SETTING
 - COOLING FAN SETTING
 - INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
 - 4ch AUDIO PLAYBACK
 - MOVIE OPTIMIZED CONTROL → ►
- VIEW MODE SETTING
 - FVF/I CD SWITCH
 - PREVIEW DEPTH OF FIELD
- PREVIEW FXP./WB IN MANUAL MODE
 - NATURAL LIVE VIEW
 - HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
 - LARGE INDICATORS MODE
 - F-Log VIEW ASSIST
 - COMMAND DIAL LOCK
 - 700M/FOCUS CONTROL RING
 - LOCK SETTING
 - PERFORMANCE
 - AUTO IMAGE TRANSFER ORDER

- Bluetooth ON/OFF
- PLAYBACK
- QUICK MENU

- NONE

To disable touch-function gestures, choose **NONE**.

Lens Function Buttons


Choose the roles played by the function buttons on the lens (where applicable).

Lens Function Button Defaults

The default assignments are:



A XF18-120mmF4 LM PZ WR lens is used here for illustrative purposes.



Lens function button	Default
① Z/F	ZOOM/FOCUS CONTROL RING
② L-Fn1 (rocker zoom button pressed up)	CONSTANT SPEED ZOOM (T)
3 L-Fn2 (rocker zoom button pressed down)	CONSTANT SPEED ZOOM (W)

Assigning Roles to the Lens Function Buttons

The roles played by the lens function buttons can be selected using the BUTTON/DIAL SETTING > POWER ZOOM LENS FUNCTION (Fn) SETTING option in the setup menu.

- ₩ WHEN SETTO M (ON/OFF SWITCH) SHUTTER TYPE
- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME EX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- RECALL CUSTOM 1 SETTING
- FOCUS ARFA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- RIGHT/I FFT FYF SWITCH
- SUBJECT DETECTION ON/OFF
- AF RANGE I IMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT **ES ₽**
- SELF-TIMER
- AF BKT SFTTING
- FOCUS BKT SETTING
- PHOTOMETRY

- FLICKER REDUCTION
- FLICKERLESS S.S. SETTING
- ISO
- IS MODE
- WIRELESS COMMUNICATION
- FLASH FUNCTION SETTING
- TTI-LOCK
 - MODFLING FLASH
- MOVIE RECORDING RELEASE
 - HIGH SPEED REC
 - FIX MOVIE CROP MAGNIFICATION
 - IS MODE BOOST
 - 7FBRA SETTING
 - COOLING FAN SETTING
- INTERNAL/EXTERNAL MIC LEVEL ADJUSTMENT
- 4ch AUDIO PI AYBACK
- MOVIF OPTIMIZED CONTROL
- VIEW MODE SETTING
- FVF/I CD SWITCH
- PREVIEW DEPTH OF FIELD
- PREVIEW EXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
 - HISTOGRAM
 - FLECTRONIC LEVEL SWITCH
- I ARGE INDICATORS MODE
- F-Log VIEW ASSIST
- COMMAND DIAL LOCK

- ZOOM/FOCUS CONTROL RING
- CONSTANT SPEED ZOOM (T)
- CONSTANT SPEED ZOOM (W) PERFORMANCE
- ME CONSTANT SPEED FOCUS (N) AUTO IMAGE TRANSFER ORDER
- ME CONSTANT SPEED FOCUS (F)
- AF LOCK ONLY
- AF LOCK ONLY
- AE/AF LOCK
- AF-ON

- AWB LOCK ONLY
- LOCK SETTING
- Bluetooth ON/OFF
 - QUICK MENU
- PLAYBACK
 - NONF




To disable the function button, choose **NONE**.


Peripherals and Optional Accessories


Lenses

The camera can be used with lenses for the FUJIFILM X-mount.

Lens Parts







- (1) Lens hood
- (2) Mounting marks
- (3) Focus ring
- 4 Zoom ring
- (5) Aperture ring

- (6) O.I.S. switch
- (7) Aperture mode switch
- (8) Lens signal contacts
- Front lens cap
- (10) Rear lens cap




Lens Care

- Use a blower to remove dust, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied.
- Replace the front and rear caps when the lens is not in use.

Removing Lens Caps

Remove lens caps as shown.






Lens caps may differ from those shown.


Attaching Lens Hoods

When attached, lens hoods reduce glare and protect the front lens element.



Lenses with Aperture Rings

At settings other than A, you can adjust aperture by rotating the lens aperture ring (exposure modes A and M).




Aperture ring



- Selecting ON for MOVIE OPTIMIZED CONTROL → b disables the aperture ring.
 - When the aperture ring is set to **A**, rotate the command dials to adjust aperture.

The Aperture Mode Switch-

If the lens has an aperture mode switch, aperture can be adjusted manually by sliding the switch to \$ and rotating the aperture ring.



Lenses with No Aperture Rings

Aperture can be adjusted using the front command dial in modes A (aperture-priority AE) and M (manual).






Negreture control can be reassigned to the rear command dial using BUTTON/DIAL SETTING > COMMAND DIAL SETTING.

Lenses with O.I.S. Switches

If the lens supports optical image stabilization (O.I.S.), the image stabilization mode can be chosen in the camera menus. To activate image stabilization, slide the O.I.S. switch to ON.



Manual Focus Lenses

Slide the focus ring to the front for autofocus.



For manual focus, slide the focus ring to the back and rotate it while checking the results in the camera display. The focus distance and depth-of-field indicators can be used to assist manual focus.



Note that manual focus may not be available in all shooting modes.

-The Depth-of-Field Indicator-


The depth-of-field indicator shows the approximate depth of field (the distance in front of and behind the focus point that appears to be in focus). The indicator is displayed in film format.



Power Zoom Lenses

Zoom can be adjusted on power zoom lenses using the zoom/ focus control ring, zoom button, or zoom ring.

- Adjusting zoom while the lens is wet makes it easier for water to find its way inside the lens. Wipe any water from the lens before adjusting zoom.
- A XF18-120mmF4 LM PZ WR lens is used here for illustrative purposes.



Control	Description
1 Zoom ring	Rotate the zoom ring to zoom in or out manually.
② Zoom/focus control ring	Rotate the zoom/focus control ring to zoom in or out using powered zoom. The zoom speed is proportional to the speed with which the ring is rotated.
③ Z/F (zoom/focus) button	Switch the role of zoom/focus control ring from focus to zoom or <i>vice versa</i> .
Zoom buttons	Press a zoom button to zoom in or out at a steady speed using powered zoom. Zoom ends when the button is pressed a second time.

- The Z/F and zoom buttons can be assigned other roles using BUTTON/DIAL SETTING > POWER ZOOM LENS FUNCTION (Fn) SETTING
 - The speed at which zoom can be adjusted via the zoom buttons can be chosen using ■ BUTTON/DIAL SETTING > LENS ZOOM/FOCUS SETTING.

External Flash Units

Use optional external flash units for flash photography. Some units support high-speed sync (FP) and can be used at shutter speeds faster than the flash sync speed, while others can function as commanders controlling remote units via optical wireless flash control.

You may be unable to test-fire the flash in some circumstances, for example when a setup menu is displayed on the camera.

Red-Eye Removal-

Red-eye removal is available when an option other than **OFF** is selected for **I FLASH SETTING** > **RED EYE REMOVAL** and **I AF/MF SETTING** > **I FACE/EYE DETECTION SETTING** is **FACE DETECTION ON**. Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas.

-Flash Sync Speed-

The flash will synchronize with the mechanical shutter at shutter speeds of $\frac{1}{250}$ s or slower and with the electronic shutter as speeds of $\frac{1}{125}$ s or slower.

Optional Flash Units from Fujifilm

The camera can be used with optional Fujifilm shoe-mounted flash units.

Third-Party Flash Units-

Do not use third-party flash units that apply over 300 V to the camera hot shoe.

Flash Settings

- 1 Connect the unit to the camera.
- 2 In shooting mode, select FLASH FUNCTION SETTING in the ☑ (FLASH SETTING) menu tab. The options available vary with the flash unit.



Menu	Description	
EF-X8	Displayed when an optional EF-X8 flash unit is mounted on the hot shoe and raised.	317
SYNC TERMINAL	Adjust settings for flash units connected via the sync terminal. SYNC TERMINAL is displayed if the EF-X8 is lowered and either no flash unit, or an incompatible flash unit, is mounted on the hot shoe.	
SHOE MOUNT FLASH	Displayed when an optional flash unit other than the EF-X8 is mounted on the hot shoe and turned on.	320
COMMANDER (OPTICAL)	Displayed if an optional flash unit functioning as a com- mander for Fujifilm optical wireless remote flash control is connected and turned on.	


3 Highlight items using the focus stick (focus lever) and rotate the rear command dial to change the highlighted setting.



4 Press DISP/BACK to put the changes into effect.

EF-X8

The following settings are available when an optional EF-X8 shoe-mounted flash unit is attached.



Setting	Description
1 Flash control mode	Choose from the following options: • TTL: TTL mode. Adjust flash compensation (②) and choose a flash mode (③). • M: The flash fires at the selected output (②) regardless of subject brightness or camera settings. Output is expressed in fractions of full power, from ⅓ to ⅙4. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results. • M€ (COMMANDER): Choose if the flash is being used to control remote synced flash units, for example as part of a studio flash system. • ⑤OFF (OFF): The EF-X8 does not fire. Flash units connected via the sync terminal will still fire when the shutter is released, but can be disabled by lowering the EF-X8 and turning the units off in the flash settings menu.
2 Flash compensation/	Adjust flash level. The options available vary with the flash
output	control mode (1).

C - 44 ²	D
Setting	Description
(3) Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (P, S, A, or M) selected. • 知 (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness. A icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • 知 (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • 知 (SLOW SYNC.): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
(4) Sync	Choose whether the flash is timed to fire immediately after the shutter opens ($_{RDR}^{4}/1ST$ CURTAIN) or immediately before it closes ($_{RDR}^{4}/2ND$ CURTAIN). 1ST CURTAIN is recommended in most circumstances.

SYNC TERMINAL


The following options are available when no compatible flash unit is connected or if a unit is connected via the sync terminal or uses only the X-contact on the hot shoe.



Setting	Description
1 Flash control mode	Choose from the following options: • M: A trigger signal is transmitted via the hot shoe X contacts when a picture is taken. Choose a shutter speed slower than the sync speed; even slower speeds may be required if the unit uses long flashes or has a slow response time. • ①OFF (OFF): The trigger signal is disabled.
	Choose whether the flash is timed to fire immediately after the shutter opens ($_{RMT}^{4}/1ST$ CURTAIN) or immediately before it closes ($_{RMR}^{4}/2ND$ CURTAIN). 1ST CURTAIN is recommended in most circumstances.

-The Sync Terminal -

Use the sync terminal to connect flash units that require a sync cable.



SHOE MOUNT FLASH

The following options are available when an optional shoe-mounted flash unit is attached and turned on.



Setting	Description
1 Flash control mode	The flash control mode selected with the flash unit. This can in some cases be adjusted from the camera; the options available vary with the flash. • TTL: TTL mode. Adjust flash compensation (②). • M: The flash fires at the selected output regardless of subject brightness or camera settings. Output in some cases can be adjusted from the camera (②). • MULTI: Repeating flash. Compatible shoe-mounted flash units will fire multiple times with each shot. • ③OFF (OFF): The flash does not fire. Some flash units can be turned off from the camera.

Setting	Description
Jetting	The options available vary with flash control mode.
② Flash compensation/ output	 TTL: Adjust flash compensation (the full value may not be applied if the limits of the flash control system are exceeded). In the cases of the EF-X20, EF-20, and EF-42, the selected value is added to the value selected with the flash unit. M/MULTI: Adjust flash output (compatible units only). Choose from values expressed as fractions of full power, from ⅓ (mode M) or ⅓ (MULTI) down to ⅓sız in increments equivalent to ⅓ EV. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results.
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (P , S , A , or M) selected. • 知 (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness. A claim condisplayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • 知 (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • 知 (SLOW SYNC.): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.

Setting	Description
(4) Sync	Control flash timing. • RÉMT (1ST CURTAIN): The flash fires immediately after the shutter opens (generally the best choice). • RÉMR (2ND CURTAIN): The flash fires immediately before the shutter closes. • \$ (AUTO FP(HSS)): High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to 1ST CURTAIN when MULTI is selected for flash control mode.
(5) Zoom	The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If AUTO is selected, zoom will automatically be adjusted to match coverage to lens focal length.
(6) Lighting	If the unit supports this feature, choose from: ■ (FLASH POWER PRIORITY): Gain range by slightly reducing coverage. ■ (STANDARD): Match coverage to picture angle. ■ (EVEN COVERAGE PRIORITY): Slightly increase coverage for more even lighting.
(7) LED light	Choose how the built-in LED light functions during still photography (compatible units only): as a catchlight (今 / CATCHLIGHT), as an AF-assist illuminator (AF/AF ASSIST), or as both a catchlight and an AF-assist illuminator (答/AF ASSIST+CATCHLIGHT). Choose OFF to disable the LED during photography.
7 Number of flashes *	Choose the number of times the flash fires each time the shutter is released in MULTI mode.
8 Frequency*	Choose the frequency at which the flash fires in MULTI mode.

^{*} Full value may not be applied if limits of flash control system are exceeded.


COMMANDER(OPTICAL)

The options will be displayed if the unit is currently functioning as a commander for Fujifilm optical wireless remote flash control.



Fujifilm optical wireless remote flash control offers a choice of four channels (Channels 1 through 4) for the exchange of optical signals between the commander and remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.

The flash units can also be placed in up to three groups (A, B, and C) and flash mode and flash level adjusted separately for each group.




C - 44!	D
Setting	Description
(1) Flash control mode (group A)	 Choose flash control modes for groups A, B, and C. TTL% is available for groups A and B only. TTL: The units in the group fire in TTL mode. Flash compensation can be adjusted separately for each group. TTL%: If TTL% is selected for either group A or B, you can
② Flash control mode (group B)	specify the output of the selected group as a percentage of the other and adjust overall flash compensation for both groups. • M: In mode M, the units in the group fire at the selected output (expressed as a fraction of full power) regardless
(3) Flash control mode (group C)	of subject brightness or camera settings. • MULTI: Choosing MULTI for any group sets all the units in all groups to repeating flash mode. All units will fire multiple times with each shot. • SOFF (OFF): If OFF is selected, the units in the group will not fire.
Flash compensation/ output (group A)	Adjust flash level for the selected group according to option selected for flash control mode. Note that the full value may not be applied if the limits of the flash control
5 Flash compensation/ output (group B)	system are exceeded. • TTL: Adjust flash compensation.
6 Flash compensation/ output (group C)	• M/MULTI: Adjust flash output. • TTL%: Choose the balance between groups A and B and adjust overall flash compensation.


Setting	Description
(7) Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (P , S , A , or M) selected.
	• III (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness. A ☐ icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken.
(T) Hasiffilloce (TE)	• \$TIL (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released.
	• III (SLOW SYNC.): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
8 Sync	Control flash timing. • #6 (1ST CURTAIN): The flash fires immediately after the shutter opens (generally the best choice). • #6 (2ND CURTAIN): The flash fires immediately before the shutter closes.
	• * (AUTO FP(HSS)): High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to 1ST CURTAIN when MULTI is selected for flash control mode.
(9) Zoom	The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If AUTO is selected, zoom will automatically be adjusted to match coverage to lens focal length.
	If the unit supports this feature, choose from: • = (FLASH POWER PRIORITY): Gain range by slightly reducing coverage.
10 Lighting	


C - 44!	Dt4t
Setting	Description
① Commander	Choose the group for units functioning as a commander for Fujifilm optical wireless remote flash control in TTL ,
	TTL%, or M mode. This option is available only with clip-
	on flash units that support Fujifilm optical wireless remote
	flash control.
	• Gr A : Assign the commander to group A.
	• Gr B : Assign the commander to group B.
	• Gr C : Assign the commander to group C.
	• 0FF : Output from the commander is held to a level that
	does not affect the final picture.
11) Number of flashes	Choose the number of times the flash fires each time the
	shutter is released in MULTI mode.
(12) Channel	Choose the channel used by the commander for commu-
	nication with the remote flash units. Separate channels
	can be used for different flash systems or to prevent in-
	terference when multiple systems are operating in close
	proximity.
12) Frequency	Choose the frequency at which the flash fires in MULTI
	mode.

Vertical Battery Grips

The VG-XH vertical battery grip can be used to supplement the camera battery or when holding the camera rotated to take pictures in portrait ("tall") orientation.








- (1) Fn1 button
- (2) WB button (3) ISO button
- (4) Shutter button
- (5) Control lock
- (6) Front command dial
- (7) Lock screw knob
- (8) Tripod socket
- (9) Eyelet for camera strap
- (10) Connector cover
- (11) Lock screw
- (12) Serial number plate

- (13) Focus stick (focus lever)
- (14) Rear command dial
- (15) AFON button
- (16) AEL (exposure lock) button
- (17) **Q** (quick menu) button
- (18) Indicator lamps
- (19) Performance selector
- **(20)** Battery tray
- (21) Battery-chamber cover latch
- (22) Connector
- (23) Compartment for connector cover supplied with camera



All controls perform the same function as the matching controls on the camera


Attaching the Vertical Battery Grip




- Check that the camera is off before attaching or removing the vertical battery grip.
 - The camera file transmitter/vertical battery grip connector cover (A) can be stored in the grip connector cover compartment. Keep the grip contact cap (B) in a safe place when not in use.
- Fully tighten the lock screw knob after attaching the grip.
 - Do not touch the contacts.
 - After removing the grip, replace the file transmitter/vertical battery grip connector cover (A) and contact cap (B).
 - The grip is not waterproof, and caution is required to prevent the entry of dirt, dust, water, noxious gases, salt, and other foreign matter. Do not place the grip on wet surfaces. Before use, be sure that the battery tray and battery-chamber cover are fully closed.

Inserting and Removing Batteries

Insert the batteries as shown.



The batteries can be removed as shown.



- Be sure the camera is off before exchanging batteries.
 - Use only NP-W235 batteries.

-Battery Level-

When a vertical battery grip is connected, the camera battery level display shows the camera battery level and the level of the batteries inserted in the VG-XH.




- The display shows the level of inserted batteries only.
- When a full complement of batteries are inserted in the camera and the VG-XH, the batteries will be used in the following order:
 - 1) The left grip battery (L)
 - $\begin{tabular}{ll} \begin{tabular}{ll} \beg$
 - 3 The camera battery

Charging the Batteries

The batteries in the vertical battery grip will charge when the grip is attached to a camera that is connected to an AC-5VJ AC adapter via a USB cable.

The indicator lamps will light green while the battery charges; the lamp on the left shows the status of the left battery, the lamp on the right the status of the right battery.




Indicator lamp	Battery status
On	Battery charging
Off	Charging complete
Blinks	Battery fault



- All three batteries charge simultaneously; charging takes about 330 minutes.
 - Using a device that supplies power with an outputs of 45 W or above reduces charging times to as little as 180 minutes.
 - The batteries will not charge while the camera is on.
 - For more information, see "Charging the Battery" (\$\equiv 46\$) and "The Battery and Power Supply" (348).

File Transmitters

Attach an optional FT-XH file transmitter to connect to wireless LAN or Ethernet networks for file upload or tethered photography. The FT-XH can also be used in combination with a battery inserted in the camera for greater battery capacity.



- (1) Fn1 button
- (2) WB button
- (3) ISO button
- (4) Shutter button
- (5) Control lock
- (6) Front command dial
- (7) Lock screw knob
- 8 Tripod socket
- 9 Eyelet for camera strap
- 10 Connector cover
- 11 Lock screw
- (12) Serial number plate
- (13) Focus stick (focus lever)
- (14) Rear command dial
- (15) AFON button

- (16) AEL (exposure lock) button
- (17) **Q** (quick menu) button
- (18) Indicator lamps
- 19 Performance selector
- **20** Battery tray
- **21)** Battery-chamber cover latch
- (22) USB connector cover
- (23) LAN connector cover
- 24) USB connector (Type-C)
- **25** Hole to screw USB cable
- (26) LAN connector
- 27 Connector
- (28) Compartment for connector cover supplied with camera



- The controls on the FT-XH perform the same functions as the matching controls on the camera.
 - The USB (Type-C) connector is for smartphone tethering only. Use the camera USB connector when uploading pictures to a computer or smartphone, performing tethered photography via USB, or charging batteries.
 - For information for accessing network/USB features while the file transmitter is connected, visit: https://fujifilm-dsc.com/en/manual/x-h2s_connection/

Attaching the File Transmitter

The procedure is the same as for vertical battery grips (12) 328).

Inserting and Removing Batteries

The procedure is the same as for vertical battery grips (191329).

Access to the network/USB features in only available when a battery is inserted in the camera and at least one battery is inserted in the transmitter

Charging the Batteries

The procedure is the same as for vertical battery grips (\$\equiv\$ 331).


Cooling Fans

Cooling fans help keep the camera cool, allowing longer periods of non-stop movie recording.

Attaching a Cooling Fan


Open the monitor and attach an FAN-001 cooling fan.

- ① Turn the camera off before attaching or removing the fan.
 - 1 Open the monitor.




2 Remove the camera cooling fan connector cover and the fan connector cap.


After removing the cooling fan connector cover (A), attach it to the fan for safe-keeping. Keep the fan connector cap (B) in a safe place.



3 Place the fan on the camera, making sure the screws and connectors are correctly aligned.



4 Tighten the screws.



The cooling fan may fall off if the screws are not sufficiently tightened.

Using the Fan

Fan speed can be adjusted using the SHOOTING SETTING > COOLING FAN SETTING and MOVIE SETTING > COOLING FAN SETTING options in the photo and movie menus, respectively. Select OFF to turn the fan off.

① At some speeds, the noise of the fan may be audible in movies recorded with the camera.

Technical Notes

Accessories from Fujifilm

The following optional accessories are available from Fujifilm. For the latest information on the accessories available in your region, check with your local Fujifilm representative or visit https://fujifilm-x.com/support/compatibility/cameras/.

Rechargeable Li-ion batteries

NP-W235: Additional high-capacity NP-W235 rechargeable batteries can be purchased as required.

Dual battery chargers

BC-W235: The BC-W235 can charge up to two NP-W235 batteries at a time. At +25 °C/+77 °F, the batteries will charge in about 200 minutes. Using a device that supplies power with an outputs of 30 W or above reduces charging times to as little as 150 minutes.

Eye cups

EC-XH W/EC-XT L/EC-XT M/EC-XT S/EC-GFX: Attach viewfinder eyecups to prevent light leaking into the viewfinder window.

Remote releases

RR-100: Use to reduce camera shake or keep the shutter open during a time exposure (\emptyset 2.5 mm).

Stereo microphones

MIC-ST1: An external microphone for movie recording.

FUJINON lenses

XF-/XC-series lenses: Interchangeable lenses for use exclusively with the FUJIFILM X-mount.

FUJINON MKX-series lenses: Cinema lenses for the FUJIFILM X-mount.

Macro extension tubes

MCEX-11/16: Attach between the camera and the lens to shoot at high reproduction ratios.

Teleconverters

XF1.4X TC WR: Increases the focal length of the compatible lenses by about 1.4×. **XF2X TC WR**: Increases the focal length of the compatible lenses by about 2.0×.

Mount adapters

FUJIFILM M MOUNT ADAPTER: Allows the camera to be used with a wide selection of M-mount lenses.

Body caps

BCP-001: Cover the camera lens mount when no lens is attached.

Shoe-mounted flash units

EF-X500: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 50/164 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. Featuring support for the optional EF-BP1 battery pack and Fujifilm optical wireless flash control, it can be used as a commander or remote flash unit for remote wireless flash photography.

EF-BP1: A battery pack for EF-X500 flash units. Takes up to 8 AA batteries.

EF-60: In addition to manual and TTL flash control, this clip-on flash unit has a Guide Number of 60/197 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. It can also be used as remote flash under the control of an optional EF-W1 wireless commander.

EF-W1: With support for the NAS* wireless communication standard developed by Nissin Japan, this wireless flash commander can be used with optional EF-60 clip-on flash units and other NAS-compliant units.

* NAS is a registered trademark of Nissin Japan Ltd.

EF-X8: This compact, clip-on flash unit draws power from the camera has a Guide Number of approximately 8/26 (ISO 100, m/ft.) and can cover the angle of view of a 16 mm lens (equivalent to 24 mm in 35 mm format).

EF-42: This clip-on flash unit has a Guide Number of 42/137 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-X20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports manual and TTL flash control.

EF-20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.) and supports TTL flash control (manual flash control is not supported).

Vertical battery grips

VG-XH: See "Vertical battery grips" (■ 327).

File transmitters

FT-XH: See "File Transmitters" (332).

Cooling fans

FAN-001: See "Cooling Fans" (■ 334).

Grip belts

GB-001: Improves grip. Combine with a hand grip for more secure handling.

Cover kits

CVR-XH: A set of covers for the X-H2S. Contains a sync terminal cap, a hot-shoe cover, and a memory card slot cover, as well as two file transmitter/vertical battery grip connector covers.

instax SHARE printers

SP-1/SP-2/SP-3: Connect via wireless LAN to print pictures on instax film.

Software for Use with Your Camera

The camera can be used with the following software. For the latest information on software available from Fujifilm, visit https://fujifilm-x.com/support/compatibility/cameras/.

Smartphone Apps

Establish a wireless connection between your camera and a smartphone or tablet.

https://app.fujifilm-dsc.com/

RAW FILE CONVERTER EX powered by SILKYPIX

RAW FILE CONVERTER EX powered by SILKYPIX is RAW conversion software from Ichikawa Soft Laboratory Co., Ltd. View RAW pictures on your computer and convert them into other formats. RAW FILE CONVERTER EX powered by SILKYPIX is available free of charge from the Fujifilm website.

https://fujifilm-x.com/support/download/software/raw-file-converterex-powered-by-silkypix/



- * "RAW FILE CONVERTER EX powered by SILKYPIX" is supplied by Ichikawa Soft Laboratory Co., Ltd.
 - For information on when support will be available, visit: https://fujifilm-x.com/support/compatibility/software/raw-file-converter-expowered-by-silkypix/

Capture One Express for Fujifilm

View RAW pictures on your computer and convert them into other formats. Capture One Express for Fujifilm is available free of charge from Capture One A/S.

https://www.captureone.com/products-plans/capture-one-express/fujifilm



Visit the website above for information on when support will be available.

Capture One for Fujifilm

Capture One for Fujifilm workflow software from Capture One A/S supports tethered shooting and the conversion of RAW pictures into other formats.

https://www.captureone.com/explore-features/fujifilm



Visit the website above for information on when support will be available.

FUJIFILM Tether Shooting Plug-in (Exclusively for Lightroom)

A plug-in for Adobe Lightroom Classic.

 FUJIFILM Tether Shooting Plug-in PRO/FUJIFILM Tether Shooting Plug-in https://fujifilm-x.com/products/software/adobe-photoshop-lightroomtether-plugin/

FUJIFILM X Acquire

This application for Windows and macOS lets you connect to the camera via USB or Wi-Fi and automatically download photos to a specified folder as they are taken, or backup and restore the camera via USB.

https://fujifilm-x.com/products/software/x-acquire/

1 Auto download (tethered shooting) is not supported with some cameras

FUJIFILM X RAW STUDIO

When the camera is connected to a computer via USB, FUJIFILM X RAW STUDIO can use the camera's unique image processing engine to rapidly convert RAW files to create high-quality images in other formats.

https://fujifilm-x.com/products/software/x-raw-studio/

For Your Safety

IMPORTANT SAFETY INSTRUCTIONS

- should be read before the appliance is operated.
- should be retained for future reference.
- . Heed Warnings: All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions: All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

Attachments: Do not use attachments not recommended by Power Service Grounding Electrode the video product manufacturer as they may cause hazards. System (NEC ART 250. PART H)

Water and Moisture: Do not use this video product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.


• Read Instructions: All the safety and operating instructions Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by • Retain Instructions: The safety and operating instructions items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

> Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod. bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufac-

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



Antennas Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.



light or power circuits, or where it can fall into such power nel under the following conditions: lines or circuits. When installing an outside antenna system, • When the power-supply cord or plug is damaged extreme care should be taken to keep from touching such . If liquid has been spilled, or objects have fallen into the power lines or circuits as contact with them might be fatal.

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Power Lines: An outside antenna system should not be locat- Damage Requiring Service: Unplug this video product from ed in the vicinity of overhead power lines or other electric the wall outlet and refer servicing to qualified service person-

- video product.
- If the video product has been exposed to rain or water.
- If the video product has been dropped or the cabinet has been damaged.

If the video product does not operate normally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance — this indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

Be sure to read these notes before use

Safety Notes

- Make sure that you use your camera correctly. Read these safety notes and your Basic Manual carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



This icon indicates that death or serious injury can result if the information is ignored.



This icon indicates that personal injury or material damage can result if the information is ignored

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information reguires attention ("Important").



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark indicate an action that must be performed ("Required").

The symbols on the product (including the accesories) represent the following:





Class II equipment (The construction of the product is double-insulated.)

∕N WARNING



battery, disconnect the USB cable, and unplug the AC power adapter. Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your Fujifilm dealer.

If a problem arises, turn the camera off, remove the



Do not allow water or foreign objects to enter the camera or connecting cables. Do not use the camera or connecting cables following ingress of fresh or salt water, milk, beverages, detergents, or other liquids. Should liquid find its way into the camera or connecting cables, turn the camera off, remove the battery, disconnect the USB cable, and disconnect and unplug the AC adapter. Continued use of the camera can cause a fire or electric shock. Contact vour Fuiifilm dealer.

₩ARNING



Do not use the camera in the bathroom or shower. This can cause a fire or electric shock.



Never attempt to change or take apart the camera (never open the case). Failure to observe this precaution can cause fire or electric shock.



Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged. contact your Fujifilm dealer. Do not use cables with bent connectors



Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause



Never attempt to take pictures while in motion. Do not use the camera while walking or driving. This can result in you falling down or being involved in a traffic accident.



Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge.



Do not use the battery except as specified. Load the battery as shown by the indicator.

Do not disassemble, modify, or heat batteries. Do not drop, strike, or throw batteries or otherwise subject them to strong impacts. Do not use batteries that show signs of leaking, deformation, discoloration, or other abnormalities. Use only designated chargers to recharge rechargeable batteries and do not attempt to recharae non-recharaeable Li-ion or alkaline batteries. Do not short batteries or store them with metallic objects. Failure to observe these precautions could result in the batteries overheating, igniting, rupturing, or leaking, causing fire, burns, or other injury.



Use only batteries or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire

WARNING



If the battery leaks and fluid gets in contact with your eyes, skin or clothing, flush the affected area with clean water and seek medical attention or call an emergency number riaht awav.



Do not use the charger to charge batteries other than those specified here. The supplied charger is for use only with batteries of the type supplied with the camera. Using the charger to charge conventional batteries or other types of rechargeable batteries can cause the battery to leak, overheat or burst.



Using a flash too close to a person's eves may cause visual impairment. Take particular care when photographing infants and young children. Do not remain in prolonged contact with hot surfaces.



Do not leave one part of the body in contact with the product for prolonged periods while the product is on. Failure to observe this precaution could result in low-temperature burns, particularly during prolonged use, at high ambient temperatures, when HIGH is selected for AUTO POWER OFF TEMP. or with users who suffer from poor circulation or reduced sensation, in which case use of a tripod or similar precautions are recommended.



Do not use in the presence of flammable objects, explosive aases, or dust. When carrying the battery, install it in a digital camera



or keep it in the hard case. When storing the battery, keep it in the hard case. When discarding, cover the battery terminals with insulation tape. Contact with other metallic objects or batteries could cause the battery to ignite or burst.



Keep memory cards, hot shoes, and other small parts out of the reach of small children. Children may swallow small parts; keep out of reach of children. Should a child swallow a small part, seek medical attention or call emergency.



Keep out of reach of small children. Among the elements that could cause injury are the strap, which could become entangled about a child's neck, causing strangulation, and the flash, which could cause visual impairment.



Follow the directions of airline and hospital personnel. This product generates radio-frequency emissions that could interfere with navigational or medical equipment.

⚠ CAUTION



Do not use this camera in locations affected by oil fumes, steam, humidity or dust. This can cause a fire or electric shock



Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.



Do not place heavy objects on the camera. This can cause the heavy object to tip over or fall and cause injury.



Do not move the camera while the AC power adapter is still connected. Do not pull on the connection cord to disconnect the AC power adapter. This can damage the power cord or cables and cause a fire or electric shock.



Do not cover or wrap the camera or the AC power adapter in a cloth or blanket. This can cause heat to build up and distort the casing or cause a fire.



Do not use the plug if it is damaged or if it does not fit
securely into the outlet. Failure to observe this precaution could result in fire or electric shock



When you are cleaning the camera or you do not plan to use the camera for an extended period, remove the battery and disconnect and unplug the AC power adapter.

Failure to do so can cause a fire or electric shock



When charging ends, unplug the charger from the power socket. Leaving the charger plugged into the power socket can cause a fire.



When a memory card is removed, the card could come out of the slot too quickly. Use your finger to hold it and gently release the card. In jury could result to those struck by the ejected card.



Do not handle the memory card immediately after shooting. The memory card may be hot, resulting in burns. Wait for the card to cool before removing it from the camera.



Request regular internal testing and cleaning for your camera. Build-up of dust in your camera can cause a fire or electric shock. Contact your Fujifilm dealer to request internal cleaning every two years. Please note that this service is not free of charge.



<u>Dispose of the product in accord with location regulations.</u>



Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.



Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

The Battery and Power Supply

Note: Check the type of battery used in your camera and read ■ Cautions: Handling the Battery the appropriate sections.

MARNING: Battery shall not be exposed to excessive heat such as sunshine, fire or the like.

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

Li-ion Batteries

Read this section if your camera uses a rechargeable Li-ion

before use. Keep the battery in its case when not in use.

■ Notes on the Battery

The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

Battery life can be extended by turning the camera off when not in use.

Battery capacity decreases at low temperatures; a depleted ACPower Adapters battery may not function when cold. Keep a fully charged • The AC power adapter is for indoor use only. spare battery in a warm place and exchange as necessary. • Be sure the cable is securely connected to the camera. or keep the battery in your pocket or other warm place and • Turn the camera off before disconnecting the adapter. Disinsert it in the camera only when shooting. Do not place the connect the adapter by the plug, not the cable. battery in direct contact with hand warmers or other heating • Do not disassemble. devices.

■ Charging the Battery

The battery can be charged using the camera and supplied AC adapter or an optional BC-W235 dual battery charger. $Charging\ times\ will increase\ at\ ambient\ temperatures\ below \\ \bullet\ If\ the\ adapter\ causes\ radio\ interference,\ reorient\ or\ relocate$ +10°C (+50°F) or above +35°C (+95°F). Do not attempt to charge the battery at temperatures above +40 °C (+104 °F); at temperatures below +5°C (+41°F), the battery will not charge.

Do not attempt to recharge a fully charged battery. The battery does not however need to be fully discharged before charging.

The battery may be warm to the touch immediately after charging or use. This is normal.

■ Battery Life

A noticeable decrease in the length of time the battery will hold a charge indicates that it has reached the end of its service life and should be replaced.

If the battery is left for long periods without charging, you may find that its quality degrades or that it no longer holds a charge. Charge the battery regularly.

■ Storage

If the camera will not be used for an extended period, store it at room temperature with the battery charged to approximately one half to 3/3 capacity.

If the camera will not be used for an extended period, remove the battery and store it in a dry place with an ambient temperature of from +15 °C to +25 °C (+59 °F to +77 °F). Do not store in locations exposed to extremes of temperature.

- · Do not transport or store with metal objects such as necklaces or hairpins.
- Do not expose to flame or heat.
- Do not disassemble or modify.
- Do not expose to low atmospheric pressures.
- Use with designated chargers only.
- · Dispose of used batteries promptly.
- Do not drop or subject to strong physical shocks.
- . Do not expose to water.
- Keep the terminals clean.
- The battery is not charged at shipment. Charge the battery The battery and camera body may become warm to the touch after extended use. This is normal.

■ Caution: Disposal

Dispose of used batteries in accord with local regulations. Attention should be drawn to the environmental aspects of battery disposal. Use the apparatus under moderate climate. Do not mechanically crush or split batteries.

- - Do not expose to high heat and humidity.
- · Do not subject to strong physical shocks.
- The adapter may hum or become hot to the touch during use. This is normal.
- the receiving antenna.

Using the Camera

- · Do not aim the camera at extremely bright light sources, precaution could damage the camera image sensor.
- · Strong sunlight focused through the viewfinder may damthe electronic viewfinder at the sun.

Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip), take a test shot and view the results to ensure that the camera is functioning normally. FUJIFILM Corporation cannot accept liability for damages or lost profits incurred as a result of product malfunction.

Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways by Fujifilm is under license. The SDHC and SDXC logos are that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing (CompactFlash Association). The HDMI logo is a trademark or of stage performances, entertainments, and exhibits, even registered trademark of HDMI Licensing LLC. All other trade when intended purely for personal use. Users are also asked names mentioned in this manual are the trademarks or registo note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Handlina

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

Liquid Crystal

In the event that the display is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- . If liquid crystal comes in contact with your skin, clean the area with a cloth and then wash thoroughly with soap and running water.
- . If liquid crystal enters your eyes, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance
- If liquid crystal is swallowed, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance.

Although the display is manufactured using extremely high-precision technology, it may contain pixels that are always lit or that do not light. This is not a malfunction, and images recorded with the product are unaffected.

Trademark Information

including artificial light sources or natural light sources Digital Split Image is a trademark or registered trademark of such as the sun in a cloudless sky. Failure to observe this FUJIFILM Corporation. Digital Micro Prism is a trademark or registered trademark of FUJIFILM Corporation. The typefaces included herein are solely developed by DynaComware Taiage the panel of electronic viewfinder (EVF). Do not aim wan Inc. Apple, iPhone, iPad, Mac, Mac OS X, OS X, macOS, Lightning and Apple ProRes are registered trademarks of Apple Inc. in the U.S.A. and other countries. Windows is a registered trademark of Microsoft Corporation in the U.S.A. and other countries. Android is a trademark or registered trademark of Google LLC. Adobe, the Adobe logo, Photoshop, and Lightroom are trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and other countries. Wi-Fi®, the Wi-Fi CERTIFIED logo, and Wi-Fi Protected Setup® are registered trademarks of the Wi-Fi Alliance®. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc., and any use of such marks trademarks of SD-3C, LLC. CFexpress is a trademark of the CFA tered trademarks of their respective owners.

Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

Color Television Systems

NTSC (National Television System Committee) is a color tele vision telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phase Alternation by Line) is a color television system adopted mainly in European countries and China.

Exif Print (Exif Version 2.32)

Exif Print is a newly revised digital camera file format in which information stored with photographs is used for optimal color reproduction during printing.

IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.

Lenses and Other Accessories

- Use a screw 4.5 mm or shorter when attaching a tripod.
- Fujifilm will not be held liable for performance issues or damage caused by the use of third-party accessories.

NOTICES

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Please read the "Safety Notes" and make sure you understand them before using the camera.

Perchlorate Material—special handling may apply. See: http://www.dtsc.ca.gov/hazardouswaste/perchlorate

For Customers in the U.S.A.

Tested To Comply With FCC Standards FOR HOME OR OFFICE USE



Contains IC: 10293A-WMBACBM25 Contains FCC ID: COF-WMBACBM25

FCC Statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement: This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

Notes on the Grant: To comply with Part 15 of the FCC Rules, this product must be used with a Fujifilm-specified ferrite-core A/V cable, USB cable, and DC supply cord.



A lithium ion battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.



California Code of Regulations, Title 20, Division 2, Chapter 4, Article 4, Appliance Efficiency Regulations, Sections 1601 through 1609

For Customers in Canada

CAN ICES-003 (B)/NMB-003(B)

CAUTION: This Class B digital apparatus complies with Canadian ICES-003

Industry Canada statement: This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter, except tested built-in radios. The County Code Selection This symbol on the batteries or accumulators feature is disabled for products marketed in the US/ Canada.

Radiation Exposure Statement: The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power Wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not product. found any biological effects. Some studies have suggested that some biological effects might occur, but such findings Liechtenstein: If you wish to discard this product, including have not been confirmed by additional research. X-H2S has the batteries or accumulators, please contact your local aubeen tested and found to comply with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Disposal of Electrical and Electronic Equipment in Private Households

In the European Union, Norway, Iceland and Liechtenstein: This symbol on the product, or in

the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste. Instead it should

be taken to an applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

indicates that those batteries shall not be treated as household waste.



If your equipment contains easy removable batteries or accumulators please dispose these separately according to your local requirements.

The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the

In Countries Outside the European Union, Norway, Iceland and

thorities and ask for the correct way of disposal.

In Japan: This symbol on the batteries indicates that they are to be disposed of separately.



Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- · exposed to rain, steam, or smoke
- · very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- · extremely cold
- · subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- · next to rubber or vinyl products

Wireless Network and Bluetooth Devices: Cautions

This product complies with the following EU Directives:

- RoHS Directive 2011/65/EU
- RE Directive 2014/53/EU

Hereby, FUJIFILM Corporation declares that the radio equipment type FF210002 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

https://dl.fujifilm-x.com/global/products/cameras/x-h2s/pdf/x-h2s_doc-nkt.pdf
The full text of the UK declaration of conformity is available at the following internet address:

The full text of the Un declaration of conformity is available at the following internet address: https://dl.fujifilm-x.com/en-gb/products/cameras/x-h2s/pdf/x-h2s_doc-nkt_uk.pdf
This compiliance is indicated by the following conformity marking placed on the product:

 $C \in$

This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth®).

Maximum radio-frequency power (EIRP):

WLAN 2.4 GHz: 10.81 dBm WLAN 5 GHz: 12.56 dBm Bluetooth: 1.86 dBm

IMPORTANT: Read the following notices before using the camera's built-in wireless transmitter.

- ① This product, which contains encryption function developed in the United States, is controlled by the United States Export Administration Regulations and may not be exported or re-exported to any country to which the United States embarques goods.
- Use only a wireless network or Bluetooth device. Fujifilm does not accept liability for damages resulting from unauthorized
 use. Do not use in applications requiring a high degree of reliability, for example in medical devices or other systems that
 may directly or indirectly impact human life. When using the device in computer and other systems that demand a greater
 degree of reliability than offered by wireless network or Bluetooth devices, be sure to take all necessary precautions to
 ensure safety and prevent malfunction.
- Use only in the country in which the device was purchased. This device conforms to regulations governing wireless network
 and Bluetooth devices in the country in which it was purchased. Observe all location regulations when using the device.
 Fujifilm does not accept liability for problems arising from use in other jurisdictions.
- Do not use the device in locations subject to magnetic fields, static electricity, or radio interference. Do not use the transmitter in
 the vicinity of microwave ovens or in other locations subject to magnetic fields, static electricity, or radio interference that
 may prevent reception of wireless signals. Mutual interference may occur when the transmitter is used in the vicinity of
 other wireless devices operating in the 2.4 GHz band.
- The wireless transmitter operates in the 2.4 GHz and 5 GHz bands using DSSS, OFDM and GFSK modulation.
- Security: Wireless network and Bluetooth devices transmit data via radio and consequently their use requires greater attention to security than applies in the case of wired networks.
 - Do not connect to unknown networks or networks to which you do not have access rights, even if they are displayed on your device, as such access may be considered unauthorized. Connect only to networks to which you have access rights.
 - Be aware that wireless transmissions may be vulnerable to interception by third parties.
 - This device cannot be directly connected to telecommunications networks (including public wireless LANs) operated by providers or mobile, landline, Internet, or other telecommunications services.
- The following may be punishable by law:
 - Disassembly or modification or this device
 - Removal of device certification labels
- This device operates on the same frequency as commercial, educational, and medical devices and wireless transmitters. It also operates on the same frequency as licensed transmitters and special unlicensed low-voltage transmitters used in RFID tracking systems for assembly lines and in other similar applications.
- To prevent interference with the above devices, observe the following precautions.
 Confirm that the RFID transmitter is not in operation before using this device. Should you observe that the device causes interference in licensed transmitters used for RFID tracking, immediately stop using the affected frequency or move the device to another location. If you notice that this device causes interference in low-voltage RFID tracking systems, contact a Fujifilm representative.

- Do not use this device on board an aircraft. When on an aircraft, follow the instructions of airline personnel. Note that this product may emit radio-frequency radiation even when off. This can be prevented by selecting **ON** for **AIRPLANE MODE** in the network/USB setting menu before boarding.
- Requirements in AT/BE/BG/CZ/DK/EE/FR/DE/IS/IE/IT/EL/ES/CY/LV/LI/LT/LU/HU/MT/NL/NO/PL/PT/RO/SI/SK/TR/FI/SE/CH/ UK/HR. 5150 MHz-5350 MHz is for indoor use only.

Specific Absorption Rate (SAR) Information

SAR is measured with the device at 0 mm to the body, while transmitting at the highest certified output power level in all frequency bands of the device. The maximum SAR value is 0.235 W/kg (head/body) averaged over 10 gram of tissue.



U.K. Importer

FUJIFILM UK Limited

Fujifilm House, Whitbread Way, Bedford, Bedfordshire, MK42 0ZE, United Kingdom

EU Importer:

FUJIFILM Electronic Imaging Europe GmbH Fujistrasse 1 47533 Kleve, Germany

Be sure to read these notes before using the lens

Safety Notes

- Make sure that you use the lens correctly. Read these safet notes and the camera Basic Manual carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



This icon indicates that death or serious WARNING injury can result if the information is ignored.



This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information requires attention ("Important").



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark indicate an action that must be performed ("Required").

∕N WARNING



Do not immerse in or expose to water. Failure to observe this precaution can cause a fire or electric shock



Do not disassemble (do not open the case). Failure to observe this precaution can cause fire, electric shock, or injury due to product malfunction.



Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not place on unstable surfaces. The product may fall, causing injury.



Do not view the sun through the lens or camera viewfinders. Failure to observe this precaution can cause permanent visual impairment.

CAUTION



Do not use or store in locations that are exposed to steam, or smoke or are very humid or extremely dusty. Failure to observe this precaution can cause fire or electric shock.



Do not leave in direct sunlight or in locations subject to very high temperatures, such as in a closed vehicle on a sunny day. Failure to observe this precaution can cause fire.



Keep out of the reach of small children. This product could cause injury in the hands of a child.



Do not handle with wet hands. Failure to observe this precaution can cause electric shock. Keep the sun out of the frame when shooting backlit



subjects. Sunlight focused into the camera when the sun is in or close to the frame can cause fire



When the product is not in use, replace the lens caps and store out of direct sunlight. Sunlight focused by the lens can cause fire or burns.



Do not carry the camera or lens while they are attached to a tripod. The product can fall or strike other objects, causing injury.

Product Care

To ensure continued enjoyment of the product, observe the following precautions.

Camera body: Use a soft, dry cloth to clean the camera body after each use. Do not use alcohol, thinner, or other volatile chemicals, which could discolor or deform the leather on the camera body. Any liquid on the camera should be removed immediately with a soft, dry cloth. Use a blower to remove dust from the monitor, taking care to avoid scratches, and then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. To prevent dust entering the camera, replace the body cap when no lens is in place.

Image sensor: Multiple photographs marred by spots or blotches in identical locations may indicate the presence of dust on the image sensor. Clean the sensor using ☑ USER SETTING > SENSOR CLEANING.

Cleaning the Image Sensor

Dust that cannot be removed using **ZUSER SETTING** > **SENSOR CLEANING** can be removed manually as described below.

- Note that there will be a charge to repair or replace the image sensor if it is damaged during cleaning.
 - 1 Use a blower (not a brush) to remove dust from the sensor.
 - Do not use a brush or blower brush. Failure to observe this precaution could damage the sensor.



- 2 Check whether the dust has been successfully removed. Repeat Steps 1 and 2 as necessary.
- 3 Replace the body cap or lens.

Firmware Updates

Updates to product firmware may result in changes not described in the manual. For more information, visit: https://fujifilm-x.com/support/download/firmware/cameras/

Checking the Firmware Version

- The camera will only display the firmware version if a memory card is inserted.
 - 1 Turn the camera off and check that a memory card is inserted.
 - 2 Turn the camera on while pressing the DISP/BACK button. The current firmware version will be displayed; check the firmware version.
 - 3 Turn the camera off.
- To view the firmware version or update firmware for optional accessories such as interchangeable lenses, shoe-mounted flash units, and mount adapters, mount the accessories on the camera.

Troubleshooting

Consult the table below should you encounter problems using your camera. If you don't find the solution here, contact your local Fujifilm distributor.



Troubleshooting information for network/USB features is available at: https://fujifilm-dsc.com/en/manual/x-h2s connection/

Power and Battery

1 ower and batte	• 7
Problem	Solution
The camera does not turn on.	 The battery is exhausted: Charge the battery or insert a fully-charged spare battery (46). The battery is inserted incorrectly: Reinsert in the correct orientation (40). The battery-chamber cover is not latched: Latch the battery-chamber cover (40).
The monitor does not turn on.	The monitor may not turn on if the camera is turned off and then on again very quickly. Keep the shutter button pressed halfway until the monitor activates.
The battery runs down quickly.	The battery is cold: Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture. There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth. ON is selected for AF/MF SETTING > PRE-AF: Turn PRE-AF off (■ 152). The battery has been charged many times: Select BATTERY AGE to view the battery age; if the battery is old, replace it with a new battery (■ 248).
The camera turns off	The battery is exhausted: Charge the battery or insert a
suddenly.	fully-charged spare battery (🕮 46).
The camera does not turn off.	The camera may be busy. Check the indicator lamp (11).

O,
$\overline{\Box}$
3
Ξ.
a
_
Z
0
-
ው
S

Problem	Solution
	• Make sure that the AC power adapter is correctly plugged in (□ 46).
	• Ensure that the plug adapter is correctly connected to the AC power adapter (≅ 46).
Charging does not start.	• The battery has not been recharged for an extended period: If
	the battery has not been charged for an extended period,
	charging will be disabled to ensure safety. Replace it with a new battery.
	• Insert the camera battery (🕮 40).
Charging does not start (USB).	• Reinsert the camera battery in the correct orientation (1994).
	• Confirm that the camera is connected to the computer (1994).
	• If the computer is off or in sleep mode, turn on or wake
	the computer and disconnect and reconnect the USB cable (🗎 49).
	Insert the battery.
Charging does not start	 Reinsert the battery in the correct orientation.
(battery charger).	• The AC adapter is not correctly connected to the charger: Check
	that adapter is correctly connected to the charger.
Charging is slow.	Charge the battery at room temperature.
	• There is dirt on the battery terminals: Clean the terminals
The indicator lamp	with a soft, dry cloth (🗐 40).
blinks, but the battery does not charge.	• The battery has been charged many times: Select BATTERY
	AGE to view the battery age; if the battery is old, replace
	it with a new battery (1 248). If the battery still fails to
The power supply icon is	charge, contact your Fujifilm dealer (🗎 338). Confirm that POWER SUPPLY ON/COMM OFF is se-
not displayed.	lected for USB POWER SUPPLY/COMM SETTING.
not dispiayed.	piccica for OSD FOWER SOFFEI/COIVIIVI SETTING.

Menus and Displays

Problem	Solution
Display is not in English.	Select ENGLISH for I USER SETTING > ■ 言語/LANG. (■ 54, 247).

Shooting

Shooting	
Problem	Solution
No picture is taken when the shutter button is pressed.	 The memory card is full: Insert a new memory card or delete pictures (□ 42, 223). The memory card is not formatted: Format the memory card in the camera (□ 244). There is dirt on the memory card contacts: Clean the contacts with a soft, dry cloth. The memory card is damaged: Insert a new memory card (□ 42). The battery is exhausted: Charge the battery or insert a fully-charged spare battery (□ 46). The camera has turned off automatically: Turn the camera on (□ 50). You are using a third-party mount adapter: Select ON for SHOOT WITHOUT LENS (□ 271).
Mottling ("noise") appears in the monitor or viewfinder when the shutter button is pressed halfway.	Gain is increased to aid composition when the subject is poorly lit and aperture is stopped down, which may result in noticeable mottling when images are previewed in the displays. Images taken with the camera are unaffected.
The camera does not focus.	 The subject is not suited to autofocus: Use focus lock or manual focus (□ 109). The focus area is too small for the intended subject: Increase the size of the focus area by a couple of steps (□ 98).
No panorama is recorded when the shutter button is pressed.	The indicator lamp was orange when you attempted to record a panorama: Wait until the indicator lamps turns off (🗐 11).

Problem	Solution
	• The subject's face is obscured by sunglasses, a hat, long hair, or
	other objects: Remove the obstructions (🕮 153).
	• The subject's face occupies only a small area of the frame:
	Change the composition so that the subject's face occu-
	pies a larger area of the frame (🕮 153).
No face is detected.	• The subject's face is turned away from the camera: Ask the sub-
	ject to face the camera (🕮 153).
	• 🖳 FACE/EYE DETECTION SETTING is off: Turn 🖳 FACE/EYE
	DETECTION SETTING on (🕮 153).
	The camera is tilted: Keep the camera level.
	• The subject's face is poorly lit: Shoot in better light.
	• The subject is partially hidden: Choose a vantage point
	where you can see as much of the subject as possible
	(□ 155).
	• The subject occupies only a small portion of the frame: Get
No subject is detected.	closer to your subject so it occupies more of the frame
	(■ 155).
	• OFF is selected for SUBJECT DETECTION SETTING: Select
	SUBJECT DETECTION ON (EE 155).
	The subject is poorly lit: Shoot in better light.
	• The flash is disabled: Adjust settings (🕮 175).
	• The electronic shutter is enabled: Choose a SHUTTER TYPE
	that does not use the electronic shutter (🕮 171).
The flash does not fire.	• The battery is exhausted: Charge the battery or insert a ful-
	ly-charged spare battery (🕮 46).
	• The camera is in bracketing or continuous mode: Select single
	frame mode (🕮 9).
	• The subject is not in range of the flash: Position the subject in
The flack door not fully	range of the flash.
The flash does not fully light the subject.	• The flash window is obstructed: Hold the camera correctly.
	• Shutter speed is faster than the sync speed: Choose a slower
	shutter speed (🕮 74, 78, 373).

Problem	Solution
Pictures are blurred.	The lens is dirty: Clean the lens. The lens is blocked: Keep objects away from the lens (57). The lens is directly divising the sting and the forms in directly are the forms in directly and the forms in directly are the forms in directly and the forms in directly are the d
	• !AF is displayed during shooting and the focus frame is displayed in red: Check focus before shooting (\$\square\$ 58).
Pictures are mottled.	Shutter speed is slow and the ambient temperature is high: This is normal and does not indicate a malfunction. * Use pixel mapping (■ 141). * X-rays, cosmic rays, and other forms of radiation interacting with the image sensor may cause bright spots of various colors such as white, red, and blue. Pixel mapping helps reduce the occurrence of such bright spots.
	 The camera has been used continuously at high temperatures: Turn the camera off and wait for it to cool down (== 50, 368). A temperature warning is displayed: Turn the camera off and wait for it to cool down (== 50, 368).

Playback

· injution	
Problem	Solution
Pictures are grainy.	The pictures were taken with a different make or model of camera.
Playback zoom is unavailable.	The pictures were created using RESIZE or with a different make or model of camera.
No sound in movie playback.	 Playback volume is too low: Adjust playback volume (@ 252). The microphone was obstructed: Hold the camera correctly during recording.
	 The speaker is obstructed: Hold the camera correctly during playback.
Selected pictures are not deleted.	Some of the pictures selected for deletion are protected
Pictures remain after ERASE > ALL FRAMES is selected.	Remove protection using the device with which it was originally applied (1998) 227).
File numbering is unexpectedly reset.	The battery-chamber cover was opened while the camera was on. Turn the camera off before opening the battery-chamber cover (🕮 281).

Connections

Problem	Solution
The monitor is blank.	The camera is connected to a TV: Pictures will be displayed on
	the TV instead of in the camera monitor (🕮 60).
Both the TV and camera monitor are blank.	The display mode selected with the VIEW MODE button is EVF ONLY + . Put your eye to the viewfinder. Use the VIEW MODE button to choose another display mode (18).
No picture or sound on TV.	 The camera is not properly connected: Connect the camera properly (□ 60). Input on the television is set to "TV": Set input to "HDMI" (□ 60). The volume on the TV is too low: Use the controls on the television to adjust the volume (□ 60).

Miscellaneous

Solution
• Temporary camera malfunction: Remove and reinsert the
battery (🕮 40).
• The battery is exhausted: Charge the battery or insert a ful-
ly-charged spare battery (🕮 46).
• The camera is connected to a wireless LAN: End the connec-
tion.
• The controls are locked: Press and hold the MENU/OK button
to unlock the controls (🕮 15, 17).
Remove and reinsert the battery (🕮 40). If the problem
persists, contact your Fujifilm dealer.
Adjust the volume (🕮 250).
TTL-LOCK is active: End TTL-LOCK (🕮 176).

Warning Messages and Displays

The following warnings appear in the display.

Warning	Description
red)	Low battery. Charge the battery or insert a fully-charged
	spare battery.
(blinks red)	Battery exhausted. Charge the battery or insert a ful-
	ly-charged spare battery.
! AF (displayed in red with	The camera cannot focus. Use focus lock to focus on an-
red focus frame)	other subject at the same distance, then recompose the
ieu iocus iidilie)	picture.
Aperture or shutter	The subject is too bright or too dark and the picture will be
speed displayed in red	over- or under-exposed. Use the flash for additional light-
	ing when taking photographs of poorly-lit subject.
FOCUS ERROR	Camera malfunction. Turn the camera off, remove the lens,
LENS CONTROL ERROR	and check for foreign matter between the lens and the
TURN OFF THE CAMERA	camera body, then replace the lens and turn the camera
AND TURN ON AGAIN	on. If the problem persists, contact a Fujifilm dealer.
	The memory card is not formatted or the memory card has been
	formatted in a computer or other device: Format the memory
	card using USER SETTING > FORMAT .
CARD NOT INITIALIZED	• The memory card contacts require cleaning: Clean the con-
	tacts with a soft, dry cloth. If the message is repeated,
	format the card. If the message persists, replace the card.
	Camera malfunction: Contact a Fujifilm dealer.
	Turn the camera off, remove the lens, and check for for-
LENS ERROR	eign matter between the lens and the camera body, then
	replace the lens and turn the camera on. If the problem
	persists, contact a Fujifilm dealer.

Warning	Description
	• The memory card is not formatted for use in the camera: For
	mat the card.
	 The memory card contacts require cleaning or the memory card
CARD ERROR	is damaged: Clean the contacts with a soft, dry cloth. If the
CARD ERROR	message is repeated, format the card. If the message per
	sists, replace the card.
	 Incompatible memory card: Use a compatible card.
	 Camera malfunction: Contact a Fujifilm dealer.
PROTECTED CARD	The memory card is locked. Unlock the card.
BUSY	The memory card is incorrectly formatted. Use the camer
	to format the card.
	The memory card is full and pictures cannot be recorded
SD MEMORY FULL	Delete pictures or insert a memory card with more fre
	space.
	Memory card error or connection error: Reinsert the card or
	turn the camera off and then on again. If the messag
	persists, contact a Fujifilm dealer.
	Not enough memory remaining to record additional picture
	Delete pictures or insert a memory card with more fre
WRITE ERROR	space.
	The memory card is not formatted: Format the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of the memory card The memory card was a series of th
	The memory card was removed while data were being recorded On not remove the memory card during recording.
	Do not remove the memory card during recording.
FRAME NO. FULL	The memory card write speed is slow: When recording moving the sure the memory card write speed is fast enough.
	ies, be sure the memory card write speed is fast enough. The camera has run out of frame numbers (current fram
	number is 999-9999). Insert a formatted memory card and
	select RENEW for 2 SAVE DATA SET-UP > FRAME NO
	Take a picture to reset frame numbering to 100-0001, the
	select CONTINUOUS for FRAME NO.
	percet Colatination 1011 Invite 140.

4
0
₫
ijυ
V1

Warning	Description	
	• The file is corrupt or was not created with the camera: The file	
READ ERROR	cannot be viewed.	
	• The memory card contacts require cleaning: Clean the con-	
NEAD ENNUN	tacts with a soft, dry cloth. If the message is repeated,	
	format the card. If the message persists, replace the card.	
	Camera malfunction: Contact a Fujifilm dealer.	
PROTECTED FRAME	An attempt was made to delete or rotate to a protected pic-	
PROTECTED FRAME	ture. Remove protection and try again.	
CAN NOT CROP	The picture is damaged or was not created with the camera.	
	Print orders can contain no more than 999 pictures. Copy	
DPOF FILE ERROR	any additional pictures you wish to print to another memo-	
	ry card and create a second print order.	
CAN NOT SET DPOF	The picture cannot be printed using DPOF.	
CAN NOT SET DPOF	Movies cannot be printed using DPOF.	
CAN NOT ROTATE	The selected picture cannot be rotated.	
CAN NOT ROTATE	Movies cannot be rotated.	
CANNOT EXECUTE	The selected operation is not supported: Check whether the	
	picture was recorded with a different model of camera.	

Warning	Description		
! ∦ (yellow)	The camera is approaching the maximum temperature al-		
CAMERA IS APPROACHING	Glowed when STANDARD is selected for AUTO POWER		
STANDARD	OFF TEMP. and will shortly turn off automatically. Turn th		
TEMPERATURE LIMIT	camera off and wait for it to cool.		
!# (yellow) CAMERA IS APPROACHING HIGH TEMPER- ATURE LIMIT.DO NOT HOLD CAMERA FOR LONG PERIODS OF TIME	The camera is approaching the maximum temperature allowed when HIGH is selected for AUTO POWER OFF TEMP . and will shortly turn off automatically. Remaining in contact with the camera could result in low-temperature burns; mount the camera on a tripod or take other steps to avoid prolonged contact with the camera. The camera will shortly turn off automatically. Turn the camera off and wait for it to cool. Mottling may increase in pictures taken when this warning is displayed.		
!\$ (red) HIGH TEMPERATURE LIMIT REACHED SHUTTING DOWN	The camera temperature has reached the cutoff point and the camera is about to turn off automatically. Turn the camera off and wait for it to cool. Mottling may increase in pictures taken when this warning is displayed.		

Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

	Capacity	SD/CFexpress memory cards 64 GB	
		FINE	NORMAL
Photos	3:2	4080	6040
	RAW (UNCOMPRESSED)	1090	
riiutus	RAW (LOSSLESS COMPRESSED)	SSED) 1990	
RAW (COMPRESSED)		276	0
Movies ^{1,2} 4K 2160		80 min	utes
MONIES	1080 III	80 minutes	

¹ Use a UHS speed class 3 card or better.

² Assumes default bit rate.



Specifications

- Peci.			
System			
Model	FUJIFILM X-H2S		
Product Number	FF210002		
Effective pixels	Approx. 26.16 million		
lmage sensor	23.5 mm $ imes$ 15.6 mm (APS-C), X-Trans CMOS 5 HS senso		
	primary color filter		
Storage media	· ·		
	memory cards		
Memory card slots	 SD memory card slot (UHS-II compliant) ×1 		
	 CFexpress memory card slo 		
File system	Still pictures: Compliant with DCF 2.0		
	• Compressed: Exif 2.32 JPEG-baseline compliant; DPOF compli-		
	ant; HEIF compliant (4:2:2, 10-bit)		
	 Uncompressed or compressed using a reversible or non-reversible 		
	algorithm: RAW (original RAF format; special-purpose software		
	required); RAW+JPEG available; TIFF (RGB)		
	• Movies: Compliant with HEVC/H.265, H.264, and ProRes		
	Audio (including voice memos):		
	- LPCM (two channels: 24-bit, 48 kHz sampling)		
	- AAC (MP4 recordings only)		
	Audio (via XLR microphone adapter): DCAA (records as a 24 bit 40 bit a consultant formula as a		
	- LPCM (two channels: 24-bit, 48 kHz sampling; four chan-		
	nels: 24-bit, 48 kHz sampling) - AAC (MP4 recordings only; two channels: 16-bit, 48 kHz		
		only; two channels: 16-bit, 48 kHz	
lmage size	sampling) 3:2 (6240 × 4160)	1:1 (4160 × 4160)	
illage size	16:9 (6240 × 4100)	I. I (4100 × 4100)	
	M 3:2 (4416 × 2944)	M 1:1 (2944 \times 2944)	
	M 16 : 9 (4416 \times 2488)		
	S 3:2 (3120 × 2080)	S 1:1 (2080 × 2080)	
	S 16:9 (3120 × 1760)		
	RAW (6336 × 4188)	TIFF (6240 × 4160)	
	Danorama : vertical (2160×9	9600)/horizontal (9600 × 1440)	
	M panorama: vertical (2160×6		
		,	

FUJIFII M X mount
 Still pictures: Standard output sensitivity equivalent to ISO 160–12800 in increments of ½ EV; AUTO 1–3; extended output sensitivity equivalent to ISO 80, 100, 125, 25600, or 51200 Movies: Standard output sensitivity equivalent to ISO 160–12800 in increments of ½ EV; AUTO; extended output sensitivity equivalent to ISO 25600
256-segment through-the-lens (TTL) metering; MULTI, SPOT, AVERAGE, CENTER WEIGHTED
Programmed AE (with program shift); shutter-priority AE; aperture-priority AE; manual exposure
• Still pictures: −5 EV−+5 EV in increments of ⅓ EV • Movies: −2 EV−+2 EV in increments of ⅓ EV
• MECHANICAL SHUTTER, E-FRONT CURTAIN SHUTTER, E-FRONT + MECHANICAL • Mode P: 4 s to 1/8000 s • Modes S and M: 15 min. to 1/8000 s • Bulb: Max. 60 min. • ELECTRONIC SHUTTER • Mode P: 4 s to 1/32000 s • Modes S and M: 15 min. to 1/32000 s • Modes S and M: 15 min. to 1/32000 s • Bulb: Fixed at 1 s • MECHANICAL + ELECTRONIC, E-FRONT + MECHANICAL + ELECTRONIC • Mode P: 4 s to 1/32000 s • Mode A: 30 s to 1/32000 s • Mode A: 30 s to 1/32000 s • Mode S and M: 15 min. to 1/32000 s • Modes S and M: 15 min. to 1/32000 s • Modes S and M: 15 min. to 1/32000 s • Bulb: Max. 60 min

Continuous	CONTINUE LABOR	Available frame advance rates	
	CONTINUOUS MODE	(JPEG)	
	40fps(1.25X CROP)*	40	
	30fps(1.25X CROP)*	30	
	20fps(1.25X CROP)*	20	
	15fps(1.25X CROP)*	15	
	10fps(1.25X CROP)*	10	
	40fps*	40	
	30fps*	30	
	20fps*	20	
	15fps	15	
	10fps	10	
	8.0fps	8.0	
	7.0fps	7.0	
	5.0fps	5.0 3.0	
	3.0fps		
	* Available with electronic shutter only. The frame rate and number of frames per burst varies with shooting conditions and type of memory card used.		
	 Focus-area selection: SINGLE F 	POINT, ZONE, WIDE/TRACKING, ALL	
White balance	Auto (WHITE PRIORITY, AUTO, AMBIENCE PRIORITY), Custom 1,		
	Custom 2, Custom 3, color temperature selection, direct sun-		
	light, shade, daylight fluorescent, warm white fluorescent,		
	cool white fluorescent, incan	descent, underwater	
Self-timer	Off, 2 sec., 10 sec.		

cal
N _o
tes

System	
Flash mode	• MODE: TTL MODE (FLASH AUTO, STANDARD, SLOW SYNC.),
	MANUAL, MULTI, OFF
	• SYNC. MODE: 1ST CURTAIN, 2ND CURTAIN, AUTO FP (high-
	speed sync)
	• RED EYE REMOVAL: 🍑 FLASH, OFF
Hot shoe	Provided (supports TTL flash control); supports sync speeds as
	fast as $\frac{1}{250}$ s (mechanical shutter) or $\frac{1}{125}$ s (electronic shutter)
Sync contact	X contact; supports sync speeds as fast as ½50 s (mechanical
	shutter) or 1/125 s (electronic shutter)
Sync terminal	Provided
Electronic viewfinder	$^{\prime}$ 0.5-in., 5760k-dot OLED viewfinder; magnification 0.80 $ imes$ with
(EVF)	50 mm lens (35 mm format equivalent) at infinity and diopter
	set to -1.0 m^{-1} ; diagonal angle of view approximately 40°
	(horizontal angle of view approximately 32°)
	• Diopter adjustment: -5 to +3 m ⁻¹
	• Eyepoint: Approximately 24 mm
LCD monitor	• Rear monitor: 3.0-in/7.6 cm, 1620k-dot color touch screen
	LCD monitor, Vari-angle LCD monitor
	• Shoulder monitor: 1.28-in/3.25 cm, 128 × 128-dot memory
	LCD monitor
Movies	• Movie size: 621 3:2, 41 16:9, DCI 17:9, FHD 16:9, FHD 17:9
(with stereo sound)	• Frame rate: 59.94P, 50P, 29.97P, 25P, 24P, 23.98P
	Recording/output format:
	- H.265 (10-bit MOV 4:2:2/4:2:0; 720, 360, 200, 100, or 50
	Mbps)
	- H.264 (8-bit MOV/MP4 4:2:0; 360, 200, 100, or 50Mbps)
	- ProRes 422 HQ, ProRes 422, ProRes 422 LT (10-bit MOV
	4:2:2)
	- HDMI output supported (RAW output supported with
	Atomos and Blackmagic Design external recorders; 8-bit
	4:2:2/10-bit 4:2:2)

System

High-speed movies • **Movie size**: **413** 16:9, **DCI** 17:9, **FHD** 16:9, **FHD** 17:9

• Frame advance rate: 240P*, 200P*, 120P, 100P

* FID only.

Input/output terminals

Microphone connector Ø3.5 mm mini-stereo jack **Headphone jack socket** Ø3.5 mm mini-stereo jack Remote release connector Ø2.5 mm 3-pole mini jack Digital input/output USB connector (Type-C) USB3.2 Gen2x1 HDMI output HDMI connector (Type A)

Power supply/other Power supply NP-W235 rechargeable battery (supplied with camera) Battery life • Battery type: NP-W235

• Lens: XF35mmF1.4 R

External flash units: Disabled

Shooting mode: Mode P

Number of shots			
PERFORMANCE	LCD	EVF	
B00ST ¹	Approx. 530	Approx. 390	
NORMAL	Approx. 580	Approx. 550	
ECONOMY	Approx. 720	Approx. 610	

Number of shots (VG-XH vertical battery grip)			
PERFORMANCE	LCD	EVF	
B00ST ¹	Approx. 1410	Approx. 1040	
NORMAL	Approx. 1520	Approx. 1440	
ECONOMY	Approx. 1850	Approx. 1580	

Total length of footage that can be recorded on a single charge

	Actual battery life	Continuance battery life of	
Mode	of movie capture	movie capture	
6.2K ²	Approx. 90 minutes	Approx. 120 minutes	
4K ³	Approx. 70 minutes	Approx. 105 minutes	
FHD: 3	Approx. 95 minutes	Approx. 165 minutes	
High-speed movies ⁴	Approx. 60 minutes	-	

1 EVF FRAME RATE PRIORITY (120P) selected EVF/LCD BOOST SETTING.

2 At a frame rate of 29.97 fps.

3 At a frame rate of 59.94 fps.

4 4K at a frame rate of 120 fps.

CIPA standard. Measured using battery supplied with camera and SD memory card.

Note: Battery endurance varies with battery charge level and the figures given above are not guaranteed. Battery endurance will decline at low temperatures.

Power supply/other	
Camera size	136.3 mm \times 92.9 mm \times 84.6 mm (42.8 mm excluding projections,
$(W \times H \times D)$	measured at thinnest part)/5.37 in. \times 3.66 in. \times 3.33 in. (1.69 in.)
Camera weight	Approx. 579 g/20.5 oz., excluding battery, accessories, and
	memory card
Shooting weight	Approx. 660 g/23.3 oz., including battery and memory card
Operating conditions	• Temperature : -10 °C to +40 °C/+14 °F to +104 °F (+5 °C to
	$+40 ^{\circ}\text{C}/+41 ^{\circ}\text{F}$ to $+104 ^{\circ}\text{F}$ when battery is charging)
	• Humidity: 10% to 80% (no condensation)

	rainary. 1070 to 0070 (no condensation)
Wireless transmitter	
Wireless LAN	
Standards	IEEE 802.11a/b/g/n/ac (standard wireless protocol)
Operating frequency	Israel, Indonesia
(center frequency)	: 2,412 MHz–2,462 MHz (11 channels)
	 USA, Canada, Brazil, China, India, Korea, Malaysia
	: 2,412 MHz–2,462 MHz (11 channels)
	: 5,180 MHz-5,320 MHz (W52, W53)
	: 5,745 MHz-5,825 MHz (UNII-3)
	• European Union, Japan, United Kingdom, Australia, Norway, New
	zealand, Turkey, Hong Kong, Philippines, Vietnam, Singapore,
	Thailand, UAE, Russia, Taiwan, Saudi Arabia, Qatar, Bahrain,
	Oman, Egypt, Iran, Kuwait, Lebanon, Uzbekistan
	: 2,412 MHz–2,462 MHz (11 channels)
	: 5,180 MHz-5,320 MHz (W52, W53)
	: 5,500 MHz-5,700 MHz (W56)
Access protocols	Infrastructure
Bluetooth®	
Standards	Bluetooth version 4.2 (Bluetooth Low Energy)
Operating frequency (center frequency)	2,402 MHz–2,480 MHz

12

NP-W235 rechargeable battery		
Nominal voltage	7.2 V	
Nominal capacity	2350 mAh	
Rating capacity	2200 mAh	
Operating	0 °C to +40 °C/+32 °F to +104 °F	
temperature		
Dimensions	38.92 mm × 22.8 mm × 52.26 mm/	
$(W \times H \times D)$	1.5 in. \times 0.9 in. \times 2.1 in.	
Weight	Approx. 79 g/2.8 oz.	

AC-5VJ AC power adapter	
Manufacturer	Dongguan Yingiu Power Co.,Ltd.
Address	No.6 Yongxing Road, Shayao Village, Shijie Town, 523292 Dongguan City, Guangdong Province, PEOPI F'S REPUBLIC OF CHINA
Model name	AC-5VJ
Rated input	100 V – 240 V AC, 50/60 Hz
Input capacity	Max. 50 VA
Rated output	DC5.0V 3.0A 15.0W
Average active efficiency	84.8 %
Efficiency at load 10%	84.2 %
No-load power consumption	0.02 W
Operating temperature	0 °C to +40 °C/+32 °F to +104 °F
Weight	Approx. 45 g \pm 2 g/1.6 oz. \pm 0.1 oz.



Weight and dimensions vary with the country or region of sale.



Specifications and performance are subject to change without notice. Fujifilm will not be held liable for any errors this manual may contain. The appearance of the product may differ from that described in this manual.

MEMO

MEMO

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN https://fujifilm-x.com













