

# **Exus**

2019

ES 350

OWNER'S MANUAL



<u>^</u>

**WARNING:** Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

#### Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

#### **U.S. OWNERS**

- In the U.S. mainland or Canada: Lexus Roadside Assistance
   1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- In Hawaii:
   Servco Automotive Roadside Assistance/Customer Services
   1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

#### CANADIAN OWNERS

In Canada or the U.S. mainland:
 Lexus Roadside Assistance/Customer Service
 1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our websites for further information.

- The U.S. mainland: www.lexus.com
- Hawaii: www.servcolexus.com
- Canada: www.lexus.ca

#### ©2018 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

Picto	rial	index
1 1010	ııaı	IIIUEX

## Search by illustration

For safety and security	Make sure to read through them (Main topics: Child seat, theft deterrent system)	1
Vehicle status information and indicators	Reading driving-related information (Main topics: Meters, multi-information display)	2
Before driving	Opening and closing the doors and windows, adjustment before driving (Main topics: Keys, doors, seats, power windows)	3
Driving	Operations and advice which are necessary for driving (Main topics: Starting engine, refueling)	4
Interior features	Usage of the interior features (Main topics: Air conditioner, storage features)	5
Maintenance and care	Caring for your vehicle and maintenance procedures (Main topics: Interior and exterior, light bulbs)	6
When trouble arises	What to do in case of malfunction and emergency (Main topics: Battery discharge, flat tire)	7
Vehicle specifications	Vehicle specifications, customizable features (Main topics: Fuel, oil, tire inflation pressure)	8
For owners	Reporting safety defects for U.S. owners, and seat belt, SRS airbag and headlight aim instructions for Canadian owners	9
Index	Search by symptom	
index	Search alphabetically	

Fory	our information6		D ( 1	
Read	ding this manual10	3	Before driving	
	to search11			
Picto	orial index12	3-1.	Key information	
1	For safety and security		Keys	86
	Tor safety and security	3-2.	Opening, closing and locking	y the
1-1.	For safe use		doors and trunk	
1-1.	Before driving22		Doors	
	For safe driving23		Trunk	
	Seat belts24		Smart access system with puston start	
	SRS airbags <b>28</b>	3-3.	Adjusting the seats	
	Front passenger occupant classifi-		Front seats	107
	cation system37		Driving position memory	108
	Exhaust gas precautions41		Head restraints	111
1-2.	Child safety	3-4.	Adjusting the steering wheel	and
	Riding with children42		mirrors	
	Child restraint systems42		Steering wheel	113
1-3.	Theft deterrent system		Inside rear view mirror	114
	Engine immobilizer system 54		Outside rear view mirrors	115
	Alarm <b>56</b>	3-5.	Opening and closing the win	dows
	Vehicle status information and		and moon roof	
2	indicators		Power windows	118
			Moon roof	
2-1.	Instrument cluster		Panoramic moon roof	123
	Warning lights and indicators 60	4	Dutata a	
	Gauges and meters (except F SPORT models)64		Driving	
	Gauges and meters (F SPORT	4-1.	Before driving	
	models)		Driving the vehicle	128
	Multi-information display71		Cargo and luggage	133
	Head-up display78		Vehicle load limits	
	Fuel consumption screen82		Trailer towing	135
			Dinghy towing	136
		4-2.	Driving procedures	
			Engine (ignition) switch	137

	Automatic transmission141	5	
	Turn signal lever145	5	nterior features
	Parking brake <b>146</b>	E 1	D . T .
	Brake Hold148	J-1.	Remote Touch
-3.	Operating the lights and wipers	г о	Remote Touch244
	Headlight switch150	5-2.	Lexus Climate Concierge
	Automatic High Beam153		Lexus Climate Concierge 249
	Windshield wipers and washer 155	5-3.	Using the air conditioning system
4.	Refueling		Automatic air conditioning system25
	Opening the fuel tank cap 161		Heated steering wheel/seat heat-
5.	Using the driving support systems		ers/seat ventilators258
	Lexus Safety System+2.0163	5-4	Using the interior lights
	PCS (Pre-Collision System)169	•	Interior lights list262
	LTA (Lane Tracing Assist) 176	5-5	Using the storage features
	RSA (Road Sign Assist)185	J-J.	List of storage features 265
	Dynamic radar cruise control with		Trunk features268
	full-speed range187	5.6	Using the other interior features
	BSM (Blind Spot Monitor) 197	J-0.	Other interior features
	Driving Mode Select switch 202		
	PKSA (Parking Support Alert)204		Garage door opener
	Intuitive parking assist205		Compass
	RCTA (Rear cross traffic alert)		Lexus Enform Safety Connect 289 Lexus Enform Remote
	function		Lexus Enform Service Connect
	RCD (Rear Camera Detection)		Lexus Enform Service Connect
	function		
	PKSB (Parking Support Brake)218	6	Maintenance and care
	Parking Support Brake function (static objects) 224		
	Parking Support Brake function	6-1.	Maintenance and care
	(rear-crossing vehicles)229		Cleaning and protecting the vehi-
	Parking Support Brake function		cle exterior290
	(rear pedestrians)		Cleaning and protecting the vehi-
	Driving assist systems236		cle interior299
ó.	Driving tips	6-2.	Maintenance
	Winter driving tips240		Maintenance requirements30
			General maintenance302

If you have a flat tire......362
If the engine will not start .......369

6-3.	Emission inspection and maintenance (I/M) programs	If you lose your keys371  If the fuel filler door cannot be opened371  If the electronic key does not operate properly
	Tires	8 Vehicle specifications
7 ' 7-1.	Wheels	8-1. Specifications  Maintenance data (fuel, oil level, etc.)
7-2.	If your vehicle has to be stopped in an emergency	9-1. For owners  Reporting safety defects for U.S. owners

## Index

#### For your information

#### Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Lexus policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of color and equipment.

# Noise from under vehicle after turning off the engine

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

# Accessories, spare parts and modification of your Lexus

A wide variety of non-genuine spare parts and accessories for Lexus vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance,

repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Lexus vehicle.

This vehicle should not be modified with non-genuine Lexus products. Modification with non-genuine Lexus products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

# Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Lexus Safety System+2.0
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Lexus dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

#### Vehicle data recording

The vehicle is equipped with sophisticated computers that will record certain data, such as:

The recorded data varies according to the vehicle grade level and options with which it is equipped.

These computers do not record conversations or sounds, and only record images outside of the vehicle in certain situations.

- Engine speed / Electric motor speed (traction motor speed)
- Accelerator status
- Brake status
- Vehicle speed
- Operation status of the driving assist systems, such as the ABS and pre-collision system
- Images from the front camera (available only when certain safety systems are activated, which varies depending on the vehicle specifications).
- Data Transmission

Your vehicle may transmit the data recorded in these computers to Lexus without notification to you.

#### Data usage

Lexus may use the data recorded in this computer to diagnose malfunctions, conduct research and development, and improve quality.

Lexus will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency

- For use by Lexus in a lawsuit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner
- Recorded image information can be erased by your Lexus dealer

The image recording function can be disabled. However, if the function is disabled, data from when the pre-collision system operates will not be available.

To learn more about the vehicle data collected, used and shared by Lexus, please visit

www.lexus.com/privacyvts/.

## Usage of data collected through Lexus Enform (U.S.mainland only)

If your Lexus has Lexus Enform and if you have subscribed to those services, please refer to the Lexus Enform Telematics Subscription Service Agreement for information on data collected and its usage.

To learn more about the vehicle data collected, used and shared by Lexus, please visit

www.lexus.com/privacyvts/.

### Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to

record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

#### • Disclosure of the EDR data

Lexus will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- · For use by Lexus in a lawsuit

However, if necessary, Lexus may:

- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

#### Scrapping of your Lexus

The SRS airbag and seat belt pretensioner devices in your Lexus contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners not deployed, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Lexus dealer before you scrap your vehicle.

## Perchlorate Material

Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.

Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries.



#### WARNING

#### General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

#### General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof or panoramic moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.


## Reading this manual

Explains symbols used in this manual


## Symbols in this manual

Symbols	Meanings
	WARNING:
	Explains something that, if not obeyed, could cause death or serious injury to people.
	NOTICE:
$\triangle$	Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.
	Indicates operating or
123	working procedures. Follow the steps in numerical order.

## Symbols in illustrations




Symbols	Meanings
<b>→</b>	Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
	Indicates the outcome of an operation (e.g. a lid opens).




Symbols	Meanings
<b>&gt;</b>	Indicates the component or position being explained.
0	Means Do not, Do not do this, or Do not let this happen.


## How to search

- Searching by name
- Alphabetical index:  $\rightarrow$  P.429





- Searching by installation position
- Pictorial index:  $\rightarrow$  P.12




- $\blacksquare$  Searching by symptom or sound
- What to do if... (Troubleshooting):
   →P.426



- Searching by title
- Table of contents:  $\rightarrow$  P.2

## Pictorial index


## **■**Exterior



Α	Doors	P.89
	Locking/unlocking	P.89
	Opening/closing the side windows	P.118
	Locking/unlocking by using the mechanical key	P.372
	Warning buzzer	P.92
В	Trunk	P.93
	Opening from inside the cabin	P.95
	Opening from outside	P.95
	Opening by using the mechanical key	P.372
	Warning buzzer	P.92
С	Outside rear view mirrors	P.115
	Adjusting the mirror angle	P.115
	Folding the mirrors	P.116
	Driving position memory*	P.108
	Defogging the mirrors	P.252
D	Windshield wipers	P.155

	Precautions against winter season	P.242
	To prevent freezing (windshield wiper de-icer)*	P.255
	Precautions against car wash	P.297
E	Fuel filler door	P.161
	Refueling method	P.161
	Fuel type/fuel tank capacity	P.383
F	Tires	P.316
	Tire size/inflation pressure	P.387
	Winter tires/tire chain	P.240
	Checking/rotation/tire pressure warning system	P.316
	Coping with flat tires	P.362
G	Hood	P.308
	Opening	P.308
	Engine oil	P.384
	Coping with overheating	P.377
	Warning messages	P.358
_	oulbs of the exterior lights for driving acing method: P.335, Watts: P.388)	
Н	Headlights/side marker lights/cornering lights Turn signal lights	
1	Parking lights/daytime running lights	P.150
J	Tail/stop lights	P.150
K	License plate lights	P.150
L	Back up lights	
	Shifting the shift lever to R	P.142
*: If equ	ipped	

## ■Instrument panel




Α	Engine switch	P.137
	Starting the engine/changing the mode	P.137,139
	Emergency stop of the engine	P.340
	When the engine will not start	P.369
	Warning messages	P.358
В	Shift lever	P.141
	Changing the shift position	P.142
	Precautions against towing	P.343
	When the shift lever does not move	P.142
С	Meters	P.64, 67
	Reading the meters/adjusting the instrument panel lights	P.64, 66, 67, 70
	Warning lights/indicator lights	P.60
	When the warning lights come on	P.348
D	Multi-information display	P.71
	Display	P.71
	When the warning messages are displayed	P 358

E	Parking brake switch	P.146
	Applying/releasing	P.146
	Precautions against winter season	P.241
	Warning buzzer/message	P.359
F	Turn signal lever Headlight switch	
	Headlights/parking lights/tail lights/daytime running lights	P.150
	Automatic High Beam	P.153
G	Windshield wiper and washer switch	P.155
	Usage	P.155
	Adding washer fluid	P.315
	Warning messages	P.359
Н	Emergency flasher switch	P.340
	Hood lock release lever	P.308
J	Tilt and telescopic steering control switch/tilt and telescopic release lever	
	Adjustment	P.113
	Driving position memory*1	P.108
K	Air conditioning system	P.251
	Usage	P.251
	Rear window defogger	P.252
L	Audio system*2	
M	Trunk opener main switch	P.99
lf eq	uipped	

 $<sup>^{\</sup>star 2}$ : Refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

## **■**Switches




	Camera		*1	2
I A	Camera	switch	ı ''	_

B Head-up display switch*1	P.78
C Instrument panel light control switches	P.66, 70
D Odometer/trip meter/trip meter reset button	P.65,70
E VSC OFF switch	P.237
F Driving Mode Select switch	P.202
G Trunk opener switch	P.95
H Fuel filler door opener switch	P.162


<sup>\*1:</sup> If equipped

 $<sup>^{\</sup>star 2}$ : Refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".



A	Driving position memory switches*	P.108
В	Outside rear view mirror switches	P.115
С	Door lock switches	P.91
D	Window lock switch	P.119
E	Power window switches	P.118

## \*: If equipped




Α	Meter control switches	P.72
В	Paddle shift switches	P.143

C TEL switch\*

D LTA (Lane Tracing Assist) switch	P.176
Vehicle-to-vehicle distance switch	P.192
F Cruise control switches	P.187
G Audio remote control switches*	
H Talk switch*	


\*: Refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".



A Seat ventilator switches*	P.258
B Seat heater switches*	P.258
C Heated steering wheel switch*	P.258
D Rear sunshade switch*	P.278
E Remote Touch	P.244
F Brake hold switch	P.148


 $<sup>\</sup>dot{}$ : If equipped

## **■**Interior



Α	SRS airbags	P.28
В	Floor mats	P.22
С	Front seats	P.107
D	Head restraints	P.111
E	Seat belts	P.24
F	Inside lock buttons	P.91
G	Console box	P.266
Н	Cup holder	P.266
I	Assist grips	P.278

## ■Ceiling



A Interior lights	P.263
B Personal lights	P.263
C Moon roof switches*	P.120
Panoramic moon roof switches*	P.123
D "SOS" button*	P.289
Door-linked interior light switch	P.263
F Vanity mirrors	P.269
G Sun visors	P.269
H Inside rear view mirror	P.114
Garage door opener buttons	P.281
*: If equipped	

## For safety and security

1-1.	For safe use
	Before driving22
	For safe driving23
	Seat belts <b>24</b>
	SRS airbags <b>28</b>
	Front passenger occupant classification system37
	Exhaust gas precautions41
1-2.	Child safety
	Riding with children42
	Child restraint systems42
1-3.	Theft deterrent system
	Engine immobilizer system 54
	Alarm 56


### **Before driving**

Observe the following before starting off in the vehicle to ensure safety of driving.


### Installing floor mats

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

1 Insert the retaining hooks (clips) into the floor mat eyelets.



2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.



Always align the  $\triangle$  marks  $oldsymbol{A}$  .

The shape of the retaining hooks (clips) may differ from that shown in the illustration.

## A

#### **WARNING**

Observe the following precautions. Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

#### ■ When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Lexus Genuine floor mats
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottomside up or upside-down.

#### ■Before driving

 Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.




 With the engine stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

#### For safe driving

For safe driving, adjust the seat and mirror to an appropriate position before driving.

### Correct driving posture



- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P.107)
- B Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P.107)
- C Lock the head restraint in place with the center of the head restraint closest to the top of your ears.

  (→P.111)
- $\bigcirc$  Wear the seat belt correctly.  $(\rightarrow P.25)$



#### WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving.
   Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback.
   A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats.

Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.

- Always observe the legal speed limit when driving on public roads.
- When driving over long distances, take regular breaks before you start to feel tired.

Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

#### Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.  $(\rightarrow P.25)$ 

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.  $(\rightarrow P.42)$ 

#### Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. ( $\rightarrow$ P.114, 115)

#### Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.



#### WARNING

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

#### Wearing a seat belt


- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Lexus recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

#### ■Pregnant women

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P.25)$ 

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



#### ■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P.25)$ 

- When children are in the vehicle
- $\rightarrow$ P.42

#### ■ Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.

#### **WARNING**

- Ensure that the belt and plate are locked and the belt is not twisted. If the seat belt does not function correctly, immediately contact your Lexus dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Lexus dealer. Inappropriate handling may lead to incorrect operation.

#### Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.


### ■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.  $(\rightarrow P.42)$
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage.  $(\rightarrow P.24)$

#### ■ Seat belt extender

If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Lexus dealer free of charge.





#### **WARNING**

#### Using a seat belt extender

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.




#### **NOTICE**

#### ■ When using a seat belt extender

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt. This helps prevent damage to the vehicle interior and the extender itself.

# Fastening and releasing the seat belt



- To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- 2 To release the seat belt, press the release button **A** .


#### ■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### ■ Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold a child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more.

# Adjusting the seat belt shoulder anchor height (front seats)



- Push the seat belt shoulder anchor down while pressing the release button A.
- Push the seat belt shoulder anchor up.

Move the height adjuster up and down as needed until you hear a click.



#### **WARNING**

#### Adjustable shoulder anchor


Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident.

# Seat belt pretensioners (front and outboard rear seats)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal or side collision or a vehicle rollover.

The pretensioners do not activate in the

event of a minor frontal impact, a minor side impact or a rear impact.



## Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.



#### WARNING

#### Seat belt pretensioners

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.


- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Lexus dealer.

### **SRS** airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.

### SRS airbag system

#### ■ Location of the SRS airbags



- ▶ SRS front airbags
- A SRS driver airbag/front passenger airbag

  Can help protect the head and chest of the driver and front passenger from impact with interior components
- B SRS knee airbags

  Can help provide driver and front passenger protection
- ▶ SRS side and curtain shield airbags
- © SRS front side airbags


  Can help protect the torso of the front seat occupants
- D SRS rear side airbags

  Can help protect the torso of occupants in the rear outer seats

#### **E** SRS curtain shield airbags

- · Can help protect primarily the head of occupants in the outer seats
- Can help prevent the occupants from being thrown from the vehicle in the event of vehicle rollover

### ■ SRS airbag system components



- A Front passenger occupant classification system (ECU and sensors)
- **B** Knee airbags
- C Front passenger airbag
- D Curtain shield airbags
- **E** Side impact sensors (front doors)
- F Seat belt pretensioners and force limiters
- **G** Side impact sensors (front)
- H Front side airbags
- Side impact sensors (rear)
- Rear side airbags
- **K** Driver airbag
- L SRS warning light
- M Driver's seat position sensor

- N Driver's seat belt buckle switch
- O Airbag sensor assembly
- P "AIR BAG ON" and "AIR BAG OFF" indicator lights
- Q Front passenger's seat belt buckle switch
- R Front impact sensors

Your vehicle is equipped with ADVANCED AIRBAGS designed based on the US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors etc. shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

#### ■ If the SRS airbags deploy (inflate)

- Slight abrasions, burns, bruising etc., may be sustained from SRS airbags, due to the extremely high speed deployment (inflation) by hot gases.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, parts of the front and rear pillars, and roof side rails may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- The interior lights will turn on automatically. (→P.262)
- The emergency flashers will turn on automatically. (→P.340)
- For Lexus Enform Safety Connect subscribers, if any of the following situations occur, the system is designed to send an emergency call to the response center, notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency ser-

- vices.( $\rightarrow$ P.289)
- An SRS airbag is deployed.
- A seat belt pretensioner is activated.
- The vehicle is involved in a severe rearend collision.

## SRS airbag deployment conditions (SRS front airbags)

- The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12 18 mph [20 30 km/h] frontal collision with a fixed wall that does not move or deform).
  - However, this threshold velocity will be considerably higher in the following situations:
- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle underrides, or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners and SRS knee airbags will activate.
- The SRS front airbags for the front passenger will not activate if there is no passenger sitting in the front passenger seat.
   However, the SRS front airbags for the front passenger may deploy if luggage is

put in the seat, even if the seat is unoccupied.


## SRS airbag deployment conditions (SRS side and curtain shield airbags)

- The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12 18 mph [20 30 km/h]).
- Both SRS curtain shield airbags may deploy in the event of a severe side collision.
- Both SRS curtain shield airbags will deploy in the event of vehicle rollover.
- Both SRS curtain shield airbags may also deploy in the event of a severe frontal collision.

#### Conditions under which the SRS airbags may deploy (inflate), other than a collision

The SRS front airbags and SRS curtain shield airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.

- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



The SRS curtain shield airbags may also deploy under the situations shown in the illustration.


- The angle of vehicle tip-up is marginal.
- The vehicle skids and hits a curb stone.



## ■ Types of collisions that may not deploy the SRS airbags (SRS front airbags)

The SRS front airbags do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



#### ■ Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.

- Collision from the front
- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it pitches end over end, or if it is involved in a low-speed side or low-speed frontal collision.

- Collision from the rear
- Pitching end over end




#### ■ When to contact your Lexus dealer


In the following cases, the vehicle will require inspection and/or repair. Contact your Lexus dealer as soon as possible.

- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident


that was not severe enough to cause the SRS front airbags to inflate.




A portion of a door or its surrounding area is damaged, deformed or has had a hole made in it, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate.



 The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



 The surface of the seats with the SRS side airbag is scratched, cracked, or otherwise damaged.



 The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the SRS curtain shield airbags inside is scratched, cracked, or otherwise damaged.



## A

#### WARNING

#### SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

 The driver and all passengers in the vehicle must wear their seat belts properly.
 The SRS airbags are supplemental

The SRS airbags are supplemental devices to be used with the seat belts.

- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration (NHTSA) advises: Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:
- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat.
   Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

## A


#### WARNING

• If the seat belt extender has been connected to the front seat belt buckles but the seat belt extender has not also been fastened to the latch plate of the seat belt, the SRS front airbags will judge that the driver and front passenger are wearing the seat belt even though the seat belt has not been connected. In this case, the SRS front airbags may not activate correctly in a collision, resulting in death or serious injury in the event of a collision. Be sure to wear the seat belt with the seat belt extender.




- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Lexus strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P.42)

 Do not sit on the edge of the seat or lean against the dashboard.



 Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.



- Do not allow the front seat occupants to hold items on their knees.
- Do not lean against the door, the roof side rail or the front, side and rear pillars.



 Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle.



# **WARNING**

 Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel. These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.



 Do not attach anything to areas such as a door, windshield, side window, front or rear pillar, roof side rail and assist grip.



- Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.
- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the SRS airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.

- Do not strike or apply significant levels of force to the area of the SRS airbag components or the front doors. Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillar garnishes are damaged or cracked, have them replaced by your Lexus dealer.
- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front airbags for the front passenger may not deploy in the event of a collision.
- Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Lexus dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars, roof side rails, front door panels, front door trims or front door speakers
- Modifications to the front door panel (such as making a hole in it)




#### **WARNING**

- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows, winches or roof luggage carrier
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios and CD players
- Modifications to your vehicle for a person with a physical disability

## Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the front passenger airbag, and front passenger knee airbag.

## System components



- A Driver's and front passenger's seat belt reminder light
- **B** SRS warning light
- ► For the U.S.A.
- C "AIR BAG ON" indicator light
- **D** "AIR BAG OFF" indicator light
- ▶ For Canada
- **E** "AIR BAG ON" indicator light
- F "AIR BAG OFF" indicator light

# A

#### WARNING

# Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.



#### WARNING

- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, and reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the SRS airbags for the front passenger will not activate, which could cause death or serious injury in the event of a collision.
- Do not apply a heavy load to the front passenger seat or equipment (e.g. seatback pocket).
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.
- Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated, which indicates that the SRS airbags for the front passenger will not activate in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.

- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P.44)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the front passenger occupant classification system. In this case, contact your Lexus dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.
- Do not place anything between the console box and front passenger seat. Otherwise, the system may not detect the front passenger properly, leading to improper operation of the airbags.
- Adjust the front passenger seat so that the head restraint does not touch the ceiling. If the head restraint is left in contact with the ceiling, the system may not detect the front passenger properly, leading to improper operation of the airbags.

# Condition and operation in the front passenger occupant classification system

# ■ Adult\*1

	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG ON"
Indicator/warning light	SRS warning light	Off
	Driver's and front passenger's seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	Activated
	Front passenger knee airbag	

# ■ Child\*4

Indicator/warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF" or "AIR BAG ON" <sup>*4</sup>
	SRS warning light	Off
	Driver's and front passenger's seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	Deactivated or acti-
	Front passenger knee airbag	vated <sup>*4</sup>

# $\blacksquare$ Child restraint system with infant $^{*5}$

Indicator/warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"*6
	SRS warning light	Off
	Driver's and front passenger's seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	Deactivated
	Front passenger knee airbag	Deactivated

# ■ Unoccupied

	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"
Indicator/warning light	SRS warning light	Off
	Driver's and front passenger's seat belt reminder light	
Devices	Front passenger airbag	- Deactivated
	Front passenger knee airbag	

# ■ There is a malfunction in the system

Indicator/warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"
	SRS warning light	
	Driver's and front passenger's seat belt reminder light	On
Devices	Front passenger airbag	- Deactivated
	Front passenger knee airbag	

<sup>\*1:</sup> The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may not recognize him/her as an adult depending on his/her physique and posture.

 $<sup>^{\</sup>star 2}$ : In the event the front passenger is wearing a seat belt.

 $<sup>^{*3}</sup>$ : In the event the front passenger does not wear a seat belt

<sup>\*4:</sup> For some children, child in seat, child in booster seat or child in convertible seat, the system may not recognize him/her as a child. Factors which may affect this can be the physique or posture.

<sup>\*5:</sup> Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P.44)

<sup>\*6:</sup> In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly.  $(\rightarrow P.42)$ 

## **Exhaust gas precautions**

Harmful substance to the human body is included in exhaust gases if inhaled.



#### WARNING

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

#### Important points while driving

- Keep the trunk lid closed.
- If you smell exhaust gases in the vehicle even when the trunk lid is closed, open the windows and have the vehicle inspected at your Lexus dealer as soon as possible.

#### ■ When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine running for a long time.
   If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.

#### Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Lexus dealer.

## Riding with children

Observe the following precautions when children are in the vehicle. Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch, etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.  $(\rightarrow P.92, 119)$
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, trunk, seats etc.

#### WARNING

#### ■ When children are in the vehicle

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof (if equipped), panoramic moon roof (if equipped), or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

## **Child restraint systems**

Before installing a child restraint system in the vehicle, there are precautions that need to be observed. different types of child restraint systems, as well as installation methods, etc., written in this manual.

Use a child restraint system when riding with a small child that cannot properly use a seat belt. For the child's safety, install the child restraint system to a rear seat. Be sure to follow the installation method that is in the operation manual enclosed with the restraint system.

#### Table of contents

Points to remember: P.42

Child restraint system: P.43

When using a child restraint system: P.44

Child restraint system installation method

- Fixed with a seat belt: P.46
- Fixed with a child restraint LATCH anchor: P.49
- Using an anchor bracket (for top tether strap): P.51

# Points to remember

The laws of all 50 states of the U.S.A. as well as Canada now require the use of child restraint systems.

 Prioritize and observe the warnings, as well as the laws and regulations for child restraint systems.

- Use a child restraint system until the child becomes large enough to properly wear the vehicle's seat belt.
- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.

# A

#### WARNING

#### ■ When a child is riding

Observe the following precautions. Failure to do so may result in death or serious injury.

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system which is correctly installed. For installation details, refer to the operation manual enclosed with the child restraint system. General installation instruction is provided in this manual.
- Lexus strongly urges the use of a proper child restraint system that conforms to the weight and size of the child, installed on the rear seat.
   According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.

- Holding a child in your or someone else's arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield or between the holder and the interior of the vehicle.
- Handling the child restraint system

If the child restraint system is not properly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving, or an accident.

- If the vehicle were to receive a strong impact from an accident, etc., it is possible that the child restraint system has damage that is not readily visible. In such cases, do not reuse the restraint system.
- Make sure you have complied with all installation instructions provided with the child restraint system manufacturer and that the system is properly secured.
- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk.

# Child restraint system

#### ■ Types of child restraint system installation methods

Confirm with the operation manual enclosed with the child restraint system about the installation of the child restraint system.

Installation method		Page
Seat belt attachment		P.46
Child restraint LATCH anchors attachment		P.49
Anchor brackets (for top tether strap) attachment		P.51

# When using a child restraint system

# When installing a child restraint system to a front passenger seat

For the safety of a child, install child restraint systems to a rear seats. When installing child restraint system to a front passenger seat is unavoidable, adjust the seat as follows and install the child restraint system.

- Move the front seat fully rearward.
- Adjust the seatback angle to the most upright position.

When installing a forward-facing child seat, if there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.

- Adjust the front of the seat cushion to the uppermost position.
- Adjust the seat height to the uppermost position.

- Adjust the lumbar support to the lowest position.
- Adjust the pelvic support\* to the lowest position.
- If the head restraint interferes with the child restraint system installation and the head restraint can be removed, remove the head restraint.
   Otherwise, put the head restraint in the upper most position.



\*: If equipped

# A

#### WARNING

#### ■ When using a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

• Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.

- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. When installing a forward-facing child restraint system on the front passenger seat, adjust the seatback angle to the most upright position, move the seat to the rearmost position, and raise the seat to the upper most position, even if the "AIR BAG OFF" indicator light is illuminated.



Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front or rear pillars, or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.



# A

#### WARNING

- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.
- Use child restraint system suitable to the age and size of the child and install it to the rear seat.
- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the righthand rear seat.



 Adjust the front passenger seat so that it does not interfere with the child restraint system.


# Child restraint system fixed with a seat belt

A child restraint system for a small child or baby must itself be properly restrained on the seat with the lap portion of the lap/shoulder belt.


 Installing child restraint system using a seat belt (child restraint lock function belt)

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.


- Rear-facing—Infant seat/convertible seat
- Place the child restraint system on the rear seat facing the rear of the vehicle.



2 Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



- After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.49)
- Forward-facing—Convertible seat
- 1 Adjust the seat

When using the front passenger seat: If installing the child restraint system to the front passenger seat is unavoidable, refer to P.44 for front passenger seat adjustment.


Place the child restraint system on the seat facing the front of the vehicle.



3 Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.



4 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



- 6 If the child restraint has a top tether strap, follow the child restraint manufacturer's operation manual regarding the installation, using the top tether strap to latch onto the top tether strap anchor. (→P.51)
- 7 After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.49)

#### ■ Booster seat

- 1 If installing the child restraint system to the front passenger seat is unavoidable, refer to P.44 for front passenger seat adjustment.
- 2 Place the child restraint system on the seat facing the front of the vehicle.

#### ▶ Booster type



▶ High back type



3 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as low as possible.  $(\rightarrow P.24)$ 




## Removing a child restraint system installed with a seat belt

Press the buckle release button and fully retract the seat belt.

When releasing the buckle, the child restraint system may spring up due to the rebound of the seat cushion. Release the buckle while holding down the child restraint system.

Since the seat belt automatically reels itself, slowly return it to the stowing position.



# A

#### **WARNING**

# When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.

- After securing a child restraint system, never adjust the seat.
- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.
- Follow all installation instructions provided by the child restraint system manufacturer.
- When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

#### ■ When installing a booster seat

To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child.  $(\rightarrow P.26)$ 

#### Do not use a seat belt extender


If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.

# Child restraint system fixed with a child restraint LATCH anchor

#### Child restraint LATCH anchors

LATCH anchors are provided for the outboard rear seat. (Marks displaying


the location of the anchors are attached to the seats.)



## ■ Installation with LATCH system


Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.

1 Remove the cover.



- ▶ Type A
- 2 Latch the hooks of the lower straps onto the LATCH anchors. For owners in Canada: The symbol on a child restraint sys-

tem indicates **A** the presence of a lower connector system.




- A Canada only
- ▶ Type B
- 2 Latch the buckles onto the LATCH anchors.

For owners in Canada:

The symbol on a child restraint sys-

tem indicates **A** the presence of a lower connector system.



# A Canada only

- 3 If the child restraint has a top tether strap, follow the child restraint manufacturer's operation manual regarding the installation, using the top tether strap to latch onto the top tether strap anchor. (→P.51)
- 4 After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.49)

#### Laws and regulations pertaining to anchors

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to SAE J1819.



#### **WARNING**

# ■ When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

- After securing a child restraint system, never adjust the seat.
- When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system.
- Follow all installation instructions provided by the child restraint system manufacturer.
- When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.


# Using an anchor bracket (for top tether strap)

Anchor brackets (for top tether strap)


Anchor brackets are provided for each rear seat.

Use anchor brackets when fixing the top tether strap.

▶ Outboard rear seats




- A Anchor brackets
- **B** Top tether strap
- ▶ Rear center seat



- A Anchor bracket
- **B** Top tether strap
- Fixing the top tether strap to the anchor bracket

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.


1 Remove the head restraint.




2 Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.  $(\rightarrow P.49)$ 

Outboard rear seats



- A Hook
- **B** Top tether strap
- ▶ Rear center seat



A Hook

# **B** Top tether strap

#### Laws and regulations pertaining to anchors

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to SAE J1819.



#### WARNING

# When installing a child restraint system

Observe the following precautions. Failure to do so may result in death or serious injury.

- Firmly attach the top tether strap and make sure that the belt is not twisted.
- Do not attach the top tether strap to anything other than the anchor bracket.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.



#### **NOTICE**

# Anchor brackets (for top tether strap)

When not in use, make certain to close the lid. If it remains open, the lid may be damaged.

## Engine immobilizer system

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

## Operating the system

The indicator light flashes after the engine switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to


- Certifications for the engine immobilizer system
- ▶ For vehicles sold in the U.S.A., Hawaii, Guam and Puerto Rico

FCC ID: NI4TMIMB-3

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ACCESSORY or IGNITION ON mode to indicate that the system has been canceled.



#### ■ System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

- Conditions that may cause the system to malfunction
- If the grip portion of the key is in contact with a metallic object
- If the key is in close proximity to or touching a key registered to the security system (key with a built-in transponder chip) of another vehicle

#### ► For vehicles sold in Canada

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : 1) l'appareil ne doit pas produire de brouillage; 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



#### **NOTICE**

#### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

## **Alarm**

The alarm uses light and sound to give an alert when an intrusion is detected.

The alarm is triggered in the following situations when the alarm is set:

- A locked door is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- A locked trunk is unlocked or opened in any way other than using the entry function or wireless remote control.
- The hood is opened.

# Setting/canceling/stopping the alarm system

Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:


- Nobody is in the vehicle.
- The windows and moon roof (if equipped) or panoramic moon roof (if equipped) are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

## ■ Setting

Close the doors, trunk and hood, and lock all the doors. The system will be

set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.



#### ■ Canceling or stopping

Do one of the following to deactivate or stop the alarm:

- Unlock the doors.
- Turn the engine switch to ACCES-SORY or IGNITION ON mode, or start the engine. (The alarm will be deactivated or stopped after a few seconds.)

#### ■ System maintenance


The vehicle has a maintenance-free type alarm system.

#### ■ Triggering of the alarm

The alarm may be triggered in the following situations:

(Stopping the alarm deactivates the alarm system.)


The trunk is unlocked using the mechanical key.



 A person inside the vehicle opens a door, the trunk or hood, or unlocks the vehicle using a door lock switch.



• The battery is recharged or replaced when the vehicle is locked. (→P.376)



#### ■ Alarm-operated door lock

In the following cases, depending on the situation, the door may automatically lock to prevent improper entry into the vehicle:

- When a person remaining in the vehicle unlocks the door and the alarm is activated.
- While the alarm is activated, a person remaining in the vehicle unlocks the door.
- When recharging or replacing the battery



#### **NOTICE**

# ■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

# Vehicle status information and indicators

2-1.	Instrument c	uster
	misti amicine	43.00


Warning lights and indicators. 60
Gauges and meters (except F SPORT models)64
Gauges and meters (F SPORT models)67
Multi-information display71
Head-up display <b>78</b>
Fuel consumption screen82

# Warning lights and indicators

The warning lights and indicators on the instrument cluster, center panel and outside rear view mirrors inform the driver of the status of the vehicle's various systems.

# Warning lights and indicators displayed on the instrument cluster

► Except F SPORT models



The image may differ from the actual condition.

▶ F SPORT models



The image may differ from the actual condition.

2

## Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.



Brake system warning light\* $^{1}$  ( $\rightarrow$ P.348)



Brake system warning light<sup>\*1</sup>  $(\rightarrow P.348)$ 



(Canada)

Brake system warning light<sup>\*1</sup> (→P.348)



High coolant temperature warning light \*2 (→P.348)



Charging system warning light  $^{*2}$  ( $\rightarrow$ P.349)



Low engine oil pressure warning light  $^{*2}$  ( $\rightarrow$ P.349)



Malfunction indicator lamp $^{*1}$  ( $\rightarrow$ P.349)



Malfunction indicator lamp $^{*1}$  ( $\rightarrow$ P.349)



SRS warning light  $^{\star 1}$  ( $\rightarrow$ P.349)



ABS warning light<sup>\*1</sup> ( $\rightarrow$ P.350)



ABS warning light\* $^{*1}$ ( $\rightarrow$ P.350)



Brake Override System warning light/Drive-Start Control warning light\*<sup>2</sup> (→P.350)



Electric power steering system warning light  $^{*1}(\rightarrow P.350)$ 



Electric power steering system warning light  $^{*1}(\rightarrow P.350)$ 



Low fuel level warning light  $(\rightarrow P.351)$ 



Driver's and front passenger's seat belt reminder light  $(\rightarrow P.351)$ 



Rear passengers' seat belt reminder lights ( $\rightarrow$ P.351)



Tire pressure warning light  $(\rightarrow P.352)$ 



LTA indicator ( $\rightarrow$ P.352)



Intuitive parking assist OFF indicator  $^{*1}$  (if equipped) ( $\rightarrow$ P.352)



(flashes)

RCTA OFF indicator  $^{*1}$  (if equipped) ( $\rightarrow$ P.353)



RCD OFF indicator (if equipped)  $(\rightarrow P.353)$ 



PKSB OFF indicator  $^{*1}$  (if equipped) ( $\rightarrow$ P.353)



PCS warning light  $^{*1}$  ( $\rightarrow$ P.354)



Slip indicator $^{*1}(\rightarrow P.354)$ 



Parking brake indicator (→P.354)



Parking brake indicator (→P.354)

(flashes) (Canada) HOLD

Brake hold operated indicator  $^{*1}$  ( $\rightarrow$ P.355)



Master warning light<sup>\*1</sup>  $(\rightarrow P.355)$ 

- \*1: These lights come on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will go off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or go off. Have the vehicle inspected by your Lexus dealer.
- \*2: This light illuminates on the multi-information display.



#### WARNING

# If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Lexus dealer immediately if this occurs.

#### Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator  $(\rightarrow P.145)$ 



Headlight indicator ( $\rightarrow$ P.150)



Tail light indicator ( $\rightarrow$ P.150)

Headlight high beam indicator  $(\rightarrow P.152)$ 



Automatic High Beam indicator (→P.153)



PCS warning light\* $^{1,2}$  ( $\rightarrow$ P.171)



Cruise control indicator  $(\rightarrow P.194)$ 



Dynamic radar cruise control indicator  $(\rightarrow P.187)$ 



Cruise control "SET" indicator  $(\rightarrow P.187)$ 



LTA indicator ( $\rightarrow$ P.181)



LTA indicator ( $\rightarrow$ P.181)



(orange)

LTA indicator ( $\rightarrow$ P.181)



(flashes)

BSM outside rear view mirror indicators  $^{*1,3}$  (if equipped)  $(\rightarrow P.197, 211)$ 



BSM indicator (if equipped) (→P.197)



Intuitive parking assist OFF indicator  $^{*1,2}$  (if equipped)  $(\rightarrow P.206)$ 



RCTA OFF indicator \*1,2 (if equipped) ( $\rightarrow$ P.212)



RCD OFF indicator  $^{*2}$  (if equipped) ( $\rightarrow$ P.215)



PKSB OFF indicator  $^{*1,2}$  (if equipped) ( $\rightarrow$ P.219)



Slip indicator  $^{*1}$  ( $\rightarrow$ P.237)



VSC OFF indicator  $^{*1,2}$  ( $\rightarrow$ P.237)



Smart access system with pushbutton start indicator  $(\rightarrow P.137)$ 



Parking brake indicator  $(\to P.146)$ 



Parking brake indicator  $(\to P.146)$ 



Brake hold standby indicator\*1  $(\to P.148)$ 



Brake hold operated indicator\*1  $(\to P.148)$ 



Eco Driving Indicator Light\*1  $(\rightarrow P.74)$ 



Low outside temperature indi $cator^{*4} (\rightarrow P.64, 67)$ 



Security indicator  $^{*5}$  ( $\rightarrow$  P.54, 56)



"AIR BAG ON/OFF" indica $tor^{*1, 5} (\to P.37)$ 



"AIR BAG ON/OFF" indica $tor^{*1,5} (\to P.37)$ 

(Canada)

- Drive mode indicators
- Except F SPORT models



Eco drive mode indicator  $(\to P.202)$ 



Sport mode indicator  $(\to P.202)$ 

#### ▶ F SPORT models



Custom mode indicator  $(\to P.202)$ 



Eco drive mode indicator  $(\to P.202)$ 



Sport S mode indicator  $(\to P.202)$ 




Sport S+ mode indicator (→P.202)

- \*1: These lights come on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will go off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or go off. Have the vehicle inspected by your Lexus dealer.
- \*2: This light comes on when the system is turned off.
- $^{*3}$ : This light illuminates on the outside rear view mirrors.
- \*4: When the outside temperature is approximately 37°F (3°C) or lower, this indicator will flash for approximately 10 seconds, then stay on.
- \*5: This light illuminates on the center panel.

# Gauges and meters (except F SPORT models)

# Meter display

#### ■ Locations of gauges and meters



The units of measure may differ depending on the intended destination of the vehicle.

#### A Multi-information display

Presents the driver with a variety of vehicle data  $(\rightarrow P.71)$ 

Displays warning messages if a malfunction occurs ( $\rightarrow$ P.358)

#### **B** Outside temperature

Displays the outside temperature within the range of  $-40^{\circ}F$  ( $-40^{\circ}C$ ) to  $122^{\circ}F$  ( $50^{\circ}C$ )

Low outside temperature indicator comes on when the ambient temperature is  $37^{\circ}F(3^{\circ}C)$  or lower

# C Tachometer

Displays the engine speed in revolutions per minute

When sport mode is selected for the driving mode, the periphery of the tachometer will change color and the scale of the tachometer will be emphasized.

D Speedometer

## E Clock

Time displayed is linked to the analog clock on the center panel.  $(\rightarrow P.269)$ 

**F** Engine coolant temperature gauge

Displays the engine coolant temperature

## **G** Fuel gauge

Displays the quantity of fuel remaining in the tank

2

- **H** Shift position and shift range  $(\rightarrow P.141)$
- $\square$  Odometer and trip meter display ( $\rightarrow$ P.65)

#### Outside temperature display

- In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:
- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)
- When "--" or "E" is displayed, the system may be malfunctioning. Take your vehicle to your Lexus dealer.
- Liquid crystal display
- $\rightarrow$ P.72

#### ■ Customization

The gauges and meters can be customized on of the multi-information display.  $(\rightarrow P.76)$ 



#### WARNING

#### The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.



#### NOTICE

- To prevent damage to the engine and its components
- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P.377)

# Odometer and trip meter display

- Display items
- Odometer

Displays the total distance the vehicle has been driven.

Trip meter A/trip meter B


Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

 Distance until next engine oil change

Displays the distance the vehicle can be driven until an oil change is necessary.

## Changing the display

Each time the "ODO TRIP" switch is pressed, the displayed item will be changed. When the trip meter is displayed, pressing and holding the switch will reset the trip meter.




# ■ Pop-up display

Distance until the next engine oil change will displayed when a warning message indicating that oil maintenance should be performed soon or is required is displayed.

# Changing the instrument panel light brightness

The brightness of the instrument panel lights can be adjusted.



- 1 Darker
- 2 Brighter
- Brightness of the meter lights (day mode and night mode)

The brightness of the meter lights can be adjusted individually.

In the following situations, the meters changes between day mode and night mode.

 Day mode: When the tail lights are off or when the tail lights are on but the surrounding area is bright

 Night mode: When the tail lights are on and the surrounding area is dark

2


# Gauges and meters (F SPORT models)

# Meter display

#### ■ Locations of gauges and meters

When the main meter is moved to the right, some of the meter displays and the gauge layout will change.  $(\rightarrow P.71)$ 

▶ Main meter in center position



The units of measure may differ depending on the intended destination of the vehicle.

- $\blacksquare$  Odometer and trip meter display ( $\rightarrow$ P.70)
- **B** Engine coolant temperature gauge

Displays the engine coolant temperature

## C Outside temperature

Displays the outside temperature within the range of -40°F (-40°C) to 122°F (50°C)

Low outside temperature indicator comes on when the ambient temperature is  $37^{\circ}F(3^{\circ}C)$  or lower

## **D** Tachometer

Displays the engine speed in revolutions per minute

When sport mode is selected for the driving mode, the periphery of the tachometer will change color and the scale of the tachometer will be emphasized.

- Rev indicator  $(\rightarrow P.69)$
- Rev peak (→P.69)
- **E** Speedometer
- **F** Shift position/shift range/gear position ( $\rightarrow$ P.141)

#### G Clock

Time displayed is linked to the analog clock on the center panel.  $(\rightarrow P.269)$ 

## **H** Fuel gauge


Displays the quantity of fuel remaining in the tank

#### Multi-information display

Presents the driver with a variety of vehicle data  $(\rightarrow P.71)$ 

Displays warning messages if a malfunction occurs ( $\rightarrow$ P.358)

▶ Main meter moved to the right



The units of measure may differ depending on the intended destination of the vehicle.

## A Outside temperature

Displays the outside temperature within the range of -40°F (-40°C) to 122°F (50°C)

Low outside temperature indicator comes on when the ambient temperature is  $37^{\circ}F(3^{\circ}C)$  or lower

#### **B** Clock

Time displayed is linked to the analog clock on the center panel.  $(\rightarrow P.269)$ 

## **C** Tachometer

Displays the engine speed in revolutions per minute

When sport mode is selected for the driving mode, the periphery of the tachometer will change color and the scale of the tachometer will be emphasized.

- Rev indicator  $(\rightarrow P.69)$
- Rev peak  $(\rightarrow P.69)$
- **D** Speedometer
- **E** Shift position and shift range  $(\rightarrow P.141)$
- $\mathbf{F}$  Odometer and trip meter display ( $\rightarrow$ P.70)

#### **G** Fuel gauge

Displays the quantity of fuel remaining in the tank

H Engine coolant temperature gauge

Displays the engine coolant temperature

Multi-information display

Presents the driver with a variety of vehicle data ( $\rightarrow$ P.71) Displays warning messages if a malfunction occurs ( $\rightarrow$ P.358)

#### ■ Revindicator

When the engine speed reaches a set speed or the red zone, a ring-shaped indicator (A) will be displayed on the tachometer.

The indicators will be displayed in amber when the engine speed reaches a set speed, and in red when the engine speed reaches the red zone.


The engine speed at which the rev indicator will begin to be displayed can be set on

of the multi-information display.  $(\rightarrow P.76)$ 



#### ■ Rev peak

When the engine speed reaches or exceeds 5000 rpm, an afterimage of the tachometer will be displayed at the highest engine speed for approximately 1 second.



#### Outside temperature display

- In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:
- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)
- When "--" or "E" is displayed, the system may be malfunctioning. Take your vehicle to your Lexus dealer.

## ■ Liquid crystal display

→P.72

#### ■ Customization

The gauges and meters can be customized on of the multi-information display.

 $(\rightarrow \overline{P.76})$ 



#### WARNING

#### The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.



#### **NOTICE**

- To prevent damage to the engine and its components
- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P.377)

# Odometer and trip meter display

- Display items
- Odometer

Displays the total distance the vehicle has been driven.

• Trip meter A/trip meter B

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.


• Distance until next engine oil

#### change

Displays the distance the vehicle can be driven until an oil change is necessary.

# ■ Changing the display

Each time the "ODO TRIP" switch is pressed, the displayed item will be changed. When the trip meter is displayed, pressing and holding the switch will reset the trip meter.




#### ■ Pop-up display

The distance until the next engine oil change will displayed when a warning message indicating that oil maintenance should be performed soon or is required is displayed.

# Changing the instrument panel light brightness

The brightness of the instrument panel lights can be adjusted.



- 1 Darker
- 2 Brighter

#### Brightness of the meter lights (day mode and night mode)

The brightness of the meter lights can be adjusted individually.

In the following situations, the meters changes between day mode and night mode.

- Day mode: When the tail lights are off or when the tail lights are on but the surrounding area is bright
- Night mode: When the tail lights are on and the surrounding area is dark

# Changing the main meter location

The display can be switched between the center and side positions.



## Multi-information display

## Display and menu icons

## ■ Display (except F SPORT models)

By selecting menu icons on the multiinformation display, a variety of drivingrelated information can be displayed. The multi-information display can also be used to change display settings and other vehicle settings.

Warning or suggestion/advice pop-up displays are also displayed in certain situations.



## ■ Display (F SPORT models)

▶ Main meter in center position

The multi-information display presents the driver with a variety of drivingrelated information.


Warning or suggestion/advice pop-up displays are also displayed in certain situations.



Main meter moved to the right

By selecting menu icons on the multiinformation display, a variety of drivingrelated information can be displayed. The multi-information display can also be used to change display settings and other vehicle settings.

Warning or suggestion/advice pop-up displays are also displayed in certain situations.



#### ■ Menu icons

The menu icons will be displayed by pressing or of the meter control switches.

F SPORT models: The menu icons can be displayed when the main meter is moved to the right.



Driving information display  $(\rightarrow P.73)$ 



Navigation system-linked display (if equipped)  $(\rightarrow P.75)$ 



Audio system-linked display  $(\rightarrow P.75)$ 



Driving support system information display  $(\rightarrow P.76)$ 



Warning message display  $(\rightarrow P.358)$ 



Settings display  $(\rightarrow P.76)$ 

#### Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.



#### WARNING


## Caution for use while driving

- When operating the multi-information display while driving, pay extra attention to the safety of the area around the vehicle.
- Do not look continuously at the multiinformation display while driving as you may fail to see pedestrians, objects on the road, etc. ahead of the vehicle.
- The information display at low temperatures

→P.65, 70

## Changing the meter display

The multi-information display is operated using the meter control switches.



- A / >: Select menu icons

  A / Y: Change displayed content, scroll up/down the screen and move the cursor up/down
- B Press: Enter/Set
  Press and hold: Reset
- Move the main meter\* and return to the previous screen
- \*: F SPORT models

## Content of driving information

Display items (except F SPORT models)

Press or of the meter control switches and select . Then press or to display the following items:

- Drive information 1
- Drive information 2
- Eco Driving Indicator
- Tire pressure ( $\rightarrow$ P.319)
- Display off
- Display items (F SPORT models)
- ► Main meter in center position

Press or of the meter control switches to display the following items:

- Drive information 1
- Drive information 2
- Gear position
- Tire pressure ( $\rightarrow$ P.319)
- Units
- Display off

▶ Main meter moved to the right

Press < or > of the meter control switches and select . Then press ^ or > to display the following items:

- Drive information 1
- Drive information 2
- Eco Driving Indicator
- G-force
- Gear Position
- Tire pressure ( $\rightarrow$ P.319)
- Display off
- Drive information 1/Drive information 2

Displays drive information such as the following:

Use the displayed values as a reference only.

- Drive information 1
- · Current fuel consumption
- Average fuel economy (after reset)
- Drive information 2
- Distance (driving range)
- Average vehicle speed (after reset)
   Displayed items (listed below) can be changed on <a>P.76</a>)
- Current fuel consumption

Bar type: Displays instantaneous current fuel consumption

Average fuel economy

After reset: Displays average fuel consumption since the display was reset \*1

After start: Displays average fuel consumption since engine start

After refuel: Displays average fuel consumption since refuel

#### Average vehicle speed

After reset: Displays average vehicle speed since the display was reset \*1

After start: Displays average vehicle speed since engine start

## Elapsed time

After reset: Displays elapsed time since the display was reset \*1

After start: Displays elapsed time since engine start

#### Distance

Driving range: Displays driving range with remaining fuel $^{*2,3}$ 

After start: Displays the distance driven since engine start


#### Other

Blank: No item

- \*1: To reset, display the desired item and press and hold "OK" of the meter control switches.
- \*2: This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- \*3: When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

## ■ Eco Driving Indicator



## A Eco Driving Indicator Light

During Eco-friendly acceleration (Eco driving), the Eco Driving Indicator Light will turn on. When the acceleration exceeds the Zone of Eco driving, or when the vehicle is stopped, the light turns off.

**B** Eco Driving Indicator Zone Display Suggests the Zone of Eco driving with current Eco driving ratio based on acceleration.

© Eco driving ratio based on acceleration

If the acceleration exceeds the Zone of Eco driving, the right side of the Eco Driving Indicator Zone Display will illuminate. At this time, the Eco Driving Indicator Light will turn off.

D Zone of Eco driving


## ■ Boost gauge

Displays the boost pressure. The display will change color if the specified pressure is exceeded.

This display is intended for use as a guideline. Depending on factors such as the road surface condition, temperature and vehicle speed, the display may not show the actual condition of the vehicle.

## ■ G-force (F SPORT models)

Displays lateral G-forces on the vehicle.



- A Acceleration G-force on the vehicle
- B Current G-force value (analyzed value of front/rear and left/right G-forces)
- Record of the maximum G-forces

This display is intended for use as a guideline. Depending on factors such as the road surface condition, temperature and vehicle speed, the display may not show the actual condition of the vehicle.

Resetting the record of maximum
 G-forces

Press and hold "OK" of the meter control switches to reset the record.

Peak hold function

If lateral G-forces of 0.5 G or greater are generated, the G-force value display will turn amber and be held for 2 seconds.

## ■ Gear Position (F SPORT models)

Displays the current shift range or gear position when the shift lever is in D or S.

## ■ Units (F SPORT models)

The units of measure used can be changed while driving.

Unlike the units setting performed on the settings display, the units setting performed on the drive information display can be changed while driving.

#### ■ Eco Driving Indicator

Eco Driving Indicator will not operate under the following conditions:

- The shift lever is in any position other than D.
- A paddle shift switch is operated.
- The driving mode is set to other than normal mode or eco drive mode.
- The vehicle speed is approximately 80 mph (130 km/h) or higher.

## Navigation system-linked display (if equipped)

Select to display the following navigation system-linked information.

- Route guidance to destination
- Compass display (heading-up display)

## ■ Route guidance to destination display

When the route guidance to destination display is enabled on the head-up display, it will not be displayed on the multi-information display. (→P.79)

## Audio system-linked display

Select to enable selection of an audio source or track on the meter using the meter control switches.

# Driving support system information display

Select to display the operational status of the following systems:

- LTA (Lane Tracing Assist)  $(\rightarrow P.176)$
- Dynamic radar cruise control with full-speed range (→P.187)
- RSA (Road Sign Assist) (if equipped) (→P.185)

## Settings display

- Meter display settings that can be changed
- Language

Select to change the language displayed.

Units

Select to change the units of measure displayed.

 Speedometer display (except F SPORT models)

Select to set the display of the speedometer to digital/analog/both digital and analog.

Drive information 1/Drive information 2

Select to select up to 2 items ( $\rightarrow$ P.73) that will be displayed on each Drive information screen (Drive information 1 screen and Drive information 2 screen) respectively.

Clock

Select to switch between 12-hour display and 24-hour display.

Pop-up display

Select to enable/disable pop-up displays for each relevant system.

Accent color

Select to change the accent color on the screen, such as the cursor color.

- Rev indicator (F SPORT models)
- Select to enable/disable the rev indicator.
- Select to set the engine speed at which the rev indicator (amber) will begin to be displayed.
- Rev peak (F SPORT models)

Select to enable/disable the rev peak.

Eco Driving Indicator Light

Select to enable/disable the Eco Driving Indicator Light.

Default setting

Select to reset the meter display settings to the default setting.

 Vehicle functions and settings that can be changed

→P.400

- Suspension of the settings display
- Some settings cannot be changed while driving. When changing settings, park the vehicle in a safe place.
- If a warning message is displayed, operation of the settings display will be suspended.

## $\mathbf{A}$

#### WARNING

### Cautions during setting up the display

As the engine needs to be running during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

2



#### **NOTICE**

#### During setting up the display

To prevent battery discharge, ensure that the engine is running while setting up the display features.

## Suggestion function

Displays suggestions to the driver in the following situations. To select a response to a displayed suggestion, use the meter control switches.

## Suggestion to turn off the headlights

If the headlights are left on for a certain amount of time with the headlight

switch in AUTO after the engine switch has been turned off, a suggestion message will be displayed asking if you wish to turn the headlights off.

To turn the headlights off, select "Yes".

If a front door is opened after the engine switch is turned off, this suggestion message will not be displayed.

#### ■ Customization


Some functions can be customized.  $(\rightarrow P.400)$ 

## Head-up display

## \*: If equipped

The head-up display projects a variety of driving-related information and the operating state of the driving support systems on the windshield.

## System components



Illustrations used in this text are intended as examples, and may differ from the image that is actually displayed by the head-up display.

 $\blacksquare$  Driving support system display area ( $\rightarrow$ P.80)

Navigation system-linked display area (if equipped)

Displays the following items which are linked to the navigation system:

- Route guidance to destination
- Street name
- Compass (heading-up display)
- **B** Driving information display area

Displays the following items:

- Speed limit of the current road (linked to the navigation system) (U.S.A. only)
- RSA (Road Sign Assist) display (if equipped)  $(\rightarrow P.185)$
- Speedometer
- Shift position and shift range  $(\rightarrow P.141)$

2

- $\boxed{\mathbf{c}}$  Tachometer/Eco Driving Indicator display area ( $\rightarrow$ P.81)
- **D** Head-up display switch

## ■ Head-up display will operate when

The engine switch is in IGNITION ON mode.

#### ■ When using the head-up display

The head-up display may seem dark or hard to see when viewed through sunglasses, especially polarized sunglasses. Adjust the brightness of the head-up display or remove your sunglasses.

### ■ Street name display

Only street names which are included in the map data will be displayed.



#### WARNING

### ■ When using the head-up display

- Check that the position and brightness of the head-up display image does not interfere with safe driving. Incorrect adjustment of the image's position or brightness may obstruct the driver's view and lead to an accident, resulting in death or serious injury.
- Do not continuously look at the headup display while driving as you may fail to see pedestrians, objects on the road, etc. ahead of the vehicle.



#### NOTICE

## Head-up display projector

 Do not place any drinks near the headup display projector. If the projector gets wet, electrical malfunctions may result.




- Do not place anything on or put stickers onto the head-up display projector.
   Doing so could interrupt head-up display indications.
- Do not touch the inside of the head-up display projector or thrust sharp edges or the like into the projector.
   Doing so could cause mechanical malfunctions

## Using the head-up display

Enabling/disabling the head-up display

Press the Head-up display switch.



# Changing settings of the head-up display

The following settings can be changed on  $\bigcirc$  of the multi-information display.  $(\rightarrow P.400)$ 

 Brightness and vertical position of the head-up display

Select to adjust the brightness or vertical position of the head-up display.

• Tachometer/Eco Driving Indicator

Select to display the tachometer, Eco Driving Indicator or no content.

Display content

Select to enable/disable the following items:

- Route guidance to destination/street name
- Driving support system display
- Compass (heading-up display)
- Audio system operation status
- \*: Make sure to enable this display when using the driving support systems
- Display angle

Select to adjust the angle of the head-up display.

## ■ Enabling/disabling of the head-up display

If the head-up display is disabled, it will remain disabled when the engine switch is turned off then back to IGNITION ON mode.

#### ■ Display brightness

The brightness of the head-up display can be adjusted on of the multi-information display. Also, it is automatically adjusted according to the ambient brightness.

#### Head-up display automatic position adjustment

If the display position is recorded into memory, the head-up display will be automatically adjusted to the desired position.  $(\rightarrow P.108)$ 

## ■ When the battery is disconnected

The customize settings of the head-up display will be reset.

## A

#### WARNING

#### Caution for changing settings of the head-up display

As the engine needs to be running while changing the settings of the head-up display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



#### NOTICE

## ■ When changing the settings of the head-up display

To prevent battery discharge, ensure that the engine is running while the changing the settings of the head-up display.

# Driving support system display area

Displays the operational status of the following systems:

- LTA (Lane Tracing Assist) (→P.176)
- Dynamic radar cruise control with full-speed range (→P.187)

Details of content displayed on the headup display may differ from that displayed on the multi-information display. For details, refer to the explanation of each system.

## Pop-up display

Pop-up displays for the following systems will be displayed when necessary.

## ■ Driving support systems

Displays a warning/suggestion/advice message or the operating state of a rel-

2

- PCS (Pre-Collision System)(→P.169)
- Intuitive parking assist (if equipped)
   (→P.205)
- Parking Support Brake function (static objects) (if equipped) (→P.224)
- Brake Override System ( $\rightarrow$ P.128)
- Drive-Start Control ( $\rightarrow$ P.129)

Details of content displayed on the headup display may differ from that displayed on the multi-information display. For details, refer to the explanation of each system.

## ■ **A**/(i) icons

These icons are linked to the multiinformation display

## A: Master warning icon

Displayed when a warning message is displayed on the multi-information display. (\$\rightarrow\$P.358)

## ①: Information icon

Displayed when a suggestion pop-up display ( $\rightarrow$ P.77) or advice pop-up display is displayed on the multi-information display.

## ■ Warning message

Some warning messages are displayed when necessary, according to certain conditions.

Details of content displayed on the headup display may differ from that displayed on the multi-information display.

## Audio system operation status

Displayed when an audio remote control switch on the steering wheel is

operated.

### ■ Hands-free system status

Displayed when the hands-free system is operated.

#### ■ When a pop-up display is displayed


When a pop-up display is displayed, a current display may no longer be displayed. In this case, the display will return after the pop-up display disappears.

# Tachometer/Eco Driving Indicator display area

### ■ Tachometer

Displays the engine speed in revolutions per minute.

## ■ Eco Driving Indicator



- A Eco Driving Indicator Zone Display
- **B** Eco driving ratio based on acceleration

## C Zone of Eco driving


Displayed content is the same as that displayed on the multi-information display (Eco Driving Indicator). For details, refer to P.74.

## **Fuel consumption screen**

You can view the status of your fuel consumption information on the multi-information display and Center Display.

12.3-inch display model: The consumption screen can be displayed on the side display.

## System components



- Multi-information display
- **B** Center Display
- C Meter control switches
- **D** "MENU" button
- **E** Touchpad


## Consumption

Press the "MENU" button on the

Remote Touch, then select ① on the screen, and then select "Trip Information" or "History".

## ■ Trip information

If a screen other than "Trip Information" is displayed, select "Trip Information".




- A Resetting the consumption data
- **B** Fuel consumption in the past 15 minutes
- C Current fuel consumption
- **D** Average vehicle speed since the engine was started.
- **E** Elapsed time since the engine was started.
- **F** Cruising range

Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to IGNITION ON mode. Use the displayed average fuel consumption as a reference. The image is an example only, and may

## ■ History

If a screen other than "History" is displayed, select "History".

vary slightly from actual conditions.



- A Best recorded fuel consumption
- **B** Latest fuel consumption
- C Previous fuel consumption record
- **D** Resetting the history data
- **E** Updating the latest fuel consumption data

The average fuel consumption history is divided by color into past averages and the average fuel consumption since the last updated. Use the displayed average fuel consumption as a reference.

The image is an example only, and may vary slightly from actual conditions.

## ■ Updating the history data

Update the latest fuel consumption by selecting "Clip" to measure the current fuel consumption again.

## ■ Resetting the data

The fuel consumption data can be deleted by selecting "Clear".

## ■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption.

As a result, the actual distance that can be driven may differ from that displayed.

# Using the side display (12.3-inch display model)

Display the vehicle information on the side display ( $\rightarrow$ P.247), and then select or to display the desired

or to display the desired screen.

## ■ Trip information (type A)

Displays the average fuel consumption for the past 10 minutes in 1 minute intervals, as well as the cruising range.




The image is an example only, and may vary slightly from actual conditions.

Use the displayed average fuel consumption as a reference.

## ■ Trip information (type B)

Displays the cruising range, latest fuel consumption and the amount of time elapsed since the engine was started.



The image is an example only, and may vary slightly from actual conditions.

Use the displayed average fuel consumption as a reference.

## ■ History

Displays the average fuel consumption and highest fuel consumption.



The image is an example only, and may vary slightly from actual conditions.

Use the displayed average fuel consumption as a reference.


## Before driving

3-1.	Key information
	Keys86
3-2.	Opening, closing and locking the doors and trunk
	Doors89
	Trunk93
	Smart access system with push- button start100
3-3.	Adjusting the seats
	Front seats107
	Driving position memory108
	Head restraints111
3-4.	Adjusting the steering wheel and mirrors
	Steering wheel113
	Inside rear view mirror114
	Outside rear view mirrors 115
3-5.	Opening and closing the windows and moon roof
	Power windows118
	Moon roof120
	Panoramic moon roof123

## Keys

## Key types

The following keys are provided with the vehicle.



## A Electronic keys

- Operating the smart access system with push-button start (→P.100)
- Operating the wireless remote control function
- **B** Mechanical keys
- C Key number plate

#### ■ When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

## ■ Electronic key battery depletion

- ullet The standard battery life is 1 to 2 years.
- If the battery becomes low, an alarm will sound in the cabin when the engine is stopped.
- Battery-saving mode can reduce the power consumption of electronic keys that are not used for long periods of time. (→P.101)

- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P.330)
- The smart access system with push-button start or the wireless remote control does not operate.
- The detection area becomes smaller.
- The LED indicator on the key surface does not turn on.

You can replace the battery by yourself  $(\rightarrow P.330)$ . However, as there is a danger that the electronic key may be damaged, it is recommended that replacement be carried out by your Lexus dealer.

- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field:
- TVs
- · Personal computers
- Cellular phones, cordless phones and battery chargers
- Recharging cellular phones or cordless phones
- Table lamps
- Induction cookers

#### ■ Replacing the battery

→ P.330

#### Confirmation of the registered key number

The number of keys already registered to the vehicle can be confirmed. Ask your Lexus dealer for details.

#### If "A New Key has been Registered Contact Your Dealer for Details" is shown on the multi-information display

This message will be displayed each time the driver's door is opened when the doors are unlocked from the outside for approximately 10 days after a new electronic key has been registered.

If this message is displayed but you have not had a new electronic key registered, ask your Lexus dealer to check if an unknown electronic key (other than those in your possession) has been registered.



#### **NOTICE**

#### To prevent key damage


- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers.
- Do not place the keys near medical electrical equipment such as low-frequency therapy equipment or microwave therapy equipment, and do not receive medical attention with the keys on your person.
- Carrying the electronic key on your person

Carry the electronic key 3.9 in. (10 cm) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 3.9 in. (10 cm) of the electronic key may interfere with the key, causing the key to not function properly.

- In case of a smart access system with push-button start malfunction or other key-related problems
- $\rightarrow P.372$
- When an electronic key is lost
- →P.371

## Wireless remote control

The electronic keys are equipped with the following wireless remote control:



- $\blacktriangle$  Locks the doors ( $\rightarrow$ P.89)
- **B** Unlocks the doors  $(\rightarrow P.89)$
- C Opens the windows and moon roof (if equipped) or panoramic moon roof (if equipped) $^*$  ( $\rightarrow$ P.89)
- $\bigcirc$  Opens the trunk ( $\rightarrow$ P.95)
- **E** Sounds the alarm  $(\rightarrow P.87)$
- \*: This setting must be customized at your Lexus dealer.

## ■ Theft deterrent panic mode

When (() is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.




## Using the mechanical key

To take out the mechanical key, push the release button and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key.  $(\rightarrow P.372)$ 



#### When required to leave the vehicle's key with a parking attendant

Turn the trunk opener main switch off  $(\rightarrow P.99)$ , lock the glove box  $(\rightarrow P.266)$  and armrest door  $(\rightarrow P.279)$  as circumstances demand.

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

## ■ If you lose your mechanical keys


→P.371

#### **Doors**

# Unlocking and locking the doors from the outside

### Smart access system with pushbutton start

Carry the electronic key to enable this function.



1 Grip the driver's door handle to unlock the door. Holding the driver's door handle for approximately 2 seconds unlocks all the doors. Grip the passenger's door handle to unlock all the doors.\*


Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.

- \*: The door unlock settings can be changed.
- 2 Touch the lock sensor (the indentation on the upper part of the door handle) to lock all the doors.

Check that the door is securely locked.

#### ■ Wireless remote control



Locks all the doors

Check that the door is securely locked.

2 Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Press and hold to open the windows and moon roof (if equipped) or panoramic moon roof (if equipped).\*

\*: This setting must be customized at your Lexus dealer.

## ■ Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1 Turn the engine switch off.
- When the indicator light on the key surface is not on, press and hold

or (() for approximately 5 seconds while pressing and holding



The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step **2**.)

Multi-information display/Beep	Unlocking function
	Holding the driver's door handle unlocks only the driver's door.
Exterior: Beeps 3 times Interior: Pings once	Holding a passenger's door handle unlocks all the doors.
Exterior: Beeps twice Interior: Pings once	Holding a door handle unlocks all the doors.

To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds

after is pressed, the doors will be locked again and the alarm will automatically be set.)

In a case that the alarm is triggered, immediately stop the alarm.  $(\rightarrow P.56)$ 

## ■ Impact detection door lock release system

In the event that the vehicle is subject to a strong impact, all the doors are unlocked. Depending on the force of the impact or the type of accident, however, the system may not operate.

## ■ Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: once; Unlocked: twice)

Windows and moon roof (if equipped) or panoramic moon roof (if equipped): A buzzer sounds to indicate that the windows and moon roof or panoramic moon roof are opening.


#### ■ Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again. (However, depending on the location of the electronic key, the key may be detected as being in the vehicle. In this case, vehicle may be unlocked.)

#### When the doors cannot be locked by the lock sensor on the upper part of the door handle

When the doors cannot be locked even if the lock sensor on the surface of the door handle is touched by a finger, touch the lock sensor with the palm.

If you are wearing gloves, remove them.



#### Open door warning buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door to stop the buzzer, and lock the vehicle once more.

## ■ Setting the alarm

Locking the doors will set the alarm system.  $(\rightarrow P.56)$ 

- Conditions affecting the operation of the smart access system with push-button start or wireless remote control
- →P.101
- If the smart access system with pushbutton start or the wireless remote control does not operate properly

trol does not operate properly
Use the mechanical key to lock and unlock

the doors.  $(\rightarrow P.372)$ Replace the key battery with a new one if it is depleted.  $(\rightarrow P.330)$ 

## If the battery is discharged

The doors cannot be locked and unlocked using the smart access system with push-

button start or wireless remote control. Lock or unlock the doors using the mechanical key. (\$\ightarrow\$P.372)

#### ■ Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features: →P.400)



#### WARNING

#### ■ To prevent an accident

Observe the following precautions while driving the vehicle.

Failure to do so may result in a door opening and an occupant being thrown out of the vehicle, resulting in death or serious injury.


- Ensure that all doors are properly closed and locked.
- Do not pull the inside handle of the doors while driving.
   Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position.
- Set the rear door child-protector locks when children are seated in the rear seats.

## ■ When opening or closing a door

Check the surroundings of the vehicle such as whether the vehicle is on an incline, whether there is enough space for a door to open and whether a strong wind is blowing. When opening or closing the door, hold the door handle tightly to prepare for any unpredictable movement.


# Unlocking and locking the doors from the inside

■ Door lock switches (to lock/unlock)



- Locks all the doors
- 2 Unlocks all the doors
- Inside lock buttons (to lock)

Push down the inside lock button to lock the door.



- Inside door handles (to unlock)
- ► For the front doors


Pull the handle to unlock and open the door.

When the door is unlocked, the inside lock button will pop up.

► For the rear doors

Pull the handle to unlock the door. Pull the handle a second time to open the door.

When the door is unlocked, the inside lock button will pop up.



#### Locking the front doors from the outside without a key

- 1 Push down the inside lock button.
- 2 Close the door.


The door cannot be locked if the engine switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle. However, the key may not be detected correctly and the door may be locked.

#### Open door warning buzzer

The hood, one or all of the doors, or trunk is not fully closed. If the vehicle reaches a speed of 3 mph (5 km/h), the master warning light flashes and a buzzer sounds to indicate that the door(s) are not fully closed. Make sure to close hood, all doors and trunk.

## Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.



#### 2 Lock

These locks can be set to prevent children from opening the rear doors.

Push down on each rear door switch to lock both rear doors.

# Automatic door locking and unlocking systems

The following functions can be set or canceled:

For instructions on customizing, refer to P.400.

Function	Operation			
Speed linked door locking function	All doors are automatically locked when vehicle speed is approximately 12 mph (20 km/h) or higher.			
Shift position linked door lock- ing function	All doors are automatically locked when the shift lever is shifted to a position other than P.			
Shift position linked door unlocking func- tion	All doors are automatically unlocked when the shift lever is shifted to P.			
Driver's door linked door unlocking func- tion	All doors are automatically unlocked when driver's door is opened within approximately 45 seconds after turning the engine switch off.			

The trunk can be opened using the trunk opener switch, entry function or wireless remote control.

If the vehicle is equipped with a power trunk lid, the trunk can be closed using the trunk closer.



#### WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

#### ■ Before driving

- Make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving and hit near-by objects or luggage in the trunk may be thrown out, causing an accident.
- Do not allow children to play in the trunk.
   If a child is accidentally locked in the trunk, they could suffer from heat exhaustion, suffocation or other injuries.
- Do not allow a child to open or close the trunk lid.
   Doing so may cause the trunk lid to open unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

## Important points while driving

Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.


## Using the trunk

Observe the following precautions. Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to suddenly shut again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.
- Vehicles without power trunk lid: The trunk lid may suddenly shut if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.



 When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.



## A

#### WARNING

- Vehicles without power trunk lid: When closing the trunk lid, make sure to press it lightly on its outer surface. If the trunk grip is used to fully close the trunk lid, it may result in hands or arms being caught.
- Do not attach any accessories other than genuine Lexus parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to suddenly shut again after it is opened.
- Trunk easy closer (vehicles with power trunk lid)

In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position. It takes several seconds before the trunk easy closer begins to operate. Be careful not to catch fingers or anything else in the trunk lid, as this may cause bone fractures or other serious injuries.



## ■ Power trunk lid (if equipped)

Observe the following precautions when operating the power trunk lid.
Failure to do so may cause serious injury.

- Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.

- If the trunk closer switch is pressed while the trunk lid is opening during automatic operation, the trunk lid stops opening. Take extra care when on an incline, as the trunk lid may open or close suddenly.
- On an incline, the trunk lid may suddenly shut after it opens automatically. Make sure the trunk lid is fully open and secure before using the trunk.
- In the following situations, the power trunk lid may detect an abnormality and automatic operation may be stopped. In this case, the trunk lid has to be operated manually. Take extra care in this situation, as the stopped trunk lid may suddenly shut, causing an accident.
- When the trunk lid contacts an obstacle
- When the battery voltage suddenly drops, such as when the engine switch is turned to IGNITION ON mode or the engine is started during automatic operation
- Do not attach any accessories other than genuine Lexus parts to the trunk lid. The power trunk lid may not operate, causing itself to malfunction, or the trunk lid may suddenly shut again after it is opened.
- Hands Free Power Trunk Lid (vehicles with power trunk lid)

Observe the following precautions. Failure to do so may cause serious injury.

- Exhaust gases cause the exhaust pipes to become quite hot. When operating the Hands Free Power Trunk Lid, be careful not to touch the exhaust pipe.
- Do not operate the Hands Free Power Trunk Lid if there is little space under the rear bumper.
- Jam protection function (vehicles with power trunk lid)

Observe the following precautions. Failure to do so may cause serious injury.

## **WARNING**

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the trunk lid fully closes. Be careful not to catch fingers or anything else in the trunk lid.
- The jam protection function may not work depending on the shape of the object that is caught. Be careful not to catch fingers or anything else.



#### **NOTICE**

■ To prevent trunk easy closer malfunctions (vehicles with power trunk lid)


Do not apply force to the trunk lid while the trunk easy closer is operating.

- To prevent damage to the power trunk lid (vehicles with power trunk lid)
- Make sure that there is no luggage or snow on the trunk lid before operating the power trunk lid. In addition, make sure that there is no ice between the trunk lid and frame that prevents movement of the trunk lid. Operating the power trunk lid when excessive load is present on the trunk lid may cause a malfunction.
- Do not apply excessive force to the trunk lid while the power trunk lid is operating.

## Opening/closing the trunk

■ Trunk opener switch

Press the trunk opener switch.




■ Smart access system with pushbutton start

While carrying the electronic key, press the button.

When all the doors are unlocked using one of the following methods, the trunk can be opened without the electronic kev:

- Entry function
- Wireless remote control
- Door lock switches
- Automatic door unlocking system
- Mechanical key



■ Wireless remote control


Press and hold the switch.

A buzzer sounds.




## Hands Free Power Trunk Lid (vehicles with power trunk lid)

1 While carrying an electronic key, stand within the smart access system with push-button start operation range, approximately 11.8 to 19.7 in. (30 to 50 cm) from the rear bumper.



- A Hands Free Power Trunk Lid sensor
- **B** Hands Free Power Trunk Lid operation detection area
- © Smart access system with pushbutton start operation detection area (→P.100)
- 2 Perform a kick operation by moving your foot to within approximately 3.9 in. (10 cm) of the rear bumper and then pulling it back.
- Perform the entire kick operation within 1 second.
- · The trunk lid will not start operating

- while a foot is detected under the rear bumper.
- Operate the Hands Free Power Trunk Lid without contacting the rear bumper with your foot.
- If another electronic key is in the cabin or trunk, it may take slightly longer than normal for the operation to occur.



- A Hands Free Power Trunk Lid sensor
- **B** Hands Free Power Trunk Lid operation detection area
- When the sensor detects that your foot is pulled back, a buzzer will sound and the trunk will automatically fully open/close.

If a foot is moved under the rear bumper while the trunk lid is opening, the trunk lid will stop moving.


If a foot is moved under the rear bumper while the trunk lid is closing, the trunk lid will open.

## ■ Trunk closer switch (vehicles with power trunk lid)

Press the trunk closer switch.


A buzzer will sound and the trunk lid will fully close.

Pressing the switch while the trunk lid is closing opens the trunk lid again.



## ■ Trunk grip

Using the trunk grip, pull down the trunk lid without applying sideways force and push the trunk lid down from the outside to close it.



## ■ Trunk light

The trunk light turns on when the trunk is opened.

## ■ Trunk easy closer (vehicles with power trunk lid)

In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position.

- The trunk easy closer will operate regardless of the engine switch mode.
- If the trunk easy closer does not operate, open the trunk to the half open position or more and then close it.
- Function to prevent the trunk being locked with the electronic key inside
- When all doors are locked, closing the trunk lid with the electronic key left inside the trunk will sound an alarm.
   In this case, the trunk lid can be opened by pressing the trunk release button on

the trunk lid.

- If the spare electronic key is put in the trunk with all the doors locked, the key confinement prevention function is activated so the trunk can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
- If the electronic key is put in the trunk with all the doors locked, the key may not be detected depending on the location of the key and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the trunk is closed. Make sure to check where the key is before closing the trunk.
- The key confinement prevention function cannot be activated if any one of the doors is unlocked. In this case, open the trunk using the trunk opener.

## Overload protection function (vehicles with power trunk lid)

The trunk lid will not operate when excessive load is present on the top of the trunk lid.

## ■ Fall-down protection function (vehicles with power trunk lid)


While the trunk lid is opening automatically, applying excessive force to it will stop the opening operation to prevent the trunk lid from rapidly falling down.

#### Jam protection function (vehicles with power trunk lid)

While the trunk lid is closing automatically, the trunk lid will stop closing and open if something gets caught.

#### ■ Internal trunk release lever

The trunk lid can be opened by pulling the glow-in-the-dark lever located on the inside of the trunk to the side. The lever will continue to glow for some time after the trunk lid is closed.



#### ■ Using the mechanical key

The trunk can be also opened using the mechanical key. ( $\rightarrow$ P.372) If the trunk is unlocked using the mechanical key, the power trunk lid and trunk easy closer will not be operational. To return them to an operational state, fully close the trunk lid by hand.

■ If the smart access system with pushbutton start or the wireless remote control does not operate properly

Use the mechanical key to unlock the trunk.  $(\rightarrow P.372)$ 

Replace the key battery with a new one if it is depleted.  $(\rightarrow P.330)$ 

- Hands Free Power Trunk Lid operating conditions (vehicles with power trunk lid)
- When the Hands Free Power Trunk Lid (kick sensor) operation setting is turned on and the engine switch is turned off
- When an electronic key is carried within the operation range
- Situations in which the Hands Free Power Trunk Lid may not operate properly (vehicles with power trunk lid)

In the following situations, the Hands Free Power Trunk Lid may not operate properly:

- When a foot remains under the rear bumper
- If the rear bumper is strongly hit with a foot or is touched for a while If the rear bumper has been touched for a while, wait for a short time before attempting to operate the Hands Free Power Trunk Lid again.
- When operated while a person is too close to the rear bumper
- When an external radio wave source interferes with the communication

- between the electronic key and the vehicle  $(\rightarrow P.101)$
- When the vehicle is parked near an electrical noise source which affects the sensitivity of the Hands Free Power Trunk Lid, such as a pay parking spot, gas station, electrically heated road, or fluorescent light
- When the vehicle is near a TV tower, electric power plant, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When a large amount of water is applied to the rear bumper, such as when the vehicle is being washed or in heavy rain
- When mud, snow, ice, etc. is attached to the rear bumper
- When the vehicle has been parked for a while near objects that may move and contact the rear bumper, such as plants
- When an accessory is installed to the rear bumper
   If an accessory has been installed, turn the Hands Free Power Trunk Lid (kick sensor) operation setting off.
- Preventing unintentional operation of the Hands Free Power Trunk Lid (vehicles with power trunk lid)

When an electronic key is in the operation range, the Hands Free Power Trunk Lid may operate unintentionally, so be careful in the following situations.

- When a large amount of water is applied to the rear bumper, such as when the vehicle is being washed or in heavy rain
- When dirt is wiped off the rear bumper
- When a small animal or small object, such as a ball, moves under the rear bumper
- When an object is moved from under the rear bumper
- If someone is swinging their legs while sitting on the rear bumper
- If the legs or another part of someone's body contacts the rear bumper while passing by the vehicle
- When the vehicle is parked near an electrical noise source which affects the sen-

- sitivity of the Hands Free Power Trunk Lid, such as a pay parking spot, gas station, electrically heated road, or fluorescent light
- When the vehicle is near a TV tower, electric power plant, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the vehicle is parked in a place where objects such as plants are near the rear bumper
- If luggage, etc. is set near the rear bumper
- If accessories or a vehicle cover is installed/removed near the rear bumper
- When the vehicle is being towed

To prevent unintentional operation, turn the Hands Free Power Trunk Lid (kick sensor) operation setting off.


- Open door warning buzzer
- →P.92
- Customization

Some functions can be customized. (Customizable features:  $\rightarrow$  P.400)

## Protecting luggage against theft

The trunk opener switch can be temporarily disabled to protect luggage stored in the trunk against theft.

Turn the trunk opener main switch in the glove box off to disable the trunk opener.



- A On
- **B** Off

When the trunk opener main switch is off, the trunk lid cannot be opened even with the wireless remote control, entry function or Hands Free Power Trunk Lid.


- When leaving a key to the vehicle with a parking attendant
- →P.88

# Smart access system with push-button start

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. The driver should always carry the electronic key.


- Locks and unlocks the doors (→P.89)
- Opens the trunk ( $\rightarrow$ P.95)
- Starts the engine  $(\rightarrow P.137)$

#### ■ Antenna location



- Antennas outside the cabin
- **B** Antennas inside the cabin
- C Antenna inside the trunk
- **D** Antenna outside the trunk

## ■ Effective range (areas within which the electronic key is detected)



- Mhen locking or unlocking the doors
  The system can be operated when the
  electronic key is within about 2.3 ft. (0.7
  m) of an outside door handle. (Only the
  doors detecting the key can be operated.)
- B When opening the trunk
  The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of the trunk release button.
- When starting the engine or changing engine switch modes
  The system can be operated when the electronic key is inside the vehicle.

#### If an alarm sounds or a warning message is displayed

An alarm sounds and warning messages are displayed on the multi-information display to protect against unexpected accidents or theft of the vehicle resulting from erroneous operation. When a warning message is displayed, take appropriate measures based on the displayed message.

When only an alarm sounds, circumstances and correction procedures are as follows.

 When an exterior alarm sounds once for 5 seconds

Situation	Correction proce- dure
The trunk was closed while the electronic key was still inside the trunk and all the doors were locked.	Retrieve the electronic key from the trunk and close the trunk lid.
An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.

When an interior alarm sounds continuously

Situation	Correction proce- dure
The engine switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the engine switch was in ACCESSORY mode).	Turn the engine switch off and close the driver's door.
The engine switch was turned off while the driver's door was open.	Close the driver's door.

### If "Key Detected in Vehicle" is shown on the multi-information display

An attempt was made to lock the doors using the smart access system with pushbutton start while the electronic key was still inside the vehicle. Retrieve the electronic key from the vehicle and lock the doors again.

## ■ Battery-saving function

The battery-saving function will be acti-

vated in order to prevent the electronic key battery and the battery from being discharged while the vehicle is not in operation for a long time.

- In the following situations, the smart access system with push-button start may take some time to unlock the doors.
- The electronic key has been left within approximately 6 ft. (2 m) of the outside of the vehicle for 10 minutes or longer.
- The smart access system with push-button start has not been used for 5 days or longer.
- If the smart access system with push-button start has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or mechanical key, to unlock the doors.
- Turning an electronic key to batterysaving mode
- When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press twice while pressing and holding . Confirm that the electronic key indicator flashes 4 times. While the battery-saving mode is set, the

smart access system with push-button start cannot be used. To cancel the function, press any of the electronic key buttons.



Electronic keys that will not be used for long periods of time can be set to the battery-saving mode in advance.

## ■ Conditions affecting operation

The smart access system with push-button start uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart access system with push-button start, wireless remote control and engine immobilizer system from operating properly.

(Ways of coping:  $\rightarrow$ P.372)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the electronic key is in contact with, or is covered by the following metallic objects
- Cards to which aluminum foil is attached
- Cigarette boxes that have aluminum foil inside
- · Metallic wallets or bags
- Coins
- · Hand warmers made of metal
- · Media such as CDs and DVDs
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
- Portable radio, cellular phone, cordless phone or other wireless communication device
- Another electronic key or a wireless key that emits radio waves
- Personal computers or personal digital assistants (PDAs)
- Digital audio players
- Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window
- When the electronic key is placed near a battery charger or electronic devices
- When the vehicle is parked in a pay parking spot where radio waves are emitted.

## ■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
- · The electronic key is too close to the win-

- dow or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
- The electronic key is near the ground or in a high place, or too close to the center of the rear bumper when the trunk is opened.
- The electronic key is on the instrument panel, rear package tray or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the doors will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock or lock if a large amount of water splashes on the door handle, such as in the rain or in a car wash, when the electronic key is within the effective range. (The doors will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock sensor while wearing gloves may delay or prevent lock operation. Remove the gloves and touch the lock sensor again.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive

- times. After this, no recognition signals will be given.
- Unlocking the vehicle may take more time if another electronic key is within the effective range.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In this case, follow the following correction procedures to wash the vehicle:
- Place the electronic key in a location 6 ft. (2 m) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart access system with push-button start. (→P.101)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc.
  - Clean the lock sensor and attempt to operate it again.
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.

## ■ When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.
- The smart access system with push-button start can be deactivated in advance.
- Battery-saving mode can reduce the power consumption of electronic keys. (→P.101)

### ■ To operate the system properly

 Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

 Do not leave the electronic key inside the trunk.

The key confinement prevention function may not operate, depending on the location of the key (close to a spare tire, the inside edge of the trunk), conditions (inside a metal bag, close to metallic objects) and the radio waves in the surrounding area. (\$\rightarrow\$P.97)

#### ■ If an electronic key does not work properly

- Locking and unlocking the doors and opening the trunk: →P.372
- Starting the engine:  $\rightarrow$  P.373

#### ■ Customization

Settings (e. g. smart access system with push-button start) can be changed. (Customizable features: →P.400)

If the smart access system with push-button start has been deactivated in a customized setting, refer to the explanations for the following operations.

- Locking and unlocking the doors and opening the trunk:
   Use the wireless remote control or mechanical key. (→P.89, 95, 372)
- Starting the engine and changing engine switch modes: →P.373
- Stopping the engine:  $\rightarrow$  P.139

#### ■ Certification for the smart access system with push-button start

▶ For vehicles sold in the U.S.A., Hawaii, Guam and Puerto Rico

FCC ID: NI4TMLF15-1

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: HYQ23AAY FCC ID: HYQ14FBF

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

<For 14FBF>

The FCC ID/IC Certification number is affixed inside the equipment. You can find the ID/number when replacing the battery.

#### ► For vehicles sold in Canada

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : 1) l'appareil ne doit pas produire de brouillage; 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### NOTE:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

#### <For 14FBF>

The FCC ID/IC Certification number is affixed inside the equipment. You can find the ID/number when replacing the battery.

#### NOTE:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### <Pour 14FBF>

L'identification FCC/le numéro d'accréditation IC est apposé(e) à l'intérieur de l'appareil. Cette identification/ce numéro est visible au remplacement de la pile.



#### WARNING

- Caution regarding interference with electronic devices
- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should keep away from the smart access system with push-button start antennas.
   (¬P.100)

The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Lexus dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.


 Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.
 Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Lexus dealer for details on disabling the entry function.

#### Front seats

The seats can be adjusted (longitudinally, vertically, etc.). Adjust the seat to ensure the correct driving posture.

# Adjustment procedure



- A Seat position adjustment
- **B** Seatback angle adjustment
- C Seat cushion (front) angle adjustment
- D Vertical height adjustment
- **E** Lumbar support adjustment
- **F** Pelvic support adjustment (if equipped)
- **G** Seat cushion length adjustment (if equipped)

### ■ When adjusting the seat

- Make sure that no surrounding passengers or objects are in contact with the seat.
- Take care when adjusting the seat so that

the head restraint does not touch the ceiling.

#### ■ Power easy access system (if equipped)

The driver's seat and steering wheel move in accordance with engine switch mode and the driver's seat belt condition. (→P.108)

# $\mathbf{A}$

#### WARNING

#### ■ When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
  - Fingers or hands may become jammed in the seat mechanism.
- Make sure to leave enough space around the feet so they do not get stuck.

#### Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary. If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident. Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

# **Driving position memory**

# \*: If equipped

This feature automatically adjusts the positions of the driver's seat, steering wheel (power adjustment type), outside rear view mirrors and head-up display (if equipped) to make entering and exiting the vehicle easier or to suit your preferences.


Up to 3 different driving positions can be recorded.

Each electronic key can be registered to recall your preferred driving position.

# Power easy access system

When all of the following have been performed, the driver's seat and steering wheel are automatically adjusted to a position that allows the driver to enter and exit the vehicle easily.

- The shift lever has been shifted to P.
- The engine switch has been turned off.
- The driver's seat belt has been unfastened.



When any of the following has been performed, the driver's seat and steering wheel automatically return to their original positions.

- The engine switch has been turned to ACCESSORY mode or IGNI-TION ON mode.
- The driver's seat belt has been fastened

# Operation of the power easy access system

- When exiting the vehicle, the power easy access system may not operate if the seat is already in the rearmost or uppermost position or close to the rear seat.
- If the seat position is adjusted during power easy access system operation, the automatic operation will stop. (The seat will change to manual operation.)
- If the seat position is adjusted during or after the power easy access system operation when the driver is exiting the vehicle, the power easy access system will not operate when entering the vehicle.

#### ■ Customization


The seat movement amount settings of the power easy access system can be customized. (Customizable features: →P.400)

# Recording a driving position into memory

- 1 Check that the shift lever is in P.
- 2 Turn the engine switch to IGNI-TION ON mode.
- 3 Adjust the driver's seat, steering wheel, outside rear view mirrors and head-up display (if equipped) to the desired positions.
- **4** While pressing the "SET" button, or within 3 seconds after the "SET"

button is pressed, press button "1", "2" or "3" until the buzzer sounds.

If the selected button has already been preset, the previously recorded position will be overwritten.



# ■ Seat positions that can be memorized (→P.107)

The positions adjusted by the following procedure can be recorded:

- Seat position adjustment
- Seatback angle adjustment
- Seat cushion (front) angle adjustment
- Vertical height adjustment

# In order to correctly use the driving position memory function

If a seat position is already in the furthest possible position and the seat is operated in the same direction, the recorded position may be slightly different when it is recalled.



#### WARNING


#### ■ Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

### Recalling a driving position

- 1 Check that the shift lever is in P.
- 2 Turn the engine switch to IGNI-TION ON mode.

**3** Press one of the buttons for the driving position you want to recall until the buzzer sounds.



# ■ To stop the position recall operation part-way through

Perform any of the following:

- Press the "SET" button.
- Press button "1", "2" or "3".
- Operate any of the seat adjustment switches (only cancels seat position recall).
- Operate the tilt and telescopic steering control switch (only cancels steering wheel position recall).
- Operate the head-up display position adjustment switch (if equipped) (only cancels head-up display position recall).
- Operating the driving position memory after turning the engine switch off

Recorded seat positions can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again.

# Registering/canceling/recall a driving position to an electronic key (memory recall function)

### ■ Registering procedure

Record your driving position to button "1", "2" or "3" before performing the following:


Carry only the key you want to register,

and then close the driver's door.

If 2 or more keys are in the vehicle, the driving position cannot be recorded properly.

- 1 Check that the shift lever is in P.
- 2 Turn the engine switch to IGNI-TION ON mode.
- 3 Recall the driving position that you want to record.
- While pressing the recalled button, press and hold the door lock switch (either lock or unlock) until the buzzer sounds.

If the button could not be registered, the buzzer sounds continuously for approximately 3 seconds.



### ■ Cancelation procedure

1 Carry only the key you want to cancel and then close the driver's door.

If 2 or more keys are in the vehicle, the driving position cannot be canceled properly.

- 2 Turn the engine switch to IGNI-TION ON mode.
- 3 While pressing the "SET" button, press and hold the door lock switch (either lock or unlock) until the buzzer sounds twice

If the button could not be canceled, the buzzer sounds continuously for approxi-

mately 3 seconds.

#### ■ Recall procedure

Make sure that the doors are locked before recalling the driving position. Carry the electronic key that has been registered to the driving position, and then unlock and open the driver's door using the smart access system with push-button start or wireless remote control.

The driving position will move to the recorded position (not including the steering wheel and head-up display [if equipped]). However, the seat will move to a position slightly behind the recorded position in order to make entering the vehicle easier.

If the driving position is in a position that has already been recorded, the seat and outside rear view mirrors will not move.

2 Turn the engine switch to ACCES-SORY mode or IGNITION ON mode, or fasten a seat belt.

The seat, steering wheel and head-up display (if equipped) will move to the recorded position.

# Recalling the driving position using the memory recall function

- Different driving positions can be registered for each electronic key. Therefore, the driving position that is recalled may be different depending on the key being carried.
- If the a door other than the driver's door is unlocked with the smart access system with push-button start, the driving position cannot be recalled. In this case, press the driving position button which has been set.

#### ■ Customization

The unlock door settings of the memory recall function can be changed. (Customizable features: →P.400)

#### **Head restraints**

# Head restraints are provided for all seats.




#### **WARNING**

#### Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

### Vertical adjustment



1 Up

 $Pull\ the\ head\ restraints\ up.$ 


2 Down

Push the head restraint down while pressing the lock release button  $oldsymbol{A}$  .

# Adjusting the height of the head restraints

Make sure that the head restraints are

adjusted so that the center of the head restraint is closest to the top of your ears.



# Horizontal adjustment (if equipped)

The position of the head restraint can be adjusted forward in 4 stages.


If the head restraint is pulled forward from the foremost position, it will return to the rearmost position.



# Removing the head restraints

Pull the head restraint up while pressing the lock release button [A].

Front seats: If the head restraint touches the ceiling, making the removal difficult, change the seat height or angle. (→P.107)




# Installing the head restraints

Align the head restraint with the installation holes and push it down to the lock position.

Press and hold the lock release button


**A** when lowering the head restraint.



### Steering wheel


### Adjustment procedure

- Manual adjustment type
- Hold the steering wheel and pull the lever down.




Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



▶ Power adjustment type

Operating the switch moves the steering wheel in the following directions:



- **1** Up
  - 2 Down
- 3 Toward the driver
- 4 Away from the driver

# ■ The power adjustment type steering wheel can be adjusted when

The engine switch is in ACCESSORY or IGNITION ON mode.

Automatic adjustment of the steering position (power adjustment type)

A desired steering position can be entered to memory and recalled automatically by the driving position memory system. (\$\rightarrow\$P.108)

■ Power easy access system (if equipped)

The driver's seat and steering wheel move in accordance with engine switch mode and the driver's seat belt condition. (→P.108)

After adjusting the steering wheel (manual adjustment type)

Make sure that the steering wheel is securely locked.

The horn may not sound if the steering wheel is not securely locked.

■ Customization

The steering wheel movement can be changed. (Customizable features: →P.400)



#### WARNING

#### Caution while driving

Do not adjust the steering wheel while drivina.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

#### After adjusting the steering wheel (manual adjustment type)


Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury.

# Sounding the horn

Press on or close to the mark.





#### Inside rear view mirror

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

### Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



#### WARNING

### Caution while driving

Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.


# Anti-glare function

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.

Turn the automatic anti-glare function mode on/off

When the automatic anti-glare function is in ON mode, the indicator A illuminates. The function will set to ON mode each time the engine switch is turned to IGNI-TION ON mode.

Pressing the button turns the function to OFF mode. (The indicator **A** also turns off.)



#### ■ To prevent sensor error

To ensure that the sensors operate properly, do not touch or cover them.



#### **Outside rear view mirrors**

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.



#### WARNING

#### Important points while driving


Observe the following precautions while driving.

Failure to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.


# Adjustment procedure

1 To select a mirror to adjust, press the switch.



- A Left
- **B** Right

2 To adjust the mirror, press the switch.



- **A** Up
- **B** Right
- C Down
- **D** Left

#### ■ Mirror angle can be adjusted when

The engine switch is in ACCESSORY or IGNITION ON mode.

#### ■ Defogging the mirrors

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers.  $(\rightarrow P.252)$ 

#### ■ Auto anti-glare function

When the anti-glare inside rear view mirror is set to automatic mode, the outside rear view mirrors will activate in conjunction with the anti-glare inside rear view mirror to reduce reflected light. ( $\rightarrow$ P.114)

#### Automatic adjustment of the mirror angle (vehicles with driving position memory)

A desired mirror face angle can be entered to memory and recalled automatically by the driving position memory.  $(\rightarrow P.108)$ 

# A


#### WARNING

#### When the outside rear view mirror defoggers are operating

Do not touch the outside rear view mirror surfaces, as they can become very hot and burn you.

# Folding the mirrors

Push the mirror back in the direction of the vehicle's rear.



# A

#### **WARNING**

#### ■ When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

# Linked mirror function when reversing (vehicles with driving position memory)

When the mirror select switch is in the "L" or "R" position, the outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground.

To disable this function, move the mirror select switch to the neutral position (between "L" or "R").

# Adjusting the mirror angle when the vehicle is reversing

With the shift lever in R, adjust the mirror angle at a desired position. The adjusted angle will be memorized and the mirror will automatically tilt to the memorized angle whenever the shift lever is shifted to R from next time.

The memorized downward tilt position of the mirror is linked to the normal position (angle adjusted with the shift lever in other than R). Therefore, if the normal position is changed after adjustment, the tilt position will also change.

When the normal position is changed, readjust the angle in reversing.

#### Power windows

# Opening and closing the power windows

The power windows can be opened and closed by one-touch operation of the switches.



- 1 Closing
- 2 One-touch closing
- 3 Opening
- 4 One-touch opening

To stop the window partway, operate the switch in the opposite direction.

# ■ The power windows can be operated when

The engine switch is in IGNITION ON mode.

#### Operating the power windows after turning the engine off

The power windows can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once the driver's door is opened.

#### ■ Jam protection function

If an object becomes jammed between the window and the window frame while the window is closing, window movement is stopped and the window is opened slightly.

#### ■ Catch protection function

If an object becomes caught between the door and window while the window is opening, window movement is stopped.

# ■ When the window cannot be opened or closed

When the jam protection function or catch protection function operates unusually and the door window cannot be opened or closed, perform the following operations with the power window switch of that door.

- Stop the vehicle. With the engine switch in IGNITION ON mode, within 4 seconds of the jam protection function or catch protection function activating, continuously operate the power window switch in the one-touch closing direction or one-touch opening direction so that the door window can be opened and closed.
- If the door window cannot be opened and closed even when performing the above operations, perform the following procedure for function initialization.
- Turn the engine switch to IGNITION ON mode.
- Pull and hold the power window switch in the one-touch closing direction and completely close the door window.
- 3 Release the power window switch for a moment, resume pulling the switch in the one-touch closing direction, and hold it there for approximately 6 seconds or more.
- Press and hold the power window switch in the one-touch opening direction. After the door window is completely opened, continue holding the switch for an additional 1 second or more.
- 5 Release the power window switch for a moment, resume pushing the switch in the one-touch opening direction, and hold it there for approximately 4 seconds or more.
- 6 Pull and hold the power window switch in the one-touch closing direction again. After the door window is completely closed, continue holding the switch for a further 1 second or more.

If you release the switch while the window is moving, start again from the beginning. If the window reverses and cannot be fully closed or opened, have the vehicle inspected by your Lexus dealer.

#### ■ Door lock linked window operation

- The power windows can be opened and closed using the mechanical key.\* (→P.372)
- The power windows can be opened using the wireless remote control.  $(\rightarrow P.89)$
- \*: These settings must be customized at your Lexus dealer.

#### ■ Power windows open warning buzzer

The buzzer sounds and "Window Open" is shown on the multi-information display when the engine switch is turned off and the driver's door is opened with the power windows open.

#### ■ Customization

Settings (e.g. linked door lock operation) can be changed.
(Customizable features: →P.400)



#### WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

## Closing the windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (→P.119)
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.

- When using the wireless remote control or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also do not let a child operate window by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the power window.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets jammed just before the window is fully closed. Be careful not to get any part of your body jammed in the window.

#### ■ Catch protection function


- Never use any part of your body or clothing to intentionally activate the catch protection function.
- The catch protection function may not work if something gets caught just before the window is fully opened. Be careful not to get any part of your body or clothing caught in the window.

# Preventing accidental operation (window lock switch)

This function can be used to prevent children from accidentally opening or closing a passenger window.

Press the switch.

The indicator **A** will come on and the passenger windows will be locked.



# ■ The power windows can be operated when

The engine switch is in IGNITION ON mode.

#### ■ When the battery is disconnected

The window lock switch is disabled. If necessary, press the window lock switch after reconnecting the battery.


### Moon roof

# \*: If equipped

Use the overhead switches to open and close the moon roof and tilt it up and down.

# Operating the moon roof

# Opening and closing




# 1 Opens the moon roof\*

The moon roof stops slightly before the fully open position to reduce wind noise. Press the switch again to fully open the moon roof.

- 2 Closes the moon roof\*
- \*: Lightly press either way of the moon roof switch to stop the moon roof partway.

# ■ Tilting up and down



1 Tilts the moon roof up

- 2 Tilts the moon roof down
- \*: Lightly press either way of the moon roof switch to stop the moon roof partway.

#### ■ The moon roof can be operated when

The engine switch is in IGNITION ON mode.

#### Operating the moon roof after turning the engine off

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

#### ■ Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

#### Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

#### ■ Door lock linked moon roof operation

- The moon roof can be opened and closed using the mechanical key.\* (→P.372)
- The moon roof can be opened using the wireless remote control.\* (→P.89)
- \*: These settings must be customized at your Lexus dealer.

#### ■ When the moon roof does not close normally

Perform the following procedure:

- 1 Stop the vehicle.
- **2** Press and hold the "CLOSE" switch. $^*$

The moon roof will close, reopen and pause for approximately 10 seconds. Then it will close again and stop at the completely closed position.

3 Check to make sure that the moon roof is completely closed and then release the switch. \*: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

#### ■ If the moon roof does not move normally

If the moon roof does not open or close normally or the automatic opening function does not operate, perform the following initialization procedure.

- 1 Stop the vehicle.
- 2 Press and hold the "DOWN" switch.

The moon roof will stop at the tilt-up position. After that, it will open, close, tilt up, tilt down, and stop at the fully closed position.

- 3 Confirm that the moon roof has completely stopped and release the switch.
- \*: If you release the switch while the moon roof is moving, perform the procedure again from the beginning.

If, after performing the above procedures correctly, the moon roof still does not open or close normally or the automatic opening function does not operate, have the vehicle inspected by your Lexus dealer.

### ■ Moon roof open warning buzzer

A buzzer sounds and a message is shown on the multi-information display when the engine switch is turned off and the driver's door is opened with the moon roof open.

#### ■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features:→P.400)

# A

#### WARNING

Observe the following precautions. Failure to do so may cause death or serious injury.


### Opening the moon roof

 Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.

# A

#### WARNING

- Do not sit on top of the moon roof.
- Opening and closing the moon roof
- The driver is responsible for moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the moon roof is being operated.



- When using the wireless remote control or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof is fully closed. Also, the jam protection function is not designed to operate while the moon roof switch is being pressed. Take care so that your fingers, etc. do not get caught.


# Panoramic moon roof

 $^{\star}$ : If equipped

Use the overhead switches to operate the panoramic moon roof and electronic roof sunshade.

# Operating the panoramic moon roof

Opening and closing the electronic sunshade



1 Opens the electronic sunshade\*

Slide and hold the switch backward.

The electronic sunshade will fully open automatically.

2 Closes the electronic sunshade\*

Slide and hold the switch forward. The electronic sunshade will fully close automatically.

If the panoramic moon roof is not fully closed, it will close fully before the electronic roof sunshade closes.

\*: Quickly slide and release the switch in either direction to stop the electronic sunshade partway.

# ■ Tilting the panoramic moon roof up and down


Press the switch to tilt the panoramic moon roof up.\*

When the panoramic moon roof is tilted up, the electronic sunshade will open to the half-open position of the roof.

\*: Lightly press the switch again to stop the panoramic moon roof partway.

Press and hold the switch to tilt the panoramic moon roof down.

The panoramic moon roof can be tilted down only when it is in the tilt-up position.




 Opening and closing the panoramic moon roof

Opens the panoramic moon roof\*

Slide and hold the switch backward. The panoramic moon roof and electronic sunshade will open automatically.


The panoramic moon roof can be opened from the tilt-up position.

\*: Quickly slide and release the switch in either direction to stop the panoramic moon roof partway.



Closes the panoramic moon roof

The panoramic moon roof will fully close automatically.



#### ■ The panoramic moon roof can be operated when

The engine switch is in IGNITION ON mode.

#### Operating the panoramic moon roof after turning the engine off

The panoramic moon roof and electronic roof sunshade can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once the driver's door is opened.

#### Jam protection function

If an object is detected between the panoramic moon roof and the frame in the following situations, travel is stopped and the panoramic moon roof opens slightly:

- The panoramic moon roof is closing or tilting down.
- The electronic roof sunshade is closing.

#### Closing both the panoramic moon roof and electronic sunshade




Slide the switch forward.

The electronic sunshade will close to the half-open position and pause. The panoramic moon roof will then fully close. Then the electronic sunshade will fully close.

- Door lock linked panoramic moon roof operation
- The panoramic moon roof can be opened and closed using the mechanical  $\text{kev.}^* (\rightarrow P.372)$
- The panoramic moon roof can be opened using the wireless remote con $trol.^*(\rightarrow P.89)$
- : These settings must be customized at your Lexus dealer.
- When the panoramic moon roof or electronic sunshade does not close normally

Perform the following procedure:

- Stop the vehicle.
- Turn the engine switch to IGNITION ON mode.
- 3 Slide and hold the 📧 switch or



- 4 Check that the panoramic moon roof and electronic sunshade are fully closed and release the switch.
- : If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

If the panoramic moon roof or electronic roof sunshade does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

# Panoramic moon roof open warning buzzer

A buzzer sounds and a message is shown on the multi-information display when the engine switch is turned off and the driver's door is opened with the panoramic moon roof open.

#### ■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features:→P.400)



#### WARNING

Observe the following precautions. Failing to do so may cause death or serious injury.


- Opening and closing the electronic roof sunshade
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the electronic sunshade is being operated.
- Do not let a child operate the electronic sunshade. Closing the electronic roof sunshade on someone can cause death or serious injury.



- Opening the panoramic moon roof
- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the panoramic moon roof.

#### Opening and closing the panoramic moon roof

- The driver is responsible for panoramic moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the panoramic moon roof. It is possible for children and other passengers to have body parts caught in the panoramic moon roof.
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the panoramic moon roof is being operated.



• When using the wireless remote control or mechanical key and operating the panoramic moon roof, operate the panoramic moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the panoramic moon roof. Also, do not let a child operate panoramic moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the panoramic moon roof.

# A

#### WARNING

• When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the panoramic moon roof or electronic roof sunshade is fully closed. Also, the jam protection function is not designed to operate while the switch is being pressed. Take care so that your fingers, etc. do not get caught.

#### ■ To prevent burns or injuries

Do not touch the area between the underside of the panoramic moon roof and the electronic sunshade. Your hand may get caught and you could injure yourself. Also, if the vehicle is left in direct sunlight for a long time, the underside of the panoramic moon roof could become very hot and could cause burns.



#### NOTICE

# ■ To prevent damage to the panoramic moon roof

- Before opening the panoramic moon roof, make sure that there are no foreign objects, such as stones or ice, around the opening.
- Do not hit the surface or edge of the panoramic moon roof with hard objects.

#### After the vehicle has been washed or rained on

Before opening the panoramic moon roof, wipe any water off the panoramic moon roof. Otherwise, water may enter the cabin when the panoramic moon roof is opened.

4-1.	Before driving
	Driving the vehicle128
	Cargo and luggage133
	Vehicle load limits135
	Trailer towing135
	Dinghy towing136
4-2.	Driving procedures
	Engine (ignition) switch137
	Automatic transmission
	Turn signal lever145
	Parking brake146
	Brake Hold <b>148</b>
4-3.	Operating the lights and wipers
	Headlight switch150
	Automatic High Beam153
	Windshield wipers and washer
4-4.	
	Opening the fuel tank cap161
4-5.	Using the driving support systems
	Lexus Safety System+2.0163
	PCS (Pre-Collision System) 169
	LTA (Lane Tracing Assist)176
	RSA (Road Sign Assist)185
	Dynamic radar cruise control with full-speed range187
	BSM (Blind Spot Monitor)197
	Driving Mode Select switch . 202

	PKSA (Parking Support Alert)
	Intuitive parking assist205
	RCTA (Rear cross traffic alert) function211
	RCD (Rear Camera Detection) function215
	PKSB (Parking Support Brake)
	Parking Support Brake function (static objects)24
	Parking Support Brake function (rear-crossing vehicles) 229
	Parking Support Brake function (rear pedestrians)233
	Driving assist systems 236
4-6.	Driving tips
	Winter driving tips240

### **Driving the vehicle**

The following procedures should be observed to ensure safe driving:

# Driving procedure

#### ■ Starting the engine

 $\rightarrow$ P.137

#### ■ Driving

- 1 With the brake pedal depressed, shift the shift lever to D.  $(\rightarrow P.142)$
- 2 If the parking brake is in manual mode, release the parking brake.
  (→P.146)
- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

#### Stopping

- 1 With the shift lever in D, depress the brake pedal.
- 2 If necessary, set the parking brake.

If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or  $N. (\rightarrow P.142)$ 

### ■ Parking the vehicle

- With the shift lever in D, depress the brake pedal.
- 2 Set the parking brake (→P.146), and shift the shift lever to P (→P.142).
- **3** Press the engine switch to stop the engine.
- 4 Lock the door, making sure that you have the electronic key on your person.

If parking on a hill, block the wheels as needed.

### Starting off on a steep uphill

- Make sure that the parking brake is set with the brake pedal depressed, and then shift the shift lever to D.
- 2 Release the brake pedal and gently depress the accelerator pedal.
- 3 Release the parking brake.

#### ■ When starting off on a uphill

The hill-start assist control will activate.  $(\rightarrow P.236)$ 

#### ■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

#### ■ Engine speed while driving

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released
- When the brake pedal is firmly or quickly depressed

# Restraining the engine output (Brake Override System)

 When the accelerator and brake pedals are depressed at the same time, the engine output may be restrained.

- A warning message is displayed on the multi-information display while the system is operating. (→P.350)
- Restraining sudden start (Drive-Start Control)
- When the following unusual operation is performed, the engine output may be restrained.
- When the shift lever is shifted from R to D, D to R, N to R, P to D, or P to R (D includes S) with the accelerator pedal depressed, a warning message appears on the multi-information display. If a warning message is shown on the multiinformation display, read the message and follow the instructions.
- When the accelerator pedal is depressed too much while the vehicle is in reverse.
- While Drive-Start Control is being activated, your vehicle may have trouble escaping from the mud or fresh snow. In such case, deactivate TRAC (→P.237) to cancel Drive-Start Control so that the vehicle may become able to escape from the mud or fresh snow.

#### ■ Breaking in your new Lexus

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 186 miles (300 km): Avoid sudden stops.
- For the first 621 miles (1000 km):
- Do not drive at extremely high speeds.
- Avoid sudden acceleration.
- Do not drive continuously in low gears.
- Do not drive at a constant speed for extended periods.

# Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. (→P.383)



#### WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

#### ■ When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

#### When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
- Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
- When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
- Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
- Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.
- During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P.340

# A

#### WARNING

- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.
   Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (

  P.141)
- Do not adjust the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.
   Doing so may result in a loss of vehicle

Doing so may result in a loss of vehicle control.

- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.
- Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has highspeed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.
- When driving on slippery road surfaces
- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid, resulting in an accident.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

#### ■ When shifting the shift lever

 Do not let the vehicle roll backward while the shift lever is in a driving position or roll forward while the shift lever is in R.

Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.

- Do not shift the shift lever to P while the vehicle is moving.
   Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to a driving position while the vehicle is moving backward.
   Doing so can damage the transmission and may result in a loss of vehicle control.
- Shifting the shift lever to N while the vehicle is moving will disengage the engine from the transmission. Engine braking is not available when N is selected.
- Be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.
- If you hear a squealing or scraping noise (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Lexus dealer as soon as possible. Rotor damage may result if the pads are not replaced when needed. It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.



# **WARNING**

#### When the vehicle is stopped

- Do not race the engine. If the vehicle is in any gear other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.
- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

#### When the vehicle is parked

- Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun. Doing so may result in the following:
- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.

- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P, stop the engine and lock the vehicle. Do not leave the vehicle unattended while the engine is running. If the vehicle is parked with the shift lever in P but the parking brake is not set, the vehicle may start to move, possibly leading to an accident.
- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off. Doing so may cause burns.

#### When taking a nap in the vehicle

Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area. exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

#### When braking

When the brakes are wet, drive more cautiously.

Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehi-

# A

#### WARNING

- If the brake booster device does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- Do not pump the brake pedal if the engine stalls.
   Each push on the brake pedal uses up the reserve for the power-assisted brakes.
- The brake system consists of 2 or more individual hydraulic systems; if one of the systems fails, the other(s) will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately.

# $\Lambda$

#### NOTICE

#### ■ When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time while driving, as this may restrain the engine output.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

### Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
   Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

#### If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally.

Information on what to do in case of a flat tire  $(\rightarrow P.362)$ 

#### ■ When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Lexus dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, automatic transmission, etc.
- Lubricant condition for the bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

# ■ When parking the vehicle

Always set the parking brake, and shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

### Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load:

# A

#### WARNING

■ Things that must not be carried in the trunk

The following things may cause a fire if loaded in the trunk:

- Receptacles containing gasoline
- Aerosol cans
- Storage precautions

Observe the following precautions. Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the trunk whenever possible.
- Do not place cargo or luggage in or on the following locations.
- At the feet of the driver.
- On the front passenger or rear seats (when stacking items)
- On the package tray
- On the instrument panel
- On the dashboard
- · In front of the Center Display
- Secure all items in the occupant compartment.

# Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity)—(Total weight of occupants)

Steps for Determining Correct Load Limit —

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.

For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 - 750 (5 \times 150) = 650$  lbs.)

- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle. (→P.135)

Lexus does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.


# A

#### WARNING

#### Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

# Calculation formula for your vehicle



- A Cargo capacity
- **B** Total load capacity (vehicle capacity weight)  $(\rightarrow P.382)$

When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will be C lb. (kg) as follows:

$$B^{*2}$$
 lb. (kg) -  $A^{*1}$  lb. (kg) =  $C^{*3}$  lb. (kg)

\*1: A = Weight of people

\*2: B = Total load capacity

\*3: C = Available cargo and luggage load

In this condition, if 3 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows:

C lb. (kg) - 
$$D^{*4}$$
 lb. (kg) =  $E^{*5}$  lb. (kg)

\*4: D = Additional weight of people

\*5: E = Available cargo and luggage load

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

### **Vehicle load limits**

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

 Total load capacity (vehicle capacity weight): →P.382

Total load capacity means the combined weight of occupants, cargo and luggage.

 Seating capacity: 5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

Towing capacity

Lexus does not recommend towing a trailer with your vehicle.

Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

### ■ Total load capacity and seating capacity

These details are also described on the tire and loading information label.  $(\rightarrow P.325)$ 



#### WARNING

#### Overloading the vehicle

Do not overload the vehicle. It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

# **Trailer towing**

Lexus does not recommend towing a trailer with your vehicle. Lexus also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.



# **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.





#### **NOTICE**

■ To avoid serious damage to your vehicle

Do not tow your vehicle with the four wheels on the ground.

# **Engine (ignition) switch**

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.

### Starting the engine

 Press the parking brake switch to check that the parking brake is set. (→P.146)

Parking brake indicator will come on.

- **2** Check that the shift lever is in P.
- **3** Firmly depress the brake pedal.



and a message will be displayed on

the multi-information display.
If it is not displayed, the engine cannot be started.

4 Press the engine switch shortly and firmly.

When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal until the engine is completely started.

The engine can be started from any engine

switch mode.



#### ■ Engine switch illumination

According to the situation, the engine switch illumination operates as follows.

- When a door is opened, or the engine switch mode is changed from ACCES-SORY or IGNITION ON mode to off, the engine switch illumination slowly blinks.
- When depressing the brake pedal with carrying the electronic key on your person, the engine switch illumination rapidly blinks.
- When the engine switch is in ACCES-SORY or IGNITION ON mode, the engine switch illumination illuminates.

#### ■ If the engine does not start

- The engine immobilizer system may not have been deactivated. (→P.54)
   Contact your Lexus dealer.
- If a message related to start-up is shown on the multi-information display, read the message and follow the instructions.

#### ■ If the battery is discharged

The engine cannot be started using the smart access system with push-button start. Refer to P.374 to restart the engine.

#### ■ Electronic key battery depletion


→P.86

- Conditions affecting operation
- →P.101
- Notes for the entry function
- $\rightarrow$ P.102

#### ■ Steering lock function

- After turning the engine switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.
- When the steering lock cannot be released, "Push Engine Switch while Turning Steering Wheel in Either Direction" will be displayed on the multi-information display.

Check that the shift lever is set in P. Press the engine switch shortly and firmly while turning the steering wheel left and right.



- To prevent the steering lock motor from overheating, operation of the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from operating the engine switch. After about 10 seconds, the steering lock motor will resume functioning.
- If there is a malfunction in the smart access system with push-button start

If "Access System with Elec. Key Malfunction See Owner's Manual" is displayed on the multi-information display, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

- Electronic key battery
- $\rightarrow P.330$
- Operation of the engine switch
- If the switch is not pressed shortly and

- firmly, the engine switch mode may not change or the engine may not start.
- If attempting to restart the engine immediately after turning the engine switch off, the engine may not start in some cases.
  After turning the engine switch off, please wait a few seconds before restarting the engine.

#### ■ Customization

If the smart access system with push-button start has been deactivated in a customized setting, refer to P.400.



#### WARNING

#### ■ When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

#### ■ Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.



#### NOTICE

#### ■ When starting the engine

- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Lexus dealer immediately.
- Symptoms indicating a malfunction with the engine switch

If the engine switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Lexus dealer immediately.

### Stopping the engine

- 1 Stop the vehicle completely.
- 2 Set the parking brake (→P.146), and shift the shift lever to P (→P.142).
- 3 Press the engine switch.
- 4 Release the brake pedal and check that "ACCESSORY" or "IGNI-TION ON" is not shown on the meter.

# A


#### WARNING

#### Stopping the engine in an emergency

- If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession. (→P.340)
  - However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.
- If the engine switch is operated while the vehicle is running, a warning message will be shown on the multi-information display and a buzzer sounds.
- When restarting the engine after an emergency shutdown, press the engine switch.

# Changing engine switch modes

Modes can be changed by pressing the engine switch with the brake pedal released. (The mode changes each time the switch is pressed.)



1 Off\*

The emergency flashers can be used.

2 ACCESSORY mode

Some electrical components such as the audio system can be used.

"ACCESSORY" will be displayed on the meter.

3 IGNITION ON mode

All electrical components can be used. "IGNITION ON" will be displayed on the meter.

\*: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACCES-SORY mode, not to off.

# ■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than 20 minutes or IGNITION ON mode (the engine is not running) for more than an hour with the shift lever in P, the engine switch will automatically turn off. However, this function cannot entirely prevent the battery discharge. Do not leave the vehicle with the engine switch in ACCES-

SORY or IGNITION ON mode for long periods of time when the engine is not running.

# When stopping the engine with the shift lever in a position other than P

If the engine is stopped with the shift lever in a position other than P, the engine switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

- If the parking brake is in manual mode, set the parking brake. (→P.146)
- 2 Shift the shift lever to P.
- 3 Check that "Turn Power Off" is displayed on the multi-information display and then press the engine switch once.
- 4 Check that "Turn Power Off" on the multi-information display is turned off.



#### NOTICE

#### ■To prevent battery discharge

- Do not leave the engine switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.
- If "ACCESSORY" or "IGNITION ON" is displayed on the meter, the engine switch is not off.
   Exit the vehicle after turning the engine switch off.

Do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the engine switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCESSORY mode, battery discharge may occur.

#### **Automatic transmission**

Select the shift position depending on your purpose and situation.

# Shift position purpose and functions

Shift posi- tion	Objective or function
Р	Parking the vehicle/starting the engine
R	Reversing
N	Neutral
D	Normal driving*1
S	S mode driving $^{*2}$ ( $\rightarrow$ P.144)

- \*1: Shifting to the D position allows the system to select a gear suitable for the driving conditions. Setting the shift lever to the D position is recommended for normal driving. You can choose shift range suitable for your driving situation by operating the paddle shift switches.
- \*2: Selecting shift ranges using S mode restricts the upper limit of the possible gear ranges, controls engine braking force, and prevents unnecessary upshifting.
- When driving with dynamic radar cruise control with full-speed range activated

Even when performing the following actions with the intent of enabling engine braking, engine braking will not be activated because dynamic radar cruise control with full-speed range will not be canceled.

 While driving in the D position or S mode, downshifting to 7, 6, 5 or 4. (→P.187)

- When switching the driving mode to sport mode while driving in D position. (→P.202)
- Restraining sudden start (Drive-Start Control)
- $\rightarrow$ P.129
- AI-SHIFT

The AI-SHIFT automatically selects the suitable gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in D. (Shifting the shift lever to the S position or using the paddle shift cancels the function.)




#### WARNING

#### When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

# Shifting the shift lever





While the engine switch is in IGNITION ON mode and the brake pedal

depressed<sup>\*</sup>, shift the shift lever while pushing the shift release button on the shift knob.



Shift the shift lever while pushing the shift release button on the shift knob.



Shift the shift lever normally.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped and the brake pedal is depressed.

\*: For the vehicle be able to be shifted from P, the brake pedal must be depressed before the shift release button is pushed. If the shift release button is pushed first, the shift lock will not be released.

#### ■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in IGNITION

ON mode the brake pedal is depressed and the shift release button is pushed.

#### ■ If the shift lever cannot be shifted from P

First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted even


though the brake pedal is depressed and the shift release button is pushed, there may be a problem with the shift lock system. Have the vehicle inspected by your Lexus dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.

Releasing the shift lock:


- 1 If the parking brake is in manual mode, set the parking brake.  $(\rightarrow P.146)$
- 2 Turn the engine switch off.
- 3 Depress the brake pedal.
- 4 Press down and release the cup holder lid to open.
- 5 Pry the cover up with a flathead screw-driver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.



6 Press and hold the shift lock override button and then push the button on the shift knob.

The shift lever can be shifted while the button is pressed



# A

#### WARNING

#### To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal. If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.


# Selecting the driving mode

→P.202

# Selecting shift ranges in the D position

To drive using temporary shift range selection, operate the "-" paddle shift switch. The shift range can then be selected by operating the "-" and "+" paddle shift switches.

Changing the shift range allows restriction of the highest gear, preventing unnecessary upshifting and enabling the level of engine braking force to be selected.



- Upshifting
- 2 Downshifting

The selected shift range, from D1 to D8, will be displayed in the meter.

#### Automatic deactivation of shift range selection in the D position

Shift range selection in the D position will be deactivated in the following situations:


- The "+" paddle shift switch is held down for a period of time
- When the vehicle comes to a stop
- If the accelerator pedal is depressed for more than a certain period of time
- When the shift lever is shifted to a position other than D

#### Downshifting restriction warning buzzer

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switch is operated. (A buzzer will sound twice.)

# Selecting shift ranges in S mode

To enter S mode, shift the shift lever to S. Shift ranges can be selected by operating the shift lever or paddle shift switches, allowing you to drive in the gear of your choosing.



- 1 Upshifting
- 2 Downshifting

The initial shift range in S mode is set automatically to 4, 5 or 6 according to vehicle's speed. However, the initial shift range may be set to 3 if Al-SHIFT has operated while the shift lever was in the D position.  $(\rightarrow P.141)$ 

Meter display	Function
S2 - S8	A gear in the range between 1 and the selected gear is automatically cho- sen depending on vehicle speed and driving conditions
S1	Setting the gear at 1

A lower shift range will provide greater engine braking forces than a higher shift range.

#### ■S mode

- When the shift range is 7 or lower, holding the shift lever toward "+" sets the shift range to 8.
- To prevent the engine from over-revving, upshifting may automatically occur.
- To protect the automatic transmission, a function is adopted that automatically selects a higher shift range when the fluid temperature is high.

# ■ Downshifting restriction warning buzzer


To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switch is operated. (A buzzer will sound twice.)

#### If the S indicator does not come on or the D indicator is displayed even after shifting the shift lever to S

This may indicate a malfunction in the automatic transmission system. Have the vehicle inspected by your Lexus dealer immediately. (In this situation, the transmission will operate in the same manner as when the shift lever is in D.)

# Turn signal lever

# Operating instructions



- 1 Right turn
- 2 Lane change to the right (move the lever partway and release it)

The right hand signals will flash 3 times.

3 Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

4 Left turn

# ■ Turn signals can be operated when

The engine switch is in IGNITION ON mode.

#### If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

■ If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

# **Parking brake**


The parking brake can be set or released automatically or manually.

In automatic mode, the parking brake can be set or released automatically according to shift lever operation. Also, even in automatic mode, the parking brake can be set or released manually.

# Operating instructions

# ■ Using the manual mode

The parking brake can be set and released manually.



- A U.S.A.
- **B** Canada
- 1 Push the switch to set the parking brake

The parking brake indicator light will turn on.


Press and hold the parking brake switch if an emergency occurs and it is necessary to operate the parking brake while driving.

- Pull the switch to release the parking brake
- Operate the parking brake switch while depressing the brake pedal.
- Using the parking brake automatic release function, the parking brake can be released by depressing the accelerator pedal. When using this function, slowly depress the accelerator pedal.

Make sure that the parking brake indicator light turn off.

#### ■ Turning the automatic mode on

While the vehicle is stopped, press and hold the parking brake switch until a message is shown on the multi-information display




When the automatic mode is turned on, the parking brake operates as follows.

- When the shift lever is shifted from P, the parking brake will be released, and the parking brake indicator light will turn off.
- When the shift lever is shifted to P, the parking brake will be set, and the parking brake indicator light will turn on.

Operate the shift lever with the vehicle stopped and the brake pedal depressed.

#### ■ Turning the automatic mode off

While the vehicle is stopped, pull and hold the parking brake switch until a message is shown on the multi-information display



#### ■ Parking brake operation

- When the engine switch is not in IGNI-TION ON mode, the parking brake cannot be released using the parking brake switch.
- When the engine switch is not in IGNI-TION ON mode, automatic mode (automatic brake setting and releasing) is not available.

# ■ Parking brake automatic release function

- When the shift lever is shifted from P, the parking brake will be released in automatic mode.
- When all of the following conditions are met in manual mode, the parking brake can be released by depressing the accelerator pedal.
- · The driver's door is closed
- · The driver is wearing the seat belt
- The shift lever is in D. S or R

#### If "Parking Brake Temporarily Unavailable" is displayed on the multi-information display

If the parking brake is operated repeatedly over a short period of time, the system may restrict operation to prevent overheating. If this happens, refrain from operating the parking brake. Normal operation will return after about 1 minute.

#### ■ If "Parking Brake Unavailable" or "EPB Unavailable" is displayed on the multiinformation display

Operate the parking brake switch. If the message does not disappear after operating the switch several times, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

#### ■ Parking brake operation sound

When the parking brake operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

#### ■ Parking brake indicator light

- Depending on the engine switch mode, the parking brake indicator light will turn on and stay on as described below: IGNITION ON mode: Comes on until the parking brake is released. Not in IGNITION ON mode: Stays on for approximately 15 seconds.
- When the engine switch is turned off with the parking brake set, the parking brake indicator light will stay on for about 15 seconds. This does not indicate a malfunction.

#### ■ When the parking brake switch malfunctions

Automatic mode (automatic brake setting and releasing) will be turned on automatically.

#### ■ Parking the vehicle

→P128

## ■ Parking brake engaged warning buzzer

A buzzer will sound if the vehicle is driven with the parking brake engaged. "EPB applied" is displayed on the multi-information display (with the vehicle reached a speed of 3 mph [5 km/h]).

#### If the brake system warning light comes on

→P.348

#### ■ Usage in winter time

→P.240



#### WARNING

## When parking the vehicle

Do not leave a child in the vehicle alone. The parking brake may be released unintentionally and there is the danger of the vehicle moving that may lead to an accident resulting in death or serious injury.



#### **NOTICE**

#### ■ When parking the vehicle

Before you leave the vehicle, shift the shift lever to P, set the parking brake and make sure that the vehicle does not move.

#### ■ When the system malfunctions

Stop the vehicle in a safe place and check the warning messages.

#### When the parking brake cannot be released due to a malfunction

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

Have the vehicle inspected by your Lexus dealer immediately if this occurs.

# **Brake Hold**


The brake hold system keeps the brake applied when the shift lever is in D, S or N with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in D or S to allow smooth start off.

# Enabling the system

Press the brake hold switch to turn the system on

The brake hold standby indicator **A** comes on. While the system is holding the brake, the brake hold operated indicator

**B** comes on.



# ■ Brake hold system operating conditions

The brake hold system cannot be turned on in the following conditions:

- The driver's door is not closed.
- The driver is not wearing the seat belt.
- "Parking Brake Unavailable" or "EPB Malfunction Visit Your Dealer" is displayed on the multi-information display.

If any of the conditions above are detected when the brake hold system is enabled, the system will turn off and the brake hold

standby indicator light will go off. In addition, if any of the conditions are detected while the system is holding the brake, a warning buzzer will sound and a message will be shown on the multi-information display. The parking brake will then be set automatically.

#### ■ Brake hold function

- If the brake pedal is left released for a period of about 3 minutes after the system has started holding the brake, the parking brake will be set automatically. In this case, a warning buzzer sounds and a message is shown on the multi-information display.
- To turn the system off while the system is holding the brake, firmly depress the brake pedal and press the button again.
- The brake hold function may not hold the vehicle when the vehicle is on a steep incline. In this situation, it may be necessary for the driver to apply the brakes. A warning buzzer will sound and the multiinformation display will inform the driver of this situation. If a warning message is shown on the multi-information display, read the message and follow the instructions.

#### When the parking brake is set automatically while the system is holding the brakes

Perform any of the following operations to release the parking brake.

- Depress the accelerator pedal. (The parking brake will not be released automatically if the seat belt is not fastened.)
- Operate the parking brake switch with the brake pedal depressed.

Make sure that the parking brake indicator light goes off.  $(\rightarrow P.146)$ 

#### ■ When an inspection at your Lexus dealer is necessary

When the brake hold standby indicator (green) does not illuminate even when the brake hold switch is pressed with the brake hold system operating conditions met, the system may be malfunctioning. Have the vehicle inspected at your Lexus dealer.

If "Brake Hold Fault Depress Brake to Deactivate Visit Your Dealer" or "Brake Hold Malfunction Visit Your Dealer" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

#### ■ Warning message and buzzers

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution. If a warning message is shown on the multi-information display, read the message and follow the instructions.

#### If the brake hold operated indicator flashes

 $\rightarrow$ P.355



#### WARNING

#### ■ When the vehicle is on a steep incline

When using the brake hold system on a steep incline exercise caution. The brake hold function may not hold the vehicle in such a situation.

#### ■ When stopped on a slippery road

The system cannot stop the vehicle when the gripping ability of the tires has been exceeded. Do not use the system when stopped on a slippery road.



#### NOTICE

#### ■ When parking the vehicle


The brake hold system is not designed for use when parking the vehicle for a long period of time. Turning the engine switch off while the system is holding the brake may release the brake, which would cause the vehicle to move. When operating the engine switch, depress the brake pedal, shift the shift lever to P and set the parking brake.

# **Headlight switch**

The headlights can be operated manually or automatically.

# Turning on the headlights

Turning the end of the lever turns on the lights as follows:



- A U.S.A.
- **B** Canada
- 1 For The side marker, parking, tail, license plate and, instrument panel lights, and daytime running lights turn on.
- 2 The headlights and all the lights listed above (except daytime running lights) turn on.
- 3 AUTO The headlights, daytime running lights and all the lights listed

above turn on and off automatically.

- - O (Canada) The daytime running lights turn on.

#### ■ AUTO mode can be used when

The engine switch is in IGNITION ON mode.

#### ■ Daytime running light system

- The daytime running lights illuminate using the same lights as the parking lights and illuminate brighter than the parking lights.
- To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically when all of the following conditions are met. (The daytime running lights are not designed for use at night.)
- The engine is running
- The parking brake is released
- The headlight switch is in the O (Canada only), ≥00€ or AUTO\* position
- \*: When the surroundings are bright

The daytime running lights remain on after they illuminate, even if the parking brake is set again.

- For the U.S.A.: Daytime running lights can be turned off by operating the headlight switch to OFF position.
- Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

## ■ Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



#### ■ Automatic light off system

When the headlights come on: The headlights and tail lights turn off 30 seconds after the driver's door is opened and closed if the engine switch is turned to ACCESSORY mode or turned off. (The

lights turn off immediately if on the key is pressed after all the doors are locked.)

• When only the tail lights come on: The tail lights turn off automatically if the engine switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the

light switch off once and then back to 30€



## ■ Light reminder buzzer

A buzzer sounds when the engine switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on.

# Automatic headlight leveling system (if equipped)

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

#### Windshield wiper linked headlight illumination

When driving during daytime with the

headlight switch turned to AUTO, if the windshield wipers are used, the headlights will turn on automatically after several seconds to help enhance the visibility of your vehicle.

#### ■ Battery-saving function

In order to prevent the battery of the vehicle from discharging, if the headlights and/or tail lights are on when the engine switch is turned off the battery saving function will operate and automatically turn off all the lights after approximately 20 minutes. When the engine switch is turned to IGNITION ON mode, the battery-saving function will be disabled.

When any of the following are performed, the battery-saving function is canceled once and then reactivated. All the lights will turn off automatically 20 minutes after the battery-saving function has been reactivated:

- When the headlight switch is operated
- When a door is opened or closed

#### ■ Welcome light illumination control

The front position and tail lights automatically turn on at night when the doors are unlocked using the entry function or wireless remote control if the light switch is in

the AUTO position.

#### ■ Customization

Settings (e.g. light sensor sensitivity) can be changed.

(Customizable features:  $\rightarrow$  P.400)




#### NOTICE

# ■To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

# Turning on the high beam headlights



 With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

2 Pull the lever toward you and release it to flash the high beams once.

You can flash the high beams with the headlights on or off.

# AFS (Adaptive Front-lighting System) (if equipped)

AFS (Adaptive Front-lighting System) secures excellent visibility at intersections and on curves by automatically adjusting the direction of the light axis of the headlights according to vehicle speed and the degree of the tire's angle as controlled by steering input.

AFS operates at speeds of approximately 6 mph (10 km/h) or higher.

# Cornering lights

When any of the following conditions is met, while the headlights (low beam) are on, the cornering lights will additionally turn on and light up the direction of movement for the vehicle. This is to ensure excellent visibility when either driving at intersections or parking at night.

- The steering wheel is operated
- The turn signal lever is operated
- The shift position is in R (both left and right side cornering lights)

#### ■ Cornering light control

- The lights illuminate when the vehicle speed is approximately 19 mph (30 km/h) or less. However, the lights turn off when the vehicle speed increases to approximately 22 mph (35 km/h) or more.
- After the lights remain illuminated for 30 minutes, they automatically turn off.

# **Automatic High Beam**

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of vehicle ahead, etc., and automatically turns the high beam on or off as necessary.



#### WARNING

#### Limitations of the Automatic High Beam


Do not rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning the high beam on or off manually if necessary.

■ To prevent incorrect operation of the Automatic High Beam system

Do not overload the vehicle.


# Activating the Automatic High Beam system

Press the Automatic High Beam switch.



Push the lever away from you with the headlight switch in the AUTO or Dosition.

The Automatic High Beam indicator will come on when the headlights are turned on automatically to indicate that the system is active.



#### ■ High beam automatic turning on or off conditions

- When all of the following conditions are met, the high beam will be automatically turned on (after approximately 1 second):
- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no vehicles ahead with headlights or tail lights turned on.
- There are few streetlights on the road
- If any of the following conditions are met, the high beam will be automatically turned off:
- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- · Vehicles ahead have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

#### ■ Camera sensor detection information

- The high beam may not be automatically turned off in the following situations:
- When oncoming vehicles suddenly appear from a curve
- When the vehicle is cut in front of by another vehicle
- When vehicles ahead are hidden from sight due to repeated curves, road dividers or roadside trees
- · When vehicles ahead appear from the faraway lane on wide road
- When vehicles ahead have no lights
- The high beam may be turned off if a vehicle ahead that is using fog lights with-

- out using the headlights is detected.
- House lights, street lights, traffic signals, and illuminated billboards or signs may cause the high beam to switch to the low beams, or the low beams to remain on.
- The following factors may affect the amount of time taken to turn the high beam on or off:
- The brightness of headlights, fog lights, and tail lights of vehicles ahead
- The movement and direction of vehicles ahead
- When a vehicle ahead only has operational lights on one side
- When a vehicle ahead is a two-wheeled vehicle
- The condition of the road (gradient, curve, condition of the road surface etc.)
- The number of passengers and amount of luggage
- The high beam may be turned on or off when the driver does not expect it.
- Bicycles or similar objects may not be detected.
- In the situations shown below, the system may not be able to accurately detect surrounding brightness levels. This may cause the low beams to remain on or the high beams to cause problems for pedestrians, vehicles ahead or other parties. In these cases, manually switch between the high and low beams.
- In bad weather (rain, snow, fog, sandstorms etc.)
- The windshield is obscured by fog, mist, ice, dirt etc.
- The windshield is cracked or damaged.
- The camera sensor is deformed or dirty.
- When the temperature of the camera sensor is extremely high
- Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
- When headlights or tail lights of vehicles ahead are turned off, dirty, changing color, or not aimed properly
- When the vehicle is hit by water, snow, dust, etc. from a preceding vehicle
- When driving through an area of intermittently changing brightness and darkness.
- When frequently and repeatedly driving

- ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.).
- When frequently and repeatedly taking curves or driving on a winding road.
- There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
- The back of a vehicle ahead is highly reflective, such as a container on a truck.
- The vehicle's headlights are damaged or dirty.
- The vehicle is listing or tilting, due to a flat tire, a trailer being towed etc.
- The high beam and low beam are repeatedly being switched between in an abnormal manner.
- The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby.

## ■ Temporarily lowering sensor sensitivity

The sensitivity of the sensor can be temporarily lowered.

- 1 Turn the engine switch off while the following conditions are met.
- The headlight switch is in To or AUTO.
- The headlight switch lever is in high beam position.
- Automatic High Beam switch is on.
- 2 Turn the engine switch to IGNITION ON mode.
- Within 30 seconds after 2, repeat pulling the headlight switch lever to the original position then pushing it to the high beam position quickly 10 times, then leave the lever in high beam position.
- 4 If the sensitivity is changed, the Automatic High Beam indicator turns on and off 3 times.

Automatic High Beam (headlights) may turn on even the vehicle is stopped.


# Turning the high beam on/off manually

# Switching to low beam

Pull the lever to the original position.

The Automatic High Beam indicator will turn off.

Push the lever away from you to activate the Automatic High Beam system again.




# Switching to high beam

Press the Automatic High Beam switch.

The Automatic High Beam indicator will turn off and the high beam indicator will turn on.

Press the switch to activate the Automatic High Beam system again.



# Windshield wipers and washer

Operating the lever can switch between automatic operation and manual operation, or can use the washer.



#### **NOTICE**


#### ■ When the windshield is dry

Do not use the wipers, as they may damage the windshield.

# Operating the wiper lever

Intermittent windshield wipers with interval adjuster

Operate the lever and switch as follows to use the wipers. When intermittent windshield wiper operation is selected, wiper interval can also be adjusted.



**1 OFF** \*1 or **O**\*2

2 INT \*1 or ♥ \*2
Intermittent operation


The intermittent windshield wiper operates more frequently as vehicle speed becomes higher.

- 3 LO  $^{*1}$  or  $\mathbf{\nabla}^{*2}$  Low speed operation
- **4** HI <sup>\*1</sup> or ▼ <sup>\*2</sup> High speed operation
- 5 MIST  $^{*1}$  or  $\triangle$   $^{*2}$ Temporary operation

\*1: For U.S.A.

\*2: For Canada

Wiper intervals can be adjusted when intermittent operation is selected.



- Increases the intermittent windshield wiper frequency
- 7 Decreases the intermittent windshield wiper frequency




8 Washer/wiper dual operation

The wipers will automatically operate a couple of times after the washer squirts. (After operating several times, the wipers operate once more time after a short delay to prevent dripping. However, the dripping prevention does not operate while the vehicle is moving.)


► Rain-sensing windshield wipers

Operate the lever and switch as follows to use the wipers. When AUTO is selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.



- 1 OFF<sup>\*1</sup> or **O**<sup>\*2</sup>
- 2 AUTO Rain-sensing operation
- 3 LO $^{*1}$  or  $\mathbf{\nabla}^{*2}$ Low speed operation
- 4 HI<sup>\*1</sup> or ▼\*2 High speed operation
- 5  $MIST^{*1}$  or  $\triangle^{*2}$ Temporary operation
- \*1: For U.S.A.
- \*2: For Canada

When AUTO is selected, the sensor sensitivity can be adjusted by turning the switch ring.



- 6 Increases the sensitivity
- 7 Decreases the sensitivity



8 Washer/wiper dual operation

The wipers will automatically operate a couple of times after the washer squirts. (After operating several times, the wipers operate once more time after a short delay to prevent dripping. However, the dripping prevention does not operate while the vehicle is moving.)

# ■ The windshield wiper and washer can be operated when

The engine switch is in IGNITION ON mode.

 Effects of vehicle speed on wiper operation (vehicles with rain-sensing windshield wipers)


Even when the wipers are not in AUTO mode, vehicle speed affects the time until the drip prevention wiper sweep occurs.

With low speed windshield wiper operation selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary. (However, when the sensor sensitivity is

adjusted to the highest level, the mode cannot be switched.)

- Raindrop sensor (vehicles with rainsensing windshield wipers)
- The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.



- If the wiper is turned to AUTO position while the engine switch is in IGNITION ON mode, the wipers will operate once to show that AUTO mode is activated.
- If the temperature of the raindrop sensor is 185°F (85°C) or higher, or -22°F (-30°C) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than AUTO.
- Front door opening linked windshield wiper stop function (vehicles with rainsensing windshield wipers)

When AUTO is selected and the windshield wipers are operating, if a front door is opened while the vehicle is stopped and the P position is selected, operation of the windshield wipers will be stopped to prevent anyone near the vehicle from being sprayed by water from the wipers. When the front door is closed, wiper operation will resume.

# ■ To protect the windshield wipers

If movement of the windshield wipers is largely restricted by a foreign object such as snow, the operation of the windshield wipers may be stopped automatically to protect the windshield wipers. In this case, turn the windshield wiper switch off and remove the foreign object, and then use the wind-

shield wipers.

# ■ When stopping the engine in an emergency while driving

If the windshield wipers are operating when the engine is stopped, the windshield wipers will operate in high speed operation. After the vehicle is stopped, operation will return to normal when the engine switch is turned to IGNITION ON mode, or operation will stop when the driver's door is opened.

# A

#### WARNING

 Caution regarding the use of windshield wipers in AUTO mode (vehicles with rain-sensing windshield wipers)

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in AUTO mode. Take care that your fingers or anything else do not become caught in the windshield wipers.

#### Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.



#### NOTICE

# ■ When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### ■ When a nozzle becomes blocked

In this case, contact your Lexus dealer. Do not try to clear it with a pin or other object. The nozzle will be damaged.


# Changing the windshield wiper rest position/Lifting the windshield wipers

When the windshield wipers are not being used, they retract to below the hood. To enable the windshield wipers to be lifted when parking in cold conditions or when replacing a windshield wiper insert, change the rest position of the windshield wipers to the service position using the wiper lever.

# Raising the wipers to the service position


Within approximately 45 seconds of turning the engine switch off, move the wiper lever to the MIST (U.S.A.) or  $\triangle$  (Canada) position and hold it for approximately 2 seconds or more.

The wipers will move to the service position.



# ■ Lifting the windshield wipers

While holding the hook portion **A** of the wiper arm, lift the windshield wiper from the windshield.



#### Lowering the windshield wipers to the retracted position


With the windshield wipers placed on the windshield, turn the engine switch to IGNI-TION ON mode and then move the wiper lever to an operating position. When the wiper switch is turned off, the windshield wipers will stop at the retracted position.

# $\triangle$

#### **NOTICE**

# ■ When lifting the windshield wipers

- Do not lift the windshield wipers when they are in the retracted position below the hood. Otherwise, they may contact the hood, possibly resulting in damage to a windshield wiper and/or the hood.
- Do not lift a windshield wiper by the wiper blade. Otherwise, the wiper blade may be deformed.





## **NOTICE**

- Do not operate the wiper lever when the windshield wipers are lifted. Otherwise, the windshield wipers may contact the hood, possibly resulting in damage to the windshield wipers and/or hood.
- Make sure that the wiper arms do not overlap each other when returning them. Failure to do so may cause damage to the windshield wipers.

# Opening the fuel tank cap

# Before refueling the vehicle

- Turn the engine switch off and ensure that all the doors and windows are closed.
- Confirm the type of fuel.

#### ■ Fuel types

→P.389

#### ■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

#### ■ If the fuel level gauge is malfunctioning

The malfunction indicator lamp may illuminate if the fuel level gauge is malfunctioning. (A malfunction may be detected and the malfunction indicator lamp may illuminate erroneously in some situations, such as when the vehicle is refueled repeatedly when the fuel tank is nearly full.)



#### WARNING

## ■ When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

 After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.

- Always hold the grips on the fuel tank cap and turn it slowly to remove it.

  A whooshing sound may be heard when the fuel tank cap is loosened.

  Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel.
   Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.

Doing so may cause the fuel to ignite and cause a fire.

 Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

# ■ When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.




#### **NOTICE**

# Refueling


Do not spill fuel during refueling. Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

# Opening the fuel tank cap

1 Press the opener switch.




2 Turn the fuel tank cap slowly and remove it, then hang it on the back of the fuel filler door.



■ If the fuel filler door cannot be opened  $\rightarrow$  P.371

# Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.



# **MARNING**

■ When replacing the fuel tank cap

Do not use anything but a genuine Lexus fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

# Lexus Safety System+2.0

The Lexus Safety System+2.0 consists of the following drive assist systems and contributes to a safe and comfortable driving experience:

# Driving assist system

- PCS (Pre-Collision System)
- →P.169
- LTA (Lane Tracing Assist)
- $\rightarrow$ P.176
- Automatic High Beam
- →P.153
- RSA (Road Sign Assist) (if equipped)
- $\rightarrow$ P.185
- Dynamic radar cruise control with full-speed range
- →P.187



#### WARNING


## ■ Lexus Safety System+2.0

The Lexus Safety System+2.0 is designed to operate under the assumption that the driver will drive safely, and is designed to help reduce the impact to the occupants and the vehicle in the case of a collision or assist the driver in normal driving conditions.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. The driver is always responsible for paying attention to the vehicle's surroundings and driving safely.

#### Sensors

Two types of sensors, located behind the front grille and windshield, detect information necessary to operate the drive assist systems.



- A Radar sensor
- **B** Front camera



#### WARNING

■ To avoid malfunction of the radar sensor


Observe the following precautions.

Otherwise, the radar sensor may not operate properly, possibly leading to an accident resulting in death or serious injury.



#### WARNING

 Keep the radar sensor and the grille cover clean at all times.



- A Radar sensor
- **B** Grille cover

If the front of the radar sensor or the front or back of the grille cover is dirty or covered with water droplets, snow, etc., clean it.

Clean the radar sensor and grille cover with a soft cloth to avoid damaging them.


- Do not attach accessories, stickers (including transparent stickers) or other items to the radar sensor, grille cover or surrounding area.
- Do not subject the radar sensor or its surrounding area to a strong impact.
   If the radar sensor, front grille, or front bumper has been subjected to a strong impact, have the vehicle inspected by your Lexus dealer.
- Do not disassemble the radar sensor.
- Do not modify or paint the radar sensor or grille cover.
- If the radar sensor, front grille, or front bumper needs to be removed and installed, or replaced, contact your Lexus dealer.

# ■ To avoid malfunction of the front camera

Observe the following precautions.

Otherwise, the front camera may not operate properly, possibly leading to an accident resulting in death or serious injury.

- Keep the windshield clean at all times.
- If the windshield is dirty or covered with an oily film, water droplets, snow, etc., clean the windshield.
- If a glass coating agent is applied to the windshield, it will still be necessary to use the windshield wipers to remove water droplets, etc. from the area of the windshield in front of the front camera.
- If the inner side of the windshield where the front camera is installed is dirty, contact your Lexus dealer.
- Do not attach objects, such as stickers, transparent stickers, etc., to the outer side of the windshield in front of the front camera (shaded area in the illustration).



- A From the top of the windshield to approximately 0.4 in. (1 cm) below the bottom of the front camera
- Approximately 7.9 in. (20 cm)

  (Approximately 4.0 in. [10 cm] to the right and left from the center of the front camera)



# **WARNING**

- If the part of the windshield in front of the front camera is fogged up or covered with condensation, or ice, use the windshield defogger to remove the fog, condensation, or ice.  $(\rightarrow P.252)$
- If water droplets cannot be properly removed from the area of the windshield in front of the front camera by the windshield wipers, replace the wiper insert or wiper blade. If the wiper inserts or wiper blades need to be replaced, contact your Lexus dealer.
- Do not attach window tint to the windshield.
- Replace the windshield if it is damaged or cracked. If the windshield needs to be replaced, contact your Lexus dealer.
- Do not allow liquids to contact the front camera.
- Do not allow bright lights to shine into the front camera.
- Do not dirty or damage the front cam-When cleaning the inside of the windshield, do not allow glass cleaner to contact the lens of the front camera. Also, do not touch the lens. If the lens is dirty or damaged, contact vour Lexus dealer.
- Do not subject the front camera to a strong impact.
- Do not change the installation position or direction of the front camera or remove it.
- Do not disassemble the front camera.
- Do not modify any components of the vehicle around the front camera (inside rear view mirror, etc.) or ceiling.

- Do not attach any accessories to the hood, front grille or front bumper that may obstruct the front camera. Contact your Lexus dealer for details.
- If a surfboard or other long object is to be mounted on the roof, make sure that it will not obstruct the front cam-
- Do not modify the headlights or other lights.

#### ■ Certification

▶ For vehicles sold in the U.S.A., Hawaii, Guam and Puerto Rico

FCC ID: HYQDNMWR009

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### ► For vehicles sold in Canada

#### NOTE:

This device complies with Industry Canada's licence-exempt RSSs.

Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

#### NOTE:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le dispositif rayonnant et le corps.

#### ■ If a warning message is displayed on the multi-information display

A system may be temporarily unavailable or there may be a malfunction in the system.

• In the following situations, perform the actions specified in the table. When the normal operating conditions are detected, the message will disappear and the system will become operational.

If the message does not disappear, contact your Lexus dealer.

Situation	Actions
When the area around a sensor is covered with dirt, moisture (fogged up, covered with condensation, ice, etc.), or other foreign matter	To clean the part of the windshield in front of the front camera, use the windshield wipers or the windshield defogger of the air conditioning system ( $\rightarrow$ P.252).
	If the front camera is hot, such as after the vehicle had been parked in the sun, use the air conditioning system to decrease the temperature around the front camera.
When the temperature around the front camera is outside of the operational range, such as when the vehicle is in the sun or in an extremely cold environment	If a sunshade was used when the vehicle was parked, depending on its type, the sunlight reflected from the surface of the sunshade may cause the temperature of the front camera to become excessively high.
	If the front camera is cold, such after the vehicle is parked in an extremely cold environment, use the air conditioning system to increase the temperature around the front camera.
The area in front of the front camera is obstructed, such as when the hood is open or a sticker is attached to the part of the windshield in front of the front camera.	Close the hood, remove the sticker, etc. to clear the obstruction.

#### 168

#### 4-5. Using the driving support systems

• In the following situations, if the situation has changed (or the vehicle has been driven for some time) and the normal operating conditions are detected, the message will disappear and the system will become operational.

If the message does not disappear, contact your Lexus dealer.

When the temperature around the radar sensor is outside of the operational range, such as when the vehicle is in the sun or in an extremely cold environment

When the front camera cannot detect objects in front of the vehicle, such as when driving in the dark, snow, or fog, or when bright lights are shining into the front camera

# PCS (Pre-Collision System)

The pre-collision system uses a radar sensor and front camera to detect objects ( $\rightarrow$ P.169) in front of the vehicle. When the system determines that the possibility of a frontal collision with an object is high, a warning operates to urge the driver to take evasive action and the potential brake pressure is increased to help the driver avoid the collision. If the system determines that the possibility of a frontal collision with an object is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

The pre-collision system can be disabled/enabled and the warning timing can be changed.  $(\rightarrow P.171)$ 

# Detectable objects

The system can detect the following:


- Vehicles
- Bicyclists
- Pedestrians

# System functions

# ■ Pre-collision warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the multi-information display to urge the driver

to take evasive action.



## ■ Pre-collision brake assist

When the system determines that the possibility of a frontal collision is high, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

## ■ Pre-collision braking

If the system determines that the possibility of a frontal collision is extremely high, the brakes are automatically applied to help avoid the collision or reduce the impact of the collision.

## ■ Suspension control (if equipped)

When the system determines that the possibility of a frontal collision is high, the Adaptive Variable Suspension System ( $\rightarrow$ P.236) will control the damping force of the shock absorbers to help maintain an appropriate vehicle posture.

# A

#### WARNING

## Limitations of the pre-collision system

- The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings. Do not use the pre-collision system instead of normal braking operations under any circumstances. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not overly rely on this system. Failure to do so may lead to an accident, resulting in death or serious injury.
- Although this system is designed to help avoid a collision or help reduce the impact of the collision, its effectiveness may change according to various conditions, therefore the system may not always be able to achieve the same level of performance. Read the following conditions carefully. Do not overly rely on this system and always drive carefully.
- Conditions under which the system may operate even if there is no possibility of a collision: →P.173
- Conditions under which the system may not operate properly: →P.174
- Do not attempt to test the operation of the pre-collision system yourself.
   Depending on the objects used for testing (dummies, cardboard objects imitating detectable objects, etc.), the system may not operate properly, possibly leading to an accident.

## ■ Pre-collision braking

- When the pre-collision braking function is operating, a large amount of braking force will be applied.
- If the vehicle is stopped by the operation of the pre-collision braking function, the pre-collision braking function operation will be canceled after approximately 2 seconds.
   Depress the brake pedal as necessary.

- The pre-collision braking function may not operate if certain operations are performed by the driver. If the accelerator pedal is being depressed strongly or the steering wheel is being turned, the system may determine that the driver is taking evasive action and possibly prevent the pre-collision braking function from operating.
- In some situations, while the pre-collision braking function is operating, operation of the function may be canceled if the accelerator pedal is depressed strongly or the steering wheel is turned and the system determines that the driver is taking evasive action.
- If the brake pedal is being depressed, the system may determine that the driver is taking evasive action and possibly delay the operation timing of the pre-collision braking function.
- When to disable the pre-collision system

In the following situations, disable the system, as it may not operate properly, possibly leading to an accident resulting in death or serious injury:

- When the vehicle is being towed
- When your vehicle is towing another vehicle
- When transporting the vehicle via truck, boat, train or similar means of transportation
- When the vehicle is raised on a lift with the engine running and the tires are allowed to rotate freely
- When inspecting the vehicle using a drum tester such as a chassis dynamometer or speedometer tester, or when using an on vehicle wheel balancer
- When a strong impact is applied to the front bumper or front grille, due to an accident or other reasons

# A

#### WARNING

- If the vehicle cannot be driven in a stable manner, such as when the vehicle has been in an accident or is malfunctioning
- When the vehicle is driven in a sporty manner or off-road
- When the tires are not properly inflated
- When the tires are very worn
- When tires of a size other than specified are installed
- When tire chains are installed
- When a compact spare tire or an emergency tire puncture repair kit is used
- If equipment (snow plow, etc.) that may obstruct the radar sensor or front camera is temporarily installed to the vehicle


# Changing settings of the pre-collision system

 Enabling/disabling the pre-collision system

The pre-collision system can be enabled/disabled on  $\bigcirc$  ( $\rightarrow$ P.72) of the multi-information display.

The system is automatically enabled each time the engine switch is turned to IGNI-TION ON mode.

If the system is disabled, the PCS warning light will turn on and a message will be displayed on the multi-information display.




4-5. Using the driving support systems

# Changing the pre-collision warning timing

The pre-collision warning timing can be changed on  $\bigcirc$  ( $\rightarrow$ P.72) of the multi-information display.

The warning timing setting is retained when the engine switch is turned off. However, if the pre-collision system is disabled and re-enabled, the operation timing will return to the default setting (middle).



- 1 Early
- 2 Middle

This is the default setting.

3 Late

#### Operational conditions

The pre-collision system is enabled and the system determines that the possibility of a frontal

collision with a detected object is high.

Each function is operational at the following speed

#### Pre-collision warning

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Vehicles	Approx. 7 to 110 mph (10 to 180 km/h)	Approx. 7 to 110 mph (10 to 180 km/h)
Bicyclists and pedestrians	Approx. 7 to 50 mph (10 to 80 km/h)	Approx. 7 to 50 mph (10 to 80 km/h)

#### Pre-collision brake assist

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Vehicles	Approx. 20 to 110 mph (30 to 180 km/h)	Approx. 20 to 110 mph (30 to 180 km/h)
Bicyclists and pedestrians	Approx. 20 to 50 mph (30 to 80 km/h)	Approx. 20 to 50 mph (30 to 80 km/h)

#### Pre-collision braking

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Vehicles	Approx. 7 to 110 mph (10 to 180 km/h)	Approx. 7 to 110 mph (10 to 180 km/h)
Bicyclists and pedestrians	Approx. 7 to 50 mph (10 to 80 km/h)	Approx. 7 to 50 mph (10 to 80 km/h)

The system may not operate in the following situations:

- If a battery terminal has been disconnected and reconnected and then the vehicle has not been driven for a certain amount of time
- If the shift lever is in R
- When the VSC OFF indicator is illuminated (only the pre-collision warning function will be operational)

## ■ Object detection function


The system detects objects based on their size, profile, motion, etc. However, an object may not be detected depending on the surrounding brightness and the motion, posture, and angle of the detected object, preventing the system from operating properly. (\$\rightarrow\$P.174\$) The illustration shows an image of detectable objects.




#### ■ Cancelation of the pre-collision braking

If either of the following occur while the pre-collision braking function is operating, it will be canceled:

- The accelerator pedal is depressed strongly.
- The steering wheel is turned sharply or abruptly.
- Conditions under which the system may operate even if there is no possibility of a collision
- In some situations such as the following, the system may determine that there is a possibility of a frontal collision and operate.
- When passing a detectable object, etc.
- When changing lanes while overtaking a detectable object, etc.
- When approaching a detectable object in an adjacent lane or on the roadside, such as when changing the course of travel or driving on a winding road




- When rapidly closing on a detectable object, etc.
- When approaching objects on the roadside, such as detectable objects, guardrails, utility poles, trees, or walls
- When there is a detectable object or other object by the roadside at the entrance of a curve




 When there are patterns or paint in front of your vehicle that may be mistaken for a detectable object


- When the front of your vehicle is hit by water, snow, dust, etc.
- When overtaking a detectable object that is changing lanes or making a right/left turn



 When passing a detectable object in an oncoming lane that is stopped to make a right/left turn




- When a detectable object approaches very close and then stops before entering the path of your vehicle
- If the front of your vehicle is raised or lowered, such as when on an uneven or undulating road surface
- When driving on a road surrounded by a structure, such as in a tunnel or on an iron bridge
- When there is a metal object (manhole cover, steel plate, etc.), steps, or a protrusion in front of your vehicle
- When passing under an object (road sign, billboard, etc.)



 When approaching an electric toll gate barrier, parking area barrier, or other barrier that opens and closes


- · When using an automatic car wash
- When driving through or under objects that may contact your vehicle, such as thick grass, tree branches, or a banner



- · When driving through steam or smoke
- When driving near an object that reflects radio waves, such as a large truck or guardrail
- When driving near a TV tower, broadcasting station, electric power plant, or other location where strong radio waves or electrical noise may be present


# Situations in which the system may not operate properly

- In some situations such as the following, an object may not be detected by the radar sensor and front camera, preventing the system from operating properly:
- When a detectable object is approaching your vehicle
- When your vehicle or a detectable object is wobbling
- If a detectable object makes an abrupt maneuver (such as sudden swerving, acceleration or deceleration)
- When your vehicle approaches a detectable object rapidly
- When a detectable object is not directly in front of your vehicle




- When a detectable object is near a wall, fence, guardrail, manhole cover, vehicle, steel plate on the road, etc.
- When a detectable object is under a structure

- When part of a detectable object is hidden by an object, such as large baggage, an umbrella, or guardrail
- When multiple detectable objects are close together
- If the sun or other light is shining directly on a detectable object
- When a detectable object is a shade of white and looks extremely bright
- When a detectable object appears to be nearly the same color or brightness as its surroundings
- If a detectable object cuts or suddenly emerges in front of your vehicle
- When the front of your vehicle is hit by water, snow, dust, etc.
- When a very bright light ahead, such as the sun or the headlights of oncoming traffic, shines directly into the front cam-
- When approaching the side or front of a vehicle ahead
- · If a vehicle ahead is a motorcycle
- If a vehicle ahead is narrow, such as a personal mobility vehicle
- If a preceding vehicle has a small rear end, such as an unloaded truck
- If a preceding vehicle has a low rear end, such as a low bed trailer




 If a vehicle ahead has extremely high ground clearance



- If a vehicle ahead is carrying a load which protrudes past its rear bumper
- If a vehicle ahead is irregularly shaped, such as a tractor or side car

- If a vehicle ahead is a child sized bicycle, a bicycle that is carrying a large load, a bicycle ridden by more than one person, or a uniquely shaped bicycle (bicycle with a child seat, tandem bicycle, etc.)
- If a pedestrian/or the riding height of a bicyclist ahead is shorter than approximately 3.2 ft. (1 m) or taller than approximately 6.5 ft. (2 m)
- If a pedestrian/bicyclist is wearing oversized clothing (a rain coat, long skirt, etc.), making their silhouette obscure
- If a pedestrian is bending forward or squatting or bicyclist is bending forward
- If a pedestrian/bicyclist is moving fast
- If a pedestrian is pushing a stroller, wheelchair, bicycle or other vehicle
- When driving in inclement weather such as heavy rain, fog, snow or a sandstorm
- When driving through steam or smoke
- When the surrounding area is dim, such as at dawn or dusk, or while at night or in a tunnel, making a detectable object appear to be nearly the same color as its surroundings
- When driving in a place where the surrounding brightness changes suddenly, such as at the entrance or exit of a tunnel
- After the engine has started the vehicle has not been driven for a certain amount of time
- While making a left/right turn and for a few seconds after making a left/right turn
- While driving on a curve and for a few seconds after driving on a curve
- If your vehicle is skidding
- If the front of the vehicle is raised or lowered



- · If the wheels are misaligned
- If a wiper blade is blocking the front camera
- The vehicle is being driven at extremely high speeds.
- When driving on a hill

- If the radar sensor or front camera is misaligned
- In some situations such as the following, sufficient braking force may not be obtained, preventing the system from performing properly:
- If the braking functions cannot operate to their full extent, such as when the brake parts are extremely cold, extremely hot, or wet
- If the vehicle is not properly maintained (brakes or tires are excessively worn, improper tire inflation pressure, etc.)
- When the vehicle is being driven on a gravel road or other slippery surface

#### ■ If VSC is disabled


- If VSC is disabled (→P.237), the pre-collision brake assist and pre-collision braking functions are also disabled.
- The PCS warning light will turn on and "VSC Turned OFF Pre-Collision Brake System Unavailable" will be displayed on the multi-information display.

# LTA (Lane Tracing Assist)

When driving on highways and freeways with white (yellow) lane lines, this function alerts the driver when the vehicle might depart from its lane or course and provides assistance by operating the steering wheel to keep the vehicle in its lane or course. Furthermore, the system provides steering assistance when dynamic radar cruise control with full-speed range is operating to keep the vehicle in its lane.

The LTA system recognizes white (yellow) lane lines or a course using the front camera. Additionally, it detects preceding vehicles using the front camera and radar.

\*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb



# **MARNING**

#### ■ Before using LTA system

- Do not rely solely upon the LTA system. The LTA system does not automatically drive the vehicle or reduce the amount of attention that must be paid to the area in front of the vehicle. The driver must always assume full responsibility for driving safely by paying careful attention to the surrounding conditions and operating the steering wheel to correct the path of the vehicle. Also, the driver must take adequate breaks when fatigued, such as from driving for a long period of time.
- Failure to perform appropriate driving operations and pay careful attention may lead to an accident, resulting in death or serious injury.
- When not using the LTA system, use the LTA switch to turn the system off.
- Situations unsuitable for LTA system
  In the following situations, use the LTA

switch to turn the system off. Failure to do so may lead to an accident, resulting in death or serious injury.

- Vehicle is driven on a road surface which is slippery due to rainy weather, fallen snow, freezing, etc.
- Vehicle is driven on a snow-covered road.
- White (yellow) lines are difficult to see due to rain, snow, fog, dust, etc.
- Vehicle is driven in a temporary lane or restricted lane due to construction work.
- Vehicle is driven in a construction zone.
- A spare tire, tire chains, etc. are equipped.
- When the tires have been excessively worn, or when the tire inflation pressure is low.

# **WARNING**


- When tires of a size other than specified are installed.
- Vehicle is driven in traffic lanes other than that highways and freeways.
- During emergency towing
- Preventing LTA system malfunctions and operations performed by mistake
- Do not modify the headlights or place stickers, etc. on the surface of the lights.
- Do not modify the suspension etc. If the suspension etc. needs to be replaced, contact your Lexus dealer.
- Do not install or place anything on the hood or grille. Also, do not install a grille guard (bull bars, kangaroo bar, etc.).
- If your windshield needs repairs, contact your Lexus dealer.
- Conditions in which functions may not operate properly

In the following situations, the functions may not operate properly and the vehicle may depart from its lane. Drive safely by always paying careful attention to your surroundings and operate the steering wheel to correct the path of the vehicle without relying solely on the functions.

When the follow-up cruising display is displayed  $(\rightarrow P.181)$  and the preceding vehicle changes lanes. (Your vehicle may follow the preceding vehicle and also change lanes.)




- When the follow-up cruising display is displayed  $(\rightarrow P.181)$  and the preceding vehicle is swaying. (Your vehicle may sway accordingly and depart from the lane.)
- When the follow-up cruising display is displayed  $(\rightarrow P.181)$  and the preceding vehicle departs from its lane. (Your vehicle may follow the preceding vehicle and depart from the lane.)
- When the follow-up cruising display is displayed  $(\rightarrow P.181)$  and the preceding vehicle is being driven extremely close to the left/right lane line. (Your vehicle may follow the preceding vehicle and depart from the lane.)
- Vehicle is being driven around a sharp curve.
- Objects or patterns that could be mistaken for white (yellow) lines are present on the side of the road (quardrails, curbs, reflective poles, etc.).



# A

#### WARNING

 Vehicle is driven where the road diverges, merges, etc.



 Repair marks of asphalt, white (yellow) lines, etc. are present due to road repair.



- There are shadows on the road that run parallel with, or cover, the white (yellow) lines.
- The vehicle is driven in an area without white (yellow) lines, such as in front of a tollgate or checkpoint, or at an intersection, etc.
- The white (yellow) lines are cracked, "Botts' dots", "Raised pavement marker" or stones are present.
- The white (yellow) lines cannot be seen or are difficult to see due to sand, etc.
- The vehicle is driven on a road surface that is wet due to rain, puddles, etc.

- The traffic lines are yellow (which may be more difficult to recognize than lines that are white).
- The white (yellow) lines cross over a curb, etc.
- The vehicle is driven on a bright surface, such as concrete.
- If the edge of the road is not clear or straight.
- The vehicle is driven on a surface that is bright due to reflected light, etc.
- The vehicle is driven in an area where the brightness changes suddenly, such as at the entrances and exits of tunnels, etc.
- Light from the headlights of an oncoming vehicle, the sun, etc. enters the camera.
- The vehicle is driven on a slope.
- The vehicle is driven on a road which tilts left or right, or a winding road.
- The vehicle is driven on an unpaved or rough road.
- The traffic lane is excessively narrow or wide.
- The vehicle is extremely tilted due to carrying heavy luggage or having improper tire pressure.
- The distance to the preceding vehicle is extremely short.
- The vehicle is moving up and down a large amount due to road conditions during driving (poor roads or road seams).
- When driving in a tunnel or at night with the headlights off or when a headlight is dim due to its lens being dirty or it being misaligned.
- The vehicle is struck by a crosswind.

### A

### WARNING

- The vehicle is affected by wind from a vehicle driven in a nearby lane.
- The vehicle has just changed lanes or crossed an intersection.
- Tires which differ by structure, manufacturer, brand or tread pattern are used.
- Snow tires, etc. are equipped.
- The vehicle is being driven at extremely high speeds.

### Functions included in LTA system


### ■ Lane departure alert function

When the system determines that the vehicle might depart from its lane or course\*, a warning is displayed on the multi-information display, and either a warning buzzer will sound or the steering wheel will vibrate to alert the driver.

When the warning buzzer sounds or the steering wheel vibrates, check the area around your vehicle and carefully operate the steering wheel to move the vehicle back to the center of the lane.

Vehicles with Blind Spot Monitor: When the system determines that the vehicle might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the lane departure alert will operate even if the turn signals are operating.

\*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb




### ■ Steering assist function

When the system determines that the vehicle might depart from its lane or course, the system provides assistance as necessary by operating the steering wheel in small amounts for a short period of time to keep the vehicle in its lane.

If the system detects that the steering wheel has not been operated for a fixed amount of time or the steering wheel is not being firmly gripped, a warning is displayed on the multi-information display and the function is temporarily canceled.


Vehicles with Blind Spot Monitor: When the system determines that the vehicle might depart from its lane and that the possibility of a collision with an overtaking vehicle in the adjacent lane is high, the steering assist function will operate even if the turn signals are operating.

 Boundary between asphalt and the side of the road, such as grass, soil, or a curb



### ■ Vehicle sway warning function

When the vehicle is swaying within a lane, the warning buzzer will sound and a message will be displayed on the multi-information display to alert the driver.




### ■ Lane centering function

This function is linked with dynamic radar cruise control with full-speed range and provides the required assistance by operating the steering wheel to keep the vehicle in its current lane.

When dynamic radar cruise control with full-speed range is not operating, the lane centering function does not operate.

In situations where the white (yellow) lane lines are difficult to see or are not visible, such as when in a traffic jam, this function will operate to help follow a preceding vehicle by monitoring the position of the preceding vehicle.

If the system detects that the steering wheel has not been operated for a fixed amount of time or the steering wheel is not being firmly gripped, a warning is displayed on the multi-information display and the function is temporarily canceled.




### Turning LTA system on

Press the LTA switch to turn the LTA system on.


The LTA indicator illuminates and a message is displayed on the multi-information display.

Press the LTA switch again to turn the LTA system off.

When the LTA system is turned on or off, operation of the LTA system continues in the same condition the next time the engine is started.



# Indications on multi-information display



### A LTA indicator

The illumination condition of the indicator informs the driver of the system operation status.

Illuminated in white:

LTA system is operating.

Illuminated in green:

Steering wheel assistance of the steering assist function or lane centering function is operating.

Flashing in orange:

Lane departure alert function is operating.

**B** Operation display of steering wheel operation support

Displayed when the multi-information display is switched to the driving assist system information screen

Indicates that steering wheel assistance of the steering assist function or lane centering function is operating.

Both outer sides of the lane are displayed: Indicates that steering wheel assist of the lane centering function is operating.

One outer side of the lane is displayed: Indicates that steering wheel assist of the steering assist function is operating.

Both outer sides of the lane are flashing: Alerts the driver that their input is necessary to stay in the center of the lane (lane centering function).

C Follow-up cruising display

Displayed when the multi-information display is switched to the driving assist system information screen

Indicates that steering assist of the lane centering function is operating by monitoring the position of a preceding vehicle.

When the follow-up cruising display is displayed, if the preceding vehicle moves, your vehicle may move in the same way. Always pay careful attention to your surroundings and operate the steering wheel as necessary to correct the path of the vehicle and ensure safety.

D Lane departure alert function display

Displayed when the multi-information dis-

play is switched to the driving assist system information screen.

▶ Inside of displayed lines is white



Indicates that the system is recognizing white (yellow) lines or a course \*. When the vehicle departs from its lane, the white line displayed on the side the vehicle departs from flashes orange.

▶ Inside of displayed lines is black



Indicates that the system is not able to recognize white (yellow) lines or a course or is temporarily canceled.

\*: Boundary between asphalt and the side of the road, such as grass, soil, or a curb

### Operation conditions of each function

Lane departure alert function

This function operates when all of the following conditions are met.

- · LTA is turned on.
- Vehicle speed is approximately 32 mph (50 km/h) or more.\*1
- System recognizes white (yellow) lane

- lines or a course \*2. (When a white [yellow] line or course \*2 is recognized on only one side, the system will operate only for the recognized side.)
- Width of traffic lane is approximately 9.8 ft. (3 m) or more.
- Turn signal lever is not operated. (Vehicles with Blind Spot Monitor: Except when another vehicle is in the lane on the side where the turn signal was operated)
- Vehicle is not being driven around a sharp curve.
- No system malfunctions are detected.
   (→P.184)
- \*1: The function operates even if the vehicle speed is less than approximately 32 mph (50 km/h) when the lane centering function is operating.
- \*2: Boundary between asphalt and the side of the road, such as grass, soil, or a curb
- Steering assist function

This function operates when all of the following conditions are met in addition to the operation conditions for the lane departure alert function.

- Setting for "Steering Assist" in of the multi-information display is set to "On".
   (→P.72)
- Vehicle is not accelerated or decelerated by a fixed amount or more.
- Steering wheel is not operated with a steering force level suitable for changing lanes.
- ABS, VSC, TRAC and PCS are not operating.
- TRÃC or VSC is not turned off.
- Hands off steering wheel warning is not displayed. (→P.183)
- Vehicle sway warning function

This function operates when all of the following conditions are met.

- Setting for "Warning" in of the multiinformation display is set to "On".
   (→P.72)
- Vehicle speed is approximately 32 mph (50 km/h) or more.
- Width of traffic lane is approximately 9.8

ft. (3 m) or more.

- No system malfunctions are detected. (→P.184)
- Lane centering function

This function operates when all of the following conditions are met.

- LTA is turned on.
- Setting for "Steering Assist" and "Lane Center" in of the multi-information display are set to "On". (→P.72)
- This function recognizes white (yellow) lane lines or the position of a preceding vehicle (except when the preceding vehicle is small, such as a motorcycle).
- The dynamic radar cruise control with full-speed range is operating in vehicleto-vehicle distance control mode.
- Width of traffic lane is approximately 10 to 13 ft. (3 to 4 m).
- Turn signal lever is not operated.
- Vehicle is not being driven around a sharp curve.
- No system malfunctions are detected. (→P.184)
- Vehicle does not accelerate or decelerate by a fixed amount or more.
- Steering wheel is not operated with a steering force level suitable for changing lanes.
- ABS, VSC, TRAC and PCS are not operating.
- TRAC or VSC is not turned off.
- Hands off steering wheel warning is not displayed. (→P.183)
- The vehicle is being driven in the center of a lane.
- · Steering assist function is not operating.

### ■ Temporary cancelation of functions

When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. (→P.182)

If the operation conditions ( $\rightarrow$ P.182) are no longer met while the lane centering function is operating, the steering wheel may vibrate and the buzzer may sound to indicate that the function has been temporarily canceled. However, if the "Steering wheel vibration" customization setting is set to "On", the system will notify the driver by

vibrating the steering wheel instead of sounding the buzzer.

### ■ Steering assist function/lane centering function

- Depending on the vehicle speed, lane departure situation, road conditions, etc., the driver may not feel the function is operating or the function may not operate at all.
- The steering control of the function is overridden by the driver's steering wheel operation.
- Do not attempt to test the operation of the steering assist function.

### ■ Lane departure alert function

- The warning buzzer may be difficult to hear due to external noise, audio playback, etc. Also, it may be difficult to feel steering wheel vibrations due to the road conditions, etc.
- If the edge of the course is not clear or straight, the lane departure alert function may not operate.
- Vehicles with Blind Spot Monitor: It may not be possible for the system to determine if there is a danger of a collision with a vehicle in an adjacent lane.
- Do not attempt to test the operation of the lane departure alert function.
- Boundary between asphalt and the side of the road, such as grass, soil, or a curb

### Hands off steering wheel warning

In the following situations, a warning message urging the driver to hold the steering wheel and the symbol shown in the illustration are displayed on the multi-information display to warn the driver. The warning stops when the system determines that the driver holds the steering wheel. Always keep your hands on the steering wheel when using this system, regardless of warnings.



 When the system determines that the driver is driving without holding the steering wheel while the system is operating

If the driver continues to keep their hands off of the steering wheel, the buzzer sounds, the driver is warned and the function is temporarily canceled. This warning also operates in the same way when the driver continuously operates the steering wheel only a small amount.

The buzzer also sounds even if the alert type is set to "Steering wheel vibration".

 When the system determines that the vehicle may not turn and instead depart from its lane while driving around a curve

Depending on the vehicle condition and road conditions, the warning may not operate. Also, if the system determines that the vehicle is driving around a curve, warnings will occur earlier than during straight-lane driving.

 When the system determines that the driver is driving without holding the steering wheel while the steering wheel assist of the steering assist function is operating.

If the driver continues to keep their hands off of the steering wheel and the steering wheel assist is operating, the buzzer sounds and the driver is warned. Each time the buzzer sounds, the continuing time of the buzzer becomes longer.

The buzzer also sounds even if the alert type is set to "Steering wheel vibration".

### ■ Vehicle sway warning function

When the system determines that the vehi-

cle is swaying while the vehicle sway warning function is operating, a buzzer sounds and a warning message urging the driver to rest and the symbol shown in the illustration are simultaneously displayed on the multi-information display.



Depending on the vehicle and road conditions, the warning may not operate.

### ■ Warning message

If the following warning message is displayed on the multi-information display and the LTA indicator illuminates in orange, follow the appropriate troubleshooting procedure. Also, if a different warning message is displayed, follow the instructions displayed on the screen.

"LTA Malfunction Visit Your Dealer"
The system may not be operating properly.
Have the vehicle inspected by your Lexus dealer.

#### "I TA Unavailable"

The system is temporarily canceled due to a malfunction in a sensor other than the front camera. Turn the LTA system off, wait for a little while, and then turn the LTA system back on.

"LTA Unavailable at Current Speed"
The function cannot be used as the vehicle speed exceeds the LTA operation range.
Drive slower.


#### ■ Customization

Function settings can be changed. (Customizable features:—P.400)

### RSA (Road Sign Assist)\*

### $^{\star}$ : If equipped

The RSA system recognizes specific road signs using the front camera to provide information to the driver via the display.



If the system judges that the vehicle is being driven over the speed limit, performing prohibited actions, etc. in relation to the recognized road signs, it alerts the driver using a warning display and warning buzzer or steering wheel vibration.



### WARNING

### Before using the RSA


Do not rely solely upon the RSA system. RSA is a system which supports the driver by providing information, but it is not a replacement for a driver's own vision and awareness. Drive safely by always paying careful attention to the traffic rules.

### Indication on the multi-information display


When the front camera recognizes a sign, the sign will be displayed on the multi-information display.

• When the driving support system

information is selected, a maximum of 3 signs can be displayed.  $(\rightarrow P.71)$ 



 When a tab other than the driving support system information is selected, only a recognized speed limit sign or do not enter sign (when notification is necessary) will be displayed. (→P.71)



If signs other than speed limit signs are recognized, they will be displayed in an overlapping stack under the current speed limit sign.

### Supported types of road signs

The following types of road signs are recognized.

A non-official or a recently introduced traffic sign may not be recognized.



: Speed limit



: Do Not Enter



: Stop



: Yield

### Warning display

In the following situations, the RSA system will alert the driver.

- When the vehicle speed exceeds the speed warning threshold of the speed limit sign displayed, the sign display will be emphasized and a buzzer will sound.
- When the RSA system recognizes a do not enter sign and determines that your vehicle has entered a noentry area, the displayed sign will flash and a buzzer will sound.

Depending on the situation, traffic environment (traffic direction, speed, unit) may be detected incorrectly and a warning display may not operate properly.

### ■ Setting procedure

- 1 Press < or > of the meter control switches and select
- Press or of the meter control switches and select "Vehicle Settings", then press "OK"
- Press or of the meter control switches and select , then press "OK"

4 Press or of the meter control switches and select "RSA", then press "OK"

### ■ Automatic turn-off of RSA sign display

In the following situations, a displayed speed limit sign will stop being displayed automatically:

A new sign is not recognized for a certain distance.

In the following situations, do not enter, stop and yield signs will stop being displayed automatically:

- The system determines that your vehicle has passed the sign.
- The road changes due to a left or right turn, etc.
- Conditions in which the function may not operate or detect correctly

In the following situations, RSA does not operate normally and may not recognize signs, display the incorrect sign, etc. However, this does not indicate a malfunction.

- The front camera is misaligned due to a strong impact being applied to the sensor, etc.
- Dirt, snow, stickers, etc. are on the windshield near the front camera.
- In inclement weather such as heavy rain, fog, snow or sand storms
- Light from an oncoming vehicle, the sun, etc. enters the front camera.
- The sign is dirty, faded, tilted or bent.
- All or part of the sign is hidden by the leaves of a tree, a pole, etc.
- The sign is only visible to the front camera for a short amount of time.
- The driving scene (turning, lane change, etc.) is judged incorrectly.
- Even if it is a sign not appropriate for the currently traveled lane, such a sign exists directly after a freeway branches, or in an adjacent lane just before merging.
- Stickers are attached to the rear of the preceding vehicle.
- A sign resembling a system compatible

sign is recognized.

- Side road speed signs may be detected and displayed (if positioned in sight of the front camera) while the vehicle is traveling on the main road.
- Roundabout exit road speed signs may be detected and displayed (if positioned in sight of the front camera) while traveling on a roundabout.
- The front of the vehicle is raised or lowered due to the carried load.
- The surrounding brightness is not sufficient or changes suddenly.
- When a sign intended for trucks, etc. is recognized.

### Speed limit sign display

If the engine switch was last turned off while a speed limit sign was displayed on the multi-information display, the same sign displays again when the engine switch is turned to IGNITION ON mode.

### ■ If "RSA Malfunction Visit Your Dealer" is shown

The system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

#### ■ Customization

Some functions can be customized. (Customizable features: →P.400)

# Dynamic radar cruise control with full-speed range


In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates, decelerates and stops to match the speed changes of the preceding vehicle even if the accelerator pedal is not depressed. In constant speed control mode, the vehicle runs at a fixed speed.

Use the dynamic radar cruise control with full-speed range on freeways and highways.

- Vehicle-to-vehicle distance control mode (→P.190)
- Constant speed control mode (→P.194)


### System Components

### ■ Meter display



- A Multi-information display
- **B** Set speed
- **C** Indicators

### ■ Operation switches



- A Vehicle-to-vehicle distance switch
- **B** +RES switch
- Cruise control main switch
- **D** Cancel switch
- E -SET switch

### A

### **WARNING**

- Before using dynamic radar cruise control with full-speed range
- Driving safely is the sole responsibility of the driver. Do not rely solely on the system, and drive safely by always paying careful attention to your surroundings.
- The dynamic radar cruise control with full-speed range provides driving assistance to reduce the driver's burden. However, there are limitations to the assistance provided. Read the following conditions carefully. Do not overly rely on this system and always drive carefully.
- When the sensor may not be correctly detecting the vehicle ahead →P.195
- Conditions under which the vehicleto-vehicle distance control mode may not function correctly →P.196
- Set the speed appropriately depending on the speed limit, traffic flow, road conditions, weather conditions, etc.
   The driver is responsible for checking the set speed.

- Even when the system is functioning normally, the condition of the preceding vehicle as detected by the system may differ from the condition observed by the driver. Therefore, the driver must always remain alert, assess the danger of each situation and drive safely. Relying solely on this system or assuming the system ensures safety while driving can lead to an accident, resulting in death or serious injury.
- Switch the dynamic radar cruise control with full-speed range setting to off, using the cruise control main switch when not in use.
- Cautions regarding the driving assist systems

Observe the following precautions, as there are limitations to the assistance provided by the system. Failure to do so may cause an accident resulting in death or serious injury.

Assisting the driver to measure following distance

The dynamic radar cruise control with full-speed range is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.

Assisting the driver to judge proper following distance

The dynamic radar cruise control with full-speed range determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is within a set range. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.

### **WARNING**

 Assisting the driver to operate the vehicle

The dynamic radar cruise control with full-speed range does not include functions which will prevent or avoid collisions with vehicles ahead of your vehicle. Therefore, if there is ever any possibility of danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

Situations unsuitable for dynamic radar cruise control with full-speed range

Do not use dynamic radar cruise control with full-speed range in any of the following situations.

Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.


- Roads where there are pedestrians. cyclists, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients Vehicle speed may exceed the set speed when driving down a steep hill.
- At entrances to freeways and highways
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog. snow, sandstorm, heavy rain, etc.)
- When there is rain, snow, etc. on the front surface of the radar or front camera

- In traffic conditions that require frequent repeated acceleration and deceleration
- During emergency towing
- When an approach warning buzzer is heard often

### Driving in vehicle-to-vehicle distance control mode

This mode employs a radar to detect the presence of vehicles up to approximately 328 ft. (100 m) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance switch.

When driving on downhill slopes, the vehicle-to-vehicle distance may become shorter.



A Example of constant speed cruising
When there are no vehicles ahead

The vehicle travels at the speed set by the driver.

**B** Example of deceleration cruising and follow-up cruising
When a preceding vehicle driving slower than the set speed appears

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the stop lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. Approach warning warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

When the vehicle ahead of you stops, your vehicle will also stop (vehicle is stopped by system control). After the vehicle ahead starts off, pressing the +RES switch or depressing the accelerator pedal (start-off operation) will resume follow-up cruising. If the start-off operation is not performed, system control continues to keep your vehicle stopped.

When the turn signal lever is operated and your vehicle moves to a left lane while driving at 50 mph (80 km/h) or more, the vehicle will quickly accelerate to help to overtake a passing vehicle.

**C** Example of acceleration

When there are no longer any preceding vehicles driving slower than the set speed


The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

### Setting the vehicle speed (vehicle-to-vehicle distance control mode)

 Press the cruise control main switch to activate the cruise control.

Radar cruise control indicator will come on and a message will be displayed on the multi-information display. Press the switch again to deactivate the cruise control.

If the cruise control main switch is pressed and held for 1.5 seconds or more, the system turns on in constant speed control mode.  $(\rightarrow P.194)$ 




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 20 mph [30 km/h])) and press the -SET switch to set the speed.

Cruise control "SET" indicator will come on.


The vehicle speed at the moment the

switch is released becomes the set speed.



### Adjusting the set speed

To change the set speed, press the +RES or -SET switch until the desired set speed is displayed.



1 Increases the speed

(Except when the vehicle has been stopped by system control in vehicle-tovehicle distance control mode)

2 Decreases the speed

Fine adjustment: Press the switch.

Large adjustment: Press and hold the switch to change the speed, and release when the desired speed is reached.

In the vehicle-to-vehicle distance con-

trol mode, the set speed will be increased or decreased as follows:

► For the U.S. mainland and Hawaii

Fine adjustment: By 1 mph  $(1.6 \text{ km/h})^{*1}$  or 1 km/h  $(0.6 \text{mph})^{*2}$  each time the switch is pressed

Large adjustment: Increases or decreases in 1mph  $(1.6 \text{ km/h})^{*1}$  or  $1 \text{ km/h} (0.6 \text{ mph})^{*2}$  increments for as long as the switch is held

Except for the U.S. mainland and Hawaii

Fine adjustment: By 1 mph  $(1.6 \text{ km/h})^{*1}$  or 1 km/h  $(0.6 \text{mph})^{*2}$  each time the switch is pressed

Large adjustment: Increases or decreases in 5 mph  $(8 \text{ km/h})^{*1}$  or  $5 \text{ km/h} (3.1 \text{ mph})^{*2}$  increments for as long as the switch is held

In the constant speed control mode  $(\rightarrow P.194)$ , the set speed will be increased or decreased as follows:


Fine adjustment: By 1 mph  $(1.6 \text{ km/h})^{*1}$  or 1 km/h  $(0.6 \text{ mph})^{*2}$  each time the switch is pressed

Large adjustment: The speed will continue to change while the switch is held.

- \*1: When the set speed is shown in "MPH"
- \*2: When the set speed is shown in "km/h"

# Changing the vehicle-to-vehicle distance (vehicle-to-vehicle distance control mode)

Pressing the switch changes the vehicle-to-vehicle distance as follows:



- 1 Long
- 2 Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode. If a vehicle is running ahead of you, the preceding vehicle mark **A** will also be displayed.

### Vehicle-to-vehicle distance settings (vehicle-to-vehicle distance control mode)

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 50 mph (80 km/h). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed. When the vehicle is stopped by system control, the vehicle stops at a certain vehicle-to-vehicle distance depending on the situation.


Distance options	Vehicle-to-vehicle distance
Long	Approximately 160 ft. (50 m)

Distance options	Vehicle-to-vehicle distance
Medium	Approximately 130 ft. (40 m)
Short	Approximately 100 ft. (30 m)


Resuming follow-up cruising when the vehicle has been stopped by system control (vehicle-to-vehicle distance control mode)

After the vehicle ahead of you starts off, press the +RES switch.

Your vehicle will also resume follow-up cruising if the accelerator pedal is depressed after the vehicle ahead of you starts off.



### Canceling and resuming the speed control



 Pressing the cancel switch cancels the speed control.


The speed control is also canceled when the brake pedal is depressed.

(When the vehicle has been stopped by system control, depressing the brake pedal does not cancel the setting.)

2 Pressing the +RES switch resumes the cruise control and returns vehicle speed to the set speed.

### Approach warning (vehicle-tovehicle distance control mode)

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.



### ■ Warnings may not occur when

In the following instances, warnings may not occur even when the vehicle-to-vehicle distance is small.

- When the speed of the preceding vehicle matches or exceeds your vehicle speed
- When the preceding vehicle is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- When depressing the accelerator pedal

### Selecting constant speed control mode


When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to a dirty radar, etc.

1 With the cruise control off, press and hold the cruise control main switch for 1.5 seconds or more.

Immediately after the switch is pressed, the radar cruise control indicator will come on. Afterwards, it switches to the cruise con-

trol indicator.

Switching to constant speed control mode is only possible when operating the switch with the cruise control off.




2 Accelerate or decelerate, with accelerator pedal operation, to the desired vehicle speed (at or above approximately 20 mph [30 km/h]) and press the -SET switch to set the speed.

Cruise control "SET" indicator will come on.

The vehicle speed at the moment the switch is released becomes the set speed.

Adjusting the speed setting: →P.191

Canceling and resuming the speed setting: →P.193



- Dynamic radar cruise control with fullspeed range can be set when
- The shift lever is in D or range 4 or higher of S has been selected.
- Range 4 or higher of D has been selected by using the paddle shift switch.
- The desired set speed can be set when

the vehicle speed is approximately 20 mph (30 km/h) or more. (However, when the vehicle speed is set while driving at below approximately 20 mph [30 km/h], the set speed will be set to approximately 20 mph [30 km/h].)

### Accelerating after setting the vehicle speed

The vehicle can accelerate by operating the accelerator pedal. After accelerating, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the preceding vehicle.

## ■ When the vehicle stops while follow-up cruising

- Pressing the +RES switch while the vehicle ahead stops will resume follow-up cruising if the vehicle ahead starts off within approximately 3 seconds after the switch is pressed.
- If the vehicle ahead starts off within 3 seconds after your vehicle stops, follow-up cruising will be resumed.

### Automatic cancelation of vehicle-tovehicle distance control mode

Vehicle-to-vehicle distance control mode is automatically canceled in the following situations.

- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off.
- The sensor cannot detect correctly because it is covered in some way.
- Pre-collision braking is activated.
- The parking brake is operated.
- The vehicle is stopped by system control on a steep incline.
- The following are detected when the vehicle has been stopped by system control:
- The driver is not wearing a seat belt.
- The driver's door is opened.
- The vehicle has been stopped for about 3 minutes

If vehicle-to-vehicle distance control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Lexus dealer.

### Automatic cancelation of constant speed control mode

Constant speed control mode is automatically canceled in the following situations:

- Actual vehicle speed is more than approximately 10 mph (16 km/h) below the set vehicle speed.
- Actual vehicle speed falls below approximately 20 mph (30 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off.
- Pre-collision braking is activated.

If constant speed control mode is automatically canceled for any reasons other than the above, there may be a malfunction in the system. Contact your Lexus dealer.

### ■ Brake operation

A brake operation sound may be heard and the brake pedal response may change, but these are not malfunctions.

### Warning messages and buzzers for dynamic radar cruise control with fullspeed range

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. If a warning message is shown on the multi-information display, read the message and follow the instructions. (→P.167, P.358)


## ■ When the sensor may not be correctly detecting the vehicle ahead

In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.


As the sensor may not be able to correctly detect these types of vehicles, the approach warning  $(\rightarrow P.193)$  may not be activated.

Vehicles that cut in suddenly


- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board, etc.)



- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the luggage compartment, etc.)



Preceding vehicle has an extremely high ground clearance




 Conditions under which the vehicle-tovehicle distance control mode may not function correctly

In the case of the following conditions, operate the brake pedal (or accelerator pedal, depending on the situation) as necessary.


As the sensor may not be able to correctly detect vehicles ahead, the system may not

operate properly.

 When the road curves or when the lanes are narrow



 When steering wheel operation or your position in the lane is unstable



- When the vehicle ahead of you decelerates suddenly
- When driving on a road surrounded by a structure, such as in a tunnel or on a bridge
- While the vehicle speed is decreasing to the set speed after the vehicle accelerates by depressing the accelerator pedal

### BSM (Blind Spot Monitor)

### \*: If equipped

The Blind Spot Monitor is a system that uses rear side radar sensors installed on the inner side of the rear bumper on the left and right side to assist the driver in confirming safety when changing lanes.

#### WARNING


### Cautions regarding the use of the function

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor is a supplementary function which alerts the driver that a vehicle is in a blind spot of the outside rear view mirrors or is approaching rapidly from behind into a blind spot. Do not overly rely on the Blind Spot Monitor. As the function cannot judge if it is safe to change lanes, over reliance could lead to an accident resulting in death or serious injury.

As the system may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary.

### System components



A Meter control switches Turn the Blind Spot Monitor on/off. When a vehicle is detected in a blind spot of the outside rear view mirrors or approaching rapidly from behind into a blind spot, the outside rear view mirror

**B** Outside rear view mirror indicators

indicator on the detected side will illuminate. If the turn signal lever is operated toward the detected side, the outside rear view mirror indicator will flash.

### **C** BSM indicator

When the Blind Spot Monitor is turned on. the indicator comes on.

### Turning the Blind Spot Monitor on/off

- 1 Press < or > of the meter control switches, select .
- 2 Press A or V of the meter control switches, select "BSM", and then press "OK".

### Outside rear view mirror indicator visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

■ When "Blind Spot Monitor Unavailable" is shown on the multi-information dis-

Ice, snow, mud, etc., may be attached to the rear bumper around the sensors.  $(\rightarrow P.198)$ Remove the ice, snow, mud, etc., attached to the rear bumper around the sensors to return the function to normal. Additionally, the sensors may not operate normally when driving in extremely hot or cold environments.

#### ■ Customization

Some functions can be customized. (Customizable features:  $\rightarrow$  P.400)

### ■ Certification for the Blind Spot Monitor

▶ For vehicles sold in the U.S.A., Hawaii, Guam and Puerto Rico

FCC ID: OAYSRR3A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### ► For vehicles sold in Canada

Applicable law : Canada 310

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Frequency bands: 24.05 - 24.25GHz Output power: less than 20 milliwatts

Droit applicable : Canada 310

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes ; (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Bandes de fréquences : 24.05 - 24.25GHz. Puissance émise : Moins de 20 milliwatts



#### WARNING


### ■ Handling the rear side radar sensors

Blind Spot Monitor sensors are installed behind the left and right sides of the rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.

### **WARNING**

 Keep the sensors and the surrounding areas on the rear bumper clean at all times.

If a sensor or its surrounding area on the rear bumper is dirty or covered with snow, the Blind Spot Monitor may not operate and a warning message  $(\rightarrow P.197)$  will be displayed. In this situation, clear off the dirt or snow and drive the vehicle with the operation conditions of the BSM function  $(\rightarrow P.201)$  satisfied for approximately 10 minutes. If the warning message does not disappear, have the vehicle inspected by your Lexus dealer.




- Do not subject a sensor or its surrounding area on the rear bumper to a strong impact.
  - If a sensor is moved even slightly off position, the system may malfunction and vehicles may not be detected cor-
  - In the following situations, have your vehicle inspected by your Lexus dealer.
- A sensor or its surrounding area is subject to a strong impact.
- If the surrounding area of a sensor is scratched or dented, or part of them has become disconnected.
- Do not disassemble the sensor.
- Do not attach accessories, stickers (including transparent stickers), aluminum tape, etc. to a sensor or its surrounding area on the rear bumper.
- Do not modify the sensor or surrounding area on the rear bumper.

- If a sensor or the rear bumper needs to be removed/installed or replaced. contact your Lexus dealer.
- Do not paint the rear bumper any color other than an official Lexus color.

### Blind Spot Monitor operation

### Vehicles that can be detected by the Blind Spot Monitor


The Blind Spot Monitor uses rear side radar sensors to detect the following vehicles traveling in adjacent lanes and advises the driver of the presence of such vehicles via the indicators on the outside rear view mirrors.



- A Vehicles that are traveling in areas that are not visible using the outside rear view mirrors (the blind spots)
- **B** Vehicles that are approaching rapidly from behind in areas that are not visible using the outside rear view mirrors (the blind spots)

### Blind Spot Monitor detection areas

The areas that vehicles can be detected in are outlined below.



The range of each detection area is:

- lackApproximately 1.6 ft. (0.5 m) to 11.5 ft. (3.5 m) from either side of the vehicle  $^{*1}$
- **B** Approximately 3.3 ft. (1 m) forward of the rear bumper
- C Approximately 9.8 ft. (3 m) from the rear bumper
- lacktriangle Approximately 9.8 ft. (3 m) to 197 ft. (60 m) from the rear bumper  $^{\star2}$
- \*1: The area between the side of the vehicle and 1.6 ft. (0.5 m) from the side of the vehicle cannot be detected.

\*2: The greater the difference in speed between your vehicle and the detected vehicle is, the farther away the vehicle will be detected, causing the outside rear view mirror indicator to illuminate or flash.

### ■ The Blind Spot Monitor is operational when

The Blind Spot Monitor is operational when all of the following conditions are met:

- The Blind Spot Monitor is on.
- The shift lever is in a position other than R.
- The vehicle speed is greater than approximately 10 mph (16 km/h).

### ■ The Blind Spot Monitor will detect a vehicle when

The Blind Spot Monitor will detect a vehicle present in the detection area in the following situations:

- A vehicle in an adjacent lane overtakes your vehicle.
- You overtake a vehicle in adjacent lane slowly.
- Another vehicle enters the detection area when it changes lanes.

### ■ Conditions under which the Blind Spot Monitor will not detect a vehicle

The Blind Spot Monitor is not designed to detect the following types of vehicles and/or objects:

- Small motorcycles, bicycles, pedestrians, etc.\*
- Vehicles traveling in the opposite direction
- Guardrails, walls, signs, parked vehicles and similar stationary objects
- Following vehicles that are in the same lane\*
- Vehicles traveling 2 lanes away from your vehicle\*
- Vehicles which are being overtaken rapidly by your vehicle.
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

- Conditions under which the Blind Spot Monitor may not function correctly
- The Blind Spot Monitor may not detect vehicles correctly in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When driving on a road surface that is wet with standing water during bad weather, such as heavy rain, snow, or fog
- When multiple vehicles are approaching with only a small gap between each vehicle
- When the distance between your vehicle and a following vehicle is short
- When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
- When the difference in speed between your vehicle and another vehicle is changing
- When a vehicle enters a detection area traveling at about the same speed as your vehicle
- As your vehicle starts from a stop, a vehicle remains in the detection area
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When driving on roads with sharp bends, consecutive curves, or uneven surfaces
- When vehicle lanes are wide, or when driving on the edge of a lane, and the vehicle in an adjacent lane is far away from your vehicle
- When an accessory (such as a bicycle carrier) or towing eyelet is installed to the rear of the vehicle
- When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
- Immediately after the Blind Spot Monitor is turned on
- Instances of the Blind Spot Monitor unnecessarily detecting a vehicle and/or

- object may increase in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When the distance between your vehicle and a guardrail, wall, etc. that enters the detection area is short
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When vehicle lanes are narrow, or when driving on the edge of a lane, and a vehicle traveling in a lane other than the adjacent lanes enters the detection area
- When driving on roads with sharp bends, consecutive curves, or uneven surfaces
- When the tires are slipping or spinning
- When the distance between your vehicle and a following vehicle is short
- When an accessory (such as a bicycle carrier) or towing eyelet is installed to the rear of the vehicle

### **Driving Mode Select switch**

The driving modes can be selected to suit driving condition.

### Selecting the driving mode

Vehicles without Adaptive Variable
 Suspension system



### 1 Normal mode

Provides an optimal balance of fuel economy, quietness, and dynamic performance. Suitable for city driving.

Press the switch to change the normal mode when not in normal mode.

### 2 Fco drive mode

Helps the driver accelerate in an ecofriendly manner and improve fuel economy through moderate throttle characteristics and by controlling the operation of the air conditioning system (heating/cooling).

When not in Eco drive mode, if the Driving Mode Select switch is turned toward you, the "Eco" indicator comes on.


### 3 Sport mode

Controls the transmission and engine to provide quick, powerful acceleration. This

mode is suitable for when agile driving response is desired, such as when driving on roads with many curves.

When not in SPORT mode, if the Driving Mode Select switch is turned away from you, the "Sport" indicator comes on.

Vehicles with Adaptive Variable Suspension system



### 1 Normal mode/Custom mode

Normal mode and custom mode are selected by pressing the Driving Mode Select switch. Each time the switch is pressed, the driving mode changes between normal mode and custom mode. When custom mode is selected, the "Custom" indicator comes on.

Press the switch to change the driving mode to normal mode when not in normal mode.

Normal mode

Provides an optimal balance of fuel economy, quietness, and dynamic performance. Suitable for city driving.

Custom mode

Allows you to drive with the power train, chassis and air conditioning system functions set to your preferred settings.

Custom mode settings can only be changed on the drive mode customization

display of the Center Display.  $(\rightarrow P.245)$ 

### 2 Eco drive mode

Helps the driver accelerate in an ecofriendly manner and improve fuel economy through moderate throttle characteristics and by controlling the operation of the air conditioning system (heating/cooling).

When not in Eco drive mode, if the Driving Mode Select switch is turned toward you, the "Eco" indicator comes on.

- 3 Sport mode
- SPORT S mode

Controls the transmission and engine to provide quick, powerful acceleration. This mode is suitable for when agile driving response is desired, such as when driving on roads with many curves.

When not in SPORT S mode, if the Driving Mode Select switch is turned away from you, the "Sport S" indicator comes on.

SPORT S+ mode

Helps to ensure steering performance and driving stability by simultaneously controlling the steering and suspension in addition to the transmission and engine.

Suitable for sportier driving.

When in SPORT S mode, if the Driving Mode Select switch is turned away from you, the "Sport S+" indicator comes on.

### Operation of the air conditioning system in Eco drive mode

Eco drive mode controls the heating/cooling operations and fan speed of the air conditioning system to enhance fuel efficiency. To improve air conditioning performance, perform the following operations:

- Turn off eco air conditioning mode (→P.255)
- $lue{}$  Adjust the fan speed (ightarrowP.254)
- $lue{Turn}$  off Eco drive mode ( $\rightarrow$ P.202)

### Automatic deactivation of sport mode and custom mode (if equipped)

If the engine switch is turned off after driving in sport mode or custom mode, the drive mode will be changed to normal mode.

## Driving mode pop-up display (12.3-inch display model)

When the driving mode is changed, the selected driving mode will be temporarily displayed on the side display. (→P.247)

## Customization (vehicles with Adaptive Variable Suspension system)

Settings (e.g. custom mode) can be changed.

(Customizable features:  $\rightarrow$ P.400)

### PKSA (Parking Support Alert)<sup>\*</sup>

### \*: If equipped

The Parking Support Alert system consists of the following functions that operate when driving at a low speed or backing up, such as when parking. When the system determines that the possibility of a collision with a detected object, such as a wall, or pedestrian is high, a warning operates to urge the driver to take evasive action.

# PKSA (Parking Support Alert) system

### ■ Intuitive parking assist

Ultrasonic sensors are used to detect static objects in the detection area when driving at a low speed or backing up.  $(\rightarrow P.205)$ 

# ■ RCTA (Rear Cross Traffic Alert) function (if equipped)

Rear side radar sensors are used to detect approaching vehicles in the detection areas behind the vehicle when backing up.  $(\rightarrow P.211)$ 

# ■ RCD (Rear Camera Detection) function (if equipped)

A rear camera sensor is used to detect pedestrians in the detection area behind the vehicle when backing up.  $(\rightarrow P.215)$ 

### Setting the buzzer volume

### Adjusting the buzzer volume

The buzzer volume can be adjusted on the multi-information display. The volume of buzzers for the intuitive parking assist, RCTA function and RCD function will be adjusted simultaneously.

Use the meter control switches to change settings.  $(\rightarrow P.72)$ 

- 1 Press < or > to select .
- 2 Press or to select "PKSA" and then press "OK".
- 3 Press or to select and then press "OK".

Each time the switch is pressed, the volume level will change between 1, 2, and 3.

### ■ Muting a buzzer temporarily

A mute button will be displayed on the multi-information display when an object or pedestrian is detected. To mute the buzzer, press "OK".

The buzzers for the intuitive parking assist, RCTA function and RCD function will be muted simultaneously.

Mute will be automatically canceled in the following situations:

- When the shift position is changed.
- When there is a malfunction in a sensor or the system is temporarily unavailable.
- When the function is disabled while it is operating.
- When the engine switch is turned off.


### Intuitive parking assist\*

### \*: If equipped

The distance from your vehicle to objects, such as a wall, when parallel parking or maneuvering into a garage is measured by the sensors and communicated via the multi-information display, head-up display (if equipped), Center Display and a buzzer. Always check the surrounding area when using this system.

### System components

### ■ Types of sensors



- A Front corner sensors
- **B** Front center sensors
- C Rear corner sensors
- **D** Rear center sensors

### ■ Display

When the sensors detect an object, such as a wall, a graphic is shown on the multi-information display, head-up display (if equipped) and Center Display depending on the position and distance to the object.

 Multi-information display and headup display




- A Front corner sensor detection
- **B** Front center sensor detection
- C Rear corner sensor detection
- D Rear center sensor detection
- Center Display

A graphic is shown when the Lexus parking assist monitor (if equipped) is displayed.

A simplified image is displayed on the Center Display when an object is detected.


• When the shift lever is in R



 When the shift lever is in N, S or D (vehicle moving forward)



When an object is detected, a graphic will be displayed on the panoramic view monitor (if equipped).



# Turning intuitive parking assist on/off

Use the meter control switches to enable/disable the Lexus parking assist-sensor.  $(\rightarrow P.72)$ 

- 1 Press ≺ or ➤ to select ⑳.
- 2 Press or to select "PKSA" and then press "OK".
- 3 Press or to select and then press "OK".

When the intuitive parking assist function is disabled, the intuitive parking assist OFF indicator ( $\rightarrow$ P.62) illuminates on the multi-information display.

To re-enable the system, select on the multi-information display, select

and turn it on. If the system is disabled, it will remain off even if the engine switch is turned to IGNTION ON mode after the engine switch has been turned off.

### A

### **WARNING**

### ■ When using the intuitive parking assist

Observe the following precautions. Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 6 mph (10 km/h).
- The sensors' detection areas and reaction times are limited. When moving forward or reversing, check the areas surrounding the vehicle (especially the sides of the vehicle) for safety, and drive slowly, using the brake to control the vehicle's speed.
- Do not install accessories within the sensors' detection areas.
- The area directly under the bumpers is not detected.

### ■ When to disable the function

In the following situations, disable the function as it may operate even though there is no possibility of a collision.

- The vehicle is equipped with a fender pole or wireless antenna.
- The front or rear bumper or a sensor receives a strong impact.
- A non-genuine Lexus suspension (lowered suspension, etc.) is installed.
- Towing eyelet is installed. (vehicles with a towing eyelet)
- A backlit license plate is installed.

### ■ When using intuitive parking assist

In the following situations, the system may not function correctly due to a sensor malfunction, etc. Have the vehicle checked by your Lexus dealer.

- The intuitive parking assist operation display flashes or shows continuously, and a buzzer sounds when no objects are detected.
- If the area around a sensor collides with something, or is subjected to strong impact.
- If the bumper or grille collides with something.
- If the display flashes or is displayed continuously and a buzzer does not sound, except when the mute function has been turned on.
- If a display error occurs, first check the sensor.

If the error occurs even when there is no ice, snow or mud on the sensor, it is likely that the sensor is malfunctioning.

### ■ Notes when washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area.

Doing so may result in the sensor malfunctioning.

- When using a high pressure washer to wash the vehicle, do not spray the sensors directly, as doing so may cause a sensor to malfunction.
- When using steam to clean the vehicle, do not direct steam too close to the sensors as doing so may cause a sensor to malfunction.

### ■ The system can be operated when

- The engine switch is in IGNITION ON mode.
- Intuitive parking assist function is on.
- The vehicle speed is less than about 6 mph (10 km/h).

 A shift lever is shifted to a position other than P.

### ■ Setting the buzzer volume

The buzzer volume can be adjusted on the multi-information display.  $(\rightarrow P.205)$ 

### If "Parking Assist Unavailable Clean Parking Assist Sensor" is displayed on the multi-information display

A sensor may be covered with ice, snow, dirt, etc. Remove the ice, snow, dirt, etc., from the sensor to return the system to normal.

Also, due to ice forming on a sensor at low temperatures, a warning message may be displayed or the sensor may not be able to detect an object. Once the ice melts, the system will return to normal.

### ■ Sensor detection information

- The sensor's detection areas are limited to the areas around the vehicle's front and rear bumpers.
- The following situations may occur during use.
- Depending on the shape of the object and other factors, the detection distance may shorten, or detection may be impossible.
- There will be a short delay between object detection and display. Even at low speeds, there is a possibility that the object will come within the sensor's detection areas before the display is shown and the warning beep sounds.
- It might be difficult to hear the buzzer due to the volume of the audio system or air flow noise of the air conditioning system.

## ■ Conditions under which the function may not function correctly

Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect objects. Particular instances where this may occur are listed below.

- There is dirt, snow or ice on a sensor. (Cleaning the sensors will resolve this problem.)
- A sensor is frozen. (Thawing the area will resolve this problem.)
   In especially cold weather, if a sensor is

frozen the sensor display may be displayed abnormally, or objects, such as a wall, may not be detected.

- A sensor is covered in any way.
- When a sensor or the area around a sensor is extremely hot or cold.
- On an extremely bumpy road, on an incline, on gravel, or on grass.
- The vicinity of the vehicle is noisy due to vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves.
- There is another vehicle equipped with parking assist sensors in the vicinity.
- A sensor is coated with a sheet of spray or heavy rain.
- If a sensor is hit by a large amount of water, such as when driving on a flooded road.
- If the vehicle is significantly tilted.
- The vehicle is approaching a tall or curved curb.
- If objects draw too close to the sensor.

### Objects which may not be properly detected


The shape of the object may prevent the sensor from detecting it. Pay particular attention to the following objects:

- Wires, fences, ropes, etc.
- Cotton, snow and other materials that absorb sound waves
- Sharply-angled objects
- Low objects
- Tall objects with upper sections projecting outwards in the direction of your vehicle

People may not be detected if they are wearing certain types of clothing.

# Sensor detection display, object distance

### ■ Detection range of the sensors



- Approximately 3.3 ft. (100 cm)
- **B** Approximately 4.9 ft. (150 cm)
- C Approximately 2.1 ft. (65 cm)

The diagram shows the detection range of the sensors. Note that the sensors cannot detect objects that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object, etc.

### ■ Multi-information display, head-up display (if equipped) and Center Display

When an object is detected by a sensor, the approximate distance to the object will be displayed on the multi-information display, Center Display, and head-up display (if equipped). (As the distance to the object becomes short, the distance segments may blink.)

Approximate distance to object: 4.9 ft. (150 cm) to 2.1 ft. (65 cm)\* (Rear center sensor)

Multi-information display	Center Display	Head-up display

- \*: Automatic buzzer mute function is enabled.  $(\rightarrow P.211)$
- Approximate distance to object: 3.3 ft. (100 cm) to 2.1 ft. (65 cm)\* (Front center sensor)

Multi-information display	Center Display	Head-up display
		(Cer vill)

- \*: Automatic buzzer mute function is enabled.  $(\rightarrow P.211)$
- Approximate distance to object: 2.1 ft. (65 cm) to 1.5 ft. (45 cm)

Multi-information display	Center Display	Head-up display
	8	<b>ā</b> ₃

- \*: Automatic buzzer mute function is enabled.  $(\rightarrow P.211)$
- Approximate distance to object: 1.5 ft. (45 cm) to 1.0 ft. (30 cm)

Multi-information display	Center Display	Head-up display

- \*: Automatic buzzer mute function is enabled.  $(\rightarrow P.211)$
- Approximate distance to object: 1.0 ft. (30 cm) to 0.5 ft. (15 cm)\*1

Multi-information display*2	Center Display*2	Head-up display

<sup>\*1:</sup> Automatic buzzer mute function is disabled.  $(\rightarrow P.211)$ 

Approximate distance to object: Less than 0.5 ft. (15 cm)<sup>\*1</sup>

Multi-information display*2	Center Display*2	Head-up display
	8	* <u>E</u>

<sup>\*1:</sup> Automatic buzzer mute function is disabled.  $(\rightarrow P.211)$ 

 $<sup>^{*2}</sup>$ : The distance segments will blink slowly.

 $<sup>^{*2}</sup>$ : The distance segments will blink rapidly.

### Buzzer operation and distance to an object

A buzzer sounds when the sensors are operating.

 The buzzer beeps faster as the vehicle approaches an object. When the vehicle comes within the following distance of the object, the buzzer sounds continuously:

Approximately 1.0 ft. (30 cm)

- When 2 or more objects are detected simultaneously, the buzzer sounds for the nearest object. If one or more objects come within approximately 1.0 ft. (30 cm) of the vehicle, the buzzer will repeat a long tone, followed by fast beeps.
- Automatic buzzer mute function:
   After a buzzer begins sounding, if the distance between the vehicle and the detected object does not become shorter, the buzzer will be muted automatically. (However, if the distance between the vehicle and object is 1.0 ft. (30 cm) or less, this function will not operate.)


The buzzer sounds volume can be adjusted.  $(\rightarrow P.205)$ 

# RCTA (Rear cross traffic alert) function\*

\*: If equipped

The RCTA function uses the BSM rear side radar sensors installed on the inner side of the rear bumper. This function is intended to assist the driver in checking areas that are not easily visible when backing up.

### System components



A Meter control switches
Turn the RCTA function on/off.
When the RCTA function is disabled, the
RCTA OFF indicator illuminates.

B Outside rear view mirror indicators
When a vehicle approaching from the right
or left at the rear of the vehicle is detected,
both outside rear view mirror indicators

will flash.

### C Center Display

If a vehicle approaching from the right or left at the rear of the vehicle is detected. the RCTA icon  $(\rightarrow P.213)$  for the detected side will be displayed on the Center Display. This illustration shows an example of a vehicle approaching from both sides of the vehicle.

### **D** RCTA buzzer

If a vehicle approaching from the right or left at the rear of the vehicle is detected, a buzzer will sound.

### Turning the RCTA function on/off

Use the meter control switches to enable/disable the RCTA function.  $(\rightarrow P.72)$ 

- Press < or > to select .
- 2 Press ▲ or ▼ to select "PKSA" and then press "OK".
- **3** Press **∧** or **∨** to select "RCTA" and then press "OK".

When the RCTA function is disabled, the RCTA OFF indicator  $(\rightarrow P.62)$  illuminates on the multi-information display. (Each time the engine switch is turned off then changed to IGNITION ON mode, the RCTA function will be enabled automatically.)

### **WARNING**

### Cautions regarding the use of the function

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The RCTA function is only a supplementary function which alerts the driver that a vehicle is approaching from the right or left at the rear of the vehicle. As the RCTA function may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary. Over reliance on this function may lead to an accident resulting death or serious injury.

### Outside rear view mirror indicator visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

### ■ Hearing the RCTA buzzer

The RCTA buzzer may be difficult to hear over loud noises, such as if the audio system volume is high.

### ■ When "Rear Cross Traffic Alert Unavailable" is shown on the multiinformation display

Ice, snow, mud, etc., may be attached to the rear bumper around the sensors.  $(\rightarrow P.199)$ Remove the ice, snow, mud, etc., attached to the rear bumper around the sensors to return the function to normal. Additionally, the sensors may not operate normally when driving in extremely hot or cold environments.


#### ■ Rear side radar sensors

 $\rightarrow$ P.199

### RCTA function

### ■ Operation of the RCTA function

The RCTA function uses rear side radar sensors to detect vehicles approaching from the right or left at the rear of the vehicle and alerts the driver of the presence of such vehicles by flashing the outside rear view mirror indicators and sounding a buzzer.



- A Approaching vehicles
- **B** Detection areas of approaching vehicles

### ■ RCTA icon display


When a vehicle approaching from the right or left at the rear of the vehicle is detected, the following will be displayed on the Center Display.

Example (Lexus parking assist monitor) (if equipped): Vehicles are approaching from both sides of the vehicle



### ■ RCTA function detection areas

The areas that vehicles can be detected in are outlined below.



The buzzer can alert the driver of faster vehicles approaching from farther away.

Example:

Approaching vehi- cle speed	A Approximate alert distance
18 mph (28 km/h) (fast)	65 ft. (20 m)
5 mph (8 km/h) (slow)	18 ft. (5.5 m)

### ■ The RCTA function is operational when

The RCTA function operates when all of the following conditions are met:

- The engine switch is in IGNITION ON mode.
- The RCTA function is on.
- The shift lever is in R.
- The vehicle speed is less than approximately 5 mph (8 km/h).
- The approaching vehicle speed is between approximately 5 mph (8 km/h) and 18 mph (28 km/h).


### ■ Setting the buzzer volume

The buzzer volume can be adjusted on the multi-information display.  $(\rightarrow P.205)$ 

### ■ Conditions under which the RCTA function will not detect a vehicle


The RCTA function is not designed to detect the following types of vehicles and/or objects:

- Vehicles approaching from directly behind
- Vehicles backing up in a parking space next to your vehicle
- Vehicles that the sensors cannot detect due to obstructions




- Guardrails, walls, signs, parked vehicles and similar stationary objects
- Small motorcycles, bicycles, pedestrians, etc.
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle\*
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

- Conditions under which the RCTA function may not function correctly
- The RCTA function may not detect vehicles correctly in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When driving on a road surface that is wet with standing water during bad weather, such as heavy rain, snow, or fog
- When multiple vehicles are approaching with only a small gap between each vehicle
- If a vehicle is approaching the rear of your vehicle rapidly
- When a towing eyelet is installed to the rear of the vehicle.
- When backing up on a slope with a sharp change in grade




When backing out of a shallow angle parking spot




- Immediately after the RCTA function is turned on
- Immediately after the engine is started

- with the RCTA function on
- When the sensors cannot detect a vehicle due to obstructions



- Instances of the RCTA function unnecessarily detecting a vehicle and/or object may increase in the following situations:
- When a vehicle passes by the side of your vehicle
- When the parking space faces a street and vehicles are being driven on the street




- When the distance between your vehicle and metal objects, such as a guardrail, wall, sign, or parked vehicle, which may reflect electrical waves toward the rear of the vehicle, is short
- When a towing eyelet is installed to the rear of the vehicle

# RCD (Rear Camera Detection) function \*

### \*: If equipped

When the vehicle is backing up, the rear camera detection function can detect pedestrians in the detection area behind the vehicle. If a pedestrian is detected, a buzzer will sound and an icon will be displayed on the Center Display to inform the driver of the pedestrian.

### Center Display



A Pedestrian detection icon

Displayed automatically when a pedestrian is detected.

### **B** RCD OFF icon

When the RCD function is disabled, the RCD OFF icon illuminates. (Each time the engine switch is turned off then changed to IGNITION ON mode, the RCD function will be enabled automatically.)

### Turning the RCD function on/off


Use the meter control switches to enable/disable the RCD function.  $(\rightarrow P.72)$ 

- 1 Press < or > to select .
- 2 Press or to select "PKSA" and then press "OK".
- 3 Press or to select "RCD" and then press "OK".

When the RCD function is disabled, the RCD OFF indicator  $(\rightarrow P.62)$  illuminates on the multi-information display.

### When a pedestrian is detected

If the rear camera detection function detects a pedestrian in the detection area, the buzzer and pedestrian detection will operate as follows:



A If a pedestrian is detected in area

Α

Buzzer: Sounds repeatedly Pedestrian detection icon: Blinks 3 times and then stays on

**B** If a pedestrian is detected in area

В

Buzzer (When the vehicle is stationary): Sounds 3 times
Buzzer (When the vehicle is back-

ing up, when a pedestrian approaches the rear of the vehicle): Sounds repeatedly Pedestrian detection icon: Blinks 3 times and then stays on

C If the system determines that your vehicle may collide with a pedes-

trian in area C

Buzzer: Sounds repeatedly Pedestrian detection icon: Blinks 3 times and then stays on

- The rear camera detection function is operational when
- The engine switch is in IGNITION ON mode.
- RCD function is on.
- The shift lever is in R.
- Setting the buzzer volume

The buzzer volume can be adjusted on the multi-information display.  $(\rightarrow P.205)$ 

■ If "Rear Camera Detection Unavailable Remove the Dirt of Rear Camera" is displayed on the multi-information display

A rear camera lens may be dirty or covered with snow or ice. In such cases, if it is removed from the rear camera lens, the system should return to normal. (It may be necessary to drive the vehicle for some time before the system returns to normal.)

- If "Rear Camera Detection Unavailable" is displayed on the multi-information display
- If this message is displayed after the battery has been disconnected and reconnected, fully turn the steering wheel to the left and then the right on level ground.
- If this message is displayed only when the shift lever is in R, the rear camera lens may be dirty. Clean the rear camera lens.
- Situations in which the system may not operate properly
- Some pedestrians, such as the following, may not be detected by the rear camera

- detection function, preventing the function from operating properly:
- Pedestrians who are bending forward or squatting
- Pedestrians who are lying down
- Pedestrians who are running
- Pedestrians who suddenly enter the detection area
- People riding a bicycle, skateboard, or other light vehicle
- Pedestrians wearing oversized clothing such as a rain coat, long skirt, etc., making their silhouette obscure
- Pedestrians whose body is partially hidden by an object, such as a cart or umbrella
- Pedestrians which are obscured by darkness, such as at night
- In some situations, such as the following, pedestrians may not be detected by the rear camera detection function, preventing the function from operating properly:
- When backing up in inclement weather (rain, snow, fog, etc.)
- When the rear camera is obscured (dirt, snow, ice, etc. are attached) or scratched
- When a very bright light, such as the sun, or the headlights of another vehicle, shines directly into the rear camera
- When backing up in a place where the surrounding brightness changes suddenly, such as at the entrance or exit of a garage or underground parking lot
- When backing up in a dim environment such as during dusk or in an underground parking lot
- Even though there are no pedestrians in the detection area, some objects, such as the following, may be detected, possibly causing the rear camera detection function to operate.
- Three dimensional objects, such as a pole, traffic cone, fence, or parked vehicle
- Moving objects, such as a car or motorcycle
- Objects moving toward your vehicle when backing up, such as flags or puddles (or airborne matter, such as smoke, steam, rain, or snow)
- Cobblestone or gravel roads, tram rails, road repairs, white lines, pedestrian crossings or fallen leaves on the road

- Metal covers (gratings), such as those used for drainage ditches
- Objects reflected in a puddle or on a wet road surface
- The roadside or bumps on the road
- Shadows on the road
- In some situations, such as the following, the rear camera detection function may operate even though there are no pedestrians in the detection area.
- When backing up toward the roadside or a bump on the road
- If the vehicle is significantly tilted, such as when carrying a heavy load
- When backing up toward an incline/decline
- If the suspension has been modified or tires of a size other than specified are installed
- If the rear of the vehicle is raised or lowered due to the carried load
- If an electronic component, such as a backlit license plate is installed near the rear camera
- If a bumper protector, such as an additional trim strip, is installed to the rear bumper
- If the orientation of the rear camera has been changed due to a collision or other impact, or removal and installation
- If a towing eyelet is installed to the rear of the vehicle
- When water is flowing over the rear camera lens
- When the rear camera is obscured (dirt, snow, ice, etc. are attached) or scratched
- If there is a flashing light in the detection area, such as the emergency flashers of another vehicle
- Situations in which the rear camera detection function may be difficult to notice
- The buzzer may be difficult to hear if the surrounding area is noisy, the volume of the audio system volume is high, the air conditioning system is being used, etc.
- If the temperature in the cabin is extremely high or low, the Center Display may not operate correctly.

# PKSB (Parking Support Brake)\*

### \*: If equipped

The Parking Support Brake system consists of the following functions that operate when driving at a low speed or backing up, such as when parking. When the system determines that the possibility of a collision with a detected object or pedestrian is high, a warning operates to urge the driver to take evasive action. If the system determines that the possibility of a collision with a detected object or pedestrian is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

# PKSB (Parking Support Brake) system

## ■ Parking Support Brake function (static objects)

Ultrasonic sensors are used to detect static objects, such as a wall, in the detection area when driving at a low speed or backing up. (→P.224)

### Parking Support Brake function (rear-crossing vehicles) (if equipped)

Rear radar sensors are used to detect approaching vehicles in the detection area behind the vehicle when backing up. (→P.229)

### Parking Support Brake function (rear pedestrians) (if equipped)

A rear camera sensor is used to detect pedestrians in the detection area behind the vehicle when backing up. ( $\rightarrow$ P.233)

### $\Lambda$

#### WARNING

### ■ Limitations of the Parking Support Brake system

Do not overly rely on the system, as doing so may lead to an accident.

- The driver is solely responsible for safe driving. Always drive carefully, taking care to observe your surroundings. The Parking Support Brake system is designed to provide support to lessen the severity of collisions. However, it may not operate in some situations.
- The Parking Support Brake system is not designed to stop the vehicle completely. Additionally, even if the system has stopped the vehicle, it is necessary to depress the brake pedal immediately as brake control will be canceled after approximately 2 seconds.



#### **NOTICE**

If "Parking Support Brake Unavailable" is displayed on the multi-information display and the PKSB OFF indicator is flashing

If this message is displayed immediately after the engine switch is changed to IGNITION ON mode, operate the vehicle carefully, paying attention to your surroundings. It may be necessary to drive the vehicle for a certain amount of time before the system returns to normal. (If the system is not return to normal after driving for a while, clean the rear camera lens.)

# Enabling/Disabling the Parking Support Brake

The Parking Support Brake can be enabled/disabled on the multi-information display. All of the Parking Support Brake functions (static objects, rearcrossing vehicles, and rear pedestrians) are enabled/disabled simultaneously.

Use the meter control switches to enable/disable the parking support brake.  $(\rightarrow P.72)$ 

- 1 Press < or > to select 🕸.
- 2 Press or to select and then press "OK".

When the Parking Support Brake is disabled, the PKSB OFF indicator (→P.62) illuminates on the multi-information display.

To re-enable the system, select on the multi-information display, select and turn it on. If the system is disabled, it will remain off even if the engine switch is turned to IGNTION ON mode after the engine switch has been turned off.

# Displays and buzzers for engine output restriction control and brake control

If the engine output restriction control or brake control operates, a buzzer will sound and a message will be displayed on the Center Display and multi-information display, to alert the driver. On vehicles with a head-up display, the head-up display will display the same message as the multi-information display.

Depending on the situation, engine output

restriction control will operate to either limit acceleration or restrict output as much as possible.

 Engine output restriction control is operating (acceleration restriction)

Acceleration greater than a certain amount is restricted by the system.

Center Display (Panoramic view monitor): No warning displayed

Multi-information display: "Object Detected Acceleration Reduced"

PKSB OFF indicator: Not illuminated

Buzzer: Does not sound

 Engine output restriction control is operating (output restricted as much as possible)

The system has determined that strongerthan-normal brake operation is necessary.

Center Display (Panoramic view monitor): "BRAKE!"

Multi-information display: "BRAKE!"
PKSB OFF indicator: Not illuminated

Buzzer: Short beep

Brake control is operating

The system determined that emergency braking is necessary.

Center Display (Panoramic view monitor): "BRAKF!"

Multi-information display: "BRAKE!"

PKSB OFF indicator: Not illuminated

Buzzer: Short beep

Vehicle stopped by system operation

The vehicle has been stopped by brake control operation.

Center Display (Panoramic view monitor): "Press Brake Pedal"


Multi-information display: "Switch to Brake" (If the accelerator pedal is not depressed, "Press Brake Pedal" will be displayed.) PKSB OFF indicator: Illuminated

Buzzer: Short beep


### System overview

If the Parking Support Brake determines that a collision with a detected object or pedestrian is possible, the engine output will be restricted to restrain any increase in the vehicle speed. (Engine output restriction control: See figure 2 below.) Additionally, if the accelerator pedal continues to be depressed, the brakes will be applied automatically to reduce the vehicle speed. (Brake control: See figure 3 below.)


• Figure 1 When the PKSB (Parking Support Brake) is disabled



- A Engine output
- **B** Braking force
- **C** Time
- Figure 2 When engine output restriction control operates



- A Engine output
- **B** Braking force
- **C** Time
- **D** Engine output restriction control begins operating
- **E** System determines that possibility of collision with detected object is high
- F Engine output reduced
- **G** Example: Multi-information display: "BRAKE!"
- Figure 3 When brake control operates



- A Engine output
- **B** Braking force

- C Time
- **D** Engine output restriction control begins operating
- **E** System determines that possibility of collision with detected object is high
- F Engine output reduced
- G System determines that possibility of collision with detected object is extremely high
- H Brake control begins operating
- I Brake control strength increased
- I Example: Multi-information display: "BRAKE!"
- K Example: Multi-information display: "Switch to Brake"

### ■ If the Parking Support Brake has operated

If the vehicle is stopped due to operation of the Parking Support Brake, the Parking Support Brake will be disabled and the PKSB OFF indicator will illuminate. If the Parking Support Brake operates unnecessarily, brake control can be canceled by depressing the brake pedal or waiting for approximately 2 seconds for it to automatically be canceled. Then, the vehicle can be operated by depressing the accelerator pedal.

### ■ Re-enabling the Parking Support Brake

To re-enable the Parking Support Brake when it is disabled due to operation of the Parking Support Brake, either enable the system again (\$\iightarrow\$P.219), or turn the engine switch off and then back to IGNITION ON mode. Additionally, if the object becomes no longer in the traveling direction of the vehicle or if the traveling direction of the vehicle changes (such as changing from moving forward to backing up, or from backing up to moving forward), the system will be re-enabled automatically.

### If "Parking Support Brake Unavailable" is displayed on the multi-information display and the PKSB OFF indicator is flashing

If the vehicle is stopped due to operation of the Parking Support Brake, the Parking Support Brake will be disabled and the PKSB OFF indicator will illuminate.

- A sensor may be covered with ice, snow, dirt, etc. Remove the ice, snow, dirt, etc., from the sensor to return the system to normal.
  - Also, due to ice forming on a sensor at low temperatures, a warning message may be displayed or the sensor may not be able to detect an object. Once the ice melts, the system will return to normal.
- If this message is displayed only when the shift lever is in R, the rear camera lens may be dirty. Clean the camera lens. If this message is displayed when the shift lever is in any position other than R, a sensor on the front or rear bumper may be dirty. Clean the sensors and their surrounding area on the bumpers.
- If this message continues to be displayed even after cleaning the sensor, or is displayed even though the sensor is clean, have the vehicle inspected by your Lexus dealer.
- Initialization may not have been performed after a battery terminal was disconnected and reconnected. Initialize the system. (→P.223)

If this message continues to be displayed even after initialization, have the vehicle inspected by your Lexus dealer.

### ■ If a battery terminal has been disconnected and reconnected

The system needs to be initialized. To initialize the system, drive the vehicle straight ahead for 5 seconds or more at a speed of approximately 22 mph (35 km/h) or more. Additionally, for vehicles with the Parking Support Brake function, turn the steering wheel fully to the left and right with the vehicle stopped.

### Parking Support Brake function (static objects)\*


### \*: If equipped

If the sensors detect a static object, such as a wall, in the traveling direction of the vehicle and the system determines that a collision may occur due to the vehicle suddenly moving forward due to an accidental accelerator pedal operation, the vehicle moving the unintended direction due to the wrong shift position being selected, or while parking or traveling at low speeds, the system will operate to lessen the impact with the detected static object and reduce the resulting damage.


### Examples of function operation

This function will operate in situations such as the following if an object is detected in the traveling direction of the vehicle.


When traveling at a low speed and the brake pedal is not depressed, or is depressed late



### ■ When the accelerator pedal is depressed excessively



■ When the vehicle moves in the unintended direction due to the wrong shift position being selected



### Types of sensors

 $\rightarrow$ P.205



### WARNING

■ To ensure the Parking Support Brake can operate properly

Observe the following precautions regarding the sensors (\$\rightarrow\$P.205). Failure to do so may cause a sensor to not operate properly, and may cause an accident.

- Do not modify, disassemble or paint the sensors.
- Do not replace a sensor with a part other than a genuine part.
- Do not subject a sensor or its surrounding area to a strong impact.
- Do not damage the sensors, and always keep them clean.

### A

#### WARNING

 If the area around a radar sensor is subjected to an impact, the system may not operate properly due to a sensor malfunction. Have the vehicle inspected by your Lexus dealer.

### Handling the suspension

Do not modify the suspension, as changes to the height or inclination of the vehicle may prevent the sensors from detecting objects correctly or cause the system to not operate or operate unnecessarily.

### If the Parking Support Brake function (static objects) operates unnecessarily, such as at a railroad crossing

In the event that the Parking Support Brake function (static objects) operates unnecessarily, such as at a railroad crossing, brake control will be canceled after approximately 2 seconds, allowing you to proceed forward and leave the area, brake control can also be canceled by depressing the brake pedal. Depressing the accelerator pedal after brake control is canceled will allow you to proceed forward and leave the area.

### ■ Notes when washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area.

Doing so may result in the sensor malfunctioning.

- When using a high pressure washer to wash the vehicle, do not spray the sensors directly, as doing so may cause a sensor to malfunction.
- When using steam to clean the vehicle, do not direct steam too close to the sensors as doing so may cause a sensor to malfunction.

### ■ When to disable the Parking Support Brake

In the following situations, disable the Parking Support Brake as the system may operate even though there is no possibility of a collision.

- When inspecting the vehicle using a chassis roller, chassis dynamo or free roller
- When loading the vehicle onto a boat, truck or other transport vessel
- If the suspension has been modified or tires of a size other than specified are installed
- If the front of the vehicle is raised or lowered due to the carried load
- When equipment that may obstruct a sensor is installed, such as a towing eyelet (if equipped) bumper protector (an additional trim strip, etc.), bicycle carrier, or snow plow
- When using an automatic car wash

### ■ The Parking Support Brake function (static object) will operate when

The function will operate when the PKSB OFF indicator is not illuminated or flashing  $(\rightarrow P.61, 62)$  and all of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is 9 mph (15 km/h) or less.
- There is a static object in the traveling direction of the vehicle and 6 to 13 ft. (2 to 4 m) away.
- The Parking Support Brake determines that a stronger-than-normal brake operation is necessary to avoid a collision.
- Brake control
- Engine output restriction control is operating.
- The Parking Support Brake determines that an immediate brake operation is necessary to avoid a collision.

### ■ The Parking Support Brake function (static objects) will stop operating when

The function will stop operating if any of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is disabled.
- The system determines that the collision

has become avoidable with normal brake operation.

- The static object is no longer 6 to 13 ft. (2 to 4 m) away from the vehicle or in the traveling direction of the vehicle.
- Brake control
- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake control.
- The brake pedal is depressed after the vehicle is stopped by brake control.
- The static object is no longer 6 to 13 ft. (2 to 4 m) away from the vehicle or in the traveling direction of the vehicle.

### Detection range of the Parking Support Brake function (static objects)

The detection range of the Parking Support Brake function (static objects) differs from the detection range of the intuitive parking assist. (→P.209) Therefore, even if the intuitive parking assist detects an object and provides a warning, the Parking Support Brake function (static objects) may not start operating.

### Objects that the Parking Support Brake function (static objects) may not detect

The sensors may not be able to detect certain objects, such as the following:

- Pedestrian
- Cotton cloth, snow, and other materials that are poor reflectors of ultrasonic waves
- Objects which are not perpendicular to the ground, are not perpendicular to the traveling direction of the vehicle, are uneven or are waving
- Low objects
- Thin objects such as wires, fences, ropes and signposts
- Objects that are extremely close to the bumper

### Intuitive parking assist buzzer


Regardless of whether the intuitive parking assist system is enabled or not ( $\rightarrow$ P.206), if the Parking Support Brake function (static objects) is enabled ( $\rightarrow$ P.219), the front or rear sensors detect an object and brake

control is performed, the intuitive parking assist buzzer will sound to notify the driver of the approximate distance to the object.


Situations in which the Parking Support Brake function (static objects) may operate even if there is no possibility of a collision

In some situations, such as the following, the Parking Support Brake function (static objects) may operate even though there is no possibility of a collision.

- Vehicle surroundings
- When driving on a narrow road



When driving on a gravel road or in an area with tall grass




- When driving toward a banner, flag, lowhanging branch or boom barrier (such as those used at railroad crossings, toll gates and parking lots)
- When driving on a narrow path surrounded by a structure, such as in a tunnel or on an iron bridge
- When parallel parking
- When there is a rut or hole in the surface of the road
- When driving on a metal cover (grating), such as those used for drainage ditches
- When driving on a steep slope
- If a sensor is hit by a large amount of water, such as when driving on a flooded road
- Weather
- · If a sensor is covered with ice, snow, dirt,

etc. (when cleared, the system will return to normal)


- If heavy rain or water strikes a sensor
- When driving in inclement weather such as fog, snow or a sandstorm
- Other ultrasonic wave sources
- When vehicle horns, vehicle detectors, motorcycle engines, air brakes of large vehicles, the clearance sonar of other vehicles or other devices which produce ultrasonic waves are near the vehicle
- If a sticker or an electronic component, such as a backlit license plate (especially fluorescent type), fog lights, fender pole or wireless antenna is installed near a sensor
- Changes in the vehicle posture
- If the vehicle is significantly tilted
- If the front of the vehicle is raised or lowered due to the carried load
- If the orientation of a sensor has been changed due to a collision or other impact
- Situations in which the Parking Support Brake function (static objects) may not operate properly

In some situations, such as the following, this function may not operate properly.

- Weather
- When a sensor or the area around a sensor is extremely hot or cold



· When strong winds are blowing



If a sensor is covered with ice, snow, dirt,

- etc. (when cleared, the system will return to normal)
- If heavy rain or water strikes a sensor
- When driving in inclement weather such as fog, snow or a sandstorm
- Vehicle surroundings
- When an object that cannot be detected is between the vehicle and a detected object
- If an object such as a vehicle, motorcycle, bicycle or pedestrian cuts in front of the vehicle or runs out from the side of the vehicle
- Other ultrasonic waves sources
- When vehicle horns, vehicle detectors, motorcycle engines, air brakes of large vehicles, the clearance sonar of other vehicles or other devices which produce ultrasonic waves are near the vehicle
- If a sticker or an electronic component, such as a backlit license plate (especially fluorescent type), fog lights, fender pole or wireless antenna is installed near a sensor
- Changes in the vehicle posture
- · If the vehicle is significantly tilted
- If the front of the vehicle is raised or lowered due to the carried load
- If the orientation of a sensor has been changed due to a collision or other impact

### Parking Support Brake function (rear-crossing vehicles)\*


### \*: If equipped

If a rear radar sensor detects a vehicle approaching from the right or left at the rear of the vehicle and the system determines that the possibility of a collision is high, this function will perform brake control to reduce the likelihood of an impact with the approaching vehicle.

### Examples of function operation

This function will operate in situations such as the following if a vehicle is detected in the traveling direction of the vehicle.

■ When reversing, a vehicle is approaching and the brake pedal is not depressed, or is depressed late



### Types of sensors

 $\rightarrow$ P.198



### WARNING

 To ensure the Parking Support Brake (rear-crossing vehicles) can operate properly

Observe the following precautions regarding the rear radar sensors (→P.198). Failure to do so may cause a sensor to not operate properly, and may cause an accident

- Do not modify, disassemble or paint the sensors.
- Do not replace a rear radar sensor with a part other than a genuine part.
- Do not damage the rear radar sensors, and always keep the radar sensors and their surrounding area on the bumper clean.

### A

#### WARNING

- If the area around a rear radar sensor is subjected to an impact, the system may not operate properly due to a sensor malfunction. Have the vehicle inspected by your Lexus dealer.
- Observe the rear radar sensor handling precautions. (→P.198)

### ■ The Parking Support Brake function (rear-crossing vehicles) will operate when

The function will operate when the PKSB OFF indicator is not illuminated or flashing  $(\rightarrow P.61, 62)$  and all of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is 9 mph (15 km/h) or less.
- Vehicles are approaching from the right or left at the rear of the vehicle at a traveling speed of less than approximately 5 mph (8 km/h)
- The shift lever is in R.
- The Parking Support Brake determines that a stronger than normal brake operation is necessary to avoid a collision with an approaching vehicle.
- Brake control
- Engine output restriction control is operating.
- The Parking Support Brake determines that an emergency brake operation is necessary to avoid a collision with an approaching vehicle.
- The Parking Support Brake function (rear-crossing vehicles) will stop operating when

The function will stop operating if any of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is disabled.
- The collision becomes avoidable with normal brake operation.
- A vehicle is no longer approaching from the right or left at the rear of the vehicle.
- Brake control


- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake control.
- The brake pedal is depressed after the vehicle is stopped by brake control.
- A vehicle is no longer approaching from the right or left at the rear of the vehicle.
- Detection area of the Parking Support Brake function (rear-crossing vehicles)

The detection area of the Parking Support Brake function (rear-crossing vehicles) differs from the detection area of the RCTA function (→P.213). Therefore, even if the RCTA function detects a vehicle and provides an alert, the Parking Support Brake function (rear-crossing vehicles) may not start operating.

### Conditions under which the Parking Support Brake function (rear-crossing vehicles) will not detect a vehicle

The Parking Support Brake function (rearcrossing vehicles) is not designed to detect the following types of vehicles and/or objects:

- Vehicles approaching from directly behind
- Vehicles backing up in a parking space next to your vehicle
- Vehicles that the sensors cannot detect due to obstructions



- Vehicles which suddenly accelerate or decelerate near your vehicle
- Guardrails, walls, signs, parked vehicles and similar stationary objects\*
- Small motorcycles, bicycles, pedestrians, etc.\*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking

- spaces next to your vehicle
- Objects which are extremely close to a radar sensor
- Vehicles are approaching from the right or left at the rear of the vehicle at a traveling speed of less than approximately 5 mph (8 km/h)
- Vehicles are approaching from the right or left at the rear of the vehicle at a traveling speed of more than approximately 15 mph (24 km/h)
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.


#### ■ PKSB function buzzer

RCTA function buzzer Regardless of whether the RCTA function is enabled or not (→P.212), if the Parking Support Brake function is enabled and brake control is performed, a buzzer will sound to notify the driver.


 Situations in which the system may operate even though there is no possibility of a collision

In some situations such as the following, the Parking Support Brake function (rearcrossing vehicles) may operate even though there is no possibility of a collision.

 When the parking space faces a street and vehicles are being driven on the street




 When a detected vehicle turns while approaching the vehicle



When a vehicle passes by the side of your vehicle



When the distance between your vehicle and metal objects, such as a guardrail, wall, sign, or parked vehicle, which may reflect electrical waves toward the rear of the vehicle, is short




- When there are spinning objects near your vehicle such as the fan of an air conditioning unit
- When water is splashed or sprayed toward the rear bumper, such as from a sprinkler
- Situations in which the Parking Support Brake function (rear-crossing vehicles) may not operate properly

In some situations, such as the following, the radar sensors may not detect an object and this function may not operate properly


- Stationary objects
- When a sensor or the area around a sensor is extremely hot or cold
- If the rear bumper is covered with ice,

snow, dirt, etc.


- When it is raining heavily or water strikes the vehicle
- When the detection area of a radar sensor is obstructed by an adjacent vehicle
- If the vehicle is significantly tilted
- When equipment that may obstruct a sensor is installed, such as a towing eyelet, bumper protector (an additional trim strip, etc.), bicycle carrier, or snow plow
- If the suspension has been modified or tires of a size other than specified are installed
- If the front of the vehicle is raised or lowered due to the carried load
- If a sticker or an electronic component, such as a backlit license plate (especially fluorescent type), fog light, fender pole or wireless antenna is installed near a radar sensor
- If the orientation of a radar sensor has been changed
- When multiple vehicles are approaching with only a small gap between each vehicle
- If a vehicle is approaching the rear of your vehicle rapidly
- Situations in which the radar sensor may not detect a vehicle
- When a vehicle approaches from the right or left at the rear of the vehicle while you are turning while backing up
- When turning while backing up




 When backing out of a shallow angle parking spot



 When backing up on a slope with a sharp change in grade



• When a vehicle turns into the detection area




### Parking Support Brake function (rear pedestrians)

### \*: If equipped

If the rear camera sensor detects a pedestrian behind the vehicle while backing up and the system determines that the possibility of colliding with the detected pedestrian is high, a buzzer will sound. If the system determines that the possibility of colliding with the detected pedestrian is extremely high, the brakes will be applied automatically to help reduce the impact of the collision.


### Examples of system operation

When a pedestrian is detected behind the vehicle while backing up, the brake pedal is not depressed or is depressed late.



### Center Display

Displays a message to urge the driver to take evasive action when a pedestrian is detected in the detection area behind the vehicle. (A message will also be displayed on the multi-information display and head-up display (if equipped).)



A Pedestrian detection icon with brake reminder



#### WARNING

### If the Parking Support Brake function (rear pedestrians) operates unnecessarily

Depress the brake pedal immediately after the Parking Support Brake function (rear pedestrians) operates. (Operation of the function is canceled by depressing the brake pedal.)

### ■ Parking Support Brake function (rear pedestrians) will operate when

The function will operate when the PKSB OFF indicator is not illuminated or flashing ( $\rightarrow$ P.61, 62) and all of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is 9 mph (15 km/h) or less.
- The shift lever is in R.
- The rear camera sensor detects a pedestrian behind the vehicle while backing up and the system determines that the possibility of colliding with the detected pedestrian is high.
- Brake control
- Engine output restriction control is operating.
- The Parking Support Brake determines that an emergency brake operation is necessary to avoid a collision with a pedestrian.

### The Parking Support Brake function (rear pedestrians) will stop operating when

The function will stop operating if any of the following conditions are met:

- Engine output restriction control
- The Parking Support Brake is disabled.
- The collision becomes avoidable with normal brake operation.
- The pedestrian is no longer detected behind your vehicle.
- Brake control
- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake

control.

- The brake pedal is depressed after the vehicle is stopped by brake control.
- The pedestrian is no longer detected behind your vehicle.

### Detection area of the Parking Support Brake function (rear pedestrians)

The detection area of the Parking Support Brake function (rear pedestrians) differs from the detection area of the RCD function (→P.216). Therefore, even if the RCD function detects a pedestrian an alert, the Parking Support Brake function (rear pedestrians) may not start operating.

### ■ Situations in which the system may not operate properly

- Some pedestrians, such as the following, may not be detected by the Parking Support Brake function (rear pedestrians), preventing the function from operating properly:
- Pedestrians who are bending forward or squatting
- Pedestrians who are lying down
- Pedestrians who are running
- Pedestrians who suddenly enter the detection area
- People riding a bicycle, skateboard, or other light vehicle
- Pedestrians wearing oversized clothing such as a rain coat, long skirt, etc., making their silhouette obscure
- Pedestrians whose body is partially hidden by an object, such as a cart or umbrella
- Pedestrians which are obscured by darkness, such as at night
- In some situations, such as the following, pedestrians may not be detected by the Parking Support Brake function (rear pedestrians), preventing the function from operating properly:
- When backing up in inclement weather (rain, snow, fog, etc.)
- When the rear camera is obscured (dirt, snow, ice, etc. are attached) or scratched
- When a very bright light, such as the sun, or the headlights of another vehicle, shines directly into the rear camera
- When backing up in a place where the surrounding brightness changes suddenly, such as at the entrance or exit of a

- garage or underground parking lot
- When backing up in a dim environment such as during dusk or in an underground parking lot
- Even though there are no pedestrians in the detection area, some objects, such as the following, may be detected, possibly causing the Parking Support Brake function (rear pedestrians) to operate.
- Three dimensional objects, such as a pole, traffic cone, fence, or parked vehicle
- Moving objects, such as a car or motorcycle
- Öbjects moving toward your vehicle when backing up, such as flags or puddles (or airborne matter, such as smoke, steam, rain, or snow)
- Cobblestone or gravel roads, tram rails, road repairs, white lines, pedestrian crossings or fallen leaves on the road
- Metal covers (gratings), such as those used for drainage ditches
- Objects reflected in a puddle or on a wet road surface
- The roadside or bumps on the road
- Shadows on the road
- In some situations, such as the following, the Parking Support Brake function (rear pedestrians) may operate even though there are no pedestrians in the detection area.
- When backing up toward the roadside or a bump on the road
- If the vehicle is significantly tilted, such as when carrying a heavy load
- When backing up toward an incline/decline
- If the suspension has been modified or tires of a size other than specified are installed
- If the rear of the vehicle is raised or lowered due to the carried load
- If an electronic component, such as a backlit license plate or rear fog light, is installed near the rear camera
- If a bumper protector, such as an additional trim strip, is installed to the rear bumper
- If the orientation of the rear camera has been changed due to a collision or other impact, or removal and installation
- · If a towing eyelet is installed to the rear of

- the vehicle
- When water is flowing over the rear camera lens
- When the rear camera is obscured (dirt, snow, ice, etc. are attached) or scratched
- If there is a flashing light in the detection area, such as the emergency flashers of another vehicle

### **Driving assist systems**

To keep driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

# Summary of the driving assist systems

### ■ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

### ■ Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

### ■ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

### Enhanced VSC (Enhanced Vehicle Stability Control)

Provides cooperative control of the ABS, TRAC, VSC and EPS.

Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

### ■ Secondary Collision Brake (SCB)

When the airbag sensor detects a collision, the brakes and brake lights are automatically controlled to reduce the vehicle speed and that helps reduce the possibility of further damage due to a secondary collision

### ■ TRAC (Traction Control)

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

### ■ Active Cornering Assist (ACA)

Helps to prevent the vehicle from drifting to the outer side by performing inner wheel brake control when attempting to accelerate during cornering

### ■ Hill-start assist control

Helps to reduce the backward movement of the vehicle when starting on an uphill

### ■ EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

## AVS (Adaptive Variable Suspension System) (if equipped)

By independently controlling the damping force of the shock absorbers for each of the 4 wheels according to the road and driving conditions, this system helps riding comfort with superior vehicle stability, and helps good vehicle posture.

Also, the damping force changes depending on the selected driving

Driving

### ■ When the TRAC/VSC systems are operating

The slip indicator light will flash while the TRAC/VSC systems are operating.



### ■ Disabling the TRAC system

If the vehicle gets stuck in mud, dirt or snow, the TRAC system may reduce power from the engine to the wheels. Pressing the

switch to turn the system off may make it easier for you to rock the vehicle in order to free it.

To turn the TRAC system off, quickly press and release the > switch.

"Traction Control Turned Off" will be shown on the multi-information display.

Press the > switch again to turn the system back on.



### ■ Disabling both TRAC and VSC systems

To turn the TRAC and VSC systems off,

press and hold the > 🖟 switch for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "Traction Control Turned Off" will be shown on the multi-information display."

Press the > switch again to turn the systems back on.

- \*: PCS (Pre-Collision System) will also be disabled (only Pre-Collision warning is available). The PCS warning light will come on and a message will be displayed on the multi-information display. (→P.175)
- When the message is displayed on the multi-information display showing that TRAC has been disabled even if the
  - > switch has not been pressed

TRAC cannot be operated. Contact your Lexus dealer.

Operating conditions of hill-start assist control

When the following four conditions are met, the hill-start assist control will operate:

- The shift lever is in a position other than P or N (when starting off forward/backward on an upward incline).
- The vehicle is stopped.
- The accelerator pedal is not depressed.
- The parking brake is not engaged.
- Automatic system cancelation of hillstart assist control

The hill-start assist control will turn off in any of the following situations:

- The shift lever is shifted to P or N.
- The accelerator pedal is depressed.
- The parking brake is engaged.
- 2 seconds at maximum elapsed after the brake pedal is released.
- Sounds and vibrations caused by the ABS, brake assist, VSC, TRAC and hillstart assist control systems
- A sound may be heard from the engine compartment when the brake pedal is depressed repeatedly, when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.

- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
- Vibrations may be felt through the vehicle body and steering.
- A motor sound may also be heard after the vehicle comes to a stop.
- The brake pedal may pulsate slightly after the ABS is activated.
- The brake pedal may move down slightly after the ABS is activated.

### Active Cornering Assist operation sounds and vibrations

When Active Cornering Assist is operated, operation sounds and vibrations may be generated from the brake system, but this is not a malfunction.

### ■ EPS operation sound

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

### Automatic reactivation of TRAC and VSC systems

After turning the TRAC and VSC systems off, the systems will be automatically reenabled in the following situations:

- When the engine switch is turned off
- If only the TRAC system is turned off, the TRAC will turn on when vehicle speed increases

If both the TRAC and VSC systems are turned off, automatic re-enabling will not occur when vehicle speed increases.

### Secondary Collision Brake operating conditions

The vehicle speed is approximately 6 mph (10 km/h) or more and the airbag sensor detects a collision. (The Secondary Collision Brake will not operate when the vehicle speed is below approximately 6 mph [10 km/h].)

### Secondary Collision Brake automatic cancellation

The Secondary Collision Brake is automatically canceled in the following situations.

The vehicle speed drops below approximately 6 mph (10 km/h)

- A certain amount of time elapses during operation
- The accelerator pedal is depressed a large amount

### Operating conditions of Active Cornering Assist

The system operates in the following situations.

- TRAC/VSC can operate
- The system determines that the vehicle is drifting to the outer side when attempting to accelerate during cornering
- The brake pedal is released

### Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.

### A

#### WARNING

- The ABS does not operate effectively when
- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on wet or slick roads.
- Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snowcovered roads
- When driving with tire chains



### **WARNING**

- When driving over bumps in the road
- When driving over roads with potholes or uneven surfaces
- TRAC/VSC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC/VSC system is operating.

Drive the vehicle carefully in conditions where stability and power may be lost.

### Active Cornering Assist does not operate effectively when

- Do not rely solely upon Active Cornering Assist. Active Cornering Assist may not operate effectively when accelerating down slopes or driving on slippery road surfaces.
- When Active Cornering Assist frequently operates, Active Cornering Assist may temporarily stop operating to ensure proper operation of the brakes, TRAC, VSC.

### Hill- start assist control does not operate effectively when

- Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on steep inclines and roads covered with ice.
- Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline, as doing so may lead to an accident.

### ■ When the TRAC/VSC is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

#### ■ When the TRAC/VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRAC/VSC systems off unless necessary.

### Secondary Collision Brake

Do not overly rely on the Secondary Collision Brake. This system is designed to help reduce the possibility of further damage due to a secondary collision. however, that effect changes according to various conditions. Overly relying on the system may result in death or serious injury.

### Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRAC and VSC systems will not function correctly if different tires are installed on the vehicle.

Contact your Lexus dealer for further information when replacing tires or wheels

### Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.

### Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

### Preparation for winter

- Use fluids that are appropriate to the prevailing outside temperatures.
- Engine oil
- · Engine coolant
- · Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.\*

Ensure that all tires are the specified size and brand, and that chains match the size of the tires.

\*: Tire chains cannot be mounted on vehicles with 18-inch/19-inch tires.



#### WARNING

### ■ Driving with snow tires

Observe the following precautions to reduce the risk of accidents.
Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.

- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.
- Driving with tire chains (vehicles with 17-inch tires)

Observe the following precautions to reduce the risk of accidents.

Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Do not use LTA (Lane Tracing Assist) system.



#### NOTICE

### ■ Repairing or replacing snow tires

Request repairs or replacement of snow tires from Lexus dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

### Before driving the vehicle

Perform the following according to the driving conditions:

• Do not try to forcibly open a window

or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.

- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.
- To protect the windshield wipers →P.158

### When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

### When parking the vehicle

 Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If the vehicle is parked without setting the parking brake, make sure to block the wheels.
 Failure to do so may be dangerous because it may cause the vehicle to


- move unexpectedly, possibly leading to an accident.
- If the vehicle is parked without setting the parking brake, confirm that the shift lever cannot be moved out of P\*.
- \*: The shift lever will be locked if it is attempted to be shifted from P to any other position without depressing the brake pedal. If the shift lever can be shifted from P, there may be a problem with the shift lock system. Have the vehicle inspected by your Lexus dealer immediately.

### Selecting tire chains

► Vehicles with 17-inch tires

Use the correct tire chain size when mounting the tire chains.

Chain size is regulated for each tire size.



Side chain:

- A 0.12 in. (3 mm) in diameter
- **B** 0.39 in. (10 mm) in width
- 1.18 in. (30 mm) in length Cross chain:
- **D** 0.16 in. (4 mm) in diameter
- **E** 0.55 in. (14 mm) in width

**F** 0.98 in. (25 mm) in length

▶ Vehicles with 18-inch/19-inch tires

Tire chains cannot be mounted.

Snow tires should be used instead.

# Regulations on the use of tire chains (vehicles with 17-inch tires)

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

#### ■ Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires. Do not install tire chains on the rear tires.
- Install tire chains on front tires as tightly as possible. Retighten chains after driving 1/4 - 1/2 mile (0.5 - 1.0 km).
- Install tire chains following the instructions provided with the tire chains.



#### NOTICE

### Fitting tire chains

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

### Windshield wipers

To enable the windshield wipers to be lifted when heavy snow or icy conditions are expected, change the rest position of the windshield wipers from the retracted position below the hood to the service position using the wiper

lever. (→P.159)

### Interior features

5-1.	Remote Touch
	Remote Touch244
5-2.	Lexus Climate Concierge
	Lexus Climate Concierge249
5-3.	Using the air conditioning system
	Automatic air conditioning system
	Heated steering wheel/seat heaters/seat ventilators258
5-4.	Using the interior lights
	Interior lights list262
5-5.	Using the storage features
	List of storage features265
	Trunk features268
5-6.	Using the other interior features
	Other interior features269
	Garage door opener281
	Compass286
	Lexus Enform Safety Connect
	Lexus Enform Remote293
	Lexus Enform Service Connect
	4/7


### **Remote Touch**

The Remote Touch can be used to operate the Center Display.

For details on the Remote touch, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

### Remote Touch operation

### Switches



- ▶ 8-inch display model
- A "HOME" button

Press this button to display the home screen.

- ▶ 12.3-inch display model
- A "MAP" button

Press to display the current location.

**B** "MENU" button

Press to display the menu screen.

C Back button

Press to display the previous screen.

**D** Touchpad

Slide your finger on the touchpad and move the pointer to select a function, letter and screen button.


Press the touchpad to enter the selected

function, letter or screen button. Certain finger movements on the touchpad can perform functions, such as changing map scalings and scrolling list screens.

**E** Sub function button

When is displayed on the screen, a function screen assigned to the screen can be displayed.

### ■ Using the touchpad




- Select: Touch the touchpad to select the desired button on the screen.
- 2 Enter: The buttons on the screen can be selected by either depressing or double tapping on the touchpad. Once a button has been selected, the screen will change.

### ■ Touch operation

Operations are performed by touching the touchpad with your finger.


### Trace

Trace the pad surface while maintaining contact with the touchpad. Moving the cursor and the pointer.




### Double tap

Tap the touchpad twice, quickly. Select the button on the screen.




### Flick

Quick and long movement along the touchpad with your finger. Move the list screen.



### Pinch in/Pinch out

Slide fingers toward each other or apart on the touchpad. Change the scale of the map.



### NOTICE .

### ■ To prevent damage to the Remote Touch

Observe the following precautions. Failure to do so may cause damage to the Remote Touch.

- Do not allow the Remote Touch to come into contact with food, liquid, stickers or lit cigarettes.
- Do not subject the Remote Touch to excessive pressure or strong impact.
- Do not push the touchpad with a strong force or use a sharp pointed object to operate the pad.

### Center Display overview

### ■ Menu screen

Press the "MENU" button on the Remote Touch to display the menu screen.

The display may differ depending on the type of the system.

### ▶ 8-inch display model (type A)



▶ 8-inch display model (type B)



▶ 12.3-inch display model




Switch	Function
	Select to display the "Destination" screen.*1
	Select to display the radio control screen.*1,2
<b>&gt;</b>	Select to display the media control screen or the audio control screen.*1

Switch	Function		
&	Select to display the hands-free control screen.*1		
	Select to display the "Apps" screen.*1, 2		
	When an Apple CarPlay connection is established and this button displays "Apple CarPlay", select to display the home screen of Apple CarPlay. *1, 2		
<b>(i)</b>	Select to display the information screen.*1( $\rightarrow$ 82)		
503	Select to display the "Setup" screen.*1		
	Select to display the air conditioning control screen. (→P.254)		
	Select to adjust the contrast and brightness of the screens, turn the screen off, etc. *1, 2		

- \*1: Refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".
- \*2: This function is not made available on some models.

### ■ Split-screen display (12.3-inch display model)

Different information can be displayed on the left and right of the screen. For example, air conditioning system screen can be displayed and operated while the fuel consumption information screen is being displayed. The large screen on the left of the display is called the main display, and the small screen to the right is called the side display.



### ■ Main display

For details about the functions and operation of the main display, refer to the respective section and "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

### ■ Side display (12.3-inch display model)

The following functions can be displayed and operated on the side display.

Select or to display the desired screen.



- A Navigation system\*
- **B** Audio\*
- $\bigcirc$  Vehicle information ( $\rightarrow$ P.83)
- $\triangleright$  Air conditioning system ( $\rightarrow$ P.255)
- **E** Show/hide the side display
- \*: Refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

### ■ Screen display during low temperatures

When the ambient temperature is

### 248

5-1. Remote Touch

extremely low, screen response may be delayed even if the Remote Touch is operated.

### Lexus Climate Concierge

The seat heaters (if equipped), seat ventilators (if equipped) and heated steering wheel (if equipped) are each automatically controlled according to the set temperature of the air conditioning system, the outside and cabin temperature, etc. Lexus Climate Concierge allows a comfortable condition to be maintained without adjusting each system.

Press the "MENU" button on the Remote Touch and select "Climate" to display the air conditioning control screen. Then, select  $\cite{S}$  on the sub menu ( $\rightarrow$ P.254) to display the Lexus Climate Concierge control screen.

# Turning on Lexus Climate Concierge

Select 9

The indicator on the Lexus Climate Concierge control screen illuminates, and the automatic air conditioning system, seat heaters and ventilators, and heated steering wheel operate in automatic mode.

If any of the system is operated manually, the indicator turns off. However, all other functions continue to operate in automatic mode.



### ■ When using the Lexus Climate Concierge

Lexus Climate Concierge can be operated on the sub function menu or option control screen.  $(\rightarrow P.254)$ 

### Operation of each system

■ Automatic air conditioning system (→P.251)

The temperature can be adjusted individually for the driver seat and passenger seat.

Seat heaters and ventilators (if equipped)  $(\rightarrow P.258)$ 

Heating or ventilation is automatically selected according to the set temperature of the air conditioning system, the outside temperature, etc. Also, heating and ventilation may turn off.

The seat heater and ventilator of the front passenger seat operate in automatic mode if a passenger is detected.

■ Heated steering wheel (if equipped) ( $\rightarrow$ P.258)

Heated steering wheel operates automatically according to the set temperature of the air conditioning system, the outside temperature, etc.

### ■ Seat heater/ventilator operation

When automatic mode is selected using the seat heater/ventilator switch, passenger detection is not performed.


# **Automatic air conditioning system**

Air outlets and fan speed are automatically adjusted according to the temperature setting.

Press the "MENU" button on the Remote Touch, then select "Climate" to display the air conditioning control screen.  $(\rightarrow P.245)$ 

12.3-inch display model: The air conditioning system can be displayed and operated on the side display.

# Air conditioning controls



- A Left-hand side temperature control switch
- **B** Automatic mode switch
- C Off switch
- **D** Fan speed decrease switch
- **E** Fan speed increase switch
- F Airflow mode control switch
- **G** Windshield defogger switch
- H Rear window and outside rear view mirror defoggers switch
- I Outside/recirculated air mode switch
- Right-hand side temperature control switch

# Adjusting the temperature

Operate the temperature control switch upwards to increase the temperature and downwards to decrease the temperature.

If the "A/C" indicator is turned off, the system will blow ambient temperature air or heated air.

### ■ Setting the fan speed

Operate the fan speed increase switch

to increase the fan speed and the fan speed decrease switch to decrease the fan speed.

Press the off switch to turn the fan off.

# ■ Changing the air flow mode

Press the airflow mode control switch.

The mode changes as follows each time the switch is pressed.  $(\rightarrow P.254)$ 

# Switching between outside air and recirculated air modes

Press the outside/recirculated air mode switch.

The mode changes as follows each time the switch is pressed.

 $(\text{recirculated air mode}) \rightarrow (\text{outside air mode}) \rightarrow (\text{recirculated air mode}) \rightarrow (\text{recirculated air mode})$ 

When the system is switched to automatic mode, the air conditioning system operates automatically.

\*: This item cannot be selected when the air conditioning is off.

# Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press the windshield defogger switch.

Set the outside/recirculated air mode switch to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press the windshield defogger switch again when the

windshield is defogged.

# Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press the rear window and outside rear view mirror defoggers switch.

The defoggers will automatically turn off after 15 to 60 minutes. The operation time changes according to the ambient temperature and vehicle speed.

# ■ When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on

- In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce fuel consumption.
- Recirculated air mode is selected as a default mode when the engine switch is turned to IGNITION ON mode.
- It is possible to switch to outside air mode at any time by pressing the outside/recirculated air mode switch.

### Fogging up of the windows

The windows will easily fog up when the humidity in the vehicle is high. Turning "A/C" on will dehumidify the air from the outlets and defog the windshield effectively.

- If you turn "A/C" off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

#### Outside/recirculated air mode

When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode switch to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling opera-

tion, setting the recirculated air mode will also cool the vehicle interior effectively.

 Outside/recirculated air mode may automatically switch regardless of the air conditioning setting depending on the temperature setting or inside temperature.

#### Registering air conditioning settings to electronic keys

- Unlocking the vehicle using an electronic key and turning the engine switch to IGNITION ON mode will recall that key's registered air conditioning settings.
- When the engine switch is turned off, the current air conditioning settings will automatically be registered to the electronic key that was used to unlock the vehicle.
- The system may not operate correctly if more than one electronic key is in the vicinity or if the smart access system with push-button start is used to unlock the passenger door.
- Vehicles with the driving position memory: The doors that can recall the air conditioning setting\* when unlocked using the smart access system with push-button start can be changed. For details, contact your Lexus dealer.
- \*: The doors that can recall the driving position memory are changed at the same time.

# Operation of the air conditioning system in Eco drive mode

In Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency:

- Engine speed and compressor operation controlled to restrict heating/cooling capacity
- Fan speed restricted when automatic mode is selected

To improve air conditioning performance, perform the following operations:

- Turn off eco air conditioning mode (→P.255)
- Adjust the fan speed
- Turn off Eco drive mode ( $\rightarrow$ P.202)

# ■ When the outside temperature falls to nearly 32°F (0°C)

The dehumidification function may not operate even when "A/C" is selected.

#### ■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- When parking, the system automatically switches to fresh air intake mode to encourage better air circulation throughout the vehicle, helping to reduce odors that occur when starting the vehicle.

#### ■ Using the voice command system

Air conditioning system can be operated using voice commands. For details, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

#### ■ Air conditioning filter

→P.328

#### ■ Customization

Settings (e.g. A/C Auto switch operation) can be changed. (Customizable features →P.400)



#### WARNING

#### To prevent the windshield from fogging up

Do not use the windshield defogger switch during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

# ■ When the outside rear view mirror defoggers are operating

Do not touch the outside rear view mirror surfaces, as they can become very hot and burn you.



#### **NOTICE**

#### To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

# Air conditioning control screen

#### ■ Main control screen

Using the touchpad of the Remote Touch, select the button on the screen.

**B** to **E** can be adjusted by performing the following operations.


Flick operation: Move the pointer to the desired item and flick the touchpad up or down.

The item can be adjusted by one level.

Trace operation: After selecting the desired item, trace the pad surface.

The item can be adjusted by the amount that you trace.

Trace operation cannot be used while driving.



A Sub menu

Selecting the sub menu item to switch the main screen.

ಸ್ರವಿ: Display the air conditioning control screen Display the heated steering wheel/seat heater/seat ventilator control screen (if equipped)

డ్డు: Display the Lexus Climate Concierge control screen

: Display the option control screen

**B** Adjust the left-hand side temperature setting

C Adjust the fan speed setting

D Select the air flow mode

: Air flows to the upper body

: Air flows to the upper body and feet

: Air flows to the feet

: Air flows to the feet and the windshield defogger operates

**E** Adjust the right-hand side temperature setting

F Function on/off indicators

When the function is on, the indicator illuminates on the control screen.

**G** Sub function menu

When the sub function button on the Remote Touch is pressed, the following functions can be switched on and off.

%: Set Lexus Climate Concierge (→P.249)


"AUTO": Set automatic mode on/off  $(\rightarrow P.256)$ 

"Off": Turn the fan off

"A/C": Set cooling and dehumidification function

"DUAL": Adjust the temperature for driver and front passenger seats separately

### ("DUAL" mode) ( $\rightarrow$ P.256)



#### ■ Option control screen

Select on the sub menu to display the option control screen.


The functions can be switched on and off.

When the function is on, the indicator illuminates on the screen.



- A Set Lexus Climate Concierge (→P.249)
- B Adjusting the temperature for driver and front passenger seats separately ("DUAL" mode) (→P.256)
- C Set eco air conditioning mode Air conditioning and heater output is limited to prioritize fuel economy.
- D Cooling and dehumidification function
- Prevent ice from building up on the windshield and wiper blades (Windshield wiper de-icer) (if equipped)

# ■ Side display (12.3-inch display model)



- A Display the heated steering wheel/seat heaters/seat ventilators control screen (if equipped) (→P.258)
- **B** Adjust the left-hand side temperature setting
- C Adjust the fan speed setting
- Adjust the right-hand side temperature setting
- E Set cooling and dehumidification function on/off
- F Adjust the temperature for the driver's and front passenger's seats separately ("DUAL" mode)
  (→P.256)
- G Select the air flow mode

### ■ Windshield wiper de-icer (if equipped)

This feature is used to prevent ice from building up on the windshield and wiper blades.

The windshield de-icer will automatically turn off after approximately 15 minutes.

### ■ Eco air conditioning mode

When Eco drive mode is selected using the Driving Mode Select switch, eco air conditioning mode turns on.

When a drive mode other than Eco drive

mode is selected, eco air conditioning mode may turn off.



#### WARNING

#### To prevent burns (vehicles with windshield wiper de-icer)

Do not touch the glass at lower part of the windshield or to the side of the front pillars when the windshield wiper de-icer is on.

# Using automatic mode

- Press the automatic mode switch or select "AUTO" on the sub function menu. (→P.254)
- 2 Press the outside/recirculated air mode switch to switch to automatic air intake mode.

The air conditioning system automatically switches between outside air and recirculated air modes.

- 3 Adjust the temperature setting.
- 4 To stop the operation, press the off switch or select "Off" on the sub function menu. (→P.254)

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

### ■ Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and the ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after the automatic mode switch is pressed or "AUTO" is selected.

Cool air may blow around the upper body even when the heater is on due to sunlight.

#### Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the dehumidification function is off, and the fan is operating, turning automatic mode on will activate the dehumidification function. The next time the dehumidification function is turned off, the AUTO mode for switching between outside air and recirculated air modes is canceled.

# Adjusting the temperature for driver and passenger seats separately ("DUAL" mode)

To turn on the "DUAL" mode, perform any of the following procedures:


- Select "DUAL" on the sub function menu. (→P.255)
- Select "DUAL" on the option control screen.
- Adjust the front passenger's side temperature setting.

The indicator on the main control screen comes on when the "DUAI" mode is on


### Air outlet layout and operations

#### ■ Location of air outlets


The air outlets and air volume changes according to the selected air flow mode.



- Adjusting the air flow direction and opening/closing the air outlets
- ► Front center/front side



- Direct air flow to the left or right, up or down
- 2 Turn the knob to open or close the vent
- ▶ Rear



- 1 Direct air flow to the left or right, up or down
- 2 Turn the knob to open or close the vent



#### **WARNING**

# ■ To prevent the windshield defogger from operating improperly

Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



# Heated steering wheel\*/seat heaters\*/seat ventilators\*

- \*: If equipped
  - Heated steering wheel

Warms up the grip of the steering wheel

Seat heaters

Warm up the seat upholstery

Seat ventilators

Maintain good air flow by sucking air into the seats

Press the "MENU" button on the Remote Touch and select "Climate" to display the air conditioning control

screen. Then, select  $\longrightarrow$  on the sub menu ( $\rightarrow$ P.254) to display the heated steering wheel/seat heaters/seat ventilators control screen.



#### WARNING

#### ■ To prevent minor burn injuries

Care should be taken if anyone in the following categories comes in contact with the steering wheel or seats when the heater is on:

- Babies, small children, the elderly, the sick and the physically challenged
- Persons with sensitive skin
- Persons who are fatigued
- Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)

# $\Lambda$

#### NOTICE

# To prevent damage to the seat heaters and seat ventilators

Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

#### ■ To prevent battery discharge


Do not use the functions when the engine is off.

# Heated steering wheel

Each time the switch is pressed, the operation condition changes as follows.

AUTO (lit)  $\rightarrow$  Hi (2 segments lit)  $\rightarrow$  Lo (1 segment lit)  $\rightarrow$  Off

The AUTO indicator **A** and/or level indicator **B** illuminates during operation.



### ■ Operation condition

The engine switch is in IGNITION ON mode.

#### ■ When AUTO mode is selected

The heated steering wheel function may turn off according to the air conditioning set temperature, outside temperature, etc.

#### ■ Stored settings

When the engine switch is turned to IGNI-TION ON mode, the stored settings are recalled.


# Seat heaters and ventilators

#### ■ Seat heaters

Each time the switch is pressed, the operation condition changes as follows.

AUTO (lit)  $\rightarrow$  Hi (3 segments lit)  $\rightarrow$  Mid (2 segments lit)  $\rightarrow$  Lo (1 segment lit)  $\rightarrow$  Off

The AUTO indicator **A** and/or level indicator **B** illuminates during operation.




#### ■ Seat ventilators

Each time the switch is pressed, the operation condition changes as follows.

AUTO (lit)  $\rightarrow$  Hi (3 segments lit)  $\rightarrow$  Mid (2 segments lit)  $\rightarrow$  Lo (1 segment lit)  $\rightarrow$  Off

The AUTO indicator **A** and/or and level indicator **B** illuminates during operation.



#### ■ Operation condition

The engine switch is in IGNITION ON mode.

# Air conditioning system-linked control mode

When the seat ventilator fan speed level is Hi (when AUTO is selected), the seat ventilator fan speed may become higher according to the fan speed of the air conditioning system.

### ■ When AUTO mode is selected

The following functions may turn off according to the air conditioning set temperature, outside temperature, etc.

- Seat heaters
- Seat ventilators

### ■ Stored settings

When the engine switch is turned to IGNI-TION ON mode, the following stored settings are recalled.

- Seat heaters
- Seat ventilators



#### WARNING

#### To prevent overheating and minor burn injuries

Observe the following precautions when using the seat heaters.

- Do not cover the seat with a blanket or cushion when using the seat heater.
- Do not use seat heater more than necessary.

# Control screen

### Main display

Using the touchpad of the Remote Touch, select the button on the screen.

**A** to **C** can be adjusted by performing the following operations.


Flick operation: Move the pointer to the desired item and flick the touchpad up or down.

The item can be adjusted by one level.

Trace operation: After selecting the desired item, trace the pad surface.

The item can be adjusted by the amount that you trace.

Trace operation cannot be used while driving.



Adjust the seat ventilator fan speed level

The seat ventilator can be adjusted in 3 levels.

When the seat ventilator is operated, the fan speed level is displayed on the screen.

**B** Adjust the seat heater temperature

The seat heater can be adjusted in 3 levels. When the seat heater is operated, the temperature level is displayed on the screen.

C Adjust the heated steering wheel

temperature level

The heated steering wheel can be adjusted in 2 levels.

When the heated steering wheel is operated, the temperature level is displayed on the screen.

D Automatic mode on/off indicators
When the automatic mode is on, the indicator illuminates on the screen.

**E** Sub function menu


When the sub function button on the Remote Touch is pressed, the following functions can be set to automatic mode.

<u>VAUTO</u>: Left-hand side seat heater/seat ventilator

AUTO: Heated steering wheel

MAUTO: Right-hand side seat heater/seat ventilator

Side display (12.3-inch display model)



- A Display the air conditioning control screen ( $\rightarrow$ P.254)
- **B** Adjust the seat heater temperature level

Each time the switch is selected, the temperature level and level indicator (orange) change as follows:

 $AUTO \rightarrow Hi \rightarrow Mid \rightarrow Lo \rightarrow Off$ 

C Adjust the seat ventilator fan speed

Interior features

Each time the switch is selected, the fan speed level and level indicator (blue) change as follows:

$$AUTO \rightarrow Hi \rightarrow Mid \rightarrow Lo \rightarrow Off$$

D Adjust the heated steering wheel temperature level

Each time the switch is selected, the temperature level and level indicator change as follows:


$$AUTO \rightarrow Hi \rightarrow Lo \rightarrow Off$$

#### ■ Customization

Steering wheel heating preference in automatic mode and the automatic mode settings for the seat heaters and ventilators can be changed. (Customizable features:  $\rightarrow$ P.400)

# Interior lights list

# Location of the interior lights




- $\blacksquare$  Rear personal lights ( $\rightarrow$ P.263)
- **B** Inside door handle lights (if equipped)
- C Instrument panel ornament lights (if equipped)
- **D** Shift lever light
- **E** Front personal lights  $(\rightarrow P.263)$
- $\mathbf{F}$  Interior lights ( $\rightarrow$ P.263)
- **G** Clock light
- **H** Footwell lights
- I Engine switch light
- Door trim ornament lights (if equipped)
- K Door courtesy lights
- L Outer foot lights (front/ front and rear)

# Operating the interior lights

#### ■ Turning the door position on

Press the door-linked interior light switch

The lights are turned on and off according to whether the doors are opened/closed.




# ■ Turning the lights on/off

Turns the lights on/off (touch the light)

The rear interior light turns on/off together with the front interior light.

When a door is opened while the door position is on, the lights turn on.




# Operating the personal lights

- Turning the lights on/off
- ► Front

Turns the lights on/off (touch the light)


When a door is opened while the door position is on, the lights turn on.



#### ▶ Rear

Turns the lights on/off

When a door is opened while the door position is on, the lights turn on.



### ■ Illuminated entry system

The lights automatically turn on/off according to the engine switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are opened/closed.

#### ■ To prevent the battery from being discharged

If the interior lights remain on when the engine switch is turned off, the lights will go off automatically after 20 minutes.

- When front interior light or front personal lights do not respond as normal
- When water, dirt, etc., have adhered to the lens surface
- When operated with a wet hand
- When wearing gloves, etc.
- Automatic turning on of the interior lights

If any of the SRS airbags deploy (inflate) or

in the event of a strong rear impact, the interior lights will turn on automatically.

The interior lights will turn off automatically after approximately 20 minutes. The interior lights can be turned off manually. However, in order to help prevent further collisions, it is recommended that they be left on until safety can be ensured. (The interior lights may not turn on automatically depending on the force of the impact and conditions of the collision.)

#### ■ Customization

Some functions can be customized.  $(\rightarrow P.400)$ 



#### **NOTICE**

#### ■ To prevent battery discharge


Do not leave the lights on longer than necessary when the engine is not running.

#### Removing light lenses

Never remove the lens for the front interior light and front personal lights. Otherwise, the lights will be damaged. If a lens needs to be removed, contact your Lexus dealer.

# List of storage features

# Location of the storage features



- $\blacksquare$  Cup holder ( $\rightarrow$ P.266)
- **B** Glove box  $(\rightarrow P.266)$
- $\bigcirc$  Console box ( $\rightarrow$ P.266)
- $\triangleright$  Auxiliary box ( $\rightarrow$ P.267)



#### WARNING

# ■ Items that should not be left in the vehicle

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:


 Glasses may be deformed by heat or cracked if they come into contact with other stored items.

- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.
- When storage compartments are not in use

When driving or when the storage compartments are not in use, keep the lids closed.

In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open lid or the items stored inside.

### Glove box




- 1 Open (press the glove box opener)
- 2 Unlock with the mechanical key
- 3 Lock with the mechanical key

#### ■Glove box light

The glove box light turns on when the tail lights are on.

- Trunk opener main switch
- →P.99

# Console box



Press a button to open the console box.

The console box can be opened from either side.

# ■ Console box light

The console box light turns on when the tail lights are on.

# A

#### **WARNING**

#### ■ Caution while driving

Keep the console box closed.

Injuries may result in the event of an accident or sudden braking.




#### NOTICE

- To prevent damage to the console box
- When the console box is open, do not apply excessive force in the direction that it was opened.

# Cup holders


► Front (type A)

To open, press down and release the cup holder lid.



► Front (type B)

Adjust the depth of the cup holder.




A Shallow (press the button)

### **B** Deepen

▶ Rear

To open, pull down the armrest and open the lid.



- Front cup holder (type A)
- After closing the USB terminal lid, close the cup holder lid.
- When cleaning the cup holder, the partition and another parts can be removed according to the following procedure.
- 1 Remove the partition



2 Remove the plate



# A

#### WARNING

#### ■ Items unsuitable for the cup holder

Do not place anything other than a cup, beverage can or bottle (front [type B]) in the cup holder. Even when the lid is closed, items must not be stored in the cup holder.

Other items may be thrown out of the holder in the event of an accident or sudden braking, causing injury. If possible, cover hot drinks to prevent burns.

### $\Lambda$


#### NOTICE

#### ■To prevent damage to the cup holder

- Depending on the size of the cup, beverage can or bottle, do not use the cup holder in the shallow condition. When taking out the cup, beverage can or bottle or in the event of sudden braking, they may be thrown out of the holder or the contents may spill.
- Stow the rear cup holder before stowing the armrest.

# Auxiliary box

Press in the button.




# Trunk features

# Cargo hooks

Raise the hooks when needed.

The cargo hooks are provided for securing loose items.






### **WARNING**

■ When the cargo net hooks are not in use


To avoid injury, always return the cargo net hooks to their stowed positions when not in use.

# Grocery bag hooks




# Luggage mat

Lift the luggage mat up.



### Other interior features

#### Sun visors



- 1 To set the visor in the forward position, flip it down.
- 2 To set the visor in the side position, flip down, unhook, and swing it to the side.
- 3 To use the side extender, place the visor in the side position, then slide it backward.

# Vanity mirrors

Slide the cover to open.

The light turns on when the cover is opened.



# ♠ NOTICE


### ■To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is off.

### Clock

The GPS clock's time is automatically adjusted by utilizing GPS time information.

For details, refer to the "NAVIGATION AND MULTIMEDIA SYSTEMOWNER'S MANUAL".




# Power outlets

Please use as a power supply for electronic goods that use less than 12 VDC/10 A (power consumption of 120 W).


▶ Front

Open the lid.



▶ Rear

Open the lid.



#### ■ The power outlet can be used when

The engine switch is in ACCESSORY or IGNITION ON mode.

### ■ When stopping the engine

Disconnect electrical devices such as mobile battery packs.

#### ■ Using the power outlet

The shape of the console box partition allows power cables to be passed through when the console box lid is partially closed.



# <u>^</u>

#### **NOTICE**

### ■ When the power outlet is not in use

To avoid damaging the power outlet, close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

# ■ To prevent battery discharge

Do not use the power outlet longer than necessary when the engine is off.

# USB charging ports


The USB charging ports are used to supply  $2.1\,\mathrm{A}$  of electricity at  $5\,\mathrm{V}$  to

external devices.

The USB charging ports are for charging only. They are not designed for data transfer or other purposes. Depending on the external device, it may not charge properly. Refer to the manual included with the device before using a USB charging port.

# ■ Using the USB charging ports

Open the lid.



# ■ The USB charging ports can be used when

The engine switch is in ACCESSORY or IGNITION ON mode.

- Situations in which the USB charging ports may not operate correctly
- If a device which consumes more than 2.1
   A at 5 V is connected
- If a device designed to communicate with a personal computer, such as a USB memory device, is connected
- If the connected external device is turned off (depending on device)
- If the temperature inside the vehicle is high, such as after the vehicle has been parked in the sun

#### ■ About connected external devices

Depending on the connected external device, charging may occasionally be suspended and then start again. This is not a malfunction.

#### **NOTICE**

# ■ To prevent damage to the USB charging ports

- Do not insert foreign objects into the ports.
- Do not spill water or other liquids into the ports.
- When the USB charging ports are not in use, close the lids. If a foreign object or liquid enters a port may cause a short circuit.
- Do not apply excessive force to or impact the USB charging ports.
- Do not disassemble or modify the USB charging ports.

# To prevent damage to external devices

- Do not leave external devices in the vehicle. The temperature inside the vehicle may become high, resulting in damage to an external device.
- Do not push down on or apply unnecessary force to an external device or the cable of an external device while it is connected.

### ■ To prevent battery discharge

Do not use the USB charging ports for a long period of time with the engine stopped.

# Wireless charger (if equipped)

A portable device can be charged by just placing Qi standard wireless charge compatible portable devices according to the Wireless Power Consortium, such as smart phones and mobile batteries, etc., on the charge area.

This function cannot be used with portable devices that are larger than the


charging area. Also, depending on the portable device, it may not operate as normal. Please read the operation manual for portable devices to be used.

# ■ The "Qi" symbol

The "Qi" symbol is a trademark of the Wireless Power Consortium.



#### ■ Name for all parts




- A Operation indicator light
- **B** Power supply switch
- **C** Charge area

# ■ Using the wireless charger

- **1** Open the console box.  $(\rightarrow P.266)$
- **2** Press the power supply switch of the wireless charger.


Switches on and off with each press of the

power supply switch.
When turned on, the operation indicator light (green) comes on.
Even with the engine off, the on/off state of the power supply switch is memorized.



Place the charging side of the portable device down.

When charging, the operation indicator light (orange) comes on. If charging is not occurring, try placing the portable device as close to the center of the charging area as possible. When charging is complete, the operation indicator light (green) comes on.



### ■ Recharging function

- When charging is complete and after a fixed time in the charge suspension state, charging restarts.
- When the portable device is moved, charging is stopped for a moment and then it restarts.

# Lighting conditions of operation indicator light

Operation indicator light	Conditions
Turning off	When the Wireless charger power supply is off
Green (comes on)	On Standby (charging possible state)
	When charging is complete*
Orange (comes on)	When placing the portable device on the charging area (detecting the portable device)
	Charging

- \*: Depending on the portable device, there are cases where the operation indicator light will continue being lit up orange even after the charging is complete.
- When the operation indicator light flashes

When an error occurs, the operation indicator light flashes an orange color. Handle the error based on the following tables.

 Flashing repeatedly once every second (Orange)

Suspected cause	Handling method
Vehicle to charger communication failure.	Contact your Lexus dealer.

 Repeatedly flashes 3 times continuously (Orange)

Suspected causes	Handling method
A foreign substance is between the portable device and charge area.	Remove the foreign substance from between portable device and the charge area.
The portable device is out of sync due to the device being shifted from the center of the charge area.	Place the portable device near the cen- ter of the charge area.

 Repeatedly flashes 4 times continuously (Orange)

Suspected cause	Handling method
Temperature rising within the wireless charger.	Stop charging at once and start charging again after for a while.

# ■ The wireless charger can be operated when

The engine switch is in ACCESSORY or IGNITION ON mode.

- Usable portable devices
- Qi standard wireless charge standard can be used on compatible devices.
   However, not all Qi standard devices and compatibility are guaranteed.
- Starting with mobile phones and smart phones, it is aimed for low power electrically supplied portable devices of no more than 5W.
- When covers and accessories are attached to portable devices

Do not charge in situations where cover and accessories not able to handle Qi are attached to the portable device. Depending on the type of cover and accessory, it may not be possible to charge. When charging is not performed even with the portable device placed on the charge area, remove the cover and accessories.

# ■ While charging, noise enters the AM radio

Turn off the wireless charger and confirm that the noise has decreased. If the noise decreases, continuously pushing the power supply switch of the wireless charger for 2 seconds, the frequency of the charger can be changed and the noise can be reduced. Also, on that occasion, the operation indicator light will flash orange 2 times.

#### ■ Important points of the wireless charger

- If the electronic key cannot be detected within the vehicle interior, charging cannot be done. When the door is opened and closed, charging may be temporarily
- Certification for the wireless charger

suspended.

• When charging, the wireless charging device and portable device will get warmer, however this is not a malfunction. When a portable device gets warm while charging, charging may stop due to the protection function on the portable device side. In this case, when the temperature of the portable device drops significantly, charge again.

#### ■ Operation sounds

When the power supply is turned on, while searching for the portable device a sound will be produced, however this is not a malfunction.

#### FCC Provided Information:

This equipment has been tested and found to comply with Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: Panasonic

Model Numbers: AT1701 contains CA-QS03J1AJ

Responsible Party: Panasonic Corporation of North America

Two Riverfront Plaza, Newark, NJ 07102-5490

Support Contact: http://www.panasonic.com/support/

# Panasonic 4 6 1

PRODUCT SAFETY AND COMPLIANCE DEPARTMENT. PARASONIC CORPORATION OF WORTH AMERICA. TWO REVERFRONT PLAZA, WY FLOOR, WEWARK, NJ 57102 AME

# FCC Declaration of Conformity Summary

Product Name	In-Vehicle Wirel	ess Charger
Model Number	AT1701	
Brand Name	Panasonic	
Size and Mass	• 245mm (w), 1	36mm (I) and 48mm (h) and mass is 515grams
Purpose Updated DoC	Added similarity variant model / AT1701 contains CA-QS03J1AJ	
Compliance Information	47 CFR, FCC Part 18, Subpart C for ISM Equipment FCC's KDB 680106 D01 RF Exposure Wireless Charging Apps v02     Industry Canada RSS-216, Issue 1, dated August 2014 For Wireless Power Transfer Devices (Wireless Chargers)	
Responsible Applicant	Panasonic Corporation Automotive & Industrial Systems Company Automotive Infotainment Systems Business Division 4261, Ikonobe-cho, Tsuzuki-ku, Yokohama-shi, 224-8520, Japan	
Responsible Factories	Panasonic Corporation, Automotive & Industrial Systems Company Automotive Infotainment / Systems Business Division Global Manufacturing Innovation Center, Matsumoto Factory 5652 Sasaga, Matsumoto city, Nagano 399-8730, Japan Panasonic Automotive Systems Czech, s.r.o. U Panasonic Automotive Systems Czech, s.r.o. U Panasonic Automotive Systems Asia Pacific (Thailand) Co., Ltd. 101 Moo 2 Teparak Road, T.Bangsaothong Ging A.Bangsaothong Samutprakam 10540 Thailand Panasonic Automotive Systems Dalian Co., Ltd. No.300, HongGang Road, GanJingZi District, Dalian, Liaoning Province, 116033 China	
Responsible Sales Company	Panasonic Consu Division of Pana Two Riverfront I	mer Electronics Company sonic Corporation of North America Plaza, Newark, NJ 07102-5490 http://shop.panasonic.com/support
Special Conditions For Compliance	In-Vehicle Wireless Charger will be installed and used exclusively within transportation vehicle and as such, it is exempt from the following requirements: (1) Part 15 digital device technical rules in accordance with §15.103(a); and (2) §15.105(b) full text information to user to appear in User Manual in accordance with §18.213.	
EMI Test Report	TCB	UL Japan
	Test Report	10120384-R2
	Model Tested	AT1701 contains CA-QS03J1AJ
DCCD	Date Issued	12/14/2015
	Methodology	FCC-OET MP-4



PRODUCT BAFETY AND COMPLIANCE DEPARTMENT, PARAMONIC CORPORATION OF NORTH AMERICA. TWO RIVERPRONT PLAZA, 6<sup>th</sup> FLOOR, NEWARK, NJ 117122-5409

# **Panasonic**

PRODUCT BAPETY AND COMPLIANCE DEPARTMENT, PANABONIC CORPORATION OF NORTH AMERICA, TWO RIVERFRONT PLAZA, IN FLOOR, WEMARK, NJ ETHIS 4465

# FCC Declaration of Conformity Summary

RF Exposure Evaluation	TCB	UL Japan	
	MPE Test Report	10197157S-E-R1	
	Model Tested	AT1701 contains CA-QS03J1AJ	
	Date Issued	12/14/2015	
	Methodology	KDB 680106 D01 RF Exposure Wireless Charging Apps v02	
Importation	The subject In-Vehicle Wireless Charger can be imported on behalf of Panasonic affiliated sales companies by PNA's Logistics Import Customs, or their authored brokers, by electrically filing PCC Form 740 while declaring Box 2 with no reference to any FCC ID.		

This DoC is granted for the subject In-Vehicle Wireless Charger on the basis of the manufacturer's attested compliance with the above described conditions and in accordance with FCC Part 18 and FCC's KDB 0680106 D01 RF Exposure Wireless Charging Apps v02.

Certificate Number: DoC 2014-008C Applicant Ref No.: PAS-16-F001 Issued by: Richard Mullen Issue Date: January 14, 2016

PRODUCT BAFETY AND COMPLIANCE DEFARTMENT . PARABONIC CORPORATION OF NORTH AMERICA . TWO RIVERPRONT PLAZA, V<sup>III</sup> FLOOR, WEMARK, NJ STISS-1460



#### WARNING

### ■ Caution while driving

When charging a portable device, for safety reasons, the driver should not operate the main the part of the portable device while driving.

# **WARNING**

#### Caution regarding interference with electronic devices

People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators, as well as any other electrical medical device, should consult their physician about the usage of the wireless charger.

The operations of the wireless charger may have an affect on medical devices.

#### To prevent damage or burns

Observe the following precautions. Failure to do so may result in a possibility of equipment failure and damage, catch fire, burns due to overheat.

- Do not insert any metallic objects between the charging area and the portable device while charging
- Do not attach stickers, metallic objects, etc., to the charger area or portable device
- Do not cover with cloth, etc., and charge
- Do not charge portable devices other than designated
- Do not attempt to dismantle for disassembly or modifications
- Do not hit or apply a strong force



#### **NOTICE**

#### Conditions in which the function may not operate correctly

In the following conditions, it may not operate correctly

- The portable device is fully charged
- There is foreign matter between the charge area and portable device
- The temperature of the portable device gets higher from charging

- The charging surface of the portable device is facing up
- The placement of the portable device is out of alignment with the charge area
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the electronic key is in contact with, or is covered by the following metallic objects
- Cards to which aluminum foil is attached
- Cigarette boxes that have aluminum foil inside
- · Metallic wallets or bags
- Coins
- Hand warmers made of metal
- Media such as CDs and DVDs.
- When other wireless kevs (that emit radio waves) are being used nearby In addition, excluding the above-men-

tioned, when the charger does not perform normally or the operation indicator light is flashing continuously, it is considered that the wireless charger is malfunctioning. Contact your Lexus dealer.

# ■To prevent failure or damage to data

- Do not bring magnetic cards, such as credit cards, or magnetic recording media, etc., close to the charger while charging, otherwise, data may disappear under the influence of magnetism. Also, do not bring precision instruments such as wrist watches, etc., close to the charger, as such objects may break.
- Do not leave portable devices in the cabin. The temperature inside the cabin may become high, when under the sun, and cause damage to the device.



#### NOTICE

#### ■ To prevent battery discharge

When the engine is stopped, do not use the wireless charger for a long time.

#### Armrest

Fold down the armrest for use.



# <u>^</u>


#### **NOTICE**

#### ■ To prevent damage to the armrest

Do not apply too much load on the armrest.

# Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.



# A

#### **WARNING**

#### ■ Assist grips

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.



#### **NOTICE**

### ■To prevent damage to the assist grip


Do not hang any heavy object or put a heavy load on the assist grip.

# Rear sunshade (if equipped)/rear door sunshades (if equipped)

#### ■ Rear sunshade

The rear sunshade can be raised and lowered by operating the button shown below.


Press the switch. (Raise/lower)



#### ■ Rear door sunshades

Pull the tab of the rear door sunshade and hook the sunshade on the anchors.

To retract the rear door sunshade, unhook the sunshade and retract it slowly.



#### ■ The rear sunshade can be used when

- The engine switch is in IGNITION ON mode.
- The rear sunshade can be operated for approximately 1 minute even after the engine switch is turned to ACCESSORY mode or turned off.

#### ■ Reverse operation feature

To ensure adequate rear visibility, the rear sunshade automatically lowers when the shift lever is shifted to R.

However, the rear sunshade is raised again if any of the following occurs:

- The button is pressed again.\*
- Shift the shift lever to P.
- The shift lever is shifted out of R, and the vehicle reaches a speed of 9 mph (15 km/h). If the engine is not running when the rear sunshade has been lowered due to the reverse operation feature, it will not be raised even when the engine is turned on again and the vehicle reaches a speed of 9 mph (15 km/h). To raise the sunshade again, press the button.
- \*: Occasionally, the reverse function may not be carried out after the switch has been pressed. Repeat the above operation to operate the function.

# Λ

#### WARNING

# ■ When the rear sunshade is being raised or lowered

When the rear sunshade is being operated not place fingers or other objects in the fastener section or in the opening. They may get caught, causing injury.




#### NOTICE

#### ■ To prevent battery discharge

Do not operate the rear sunshade when the engine is not running.

- To ensure normal operation of the sunshades
- Do not operate the rear sunshade when any objects are on top of its opening/closing part. The rear sunshade may not operate properly.



- To ensure normal operation of the rear sunshade and rear door sunshades, observe the following precautions:
- Do not place excessive load on the motor or other components of the rear sunshade.
- Do not attach items to the rear sunshade and rear door sunshades.
- Keep the opening clean and clear of obstructions.
- Do not operate the rear sunshade continuously for long periods of time.


# Trunk storage extension

Long objects can be loaded into the vehicle by utilizing the trunk space and rear seat area.

Fold down the armrest.



Fold down the handle and open the armrest door.



The armrest door can be locked and unlocked using the mechanical key.

A Unlock

**B** Lock




#### **WARNING**

#### ■ When not in use

Ensure that the armrest door is closed. In the event of sudden braking, items stored in the trunk may be thrown forward into the cabin, resulting in injury.

# Coat hooks

The coat hooks are provided with the rear assist grips.



# **WARNING**

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.


■ Items that should not be hanged

# Garage door opener

The garage door opener can be programmed using the HomeLink<sup>®</sup> to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

# System components

The HomeLink  $^{\circledR}$  wireless control system in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming methods on the following pages to determine the method which is appropriate for the device.



- lack A HomeLink $^{lack}$  indicator light
- **B** Garage door operation indicators
- lacktriangle HomeLink $^{lacktriangle}$  icon

Illuminates while  $HomeLink^{\mathbb{R}}$  is operating.

**D** Buttons

# ■ Codes stored in the HomeLink<sup>®</sup> memory

- The registered codes are not erased even if the battery cable is disconnected.
- If learning failed when registering a different code to a HomeLink® button that already has a code registered to it, the already registered code will not be erased.

#### ■ Certification for the garage door opener

FCC (USA) and ISED (Canada)

This device complies with FCC rules part 15 and Innovation, Science, and Economic Development Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation. WARNING: The transmitter has been tested and complies with FCC and ISED rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. End Users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter.

#### FCC (États-Unis) et ISED (Canada)

Cet appareil est conforme aux règlements de la FCC, section 15, et au CNR-210 d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est assujetti aux deux conditions suivantes (1) cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris celle qui pourrait entraîner un dysfonctionnement. MISE EN GARDE: L'émetteur a subi des tests et est conforme aux règlements de la FCC et d'ISDE. Les changements ou modifications non approuvés explicitement par la partie responsable de la conformité pourraient rendre caduque l'autorisation de l'utilisateur de se servir du dispositif.

Cet appareil est conforme aux limites d'exposition aux radiations de la FCC et d'ISDE établies pour un environnement non contrôlé. Les utilisateurs finaux doivent respecter les instructions d'utilisation spécifiques pour satisfaire aux exigences de conformité aux expositions de RF. L'émetteur doit se trouver à 20 cm au minimum de l'utilisateur et ne doit pas être situé au même endroit que tout autre émetteur ou antenne ni fonctionner avec un autre émetteur ou antenne.

#### ■ When support is necessary

Visit on the web at www.homelink.com/lexus or call 1-800-355-3515.



#### WARNING

# When programming a garage door or other remote control device

The garage door or other device may operate, so ensure people and objects are out of danger to prevent potential harm.

#### Conforming to federal safety standards

Do not use the HomeLink<sup>®</sup> compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an interfering object. A door or device without these features increases the risk of death or serious injury.

# ■ When operating or programming HomeLink®

Never allow a child to operate or play with the HomeLink $^{\textcircled{R}}$  buttons.

# Programming the HomeLink®

- Before programming HomeLink<sup>®</sup>
- During programming, it is possible

that garage doors, gates, or other devices may operate. For this reason, make sure that people and objects are clear of the garage door or other devices to prevent injury or other potential harm.

- It is recommended that a new battery be placed in the remote control transmitter for more accurate programming.
- Garage door opener motors manufactured after 1995 may be equipped with rolling code protection. If this is the case, you may need a stepladder or other sturdy, safe device to reach the "Learn" or "Smart" button on the garage door opener motor.

# ■ Programming HomeLink<sup>®</sup>

Steps 1 through 3 must be performed within 60 seconds, otherwise the indicator light will stop flashing and programming will not be able to be completed.


Press and release the HomeLink<sup>®</sup> button you want to program and check that the HomeLink<sup>®</sup> indicator light flashes (orange).

2 Point the remote control transmitter for the device at the rear view mirror, 1 to 3 in. (25 to 75 mm) from the HomeLink® buttons.

Keep the  $HomeLink^{\textcircled{R}}$  indicator light in view while programming.



3 Program a device.



Programming a device other than an entry gate (for U.S.A. owners)

Press and hold the remote control transmitter button until the HomeLink<sup>®</sup> indicator light changes from slowly flashing orange to rapidly flashing green (rolling code) or continuously lit green (fixed code), then release the button.

► Programming an entry gate (for U.S.A. owners)/Programming a device in the Canadian market

Press and release the remote control transmitter button at 2 second inter-


- vals, repeatedly, until the HomeLink<sup>®</sup> indicator light changes from slowly flashing (orange) to rapidly flashing (green) (rolling code) or continuously lit (green) (fixed code).
- 4 Test the HomeLink® operation by pressing the newly programmed button and observing the indicator light:
- Indicator light illuminates: Programming of a fixed code device has completed. The garage door or other device should operate when a HomeLink<sup>®</sup> button is pressed and released.
- Indicator light flashes rapidly: The garage door opener motor or other device is equipped with a rolling code. To complete programming, firmly press and hold the HomeLink<sup>®</sup> button for 2 seconds then release it.
- If the garage door or other device does not operate, proceed to "Programming a rolling code system".
- Repeat the steps above to program another device for any of the remaining HomeLink<sup>®</sup> buttons.
- Programming a rolling code system

2 or more people may be necessary to complete rolling code programming.

 Locate the "Learn" or "Smart" button on the garage door opener motor in the garage.


This button can usually be found where the hanging antenna wire is attached to the

unit. The name and color of the button may vary by manufacturer. Refer to the owner's manual supplied with the garage door opener motor for details.



2 Press and release the "Learn" or "Smart" button.

Perform  $\bf 3$  within  $\bf 30$  seconds after performing  $\bf 2$ .



3 Press and hold the desired
HomeLink® button (inside the vehicle) for 2 seconds and release it. Repeat this sequence (press/hold/release) up to 3 times to complete programming.
If the garage door opener motor operates when the HomeLink® button is pressed, the garage door

opener motor recognizes the  $\mathsf{HomeLink}^{(\! R \!)}$  signal.



■ Enabling 2-way communication with a garage door (only available for compatible devices)

When enabled, 2-way communication allows you to check the status of the opening and closing of a garage door through indicators in your vehicle.

2-way communication is only available if the garage door opener motor used is a compatible device. (To check device compatibility, refer to www.homelink.com.)

1 Within 5 seconds after programming the garage door opener has been completed, if the garage door opener motor is trained to

HomeLink<sup>®</sup>, both garage door operation indicators will flash rapidly (green) and the light on the garage door opener motor will blink twice, indicating that 2-way communication is enabled.

If the indicators do not flash, perform **2** and **3** within the first 10 presses of the HomeLink<sup>®</sup> button after programming has been completed.

2 Press a programmed HomeLink<sup>®</sup> button to operate a garage door.

Within 1 minute of pressing the HomeLink ® button, after the garage door operation has stopped, press the "Learn" or "Smart" button on the garage door opener motor. Within 5 seconds of the establishment of 2-way communication with the garage door opener, both garage door opener, both garage door openation indicators in the vehicle will flash rapidly (green) and the light on the garage door opener motor will blink twice, indicating that 2-way communication is enabled.

# Reprogramming a single HomeLink<sup>®</sup> button

When the following procedure is performed, buttons which already have devices registered to them can be overwritten:

- 1 With one hand, press and hold the desired HomeLink® button.
- When the HomeLink<sup>®</sup> indicator starts flashing (orange), continue to hold the HomeLink<sup>®</sup> button and perform "Programming HomeLink<sup>®</sup>" 1 (it takes 20 seconds for the HomeLink<sup>®</sup> indicator to start flashing).


# ■ Before programming

- Install a new battery in the transmitter.
- The battery side of the transmitter must be pointed away from the HomeLink<sup>®</sup>.

# Operating HomeLink®

Press the appropriate HomeLink<sup>®</sup> button. The HomeLink<sup>®</sup> indicator light should turn on.

The status of the opening and closing of a garage door is shown by the indicators.



**A** Opening

# **B** Closing

This function is only available if the garage door opener motor used is a compatible device. (To check device compatibility, refer to www.homelink.com.)

Color	Status
Orange (flashing)	Currently open- ing/closing
Green	Opening/closing has completed
Red (flashing)	Feedback signals cannot be received

The indicators can operate within approximately 820 ft. (250 m) of the garage door. However, if there are obstructions between the garage door and the vehicle, such as houses and trees, feedback signals from the garage door may not be received.

To recall the previous door operation status, press and release either



neously. The last recorded status will be displayed for 3 seconds.

# Erasing the entire HomeLink® memory (all three codes)

Press and hold the 2 outside buttons for 10 seconds until the HomeLink<sup>®</sup> indicator light changes from continuously lit (orange) to rapidly flashing (green).

If you sell your vehicle, be sure to erase the programs stored in the  $\mathsf{HomeLink}^{\circledR}$  memory.




# Compass'

# \*: If equipped

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

# Operation and displays

To turn the compass on or off, press and hold the button for more than 3 seconds.



Directions are displayed as follows:

Display	Direction
"N"	North
"NE"	Northeast
"E"	East
"SE"	Southeast
"S"	South
"SW"	Southwest
"W"	West
"NW"	Northwest

# ■ Conditions unfavorable to correct operation

The compass may not show the correct direction in the following conditions:

● The vehicle is stopped immediately after

#### turning.

- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized. (There is a magnet or metal object near the inside rear view mirror.)
- The battery has been disconnected.
- A door is open.



#### WARNING

### ■ While driving the vehicle

Do not adjust the display. Adjust the display only when the vehicle is stopped.



#### NOTICE

### ■ To avoid the compass malfunctions


Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause the compass sensor to malfunction.

## To ensure normal operation of the compass

- Do not perform a circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof [if equipped] or panoramic moon roof [if equipped], power windows, etc.) as they may interfere with the calibration.

## Calibrating the compass

#### ■ Deviation



The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies depending on the geographic position of the vehicle.

If you cross over one of the map boundar-


ies shown in illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to "Deviation calibration".

#### ■ Deviation calibration

Stop the vehicle.

2 Press and hold the button for 6 seconds. A number (1 to 15) appears on the compass display.




3 Referring to the map above, press the button to select the number of the zone you are in.

If the direction is displayed several seconds after adjustment, the calibration is complete.

## ■ Circling calibration

- 1 Stop the vehicle in a place where it is safe to drive in a circle.
- **2** Press and hold the button for 9 seconds.

"C" appears on the compass display.



3 Drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until a direc-

tion is displayed.



## **MARNING**

#### ■ When doing the circling calibration

Secure a wide space, and watch out for people and vehicles in the vicinity. Do not violate any local traffic rules while performing circling calibration.

# Lexus Enform Safety Connect\*


## \*: If equipped

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at Lexus.com. All use of the Safety Connect service is subject to such then-applicable Terms and Conditions.

## System components



- A "SOS" button
- **B** LED light indicators
- **C** Microphone

#### ■ Certification for Lexus Enform

FCC ID: JOYJ79 IC: 574B-J79

#### FCC/IC WARNING:

Changes or modifications not expressly approved by the manufacture could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for uncontrolled environment.

The antennas used for this transmitter must be installed to provide a separation distance of least 20cm from all persons.

#### FCC/IC AVERTISSEMENT:

L'utilisateur est averti que les changements ou modifications non express ément approuvés par le fabricant pourraient annuler l'autorité de l'utilisateur à utiliser l'équipement.

Ce appareil est compatible avec la Partie 15 du règlement FCC et de la Licence de l'industrie canadienne et des normes exemptes de RSS.

Opération soumise aux deux conditions suivantes :

- (1) ce appareil ne doit pas causer des interférences nuisibles, et
- (2) cet appareil doit accepté toutes les interférences, y compris les interférences qui peuvent entraîner un fonctionnement indésirable de l'appareil.

Cet appareil est compatible aux limites d'exposition aux radiation IC RSS-102 définies pour un environnement non contrôlé.

Les antennes utilisées pour cet émetteur doivent être installées à une distance d'au moins 20 cm de toutes les personnes.

## Services

Subscribers have the following Safety Connect services available:

Automatic Collision Notification\*

Helps drivers receive necessary response from emergency service providers.

 $(\to P.292)$ 

\*: U.S. Patent No. 7.508.298 B2

Stolen Vehicle Location

Helps drivers in the event of vehicle theft.  $(\rightarrow P.292)$ 

Emergency Assistance Button ("SOS") Connects drivers to response-center support.  $(\rightarrow P.292)$ 

Enhanced Roadside Assistance

Provides drivers various on-road assistance.  $(\rightarrow P.292)$ 

## Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms is available for purchase. Contact your Lexus dealer, call the following or push the "SOS" button in your vehicle for further subscription details.

The United States

1-800-25-LEXUS (1-800-255-3987)

Canada

1-800-26-LEXUS (1-800-265-3987)

Puerto Rico

1-877-539-8777

## ■ Safety Connect Services Information

- Phone calls using the vehicles Bluetooth<sup>®</sup> technology will not be possible during Safety Connect.
- Safety Connect is available beginning Fall 2009 on select Lexus models (in the contiguous United States only). Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or receive emergency service support. Enrollment and Telematics Subscription Service Agreement required. A variety of subscription terms is available; charges vary by subscription term selected and loca-

tion.

- Automatic Collision Notification, Emergency Assistance and Stolen Vehicle Location will function in the United States, including Hawaii and Alaska, Puerto Rico and in Canada, and Enhanced Roadside Assistance will function in the United States, Puerto Rico and in Canada.
- Automatic Collision Notification, Emergency Assistance, Stolen Vehicle and Enhanced Road Assistance will not function in the United States Virgin Islands. For vehicles first sold in the USVI, no Safety Connect services will function in and outside the United States Virgin Islands.
- Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

#### ■ Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English, Spanish, and French. Please indicate your language of choice when enrolling.

#### ■ When contacting the response center

You may be unable to contact the response center if the network is busy.

## Safety Connect LED light Indicators

When the engine switch is turned to IGNITION ON mode, the red indicator light comes on for 2 seconds then turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

Green indicator light on = Active

service

- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Lexus dealer)
- No indicator light (off) = Safety
   Connect service not active

## Safety Connect services

#### Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

#### ■ Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) in the United States, 1-877-539-8777 in Puerto Rico or 1-800-265-3987 in Canada, and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Lexus.com.

# ■ Emergency Assistance Button ("SOS")

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

# ■ Enhanced Roadside Assistance Enhanced Roadside Assistance adds

GPS data to the already included warranty-based Lexus roadside service. Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Lexus.com.

# Safety information for Safety Connect

Important! Read this information about exposure to radio frequency signals

before using Safety Connect;

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement)
   Report 86 [1986]
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

## Lexus Enform Remote

## \*: If equipped

Lexus Enform Remote is a cellular phone application that lets you view and remotely control certain aspects of your vehicle.

For details about the functions and services of this application, refer to http://www.lexus.com/enform/.

Function of the Lexus Enform Remote is achieved by using DCM (Data Communication Module).

## Subscription

After you sign the Telematics Subscription Service Agreement, download the Lexus Enform Remote app from your cellular phone's app store, and register within the app (or enroll and complete registration at the dealer), you can begin using these services. ( $\rightarrow$ P.289)

A variety of subscription terms are available. Contact your Lexus dealer, or call 1-800-25-LEXUS (1-800-255-3987) for further subscription details.

## ■ Availability of service

Lexus Enform Remote is available in the contiguous United States, Washington D.C. and Alaska.

Lexus Enform Remote is not available in some countries or areas.

#### ■ Lexus Enform Remote Information

- Lexus Enform Remote should only be used by authorized users.
- Laws in some communities may require that the vehicle be within view of the user

when operating Lexus Enform Remote. In some states, use of Lexus Enform Remote may violate state or local laws. Before using Lexus Enform Remote, check your state and local laws.

- Any malfunction of the Lexus should be repaired by your Lexus dealer.
- Lexus Enform Remote is designed to work at temperatures above -22°F (-30°C). This specification is related to the Lexus Enform Remote operation, but is dependent on the vehicle's operating temperature range which may be different.
- Content is subject to change without notice.
- Some features of the Lexus Enform Remote may not be available on some models.
- Additional information can be found at www.lexus.com/enform/.
- Availability of functions of the Lexus Enform service is dependent on network reception level.
- Safety information for Lexus Enform Remote

Refer to the safety information for Safety Connect: →P.292

# Lexus Enform Service Connect\*

#### \*: If equipped

Lexus Enform Service Connect uses DCM (Data Communication Module) to collect and transmit vehicle data that allows Lexus to provide:

- Vehicle Health Report (VHR)
   (Safety Recalls, Service Campaigns, Current Vehicle Alerts, Required Maintenance, and Vehicle Condition Status)
- Maintenance Notifications
- Vehicle Alert Notifications

For details about this service and how to register, refer to http://www.lexus.com/enform/.

The Lexus Enform Service Connect is achieved by using a DCM built in the vehicle.

## ■ Availability of service

Lexus Enform Service Connect is not available in some countries or areas.

■ Lexus Enform Service Connect Information

Availability of functions of the Lexus Enform Service Connect is dependent on network reception level.

■ Safety information for Lexus Enform Service Connect

Refer to the safety information for Safety Connect:  $\rightarrow$  P.292

## Maintenance and care

6

6-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior296
	Cleaning and protecting the vehicle interior
6-2.	Maintenance
	Maintenance requirements 301
	General maintenance302
	Emission inspection and maintenance (I/M) programs305
6-3.	Do-it-yourself maintenance
	Do-it-yourself service precautions
	306
	Hood308
	Positioning a floor jack308
	Engine compartment310
	Tires316
	Tire inflation pressure325
	Wheels <b>327</b>
	Air conditioning filter328
	Electronic key battery330
	Checking and replacing fuses331
	Headlight aim333
	Light bulbs335

# Cleaning and protecting the vehicle exterior

Perform cleaning in a manner appropriate to each component and its material.

## Cleaning instructions

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

## ■ Self-restoring coat

The vehicle body has a self-restoring coating that is resistant to small surface scratches caused in a car wash etc.

- The coating lasts for 5 to 8 years from when the vehicle is delivered from the plant.
- The restoration time differs depending on the depth of the scratch and outside temperature.
  - The restoration time may become shorter when the coating is warmed by applying warm water.
- Deep scratches caused by keys, coins, etc. cannot be restored.
- Do not use wax that contain abrasives.

#### Automatic car washes

- Fold the mirrors before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle body and damage the paint.
- Rear spoiler (if equipped) may not be washable in some automatic car washes.
   There may also be an increased risk of damage to vehicle.

#### ■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

## Notes for the smart access system with push-button start

If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:

- Place the key in a position 6 ft. (2 m) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart access system with push-button start. (→P.101)

#### ■ Aluminum wheels

- Remove any dirt immediately by using a neutral detergent.
- Wash detergent off with water immediately after use.
- To protect the paint from damage, make sure to observe the following precautions.
- Do not use acidic, alkaline or abrasive detergent
- Do not use hard brushes
- Do not use detergent on the wheels when they are hot, such as after driving or parking in hot weather

#### Bumpers

Do not scrub with abrasive cleaners.

## Front side windows water-repellent coating

- The following precautions can extend the effectiveness of the water-repellent coating.
- Remove any dirt, etc. from the front side windows regularly.
- Do not allow dirt and dust to accumulate on the windows for a long period.
   Clean the windows with a soft, damp cloth as soon as possible.
- Do not use wax or glass cleaners that contain abrasives when cleaning the windows.
- Do not use any metallic objects to remove condensation build up.
- When the water-repellent performance has become insufficient, the coating can be repaired. Contact your Lexus dealer.



### WARNING


#### ■ When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

#### ■ When cleaning the windshield (vehicles with rain-sensing windshield wipers)

Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



A Off

## **B** AUTO

- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor

## Precautions regarding the exhaust pipes and rear bumper diffusers

As exhaust gases cause the exhaust pipes and rear bumper diffusers to become quite hot, do not touch the exhaust pipes and rear bumper diffusers while the engine is running or immediately after the engine is turned off.

When washing the vehicle, be careful not to touch the exhaust pipes and rear bumper diffusers until they have cooled sufficiently, as touching hot exhaust pipes and rear bumper diffusers can cause burns.



#### WARNING

 Precaution regarding the rear bumper with Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, consult your Lexus dealer.



#### **NOTICE**

- To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)
- Wash the vehicle immediately in the following cases:
- · After driving near the sea coast
- After driving on salted roads
- If coal tar, pollen or tree sap is present on the paint surface
- If dead insects, insect droppings or bird droppings are present on the paint surface
- After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
- If the vehicle becomes heavily soiled with dust or mud
- If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

## Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax to the surfaces of the lights.
   Wax may cause damage to the lenses.

#### When using an automatic car wash (vehicles with rain-sensing windshield wipers)

Set the wiper switch to the off position.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

#### ■ When using a high-pressure car wash

- When washing the vehicle, do not let water of the high-pressure washer hit directly or the vicinity of the camera.
   Due to the shock from the high-pressure water, it is possible the device may not operate as normal.
- Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), connectors or the following parts. The parts may be damaged if they come into contact with high-pressure water.
- Traction related parts
- Steering parts
- · Suspension parts
- Brake parts
- Keep the cleaning nozzle at least 11.9 in. (30 cm) away from the vehicle body. Otherwise resin section, such as molding and bumpers, may be deformed and damaged.
   Also, do not continuously hold the nozzle in the same place.

# Cleaning and protecting the vehicle interior

Perform cleaning in a manner appropriate to each component and its material.

## Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.

Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

## ■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

## ■ Handling the seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

■ When cleaning the carpeted portions of the glove box, console box, etc.

If a strong adhesive tape is used, there is a possibility that the surface of the carpet could be damaged.



#### WARNING

#### Water in the vehicle

- Do not splash or spill liquid in the vehicle.
  - Doing so may cause electrical components etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet. (→P.28)

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

## Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.



#### **NOTICE**

## ■Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
- Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
- Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.
- Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

 Remove any dust or dirt from leather surfaces immediately.



#### NOTICE

- Do not expose the vehicle to direct sunlight for extended periods of time.
   Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

#### ■ Water on the floor

Do not wash the vehicle floor with water. Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

#### When cleaning the inside of the windshield

Do not allow glass cleaner to contact the lens. Also, do not touch the lens.  $(\rightarrow P.163)$ 

- Cleaning the inside of the rear window
- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

# Cleaning the areas with satin-finish metal accents

- Remove dirt using a water-dampened soft cloth or synthetic chamois.
- Wipe the surface with a dry soft cloth to remove any remaining moisture.

## Cleaning the areas with satin-finish metal accents

The metal areas use a layer of real metal for the surface. It is necessary to clean them regularly. If dirty areas are left uncleaned for long periods of time, they may be difficult to clean.

## Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

## ■ Caring for leather areas

Lexus recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

# Cleaning the synthetic leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

## **Maintenance requirements**

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. It is the owner's responsibility to perform regular checks. Lexus recommends the following maintenance:

#### Repair and replacement

It is recommended that genuine Lexus parts be used for repairs to ensure performance of each system. If non-Lexus parts are used in replacement or if a repair shop other than a Lexus dealer performs repairs, confirm the warranty coverage.

#### Allow inspection and repairs to be performed by a Lexus dealer

- Lexus technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Lexus dealer will promptly take care of it.



#### WARNING

## If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

## Handling of the battery

Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.

- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P.314)

#### General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Lexus dealer.

## Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Warranty and Service Guide", "Owner's Manual Supplement" or "Scheduled Maintenance".

#### Resetting the message indicating maintenance is required

After the required maintenance is performed according to the maintenance schedule, please reset the message. To reset the message, follow the procedure described below:

- 1 Press < or > of the meter control switches and select .
- Press or of the meter control switches and select "Vehicle Settings". Then press "OK".

- 3 Press or of the meter control switches and select "Scheduled Maintenance". Then press "OK".
- 4 Select "Yes" and press "OK".

A message will be displayed when the reset procedure has been completed.



## Do-it-yourself maintenance

You can perform some maintenance procedures by yourself.

Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Lexus repair manuals is recommended.

For details about warranty coverage, refer to the separate "Owner's Guide", "Warranty and Service Guide", "Owner's Manual Supplement" or "Warranty Booklet".

#### General maintenance

Listed below are the general maintenance items that should be performed at the intervals specified in the "Warranty and Service Guide" or "Owner's Manual Supplement". It is recommended that any problem you notice should be brought to the attention of your Lexus dealer or qualified service shop for advice.



#### WARNING

#### If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks.

## Engine compartment

Items	Check points
Battery	Check the battery fluid level and connections. (→P.314)
Brake fluid	Is the brake fluid at the correct level? (→P.313)
Engine coolant	Is the engine coolant at the correct level? (→P.312)
Engine oil	Is the engine oil at the correct level? (→P.310)
Exhaust system	There should not be any fumes or strange sounds.

Items	Check points
Radiator/con- denser	The radiator and condenser should be free from foreign objects. (→P.313)
Washer fluid	Is there sufficient washer fluid? (→P.315)

## Vehicle interior

Items	Check points
Accelerator pedal	The accelerator pedal should move smoothly (without uneven pedal effort or catching).
Automatic trans- mission "Park" mechanism	<ul> <li>When parked on a slope and the shift lever is in P, is the vehicle securely stopped?</li> </ul>
Brake pedal	<ul> <li>Does the brake pedal move smoothly?</li> <li>Does the brake pedal have appropriate clearance from the floor?</li> <li>Does the brake pedal have the correct amount of free play?</li> </ul>

ltems	Check points
Brakes	<ul> <li>The vehicle should not pull to one side when the brakes are applied.</li> <li>The brakes should work effectively.</li> <li>The brake pedal should not feel spongy.</li> <li>The brake pedal should not get too close to the floor when the brakes are applied.</li> </ul>
Head restraints	Do the head restraints move smoothly and lock securely?
Indicators/buzz- ers	Do the indicators and buzzers function properly?
Lights	<ul> <li>Do all the lights come on?</li> <li>Are the headlights aimed correctly?</li> </ul>
Parking brake	<ul> <li>Does the parking brake operate nor- mally?</li> <li>When parked on a slope and the park- ing brake is on, is the vehicle securely stopped?</li> </ul>
Seat belts	<ul> <li>Do the seat belts operate smoothly?</li> <li>The seat belts should not be damaged.</li> </ul>

ltems	Check points
Seats	• Do the seat controls operate properly?
Steering wheel	<ul> <li>Does the steering wheel rotate smoothly?</li> <li>Does the steering wheel have the correct amount of free play?</li> <li>There should not be any strange sounds coming from the steering wheel.</li> </ul>

## Vehicle exterior

ltems	Check points
Doors/trunk	<ul> <li>Do the doors/trunk operate smoothly?</li> </ul>
Engine hood	Does the engine hood lock system work properly?
Fluid leaks	There should not be any signs of fluid leakage after the vehicle has been parked.

Items	Check points
Tires	<ul> <li>Is the tire inflation pressure correct?</li> <li>The tires should not be damaged or excessively worn.</li> <li>Have the tires been rotated according to the maintenance schedule?</li> <li>The wheel nuts should not be loose.</li> </ul>
Windshield wip- ers	<ul> <li>The wiper blades should not show any signs of cracking, splitting, wear, con- tamination or defor- mation.</li> <li>The wiper blades should clear the windshield without streaking or skip- ping.</li> </ul>

# Emission inspection and maintenance (I/M) programs

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

# If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Lexus dealer to service the vehicle.

# Your vehicle may not pass the I/M test in the following situations:

- When the battery is disconnected or discharged
   Readiness codes that are set during ordinary driving are erased.
   Also, depending on your driving habits, the readiness codes may not be completely set.
- When the fuel tank cap is loose
   The malfunction indicator lamp
   comes on indicating a temporary
   malfunction and your vehicle may
   not pass the I/M test.

## When the malfunction indicator lamp still remains on after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

# If your vehicle does not pass the I/M test

Contact your Lexus dealer to prepare the vehicle for re-testing.

## Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

## Maintenance

ltems		Parts and tools
Battery condition (→P.314)		Warm water Baking soda Grease Conventional wrench (for terminal clamp bolts)
Brake fluid level (→P.313)	•	FMVSS No.116 DOT 3 or SAE J1703 brake fluid FMVSS No.116 DOT 4 or SAE J1704 brake fluid Rag or paper towel Funnel (used only for adding brake fluid)

Items	Parts and tools
Engine coolant level (→P.312)	Toyota Super Long Life Coolant" or a similar high quality ethylene glycol-based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology For the U.S.A.: Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water. For Canada: Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water. Funnel (used only for adding coolant)
Engine oil level (→P.310)	<ul> <li>"Toyota Genuine Motor Oil" or equivalent</li> <li>Rag or paper towel</li> <li>Funnel (used only for adding engine oil)</li> </ul>
Fuses (→P.331)	Fuse with same amperage rating as original
Headlight aim	Phillips-head screw- driver
Light bulbs (→P.335)	<ul> <li>Bulb with same number and wattage rating as original</li> <li>Flathead screwdriver</li> </ul>
Radiator and condenser (→P.313)	_

Items	Parts and tools
Tire inflation pressure (→P.325)	<ul><li>Tire pressure gauge</li><li>Compressed air source</li></ul>
Washer fluid (→P.315)	<ul> <li>Water or washer fluid containing antifreeze (for winter use)</li> <li>Funnel (used only for adding water or washer fluid)</li> </ul>

## A

#### WARNING

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

- When working on the engine compartment
- Keep hands, clothing and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery.
   Fuel and battery fumes are flammable.
- When working near the electric cooling fan or radiator grille

Be sure the engine switch is off. With the engine switch in IGNITION ON mode, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. (→P.313)

#### Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.



#### NOTICE

#### ■ If you remove the air cleaner filter


Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.

## Hood


## Opening the hood

1 Pull the hood lock release lever.

The hood will pop up slightly.



Pull up the auxiliary catch lever and lift the hood.



## A

#### WARNING

## ■ Pre-driving check

Check that the hood is fully closed and locked.

If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.


## Positioning a floor jack

When using a floor jack, follow the instructions in the manual provided with the jack and perform the operation safely.


When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

## Location of the jack point

■ Front




## ■ Rear



## **Engine compartment**

## Components



- $\overline{\mathbf{A}}$  Fuse box ( $\rightarrow$ P.331)
- **B** Engine oil filler cap  $(\rightarrow P.311)$
- $\overline{\mathbf{C}}$  Engine oil level dipstick ( $\rightarrow$ P.310)
- $\triangleright$  Battery ( $\rightarrow$ P.314)
- **E** Brake fluid reservoir  $(\rightarrow P.313)$
- $\mathbf{F}$  Radiator ( $\rightarrow$ P.313)
- **G** Electric cooling fan
- **H** Condenser ( $\rightarrow$ P.313)
- $\square$  Engine coolant reservoir ( $\rightarrow$ P.312)
- $\supset$  Washer fluid tank ( $\rightarrow$ P.315)

# Checking and adding the engine oil

With the engine at operating temperature and turned off, check the oil level

on the dipstick.


## ■ Checking the engine oil

1 Park the vehicle on level ground.


After warming up the engine and turning it

off, wait more than 5 minutes for the oil to drain back into the bottom of the engine.

2 Holding a rag under the end, pull the dipstick out.



- 3 Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- 5 Holding a rag under the end, pull the dipstick out and check the oil level.



- A Low
- **B** Normal
- **C** Excessive

The shape of the dipstick may differ depending on the type of vehicle or engine.

- **6** Wipe the dipstick and reinsert it fully.
- Checking the oil type and preparing the items needed

Make sure to check the oil type and

prepare the items needed before adding oil.

- Engine oil selection
- →P.384
- Oil quantity (Low  $\rightarrow$  Full)


1.9 qt. (1.8 L, 1.6 Imp.qt.)

Item

Clean funnel

## Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



- Remove the oil filler cap by turning it counterclockwise.
- 2 Add engine oil slowly, checking the dipstick.
- 3 Install the oil filler cap by turning it clockwise.

## ■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used

- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

#### After changing the engine oil

The engine oil maintenance data should be reset. Perform the following procedures:

- 1 While the vehicle is stopped, press of the meter control switches.
- 2 Press < or > of the meter control switches, and select .
- Press or of the meter control switches, select "Vehicle Settings", and then press "OK".
- 4 Press or of the meter control switches, select "Oil Maintenance", and then press "OK".
- **5** Select "Yes" and then press "OK".

A message will be displayed on the multiinformation display.

## A

#### WARNING

## Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground.
  - Call your Lexus dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

## $\Lambda$

#### NOTICE


## ■To prevent serious engine damage

Check the oil level on a regular basis.

- When replacing the engine oil
- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

## Checking the engine coolant

The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir when the engine is cold.



- A Reservoir cap
- **B** "F" line
- C "L" line

If the level is on or below the "L" line, add coolant up to the "F" line.  $(\rightarrow P.377)$ 

#### ■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

#### U.S.A.:

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: -31°F [-35°C])

#### Canada:

"Toyota Super Long Life Coolant" is a mixture of 55% coolant and 45% deionized water. (Minimum temperature: -44°F [-42°C])

For more details about engine coolant, contact your Lexus dealer.

### If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir cap, drain cock and water pump.

If you cannot find a leak, have your Lexus dealer test the cap and check for leaks in the cooling system.



#### WARNING

### ■ When the engine is hot

Do not remove the engine coolant reservoir cap or the radiator cap. ( $\rightarrow$ P.379) The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



#### NOTICE

## ■ When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

## ■ If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

# Checking the radiator and condenser

Check the radiator and condenser and

clear away any foreign objects.

If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Lexus dealer.



#### **WARNING**


## ■ When the engine is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

# Checking and adding the brake fluid

## Checking fluid level

The brake fluid level should be between the "MAX" and "MIN" lines on the tank.



## Adding fluid

Make sure to check the fluid type and prepare the necessary items.

Fluid type

FMVSS No.116 DOT 3 or SAE J1703 brake fluid

FMVSS No.116 DOT 4 or SAE J1704 brake fluid

Item

Clean funnel

## ■ Brake fluid can absorb moisture from the air

Excess moisture in the brake fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.



#### **WARNING**

#### ■ When filling the reservoir

Take care as brake fluid can harm your hands and eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.



#### NOTICE

## ■ If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear out or when the fluid level in the accumulator is high.


If the reservoir needs frequent refilling, there may be a serious problem.

## Checking the battery

Check the battery as follows.

## ■ Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- **A** Terminals
- **B** Hold-down clamp

#### ■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following precautions before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.
- After recharging/reconnecting the battery
- The engine may not start. Follow the procedure below to initialize the system.
- Shift the shift lever to P.
- 2 Open and close any of the doors.
- 3 Restart the engine.
- Unlocking the doors using the smart access system with push-button start may not be possible immediately after reconnecting the battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the engine with the engine switch in ACCESSORY mode. The engine may not start with the engine switch turned off. However, the engine will operate normally from the second attempt.
- The engine switch mode is recorded by the vehicle. If the battery is reconnected, the vehicle will return the engine switch mode to the status it was in before the battery was disconnected. Make sure to

turn off the power before disconnect the battery. Take extra care when connecting the battery if the engine switch mode prior to discharge is unknown.

If the engine will not start even after multiple attempts at all methods above, contact your Lexus dealer.



#### WARNING

#### ■ Chemicals in the battery

Battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.
- Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is insufficient ventilation.

## ■ How to recharge the battery

Only perform a slow charge (5 A or less). The battery may explode if charged at a quicker rate.

## ■ Emergency measures regarding electrolyte

- If electrolyte gets in your eyes
   Flush your eyes with clean water for at
   least 15 minutes and get immediate
   medical attention. If possible, continue
   to apply water with a sponge or cloth
   while traveling to the nearest medical
   facility.
- If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte Drink a large quantity of water or milk. Get emergency medical attention immediately.

## ■ When there is insufficient battery fluid

Do not use if there is insufficient fluid in the battery. There is a possible danger that the battery may explode.



#### NOTICE

## ■ When recharging the battery


Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

## ■ When adding distilled water

Avoid overfilling. Water spilled during battery recharging may cause corrosion.

## Adding the washer fluid

If any washer does not work or "Windshield Washer Fluid Low" is shown on the multi-information display, the washer tank may be empty. Add washer fluid.



## A

#### WARNING

#### ■ When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.



#### **NOTICE**

## Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces, as well as damaging the pump leading to problems of the washer fluid not spraying.

## Diluting washer fluid

Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.


#### **Tires**

Replace or rotate tires in accordance with maintenance schedules and treadwear.

## Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread.

Check the spare tire condition and pressure if not rotated.



- A New tread
- **B** Worn tread
- Treadwear indicator
  The location of treadwear indicators is
  shown by a "TWI" or " △ " mark, etc.,
  molded into the sidewall of each tire.
  Replace the tires if the treadwear indica-

tors are showing on a tire.

#### ■ When to replace your vehicle's tires

- Tires should be replaced if:
- The treadwear indicators are showing on a tire.
- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult your Lexus dealer.

#### Vehicles with 17-inch tires:

The wheel angle differs from vehicles equipped with 18-inch/19-inch tires. Therefore, 18-inch/19-inch tires cannot be installed, as sufficient gaps with surrounding parts cannot be ensured.

#### ■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

## ■ Low profile tires (18-inch/19-inch tires)

Generally, low profile tires will wear more rapidly and tire grip performance will be reduced on snowy and/or icy roads when compared to standard tires. Be sure to use snow tires on snowy and/or icy roads and drive carefully at a speed appropriate for road and weather conditions.

#### ■ Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.

For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire.  $(\rightarrow P.391)$ 



### ■ Tire types

Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

#### All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions as well as for use year-round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

#### Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. ( $\rightarrow$ P.240)

## ■ If the tread on snow tires wears down below 0.16 in. (4 mm)

The effectiveness of the tires as snow tires is lost.

## A

#### WARNING

## ■ When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drivetrain as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns.
   Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Lexus.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not tow if your vehicle has a compact spare tire installed.
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle.
   Do not use tires if you do not know how they were used previously.



#### NOTICE

## Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

## ■ Low profile tires (18-inch/19-inch tires)

Low profile tires may cause greater damage than usual to the tire wheel when sustaining impact from the road surface. Therefore, pay attention to the following:

- Be sure to use proper tire inflation pressure. If tires are under-inflated, they may be damaged more severely.
- Avoid potholes, uneven pavement, curbs and other road hazards. Failure to do so may lead to severe tire and wheel damage.
- If tire inflation pressure of each tire becomes low while driving


Do not continue driving, or your tires and/or wheels may be ruined.

#### Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Lexus recommends that tire rotation is carried out at the same interval as tire inspection.

Do not fail to initialize the tire pressure warning system after tire rotation.



#### ■ When rotating the tires

Make sure that the engine switch is off. If the tires are rotated while the engine switch is in IGNITION ON mode, the tire position information will not be updated.

If this accidentally occurs, either turn the engine switch to off and then to IGNITION ON mode, or initialize the system after checking that the tire pressure is properly adjusted.

## Tire pressure warning system

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

- If the tire pressure drops below a predetermined level, the driver is warned by a screen display and a warning light. (→P.352)
- The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display. (→P.71)

The illustration used is intended as an example, and may differ from the image that is actually displayed on the multi-information display.



## ■ Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

## ■ Tire inflation pressure

• It may take a few minutes to display the tire inflation pressure after the engine switch is turned to IGNITION ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted.

- Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.
- Situations in which the tire pressure warning system may not operate properly
- In the following cases, the tire pressure warning system may not operate properly.
- If non-genuine Lexus wheels are used.
- A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
- A tire has been replaced with a tire that is not of the specified size.
- Tire chains etc. are equipped.
- An auxiliary-supported run-flat tire is equipped.
- If a window tint that affects the radio wave signals is installed.
- If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
- If the tire inflation pressure is extremely higher than the specified level.
- If wheel without tire pressure warning valves and transmitters are used.
- If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- Performance may be affected in the following situations.
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device

If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.

- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

#### Warning performance of the tire pressure warning system

The warning of the tire pressure warning system will change in accordance with driving conditions. For this reason, the system

may give a warning even if the tire pressure does not reach a low enough level, or if the pressure is higher than the pressure that was adjusted to when the system was initialized.

- Tire pressure warning system certification
- ▶ For vehicles sold in the U.S.A., Hawaii, Guam and Puerto Rico

## FCC ID: PAXPMVC015

## NOTE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

### Model:PMV-C015

#### NOTE

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### NOTE

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioé lectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

# Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. ( $\rightarrow$ P.323)

#### ■ When replacing the tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 20 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.



#### NOTICE

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps
- When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Lexus dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
- Make sure to install the tire valve caps.
   If the tire valve caps are not installed,
   water could enter the tire pressure
   warning valves and the tire pressure
   warning valves could be bound.
- When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.

# Initializing the tire pressure warning system

- The tire pressure warning system must be initialized in the following circumstances:
- When rotating the tires.
- When the tire inflation pressure is changed when changing traveling speed.
- When the tire inflation pressure is changed such as when changing tire size. (When there are multiple specified pressures)
- After registering the ID codes.
   (→P.323)

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.

- How to initialize the tire pressure warning system
- Park the vehicle in a safe place and stop the engine for 20 minutes or more.

Initialization cannot be performed while the vehicle is moving.


Adjust the tire inflation pressure to the specified cold tire inflation pressure level.

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

- **3** Start the engine.  $(\rightarrow P.137)$
- 4 Press ✓ or ➤ of the meter control switches and select .

- 5 Press ▲ or ▼ of the meter control switches and select "Vehicle Settings", then press "OK".
- 6 Press → or ▼ of the meter control switches and select "TPWS", then press "OK".
- 7 Press or of the meter control switches and select "Set Pressure". Then press and hold "OK" until the tire pressure warning light starts blinking.

A message is displayed on the multi-information display. Also, "--" is displayed for inflation pressure of each tire on the multi-information display while the tire pressure warning system determines the position.



8 Drive at approximately 25 mph (40 km/h) or more for approximately 10 to 30 minutes.

When initialization is complete, the inflation pressure of each tire will be displayed on the multi-information display.

Even if the vehicle is not driven at approximately 25 mph (40 km/h) or more, initialization can be completed by driving for a long time. However, if initialization does not complete after driving for 1 hour or more, park the vehicle in a safe place for approximately 20 minutes and then drive the vehicle again.

#### ■ When initializing

Initialization is performed while driving at

- a vehicle speed of approximately 25 mph (40 km/h) or more.
- Make sure to carry out initialization after adjusting the tire inflation pressure.
   Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
- The tire pressure warning system can be initialized by yourself, but depending on the driving conditions and driving environment, initialization may take some time to complete.

#### ■ The initialization operation

- If you have accidentally turned the engine switch off during initialization, it is not necessary to manually restart the initialization again, as initialization will restart automatically the next time the engine switch is turned to IGNITION ON mode.
- If you accidentally perform initialization when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.
- While the position of each tire is being determined and the inflation pressures are not being displayed on the multiinformation display, if the inflation pressure of a tire drops, the tire pressure warning light will come on.

#### If the tire pressure warning system is not initialized properly

- In the following situations, initialization may take longer than usual to be completed or may not be possible. Normally, initialization completes within approximately 30 minutes.
- Vehicle is not driven at approximately 25 mph (40 km/h) or more
- Vehicle is driven on unpaved roads
- Vehicle is driven near other vehicles and system cannot recognize tire pressure warning valve and transmitters of your vehicle over those of other vehicles

If initialization does not complete after driving for 1 hour or more, park the vehicle in a safe place for approximately 20 minutes and then drive the vehicle again.

• If the vehicle is reversed during initializa-

- tion, the data up to that point is reset, so perform the initialization procedure again from the beginning.
- In the following situations, initialization will not be started or was not completed properly and the system will not operate properly. Perform the initialization procedure again.
- If, when attempting to start initialization, the tire pressure warning light does not blink 3 times.
- If, when the vehicle has been driven for about 20 minutes after performing initialization, the tire pressure warning light blinks for approximately 1 minute and then illuminates.

If initialization cannot be completed after performing the above procedure, contact your Lexus dealer.



### **WARNING**

## When initializing the tire pressure warning system

Do not initialize tire inflation pressure without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

## Registering ID codes

Every tire pressure warning valve and transmitter has a unique ID code.

When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code.


When registering the ID codes, perform the following procedure.

Park the vehicle in a safe place, wait for approximately 20 minutes, and then start the engine. (→P.137)

- 2 Press ✓ or ➤ of the meter control switches and select .
- Press or of the meter control switches and select "Vehicle Settings", and then press "OK".
- 4 Press or ✓ of the meter control switches and select "TPWS", and then press "OK".
- Fress or of the meter control switches and select "Change Wheel Set". Then press and hold "OK" until the tire pressure warning light starts slowly blinking 3 times.

Then a message will be displayed on the multi-information display.

When registration is being performed, the tire pressure warning light will blink for approximately 1 minute then illuminate and "--" will be displayed for the inflation pressure of each tire on the multi-information display.



6 Drive at approximately 25 mph (40 km/h) or more for approximately 10 to 30 minutes.

Registration is complete when the tire pressure warning light turns off and the inflation pressure of each tire is displayed on the multi-information display.

Even if the vehicle is not driven at approximately 25 mph (40 km/h) or more, registration can be completed by driving for a long time. However, if registration does not

complete after driving for 1 hour or more, perform the procedure again from the beginning.

7 Initialize the tire pressure warning system. (→P.321)

### ■ When registering ID codes

- ID code registration is performed while driving at a vehicle speed of approximately 25 mph (40 km/h) or more.
- Before performing ID code registration, make sure that no wheels with tire pressure warning valve and transmitters installed are near the vehicle.
- Make sure to initialize the tire pressure warning system after registering the ID codes. If the system is initialized before registering the ID codes, the initialized values will be invalid.
- ID codes can be registered by yourself, but depending on the driving conditions and driving environment, registration may take some time to complete.

### ■ Canceling ID code registration

- To cancel ID code registration after it has been started, turn the engine switch off before driving the vehicle. If the vehicle is driven after ID code registration is started, to cancel registration, perform the ID code registration start procedure again and turn the engine switch off before driving.
- If ID code registration has been canceled, the tire pressure warning light will blink for approximately 1 minute when the engine switch is turned to IGNITION ON mode and then illuminate. The tire pressure warning system will be operational when the tire pressure warning light turns off.
- If the warning light does not turn off even after several minutes have elapsed, ID code registration may not have been canceled correctly. To cancel registration, perform the ID code registration start procedure again and then turn the engine switch off before driving.

### ■ If ID codes are not registered properly

- In the following situations, ID code registration may take longer than usual to be completed or may not be possible. Normally, registration completes within approximately 30 minutes.
- Vehicle is not parked for approximately 20 minutes or more before driving
- Vehicle is not driven at approximately 25 mph (40 km/h) or more
- Vehicle is driven on unpaved roads
- Vehicle is driven near other vehicles and system cannot recognize tire pressure warning valve and transmitters of your vehicle over those of other vehicles
- Wheel with tire pressure warning valve and transmitter installed is inside or near the vehicle


If registration does not complete after driving for 1 hour or more, perform the ID code registration procedure again from the beginning.

- If the vehicle is reversed during registration, the data up to that point is reset, so perform the registration procedure again from the beginning.
- In the following situations, ID code registration will not be started or was not completed properly and the system will not operate properly. Perform the ID code registration procedure again.
- If, when attempting to start ID code registration, the tire pressure warning light does not blink slowly 3 times.
- If, when the vehicle has been driven for about 20 minutes after performing ID code registration, the tire pressure warning light blinks for approximately 1 minute and then illuminates.
- If ID code registration cannot be completed after performing the above procedure, contact your Lexus dealer.


## Tire inflation pressure

# Checking the specified tire inflation pressure

The recommended cold tire inflation pressure and tire size are displayed on the tire and loading information label.  $(\rightarrow P.387)$ 



# Inspection and adjustment procedure



A Tire valve

- **B** Tire pressure gauge
- 1 Remove the tire valve cap.
- 2 Press the tip of the tire pressure gauge onto the tire valve.
- 3 Read the pressure using the gauge gradations.
- 4 If the tire inflation pressure is not at the recommended level, adjust the pressure.
  - If you add too much air, press the center of the valve to deflate.
- 5 After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- 6 Put the tire valve cap back on.

### ■ Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month. Do not forget to check the spare.

## Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel economy
- Reduced driving comfort and poor handling
- Reduced tire life due to wear
- Reduced safety
- Damage to the drivetrain

If a tire needs frequent inflating, have it checked by your Lexus dealer.

## ■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

 Check only when the tires are cold.
 If your vehicle has been parked for at least 3 hours or has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.

- Always use a tire pressure gauge.
   It is difficult to judge if a tire is properly inflated based only on its appearance.
- It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after driving.
- Never exceed the vehicle capacity weight.
   Passengers and luggage weight should be placed so that the vehicle is balanced.

## A

#### WARNING

## Proper inflation is critical to save tire performance

Keep your tires properly inflated. If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Air leaking from between tire and wheel
- Wheel deformation and/or tire damage
- Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)



#### NOTICE

## When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on. If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

## Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

### Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset.\*

Replacement wheels are available at your Lexus dealer.

- \*: Conventionally referred to as offset. Lexus does not recommend using the following:
- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

## ■ When replacing wheels

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. (→P.321)



#### WARNING

### ■ When replacing wheels

 Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.

- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.
- ■Use of defective wheels prohibited

Do not use cracked or deformed wheels. Doing so could cause the tire to leak air during driving, possibly causing an accident.



#### NOTICE

- Replacing tire pressure warning valves and transmitters
- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Lexus dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Lexus dealer.
- Ensure that only genuine Lexus wheels are used on your vehicle.
   Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

## Aluminum wheel precautions

- Use only Lexus wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Vehicles with 17-inch tires: Be careful not to damage the aluminum wheels when using tire chains.
- Use only Lexus genuine balance weights or equivalent and a plastic or rubber hammer when balancing


your wheels.

## Air conditioning filter

The air conditioning filter must be changed regularly to maintain air conditioning efficiency.


# Removing the air conditioning filter

- 1 Turn the engine switch off.
- 2 Open the glove box.
- 3 Remove the panel.




- Unlock the filter cover (A), pull the filter cover out of the claws
  (B), and remove the filter cover.
- B

### 5 Remove the filter case.



6 Remove the air conditioning filter from the filter case and replace it with a new one.

The " Tup" marks shown on the filter and the filter case should be pointing up.



### ■ Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Owner's Manual Supplement" or "Scheduled Maintenance".)

### If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

## Air conditioning filter with deodorizing function

When fragrances are placed in your vehicle, the deodorizing effect may become significantly weakened in a short period. When an air conditioning odor comes out continuously, replace the air conditioning

filter.

## <u>^</u>


#### NOTICE

- When using the air conditioning system
- Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

- The filter is replaceable.
   When cleaning the filter, do not clean with water or an air gun.
- ■To prevent damage to the filter cover

When moving the filter cover in the direction of arrow to release the fitting, pay attention not to apply excessive force to the claws. Otherwise, the claws may be damaged.



## **Electronic key battery**

# Replace the battery with a new one if it is depleted.

### ■ If the electronic key battery is depleted

The following symptoms may occur:

- The smart access system with push-button start and wireless remote control will not function properly.
- The operational range will be reduced.

### Items to prepare

Prepare the following before replacing the battery:

- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2032

### ■ Use a CR2032 lithium battery

- Batteries can be purchased at your Lexus dealer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the local laws.


## Replacing the battery

1 Take out the mechanical key.




### 2 Remove the cover.

To prevent damage to the key, wrap the tip of the screwdriver with tape.



### 3 Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.



### **WARNING**

### ■Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.



#### NOTICE

### ■ When replacing the battery

Use a screwdriver of appropriate size. Applying excessive force may deform or damage the cover.

## For normal operation after replacing the battery

Observe the following precautions to prevent accidents:



### **NOTICE**

- Always work with dry hands.
   Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.


# Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

## Checking and replacing fuses


- 1 Turn the engine switch off.
- **2** Open the Fuse box cover.
- ► Engine compartment: type A fuse box

Push the tab in and lift the lid off.



► Engine compartment: type B fuse box


Push the tab in and lift the lid off.



Driver's side instrument panel

Push the tab in and remove the lid.

Make sure to push the tab in during removal or installation.



3 Remove the fuse with the pullout tool

Only type A fuses can be removed using the pullout tool.



4 Check if the fuse is blown.


Type A and B:

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.


Type C:

Contact your Lexus dealer.


▶ Type A



- A Normal fuse
- **B** Blown fuse
- ▶ Type B



- A Normal fuse
- **B** Blown fuse
- ▶ Type C



- A Normal fuse
- **B** Blown fuse

### ■ After a fuse is replaced

- When installing the lid, make sure that the tab is installed securely.
- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P.335)
- If the replaced fuse blows again, have the vehicle inspected by your Lexus dealer.

### ■ If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.

### ■ When replacing light bulbs

Lexus recommends that you use genuine Lexus products designed for this vehicle. Because certain bulbs are connected to circuits designed to prevent overload, nongenuine parts or parts not designed for this vehicle may be unusable.



#### WARNING

### To prevent system breakdowns and vehicle fire

Observe the following precautions. Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Lexus fuse or equivalent.
   Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.



#### **NOTICE**


### ■ Before replacing fuses

Have the cause of electrical overload determined and repaired by your Lexus dealer as soon as possible.


## **Headlight aim**

# Vertical movement adjusting bolts

Vehicles with single-beam headlights



- A Adjustment bolt A
- **B** Adjustment bolt B
- ▶ Vehicles with triple-beam headlights



- A Adjustment bolt A
- **B** Adjustment bolt B

# Before checking the headlight aim

- Make sure the vehicle has a full tank of gasoline and the area around the headlight is not deformed.
- Park the vehicle on level ground.

- Make sure the tire inflation pressure is at the specified level.
- Have someone sit in the driver's seat.
- Bounce the vehicle several times.

## Adjusting the headlight aim

- Vehicles with single-beam headlights
- Using a Phillips-head screwdriver, turn bolt A in either direction.

Remember the turning direction and the number of turns.



2 Turn bolt B the same number of turns and in the same direction as step 1.

If the headlight cannot be adjusted using this procedure, take the vehicle to your Lexus dealer to adjust the headlight aim.




- ► Vehicles with triple-beam headlights
- 1 Using a Phillips-head screwdriver, turn bolt A in either direction.

Remember the turning direction and the number of turns.



2 Turn bolt B the same number of turns and in the same direction as step 1.


If the headlight cannot be adjusted using this procedure, take the vehicle to your Lexus dealer to adjust the headlight aim.



## **Light bulbs**

You may replace the following bulb by yourself. Before replacing, check the wattage of the light bulb to be replaced. As there is a danger that components may be damaged, we recommend that replacement is carried out by your Lexus dealer.

### **Bulb** location



- A Front turn signal lights (vehicles with single-beam headlights)
- **B** Front side marker lights (vehicles with single-beam headlights)
- Bulbs that need to be replaced by your Lexus dealer
- Headlights
- Front position lights and daytime running lights
- Front turn signal lights (vehicles with triple-beam headlights)
- Front side marker lights (vehicles with triple-beam headlights)

- Cornering lights
- Side turn signal lights
- Outer foot lights
- Tail lights
- Stop lights
- Rear turn signal lights
- Rear side marker lights
- Back-up lights
- High mounted stoplight
- License plate lights

### ■ LED lights

The lights other than the front turn signal lights (vehicles with single-beam head-lights) and front side marker lights (vehicles with single-beam headlights) each consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Lexus dealer to have the light replaced.

## Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction. Contact your Lexus dealer for more information in the following situations:

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.
- When replacing light bulbs


→P.333

## Replacing light bulb

- Front turn signal lights (vehicles with single-beam headlights)/front side marker lights (vehicles with single-beam headlights)
- 1 To ensure enough space to perform work, turn the steering wheel


to rotate the front wheel away from the bulb to be replaced. Remove the fender liner clip.

Turn the steering wheel to the left when replacing the right side light bulb, and turn the steering wheel to the right when replacing the left side light bulb.




2 To protect the front bumper from being damaged, apply protective tape around the clips as shown in the illustration.

Use masking tape, etc. Do not use duct tape, as it may leave residue or damage the paint when removed.




Insert a flathead screwdriver between the front bumper and fender liner and then separate the front bumper from the fender liner.

To separate the front bumper from the fender liner, pry up the fender liner while pulling the front bumper outward as shown in the illustration.




4 Pull back the fender liner and turn the bulb base counterclockwise.




- A Front turn signal lights
- **B** Front side marker lights

5 Remove the light bulb.



6 Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.


After installing the light bulb, turn on the front turn signal light to visually check that there is no light leaking from the bulb base.




7 Return the fender liner to its original position, and install the clip.

Make sure that the fender liner is correctly positioned on the inner side of the front

bumper.



8 Engage the clips to the front bumper to install the fender liner, and then remove the protective tape.





### WARNING

### ■Replacing light bulb

 Turn off the light. Do not attempt to replace the bulb immediately after turning off the light.
 The bulb become very hot and may

I he bulb become very hot and may cause burns.

## A

### WARNING

 Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.

Also, if the bulb is scratched or dropped, it may blow out or crack.

- Fully install light bulb and any parts used to secure it. Failure to do so may result in heat damage, fire, or water entering the light unit. This may damage the light or cause condensation to build up on the lens.
- ■To prevent damage or fire
- Make sure bulb is fully seated and locked.
- Check the wattage of the bulb before installing to prevent heat damage.

## When trouble arises

7-1.	Essential information
	Emergency flashers340
	If your vehicle has to be stopped in an emergency340
	If the vehicle is trapped in rising water341
7-2.	Steps to take in an emergency
	If your vehicle needs to be towed343
	If you think something is wrong346
	Fuel pump shut off system 347
	If a warning light turns on or a warning buzzer sounds348
	If a warning message is displayed358
	If you have a flat tire362
	If the engine will not start369
	If you lose your keys371
	If the fuel filler door cannot be opened371
	If the electronic key does not operate properly372
	If the battery is discharged $\dots 374$
	If your vehicle overheats 377
	If the vehicle becomes stuck 379


## **Emergency flashers**

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

### Operating instructions

Press the switch to flash all of the turn signal lights.

To turn them off, press the switch once again.



### ■ Emergency flashers

- If the emergency flashers are used for a long time while the engine is not running, the battery may discharge.
- If any of the SRS airbags deploy (inflate) or in the event of a strong rear impact, the emergency flashers will turn on automatically.

The emergency flashers will turn off automatically after operating for approximately 20 minutes. To manually turn the emergency flashers off, press the switch twice.

(The emergency flashers may not turn on automatically depending on the force of the impact and conditions of the collision.)

# If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

## Stopping the vehicle

1 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

- 2 Shift the shift lever to N.
- If the shift lever is shifted to N
- **3** After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the engine.
- If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- 4 To stop the engine, press and hold the engine switch for 2 consecutive

seconds or more, or press it briefly 3 times or more in succession.



5 Stop the vehicle in a safe place by the road.



#### WARNING

### If the engine has to be turned off while driving

Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.

# If the vehicle is trapped in rising water

## In the event the vehicle is submerged in water, remain calm and perform the following.

- Remove the seat belt first.
- If the door can be opened, open the door and exit the vehicle.
- If the door can not be opened, open the window using the power window switch and exit the vehicle through the window.
- If the window can not be opened using the power window switch, remain calm, wait until the water level inside the vehicle rises to the point that the water pressure inside of the vehicle equals the water pressure outside of the vehicle, and then open the door and exit the vehicle.



### WARNING

## ■ Using an emergency hammer \*1 for emergency escape

The rear side windows and rear window of this vehicle can be shattered by an emergency hammer \*1 used for emergency escape, however, since the windshield and front side windows \*2 are laminated glass they can not be shattered by an emergency hammer \*1.

- \*1: Contact your Lexus dealer or aftermarket accessory manufacturer for further information about an emergency hammer.
- \*2: Vehicles with laminated glass



### **WARNING**


## ■ Escaping the vehicle from the window

There are cases where escaping the vehicle from the window is not possible due to seating position, passenger body type, etc.

When using an emergency hammer, consider your seat location and the size of the window opening to ensure that the opening is accessible and large enough to escape.

### ■ How to distinguish laminated glass

When looking from the cross-sectional view point, laminated glass is two sheets of glass pasted together.



- **A** Laminated glass
- **B** Tempered glass

# If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Lexus dealer or commercial towing service, using a wheel-lift type truck or flatbed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.




### WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

### ■ When towing the vehicle

Be sure to transport the vehicle with the front wheels raised or with all four wheels raised off the ground. If the vehicle is towed with the front wheels contacting the ground, the drivetrain and related parts may be damaged.



- While towing (vehicles with a towing eyelet)
- When towing using cables or chains, avoid sudden starts, etc. which place excessive stress on the towing eyelets, cables or chains. The towing eyelets, cables or chains may become damaged, broken debris may hit people, and cause serious damage.

- Do not turn the engine switch off.
   There is a possibility that the steering wheel is locked and cannot be operated.
- Installing towing eyelets to the vehicle (vehicles with a towing eyelet)

Make sure that towing eyelets are installed securely.

If not securely installed, towing eyelets may come loose during towing.



### NOTICE

- To prevent damage to the vehicle when towing using a wheel-lift type truck
- Do not tow the vehicle from the rear when the engine switch is off. The steering lock mechanism is not strong enough to hold the front wheels straight.
- When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.
- To prevent damage to the vehicle when towing with a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

 To prevent damage to the vehicle during emergency towing (vehicles with a towing eyelet)

Do not secure cables or chains to the suspension components.

# Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Lexus dealer or commercial towing service before towing.

- The engine is running but the vehicle does not move.
- The vehicle makes an abnormal sound.


## Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.




# Towing with a wheel-lift type truck

▶ From the front



Release the parking brake.


▶ From the rear



Use a towing dolly under the front wheels.


# Using a flatbed truck (vehicles with a towing eyelet)

If your vehicle is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be  $45^{\circ}$ .

Do not overly tighten the tie downs or the vehicle may be damaged.



# Emergency towing (vehicles with a towing eyelet)

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using cables or chains secured to the emergency towing eyelets. This should only be attempted on hard surfaced roads for at most 50 miles (80 km) at under 18 mph (30 km/h).

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.


# Emergency towing procedure (vehicles with a towing eyelet)

To have your vehicle towed by another vehicle, the towing eyelet must be installed to your vehicle. Install the towing eyelet using the following procedure.


- Take out the towing eyelet. (→P.363)
- 2 Remove the eyelet cover using a flathead screwdriver.

To protect the bodywork, place a rag between the screwdriver and the vehicle


body as shown in the illustration.



Insert the towing eyelet into the hole and tighten partially by hand.



4 Tighten down the towing eyelet securely using a wheel nut wrench or hard metal bar.



5 Securely attach cables or chains to the towing eyelet.

Take care not to damage the vehicle body.

**6** Enter the vehicle being towed and start the engine.

If the engine does not start, turn the engine switch to IGNITION ON mode.

7 Shift the shift lever to N and release the parking brake.

When the shift lever cannot be shifted:  $\rightarrow$  P.142

### ■ While towing

If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.

#### ■ Wheel nut wrench

Wheel nut wrench is installed in trunk.  $(\rightarrow P.363)$ 

# If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Lexus dealer as soon as possible.

## Visible symptoms

- Fluid leaks under the vehicle. (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge continually points higher than normal.

## Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

## Operational symptoms

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking

- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

## Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

## Restarting the engine

Follow the procedure below to restart the engine after the system is activated.

- 1 Turn the engine switch to ACCES-SORY mode or turn it off.
- **2** Restart the engine.



### NOTICE

### ■ Before starting the engine

Inspect the ground under the vehicle. If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

## If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Lexus dealer.

## Actions to the warning lights or warning buzzers

■ Brake system warning light (warning buzzer)

Warning light	Details/Actions
BRAKE (U.S.A.) or	Indicates that:  The brake fluid level is low; or The brake system is malfunctioning
(red) (Canada)	→ Immediately stop the vehicle in a safe place and contact your Lexus dealer. Continuing to drive the vehicle may be dangerous.

## ■ Brake system warning light (warning buzzer)

Warning light	Details/Actions
	Indicates a malfunction in:  ● The electronically controlled brake system (if equipped); or  ● The parking brake system  → Have the vehicle inspected by your Lexus dealer immediately.

## ■ High coolant temperature warning light (warning buzzer)

Warning light	Details/Actions
L	Indicates that the engine coolant temperature is too high  → Immediately stop the vehicle in a safe place.  Handling method (→P.377)

<sup>\*:</sup> This light illuminates on the multi-information display.

## ■ Charging system warning light\* (warning buzzer)

Warning light	Details/Actions
= +	Indicates a malfunction in the vehicle's charging system  → Immediately stop the vehicle in a safe place and contact your Lexus dealer.

 $<sup>^{\</sup>star}$ : This light illuminates on the multi-information display.

## ■ Low engine oil pressure warning light\* (warning buzzer)

Warning light	Details/Actions
الميكر:	Indicates that the engine oil pressure is too low  → Immediately stop the vehicle in a safe place and contact your Lexus dealer.

<sup>\*:</sup> This light illuminates on the multi-information display.

## ■ Malfunction indicator lamp (warning buzzer)

Warning light	Details/Actions	
CHECK (U.S.A.) or	Indicates a malfunction in:  The electronic engine control system; or The electronic throttle control system;	
(Canada)	→ Immediately stop the vehicle in a safe place and contact your Lexus dealer.	

## ■ SRS warning light (warning buzzer)

Warning light	Details/Actions
•	Indicates a malfunction in:  ■ The SRS airbag system;  ■ The front passenger occupant classification system; or  ■ The seat belt pretensioner system  → Have the vehicle inspected by your Lexus dealer immediately.

■ ABS warning light (warning buzzer)

Warning light	Details/Actions
ABS (U.S.A.) or (Canada)	Indicates a malfunction in:  ● The ABS; or  ● The brake assist system  → Have the vehicle inspected by your Lexus dealer immediately.

■ Brake Override System warning light/Drive-Start Control warning light<sup>\*</sup> (warning buzzer)

Warning light	Details/Actions
••	When a buzzer sounds:  ■ Brake Override System is malfunctioning;  ■ Drive-Start Control is operating; or  ■ Drive-Start Control is malfunctioning  → Follow the instructions displayed on the multi-information display.  When a buzzer does not sound:  Brake Override System is operating  → Release the accelerator pedal and depress the brake pedal.

 $<sup>\</sup>overset{*}{:}\,$  This light illuminates on the multi-information display.

■ Electric power steering system warning light (warning buzzer)

Warning light	Details/Actions
(red) or  (yellow)	Indicates a malfunction in the EPS (Electric Power Steering) system  → Have the vehicle inspected by your Lexus dealer immediately.

### ■ Low fuel level warning light

Warning light	Details/Actions
	Indicates that remaining fuel is approximately 2.4 gal. (9 L, 2.0 Imp.gal.) or less $\rightarrow$ Refuel the vehicle.

## ■ Driver's and front passenger's seat belt reminder light (warning buzzer)\*

Warning light	Details/Actions
	Warns the driver and/or front passenger to fasten their seat belts  → Fasten the seat belt.  If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.

<sup>\*:</sup> Driver's seat belt warning buzzer:

The driver's seat belt warning buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the engine switch is turned to IGNITION ON mode, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 12 mph (20 km/h), the buzzer sounds once. If the seat belt is still unfastened after 24 seconds, the buzzer will sound intermittently for 6 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.

Front passenger's seat belt warning buzzer:

The front passenger's seat belt warning buzzer sounds to alert the front passenger that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of  $12 \, \text{mph} (20 \, \text{km/h})$ . If the seat belt is still unfastened after  $24 \, \text{seconds}$ , the buzzer will sound intermittently for  $6 \, \text{seconds}$ . Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for  $90 \, \text{more seconds}$ .

## Rear passengers' seat belt reminder lights (warning buzzer)

Warning light	Details/Actions
REAR	Warns the rear passengers to fasten their seat belts $ ightarrow$ Fasten the seat belt.

<sup>\*:</sup> Rear passengers' seat belt warning buzzer:

The rear passengers' seat belt warning buzzer sounds to alert the rear passengers that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of  $12 \, \text{mph} (20 \, \text{km/h})$ . If the seat belt is still unfastened after  $24 \, \text{seconds}$ , the buzzer will sound intermittently for  $6 \, \text{seconds}$ . Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for  $30 \, \text{more}$  seconds.

## ■ Tire pressure warning light

Warning light	Details/Actions
(!)	When the light comes on after blinking for approximately 1 minute:  Malfunction in the tire pressure warning system  → Have the system checked by your Lexus dealer.  When the light comes on:  Low tire inflation pressure such as  Natural causes
	<ul> <li>Flat tire</li> <li>→ Immediately stop the vehicle in a safe place.</li> <li>Handling method (→P.355)</li> </ul>

## ■ LTA indicator (warning buzzer)

Warning light	Details/Actions
	Indicates a malfunction in the LTA (Lane Tracing Assist)  → Follow the instructions displayed on the multi-information display.  (→P.184)

## ■ Intuitive parking assist OFF indicator (warning buzzer)

Warning light	Details/Actions
	When a buzzer sounds:
	Indicates a malfunction in the intuitive parking assist function
P <i>י</i> יי≜	ightarrow Have the vehicle inspected by your Lexus dealer immediately.
OFF	When a buzzer does not sound:
(flashes) (if equipped)	Indicates that the system is temporarily unavailable, possibly due to a sensor being dirty or covered with ice, etc.
	$\rightarrow$ Follow the instructions displayed on the multi-information display. $(\rightarrow P.208)$

## ■ RCTA OFF indicator (warning buzzer)

Warning light	Details/Actions
RCTA OFF (flashes) (if equipped)	When a buzzer sounds: Indicates a malfunction in the RCTA (Rear Cross Traffic Alert) function  → Have the vehicle inspected by your Lexus dealer immediately.  When a buzzer does not sound: Indicates that the rear bumper around the radar sensor is covered with dirt, etc. (→P.198)  → Follow the instructions displayed on the multi-information display.  (→P.212)

## ■ RCD OFF indicator (warning buzzer)

Warning light	Details/Actions
RCD OFF (flashes) (if equipped)	When a buzzer sounds: Indicates a malfunction in the RCD (Rear Camera Detection) function  → Have the vehicle inspected by your Lexus dealer immediately. When a buzzer does not sound: Indicates that the function temporarily cannot be used due to the camera being dirty, etc.  → Follow the instructions displayed on the multi-information display. (→P.216, 358)

## ■ PKSB OFF indicator (warning buzzer)

When a buzzer sounds:	Warning light	Details/Actions
Indicates a malfunction in the PKSB (Parking Support Brake) system  Have the vehicle inspected by your Lexus dealer immediately.  When a buzzer does not sound:  Indicates that the system is temporarily unavailable, possibly due to a sensor being dirty or covered with ice, etc.  Follow the instructions displayed on the multi-information display (→P.222, 358)	OFF (flashes) (if equipped)	Indicates a malfunction in the PKSB (Parking Support Brake) system  → Have the vehicle inspected by your Lexus dealer immediately.  When a buzzer does not sound:  Indicates that the system is temporarily unavailable, possibly due to a sensor being dirty or covered with ice, etc.  → Follow the instructions displayed on the multi-information display.

## ■ PCS warning light (warning buzzer)

Warning light	Details/Actions
Warning light	When a buzzer sounds simultaneously: Indicates a malfunction has occurred in the PCS (Pre-Collision System)  → Have the vehicle inspected by your Lexus dealer immediately. When a buzzer does not sound: Indicates that the PCS (Pre-Collision System) has become temporarily unavailable, corrective action may be necessary.
nates)	<ul> <li>→ Follow the instructions displayed on the multi-information display.</li> <li>(→P.167, 358)</li> <li>If the PCS (Pre-Collision System) or VSC (Vehicle Stability Control) system is disabled, the PCS warning light will illuminate.</li> <li>→ P.175</li> </ul>

## ■ Slip indicator

Warning light	Details/Actions
<b>(1)</b>	Indicates a malfunction in:  ● The VSC system;  ● The TRAC system; or  ● The hill-start assist control system  → Have the vehicle inspected by your Lexus dealer immediately.

## ■ Parking brake indicator

Warning light	Details/Actions
PARK (flashes) (U.S.A.) or (flashes) (flashes) (Canada)	Indicates a malfunction in the parking brake system  → Have the vehicle inspected by your Lexus dealer immediately.

### ■ Brake hold operated indicator (warning buzzer)

Warning light	Details/Actions
HOLD	Indicates a malfunction in the brake hold system  → Have the vehicle inspected by your Lexus dealer immediately.

### ■ Master warning light (warning buzzer)

Warning light	Details/Actions
	A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction. $\rightarrow P.358$

### ■ Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

## Front passenger detection sensor, seat belt reminder and warning buzzer

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

### SRS warning light

This warning light system monitors the airbag sensor assembly, front impact sensors, side impact sensors (front door), side impact sensors (front), side impact sensors (rear), driver's seat position sensor, driver's seat belt buckle switch, front passenger occupant classification system (ECU and sensors), "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioners, airbags, interconnecting wiring and power sources.

### If the malfunction indicator lamp comes on while driving

First check the following:

Is the fuel tank empty?

If it is, fill the fuel tank immediately.

Is the fuel tank cap loose? If it is, tighten it securely.

The light will go off after several driving trips.

If the light does not go off even after several trips, contact your Lexus dealer as soon as possible.

## ■ Electric power steering system warning light (warning buzzer)

When the battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

## When the tire pressure warning light comes on

Inspect the tires to check if a tire is punctured.

If a tire is punctured:  $\rightarrow$  P.362

If none of the tires are punctured: Turn the engine switch off then turn it to IGNITION ON mode. Check if the tire pressure warning light comes on or blinks. ▶ If the tire pressure warning light blinks for approximately 1 minute then stays on

There may be a malfunction in the tire pressure warning system. Have the vehicle inspected by your Lexus dealer immediatelv.

- ▶ If the tire pressure warning light comes on
- After the temperature of the tires has lowered sufficiently, check the inflation pressure of each tire and adjust them to the specified level.
- 2 If the warning light does not turn off even after several minutes have elapsed, check that the inflation pressure of each tire is at the specified level and perform initialization.  $(\rightarrow P.321)$

### ■ The tire pressure warning light may come on due to natural causes

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

### ■ When a tire is replaced with a spare tire

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire. Replace the spare tire with the repaired tire and adjust the tire inflation pressure. The tire pressure warning light will go off after a few minutes.

### Conditions that the tire pressure warning system may not function properly

 $\rightarrow$ P 319

## **WARNING**

### If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact your Lexus dealer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

### ■ When the electric power steering system warning light comes on

When the light comes on yellow, the assist to the power steering is restricted. When the light comes on red, the assist to the power steering is lost and handling operations of the steering wheel become extremely heavy.

When steering wheel operations are heavier than usual, grip the steering wheel firmly and operate it using more force than usual.

### If the tire pressure warning light comes on

Be sure to observe the following precau-

Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Check and adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat. change it with the spare tire and have the flat tire repaired by the nearest Lexus dealer.
- Avoid abrupt maneuvering and brak-

If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes



## **WARNING**

### ■ If a blowout or sudden air leakage should occur

The tire pressure warning system may not activate immediately.

### Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subseguent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.



#### NOTICE


### To ensure the tire pressure warning system operates properly

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.

## If a warning message is displayed

The multi-information display shows warnings of system malfunctions, incorrectly performed operations, and messages that indicate a need for maintenance. When a message is shown, perform the correction procedure appropriate to the message.

Except F SPORT models:



A Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

B Multi-information display
Follow the instructions of the message
on the multi-information display.
If any of the warning messages are
shown again after the appropriate
actions have been performed, contact
your Lexus dealer.

F SPORT models (main meter in center position):



**A** Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

B Multi-information display
Follow the instructions of the message on the multi-information display.
If any of the warning messages are shown again after the appropriate actions have been performed, contact your Lexus dealer.

# F SPORT models (main meter moved to the right):



### A Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

**B** Multi-information display

Follow the instructions of the message on the multi-information display. If any of the warning messages are shown again after the appropriate actions have been performed, contact your Lexus dealer.

### Messages and warnings

The master warning light and warning buzzers operate as follows depending on the content of the message. If a message indicates the need for inspection by a dealer, have the vehicle inspected by your Lexus dealer immediately.

A	Warning buzzer*	Warning
Comes on	Sounds	Indicates an important situation, such as when a system related to driving is malfunctioning or that danger may result if the correction procedure is not performed
Flashes	Sounds	Indicates a situation, such as when damage to the vehicle or danger may result

A	Warning buzzer*	Warning
Comes on	Does not sound	Indicates a condition, such as malfunction of electrical components, their condition, or indicates the need for maintenance
Flashes	Does not sound	Indicates a situation, such as when an operation has been performed incorrectly, or indicates how to perform an operation correctly

- $\overset{\star}{:}$  A buzzer sounds the first time a message is shown on the multi-information display.
- In some situations, the master warning light and warning buzzer may not operate as specified. In this case, follow the instructions displayed in the warning message.
- If a warning light comes on or flashes at the same time that a warning message is displayed, take corrective action according to the warning light.  $(\rightarrow P.348)$

#### ■ Warning messages

The warning messages explained below may differ from the actual messages according to operation conditions and vehicle specifications.

#### ■ Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

# ■ If "Engine Oil Level Low Add or Replace" is displayed

The engine oil level is low. Check the level of the engine oil, and add if necessary.

This message may appear if the vehicle is stopped on a slope. Move the vehicle to a level surface and check to see if the message disappears.

#### ■ If "Engine Stopped Steering Power Low" is displayed

This message is displayed if the engine is stopped while driving.

When steering wheel operations are heavier than usual, grip the steering wheel firmly and operate it using more force than usual.

#### ■ If "Auto Power Off to Conserve Battery" is displayed

Power was turned off due to the automatic power off function. Next time when starting the engine, increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery.

#### If "High Power Consumption Power to Climate Temporarily Limited" is displayed

Turn off unnecessary electronic equipment to reduce power consumption.

Please wait until the power supply returns to normal.

# ■ If "Headlight System Uninitialized Visit Your Dealer" is displayed

The following systems may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

- The LED headlight system
- AFS (Adaptive Front-lighting System)
- The automatic headlight leveling system (if equipped)
- Automatic High Beam

#### ■ If "Radar Cruise Control Unavailable See Owner's Manual" is displayed

The dynamic radar cruise control with full-

speed range system is suspended temporarily or until the problem shown in the message is resolved. (causes and coping methods: →P.167)

#### If "Radar Cruise Control Unavailable" is displayed

The dynamic radar cruise control with fullspeed range system cannot be used temporarily. Use the system when it becomes available again.

#### If "Front Camera Unavailable" is displayed

The following systems may be suspended until the problem shown in the message is resolved. (→P.167, 354)

- PCS (Pre-Collision System)
- LTA (Lane Tracing Assist)
- Automatic High Beam
- RSA (Road Sign Assist) (if equipped)
- Dynamic radar cruise control with fullspeed range

#### If "Maintenance Required Soon" is displayed

Indicates that all maintenance according to the driven distance on the maintenance schedule should be performed soon.

Comes on approximately 4500 miles (7200 km) after the message has been reset. If necessary, perform maintenance. Please reset the message after the maintenance is performed.  $(\rightarrow P.301)$ 

\*: Refer to the separate "Scheduled Maintenance" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

#### ■ If "Maintenance Required Visit Your Dealer" is displayed

Indicates that all maintenance is required to correspond to the driven distance on the maintenance schedule.\*

Comes on approximately 5000 miles (8000 km) after the message has been reset. (The indicator will not work properly unless the message has been reset.) Perform the necessary maintenance. Please reset the message after the maintenance is

performed.  $(\rightarrow P.301)$ 

\*: Refer to the separate "Scheduled Maintenance" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

#### ■ If "Oil Maintenance Required Soon" is displayed

Indicates that the engine oil should be scheduled to be changed.

Check the engine oil and change it if necessary. After changing the engine oil, make sure to reset the message.  $(\rightarrow P.312)$ 

#### If "Oil Maintenance Required" is displayed

Indicates that the engine oil should be changed.

Check and change the engine oil, and oil filter by your Lexus dealer. After changing the engine oil, make sure to reset the message. ( $\rightarrow$ P.312)

#### If a message that indicates the need for visiting your Lexus dealer is displayed

The system or part shown on the multiinformation display is malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

#### If a message that indicates the need for referring to Owner's Manual is displayed

- If any of the following messages are shown on the multi-information display, follow the instructions.
- "Engine Coolant Temp High" (→P.377)
- If any of the following messages are shown on the multi-information display, it may indicate a malfunction. Have the vehicle inspected by your Lexus dealer immediately.
- "Access System with Elec. Key Malfunction"
- If any of the following messages are shown on the multi-information display, it may indicate a malfunction. Immediately stop the vehicle and contact your Lexus dealer.
- "Braking Power Low"
- "Charging System Malfunction"
- "Oil Pressure Low"



#### **NOTICE**

If "High Power Consumption Power to Climate Temporarily Limited" is displayed frequently

There is a possible malfunction relating to the charging system or the battery may be deteriorating. Have the vehicle inspected by your Lexus dealer.

### If you have a flat tire

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire. For details about tires: →P.316



#### WARNING


#### ■ If you have a flat tire

Do not continue driving with a flat tire. Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

### Before jacking up the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.
- Turn on the emergency flashers.
   (→P.340)

### Location of the spare tire, jack and tools



- A Wheel nut wrench
- **B** Wheel lock key\* (if equipped)
- **C** Jack
- D Jack handle
- **E** Spare tire
- F Towing eyelet (if equipped)
- \*: Documentation relating to the wheel lock key, such as the registration and I.D. card, is inside the glove box.



#### WARNING

### ■ Using the tire jack

Observe the following precautions. Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.

 Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.

- Only use the tire jack that comes with this vehicle for replacing a flat tire. Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Put the jack properly in its jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.

### A

#### WARNING

- Do not start the engine or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.

### Wheel lock nut (if equipped)

When replacing tires on a vehicle with wheel lock nuts, use the following procedures to remove and install the wheel lock nuts. The wheel lock key is stored in the tray inside the luggage compartment. Always return the wheel lock key to its original position after use, so that it does not get lost.

#### ■ Removal

For ease of removal, the wheel lock nut should always be the first one loosened.

- Place the wheel lock key on top of the wheel lock nut, turning until the wheel lock key and wheel lock nut patterns engage.
- Place the wheel nut wrench on the wheel lock key, and while applying

pressure on the wheel lock key, loosen the wheel lock nut.

#### ■ Installation

For ease of installation, the wheel lock nut should always be the last one tightened.

- 1 By hand, install a wheel lock nut on each wheel.
- Place the wheel lock key on top of the wheel lock nut, turning until the wheel lock key and wheel lock nut patterns engage.
- 3 Place the wheel nut wrench on the wheel lock key, and while applying pressure on the wheel lock key, tighten the wheel lock nut to the recommended torque.




#### NOTICE


Do not use an impact wrench. Using an impact wrench may cause permanent damage to wheel lock nut and wheel lock key. If in doubt about wheel lock application, contact your Lexus dealer.

### Taking out the jack


- 1 Open the trunk.
- 2 Pull the lever upwards when lifting the luggage mat up.



**3** The lever can be hooked on the edge of the trunk.



4 Remove the jack.



### $\triangle$


#### **NOTICE**

#### ■ To prevent damage to luggage mat


When closing the trunk door, do not leave the luggage mat lever hooked on the edge of the trunk.

### Taking out the spare tire

1 Remove the auxiliary box.



**2** Loosen the center fastener that secures the spare tire.



### A


#### **WARNING**

#### ■ When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.


### Replacing a flat tire

1 Chock the tires.




Flat tire	Wheel chock positions
Front left- hand side	Behind the rear right-hand side tire
Front right- hand side	Behind the rear left-hand side tire
Rearleft-hand side	In front of the front right- hand side tire
Rear right- hand side	In front of the front left- hand side tire

2 Slightly loosen the wheel nuts (one turn).




**3** Turn the tire jack portion **A** by hand until the notch of the jack is in contact with the jack point.


The jack point guides are located under the rocker panel. They indicate the jack point positions.



4 Assemble the jack handle.




5 Raise the vehicle until the tire is slightly raised off the ground.



6 Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



### A

#### **WARNING**

### Replacing a flat tire

Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven. After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.




### **WARNING**

- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.
- Have the wheel nuts tightened with a torque wrench to 76 ft-lbf (103 N·m, 10.5 kgf·m) as soon as possible after changing wheels.
- When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
- If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Lexus dealer.
- Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.

### Installing the spare tire


Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.



2 Install the spare tire and loosely tighten each wheel nut by hand by approximately the same amount.

Tighten the wheel nuts until the tapered portion A comes into loose contact with the disc wheel seat **B**.



3 Lower the vehicle.



4 Firmly tighten each wheel nut two or three times in the order shown in the illustration.

Tightening torque:

#### 76 ft • lbf (103 N • m, 10.5 kgf • m)



5 Stow the flat tire, tire jack and all tools

#### ■ The compact spare tire

- The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.
  - Use the compact spare tire temporarily, and only in an emergency.
- Make sure to check the tire inflation pressure of the compact spare tire.  $(\rightarrow P.387)$

#### ■ After completing the tire change

The tire pressure warning system must be reset.  $(\rightarrow P.321)$ 

#### ■ When using the compact spare tire

As the compact spare tire is not equipped with a tire pressure warning valve and transmitter, low inflation pressure of the spare tire will not be indicated by the tire pressure warning system. Also, if you replace the compact spare tire after the tire pressure warning light comes on, the light remains on.

# ■ When the compact spare tire is equipped

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires.

# If you have a flat front tire on a road covered with snow or ice

Install the compact spare tire on one of the rear wheels of the vehicle. Perform the following steps and fit tire chains to the front tires:

- 1 Replace a rear tire with the compact spare tire.
- 2 Replace the flat front tire with the tire removed from the rear of the vehicle.
- **3** Fit tire chains to the front tires.

### A

#### WARNING

#### ■ When using the compact spare tire

- Remember that the compact spare tire provided is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tire simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.

## ■ When the compact spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC
- TRAC
- Dynamic radar cruise control with fullspeed range
- PCS (Pre-Collision System)
- FPS
- LTA (Lane Tracing Assist)
- Panoramic view monitor (if equipped)
- Lexus parking assist monitor (if equipped)
- Intuitive parking assist (if equipped)
- Navigation system (if equipped)
- BSM (Blind spot monitor) (if equipped)
- Automatic high Beam



### **WARNING**

#### Speed limit when using the compact spare tire

Do not drive at speeds in excess of 50 mph (80 km/h) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failure to observe this precaution may lead to an accident causing death or serious injury.

#### After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden brakina.



#### NOTICE

#### Be careful when driving over bumps with the compact spare tire installed on the vehicle

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

#### Driving with tire chains and the compact spare tire

Do not fit tire chains to the compact spare tire.

Tire chains may damage the vehicle body and adversely affect driving performance.

### When replacing the tires

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Lexus dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

### If the engine will not start

If the engine will not start even though correct starting procedures are being followed ( $\rightarrow$ P.137), consider each of the following points:

### The engine will not start even though the starter motor operates normally.

One of the following may be the cause of the problem:

- The electronic key may not be functioning properly.  $(\rightarrow P.373)$
- There may not be sufficient fuel in the vehicle's tank Refuel the vehicle.  $(\rightarrow P.161)$
- The engine may be flooded. Try to restart the engine again following correct starting procedures.  $(\to P.137)$
- There may be a malfunction in the engine immobilizer system.  $(\to P.54)$
- There may be a malfunction in the steering lock system.

The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

The battery may be discharged.

 $(\to P.374)$ 

 The battery terminal connections may be loose or corroded.

# The starter motor does not turn over

The engine starting system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, an interim measure is available to start the engine.

The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged.
   (→P.374)
- There may be a malfunction in the steering lock system.

Contact your Lexus dealer if the problem cannot be repaired, or if repair procedures are unknown.

# Starting the engine in an emergency

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally:

 Press the parking brake switch to check that the parking brake is set. (→P.146)

Parking brake indicator will come on.

- 2 Shift the shift lever to P.
- 3 Turn the engine switch to ACCES-SORY mode.
- 4 Press and hold the engine switch for about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

### If you lose your keys

New genuine mechanical keys can be made by your Lexus dealer using another mechanical key and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.



#### **NOTICE**

#### ■ When an electronic key is lost


If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Lexus dealer immediately with all remaining electronic keys that were provided with your vehicle.

# If the fuel filler door cannot be opened

If the fuel filler door opener switch cannot be operated, the following procedure can be used to open the fuel filler door.

### Opening the fuel filler door

Remove the cover inside the trunk and pull the lever.



# If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted ( $\rightarrow$ P.101) or the electronic key cannot be used because the battery is depleted, the smart access system with push-button start and wireless remote control cannot be used. In such cases, the doors and trunk can be opened and the engine can be started by following the procedure below.

- When the electronic key does not work properly
- Make sure that the smart access system with push-button start has not been deactivated using the Remote Touch or at your Lexus dealer. If it is off, turn the function on.
- Check if battery-saving mode is set. If it is set, cancel the function.  $(\rightarrow P.101)$



#### **NOTICE**

■ In case of a smart access system with push-button start malfunction or other key-related problems


Take your vehicle with all the electronic keys provided with your vehicle to your Lexus dealer as soon as possible.

# Locking and unlocking the doors, opening the trunk and using the key linked functions


Use the mechanical key  $(\rightarrow P.88)$  in order to perform the following operations:

### ■ Unlocking the door


1 Pull the driver's door handle and insert the mechanical key.



2 Unlock the door.




- 3 Remove the key, return the handle, and then pull the handle again.
- Locking the door
- 1 With the door open, push down the inside lock button.




- 2 Close the door.
- Opening the trunk

Turn the mechanical key clockwise to

open.



### ■ Key linked functions



- Closes the windows and the moon roof (if equipped) or panoramic moon roof (if equipped) (turn and hold)
- 2 Opens the windows and the moon roof (if equipped) or panoramic moon roof (if equipped) (turn and hold)

These settings must be customized at your Lexus dealer.



#### WARNING

 When using the mechanical key and operating the power windows or moon roof (if equipped) or panoramic moon roof (if equipped)

Operate the power window, moon roof or panoramic moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window, moon roof or panoramic moon roof.

Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window, moon roof or panoramic moon roof.

### Starting the engine

- 1 Ensure that the shift lever is in P and depress the brake pedal.
- 2 Touch the Lexus emblem side of the electronic key to the engine switch.

When the electronic key is detected, a buzzer sounds and the engine switch will turn to IGNITION ON mode.

When the smart access system with pushbutton start is deactivated in customization setting, the engine switch will turn to ACCESSORY mode.



- Firmly depress the brake pedal and check that shown on the multi-information display.
- **4** Press the engine switch shortly and firmly.

In the event that the engine still cannot be started, contact your Lexus dealer.

### ■ Stopping the engine

Set the parking brake, shift the shift lever to P and press the engine switch as you normally do when stopping the engine.

### ■ Electronic key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. (\$\rightarrow\$P.330)

#### ■ Changing engine switch modes

Release the brake pedal and press the

engine switch in step **3** above.

The engine does not start and modes will be changed each time the switch is pressed.  $(\rightarrow P.139)$ 

### If the battery is discharged

The following procedures may be used to start the engine if the battery is discharged.


You can also call your Lexus dealer or a qualified repair shop.

### Restarting the engine

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle using the following procedure.

1 Confirm that the electronic key is being carried.


When connecting the jumper (or booster) cables, depending on the situation, the alarm may activate and doors locked. (\$\rightarrow\$P.57)



2 Open the hood.  $(\rightarrow P.308)$ 

3 Connect a positive jumper cable clamp to A on your vehicle and connect the clamp on the other end of the positive cable to B on the second vehicle.

Then, connect a negative cable clamp to  $\boxed{\mathbf{C}}$  on the second vehicle and connect the clamp at the other end of the negative cable to  $\boxed{\mathbf{D}}$ .



- A Positive (+) battery terminal (your vehicle)
- **B** Positive (+) battery terminal (second vehicle)
- C Negative (-) battery terminal (second vehicle)
- D Solid, stationary, unpainted metallic point away from the battery and any moving parts as shown in the illustration
- 4 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- 5 Open and close any of the doors of your vehicle with the engine switch off.
- Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the engine switch to IGNITION ON mode.
- 7 Once the vehicle's engine has started, remove the jumper cables

in the exact reverse order from which they were connected.

Once the engine starts, have the vehicle inspected at your Lexus dealer as soon as possible.

# Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

- To prevent battery discharge
- Turn off the headlights and the audio system while the engine is stopped.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.
- When the battery is removed or discharged
- Information stored in the ECU is cleared.

When the battery is depleted, have the vehicle inspected at your Lexus dealer.

• Some systems may require initialization.  $(\rightarrow P.410)$ 

#### ■ When removing the battery terminals

When the battery terminals are removed, the information stored in the ECU is cleared. Before removing the battery terminals, contact your Lexus dealer.

#### ■ Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

# ■ When recharging or replacing the battery

- In some cases, it may not be possible to unlock the doors using the smart access system with push-button start when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- The engine may not start on the first attempt after the battery has recharged but will start normally after the second attempt. This is not a malfunction.
- The engine switch mode is memorized by the vehicle. When the battery is reconnected, the system will return to the mode it was in before the battery was discharged. Before disconnecting the battery, turn the engine switch off. If you are unsure what mode the engine switch was in before the battery discharged, be especially careful when reconnecting the battery.

### ■ When replacing the battery

- Use a battery that conforms to European regulations.
- Use a battery that the case size is same as the previous one (LN3), 20 hour rate capacity (20HR) is equivalent (70Ah) or greater, and performance rating (CCA) is equivalent (592A) or greater.
- · If the sizes differ, the battery cannot be

- properly secured.
- Battery performance may decrease and the engine may not be able to start.
- If the 20 hour rate capacity is low, even if the time period where the vehicle is not used is a short time, the battery may discharge and engine may not be able to start.

For details, consult your Lexus dealer.



#### **WARNING**

#### ■ When removing the battery terminals

Always remove the negative (-) terminal first. If the positive (+) terminal contacts any metal in the surrounding area when the positive (+) terminal is removed, a spark may occur, leading to a fire in addition to electrical shocks and death or serious injury.

#### Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery:

- Make sure each jumper cable is connected to the correct terminal and that
  it is not unintentionally in contact with
  any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

#### ■ Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:



### **WARNING**

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention. Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.

#### ■ When replacing the battery

When the vent plug and indicator are close to the hold down clamp, the battery fluid (sulfuric acid) may leak.



#### NOTICE

### When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fan or engine drive belt.

### If your vehicle overheats


### The following may indicate that your vehicle is overheating.

- The engine coolant temperature gauge  $(\rightarrow P.64, 67)$  is in the red zone or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- "Engine Coolant Temp High Stop in a Safe Place See Owner's Manual" is shown on the multiinformation display.
- Steam comes out from under the hood.

### Correction procedures

- Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- **2** If you see steam: Carefully lift the hood after the steam subsides. If you do not see steam: Carefully lift the hood.
- 3 After the engine has cooled down sufficiently, inspect the hoses and


radiator core (radiator) for any leaks.



- **A** Radiator
- **B** Cooling fan

If a large amount of coolant leaks, immediately contact your Lexus dealer.


4 The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir.



- A Reservoir
- **B** "F" line
- C "L" line
- D Coolant inlet cap
- **5** Add coolant if necessary.

Water can be used in an emergency if

coolant is unavailable.



Start the engine and turn the air conditioning system on to check that the radiator cooling fan operates and to check for coolant leaks from the radiator or hoses.

The fan operates when the air conditioning system is turned on immediately after a cold start. Confirm that the fan is operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fan may not operate in freezing temperatures.)

7 If the fan is not operating: Stop the engine immediately and contact your Lexus dealer. If the fan is operating: Have the vehicle inspected at the nearest Lexus dealer.



#### WARNING

■ When inspecting under the hood of your vehicle

Observe the following precautions. Failure to do so may result in serious injury such as burns.

 If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.

### A

#### WARNING

- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- While the engine and radiator are hot, do not loosen or remove the coolant inlet cap or coolant reservoir cap. High temperature steam or coolant could spray out.



#### NOTICE

#### ■ When adding engine coolant

Add coolant slowly after the engine has cooled down sufficiently. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

■ To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additive.

### If the vehicle becomes stuck


Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt or snow:

### Recovering procedure

- 1 Stop the engine. Set the parking brake and shift the shift lever to P.
- 2 Remove the mud, snow or sand from around the front wheels.
- 3 Place wood, stones or some other material under the front wheels to help provide traction.
- 4 Restart the engine.
- 5 Shift the shift lever to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

#### ■ When it is difficult to free the vehicle

Press the > switch to turn off TRAC.





#### WARNING

#### When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

#### ■ When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.



#### NOTICE

- To avoid damaging the transmission and other components
- Avoid spinning the front wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

# Vehicle specifications

8-1.	Specifications
	Maintenance data (fuel, oil level, etc.)
	Fuel information389
	Tire information391
8-2.	Customization
	Customizable features400
8-3.	Items to initialize
	Items to initialize410

### Maintenance data (fuel, oil level, etc.)

### Dimensions and weight

Overall length		195.9 in. (4975 mm)
Overall width		73.4 in. (1865 mm)
Overall height*1		56.9 in. (1445 mm)
Wheelbase		113.0 in. (2870 mm)
	Front	62.9 in. (1598)*2
Tread <sup>*1</sup>		62.6 in. (1588) <sup>*3</sup>
read	Rear	63.3 in. (1609)*2
		63.0 in. (1599) <sup>*3</sup>
Vehicle capacity weight (Occupants + luggage)		905 lb. (410 kg)

<sup>\*1:</sup> Unladen vehicle

### Vehicle identification

#### ■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Lexus. It is used in registering the ownership of your vehicle.


This number is stamped on the top left of the instrument panel.



This number is also stamped under the right-hand front seat.

<sup>\*2:</sup> Vehicles with 215/55R17 tires

 $<sup>^{\</sup>star 3}$ : Vehicles with 235/45R18 tires and 235/40R19 tires




This number is also on the Certification Label.



### ■ Engine number

The engine number is located as shown.



### Engine

Model	3.5 L 6-cylinder (2GR-FKS)
Туре	6-cylinder V type, 4-cycle, gasoline
Bore and stroke	$3.70 \times 3.27$ in. $(94.0 \times 83.0 \text{ mm})$
Displacement	210.9 cu.in. (3456 cm <sup>3</sup> )
Valve clearance	Automatic adjustment
Drive belt tension	Automatic adjustment

### Fuel

Fuel type	Unleaded gasoline only
Octane Rating	87 (Research Octane Number 91) or higher
Fuel tank capacity (Reference)	16.0 gal. (60.6 L, 13.3 Imp.gal.)

### Lubrication system

# Oil capacity (Drain and refill [Reference\*])

With filter	5.7 qt. (5.4 L, 4.8 Imp.qt.)
Without filter	5.6 qt. (5.3 L, 4.7 Imp.qt.)

to the engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

#### ■ Engine oil selection


"Toyota Genuine Motor Oil" is used in your Lexus vehicle. Use Lexus approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC GF-5 multigrade engine oil

Recommended viscosity: SAE OW-20

SAE OW-20 is the best choice for good fuel economy and good starting in cold weather.

If SAE OW-20 is not available, SAE 5W-20 oil may be used. However, it must be replaced with SAE OW-20 at the next oil change.



**A** Outside temperature

Oil viscosity (OW-20 is explained here as an example):

- The OW in OW-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in OW-20 indicates the viscosity characteristic of the oil when
  the oil is at high temperature. An oil
  with a higher viscosity (one with a
  higher value) may be better suited if
  the vehicle is operated at high
  speeds, or under extreme load conditions.

How to read oil container label:

The International Lubricant Specification Advisory Committee (ILSAC)
Certification Mark is added to some oil containers to help you select the oil you should use.



### Cooling system

Capacity*	9.1 qt. (8.6 L, 7.6 Imp.qt.)
Coolant type	Use either of the following:  • "Toyota Super Long Life Coolant"  • Similar high-quality ethylene glycolbased non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology  Do not use plain water alone.

<sup>\*:</sup> The fluid capacity is a reference quantity.

If replacement is necessary, contact your Lexus dealer.

### Ignition system

### ■ Spark plug

Make	DENSO FK20HBR8
Gap	0.031 in. (0.8 mm)



#### **NOTICE**

### ■ Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust the spark plug gap.

### Electrical system (battery)

Open voltage at 68°F (20°C):	12.3 V or higher (Turn the engine switch off and turn on the high beam headlights for 30 seconds.)
Charging rates	
Quick charge	15 A max.
Slow charge	5 A max.

### Automatic transmission

Fluid capacity*	8.0 qt. (7.6 L, 6.7 lmp.qt.)
Fluid type	Toyota Genuine ATF WS

### **386** 8-1. Specifications

\*: The fluid capacity is a reference quantity.

If replacement is necessary, contact your Lexus dealer.



#### **NOTICE**

#### Automatic transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

#### Brakes

Pedal clearance *1	3.2 in. (81 mm) Min.
Pedal free play	0.04—0.24 in. (1.0—6.0 mm)
Brake pad wear limit	0.04 in. (1.0 mm)
Parking brake lining wear limit	0.04 in. (1.0 mm)
Parking brake indicator*2	When pushing the parking brake switch for 1 to 2 seconds: comes on
	When pulling the parking brake switch for 1 to 2 seconds: turns off
Fluid type	FMVSS No.116 DOT 3 or SAE J1703
	FMVSS No.116 DOT 4 or SAE J1704

<sup>\*1:</sup> Minimum pedal clearance when depressed with a force of 67.4 lbf (300 N, 30.6 kgf) while the engine is running.

When performing the brake pedal inspection, also be sure to check that the brake system warning light is not illuminated when the engine is running. (If the brake system warning light is illuminated, refer to P.348.)

\*2: Make sure to confirm that the brake system warning light (yellow) does not illuminate. (If the brake system warning light illuminates, refer to P.352.)

### Steering

Free play	Less than 1.2 in. (30 mm)
-----------	---------------------------

### Tires and wheels

### ▶ Type A

Tire size	215/55R17 94V, T155/70D17 110M		
Tire inflation pressure (Recommended cold tire inflation pressure)	Front		
	36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>		
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>		
	Rear		
	36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>		
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>		
	Spare		
	60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)		
Wheel size	17 x 7 1/2J, 17 x 4T (compact spare)		
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)		

<sup>\*1: 99</sup> mph (160 km/h) or less

### ▶ Type B

Tire size	235/45R18 94V, T155/70D17 110M	
Tire inflation pressure (Recommended cold tire inflation pressure)	Front	
	35 psi (240 kPa, 2.4 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>	
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>	
	Rear	
	35 psi (240 kPa, 2.4 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>	
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>	
	Spare	
	60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)	
Wheel size	18 x 8J, 17 x 4T (compact spare)	
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)	

<sup>\*1: 99</sup> mph (160 km/h) or less

<sup>\*2:</sup> More than 99 mph (160 km/h)

<sup>\*2:</sup> More than 99 mph (160 km/h)

### 388 8-1. Specifications

### ▶ Type C

Tire size	235/40R19 92V, T155/70D17 110M	
Tire inflation pressure (Recommended cold tire inflation pressure)	Front	
	35 psi (240 kPa, 2.4 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>	
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>	
	Rear	
	35 psi (240 kPa, 2.4 kgf/cm <sup>2</sup> or bar) <sup>*1</sup>	
	46 psi (320 kPa, 3.2 kgf/cm <sup>2</sup> or bar) <sup>*2</sup>	
	Spare	
	60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)	
Wheel size	19 x 8J, 17 x 4T (compact spare)	
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)	

<sup>\*1: 137</sup> mph (220 km/h) or less

# Light bulbs

Light bulbs	Bulb No.	W	Туре
Front turn signal lights (single-beam headlights)	7444NA	28/8	Wedge base bulbs (amber)
Front side marker lights (single-beam headlights)	W5W	5	Wedge base bulbs (clear)

 $<sup>^{*2}</sup>$ : More than 137 mph (220 km/h)

#### **Fuel information**

You must only use unleaded gasoline.

Select premium unleaded gasoline with an octane rating of 87 (Research Octane Number 91) or higher required for optimum engine performance and fuel economy. If the octane rating is less than 87, damage to the engine may occur and may void the vehicle warranty.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A..

#### ■ Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Lexus dealer.

#### ■ Gasoline quality standards

- Automotive manufacturers in the U.S.A., Europe and Japan have developed a specification for fuel quality called the World-Wide Fuel Charter (WWFC), which is expected to be applied worldwide.
- The WWFC improves air quality by lowering emissions in vehicle fleets, and improves customer satisfaction through better performance.
- Recommendation of the use of gasoline containing detergent additives
- Lexus recommends the use of gasoline that contains detergent additives to avoid the build-up of engine deposits.
- All gasoline sold in the U.S.A. contains minimum detergent additives to clean and/or keep clean intake systems, per

- EPA's lowest additives concentration program.
- Lexus strongly recommends the use of Top Tier Detergent Gasoline. For more information on Top Tier Detergent Gasoline and a list of marketers, please go to the official website www.toptiergas.com.

#### Recommendation of the use of low emissions gasoline


Gasolines containing oxygenates such as ethers and ethanol, as well as reformulated gasolines, are available in some cities. These fuels are typically acceptable for use, providing they meet other fuel requirements.

Lexus recommends these fuels, since the formulations allow for reduced vehicle emissions.

# ■ Non-recommendation of the use of blended gasoline

 Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30 (30% ethanol  $[\overline{\bf A}]$ ), E50 (50% ethanol  $[\overline{\bf B}]$ ), E85 (85% ethanol  $[\overline{\bf C}]$ ) (which are only some examples of fuel containing more than 15% ethanol).



- If you use gasohol in your vehicle, be sure that it has an octane rating no lower than 91.
- Lexus does not recommend the use of gasoline containing methanol.
- Non-recommendation of the use of gasoline containing MMT

Some gasoline contains an octane enhancing additive called MMT (Methylcyclopentadienyl Manganese Tricarbonyl).

Lexus does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Lexus dealer for service.

#### ■ If your engine knocks

- Consult your Lexus dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.



#### NOTICE

#### ■ Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline.
   Leaded gasoline can cause damage to
   your vehicle's three-way catalytic con verters causing the emission control
   system to malfunction.
- Do not use gasohol other than the type previously stated.
   Other gasohol may cause fuel system damage or vehicle performance problems.
- Using unleaded gasoline with an octane number or rating lower than the level previously stated may cause persistent heavy knocking.
   At worst, this may lead to engine damage and will void the vehicle warranty.

### ■ Fuel-related poor driveability

If poor driveability (poor hot starting, vaporization, engine knocking, etc.) is encountered after using a different type of fuel, discontinue the use of that type of fuel.


#### ■ When refueling with gasohol

Take care not to spill gasohol. It can damage your vehicle's paint.

### Tire information

### Typical tire symbols

▶ Full-size tire



- $\overline{\mathbf{A}}$  Tire size ( $\rightarrow$ P.393)
- **B** DOT and Tire Identification Number (TIN) ( $\rightarrow$ P.393)
- $\boxed{\mathbf{c}}$  Location of treadwear indicators ( $\rightarrow$ P.316)
- **D** Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

E Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.

### F TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

- **G** Load limit at maximum cold tire inflation pressure  $(\rightarrow P.395)$
- **H** Maximum cold tire inflation pressure  $(\rightarrow P.395)$

This means the pressure to which a tire may be inflated.


I Uniform tire quality grading

For details, see "Uniform Tire Quality Grading" that follows.

 $\square$  Summer tires or all season tires ( $\rightarrow$ P.317)

An all season tire has "M+S" on the sidewall. A tire not marked "M+S" is a summer tire.

#### ▶ Compact spare tire



- $\overline{\mathbf{A}}$  Tire size ( $\rightarrow$ P.393)
- **B** DOT and Tire Identification Number (TIN) ( $\rightarrow$ P.393)
- $\boxed{\mathbf{c}}$  Location of treadwear indicators ( $\rightarrow$ P.316)
- **D** Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

**E** Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.

### F TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

- **G** Load limit at maximum cold tire inflation pressure  $(\rightarrow P.395)$
- **H** Maximum cold tire inflation pressure  $(\rightarrow P.395)$


This means the pressure to which a tire may be inflated.

### T "TEMPORARY USE ONLY"


A compact spare tire is identified by the phrase "TEMPORARY USE ONLY" molded on its sidewall. This tire is designed for temporary emergency use only.

# Typical DOT and Tire Identification Number (TIN)

### ▶ Type A



- $\mathbf{A} \mathsf{DOT} \mathsf{symbol}^*$
- **B** Tire Identification Number (TIN)
- Tire manufacturer's identification mark
- **D** Tire size code
- Manufacturer's optional tire type code (3 or 4 letters)
- **F** Manufacturing week
- **G** Manufacturing year
- \*: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.
- Type B




- lack DOT symbol $^*$
- **B** Tire Identification Number (TIN)

- C Tire manufacturer's identification mark
- D Manufacturer's code
- **E** Manufacturing week
- F Manufacturing year
- The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

#### Tire size


### ■ Typical tire size information

The illustration indicates typical tire size.




- A Tire use (P = Passenger car, T = Temporary use)
- **B** Section width (millimeters)
- C Aspect ratio (tire height to section width)
- **D** Tire construction code (R = Radial, D = Diagonal)
- **E** Wheel diameter (inches)
- **F** Load index (2 digits or 3 digits)
- **G** Speed symbol (alphabet with one letter)

#### ■ Tire dimensions



- A Section width
- **B** Tire height
- **C** Wheel diameter

#### Tire section names



- A Bead
- **B** Sidewall
- **C** Shoulder
- **D** Tread
- **E** Belt
- **F** Inner liner
- **G** Reinforcing rubber
- **H** Carcass
- I Rim lines
- Bead wires
- **K** Chafer

### Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Lexus vehicles with information on uniform tire quality grading.

Your Lexus dealer will help answer any questions you may have as you read this information.

### ■ DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

#### ■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### ■ Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

#### ■ Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat

when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manufacturer
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine

Tire related term	Meaning
	The sum of:
N4 · 1 1 1	(a) Curb weight
Maximum loaded vehicle weight	(b) Accessory weight
l comone weight	(c) Vehicle capacity weight
	(d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table $1^{\star}$ that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table $\boldsymbol{1}^*$ below
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designa- tion	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire

Tire related term	Meaning
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or innerliner of the tire extending to cord material
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separa- tion	The parting of the innerliner from cord material in the carcass
Intended outboard	(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or
Sidewall	(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle
Light truck (LT) tire	A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure

Tire related term	Meaning
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissi- ble inflation pres- sure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, pro- vides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall

Tire related term	Meaning
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM E-1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol ( ) on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fix- ture	The fixture used to hold the wheel and tire assembly securely during testing

<sup>\*:</sup> Table 1—Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

#### Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. The settings of these features can be changed by using the meter control switches, the Remote Touch or at your Lexus dealer.

#### Customizing vehicle features

- Changing by using the meter control switches
- 1 Press < or > to select 🐯.
- 2 Operate the meter control switches to select the desired item to be customized.
- 3 According to the display, select the desired setting.

To go back to the previous screen or exit the customize mode, press ...

- Changing by using the Remote Touch
- 1 Press the "MENU" button on the Remote Touch.
- 2 Select "Setup" on the menu screen and select "Vehicle".

3 Select "Vehicle Customization" or "Drive Mode Customization".

Various setting can be changed. Refer to the list of settings that can be changed for details.

For details on the Remote Touch, refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MAN-UAL".

## ■ When customizing using the Remote Touch

Stop the vehicle in a safe place, apply the parking brake, and shift the shift lever to P. Also, to prevent battery discharge, leave the engine running while customizing the features.



#### WARNING

#### During customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



#### NOTICE

#### ■ During customization

To prevent battery discharge, ensure that the engine is running while customizing features.

#### Customizable features

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

- A Settings that can be changed using the Remote Touch
- **B** Settings that can be changed using the meter control switches

#### C Settings that can be changed by your Lexus dealer

Definition of symbols: O = Available, — = Not available

## ■ Gauges, meters and multi-information display ( $\rightarrow$ P.64, 67, 71)

Function*1	Default setting	Customized setting	A	В	C
Language	English –	French	0	0	
Language		Spanish			
		km (km/L)			
Units <sup>*2</sup>	miles (MPG)	km (L/100 km)	0	0	_
		miles (MPG Imperial)			
Drive information 1  Drive information 2	Current fuel consumption			0	
	Average fuel economy (after reset)	Customizable items: →P.73			
	Distance (driv- ing range)				
	Average vehi- cle speed (after reset)				
Clock	12-hour display	24-hour display	—	0	_
Pop-up display	On	Off		0	
Accent color	Color 1	Color 2	0	0	_
*3	5000 r/min.	2000-6700 r/min.		C	
Rev indicator <sup>*3</sup>	3000 r/min.	Off		0	
Rev peak*3	On	Off		0	
Eco Driving Indicator Light	On	Off		0	_
Suggestion function	On	On (when the vehicle is stopped)  Off	0	_	0

<sup>\*1:</sup> For details about each function:  $\rightarrow$  P.76

<sup>\*2:</sup> The default setting varies according to country.

#### 402

## \*3: F SPORT models

## ■ Head-up Display $^*$ ( $\rightarrow$ P.78)

Function	Default setting	Customized setting	A	В	С
Gauge information	Tachometer	Eco Driving Indica- tor		0	_
		No content			
Route guidance to destination/street name*	On	Off	_	0	
Driving support system display	On	Off		0	
Compass*	On	Off		0	
Audio system operation status	On	Off		0	

<sup>\*:</sup> If equipped

## ■ Door lock (→P.89, 93, 372)

Function	Default setting	Customized setting	A	В	С
Unlocking using a mechanical key	Driver's door unlocked in one step, all doors unlocked in two step	All doors unlocked in one step			0
Automatic door locking function	Shift lever linked door	Off			
	locking opera- tion	Speed linked door locking operation	0		0
	Shift lever linked door unlocking operation	Off			
Automatic door unlocking function		Driver's door linked door unlocking operation	0		0
Locking/unlocking of the trunk when all doors are locked/unlocked	On	Off			0

# ■ Smart access system with push-button start and wireless remote control $(\rightarrow P.89, 100)$

Function	Default setting	Customized setting	A	В	С
Operating signal (Buzzers)	5	Off	0		0
		1 to 7			
Operation signal (Emergency flashers)	On	Off	0		0
Time elapsed before automatic		Off			
door lock function is activated if door is not opened after being	60 seconds	30 seconds	0		0
unlocked		120 seconds			
Open door warning buzzer	On	Off			0

## ■ Smart access system with push-button start ( $\rightarrow$ P.89, 100)

Function	Default setting	Customized setting	A	В	С
Smart access system with push- button start	On	Off			0
Smart door unlocking	Driver's door	All the doors	0		0
Time elapsed before unlocking all the door when gripping and hold- ing the driver's door handle	2 seconds	Off			
		1.5 seconds		_	0
		2.5 seconds			
Number of consecutive door lock operations	2 times	As many as desired	_	_	0

## ■ Wireless remote control ( $\rightarrow$ P.86, 89, 100)

Function	Default setting	Customized setting	A	В	С
Wireless remote control	On	Off			0
Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two step	All doors unlocked in one step	0		0

Function	Default setting	Customized setting	Α	В	С
Trunk unlocking operation		One short press			
	Press and hold	Push twice			
	(short)	Press and hold (long)			0
		Off			
Theft deterrent panic mode	On	Off	_	_	0
Reservation lock	On	Off	0		0

#### ■ Trunk (→P.93)

Function	Default setting	Customized setting	A	В	C
Hands Free Power Trunk Lid (kick sensor)*	On	Off		0	_

<sup>\*:</sup> If equipped

## ■ Driving position memory $(\rightarrow P.108)$

Function	Default setting	Customized setting	A	В	С
Selecting doors linked to the memory recall function	Driver's door	All doors			0
Driver's seat slide movement when	Full	Off	0		$\circ$
exiting the vehicle*	ruii -	Partial	0		O
		Off			
Steering wheel movement*	Tilt only	Telescopic only	0		Ο
		Tilt and telescopic			

<sup>\*:</sup> If equipped

## ■ Power windows, and moon roof $^*$ or panoramic moon roof $^*$ ( $\rightarrow$ P.118, 120, 123)

Function	Default setting	Customized setting	A	В	С
Mechanical key linked operation	Off	On			0

Function	Default setting	Customized setting	A	В	С
Wireless remote control linked operation	Off	On (open only)			0
Wireless remote control linked operation signal (buzzer)	On	Off			0

<sup>\*:</sup> If equipped

## ■ Automatic light control system ( $\rightarrow$ P.150)

Function	Default setting	Customized setting	A	В	С
Light sensor sensitivity	Standard	-2 to 2	0		0
Time elapsed before headlights		Off			
automatically turn off after doors	30 seconds	60 seconds	0		0
are closed		90 seconds			
Windshield wiper linked headlight illumination	On	Off	_		0

#### ■ Lights ( $\rightarrow$ P.150)

Function	Default setting	Customized setting	A	В	С
Daytime running lights	On	Off <sup>*1</sup>	0		0
Welcome lighting	On	Off		_	0
AFS (Adaptive Front-lighting System)*2	On	Off			0

<sup>\*1:</sup> Except for Canada

## $\blacksquare$ PCS (Pre-Collision System) ( $\rightarrow$ P.169)

Function	Default setting	Customized setting	A	В	С
PCS (Pre-Collision System)	On	Off	_	0	—
Adjust alert timing	Middle	Far		0	
/ tajust alert tirriirig	1 lidule	Near		)	

<sup>\*2:</sup> If equipped

## ■ LTA (Lane Tracing Assist) ( $\rightarrow$ P.176)

Function	Default setting	Customized setting	A	В	С
Lane centering function	Off	On		0	—
Steering assist function	On	Off		0	—
Alert type	Steering wheel vibration	Buzzer		0	_
Alert sensitivity	Standard	High		0	
Vehicle sway warning function	On	Off		0	—
Vehicle sway warning sensitivity	Standard	High		0	
verifice sway warriing sensitivity	Standard	Low		J	

## ■ RSA (Road Sign Assist) $^*$ ( $\rightarrow$ P.185)

Function	Default setting	Customized setting	Α	В	С
RSA (Road Sign Assist)	On	Off	_	0	—
Excess speed notification method	Display only	No notification		0	
		Display and buzzer		0	
Excess speed notification level	1 mph (2 km/h) -	3 mph (5 km/h)		)	
Excess speed notification level		5 mph (10 km/h)		)	
Other notifications method (No-	Display only	No notification		(	
entry notification)	Display only	Display and buzzer		)	

<sup>\*:</sup> If equipped

## ■ BSM (Blind Spot Monitor) $^*$ ( $\rightarrow$ P.197)

Function	Default setting	Customized setting	A	В	С
BSM (Blind Spot Monitor)	On	Off	_	0	—
Outside rear view mirror indicator brightness	Bright	Dim		0	
		Early			
Alert timing for presence of	1	Late		•	
Alert timing for presence of approaching vehicle (sensitivity)	Intermediate	Only when vehicle detected in blind spot		0	

\*: If equipped

## ■ PKSA (Parking Support Alert) (→P.204)

Function	Default setting	Customized setting	A	В	С
Buzzer volume	Level2	Level1		0	
Duzzei voiume	Leveiz	Level3			

## ■ Intuitive parking assist $(\rightarrow P.205)$

Function	Default setting	Customized setting	A	В	С	
Intuitive parking assist	On	Off		0	_	

<sup>\*:</sup> If equipped

## ■ RCTA (Rear Cross Traffic Alert) function $(\rightarrow P.211)$

Function	Default setting	Customized setting	A	В	С
RCTA (Rear Cross Traffic Alert) function	On	Off		0	

<sup>\*:</sup> If equipped

## ■ RCD (Rear Camera Detection) function $(\rightarrow P.215)$

Function	Default setting	Customized setting	A	В	С
RCD (Rear Camera Detection) function	On	Off		0	

<sup>\*:</sup> If equipped

## ■ PKSB (Parking Support Brake) $^*$ ( $\rightarrow$ P.218)

Function	Default setting	Customized setting	A	В	С
PKSB (Parking Support Brake) function	On	Off		0	_

<sup>\*:</sup> If equipped

#### ■ Driving Mode Select switch ( $\rightarrow$ P.202)

Function	Default setting	Customized setting	A	В	С
Powertrain control in custom	Normal	Power	0		
mode <sup>*</sup>	TTOTTIBLE	Eco	)		

#### 408

Function	Default setting	Customized setting	A	В	С
Chassis control in custom mode*	Normal	Sport	0		—
Air conditioning operation in custom mode <sup>*</sup>	Normal	Eco	0		_

<sup>\*:</sup> If equipped

#### ■ Automatic air conditioning system ( $\rightarrow$ P.251)

Function	Default setting	Customized setting	A	В	С
A/C auto switch operation	On	Off	0		0
Exhaust gas sensor sensitivity	Standard	-3 to 3	0		0

## ■ Seat heater $^*$ /seat ventilators $^*$ ( $\rightarrow$ P.258)

Function	Default setting	Customized setting	A	В	С
Driver's seat temperature preference in automatic mode	Standard	-2 (cooler) to 2 (warmer)	0		0
Passenger's seat temperature preference in automatic mode	Standard	-2 (cooler) to 2 (warmer)	0		0

<sup>\*:</sup> If equipped

## $\blacksquare$ Heated steering wheel $^*$ ( $\rightarrow$ P.258)

Function	Default setting	Customized setting	A	В	С
Steering wheel heating preference in automatic mode	Standard	-2 (low) to 2 (high)	0		0

<sup>\*:</sup> If equipped

#### ■ Illumination ( $\rightarrow$ P.262)

Function	Default setting	Customized setting	A	В	С
To I II ( all our o		Off			
Time elapsed before the interior lights turn off	15 seconds	7.5 seconds	0		0
lights turn on		30 seconds			
Operation after the engine switch is turned off	On	Off			0

Function	Default setting	Customized setting	A	В	С
Operation when the doors are unlocked	On	Off	_	_	0
Operation when you approach the vehicle with the electronic key on your person	On	Off			0
Footwell lights	On	Off			0
Instrument panel ornament light* and door trim ornament lights*	On	Off			0
T		Off			
Time elapsed before the outer foot lights turn off	15 seconds	7.5 seconds	0		0
		30 seconds			
Operation of the outer foot lights when you approach the vehicle with the electronic key on your person	On	Off			0
Operation of the outer foot lights when the doors are unlocked	On	Off			0
Operation of the outer foot lights when a door is opened	On	Off	_		0
Fading out of the outer foot lights when they turn off	Long	Short	_		0

<sup>\*:</sup> If equipped

#### ■ Vehicle customization

- When the smart access system with push-button start is off, the entry unlock function cannot be customized.
- When the doors remain closed after unlocking the doors and the timer activated automatic door lock function activates, signals will be generated in accordance with the operation buzzer volume and operational signal (Emergency flashers) function settings.
- Some settings can be changed using a switch or the Center Display. If a setting is changed using a switch, the changed setting will not be reflected on the Center

Display until the engine switch is turned off and then to IGNITION ON mode.

#### ■ Clock settings screen

If the clock adjustment screen is displayed continuously when attempting to change the clock settings, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

#### Items to initialize

The following items must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle:

#### List of the items to initialize

ltem	When to initialize	Reference
PKSB (Parking Support Brake)*	After reconnecting or changing the battery	P.222
Tire pressure warning system	When rotating the tires. When the tire inflation pressure is changed by changing tire size. (When there are multiple specified pressures) After registering the ID codes. When the tire inflation pressure is changed such as when changing traveling speed.	P.321
Power windows	When functioning abnormally	P.118
Lexus parking assist monitor*	<ul> <li>Battery has been reinstalled.</li> <li>The steering wheel has been moved while the battery was being reinstalled.</li> <li>Battery power is low.</li> </ul>	Refer to "NAV- IGATION AND MULTI- MEDIA SYS- TEM OWNER'S MANUAL".
Panoramic view monitor*	<ul> <li>Battery has been reinstalled.</li> <li>The steering wheel has been moved while the battery was being reinstalled.</li> <li>Battery power is low.</li> </ul>	Refer to the "NAVIGA- TION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".
Message indicating maintenance is required	After the maintenance is per- formed	P.301
Oil maintenance	After the maintenance is per- formed	P.312

\*: If equipped

9

## S

For	own	۵r
1 01	OWII	CI:

9-1			ers

Reporting safety defects for U.S. owners
Seat belt instructions for Canadian owners (in French) 414
SRS airbag instructions for Canadian owners (in French)416
Headlight aim instructions for Canadian owners (in French)
422

# Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying the Lexus Division of Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-25-LEXUS).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Lexus Division of Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY:1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

# Seat belt instructions for Canadian owners (in French)

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

# Utilisation adéquate des ceintures de sécurité



- Tirez sur la ceinture épaulière jusqu'à ce qu'elle recouvre entièrement l'épaule; elle ne doit cependant pas toucher le cou ni glisser de l'épaule.
- Placez la ceinture abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier. Tenezvous assis bien au fond du siège, le dos droit.
- Ne vrillez pas la ceinture de sécurité.

#### Entretien et soin

 Manipulation des ceintures de sécurité

Avec un chiffon ou une éponge, nettoyez à l'aide d'un savon doux et de l'eau tiède. Vérifiez aussi les ceintures régulièrement pour vous assurer qu'elles ne présentent pas d'usure excessive, d'effilochage ou de coupures.



#### **AVERTISSEMENT**

- Dommages et usure de la ceinture de sécurité
- Vérifiez périodiquement le système de ceintures de sécurité. Vérifiez qu'il n'y a pas de coupures, d'effilochures ni de pièces desserrées. N'utilisez pas une ceinture de sécurité endommagée avant qu'elle ne soit remplacée. Les ceintures de sécurité endommagées ne peuvent pas protéger les occupants contre les blessures graves, voire mortelles.


#### SRS airbag instructions for Canadian owners (in French)

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.

#### Système de coussins gonflables SRS

■ Emplacement des coussins gonflables SRS




- ► Coussins gonflables SRS avant
- A Coussin gonflable SRS du conducteur/coussin gonflable SRS du passager avant

Peuvent aider à protéger la tête et la poitrine du conducteur et du passager avant contre les impacts avec des composants intérieurs

- B Coussins gonflables SRS de protection des genoux Peuvent aider à protéger le conducteur et le passager avant
- ► Coussins gonflables SRS latéraux et en rideau
- Coussins gonflables SRS latéraux avant Peuvent aider à protéger le torse des occupants des sièges avant
- D Coussins gonflables SRS latéraux arrière Peuvent aider à protéger le torse des occupants des sièges latéraux arrière

- E Coussins gonflables SRS en rideau
- Peuvent aider à protéger principalement la tête des occupants des sièges latéraux
- Peuvent aider à empêcher les occupants d'être éjectés du véhicule en cas de tonneaux

#### ■ Composants du système de coussins gonflables SRS



- A Système de classification de l'occupant du siège du passager avant (ECU et capteurs)
- **B** Coussins gonflables de protection des genoux
- Coussin gonflable du passager avant
- D Coussins gonflables en rideau
- E Capteurs d'impact latéral (portières avant)
- F Limiteurs de force et dispositifs de tension des ceintures de sécurité
- **G** Capteurs d'impact latéral (avant)
- H Coussins gonflables latéraux avant
- Capteurs d'impact latéral (arrière)
- J Coussins gonflables latéraux arrière
- K Coussin gonflable du conducteur
- L Lampe témoin SRS
- M Capteur de position du siège du conducteur

- N Contacteur de boucle de ceinture de sécurité du conducteur
- O Module de capteur de coussin gonflable
- P Voyants "AIR BAG ON" et "AIR BAG OFF"
- Q Contacteur de boucle de ceinture de sécurité du passager avant
- R Capteurs d'impact avant

Votre véhicule est doté de COUSSINS GONFLABLES ÉVOLUÉS dont la conception s'appuie sur les normes de sécurité des véhicules à moteur américains (FMVSS208). Le module de capteur de coussin gonflable (ECU) contrôle le déploiement des coussins gonflables en fonction des informations obtenues des capteurs et d'autres éléments affichés dans le diagramme des composants du système ci-dessus. Ces informations comprennent des données relatives à la gravité de l'accident et aux occupants. Au moment du déploiement des coussins gonflables, une réaction chimique se produit dans les gonfleurs de coussin gonflable et les coussins gonflables se remplissent rapidement d'un gaz non toxique pour aider à limiter le mouvement des occupants.



#### **AVERTISSEMENT**

#### Précautions relatives aux coussins gonflables SRS

Observez les précautions suivantes en ce qui concerne les coussins gonflables SRS.

Négliger de le faire pourrait occasionner des blessures graves, voire mortelles.

 Le conducteur et tous les passagers du véhicule doivent porter leur ceinture de sécurité de la manière appropriée. Les coussins gonflables SRS sont des dispositifs supplémentaires qui doivent être utilisés avec les ceintures de sécurité.



#### **AVERTISSEMENT**

 Le coussin gonflable SRS du conducteur se déploie avec une force considérable et peut occasionner des blessures graves, voire mortelles, notamment lorsque le conducteur se trouve très près du coussin gonflable. La National Highway Traffic Safety Administration (NHTSA), aux États-Unis, fait les recommandations suivantes:

La zone à risque du coussin gonflable du conducteur couvre 2 à 3 in. (50 à 75 mm) de la zone de déploiement du coussin gonflable. Pour assurer une marge de sécurité suffisante, restez à 10 in. (250 mm) du coussin gonflable. Cette distance est mesurée depuis le centre du volant iusqu'à votre sternum. Si maintenant vous vous tenez assis à moins de 10 in. (250 mm), yous pouvez changer votre position de conduite de plusieurs manières :

- · Reculez votre siège à la position maximale vous permettant d'atteindre encore aisément les pédales.
- Inclinez légèrement le dossier du siège. Bien que les véhicules soient concus différemment, la plupart des conducteurs peuvent maintenir une distance de 10 in. (250 mm), même si leur siège se trouve complètement vers l'avant, simplement en inclinant un peu le dossier du siège vers l'arrière. Si la visibilité avant est moindre après avoir incliné le dossier de votre siège, utilisez un coussin ferme et non alissant pour être assis plus haut ou relevez le siège si cette option est disponible sur votre véhicule.
- Si votre volant est réglable en hauteur, inclinez-le vers le bas. Cela vous permet d'orienter le coussin gonflable vers votre buste plutôt que vers votre tête et vers votre cou.

Le siège doit être réglé de la manière recommandée ci-dessus par la NHTSA, tout en gardant le contrôle des pédales et du volant, ainsi que la vue sur les commandes du tableau de bord.

• Si la rallonge de ceinture de sécurité a été reliée à la boucle des ceintures de sécurité des sièges avant sans avoir aussi été attachée à la plaque de blocage des ceintures de sécurité, les coussins gonflables SRS avant considéreront que le conducteur et le passager avant portent tout de même leur ceinture de sécurité même si les ceintures de sécurité ne sont pas attachées. Les coussins gonflables SRS avant peuvent alors ne pas s'activer correctement lors d'une collision. ce qui pourrait occasionner des blessures graves, voire mortelles, en cas de collision. Assurez-vous de toujours porter la ceinture de sécurité avec la rallonge de ceinture de sécurité.



 Le coussin gonflable SRS du passager avant se déploie également avec une force considérable et peut occasionner des blessures graves, voire mortelles, notamment lorsque le passager avant se trouve très près du coussin gonflable. Le siège du passager avant doit se trouver le plus loin possible du coussin gonflable et le dossier doit être réglé de manière à ce que le passager avant soit assis bien droit.


## A

#### **AVERTISSEMENT**

- Le déploiement d'un coussin gonflable risque d'infliger des blessures graves, voire mortelles, aux bébés et aux enfants mal assis et/ou mal attachés. Un bébé ou un enfant trop petit pour utiliser une ceinture de sécurité doit être correctement retenu à l'aide d'un dispositif de retenue pour enfants. Lexus recommande vivement de placer et d'attacher correctement tous les bébés et tous les enfants sur les sièges arrière du véhicule à l'aide de dispositifs de retenue adaptés. Les sièges arrière sont plus sécuritaires pour les bébés et les enfants que le siège du passager avant.
- N'installez jamais un dispositif de retenue pour enfants de type dos à la route sur le siège du passager avant, même si le voyant "AIR BAG OFF" est allumé. En cas d'accident, la force et la vitesse de déploiement du coussin gonflable du passager avant pourraient infliger à l'enfant des blessures graves, voire mortelles, si le dispositif de retenue pour enfants de type dos à la route était installé sur le siège du passager avant.
- Ne vous asseyez pas sur le bord du siège et ne vous appuyez pas sur la planche de bord.



 Ne laissez pas un enfant se tenir face au coussin gonflable SRS du passager avant ni s'asseoir sur les genoux d'un passager avant.



- Ne laissez pas les occupants des sièges avant tenir des objets sur leurs genoux.
- Ne vous appuyez pas sur la portière ou sur le brancard de pavillon, ni sur les montants avant, latéraux ou arrière.



 Ne laissez personne s'agenouiller face à la portière sur les sièges des passagers ni sortir la tête ou les mains à l'extérieur du véhicule.



#### **A** AVERTISSEMENT

Ne fixez et n'appuyez rien sur des zones telles que la planche de bord, le tampon de volant ou encore la partie inférieure du tableau de bord. Ces obiets peuvent se transformer en projectiles lorsque les coussins gonflables SRS du conducteur, du passager avant et de protection des genoux se déploient.



Ne fixez rien sur des zones telles que les portières, le pare-brise, les glaces latérales, les montants avant ou arrière, le brancard de pavillon et la poignée de maintien.



- N'accrochez pas de cintres ni d'autres objets rigides sur les crochets portevêtements. Tous ces objets pourraient se transformer en projectiles et vous occasionner des blessures graves. voire mortelles, en cas de déploiement des coussins gonflables SRS en rideau.
- Si un recouvrement de vinyle est placé sur la zone de déploiement du coussin gonflable SRS de protection des genoux, veillez à le retirer.

- N'utilisez pas d'accessoires recouvrant les parties du siège où les coussins gonflables SRS latéraux se déploient, car ces accessoires pourraient entraver le déploiement des coussins aonflables SRS. De tels accessoires peuvent empêcher les coussins gonflables latéraux de se déployer correctement, rendre le système inopérant ou provoquer accidentellement le déploiement des coussins gonflables latéraux, occasionnant des blessures graves, voire mortelles.
- Ne frappez pas et n'appliquez pas une pression importante à l'emplacement des portières avant ou des composants des coussins gonflables SRS. Cela peut provoquer un mauvais fonctionnement des coussins gonflables SRS.
- Ne touchez à aucun composant des coussins gonflables SRS immédiatement après leur déploiement (gonflage), car ils pourraient être chauds.
- Si vous avez de la difficulté à respirer après le déploiement des coussins gonflables SRS, ouvrez une portière ou une glace pour laisser entrer l'air frais, ou quittez le véhicule si vous pouvez le faire en toute sécurité. Dès que possible, nettoyez tous les résidus afin d'éviter les irritations cutanées.
- Si les emplacements de stockage des coussins gonflables SRS, tels que le tampon de volant et les garnitures des montants avant et arrière, sont endommagés ou fissurés, faites-les remplacer par votre concessionnaire Lexus.
- Ne placez aucun objet, par exemple un coussin, sur le siège du passager avant. Cela disperserait le poids du passager, ce qui empêcherait le capteur de le détecter correctement. Cela pourrait empêcher le déploiement des coussins gonflables SRS du passager avant en cas de collision.

## A

#### **AVERTISSEMENT**

 Modification et mise au rebut des composants du système de coussins gonflables SRS

Ne mettez pas votre véhicule au rebut et n'effectuez aucune des modifications suivantes sans d'abord consulter votre concessionnaire Lexus. Les coussins gonflables SRS pourraient fonctionner de manière incorrecte ou se déployer (gonfler) accidentellement, ce qui serait susceptible d'occasionner des blessures graves, voire mortelles.


- Installation, retrait, démontage et réparation des coussins gonflables SRS
- Réparations, modifications, retrait ou remplacement du volant, du tableau de bord, de la planche de bord, des sièges ou du capitonnage des sièges, des montants avant, latéraux et arrière, des brancards de pavillon, des panneaux des portières avant, des garnitures des portières avant ou des hautparleurs des portières avant
- Modifications du panneau de la portière avant (comme le perforer)
- Réparations ou modifications de l'aile avant, du pare-chocs avant ou du côté de l'habitacle
- Installation d'une protection de calandre (barre safari, barre kangourou, etc.), de lames de déneigement, de treuils ou d'un porte-bagages de toit
- Modifications du système de suspension du véhicule
- Installation d'appareils électroniques tels qu'un émetteur-récepteur radio ou un lecteur de CD
- Modifications à votre véhicule pour une personne aux capacités physiques réduites

# Headlight aim instructions for Canadian owners (in French)


The following is a French explanation of headlight aim instructions from the headlight aim section in this manual.

#### Boulons de réglage vertical

 Véhicules dotés de phares à faisceau unique



- A Boulon de réglage A
- **B** Boulon de réglage B
- Véhicules dotés de phares à triple faisceau



- A Boulon de réglage A
- **B** Boulon de réglage B


# Avant de vérifier la portée des phares

- Assurez-vous que le réservoir de carburant du véhicule est plein et que la partie de carrosserie située autour des phares n'est pas déformée.
- Garez le véhicule sur un sol parfaitement horizontal.
- Assurez-vous que la pression de gonflage des pneus est au niveau prescrit.
- Demandez à quelqu'un de s'asseoir sur le siège du conducteur.
- Faites rebondir le véhicule à plusieurs reprises.

## Réglage de la portée des phares

- Véhicules dotés de phares à faisceau unique
- Tournez le boulon A vers la droite ou vers la gauche à l'aide d'un tournevis cruciforme.

Retenez le sens de rotation et le nombre de tours.



Tournez le boulon B du même nombre de tours et dans le même sens qu'à l'étape 1. Si vous n'arrivez pas à régler vos phares en suivant cette procédure, apportez le véhicule chez votre concessionnaire Lexus afin qu'il règle la portée des phares.



- Véhicules dotés de phares à triple faisceau
- 1 Tournez le boulon A vers la droite ou vers la gauche à l'aide d'un tournevis cruciforme.

Retenez le sens de rotation et le nombre de tours.



**2** Tournez le boulon B du même nombre de tours et dans le même sens qu'à l'étape **1**.

Si vous n'arrivez pas à régler vos phares en suivant cette procédure, apportez le véhicule chez votre concessionnaire Lexus

## 424

#### 9-1. For owners

afin qu'il règle la portée des phares.



## Index

What to do if (Troubleshoot	ting)
	426
Alphabetical index	429

## What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Lexus dealer.

# The doors cannot be locked, unlocked, opened or closed



- If you lose your mechanical keys, new genuine mechanical keys can be made by your Lexus dealer. (→P.371)
- If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Lexus dealer immediately. (

  P.371)



## The doors cannot be locked or unlocked

- Is the electronic key battery weak or depleted? (→P.330)
- Is the engine switch in IGNITION ON mode?

When locking the doors, turn the engine switch off.  $(\rightarrow P.139)$ 

 Is the electronic key left inside the vehicle?

When locking the doors, make sure that you have the electronic key on your person.

 The function may not operate properly due to the condition of the radio wave. (→P.101)



#### The rear door cannot be opened

 Is the child-protector lock set?
 The rear door cannot be opened from inside the vehicle when the lock is set.

Open the rear door from outside and then unlock the child-protector lock.  $(\rightarrow P.92)$ 



# The trunk lid is closed with the electronic key left inside

The function to prevent the electronic key from being left inside the trunk will operate and you can open the trunk as usual. Take the key out from the trunk. (→P.97)

#### If you think something is wrong



#### The engine does not start

- Did you press the engine switch while firmly depressing the brake pedal? (

  P.137)
- Is the shift lever in P?  $(\rightarrow P.141)$
- Is the electronic key anywhere detectable inside the vehicle? (→P.100)
- Is the steering wheel unlocked?
   (→P.138)
- Is the electronic key battery weak or depleted?

In this case, the engine can be started in a temporary way.  $(\rightarrow P.373)$ 

Is the battery discharged?
 (→P.374)



The shift lever cannot be shifted from P even if you depress the brake pedal

 Is the engine switch in IGNITION ON mode?
 If you cannot release the shift lever

It you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode (→P.142)



The steering wheel cannot be turned after the engine is stopped

 It is locked automatically to prevent theft of the vehicle. (→P.138)



The windows do not open or close by operating the power window switches

• Is the window lock switch pressed?

The power window at the except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (\$\ightarrow\$P.119)



The engine switch is turned off automatically

 The auto power off function will be operated if the vehicle is left in ACCESSORY or IGNITION ON mode (the engine is not running) for a period of time. (→P.139)



# A warning buzzer sounds during driving

The seat belt reminder light is flashing

Are the driver and the passengers wearing the seat belts?  $(\rightarrow P.351, 351)$ 

• The parking brake indicator is on

Is the parking brake released?  $(\rightarrow P.146)$ 

Depending on the situation, other types of warning buzzer may also sound.  $(\rightarrow P.348, 358)$ 



An alarm is activated and the horn sounds

• Did anyone inside the vehicle open a door during setting the alarm?

The sensor detects it and the alarm sounds.  $(\rightarrow P.56)$ 

To stop the alarm, turn the engine switch to IGNITION ON mode, or start the engine.



A warning buzzer sounds when leaving the vehicle

 Is the message displayed on the multi-information display?

Check the message on the multi-information display.  $(\rightarrow P.358)$ 



A warning light turns on or a warning message is displayed

 When a warning light turns on or a warning message is displayed, refer to P.348, 358.

## When a problem has occurred



#### If you have a flat tire

 Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P.362)



#### The vehicle becomes stuck

 Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P.379)

# Alphabetical index

A/C
Air conditioning filter
Automatic air conditioning system
ABS (Anti-lock Brake System)
Function
Warning light
Active Cornering Assist (ACA)
Adaptive Front-lighting System (AFS).152 Adaptive Variable Suspension System236 AFS (Adaptive Front-lighting System).152 Airbags
Adaptive Variable Suspension System236 AFS (Adaptive Front-lighting System).152 Airbags
Adaptive Variable Suspension System236 AFS (Adaptive Front-lighting System).152 Airbags
Airbags
Airbags
Airbag precautions for your child
Correct driving posture
Curtain shield airbag operating conditions
tions
Curtain shield airbag precautions33 Front passenger occupant classification system
Front passenger occupant classification system
system
General airbag precautions
Locations of airbags
Modification and disposal of airbags.35 Side airbag operating conditions31 Side airbag precautions33
Side airbag operating conditions31 Side airbag precautions33
Side airbag precautions33
Side and curtain shield airbags operating
conditions31
Side and curtain shield airbags precau-
tions
SRS airbags28
SRS warning light349
Air conditioning filter328
Air conditioning system251
Air conditioning filter
Automatic air conditioning system251
Alarm
Alarm56
Warning buzzer
Antennas (smart access system with push-

button start)	100
Anti-lock Brake System (ABS)	236
Function	
Warning light	
Approach warning	
Armrest	
Assist grips	
Audio system-linked display	
Automatic headlight leveling system	
Automatic High Beam	
Automatic light control system	
Automatic transmission	
Paddle shift switches14.	
S mode	
Auxiliary box	
Average fuel economy	
Average vehicle speed	
В	
Back-up lights	
Replacing light bulbs	335
Battery	
Checking	314
If the battery is discharged	
Preparing and checking before wi	
Warning light	
Blind Spot Monitor (BSM)	
Boost gauge	
Brake	7 ¬
Brake hold	148
Fluid	
Parking brake	
Warning light	
Brake assist	236
Brake assist Break-in tips	236
Brake assist Break-in tips Brightness control	236 129
Brake assist Break-in tips	<b>236</b> <b>129</b> <b>1</b>

С	Exterior296
00/000	Interior299
Care296, 299	110001 301301
Aluminum wheels296	Jeat Deits
Exterior296	
Interior299	
Seat belts299	O0111pu331200
Cargo capacity135	Condenser313
Cargo hooks268	
Center Display244	Console box light266
Chains24	1 Cooling system312
Child-protectors92	Engine overheating377
Child restraint system42	Cornering lights152
Fixed with a LATCH system49	
Fixed with a seat belt	
Front passenger occupant classification	Ol disc collinol
system37	2 jilarilo radar oralbo control marian
Points to remember42	
Riding with children42	
Types of child restraint system installation	0 011 0111 1001 001100111 011011 1111111
method43	
Using an anchor bracket5	
Child safety	
Airbag precautions	
Battery precautions315, 376, 376	
Child restraint system43	5 (
<del>-</del>	Outside rear view mirrors252
Heated steering wheel and seat heater	
precautions258	
How your child should wear the seat be	·
Moon roof precautions	<b>C</b>
Panoramic moon roof precautions125	5014 (5) 10 14
Power window lock switch119	
Power window precautions119	10=
Rear door child-protectors92	
Removed electronic key battery precau	
tions330	1
Seat belt extender precautions25	
Seat belt precautions24	Multi-information display7
Trunk precautions93	
Cleaning296, 299	pedestrians)233
Aluminum wheels296	RCD (Rear Camera Detection) 215
	DCTA 21

Warning message358	Eco Driving Indicator Light	74
Distance until next engine oil change 65,	EDR (Event data recorder)	
70	Elapsed time	73
Do-it-yourself maintenance302	Electric Power Steering (EPS)	
Door courtesy lights262	Function	236
Door lock	Warning light	350
Doors89	Electronic key	86
Smart access system with push-button	Battery-saving function	
start100	If the electronic key does not ope	
Wireless remote control87	properly	
Doors89	Replacing the battery	
Automatic door locking and unlocking	Electronic roof sunshade	
system92	Jam protection function	124
Door glasses118	Operation	
Door lock89	Emergency, in case of	
Open door warning buzzer90, 92	If a warning buzzer sounds	348
Outside rear view mirrors115	If a warning light turns on	
Rear door child-protectors92	If a warning message is displayed	
Drive distance73	If the battery is discharged	
Drive info 1/Drive info 2	If the electronic key does not ope	
Driver's seat position memory108	properly	
Driving position memory108	If the engine will not start	
Memory recall function109	If the fuel filler door cannot be ope	
Drive-start control	ii the ideriller door carriot be opt	
Driving	If the vehicle is trapped in rising w	
Break-in tips	If	
Correct driving posture23	If you have a flat tire	
Driving Mode Select switch202	If you lose your keys	
Procedures	If you think something is wrong	
Winter drive tips240	If your vehicle becomes stuck	
Driving information display73	If your vehicle has to be stopped i	
Driving Mode Select switch202	emergency	
Driving range73	If your vehicle needs to be towed	
Driving support system information display	If your vehicle overheats	
76	Emergency flashers	
Dynamic radar cruise control with full-	Engine	
speed range187	ACCESSORY mode	
Warning message195	Compartment	310
	Engine switch	
E	Fuel pump shut off system	
F 1: 1 200	Hood	
Eco drive mode	How to start the engine	137
Eco Driving Indicator		

If the engine will not start	Identification number	383	Fluid	
emergency       340       Washer       31!         lgnition switch (engine switch)       137       Footwell light       26.         Overheating       377       Front passenger occupant classification         Tachometer       64, 67       System       3         Engine coolant       312       Front seats       10.         Checking       312       Adjustment       10.         Checking       312       Cleaning       290         Preparing and checking before winter       Correct driving posture       20         Engine coolant temperature gauge 64, 67       Head restraints       1         Engine immobilizer system       54       Memory recall function       100	If the engine will not start	369	Automatic transmission	385
emergency       340       Washer       31!         Ignition switch (engine switch)       137       Footwell light       26.         Overheating       377       Front passenger occupant classification         Tachometer       64, 67       system       3         Engine coolant       312       Front seats       10.         Checking       312       Adjustment       10.         Checking       312       Cleaning       29.         Preparing and checking before winter       Correct driving posture       20.         Engine coolant temperature gauge 64, 67       Head restraints       1         Engine immobilizer system       54       Memory recall function       10.	If your vehicle has to be stopped in a	an	Brake	386
Ignition switch (engine switch)137Footwell light26.7Overheating377Front passenger occupant classificationTachometer64, 67system3Engine coolant312Front seats10Capacity385Adjustment10Checking312Cleaning290Preparing and checking before winterCorrect driving posture22Engine coolant temperature gauge 64, 67Head restraints1Engine immobilizer system54Memory recall function100			Washer	315
Overheating377Front passenger occupant classificationTachometer64, 67system3Engine coolant312Front seats10Capacity385Adjustment10Checking312Cleaning29Preparing and checking before winterCorrect driving posture22Engine coolant temperature gauge 64, 67Head restraints1Engine immobilizer system54Memory recall function10			Footwell light	262
Engine coolant       312       Front seats       10         Capacity       385       Adjustment       10         Checking       312       Cleaning       29         Preparing and checking before winter       Correct driving posture       25         Engine coolant temperature gauge 64, 67       Head restraints       1         Engine immobilizer system       54       Memory recall function       10			Front passenger occupant clas	ssification
Capacity	Tachometer64	1, 67	system	37
Checking       312       Cleaning       299         Preparing and checking before winter       Correct driving posture       22         Engine coolant temperature gauge 64, 67       Driving position memory       108         Engine immobilizer system       54       Memory recall function       100	Engine coolant	.312	Front seats	107
Preparing and checking before winter Correct driving posture 23  Engine coolant temperature gauge 64, 67 Engine immobilizer system 54  Correct driving posture 23  Driving position memory 108  Head restraints 11  Memory recall function 108	Capacity	385	Adjustment	107
Engine coolant temperature gauge 64, 67 Engine immobilizer system	Checking	312	Cleaning	299
Engine coolant temperature gauge 64, 67 Head restraints	Preparing and checking before wint	er	Correct driving posture	23
Engine immobilizer system54 Memory recall function		240	Driving position memory	108
	Engine coolant temperature gauge 64	1, 67	Head restraints	111
Engine oil 310 Power easy access system 108	Engine immobilizer system	54	Memory recall function	109
	Engine oil	310	Power easy access system	
Capacity	Capacity	384	Seat heaters	258
Checking				
Preparing and checking before winter Seat ventilators258	Preparing and checking before wint	ter		
Warning light			9	150
Engine oil maintenance data312 Front side marker lights	=			
Engine switch				
Auto power off function				
Changing the engine switch modes 139, Replacing light bulbs		139,		
139 Turn signal lever				
If your vehicle has to be stopped in an Fuel				
emergency				
Starting the engine		, 13/		
Enhanced Vehicle Stability Control Fuel pump shut off system34				
(Enhanced VSC)				
Enhanced VSC (Enhanced Vehicle Stabil-			=	
ity Control)				
EPS (Electric Power Steering)				351
Function236 Fuel consumption				70
Warning light				
Event data recorder (EDR)7	Event data recorder (EDR)	/		
Fuel filler door				
If the fuel filler door cannot be opened	F			
Flat tire	Flat tire	362		
Tire pressure warning system	Tire pressure warning system	319	9	
Floor mats22 Fuel pump shut off system	Floor mats	22		

Fuses331	Hooks
	Cargo hooks268
G	Coat hooks280
001	Grocery bag hooks268
Garage door opener281	Retaining hooks (floor mat)22
Gauges	Horn114
Gear Position	HUD (Head-up display) switch79
G-force	
Glove box	
Glove box light266	104
Grocery bag hooks268	I/M test305
	Identification
Н	Engine
Hands Free Power Trunk Lid96	Vehicle
Headlights150	Ignition switch (engine switch)137
Adaptive Front-lighting System (AFS)	Auto power off function139
152	Changing the engine switch modes. 139
Automatic High Beam system153	If your vehicle has to be stopped in an
Light switch150	emergency340
Replacing light bulbs335	Starting the engine137
Headlights aim333	Immobilizer system54
Head restraints111	Indicators
Head-up display78	Initialization
Driving information display area78	Items to initialize410
Driving information display area	Maintenance301, 312
Eco Driving Indicator81	Power windows118
HUD (Head-up display) switch79	Tire pressure warning system321
Navigation system-linked display78	Inside rear view mirror114
Pop-up display80	Instrument panel light control66, 70
Settings79	Interior lights262
Heated steering wheel258	Intuitive parking assist204, 205
Heaters	Function205
Air conditioning system251	Warning message208
Heated steering wheel258	
Outside rear view mirrors252	J
Seat heaters258	Jack
High mounted stoplight	Positioning a floor jack308
Replacing light bulbs335	Vehicle-equipped jack
Hill-start assist control236	Jack handle
Hood308	Jam protection function
Open	Electronic roof sunshade124
Open300	Moon roof121
	1°100H100HIZ1

Panoramic moon roof124	Dynamic radar cruise control with full-
Power trunk opener and closer 97	speed range187
Power windows118	LTA (Lane Tracing Assist)176
	PCS (Pre-Collision System)169
K	RSA (Road Sign Assist)185
	License plate lights150
Keyless entry	Light switch150
Smart access system with push-button	Replacing light bulbs335
start100	Light bulbs
Wireless remote control87	Replacing335
Keys86	Wattage388
Battery-saving function101	Lights
Electronic key86	Automatic High Beam system153
Engine switch137	Front interior lights263
If the electronic key does not operate	Front personal lights263
properly372	Headlight switch150
If you lose your keys371	Interior lights list262
Key number plate86	Interior lights262
Keyless entry89, 95	Rear interior lights263
Mechanical key86	Rear personal lights263
Replacing the battery330	Trunk light97
Warning buzzer100	Turn signal lever145
Wireless remote control87	Vanity lights269
Knee airbags28	Wattage388
•	Welcome light illumination control 151
L	Lock steering column138
Lane Tracing Assist (LTA)176	Low profile tire
Operation176	LTA (Lane Tracing Assist)176
Warning messages184	Operation
Language (multi-information display)76	Warning messages184
LATCH anchors 49	Luggage mat268
Lever	
Auxiliary catch lever308	М
Hood lock release lever308	Maintenance
Internal trunk release lever97	Do-it-yourself maintenance306
Shift lever141	General maintenance302
Turn signal lever145	Maintenance data382
Wiper lever155	Maintenance requirements301
Lexus climate concierge249	Malfunction indicator lamp349
Lexus Enform Safety Connect289	Master warning light
Lexus Safety System+2.0163	Menu icons72
Automatic High Beam153	rienu icons/ Z

Meter	Tire pressure319
Changing the main meter location 71	Units75
Clock64, 67	Warning message358
Indicators62	
Instrument panel light control 66, 70	N
Meter control switches72	N
Meters64, 67	Navigation system-linked display 75, 78
Multi-information display71	Noise from under vehicle6
Settings76	
Units75	0
Warning lights348	Odometer65, 70
Warning message358	Odometer and trip meter display
Mirrors	"ODO TRIP" switch65, 70
Inside rear view mirror114	Display items65, 70
Outside rear view mirror defoggers 252	Pop-up display66, 70
Outside rear view mirrors115	"ODO TRIP"switch65, 70
Vanity mirrors269	Oil
Moon roof	Engine oil
Door lock linked moon roof operation	Opener
121, 124	Fuel filler door161
Jam protection function121, 124	Hood308
Operation120, 123	Trunk95
Multi-information display71	Outside door handle lights262
Audio system-linked display75	Outside rear view mirrors115
Boost gauge74	Adjustment115
Drive information 1/Drive information 2	BSM (Blind Sport Monitor)197
73	Folding116
Driving information display73	Linked mirror function when reversing
Driving support system information dis-	116
play76	Mirror position memory108
Dynamic radar cruise control with full-	Outside rear view mirror defoggers 252
speed range187	RCTA function211
Eco Driving Indicator81	Outside temperature64, 67
Gear Position75	Overheating377
G-force75	•
LTA (Lane Tracing Assist)181	Р
Menu icons72	
Meter control switches72	Paddle shift switches143, 144
Navigation system-linked display 75	Panic mode
Pop-up display	Panoramic moon roof
Settings	Jam protection function124
Suggestion function77	Operation123

Parking assist sensors (intuitive parking assist)205	R
Parking brake146	Radar cruise control (dynamic radar cruise
Operation146	control with full-speed range)182
Parking brake engaged warning buzzer	Radiator313
147	RCD (Rear Camera Detection)215
Warning light354	Function215
Warning message147	Warning message216
Parking lights	RCTA (Rear Cross Traffic Alert)
Light switch150	RCTA
Parking Support Brake function (rear-	Function21
crossing vehicles)218, 229	Warning message212
Parking Support Brake function (rear	Rear Cross Traffic Alert (RCTA)21
pedestrians)218, 233	Rear door sunshades278
Function233	Rear seats
Parking Support Brake function (static	Head restraints11
objects)218, 224	Rear side marker lights150
Function	Light switch150
PCS (Pre-Collision System)169	Rear sunshades278
Function	Rear turn signal lights145
PCS OFF switch	Replacing light bulbs335
Warning light354	Turn signal lever145
Personal lights	Rear view mirror
PKSA (Parking Support Alert)	Inside rear view mirror112
PKSB (Parking Support Brake)218	Outside rear view mirrors115
Warning message222	Rear window defogger252
Power easy access system108	Refueling16
Power outlet	Capacity383
Power steering (Electric power steering	Fuel types383
system)236	If the fuel filler door cannot be opened
Warning light	37
Power trunk lid93	Opening the fuel tank cap16
Power windows	Remote Touch244
Door lock linked window operation 119	Replacing
	Electronic key battery330
Jam protection function119	Fuses33
Operation	Light bulbs335
Window lock switch	Tires362
Pre-Collision System (PCS)169	Resetting the message indicating mainte-
Function	nance is required30
PCS OFF switch171	Rev indicator69
Warning light354	Payment 60

Road Sign Assist185	Automatic High Beam system153
RSA (Road Sign Assist)185	Inside rear view mirror115
	Intuitive parking assist205
S	LTA (Lane Tracing Assist)176
	Parking Support Brake function (rear-
SCB (Secondary Collision Brake) 236	crossing vehicles)229
Seat belt reminder light351	Parking Support Brake function (static
Seat belts	objects)225
Adjusting the seat belt	Radar sensor163, 198
Automatic Locking Retractor	Rain-sensing windshield wipers158
Child restraint system installation43	RCTA212
Cleaning and maintaining the seat belt	Service reminder message30
299	Shift lever
Emergency Locking Retractor26	Automatic transmission14
How to wear your seat belt25	Shift lever light262
How your child should wear the seat belt	Shift lock system142
25	Side airbags28
Pregnant women, proper seat belt use	Side marker lights150
24	Light switch15(
Reminder light and buzzer351	Side mirrors115
Seat belt extender	Adjustment115
Seat belt pretensioners26	BSM (Blind Sport Monitor)197
SRS warning light349	Folding116
Seat heaters	Linked mirror function when reversing
Seating capacity135	116
Seat position memory	Mirror position memory115
Seats	RCTA function21
Adjustment precautions107	Side turn signal lights145
Adjustment	Replacing light bulbs335
Child seats/child restraint system installa-	Turn signal lever145
tion42	Side windows118
Cleaning299	Smart access system with push-button
Driving position memory108	start100
Head restraints111	Antenna location100
Power easy access system108	Entry functions89, 95
Properly sitting in the seat23	Starting the engine137
Seat heaters258	Snow tires240
Seat position memory108	Spare tire
Seat ventilators258	Storage location363
Seat ventilators258	Spark plug385
Secondary Collision Brake (SCB) 236	Specifications382
Sensor	Speedometer64, 67
Automatic headlight system150	

Sport mode202	LTA (Lane Tracing Assist) switch181
Steering lock	Meter control switches72
Column lock release138	Moon roof switches120
Steering lock system warning message	Outside rear view mirror switches115
138	Paddle shift switches143, 144
Steering wheel113	Panoramic moon roof switches123
Adjustment113	Parking brake switch146
Heated steering wheel258	PCS OFF switch171
Meter control switches72	PKSB (Parking Support Brake) switch
Power easy access system108	219
Steering wheel position memory 108	Power door lock switch91
Stop lights	Power window switches118
Replacing light bulbs335	RCD (Rear Camera Detection) switch
Storage feature265	215
Stuck	RCTA switch212
If the vehicle becomes stuck379	Rear sunshades switch278
Suggestion function77	Rear window and outside rear view mir-
Sunshade	ror defoggers switch251
Roof121, 123	Seat heater switches258
Sun visors269	Seat ventilator switches258
Switches	Tilt and telescopic steering control switch
"ODO TRIP" switch65, 70	113
"SOS" button289	Tire pressure warning reset switch321
Automatic High Beam system153	Trunk closer switch96
Brake Hold switch148	Trunk opener main switch99
BSM (Blind Sport Monitor) switch197	Trunk opener switch95
Door lock switches91	Vehicle-to-vehicle distance switch188
Driving Mode Select switch202	VSC OFF switch237
Driving position memory switches108	Window lock switch119
Dynamic radar cruise control with full-	Windshield wiper and washer switch155
speed range switch188	Windshield wiper de-icer switch255
Electronic roof sunshade switches123	
Emergency flashers switch340	Т
Engine switch137	- · · · · · · · · · · · · · · · · · · ·
Garage door opener switches281	Tachometer64, 67
Heated steering wheel switch258	Rev indicator69
HUD (Head-up display) switch79	Rev peak69
Ignition switch137	Tail lights
Instrument panel light control switches	Light switch150
66,70	Replacing light bulbs335
Intuitive parking assist switch206	Theft deterrent system
Light switches150	Alarm56
5	Engine immobilizer system54

Tire inflation pressure	325	Trailer towing	135
Maintenance data		Transmission	
Tire inflation pressure display f	unction	Automatic transmission	141
	319	Driving Mode Select switch	
Warning light		Paddle shift switches	
Tire information		S mode	
Glossary		Trip meters	
Size		Trunk	
Tire identification number		Hands Free Power Trunk Lid	96
Uniform Tire Quality Grading	394	Internal trunk release lever	97
Tire pressure warning system		Power trunk lid	
Function		Smart access system with pus	sh-button
Initializing		start	
Installing tire pressure warning		Trunk closer switch	
and transmitters		Trunk easy closer	97
Registering ID codes		Trunk features	
Warning light		Trunk grip	
Tires		Trunk light	
Chains		Trunk opener main switch	
Checking		Trunk opener switch	
If you have a flat tire		Trunk storage extension	
Inflation pressure		Wireless remote control	
Information		Trunk light	
Replacing		Turn signal lights	
Rotating tires		Replacing light bulbs	
Size		Turn signal lever	
Snow tires		3	
Spare tire		U	
Tire inflation pressure display f			
		USB charging ports	270
Tire pressure warning system.	319		
Warning light		V	
Tools		Vanity lights	260
Top tether strap	51	Vanity lights	
Total load capacity		Vehicle data recordings	
Towing		Vehicle identification number	
Dinghy towing	136	Vehicle Stability Control (VSC)	
Emergency towing		Ventilators (seat ventilators)	
Towing eyelet		VSC (Vehicle Stability Control)	
Trailer towing		V 30 ( V ethicle Stability Control)	200
TRAC (Traction Control)			
Traction Control (TRAC)			

Trailer towing	135
Transmission	
Automatic transmission	
Driving Mode Select switch	
Paddle shift switches	.143,144
S mode	144
Trip meters	65,70
Trunk	
Hands Free Power Trunk Lid	96
Internal trunk release lever	97
Power trunk lid	93
Smart access system with push-	-button
start	
Trunk closer switch	
Trunk easy closer	
Trunk features	
Trunk grip	
Trunk light	
Trunk opener main switch	
Trunk opener switch	
Trunk storage extension	
Wireless remote control	
Frunk light	
Turn signal lights	
Replacing light bulbs3	
Turn signal lever	
Turri signariever	143
	_
U	
JSB charging ports	270
V	
Vanity lights	269
Vanity mirrors	
Vehicle data recordings	
Vehicle identification number	
Vehicle Stability Control (VSC)	


W	
Warning buzzers	
ABS	350
Airbags	
Approach warning	
Brake hold	355
Brake Override System	350
Brake system	
Charging system	
Downshifting14	
Drive-Start Control	
Electric power steering	
Engine	
High coolant temperature	
Intuitive parking assist21	
Low engine oil pressure	
LTA (Lane Tracing Assist)176	
Open door9	
Open hood	
Open trunk	
Open window	
PKSA (Parking Support Alert)	
PKSB (Parking Support Brake)	
Pre-collision braking	
RCD (Rear Camera Detection)	
RCTA (Rear Cross Traffic Alert)	
Seat belt	
Warning lights	
ABS	
Brake hold operated indicator	
Brake Override System	
Brake system	
Charging system	
Drive-Start Control	
Electric power steering	
High coolant temperature	
Intuitive parking assist OFF indicat	
Low engine oil pressure	
Low fuel level LTA indicator	
Malfunction indicator lamp	
i*iaitunction indicator lamp	349

Master warning light	 355
Parking brake indicator	
PKSB OFF indicator	
Pre-collision system	354
RCD OFF indicator	
RCTA OFF indicator	
Seat belt reminder light	
Slip indicator	
SRS	
Tire pressure	352
Warning messages	
Washer	155
Checking	
Preparing and checking before wi	
Switch	
Washing and waxing	
Weight	
Cargo capacity	135
Load limits	135
Weight	382
Wheel lock key	
Wheels	
Size	387
Window lock switch	119
Windows	118
Power windows	118
Rear window defogger	252
Washer	
Windshield wiper de-icer	
Windshield wipers	
Position	
Rain-sensing windshield wipers	
Winter driving tips	
Wireless charger	
Wireless remote control	
Battery-Saving Function	
Locking/Unlocking	
Replacing the battery	
, ,	

## For information regarding the equipment listed below, refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MANUAL".

- · Audio/video system
- · Navigation system
- · Lexus parking assist monitor
- · Panoramic view monitor
- · Lexus Enform

## **GAS STATION INFORMATION**



- $\blacktriangle$  Auxiliary catch lever ( $\rightarrow$ P.308)
- **B** Trunk opener  $(\rightarrow P.95)$
- **D** Fuel filler door  $(\rightarrow P.162)$
- **E** Hood lock release lever  $(\rightarrow P.308)$
- **F** Tire inflation pressure ( $\rightarrow$ P.387)

Fuel tank capacity (Reference)	16.0 gal. (60.6 L, 13.3 lmp.gal.)	
Fuel type	Unleaded gasoline only	P.383
Cold tire inflation pressure		P.387
Engine oil capacity (Drain and refill — reference)		P.384
Engine oil type		P.384

## **©**LEXUS

Owner's Manual: Publication No. OM33A85U Part No. 01999-33A85 Printed in Japan 01-1807-00 C ES 350(北米U)