


1 DESCRIPTION

- The IS40P uses Active Infrared technology for presence detection.



2 SPECIFICATIONS


DESCRIPTION	SPECIFICATION
SENSOR TILT ANGLE	15° to 45°
SUPPLY VOLTAGE	12 to 24 VAC ±10% 12 to 24 VDC +30% / -5%
MAIN FREQUENCY	50 to 60 Hz
POWER CONSUMPTION	< 2 W
RELAY OUTPUT - Max. Voltage - Max. Current - Max. Switching Power	2 Relays with switch-over contact (voltage free) 60 VDC / 125 VAC 1 A (resistive) 30 W (DC) / 60 VA (AC)
INSTALLATION HEIGHT	8 ft - 16 ft (2.5 m – 6 m)
TEMPERATURE RANGE	-22°F (-30°C) to + 140°F (60°C)
PROTECTION DEGREE	IP65 / NEMA 4
NORM CONFORMITY	Electromagnetic compatibility (EMC) according to 2004/108/EEC, R&TTE: 1999/5/EC
DIMENSIONS (D X W X H)	5 in × 4 in × 3.75 in (127 mm × 102 mm × 96 mm)
MATERIAL - Housing - Face	ABS Polycarbonate
COLOR - Housing - Face	Black Transparent Purple
CABLE LENGTH	32 ft (10 m)
TECHNOLOGY	INFRARED 
RADIATED FREQUENCY	875 nm
RADIATED POWER DENSITY	< 250 mW/m²
DETECTION MODE	Presence
MAXIMUM DETECTION FIELD	10 ft x 10 ft (3 m x 3 m)
OUTPUT HOLD TIME	0.5 s – 9 s (Activation Relay) / 0.5 s (Presence Relay)
REACTION TIME	250 ms
MINIMUM TARGET SPEED	0 in/s (0 cm/s)
LED SIGNAL	Green = Activation Relay / Red = Presence Relay
SENSOR ANGLE	15°, 30°, 45°

3 PRECAUTIONS




- ❑ This device IS NOT intended for use as a safety sensor.
- ❑ Not recommended for dynamic environments. (snow, rain, fog, etc.)
- ❑ Shut off all power before attempting any wiring procedures.
- ❑ Maintain a clean & safe environment when working in public areas.
- ❑ Constantly be aware of pedestrian/vehicle traffic around the area.
- ❑ Always stop pedestrian/vehicle traffic through the doorway when performing tests that may result in unexpected reactions by the door.
- ❑ ESD electrostatic discharge: Circuit boards are vulnerable to damage by electrostatic discharge. Before handling any board ensure you dissipate your body's charge.
- ❑ Always check placement of all wiring before powering up to insure that moving parts will not catch any wires and cause damage to equipment.
- ❑ Ensure compliance with all applicable safety standards upon completion of installation.
- ❑ DO NOT attempt any internal repair of the sensor. All repairs and/or component replacements must be performed by BEA Inc. Unauthorized disassembly or repair:
 1. May jeopardize personal safety and may expose one to the risk of electrical shock.
 2. May adversely affect the safe and reliable performance of the product and will result in a voided product warranty.


4 DIMENSIONS (inches)



Wall mounting



Ceiling mounting



Bracket dimensions


5 INSTALLATION TIPS



The sensor must be firmly fastened to prevent vibration.



DO NOT cover the sensor.



Avoid exposing the sensor to sudden temperature changes




Avoid proximity to neon lamps, fluorescent lights or moving objects




The sensor must not have any object likely to move or vibrate in its sensing field.

6 MOUNTING



Remove the bracket from the sensor. Drill 2 holes accordingly. If necessary, drill an additional hole to facilitate wire routing. Fix the bracket firmly.



Position the sensor on the bracket and fasten the angle adjustment screws.



7 WIRING AND RELAY CONFIGURATION

WIRING	POWER	RED BLACK	 12-24 V  AC-DC	 Green LED Presence  Red LED Presence
	ACTIVATION RELAY	WHITE GREEN YELLOW	 COM  NO  NC	
	PRESENCE RELAY	WHITE/BLACK GREEN/BLACK YELLOW/BLACK	 COM  NO  NC	

RELAY CONFIGURATION 		Activation Relay	Presence Relay
	1	Active	Passive
	2	Passive	Active
	3	Passive	Passive
	4	Active	Active




	Description	Active	Passive
Detection		COM ● NO ● NC	COM ● NO ● NC
			
No Detection		COM ● NO ● NC	COM ● NO ● NC
			

8 SENSOR ANGLE



Adjust the angle of the sensor to position the detection field

Tighten the screws firmly



Notes:

1. It is important to adjust sensor angle to position IR field correctly.
2. To obtain an IR pattern that's straight down (closest to the door threshold); wall mounted sensors need to be set at 20°; sensors mounted on an extension bracket or out from the wall should be set to approximately 15°.
3. The graphics above are not to scale and for illustration purposes and represent an approximate IR detection field when at 16 ft. The point of emphasis is to show the IR detection area with respect to the sensor angles.


9 IR PATTERN SIZE AT 15° SENSOR ANGLE

Approximate default IR pattern size using a 15° sensor tilt angle.
The higher the mounting height the larger the IR pattern.

Mounting Height	Width *	Depth *
A = 8 ft	5 ft	5 ft
B = 10 ft	7 ft	7 ft
C = 11.5 ft	7.5 ft	7.5 ft
D = 13 ft	8.5 ft	8.5 ft
E = 16 ft	10 ft	10 ft
Maximum Mounting Height		
IS40P	16 ft	

* Dimensions are approximate.

Use of BEA Spotfinder may be utilized to locate IR field.



OUTPUT CONFIGURATION													
OUTPUT CONFIGURATION F1 DOOR EXAMPLE <table border="1" style="width: 100px; height: 100px;"> <tr><td> </td><td> </td></tr> <tr><td>LAST LINE</td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td>FIRST LINE</td><td> </td></tr> </table>			LAST LINE						FIRST LINE		PRESENCE RELAY	IS40P	LED
	LAST LINE												
	FIRST LINE												
	0 - 6: ALL MODES		Activates when object is in presence zone.	Red									
	ACTIVATION RELAY	IS40P	LED										
0: STANDARD MODE		Activates when object is in presence zone	Green										
1: PULSE ON ENTRY		Activates when object enters presence zone											
2: PULSE ON EXIT		Activates when object exits presence zone											
3: PULSE ON ENTRY FIRST / LAST LINE (See Example to the Left)		Activates when object enters presence zone (first or last line)											
4: PULSE ON EXIT FIRST / LAST LINE (See Example to the Left)		Activates when object exits presence zone (first or last line)											
5: REMAINS ACTIVE UNTIL PRESENCE ZONE IS CLEARED		Activates when object is in presence zone											
6: REMAINS ACTIVE UNTIL PRESENCE ZONE IS CLEARED		Activates when object is in presence zone											

IR / Presence Settings

0

1

2

3

4

5

6

7

8

9

FREQUENCY													
IR IMMUNITY		low	high										
AUTOMATIC LEARN TIME		30 s	1 min	2 min	5 min	10 min	20 min	1 h	1.5 h	2 h	∞		
ACTIVATION RELAY HOLD TIME		.5 s	1 s	2 s	3 s	4 s	5 s	6 s	7 s	8 s	9 s		

Note: The automatic learn time is the amount of time a static object needs to be in the IR field before the sensor will learn it.

= FACTORY VALUES

IR / Presence Settings (Continued)



IR PATTERN SIZE BE	AVAILABLE TARGET SIZE F2

The target (Target Size) can vary location within the field (IR Pattern Size)

 = FACTORY VALUES

10 REMOTE CONTROL PARAMETERS (CONTINUED)

Check parameter values

QUESTION A VALUE

The number of green flashes indicates the value of the chosen parameter.

11 SENSOR SETUP SEQUENCE / FACTORY VALUES / ACCESS CODE

IMPORTANT: ENSURE TO SAVE ANY CHANGES DURING THE ADJUSTMENT SESSION VIA PRESSING LOCK LOCK.



IMPORTANT: ALWAYS FINISH AN ADJUSTMENT SESSION BY LAUNCHING A SETUP.



RESETTING TO FACTORY VALUES



SETTING AN ACCESS CODE



DELETING AN ACCESS CODE




If you do not know the access code, cycle the power supply. Within 1 minute, you can access the sensor without introducing any access code or delete the existing access code per the instructions above.

12 TROUBLESHOOTING


SYMPTOMS

POSSIBLE CAUSES

CORRECTIVE ACTION



12 TROUBLESHOOTING (CONTINUED)



13 ACCESSORIES




Telescoping HD Bracket
P/N: 10HDBRACKET



Remote control
P/N: 10REMOTE



Spotfinder
P/N: 10SPOTFINDER



Transformer
P/N: 1024VAC

14 COMPANY CONTACT



Do not leave problems unresolved. If a satisfactory solution cannot be achieved after troubleshooting a problem, please call BEA, Inc. If you must wait for the following workday to call BEA, leave the door inoperable until satisfactory repairs can be made. Never sacrifice the safe operation of the automatic door or gate for an incomplete solution.

Our Service Technicians can be called 24 hours a day, 7 days a week. For more information visit www.beasensors.com.

For email support contact us at: Tech_Services@beainc.com

Phone: 1-800-523-2462

Fax: 1-888-523-2462

After Normal Business Hours

West / Mexico
1-888-419-2564

Central
1-800-407-4545

AK, MI, WI, TX, Canada
1-866-836-1863

East
1-866-249-7937