

STANLEY[®]

**iQ Controller
Installation and Operation Manual
204144**

INCLUDES INSTRUCTIONS FOR

**DURA-GLIDE™ 2000/3000, 5200/5300,
DURA-GUARD™, DURA-STORM™, DURACARE™, 5400-SERIES,
PROCARE™ 8300A, AND DURACARE 7500A TL-FBO
AUTOMATIC SLIDE DOOR SYSTEMS**

Stanley Part Number 204144

REV A 05.2018

Copyright 2018, Stanley Access Technologies, LLC.

Prohibition on Copying: Any unauthorized reproduction, disclosure or distribution of copies by any person of any portion of this work may be a violation of copyright law of the United States of America and other countries, could result in the awarding of statutory damages of up to \$250,000 (17 USC 504) for infringement, and may result in further civil and criminal penalties. All rights reserved.



All manuals can be found at
www.stanleymobileapps.com



Table of Contents

General Description	2
Intended Use	2
Applicability	2
Prerequisites	3
Precautions	3
Installation Instructions	3
Installing the iQ Controller	3
Wiring Instructions	3
Evaluating Power Requirements	3
Connecting Main Power Wiring	4
Connecting Accessories (As Applicable)	4
Tune-In Instructions	4
Tuning In the iQ Controller Using a Handheld Device	5
Tuning In the iQ Controller Using the Controller Pushbuttons	9
Final Tune-In Adjustments	21
Spare Parts List	22
Attachments	23
Attachment 1 - iQ Controls and Indicators	23
Attachment 2 - iQ System Wiring Diagram	25
Attachment 3 - iQ Terminal Block Connections TB1-TB7	36
Attachment 4 - ANSI/BHMA and UL Compliance Requirements for Sliding Doors ..	37
Attachment 5 - Handheld Device Troubleshooting Aid	40
Attachment 6 - Handheld Device Troubleshooting Screen Descriptions	41
Attachment 7 - iQ Troubleshooting Aid	43
Attachment 8 - Fine Tuning Slide Doors	44

1 GENERAL DESCRIPTION

Intended Use

This manual provides installation instructions, wiring instructions, and tune-in instructions for the iQ Controller. It includes instructions for Dura-Glide™ 2000/3000, 5200/5300, Dura-Guard™, Dura-Storm™, Dura-Max™, 5400-Series, ProCare™ 8300A, and DuraCare™ 7500A TL-FBO Automatic Slide door systems.

On Dura-Glide sliding doors, the iQ Controller replaces the MC521 and MC521Pro, or both the microprocessor control box and the interface board on older models. The door activation devices (SU-100 motion sensors, carpets, control mats, push plates, etc.), lock, function switch, doorway holding beams, and door position switches previously connected to the interface board must be connected to the iQ Controller.

Attachment 1 illustrates the iQ Controller controls and indicators. Attachment 2 illustrates system wiring for Dura-Glide series sliders.

Applicability

This manual is applicable to the Dura-Glide series sliding doors used on Dura-Glide™ 2000/3000, 5200/5300, Dura-Guard™, Dura-Storm™, Dura-Max™, 5400-Series, ProCare™ 8300A, and DuraCare™ 7500A TL-FBO Automatic Slide door systems.

Instructions for connecting optional accessories are not provided in this manual.

Prerequisites

Special Items Required:

- Stanley Access Technologies document No. 203957, "SU-100 Motion Sensor Installation and Operation" (if installed).
- SU-100 tune-in remote control (if SU-100 Motion Sensor is installed).
- Stanley Access Technologies document No. 203768, "Stanguard™ Threshold Sensor Installation and Operation" (if installed).
- Optex X Zone T or X Zone ST manufacturer's installation and tune-in instructions (if installed).
- Hotron HR100 ST manufacturer's installation and tune-in instructions (if installed).
- Bluetooth adapter or cable to connect compatible handheld device to iQ Controller.
- Degreaser.
- Instructions for any other device to be wired into the iQ Controller.

Precautions

All ANSI/BHMA and UL Requirements in Attachment 4 must be met before the door is put into operation.

2 INSTALLATION INSTRUCTIONS

Installing the iQ Controller

NOTE: This manual covers new door installations in which the iQ is factory-installed and wired.

3 WIRING INSTRUCTIONS

Evaluating Power Requirements

- ENSURE power source is a dedicated 115 VAC, 50/60 Hz source with 20A circuit rating. If four operators are used, the source should have a 30A rating.
- ENSURE **no more than** four operators will be connected to one circuit.
- ENSURE power source is **not shared with other equipment**, i.e., cash registers, EAS systems, or other electromagnetic interference generators.

Connecting Main Power Wiring

⚠ Warning: To prevent injury to personnel, incoming electrical power to the header must be de-energized before connecting electrical service to the control box.

⚠ Warning: All electrical wiring must conform to National Electrical Code Requirements.

1. **DE-ENERGIZE** incoming electrical power to header.
2. Refer to Attachment 2, and, using wire nuts, **CONNECT** incoming line, neutral, and ground wires to the controller power harness.
3. **IE** adhesive wire clamps will be used, **DE-GREASE** metal surfaces on inside of header cover where clamps will mount.
4. **SECURE** wiring to top of the header track tube, and **ENSURE** the following:
 - All wires are clear of belts and belt brackets.
 - Header cover opens and closes without interference.

Connecting Accessories (As Applicable)

Refer to Attachments 2 and 3, and **CONNECT** any of the following subsystems to the iQ Controller:

- Function switch (rotary, rocker and “POWER” switch wiring).
- Stanguard™ threshold sensor.
- Doorway holding beam(s).
- Breakout switch.
- Solenoid lock.
- SU-100 motion sensor(s) wiring (refer to Stanley Document #203957).
- Optex X Zone T and X Zone ST Sensor(s) wiring.
- Push plate wiring.
- Door position switch closed contact (with door closed).
- Hotron HR100 ST Sensor(s) wiring.


4 TUNE-IN INSTRUCTIONS

⚠ Warning: The door path must be free of objects and remain clear until the First Install Sequence (FIS) is complete. During this sequence the sensors are inactive and the door has no SAFETY. To stop the door, **turn power off** or put the **doors into breakout**.

NOTE:

1. **Tune-In:** The iQ Controller can be tuned-in using a handheld device or using the pushbutton switches located on the controller. Tune-in using a handheld device is the preferred method.
2. **Status Codes:** During normal operation, the digital display indicates status codes. The “UP” and “DOWN” pushbutton switches can be used to enter and display data values. The user interface values are shown in Tables 2 through 4.

3. **Solenoid Lock:** If a solenoid lock is installed with no lock circuit board (new style), set Lock Logic to the actual lock type (Fail Safe or Fail Secure). If a Fail Safe or Fail Secure Lock is being installed with a lock circuit board (old style), the Lock Logic must be set to Fail Secure.
4. **Handing:** Manually open door noting rotation of belt pulleys. If counter clockwise (CCW) use right hand during FIS. If clockwise (CW) use left hand during FIS. See figure below.
5. **FIS:** The first installation sequence (FIS) is used to perform the initial configuration. Upon completion of FIS, all setup parameters are stored in non-volatile memory. Subsequent power cycles will reload the configuration parameters that were configured during FIS.
6. Decimal points on digital display are encoder 1 signals. Rotating motor will cause decimal points to blink and appear to dim.
7. After changing values, the values must be saved in non-volatile memory by cycling the door to full open.



Tuning In the iQ Controller Using a Handheld Device

NOTE: The following steps provide instructions for tuning the iQ Controller using a handheld device. The iQ Toolbox application software is required. Connect the handheld device to the iQ Controller, turn on header POWER switch, and perform the following steps.




Step 1: Start iQ Toolbox application.



Step 2: Press **RESTART FIS** on the **Main Selection** menu. (**FIS** = First Install Sequence).

NOTE: Firmware is the software revision. Cycles are door cycles in memory.

 <p>Step 3: Select Duraglide.</p>	 <p>Step 4: Make appropriate selection. Step 4a: Press BEGIN FIS.</p>
 <p>Step 5: Select CONFIGURE DOOR.</p>	 <p>Step 6: Press Dropdown List icon.</p>
 <p>Step 7: Select the parameter that needs to be changed. Scroll down for more options.</p>	 <p>Step 8: Use the slider to set a desired value. Step 8a: Use the BACK button to go back.</p>



9




Step 9: Select **BEGIN AUTOCONFIGURE**.

Step 10: Acknowledge the **WARNING** by pressing **NEXT**.




11



Step 11: Select **OPERATE DOOR**.


Step 12: Press **MOTOR 1** to operate door. Door will open and close slowly. Control will display 00 when complete.



Step 13: Press **TROUBLESHOOTING**.



Step 14: View the I/O grid to verify the sensors and inputs/ Dark indicates input/output contact is closed. Light indicates input/output contact is open. Gray never changes.

 <p>Step 15: Indicators for troubleshooting mode.</p> <p>Step 15a: When enabled, Output Control On is displayed. See Attachment 6 for more information.</p>	 <p>Step 16: Press MORE for more functionalities.</p>
 <p>Step 17: Press Summary to view all current settings.</p>	 <p>Step 18: Review the information on the Summary listing.</p>
 <p>Step 19: Once complete, press back.</p>	<p>Intentionally left blank</p>

Tuning In the iQ Controller Using the Controller Pushbuttons

NOTE:

1. To change the **INDEX** and **VALUE**:

To show the **INDEX** press and hold **ENTER**, the current **INDEX** will display. Once **ENTER** is released, the display will show the **VALUE** of that **INDEX**. After 2.5 seconds, the display will return to the current status code.

2. To change a **VALUE**:

a. Unlock the keypad by setting index 99 to value 00.

b. After the desired **INDEX** is selected, release **ENTER** and **within 2.5 seconds** press **UP** or **DOWN** to get the desired **VALUE**. (If the **UP** or **DOWN** buttons are not pressed within 2.5 seconds of releasing the **ENTER** button, the display will change from the **VALUE** back to the **STATUS**.)

3. To change the **INDEX**:

Hold **ENTER** switch while pressing **UP** or **DOWN** to get desired **INDEX**.

4. To display **STATUS CODE**:

A few seconds after the **VALUE** is selected, the display indicates the **STATUS CODE**.

5. Read the descriptions entirely before performing each step. Check the **INDEX** and **VALUE** after each step.

6. To **STORE CHANGES** in permanent memory:

Cycling door open one time will store changes.



7. To **LOCK** keypad:

Lock keypad by setting index **99** to value **01** or by turning power **OFF** and then **ON**.

8. To **ACCESS** the door cycle counter function:

a. **Ensure** that the keypad is locked by setting index 99 to 01.

b. **Ensure** that the index is set to any index but 99.

c. **Press** the up or down key to access the door cycle counter.

The display will show “dc” followed by four pairs of digits, followed by “dc”.

Example: If the Door Count was **12345678** cycles the controller will display “dc” “12” “34” “56” “78” “dc”.

Table 1. FIS Procedure using Pushbuttons

Step	Description	Display		
		Index	Value	Status Code
1	Set Function Switch to Closed .			
2	Turn power on.			
3	Unlock keypad.	99	00	00
4	Restart FIS .	96	01	A0
5	Select door type: Slide, <u>01</u> single motor or <u>02</u> dual motor.	00	01 (Single) 02 (Dual)	
6	Select Handing: <u>00</u> Right or <u>01</u> Left. Manually open door and note rotation of belt pulleys. If counterclockwise (CCW) use right hand during FIS. If clockwise (CW) use left hand during FIS.	01	00 (Right) 01 (Left)	A0
7	Accept FIS . Display will go to A1 .	03	01	A1
8	Make changes: Function Switch <u>01</u> Rocker or <u>00</u> Rotary. The INDEX will start at 00.	11	01 (Rocker) 00 (Rotary)	A1
9	Select Lock Logic: Lock Logic, <u>00</u> = Fail Safe; <u>01</u> = Fail Secure; <u>02</u> = Fail Safe Dura-Max; <u>03</u> = Fail Secure Dura-Max. NOTE: For locks with circuit board, set to 01 Fail Secure. For locks with no circuit board, set to Fail Safe or Fail Secure.	07	Lock Logic: 00 = Fail Safe 01 = Fail Secure 02 = Fail Safe Dura-Max 03 = Fail Secure Dura-Max	
10	Warning: During this sequence the sensors are inactive and the door has NO SAFETY . To stop the door, TURN POWER OFF or PUT THE DOOR INTO BREAKOUT . Function Switch: Switch to OPEN , momentarily, then CLOSED/LOCKED . The door opens fully, delays and then closes fully. The iQ displays A2 when FIS is completed.			A2
11	Lock keypad.	99	01	00
12	Final Tune-In.			

Table 2. Index List

Index	Description
0 - 99	Settings Values, see Table 3.
90 - 95	Reserved.
96	Command – Restart FIS. Entering “01” will cause FIS to restart.
97	Firmware – Entering “01” will display “FE” followed by two pairs of digits followed by “FE”. For example, if the firmware was 0609 the controller will display “FE” “06” “09” “FE”.
98	Command – Restart auto configuration. Entering “01” sets the Control Box to “A1” keeping all previous values and then re-learns the encoder count.
99*	Command – Lock. Entering “01” will lock all value inputs except this index. This prevents inadvertent changes to input values. Values may be unlocked by entering “00” in this index.

Table 3. Settings

Index	Min. Value	Max Value			Defaults	
					Single	Dual
0	1	99*	Open Speed	Open Speed is the speed used during normal operation in the opening state (02). This speed is set to change how long it takes the door to open.	99	99
				This parameter sets the target speed setting. Other parameters like open torque, open startup torque, open startup length, and open acceleration as well as door properties like friction, door length, and door weight affect door speed.		
1	1	99	Close Speed	Close Speed is the speed used during normal operation in the closing state (07). This speed is set to change how long it takes the door to close.	35	25
				This parameter sets the target speed setting. Other parameters like Close Torque, Close Startup Torque, Close Startup Length, and Close Acceleration as well as door properties like friction, door length, and door weight affect door speed.		
2	1	99	Open Check Speed	Open Check Speed is the speed used during normal operation in the open check state (04) prior to arriving at full open. This speed is set to determine how fast the door arrives at full open after open speed.	10	10
				This parameter sets the target speed setting. Other parameters like open check torque, open acceleration, and open braking as well as door properties like friction, door length, and door weight affect door speed.		

NOTE: Parameters available with firmware greater than 10.20

* Max Values go to 125 via handheld.

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
			Single	Dual	Single	Dual
3	5	99	Open Check Length	Open Check Length is the percent of door length in which the door starts to slow down to open check speed. This parameter typically is adjusted based on door weight and open speed setting.	40	25
4	5	99	Close Check Length	Close Check Length is the percent of door length in which the door starts to slow down to Close Check Speed. This parameter typically is adjusted based on door weight and Close Speed setting.	15	15
5	1	99	Reduced Open Length	Reduced Open Length is the percent of door length from the full open position the door will stop at if in reduced open mode.	1	1
6	1	99	Hold Open Delay	Delay that the door stays open after all sensors have cleared (0 to 25 seconds).	15	15
7	0	3	Lock Logic	Select to choose desired Lock Logic. NOTE: Dura-Max 5400 logic is different and has its own two options: 00 = Fail Safe (unlocked when power is removed), 01 = Fail Secure (locked when power is removed), 02 = Dura-Max Fail Safe (unlocked when power is removed), 03 = Dura-Max Fail Secure (locked when power is removed).	1	1
8	1	99	Open Torque	Open Torque is the torque used during normal operation following the end of open startup length. This torque must be set to comply with BHMA/ANSI door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with open speed.	40	45

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
			Single	Dual	Single	Dual
9	1	99	Close Torque	Close Torque is the torque used during normal operation following the end of Close Startup Length. This torque must be set to comply with BHMA/ANSI door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with Close Speed.	30	25
10	1	99	Close Check Torque	Close Check Torque is the torque used during normal operation in close check state. This torque must be set to comply with BHMA/ANSI door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with close check speed.	35	25
11	0	2	Function Switch Type	00 = Double pole rotary 01 = Rocker 02 = ICU	1	1
12	0	1	2S Operation;	00 = 2S mode disabled / normal 01 = Push switch to open, push switch to close;	0	0
13	1	60	Close Obstruction Time	Close Obstruction Time is the amount of time in increments of 0.025s the door applies force when almost stopped or stopped when the controller indicates a state of "07". Before increasing this parameter, check mechanical issues, and speed and torque parameter settings.	50	50
14	0	99	Open Acceleration	Open Acceleration affects the rate at which the door gets to its target speed. This parameter is used when the door is lagging open speed; open startup torque and open startup length should be investigated prior to increasing. This parameter affects all open motion speeds: open speed, open check speed, open learn speed, as well as open braking.	30	30

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value		Description	Defaults	
					Single	Dual
15	1	99	Open Braking	The Open Braking parameter adjusts how quickly the door slows down prior to check speed. Increasing this parameter increases braking power.	8	8
16	0	99	Close Acceleration	Close Acceleration affects the rate at which the door gets to its target speed. This parameter is used when the door is lagging close speed, close startup torque and close startup length should be investigated prior to increasing. This parameter affects all close motion speeds: close speed, close check speed, close learn speed, as well as close braking.	20	20
17	1	99	Close Braking	The Close Braking parameter adjusts how quickly the door slows down prior to check speed. Increasing this parameter increases braking power.	4	2
18	0	6	Delayed Egress	Special Locking Application. See the Delay Egress Instruction Manual for use. 00 = Off 01 = 15 sec delay 1 second nuisance 02 = 30 sec delay 1 second nuisance 03 = 15 sec delay 2 second nuisance 04 = 30 sec delay 2 second nuisance 05 = 15 sec delay 3 second nuisance 06 = 30 sec delay 3 second nuisance	0	0
19	0	5	Sensor System	00 - Monitored 2 Sensors: Threshold zone control (the threshold zone is enabled and disabled by the iQ). 1 - Monitored 4 Sensors: Threshold zone control (the threshold zone is enabled and disabled by the iQ). 2 - Monitored StanGuard™: (not recommended for Telescopic doors). 3 - Monitored 2 sensors. 4 - Non-monitored sensors. 5 - Monitored 4 sensors.	2	2

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
			Single	Dual		
20	0	1	Hold Beam Type	00 - Non-monitored Hold Beam 01 - Monitored Hold Beam Selects the hold beam type to be used for monitored or non-monitored applications. Monitored Hold Beams: Photobeam Pro or Optex OS12CT. Refer to wiring diagrams per application.	1	1
21	1	50	Lock Delay	This allows the lock to mechanically unlock before door motion. Lock Delay in 0.1 second increments.	1	1
22	0	99	Open Stop Distance	Distance from full open that the door will stop. This will be in 0.25" increments.	4	4
23	1	99	Close Check Speed	Close Check Speed is the speed used during normal operation in the close check state (09) prior to arriving at full closed. This speed is set to determine how fast the door arrives at full closed after close speed. This parameter sets the target speed setting. Other parameters like close check torque, close acceleration, and close braking as well as door properties like friction, door length, and door weight affect door speed.	8	8
24	0	1	Access Control Pro Enabled	Inside sensor lockout function. 00 = OFF 01 = ON	0	0
25	0	5	Close Press	Close Press affects how the doors press together at full closed. If the value selected is 0, the door does not press at the closed position. A value of 1 will have a softer release of motor energy and a value of 5 will be a quicker release.	2	2
27	1	99	Lock Release Torque	Lock Release Torque is the torque used on lock release state. A closed position switch is required, connected to TB-5. This parameter sets the maximum current available to the motor which is directly proportional to the door force.	20	20
28	1	60	Close Check Obstruction Time	Close Check Obstruction Time is the amount of time in increments of 0.025s the door applies force when almost stopped or stopped when the controller indicates a state of "09". Before increasing this parameter, check mechanical issues, and speed and torque parameter settings.	50	50

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
			Single	Dual	Single	Dual
31	1	99*	Close Learn Speed	<p>Close Learn Speed is the speed used on power up, during FIS and after an obstruction. The controller display may indicate either 07 or 09 as a door state and still use Close Learn Speed based on the conditions listed prior.</p> <p>This speed is typically set higher than check speed, to allow faster door motion when not in the check zones, but still slower door motion than normal operation.</p> <p>This parameter sets the target speed setting. Other parameters like close learn torque and close acceleration as well as door properties like friction, door length, and door weight affect door speed.</p>	20	20
32	1	99	Close Learn Torque	<p>Close Learn Torque is the torque used on power up, during FIS, after an obstruction.</p> <p>This torque must be set to comply with ANSI/BHMA door force requirements.</p> <p>This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with Close Learn Speed.</p>	30	25
33	0	99	Close Startup Length	<p>Close Startup Length is the percent of door length in which Close Startup Torque parameter is used. These parameters are used to overcome friction encountered at the beginning of close door motion.</p> <p>This parameter should be set as low as possible to ensure reliable operation.</p>	0	0
35	1	99	Close Startup Torque	<p>Close Startup Torque is the torque used when entering the closing state (07). It is used for a configurable door length (determined by the Close Startup Length parameter). After this door length, the torque setting will revert to the Close Torque.</p> <p>This torque should be set greater than Close Torque to ensure that the controller can start door motion, overcome static friction, and avoid obstructions.</p> <p>This torque must be set to comply with ANSI/BHMA door force requirements.</p> <p>This parameter sets the maximum current available to the motor which is directly proportional to the door force.</p>	35	25

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
			Single	Dual	Single	Dual
36	1	60	Open Check Obstruction Time	Open Check Obstruction Time is the amount of time in increments of 0.025s the door applies force when almost stopped or stopped when the controller indicates a state of "04". Before increasing this parameter, check mechanical issues, and speed and torque parameter settings.	50	50
37	1	99	Open Check Torque	Open Check Torque is the torque used during normal operation in open check state. This torque must be set to comply with ANSI/BHMA door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with open check speed.	40	40
39	1	99	Open Learn Speed	Open Learn Speed is the speed used on power up, during FIS, after an obstruction, and return from breakout. The controller display may indicate either 02 or 04 as a door state and still use Open Learn Speed based on the conditions listed prior. This speed is typically set higher than check speed, to allow faster door motion when not in the check zones, but still slower door motion than normal operation. This parameter sets the target speed setting. Other parameters like open learn torque, and open acceleration as well as door properties like friction, door length, and door weight affect door speed.	25	25
40	1	99	Open Learn Torque	Open Learn Torque is the torque used on power up, during FIS, after an obstruction, and return from breakout. This torque must be set to comply with ANSI/BHMA door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force. This torque setting is used in conjunction with open learn speed.	48	25
41	1	60	Open Obstruction Time	Open Obstruction Time is the amount of time in increments of 0.025s the door applies force when almost stopped or stopped when the controller indicates a state of "02". Before increasing this parameter, check mechanical issues, and speed and torque parameter settings.	50	50

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description		Defaults	
					Single	Dual
42	0	99	Open Startup Length	Open Startup Length is the percent of door length in which open startup torque parameter is used. These parameters are used to overcome friction encountered at the begining of open door motion. This parameter should be set as low as possible to ensure reliable operation.	15	15
44	1	99	Open Startup Torque	Open Startup Torque is the torque used when entering the opening state (02) and recycles. It is used for a configurable door length (determined by the Open Startup Length parameter). After this door length, the torque setting will revert to the Open Torque. This torque should be set greater than Open Torque to ensure that the controller can start door motion, overcome static friction, and avoid obstructions. This torque must be set to comply with ANSI/BHMA door force requirements. This parameter sets the maximum current available to the motor which is directly proportional to the door force.	85	85
45	0	99	Recycle Speed	Recycle Speed is the percent of open speed that is used when recycling in the open check or open braking zone.	30	20
46	0	50	Lock Release Time	The amount of time (seconds) that the door will press closed before going open when the lock needs to release at the closed position. The value zero disables the lock release. A closed position switch is required, connected to TB-5.	0	0
47	0	4	Fire Alarm Mode	Allows a normally closed contact to force the door open or closed slowly, upon contact opening. Used in conjunction with Configurable I/O parameter. Options 00 to 04 are minimum and maximum values: 00 = Disabled, 01 = Open, 02 = Close, 03 = Open with Retry, 04 = Close with Retry. After an obstruction, retry modes (03 and 04) will retry with short delay.	0	0

Table 3 Settings continued next page.

Table 3. Settings (continued)

Index	Min Value	Max Value	Description			Defaults			
			Single	Dual					
48	0	3	IO configuration			0	0		
			TB2-5	TB2-7	TB2-9				
	00 (Default)		1 way / 2 way	Reduced	Access control enhanced (highest priority when selected).				
					4 Monitored Sensors (when selected).				
					Delay egress reset (default).				
	01		1 way / 2 way	Reduced	Fire Alarm.				
	02				Access control enhanced (highest priority when selected).				
					4 Monitored Sensors (when selected).				
	03		Fire alarm	Reduced	Delay egress reset (default).				
					Access control enhanced (highest priority when selected).				
					4 Monitored Sensors (when selected).				
					Delay egress reset (default).				

IO Configuration Parameter Description

Allows the Fire Alarm to be used instead of functions normally used with the selected input:

0 = Standard Functions (NO Fire Alarm Input).

1 = Fire Alarm Input is TB2-9 (Removes Functions: Access Pro function, Delayed Egress Reset, and 4 Monitored Sensor capability).

2 = Fire Alarm Input is TB2-7 (Removes Reduced Open function).

3 = Fire Alarm Input is TB2-5 (Removes One-way function).

Index	Min Value	Max Value	Descriptions			Defaults	
			Single	Dual			
49	0	99	Open Power Assist Torque	This parameter sets the current to the motor which is used to make the door feel easier to move open when in "Manual" mode. This value should be set only as high as is needed to reduce the force required to move the door. Setting this value too high can cause the door to move by itself.		60	60
50	0	99	Close Power Assist Torque	This parameter sets the current to the motor which is used to make the door feel easier to move closed when in "Manual" mode. This value should be set only as high as is needed to reduce the force required to move the door. Setting this value too high can cause the door to move by itself.		50	50

NOTE: Door must be cycled open for changes to be stored in permanent memory.

Table 4. Status Codes

Status Code	Description	Remediation IF Necessary
00	Normal operation—All OK	
20	Breakout	
33	System error	See attachment 7
34	Internal communication error – Type 1	See attachment 7
35	Motor drive failure	Replace controller
36	Internal communication error – Type 2	See attachment 7
0b	Obstruction	
A0	First Installation Sequence (FIS)	
A1	Auto-configuration sequence	
A2	Auto-configuration confirmation sequence	
b1	Encoder error > cable failure	Verify magnet/encoder pair
b2	Encoder mismatch > wrong encoder/magnet	Verify magnet/encoder pair
b3	Encoder fault > wrong encoder/magnet or cable failure	Verify magnet/encoder pair
bE	Blocked egress	
c1	Position learn error	
Ld	Lock down (shear lock energized)	
db	Output control	See Attachment 6, Sheet 2 of 2
dc	Display door cycle counter	
dE	Delayed egress	
d0	Free egress	
E3	Door length error	Re-do First Installation Sequence (FIS)
E4	Presence sensor monitoring failure	Verify sensor wiring and safety logic setting
E5	Motor drive failure	
F0	Inside monitored sensor failure	Verify sensor wiring and safety logic setting
F1	Outside monitored sensor failure	Verify sensor wiring and safety logic setting
F2	Upper Photo Beam Pro sensor failure	Check transmitter, receiver, and hold beam type
F3	Lower Photo Beam Pro sensor failure	Check transmitter, receiver, and hold beam type
F6	Inside (2) monitored sensor failure	Verify sensor wiring and safety logic setting
F7	Outside (2) monitored sensor failure	Verify sensor wiring and safety logic setting
ho	Door held open	Check sensors and hold beam type
FA	Fire Alarm Active	
uL	Unlocked delay egress	

Table 5. Door States

Door State	Description
00	Door State is Closed
02	Door State is Opening
04	Door State is in Open Check
06	Door State is Full Open
07	Door State is Closing
09	Door State is in Close Check
10	Open Assist (manual mode door state)
11	Close Assist (manual mode door state)
12	Close Assist (manual mode door state)
14	Door Fault
15	Door State is in Open Stop
16	Door State is in Obstruction while Closing
17	Door State is in Close Press
19	Lock Release (door state)

NOTE: If the current status code is "Normal operation—All OK", the iQ will show the current door state. Otherwise, the iQ alternates between showing the current status code and the door state.

Final Tune-In Adjustments

1. Refer to ANSI/BHMA A156.10, "Standard for Power Operated Pedestrian Doors," and attachment 4 and DETERMINE ANSI and UL door operating requirements.
2. IF Stanguard™ threshold sensor is installed, refer to Stanley Access Technologies document No. 203768, "Stanguard™ Threshold Sensor Installation and Operation," and TUNE-IN Stanguard™ threshold sensor. **Ensure that the JP301 Jumper is properly installed for StanGuard™ Sensors.**
3. IF SU-100 motion sensor(s) are installed, refer to Stanley Access Technologies document No. 203957, "SU-100 Motion Sensor Installation and Operation," and TUNE-IN SU-100 motion sensor(s).
4. IF Optex X Zone T or X Zone ST Sensors are installed, refer to the manufacturer's installation and tune-in instructions.
5. To ensure that all settings have been stored in Non-Volatile memory, turn power OFF and then back ON. Repeat step 1 above.
 - If Hotron HR100 ST Sensors are installed, refer to the manufacturer's installation and tune-in instructions.
 - Verify that the correct Safety Logic has been selected for Sensor Monitoring and that the JP301 is in the correct position.
 - DO NOT remove JP301 when Stanguard™ is installed. X Zone T, X Zone ST and HR100 ST monitored sensors require JP301 to be removed.
6. Refer to ANSI/BHMA A156.38, "American National Standard for Low Energy Power Operated Sliding and Folding Doors" and Attachment 4 (Page 3 of 3) and determine ANSI and IBC-2018 door operating requirements.



Spare Parts List

Description	Part Number
iQ Controller (includes 2 additional terminal blocks)	314316
Encoder Kit	314317
iQ Controller Manual	204144
Harness, Rocker Switch to Control Box, 98 inches	414098
Harness, Rocker Switch to Control Box, 180 inches	414099
Harness, Holding Beam to Control Box, 24 inches	414106
Harness, Rotary Switch to Control Box, 180 inches	414107-1
Harness, Rulatry Switch to Control Box, 480 inches	414107-2
Harness, Power, 18 inches	415000
Harness, Encoder Cable Adapter, 12 inches	415001
Harness, Solenoid Lock, 67 inches (See Note)	516922-1
Harness, Solenoid Lock, 124 inches (See Note)	516922-2
Harness, Solenoid Lock Pigtail	516921
Power Supply 24VDC	516871
Terminal Block Plug, 10 position	714055
Bluetooth Adapter Kit	<p>314215 For a list of compatible handheld devices; visit : http://www.stanleyaccess.com Select Door Service > Technician Mobile Downloads > Android Apps. Select Compatible Handheld Devices Document.</p>
Compatible Handheld Device	<p>For a list of compatible handheld devices; visit : http://www.stanleyaccess.com Select Door Service > Technician Mobile Downloads > Android Apps. Select Compatible Handheld Devices Document.</p>
Harness, motor, 14 feet	413362
Harness, motor, 17 feet	413362-1
Harness, line connect, 6 feet	412544
Harness, line connect, 10 feet	412545
Harness, Rocker Switch to Control Box, 252 inches	414126
Harness, Solenoid Lock Power Signal, 264 inches	516823-4
Harness Motor Extension, 42 inches	411746
MC521 Comm Extension Retro Kit, 6 feet	313995
MC521 Comm Extension Retro Kit, 40 feet	313996
Harness, Encoder Extension 40 inches	415079

NOTE: When replacing a solenoid lock harness, solenoid lock pigtail harness 516921 is required for solenoid locks that do not have a pigtail.

Attachment 1
iQ Controls and Indicators
(Sheet 1 of 2)

NOTE: See next page for indicators and descriptions




Copyright 2018, Stanley Access Technologies, LLC. All rights reserved. Reproduction in whole or in part without the express written permission of Stanley is prohibited.

05.15.2018


Attachment 1
iQ Controls and Indicators
(Sheet 2 of 2)

ITEM	CONTROL/INDICATOR	DESCRIPTION
1	Motor 2 Connector	Motor No. 2 connector.
2	Power Connector	Connection point for incoming line, neutral, and common power wiring.
3	Fuse	Controller fuse-- 5 Amp, 250V.
4	Motor 1 Connector	Motor No. 1 connector.
5	Terminal Block Connector TB1	Connection point for 24V power supply and solenoid lock.
6	Terminal Block Connector TB2	Connection point for function switch (rotary or rocker).
7	Terminal Block Connector TB6	Push plate outside. Photobeam Pro and Test output.
8	Encoder 2 Connector	Encoder # 2 Connector.
9	Two Digit Display	Displays Controller Status. Also serves as the display for tune-in by pushbutton switches and indicates encoder movement. High resolution encoder may be dim.
10	Encoder 1 Connector	Connection point for motor encoder No. 1.
11	Up Pushbutton Switch	Used for manual setup and tuning of door when handheld is not available.
12	Down Pushbutton Switch	Used for manual setup and tuning of door when handheld is not available.
13	Enter Pushbutton Switch	Used for manual setup and tuning of door when handheld is not available.
14	RS232	RS232 connector. Connection point for Bluetooth harness.
15	Jumper JP301	Keep jumper installed for Stanguard™ installations. See wiring diagrams to determine when to remove JP301 for monitored sensor installations.
16	Terminal Block Connector TB7	Includes RS485 and AUX DC supply. Do not populate TB7 until further notice.
17	Terminal Block Connector TB5	Side screen sensor, door position switch.
18	Terminal Block Connector TB4	Connection point for INSIDE / OUTSIDE sensor and push plate.
19	Terminal Block Connector TB3	Connection point for Stanguard™, safety sensor and breakout switch. Using jumper wires across TB3 terminals 1 to 5 and 2 to 6, internal 24 VDC supplies power to multiple external sensors.


Attachment 2
iQ System Wiring Diagram
(Sheet 1 of 10)



Attachment 2
iQ System Wiring Diagram
(Sheet 2 of 10)




Attachment 2
iQ System Wiring Diagram
(Sheet 3 of 10)




Attachment 2 iQ System Wiring Diagram (Sheet 4 of 10)

SEE NEXT PAGE



Attachment 2 iQ System Wiring Diagram (Sheet 4 of 10, continued)


SEE PREVIOUS PAGE



Copyright 2018, Stanley Access Technologies, LLC. All rights reserved. Reproduction in whole or in part without the express written permission of Stanley is prohibited.

Attachment 2
iQ System Wiring Diagram
(Sheet 5 of 10)

PHOTO BEAM PRO HOLDING BEAM




On the iQ: Set INDEX 20 to VALUE 01 (Monitored Beam).

DUAL HOLDING BEAM WIRING		
TB6	COLOR	
1	YL	OUTPUT UPPER RECEIVER
2	BK	(-) UPPER RECEIVER
3	YL	OUTPUT LOWER RECEIVER
4	BK	(-) LOWER RECEIVER
5	OR	TRANSMITTER CONTROL LOWER AND UPPER
6	--	NO CONNECTION
7	--	NO CONNECTION
8	RD	(+) ALL RECEIVERS AND TRANSMITTERS
9	BK	(-) LOWER AND UPPER TRANSMITTERS, JUMPER TO TB6-10
10	BK	JUMPER FROM TB6-9

Attachment 2
iQ System Wiring Diagram
(Sheet 6 of 10))


OPTEX OS-12C T
DOORWAY HOLDING BEAM



Program the OS-12 CT set to "D" - Active High / N.C.
 On the iQ: Set INDEX 20 to VALUE 01 (Monitored Beam).

Attachment 2
iQ System Wiring Diagram
(Sheet 7 of 10)


PHOTO BEAM PRO BREAKOUT BEAM



TB3	COLOR	PHOTO BEAM PRO BREAKOUT BEAM
1	RD	JUMPER FROM TB3-5
2	BK	JUMPER FROM TB3-6
3	--	NO CONNECTION
4	--	NO CONNECTION
5	RD	JUMPER FROM TB3-1, (+) RECEIVER AND TRANSMITTER
6	BK	JUMPER FROM TB3-2, (-) RECEIVER AND TRANSMITTER
7	--	NO CONNECTION
8	--	NO CONNECTION
9	YL	OUTPUT RECEIVER
10	--	NO CONNECTION

Attachment 2
iQ System Wiring Diagram
(Sheet 8 of 10)

X ZONE T & ST
2 MONITORED SENSORS



X Zone ST

Key DIP Switch settings: 10 and 11 **DOWN**; 12, 14 and 15 **UP**.

iQ

Remove JP301.

Set index 19 to Value = 00 (Sensor Monitoring with Threshold Control).

X Zone T

Key DIP Switch settings: 11 and 12 **DOWN**; 13 and 15 **UP**.


iQ

Remove JP301.

Set index 19 to Value = 03 (Monitored 2 Sensors).

Attachment 2
iQ System Wiring Diagram
(Sheet 9 of 10)

X ZONE T & ST
4 MONITORED SENSORS



X Zone ST

Key DIP Switch settings: 10 and 11 **DOWN**; 12, 14 and 15 **UP**.

iQ

Remove JP301.

Set index 19 to Value = 01 (Monitored 4 Sensors - Threshold Zone Control).

X Zone T

Key DIP Switch settings: 11 and 12 **DOWN**; 13 **UP** and 15 **UP**.


iQ

Remove JP301.

Set index 19 to Value = 05 (Monitored 4 Sensors).

Attachment 2
iQ System Wiring Diagram
(Sheet 10 of 10)

HOTRON HR100-ST



HR100 ST

Recommended DIP Switch settings:

DIP Switch X: (2, 3, and 4 = **UP**) (1 = **DOWN**).

DIP Switch Y: (1, 2, 3 and 4 = **UP**)

DIP Switch Z: (1, 2, 3 and 4 = **UP**) (5 and 6 = **DOWN**).


{**UP** = OFF} {**DOWN** = ON}

iQ Settings

Remove JP301.

Set index 19 to Value = 03 (Monitored 2 Sensors).

Attachment 3
iQ Terminal Block Connections -- TB1 through TB7
(Sheet 1 of 1)



NOTES
1. REMOVE JUMPERS ON TB3 IF EXTERNAL POWER SUPPLY IS USED.
JUMPERS ON TB3 CONNECT INTERNAL POWER SUPPLY (INT)
TO THE EXTERNAL POWER SUPPLY BUS (EXT).

Attachment 4 ANSI/BHMA and UL Compliance Requirements for Sliding Doors (Sheet 1 of 3)

Final adjustment and proper operation of the door system must be and shall be performed in the field.

NOTE: These instructions are for informational purposes and do not substitute for review against the current revision of the referenced standards. Where a requirement exists in multiple standards, such as the ANSI/BHMA standard and the UL standard, the more restrictive condition applies. Other local codes and fire codes likely exist, and must also be followed.

ANSI/BHMA A156.10 Sliding Door Systems

Sliding door systems must be installed and adjusted for compliance with the current version of ANSI/BHMA A156.10, "American National Standard for Power Operated Pedestrian Doors".

Critical aspects of the installation for compliance with ANSI/BHMA A156.10 include:

- Control mat size, layout, molding height, active areas and sensitivity.
- Sensor pattern size, sensitivity, and function.
- Knowing Act guidelines and secondary activating zone.
- Entrapment protection rules including door speeds, forces, and time delays.
- Signage. (Decals and application instructions are provided with the door system.)

UL 325 Compliance

All power operated door systems must be installed in compliance with the current edition of UL 325, "Standard for Safety for Door, Drapery, Gate, Louver, and Window Operators and Systems".

Wiring

1. To reduce the risk of electric shock proper and reliable grounding is mandatory. See **Main Power Wiring** instructions and **Wiring Diagrams** in this guide for grounding techniques.
2. Permanent wiring is to be employed as required by the National Electrical Code and/or local codes.
3. Connection of external devices is shown in the wiring diagrams and terminal block layouts elsewhere in this guide. Refer to these figures for proper wiring of external devices to ensure compliance with UL 325.

Knowing Act

Doors activated by a manual switch (Knowing Act switch in ANSI/BHMA terms) must have the switch installed in a location from which operation of the door can be observed by the person operating the switch and not located in a position where the user would be in the path of the moving door.

Attachment 4
ANSI/BHMA and UL Compliance Requirements for Sliding Doors
(Sheet 2 of 3)

To ensure that a sliding door operates in accordance with UL 325 entrapment protection criteria the following must be established:

- Manual opening force (sliding doors without breakout) or breakout force with power on or off must be less than 50 lbf (222.4 N).
- Closing force must be less than 30 lbf (133.4 N).
- A closing sliding door must not develop kinetic energy in excess of 2.5 ft-lbf (3.39 J). This is achieved by proper setting of the closing speed. See section entitled "Closing Speed".
- Maximum recommended door weight:
 - Dura-Glide 5000 Series = 150 lbs (70 kg) per panel.
 - Dura-Glide/Dura-Guard/Dura-Storm and similar 2000/3000 Series = 220 lbs (100 kg) per panel.
 - IS10000/Double Diamond and similar Industrial Series = 300 lbs (90 kg) per panel

Closing Speed

Closing speed is measured over a travel distance of 2 or 3 feet. On smaller bi-part doors there may only be 2 feet of movement before the door system enters close-check (latch check). The time measurement should start once the door has achieved closing speed, usually 6 inches from full open. Mark this point on the floor with tape or other object. Measure from this point 2 or 3 feet toward the closed position and mark the next point. Use a stopwatch to measure the time it takes for the sliding panel to travel this distance during normal closing cycles. Make sure the door system is not braking or entering close-check during the measurement. Repeat the measurement 3 times and use the average value. The allowed time for a sliding panel to cover this distance during the closing cycle is given in the table below.

Door Weight (pounds)	Closing Time (seconds) 2 foot measurement	Closing Time (seconds) 3 foot measurement
160 or less	2.0	3.0
161 to 180	2.1	3.2
181 to 200	2.2	3.3
201 to 220	2.3	3.5
221 to 240	2.4	3.7
241 to 260	2.5	3.8
261 to 280	2.6	4.0
281 to 300	2.7	4.1

Attachment 4
ANSI/BHMA and IBC Compliance Requirements for
Low Energy Power Operated Sliding Doors
(Sheet 3 of 3)

To ensure that a **Low Energy** Power Operated Sliding Door operates in accordance with ANSI/BHMA and the the IBC-2018, the following must be established:

- Activation of the door must be by a **Knowing Act**.
- The Opening Time (speed) of the Door(s) shall be adjusted so that the door(s) open at a speed of **12 inches per second maximum**, from fully closed to fully open.
- When powered open, the door shall remain at the fully open position for not less than 5 seconds before starting the closing cycle.
- The Closing Time (speed) of Door(s) shall be adjusted so that the door(s) close at a speed of **6 inches per second maximum** per leaf, from fully open to latch check.
- Latch check shall occur at no less than 2 inches from fully closed.
- The **force** required to prevent a stopped door from opening or closing shall not exceed 15 lbf (67 N).
- **The required Signage must be present.**

NOTE: In special applications where safety sensors or secondary activation sensors are used on a low energy door, refer to ANSI/BHMA A156.10 for guidance on sensor performance criteria for the type of sensor selected.

Attachment 5
Handheld Device Troubleshooting Aid (Sheet 1 of 1)

Terminal and Pin	Description	State
TB1-8	Solenoid Lock Output	Dark = Unlocked
	w/o PCB, fail secure	Dark = Unlocked
	w/o PCB, fail safe	Dark = Locked

Rotary Function Switch States for TB2						
	Hold Open	Closed Locked	Automatic	One Way	Reduced	Reduced One Way
TB2-1						
TB2-3						
TB2-5					Don't Care	Don't Care
TB2-7						

Rocker Function Switch States for TB2						
	Hold Open	Closed Locked	Automatic	One Way	Reduced	Reduced One Way
TB2-1						
TB2-3						
TB2-5	Don't Care	Don't Care				
TB2-7	Don't Care	Don't Care				

Terminal and Pin	Description	State
TB3-4	Stanguard™ Input/Output	Dark = triggered or detecting
TB3-8 & TB4-8	Holding Beam Input and Outside Sensor (connected internally)	Dark = detecting
TB3-9	Breakout Input	Dark = no breakout
TB4-4 & TB4-9	Inside Sensor Input and Push Plate Input (connected internally)	Dark = detecting
TB4-8 & TB3-8	Inside Presence Sensor Input and Holding Beam Input (connected internally)	Dark = detecting
TB4-9 & TB4-4	Push Plate Input and Inside Sensor Input (connected internally)	Dark = detecting
TB5-3	Side Screen Sensor Input	Dark = detecting
TB5-7	Closed-Door Position Switch Input	Dark = closed
TB5-10	Spare	
TB6-1	Photo Beam Pro Upper Holding Beam	Dark = unobstructed White = detecting
TB6-3	Photo Beam Pro Lower Holding Beam	Dark = unobstructed White = detecting
TB6-5	Photo Beam Pro Test Output	Dark = testing
TB6-7	Sensor Test Output	Dark = normal operation

Attachment 6
Handheld Device Troubleshooting Screen Descriptions
(Sheet 1 of 2)

TB1-8 = Solenoid Lock Output
TB2-1 = Hold Open Function Switch Input
TB2-3 = Automatic Function Switch Input
TB2-5 = Enter/One Way Function Switch Input
TB2-7 = Reduced Open Function Switch Input
TB2-9 = Reduced Open/One Way Function Switch Input
TB3-4 = Stanguard™ Input/Output or
Monitored Inside Sensor Test Output
TB3-8 = Holding Beam Input or
Monitored Inside Sensor Presence Input
TB3-9 = Breakout Input
TB4-4 = Inside Sensor Input
TB4-8 = Outside Sensor Input
TB4-9 = Push Plate Input
TB5-3 = Side Screen Sensor Input
TB5-7 = Closed-Door Position Switch Input
TB6-1 = Photo Beam Pro Upper Holding Beam
TB6-3 = Photo Beam Pro Lower Holding Beam
TB6-5 = Photo Beam Pro Test Output
TB6-7 = Monitored Outside Sensor Test Output

Attachment 6
Handheld Device Troubleshooting Screen Descriptions
(Sheet 2 of 2)

Output Control Mode

The Output Control allows the user to run the iQ Control Box in a debug mode. The Output Control is located on the iQ Controller Troubleshooting Screen.

The iQ displays “**db**” to indicate that the control box is in the debug state.

The function switch must be selected to Closed/Locked or Hold Open in order to use the Output Control Mode.

Output Control Mode can also be used when the iQ control box is in “**AO**”.

1. Select **TROUBLESHOOTING** on the Main selection menu.
2. Press and hold the output that is to be controlled.

TOGGLE/PULSE should appear. Tap on **TOGGLE** or **PULSE**.

The Output Control Mode is enabled when displayed at the bottom of the screen and the Red “**LED**” indicator is **ON**.

3. Press **TOGGLE** or **PULSE**. In 1 second, the output will change state or pulse.

The inputs on troubleshooting are live and indicate their present state.

For **TOGGLE** selections, the border of that output rectangle is set to **BLUE** until **OUTPUT CONTROL MODE** is **OFF**. The output is not in the normal state and the output is in the control of the user.

The iQ will time out after 5 minutes when there is no activity from the iQ Controller Toolbox. The Output Control Mode can be turned **OFF** by changing the function switch to a setting other than Closed/Locked or Hold Open. The Output Control Mode is **OFF** when the text and Red “**LED**” indicator are hidden from the Troubleshooting screen.

Attachment 7
iQ Troubleshooting Aid
(Sheet 1 of 1)

Symptom	Remedy
Door does not close and/or Status code displays h0/E2 NOTE: E2 indicates door held open by any sensor input other than Hold Open Switch on TB-2.	Use best practices to troubleshoot using handheld device and provided wiring diagrams. Check hold beam type (index 20). Monitored beams should be set to "Monitored Beam" and non-monitored beams should be set to "Non-monitored Beam." Reference latest Photo Beam Pro Troubleshooting Tech Tip.
Handheld will not update firmware	Controller is not displaying 00. Re-FIS the door.
Door hits Open Stop/full open bumper	Increase the Open Check Length (Index 3).
Door motion is not the same as the MC521/ MC521PRO for the same settings	Parameters value for the iQ are not the same as MC521/ MC521PRO. Refer to Table 3.
Status code displays E3	Check mechanical issues, components. Re-do first installation sequence (FIS).
Status code displays E4	Verify sensor wiring and safety logic setting.
Status code displays F0-F1, F6-F7	Verify sensor wiring and safety logic setting.
Status code displays F2-F3	Monitored beam Failure. Verify proper wiring and "holding beam type"(index 20 = appropriate setting, Monitored Beam or Non-Monitored Beam. Reference latest Photo Beam Pro Troubleshooting Tech Tip.
Door moves slowly on one cycle. Status code displays 33 or 34 or 36 momentarily (3 seconds).	Note it. No action required.
Door moves slowly on several cycles. Status code displays 33 or 34 or 36 on slow cycles.	1. Reset Power. 2. If code does not clear, Call Tech Support.
Door tuning issues	Refer to parameter descriptions for useful adjustments.

Attachment 8
Fine Tuning Slide Doors
(Sheet 1 of 2)

Tuning the Stanley Automatic Door

Match your actual door to one from the list of doors described in the attachment. Start by installing these settings. Use the guide below to make adjustments to these settings.

If the door:	
OPENS TOO SLOWLY	Increase Open Speed . Maximum setting is 99 with keypad or 125 with handheld.
If it is too slow	Increase Open Torque
If it is too slow	Increase Open Acceleration
NOTES: Max Values go to 125 via handheld. Open Torque is also used to set the door open force.	
HITS THE OPEN STOP	Increase Open Stop to 8 and Open Check Length to 45 Increase Open Brake until there is good braking. Increase or decrease until there is good motion entering and in Open Check .
When the door braking and motion are under control, reduce the Open Check length as desired.	
CLOSES TOO SLOWLY	Increase Close Speed to 16
If it is too slow	Increase Close Torque
If it is too slow	Increase Close Acceleration
NOTE: Close Torque is also used to set the door closing force. Close Speed and Close Force cannot exceed the value specified by ANSI/BHMA 156.10.	

Attachment 8
Fine Tuning Slide Doors
(Sheet 2 of 2)

Tuning the Stanley Automatic Door (Continued).

Match your actual door to one from the list of doors described in the attachment. Start by installing these settings. Use the guide below to make adjustments to these settings.

If the door:	
HITS THE CLOSE STOP too hard	Set Close Check Length to 50. Set Close Press to 1 and test. Increase the Close Brake setting until there is good braking. Increase or decrease Close Check until there is smooth motion entering and in Close Check .
STALLS during opening without any mechanical reason...	Increase Obstruction Time from .5 seconds to 1.0 seconds
Continues to stall and it seems to happen at the transition from Open Brake to Open Check	Make small increases to Open Brake .
STALLS during closing without any obvious reason...	Increase Obstruction Time
Continues to stall and it seems to happen at the transition to Close Check	Increase Close Check one count at a time
SPEEDS UP during Close Check	Close Check Speed is set too high. Reduce Close Check one count at a time until door motion is suitable.

Stanley Access Technologies
65 Scott Swamp Road
Farmington, CT 06032

Document # 204144 REV A • www.stanleyaccess.com • 1.800.7.ACCESS