

377/377 FC/378/378 FC

Clamp Meter

Calibration Manual

LIMITED WARRANTY AND LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation
6920 Seaway Blvd.
Everett, WA 98203
U.S.A.

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands

Table of Contents

Title	Page
Introduction	1
Contact Fluke	1
Safety Information	1
Specifications	1
Performance Tests	1
Performance Test Procedures	2
AC Voltage	2
DC Voltage	3
Resistance/Capacitance	3
DC Current (Jaw with Calibrator, 52120A, and Coil)	4
AC Current (Jaw with Calibrator, 52120A, and Coil)	6
AC Current (iFlex Current with iFlex Current Probe with Calibrator, 52120A, and Coil)	7
AC Current (iFlex Current with Calibrator AC Voltage Simulation)	7
Performance Tests and Readout Limits	9
Maintenance	12
Maintenance Mode	12
How to Clean the Case	13
Battery Replacement	13
User Replaceable Parts	15

Introduction

Warning

Read *Safety Information* before you use the Product.

This manual explains the Performance Tests for the 377/377 FC/378/378 FC Clamp Meter (the Product, the Jaw, or the device under test (DUT)). See the *377/377 FC/378/378 FC Users Manual* for usage information.

Contact Fluke

Fluke Corporation operates worldwide. For local contact information, go to our website: www.fluke.com.

To register your product, view, print, or download the latest manual or manual supplement, go to our website.

+1-425-446-5500

fluke-info@fluke.com

Safety Information

General Safety Information is in the printed Safety Information document that ships with the Product and at www.fluke.com. More specific safety information is listed where applicable.

A **Warning** identifies conditions and procedures that are dangerous to the user. A **Caution** identifies conditions and procedures that can cause damage to the Product or the equipment under test.

Specifications

Complete specifications are at www.fluke.com. See the *377/377 FC / 378/378 FC Product Specifications*.

Performance Tests

Warning

To prevent possible electrical shock, fire, or personal injury, do not perform the performance test procedures unless the Product is fully assembled.

Fluke recommends a 1-year cycle for the Performance Tests. If the Product fails any test, return the Product to a Fluke Service Center or Authorized Service Partner. See [Contact Fluke](#) for more information.

[Table 1](#) lists the standard equipment for the Performance Tests. [Table 2](#) lists performance tests and readout limits to verify the complete operation of the Product and to check the accuracy of each function against the Product specifications.

Table 1. Standard Equipment

Equipment	Required Characteristics	Recommended Model
Calibrator (the Calibrator)	4.5-digit resolution	Fluke 55xxA or similar model
Transconductance Amplifier	100 A	Fluke 52120A
Wired Coil (the Coil)	25-turn	52120A/COIL3KA
Wired Coil (the Coil)	50-turn	52120A/COIL6KA
Test Leads	NA	PN 2070140

Performance Test Procedures

Before you start a performance test procedure:

- Read the documentation for all the test equipment used in a procedure.
- Warm up and stabilize all test equipment in an environment of 23 °C ±5 °C.

All procedures refer to the performance tests and the readout limits in [Table 2](#).

AC Voltage

To verify ac voltage:

1. Connect the test leads to the V Ω and COM input terminals on the bottom of the device under test (DUT).
2. Connect the other end of the test leads to the NORMAL output HI and LO terminals on the Calibrator.
3. Set the DUT to $\tilde{V}$.
4. On the Calibrator:
 - a. Set the desired voltage and frequency at the NORMAL output terminals.

Caution

To prevent damage to the DUT, verify the applied voltage to the DUT does not exceed the rating of the DUT insulation and the interconnection wiring.

- b. Push  to activate the Calibrator output and apply the voltage to the DUT.
5. On the DUT, verify the measurement on the display is within the readout limits for the test.

DC Voltage

To verify dc voltage:

1. Connect the test leads to the V Ω and COM input terminals on the bottom of the DUT.
2. Connect the other end of the test leads to the NORMAL output HI and LO terminals on the Calibrator.
3. Set the DUT to $\text{mV} \overline{\text{V}}$.
4. On the Calibrator:
 - a. Set the desired voltage at the NORMAL output terminals.

Caution

To prevent damage to the DUT, verify the applied voltage to the DUT does not exceed the rating of the DUT insulation and the interconnection wiring.

- b. Push  to activate the calibrator output and apply the voltage to the DUT.
5. On the DUT, verify the measurement on the display is within the readout limits for the test.
6. To verify mV voltage, push  on the DUT to go to mV mode.
7. On the Calibrator:
 - a. Set the desired voltage at the NORMAL output terminals.
 - b. Push  to activate the calibrator output and apply the voltage to the DUT.
8. On the DUT, verify the measurement on the display is within the readout limits for the test.

Resistance/Capacitance

To verify resistance and capacitance:

1. Connect the test leads to the V Ω and COM input terminals on the bottom of the DUT.
2. Connect the other end of the test leads to the NORMAL output HI and LO terminals on the Calibrator.
3. Set the DUT to $\overline{\Omega}$ to verify resistance.
4. Set the Calibrator to the desired resistance output.
5. On the DUT, verify the measurement on the display is within the readout limits for the test.
6. To verify capacitance, push  on the DUT to go to capacitance mode.
7. Set the Calibrator to the desired capacitance output.
8. On the DUT, verify the measurement on the display is within the readout limits for this test.

DC Current (Jaw with Calibrator, 52120A, and Coil)

To verify dc current measurement with the Jaw:

1. Connect the Calibrator.
 - For test points <20 A, use a single-wire short between the 20 A and AUX LO jacks on the Calibrator.
 - For test points from 20 A to 100 A:
 - Use a single-wire short between the HIGH CURRENT OUTPUT HI and LO jacks of the 52120A.
 - Connect the Calibrator's NORMAL HI and LO terminals to the INPUT HI and LO terminals of the 52120A.
 - For test points >100 A:
 - Connect the Coil to the 52120A.
 - Connect the Calibrator's NORMAL HI and LO terminals to the INPUT HI and LO terminals of the 52120A.
2. Set the DUT to $\frac{\text{ZERO}}{\text{A}}$.
3. Place the DUT on a flat surface away from any metal.
4. On the DUT, push  to zero the dc current function.
5. Place the DUT around the wire used to create the short so that the wire touches the yellow part at the tip of the closed jaw of the DUT. See [Figure 1](#).

Or,

Place the DUT around the center conductor of the Coil so that the yellow part at the tip of the DUT touches the center wires of the Coil and the jaw of the DUT remains completely closed. See [Figure 2](#).

Calibration accuracy to specifications is guaranteed only with proper clamp alignment.

Figure 1. Wire Placement with DUT





Figure 2. DUT Placement with Coil



6. Set the Calibrator to the desired dc current output.
7. Put the 52120A in standby mode.
8. On the Calibrator, push .
9. On the 52120A, push  to activate the output and apply the current to the DUT.
10. On the DUT, verify the measurement on the display is within the readout limits for the test.

AC Current (Jaw with Calibrator, 52120A, and Coil)

To verify ac current measurement with the Jaw:

1. Connect the Calibrator.
 - For test points <20 A, use a single-wire short between the 20 A and AUX LO jacks on the Calibrator.
 - For test points from 20 A to 120 A:
 - Use a single-wire short between the HIGH CURRENT OUTPUT HI and LO jacks of the 52120A.
 - Connect the Calibrator's NORMAL HI and LO terminals to the INPUT HI and LO terminals of the 52120A.
 - For test points >120 A:
 - Connect the Coil to the 52120A.
 - Connect the Calibrator's NORMAL HI and LO terminals to the INPUT HI and LO terminals of the 52120A.
 - On the 52120A, set LCOMP to ON.
 - Set the DUT to  Hz.
2. Place the DUT around the wire used to create the short so that the wire touches the yellow part at the tip of the closed jaw of the DUT. See [Figure 1](#).

Or,

Place the DUT around the center conductor of the Coil so that the yellow part at the tip of the DUT touches the center wires of the Coil and the jaw of the DUT remains completely closed. See [Figure 2](#).

Calibration accuracy to specifications is guaranteed only with proper clamp alignment.
3. Set the Calibrator to the desired ac current output.
4. Put the 52120A in standby mode.
5. On the Calibrator, push .
6. On the 52120A, push  to activate the output and apply the current to the DUT.
7. On the DUT, verify the measurement on the display is within the readout limits for the test.

AC Current (iFlex Current with iFlex Current Probe with Calibrator, 52120A, and Coil)

The Product measures both ac and dc voltage. The iFlex current probe (the Probe) only measures ac voltage. For ac current performance tests from 120 A to 2500 A, use the Product with the Probe, the Calibrator, 52120A, and the Coil. The 52120A converts low voltage input from the Calibrator into an output current up to 120 A, then sources the current into the Coil to produce up to 2500 Amp-turns ac.

Caution

Read all safety information before you use the 377/378, 52120A, and the Coil. High currents are used during this test.

To verify iFlex ac current with the Probe:

1. Connect one end of the test leads to the NORMAL output HI and LO terminals on the Calibrator.
2. Connect the other end of the test leads to the INPUT HI and LO terminals on the 52120A.
3. Connect the HI and LO terminals of the Coil to the HIGH CURRENT OUTPUT HI and LO terminals on the 52120A.
4. On the 52120A:
 - a. Select  on the input selection.
 - b. Set LCOMP to ON.
 - c. Set the OUTPUT TERMINALS to HIGH and the OUTPUT RANGE to 20 A or 120 A as noted in [Table 2](#) for each test point for iFlex Current Probe (with 52120A and Coil).
5. Connect the Probe to the DUT.
6. Center the Probe on the Coil equal distance from the conductor and the cable within the Coil.
7. Set the Calibrator to the desired voltage and frequency output.
8. On the DUT, verify the measurement on the display is within the readout limits for the test.

AC Current (iFlex Current with Calibrator AC Voltage Simulation)


Note

If the Probe is not available with the DUT for calibration, use the Calibrator to source voltage to simulate ac current up to 2500 A.

To verify ac current measurement without the Probe, use the ac voltage simulation from the Calibrator:

1. Connect the NORMAL output HI terminal of the Calibrator to the iFlex 2 mm jack flexible probe input terminal ❶ on the DUT. See [Figure 3](#).
2. Connect the Calibrator NORMAL output LO terminal to the black COM jack ❷ on the DUT. See [Figure 3](#).

Figure 3. iFlex Current Probe Connections



3. Set the DUT to Hz iFlex A .
4. Set the Calibrator to the desired voltage and frequency output.
5. On the DUT, verify the measurement on the display is within the readout limits for the test.

Performance Tests and Readout Limits

Table 2 lists performance tests and readout limits to verify the complete operation of the Product and to check the accuracy of each function against the Product specifications.

Table 2. Performance Test and Readout Limits

Test (Switch Position)	Calibrator Output	52120A Range	Readout Limit	
			Low	High
 AC Volts	30 V @ 20 Hz	NA	29.2 V	30.8 V
	30 V @ 55 Hz			
	30 V @ 500 Hz			
	570 V @ 45 Hz	NA	563.8 V	576.2 V
	570 V @ 55 Hz			
	570 V @ 500 Hz			
	1000 V @ 45 Hz	NA	985 V	1015 V
	1000 V @ 55 Hz			
	1000 V @ 500 Hz			
 DC Volts	-570 V	NA	-576.5 V	-563.3 V
	-300 V		-304.0 V	-296.0 V
	-50 V		-51.5 V	-48.5 V
	-2 V		-3.0 V	1.0 V
	0 V		-1.0 V	1.0 V
	2 V		1.0 V	3.0 V
	50 V		48.5 V	51.5 V
	300 V		296.0 V	304.0 V
	570 V		563.3 V	576.7 V
	-1000 V		-1020 V	-980 V
	1000 V		980 V	1020 V
	0 mV		-0.5 mV	0.5 mV
	500 mV		494.5 mV	505.5 mV
	-500 mV		-505.5 mV	-494.5 mV
 Resistance	0 Ω	NA	-0.5 Ω	0.5 Ω
	10 Ω		9.4 Ω	10.6 Ω
	570 Ω		563.8 Ω	576.2 Ω
	5700 Ω		5638 Ω	5762 Ω
	57 kΩ		56.38 kΩ	57.62 kΩ
 Capacitance	10 μF	NA	9.5 μF	10.5 μF
	90 μF		88.7 μF	91.3 μF
	950 μF		937 μF	964 μF

Table 2. Performance Test and Readout Limits (cont.)

Test (Switch Position)	Calibrator Output	52120A Range	Readout Limit	
			Low	High
 DC Amps: Jaw (with Calibrator short)	10 A	NA	9.3 A	10.7 A
	-10 A	NA	-10.7 A	-9.3 A
 DC Amps: Jaw (with 52120A and 25-turn coil)	using 52120A/COIL3KA			
	-975 A (-0.39 V dc)	120 A	-995.0 A	-955.0 A
	-500 A (-2.00 V dc)	20 A	-510.5 A	-489.5 A
	975 A (0.39 V dc)	120 A	955.0 A	995.0 A
	500 A (2.00 V dc)	20 A	489.5 A	510.5 A
 AC Amps: Jaw (with Calibrator short)^[X]	10 A @ 45 Hz	NA	9.3 A	10.7 A
	10 A @ 55 Hz			
	10 A @ 65 Hz			
 AC Amps: Jaw (with 52120A and 25-turn coil)	using 52120A/COIL3KA			
	450 A @ 45 Hz (1.8 V @ 45 Hz)	20 A	440.5 A	459.5 A
	450 A @ 55 Hz (1.8 V @ 55 Hz)			
	450 A @ 65 Hz (1.8 V @ 65 Hz)			
	975 A @ 45 Hz (0.39 V @ 45 Hz)	120 A	955.0 A	995.0 A
	975 A @ 55 Hz (0.39 V @ 55 Hz)			
	975 A @ 65 Hz (0.39 V @ 65 Hz)			
 AC Current Frequency	45 Hz @ 95 A	20 A	44.275 Hz	45.725 Hz
	66 Hz @ 450 A	20 A	65.17 Hz	66.83 Hz
	440 Hz @ 150 A	120 A	437.3 Hz	442.7 Hz
 iFlex Current Probe (with ac voltage simulation)	1.05 mV @ 35 Hz	NA	48.0 A	52.0 A
	3 mV @ 100 Hz			
	15 mV @ 500 Hz			
	11.4 mV @ 20 Hz		921.0 A	979.0 A
	57 mV @ 100 Hz			
	285 mV @ 500 Hz			
	29.4 mV @ 20 Hz		2372 A	2528 A
	147 mV @ 100 Hz			
	735 mV @ 250 Hz			
iFlex AC Current Frequency with simulation	20 Hz @ 1250 A ^[2]	NA	19.4 Hz	20.6 Hz
	100 Hz @ 1250 A ^[2]		99.0 Hz	101.0 Hz
	500 Hz @ 1250 A ^[2]		497.0 Hz	503.0 Hz

Table 2. Performance Test and Readout Limits (cont.)

Test (Switch Position)	Calibrator Output		52120A Range	Readout Limit	
				Low	High
 iFlex Current Probe (with 52120A and Coil)^[3]	using 52120A/COIL3KA	using 52120A/COIL6KA			
	0.6 V @ 10 Hz ^[1]	0.30 V @ 10 Hz ^[1]	20 A	145.0 A	155.0 A
	0.6 V @ 55 Hz ^[1]	0.30 V @ 55 Hz ^[1]			
	0.6 V @ 500 Hz ^[1]	0.30 V @ 500 Hz ^[1]			
	0.38 V @ 10 Hz ^[2]	0.19 V @ 10 Hz ^[2]	120 A	921.0 A	979.0 A
	0.38 V @ 55 Hz ^[2]	0.19 V @ 55 Hz ^[2]			
	0.38 V @ 500 Hz ^[2]	0.19 V @ 500 Hz ^[2]			
	0.96 V @ 10 Hz ^[2]	0.48 V @ 10 Hz ^[2]		2323.0 A	2477.0 A
	0.96 V @ 55 Hz ^[2]	0.48 V @ 55 Hz ^[2]			
	0.96 V @ 250 Hz ^[2]	0.48 V @ 250 Hz ^[2]			
[1] 52120A: Use HIGH CURRENT OUTPUT terminals. Under OUTPUT on the front panel, select TERMINALS HIGH and RANGE 20A. [2] 52120A: Use HIGH CURRENT OUTPUT terminals. Under OUTPUT on the front panel, select TERMINALS HIGH and RANGE 120A. [3] 52120A: Select L COMP ON.					

Maintenance

If the Product is used appropriately it does not require special maintenance or repair. In case of repair, go to www.fluke.com for contact information of Fluke Service Centers worldwide.

Warning

To prevent possible electrical shock, fire, or personal injury:

- **Remove the input signals before you clean the Product.**
- **Repair the Product before use if the battery leaks. Battery leakage may create a shock hazard or damage the Product.**
- **Use only specified replacement parts.**
- **Have an approved technician repair the Product.**
- **Remove the batteries if the Product is not used for an extended period of time, or if stored in temperatures above 50 °C. If the batteries are not removed, battery leakage may result.**

Maintenance Mode

In Maintenance Mode you can check:

- LCD segments
- Firmware version
- Battery status annunciators
- Fluke Connect LED
- Backlight

To enter Maintenance Mode:

1. Turn off the Clamp.
2. Push and hold  as you turn the control knob to .
3. The Clamp goes into the option mode.
4. Push  until $n \ R \ n \ Q \ d$ shows on the display.
5. Push .

All LCD segments turn on and the backlight turns off.

6. Release .

All LCD segments continue to show on the display.

7. Press **HOLD** again to show the firmware version.
8. Continue to press **HOLD** to cycle through:
 - Empty battery annunciator
 - 25 % battery annunciator
 - 50 % battery annunciator
 - 75 % battery annunciator
 - Blue LED + live battery annunciator (for FC model only, step is skipped for non-FC model)
 - White backlight + live battery annunciator
 - Green backlight + live battery annunciator
9. Press **HOLD** again to show $\frac{L}{RL}$ on the display.
10. Press **HOLD** again to loop back to show all LCD segments (see step 6).

To exit maintenance mode, turn off the Meter.

How to Clean the Case

Wipe the case with a damp cloth and mild detergent.

Caution

Do not use abrasives, isopropyl alcohol, or solvents to clean the case or lens/window.

Battery Replacement

Warning

To prevent personal injury and for safe operation of the Product:

- **The battery door must be closed and locked before you operate the Product.**
- **Remove all probes, test leads, and accessories before the battery door is opened.**
- **Replace the batteries when the low battery indicator shows to prevent incorrect measurements.**
- **When batteries are changed, ensure that the calibration seal in the battery compartment is not damaged. If damaged, the Product may not be safe to use. Return the Product to Fluke for replacement of the seal.**


⚠ Caution

To prevent damage to the battery:

- **Repair the Product before use if the battery leaks.**
- **Do not expose battery to heat sources or high-temperature environments such as an unattended vehicle in the sun.**
- **Always operate in the specified temperature range.**
- **Do not incinerate the Product and/or battery.**

The Product ships with the batteries installed. To replace batteries, see Figure [Figure 4](#).

Figure 4. Batteries



User Replaceable Parts

To maintain optimum performance, an authorized Fluke Calibration service center should service the Product every two years.

Contact your equipment distributor or authorized Fluke Calibration Service Center for any equipment performance failure or to schedule regular maintenance service. See [Contact Fluke](#) for more information.

Table [Table 3](#) lists the replacement parts of the Product.

Table 3. Replacement Parts

Item/Description	Fluke Part or Model Number
Battery, AA 1.5 V (x2)	376756
Battery Door	5105034
Test Lead Set	TL75
Test Lead Set	TL175
Test Probe	TP175
Alligator Clip	AC285
Flexible Current Probe i2500-10	3676410
Flexible Current Probe i2500-18	3798105
Magnet Strap	669952
Strap (9-inch)	669960
Carry Case	5211830

