

RoboRIO User Accounts and SSH

Note: This document contains advanced topics not required for typical FRC programming

The roboRIO image contains a number of accounts, this article will highlight the two used for FRC and provide some detail about their purpose. It will also describe how to connect to the roboRIO over SSH.

RoboRIO User Accounts

The roboRIO image contains a number of user accounts, but there are two of primary interest for FRC.

Admin

The "admin" account has root access to the system and can be used to manipulate OS files or settings. Teams should take caution when using this account as it allows for the modification of settings and files that may corrupt the operating system of the roboRIO. The credentials for this account are:

Username: admin

Password:

Note: The password is intentionally blank.

Lvuser

The "lvuser" account is the account used to run user code for all three languages. The credentials for this account should not be changed. Teams may wish to use this account (via ssh or sftp) when working with the roboRIO to ensure that any files or settings changes are being made on the same account as their code will run under.


RoboRIO User Accounts and SSH

SSH

SSH (Secure SHell) is a protocol used for secure data communication. When broadly referred to regarding a Linux system (such as the one running on the roboRIO) it generally refers to accessing the command line console using the SSH protocol. This can be used to execute commands on the remote system. A free client which can be used for SSH is PuTTY:

<http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>

Open Putty




Open Putty (clicking OK at any security prompt). Then set the following settings:

1. Host Name: roboRIO-TEAM.local (where TEAM is your team number)
2. Connection Type: SSH

Other settings can be left at defaults. Click Open to open the connection. If you see a prompt about SSH keys, click OK.

RoboRIO User Accounts and SSH

Log in



```
roboRIO-40.local - PuTTY
login as: admin
NI Linux Real-Time (run mode)

Log in with your NI-Auth credentials.

Using keyboard-interactive authentication.
Password:
admin@roboRIO-40:~#
```

When you see the prompt, enter the desired username (see above for description) then press enter. At the password prompt press enter (password for both accounts is blank).