

480 Sedan Bridge Owner's Manual Supplement

This owner's manual supplement has been written to provide additional specific information about your boat and should be read carefully. Insert this supplement in your Sport Yacht Owner's Manual as *Section 12 – Supplement*.

The owner's manual packet has been compiled to help you operate your craft with safety and pleasure. It contains details of the craft, the equipment supplied or fitted, its systems and information on its operation and maintenance. Please read the information in it carefully and familiarize yourself with the craft before using it.

If this is your first craft, or you are changing to a type of craft you are not familiar with, for your own comfort and safety, please ensure that you obtain handling and operating experience before "assuming command" of the craft. Your dealer or yacht club will be pleased to advise you of local sea schools or competent instructors.

PLEASE KEEP THIS OWNER'S MANUAL PACKET IN A SECURE PLACE AND HAND IT OVER TO THE NEW OWNER WHEN YOU SELL THE CRAFT.

TABLE OF CONTENTS

<p>Warranty Information 12.2</p> <p>Construction Standards 12.2</p> <p>Hull Identification Number 12.2</p> <p>Servicing Your Sea Ray 12.2</p> <p>Life Saving Equipment 12.3</p> <p>Boat Storage 12.3</p> <p>Troubleshooting 12.3</p> <p>Cleats & Locations 12.3</p> <p>Specifications & Dimensions 12.4</p> <p>Accommodation Plans 12.5-6</p> <p>Accessory Locations 12.7-9</p> <p>Deck Occupancy Plan 12.10-11</p> <p>Below Deck Layout 12.12-14</p> <p>General Information 12.12</p> <p style="padding-left: 20px;">Propulsion System 12.15</p> <p style="padding-left: 20px;">Water System 12.15-19</p> <p style="padding-left: 20px;">Head System 12.20-21</p> <p style="padding-left: 20px;">Engine Water Hose Routing 12.22</p> <p style="padding-left: 20px;">Fuel System 12.22</p> <p style="padding-left: 20px;">Crossover Fuel System 12.22</p> <p style="padding-left: 20px;">Fuel Recommendations 12.22</p> <p style="padding-left: 20px;">Fuel Filters 12.23</p> <p style="padding-left: 20px;">Fuel System Line Routing 12.23-24</p> <p style="padding-left: 20px;">Exhaust System 12.25</p> <p style="padding-left: 20px;">Ventilation System/Bilge Blower 12.26</p> <p style="padding-left: 20px;">Bilge Pumping System 12.27</p> <p style="padding-left: 20px;">Manual Bilge Pump 12.28</p> <p style="padding-left: 20px;">Steering System 12.29-30</p>	<p>Fire Extinguishing System 12.31-32</p> <p>Air Conditioning & Heating 12.33-35</p> <p>Engine Cooling System 12.35</p> <p>Anchoring 12.35</p> <p>Anchoring Arrangement 12.35</p> <p>Generator Information 12.36</p> <p>Location Of Through-Hull Fittings 12.37</p> <p style="padding-left: 20px;">Port Side 12.37</p> <p style="padding-left: 20px;">Starboard Side 12.37</p> <p style="padding-left: 20px;">Bilge Hull Cutouts 12.38</p> <p>Control Station Layout 12.39-42</p> <p>Special Features 12.43</p> <p style="padding-left: 20px;">Salon Conversion To Sleeper 12.43</p> <p style="padding-left: 20px;">Oil Exchanger System Hose Routing 12.43</p> <p style="padding-left: 20px;">Port Stateroom Washer/Dryer Location 12.44</p> <p style="padding-left: 20px;">Central Vacuum System Installation 12.45</p> <p>Canvas Information 12.46-47</p> <p style="padding-left: 20px;">Cabin/Cockpit Switch Location & Function 12.48-49</p> <p style="padding-left: 20px;">Electrical Installations 12.50-51</p> <p style="padding-left: 20px;">Battery 12.52-53</p> <p>AC/DC Main Distribution Panel (220 Volts AC & 12 Volts DC) 12.54</p> <p>Main DC Breaker Panel 12.55</p> <p>Battery Cable Installation 12.56-57</p> <p>Harness Installations 12.58-71</p> <p>Wiring Schematics 12.72-94</p> <p>Safety Label Locations 12.95-97</p> <p>International Hemologations 12.98</p>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

(This book contains 98 pages.)

WARRANTY INFORMATION


Sea Ray's® warranty is better than ever. Find the warranty information card in your owner's manual packet for complete details. If for some reason the card is missing, contact your Sea Ray® dealer for a new one.

CONSTRUCTION STANDARDS

Sea Ray's® commitment - Excellence by Design - has enabled us to create a superior craft providing you with comfort, performance, safety and dependability. All our boats comply with the safety standards set by the United States Coast Guard and are designed, engineered and manufactured in accordance with applicable recommendations and guidelines of the American Boat and Yacht Council (ABYC) certified by the National Marine Manufacturers Association (NMMA).

HULL IDENTIFICATION NUMBER (HIN)

The "Hull Identification Number," located on the starboard side of the transom, is the most important identifying factor and must be included in all correspondence and orders. Failure to include it only creates delays. Also of vital importance are the engine serial numbers and part numbers when writing about or ordering parts for your engine. Refer to the engine owner's manual for locations.



SERVICING YOUR SEA RAY®

When your boat needs service beyond regular maintenance it should be taken to an authorized Sea Ray® dealer.

To find a dealer in your area call:

1-800-SRBOATS.
Fax: 1-314-827-8488

If a problem is not handled to your satisfaction:

1. Discuss any warranty-related problems directly with the service manager of the dealership or your sales person. Give the dealer an opportunity to help the service department resolve the matter for you.
2. If a problem arises that has not been resolved to your satisfaction by your dealer, contact Sea Ray Boats at 1-800-SRBOATS and the appropriate customer service department information will be provided for you.

To find repair and parts facilities for equipment installed on your boat, refer to the original equipment manuals (OEMs) found in the owner's manual packet.



Sea Ray® 480 Sedan Bridge Owner's Manual Supplement • MRP #1441765
Printed in the U.S.A. June 1997, Revised: April 2000, March 2002 © Sea Ray Boats, Inc.
Sea Ray Boats, Inc. 2600 Sea Ray Blvd., Knoxville, TN 37914.
For information call 1-800-SRBOATS, or fax 1-314-827-8488
Internet address: <http://www.searay.com/boats>

Note: Not all accessories shown in pictures or described herein are standard equipment or even available as options.
Options and features are subject to change without notice.

LIFE SAVING EQUIPMENT (Personal Floatation Device (PFD))

STORAGE: The 480 DB offers lifesaving equipment storage in the cockpit storage compartments.

OPERATION: Wear PFD according to manufacturer recommendations. See pamphlet *Federal Requirements And Safety Tips For Recreational Boats* in the owner's packet or get one from your dealer.

MAINTENANCE: Rinse with fresh water and let dry thoroughly. Do not store in a damp compartment. Avoid the possibility of mildew.

BOAT STORAGE

WET STORAGE PROCEDURES: Special care for boats that are moored: If permanently moored in salt water or fresh water, your boat will collect marine growth on its bottom. This will detract from the boat's beauty and greatly affect its performance. There are two methods of preventing this:

- Periodically haul the boat out of the water and scrub the bottom with a bristle brush and a solution of soap and water.
- Paint the hull below the waterline with a good grade of antifouling paint.

NOTE: There are EPA regulations regarding bottom paint application. Consult your marine paint dealer for proper application methods.

SECURITY CONSIDERATIONS: Be conscious of the

security of your boat. Always remove the keys from the ignition, lock hatches, lock the cabin door. Remove and stow any removable electronic gear (fishfinders, LORAN, etc.) and personal gear (fishing poles, etc.) normally left aboard your boat.

TROUBLESHOOTING List of Reference Manuals and Drawings

PERFORMANCE: Refer to the owner's manual.

ENGINE: Refer to the owner's manual and/or the engine manual.

ELECTRICAL: Refer to electrical section of the owner's manual and electrical schematics in this owner's manual supplement. Only a qualified marine electrical technician may service the boat's electrical system.


Repair and Parts Facilities

To find a Sea Ray® dealer in your area, call: Sea Ray® Customer Service: 1-800-SRBOATS
FAX: 1-314-827-8488

To find repair and parts facilities for equipment installed on your boat, refer to the original equipment manuals (OEMs) found in the owner's manual packet.

CLEATS


Cleats are intended for mooring use only. Do not use cleats for towing or lifting the boat. Figure 12.3.1 illustrates the location of cleats on your boat.



SPECIFICATIONS & DIMENSIONS

Profile

(fig. 12.4.1)




SPECIFICATIONS & HEIGHT DIMENSIONS

(A) Overall Length	48' 3" (14.71 m)
(B) w/Std. Platform	51' 2" (15.60 m)
(C) Beam	15' 3" (4.66 m)
Draft	45" (114.3 cm)
Dry Weight – Standard Power	40,400 lbs. (18,325.31 kg)
Fuel Capacity	500 gal. (1,892.5 liters)
Usable Fuel	475 gal. (1,797.8 liters)
Water Capacity	140 gal. (530 liters)
Holding Tank	68 gal. (257 liters)
Dead Rise	15°

HEIGHT DIMENSIONS


(D) Wtrline To Top Of Brdg Area	12' 6" (3.81 m)
(E) Wtrline To Top Of Brdg Cover	16' 7" (5.05 m)
(F) Wtrline To Top Of Mastlight	20' 4" (6.20 m)
(G) Keel To Top Of Bridge Area	15' 0" (4.57 m)
(H) Keel To Top Of Bridge Cover	18' 11" (5.77 cm)




(fig. 12.4.2)

ACCOMMODATION PLANS

Main Deck
(fig.12.5.1)




Lower Deck
(fig. 12.5.2)




ACCOMMODATION PLANS


Bridge Plan A
(fig. 12.6.1)




Bridge Plan B
(fig. 12.6.2)




ACCESSORY LOCATIONS




Main Deck
(fig. 12.8.1)




(FIG. 12.8.2)




(FIG. 12.8.3)




(fig. 12.8.4)



Lower Deck
(fig. 12.9.1)




DECK OCCUPANCY PLAN



BRIDGE OCCUPANCY PLAN



WORKING DECK
(DECK AREA INTENDED FOR OCCUPATION
DURING ANCHORING, MOORING AND
EMERGENCY OPERATION ONLY)




ACCOMODATION DECK
(DECK AREA INTENDED FOR OCCUPATION
DURING NORMAL OPERATION)



DO NOT WALK ON THIS AREA

Bridge Plan A
(fig. 12.11.1)




! WARNING

PERSONAL INJURY HAZARD
When underway, keep pas-
sengers clear of areas not
designed for riding. Espe-
cially hazardous areas in-
clude seat backs, bow, gun-
wale, transom platform and
fore and aft decks.

! WARNING


SLIPPING HAZARD - Wet
decks are slippery. Wear
proper footwear and use ex-
treme caution on set surfaces.

Bridge Plan B
(fig. 12.11.2)



Below Deck Layout (Engine Room)


Engine Room Layout
(fig. 12.12.1)



A	Cabin Bilge Pump Float Switch	N	Bilge Blower	Z	Port Engine
B	Cabin Bilge Pump	O	STBD Engine Strainer	AA	FWD High Water Bilge Pump Float Switch
C	Bilge Manual Pump Pickup	P	Head Discharge Seacock	BB	FWD Bilge Pump
D	AC Seacock	Q	STBD Engine Fuel Filter	CC	FWD Bilge Pump Float Switch
E	Depth Transducer	R	Automatic Fire Extinguisher System	DD	STBD Engine Seacock
F	FWD High Water Bilge Pump	S	Generator Strainer	EE	Port Fuel Tank
G	AC Pump	T	Port Engine Fuel Filter	FF	Port Head Vacuum Generator
H	Bow Thruster Battery	U	Port Engine Strainer	GG	Bow Thruster Battery
I	Port Engine Seacock	V	Generator Fuel Filter	HH	AC Strainer
J	STBD Head Vacuum Generator	W	Generator Seacock (Under Exhaust Tube)	II	Speed Transducer
K	STBD Fuel Tank	X	Bilge Blower	JJ	Cabin Manual Pump Pickup
L	STBD Engine	Y	Common Drain		
M	Hydraulic Engine Control System Reservoir				

Below Deck Layout (Lazaret)


Lazaret
(fig. 12.13.1)



A	Water Tank	J	Glendening Cablemaster Tub	S	Generator Muffler
B	Power Steering Reservoir & Filter	K	Auto Pilot Rudder Feedback	T	Generator Exhaust Outlet
C	Mascerator Discharge Pump	L	Shore Power Main Breakers	U	Water Heater
D	STBD Engine Exhaust System	M	Aft High Water Bilge Pump Float Switch	V	Generator
E	Water Pumps	N	Aft High Water Bilge Pump	W	Generator Battery
F	Water Tank	O	Aft Bilge Pump	X	Port Engine Exhaust
G	Pneumatic Accumulator Tank	P	Aft Bilge Pump Float Switch	Y	Common Drain
H	Holding Tank	Q	Trim Tab Pump	Z	A/C Condensate Sump
I	Hydraulic Lift Platform Pump	R	Steering System	AA	Main Batteries

Crews Quarters Transom Lay-Out

(fig. 12.14.1)




GENERAL INFORMATION


PROPULSION SYSTEM

The 480 DB is equipped with an inboard type propulsion system also known as inboard engines.

REFER TO THE OWNER'S MANUAL AND ENGINE OWNER'S MANUAL FOR OPERATING INSTRUCTIONS AND WARRANTY INFORMATION.




WATER SYSTEM




Water system information can be found in Section 5 • Water System of the owner's manual.


REFER TO THE OWNER'S MANUAL AND OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



Water System Forward Of Engine Room (fig. 12.16.1)




Water Line Routing (1 of 4)
(fig. 12.17.1)




--- COLD WATER LINES
— HOT WATER LINES


Water Line Routing (2 of 4)
(fig. 12.17.2)




Water Line Routing (3 of 4)
(fig. 12.18.1)




Water Line Routing (4 of 4)
(fig. 12.18.2)



Gray Water System Sump
(fig. 12.19.1)



Common Drain System
(fig. 12.19.2)



HEAD SYSTEMS



Head System information can be found in *Section 6 • Head System* of the owner's manual. The Owner's Manual Packet in your boat contains information pertaining to your head system that should be carefully read.


REFER TO THE OWNER'S MANUAL AND OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.




CAUTION

Do not place facial tissue, paper towels or sanitary napkins in head.

Vacu-Flush Head System (Forward) (1 of 2)
(fig. 12.20.1)




Crews Quarters Head System Installation
(fig. 12.20.2)




Vacu-Flush Head System (Aft) (2 of 2)

(fig. 12.21.1)




Baitwell Pump Installation (Opt)

(fig. 12.21.2)



Engine Water Hose Routing (CAT 3196)

(fig. 12.22.1)



FUEL SYSTEM

The 480 DB is equipped with a diesel fuel system. A detailed drawing of the fuel system can be found in the *Parts Manual*. Fueling instructions and precautions can be found in the *Owner's Manual*.

CROSSOVER FUEL SYSTEM

The crossover fuel system allows the engines to draw fuel from either tank. This allows switching to an alternate tank in case of fuel contamination or for even fuel weight distribution. Each engine and the generator are equipped with valves on the crossover fuel board. The generator draws fuel from the port fuel tank only, utilizing valves offering OFF and ON positions.

Note: When operating the generator the FEED and RETURN valves must be in the ON position. (See Figure 12.22.2.)


The crossover fuel board is located under bridge steps.

FUEL RECOMMENDATIONS

The quality of the fuel is very important for satisfactory engine performance and long engine life. Fuel should be clean and free of contamination. Your fuel tanks should be kept full of fuel whenever possible. This will reduce the amount of water condensation and reduce the possibility of contamination.

Recommended Fuel: **#2 Diesel fuel**

Crossover Fuel Board (fig. 12.22 .2)



Fuel Filters: (Diesel)

Primary and secondary fuel filters are installed on your Sea Ray® to keep the fuel as clean as possible. Primary fuel filters are the Racor® water separating fuel filters installed on the port and starboard sides of the engine room. The secondary fuel filters are located on the engines and should be replaced in accordance with the Engine Owner's Manual.

Use of any methanol, gasohol or alcohol based fuel additive will damage the fuel filter.

Primary Fuel Filter Selection Valve:

Arrow Up: ALL OFF

Arrow Right: RIGHT ON

Arrow Down: ALL ON

Arrow Left: LEFT ON

Maximum efficiency can be accomplished by the on-line selection of the left or right fuel filter individually. This will give you a clean, efficient filter on-line while allowing maintenance on the off-line filter.


NOTE: In rough seas, allow approximately 15% reserve when planning fuel consumption.

REFER TO THE ENGINE OPERATOR'S MANUAL FOR MORE DETAILED INFORMATION.

Fuel Filters


(fig. 12.23.1)

Primary Fuel Filter (Diesel Racor)
With Filter Selection Valve .




Fuel System Line Routing


(fig. 12.23.2)



Fuel System Line Routing
(fig. 12.24.1)



Fuel Line Routing
(fig. 12.24.2)




EXHAUST SYSTEM


General exhaust system information can be found in Section 2 • Bilge & Underwater Gear of the owner's manual. Below are illustrations of the exhaust systems with different engine options.

REFER TO THE ENGINE OWNER'S MANUAL AND ENGINE OWNER'S MANUAL FOR INSTRUCTIONS AND WARRANTY INFORMATION.

Engine Exhaust System Installation
(Detroit 6V92) (fig. 12.25.1)



Engine Exhaust System Installation
(Caterpillar 3196) (fig. 12.25.2)



VENTILATION SYSTEM / BILGE BLOWER



Sea Ray® Sport Yachts are equipped with electric bilge blowers to remove fumes from the engine compartment and provide ventilation through the deck vents before starting the engine and when operating below cruising speeds. The bilge blowers are located inside the port and starboard sides of the engine room.

Bilge blower switches are located on the dash switch panel and the DC distribution panel.

The blower switches have a two way switching capability. The blower module allows the blowers to be turned ON and OFF at either the control station or the main distribution panel. Also, they can be turned ON at one station and turned OFF at the other.


Blower Switch Lights:

Lights On: When the blowers are turned ON, the lights in the switches will come on and stay on, indicating that the blowers are functioning correctly.

Lights Blinking: If the lights are blinking, it is an indication that one of the blower breakers has tripped. Reset the tripped breaker.

Lights Not On or Blinking: If you try to turn ON the blowers and no lights come on then both breakers are tripped and the switch is not receiving power. Reset the tripped breakers.

REFER TO "SECTION 2, BILGE & UNDERWATER GEAR" AND OWNER'S PACKET FOR OPERATING INSTRUCTIONS AND SAFETY PRECAUTIONS.




BILGE PUMPING SYSTEM



The 480 DB is equipped with an automatic bilge pump system.

REFER TO THE OWNER'S MANUAL AND OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



MANUAL BILGE PUMP

(WITH INTERNATIONAL CE OPTION)

The manual bilge pump system is located under the cockpit steps.


To Operate:

1. Rotate valve to select forward or aft pump.

2. Place handle into pump.

3. Move handle up and down to actuate pump.

REFER TO THE OWNER'S MANUAL, SECTION 2, FOR INSTRUCTIONS AND WARRANTY INFORMATION.




STEERING SYSTEM


Your sport yacht maybe equipped with a hydraulic power steering system option with a tilt steering wheel. For

information on the standard hydraulic steering system refer to *Section 3, Instruments and Controls*.


REFER TO THE ORIGINAL EQUIPMENT MANUAL IN THE OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



Rudder Arm, Tie Arm & Steering Ram Installation (fig. 12.30.1)



FIRE EXTINGUISHING SYSTEM



The 480 DB is offered with the standard automatic fire extinguishing system. Your boat also needs to be equipped with approved portable fire extinguishers. It is your responsibility to equip and maintain fire extinguishers.

Following are United States Coast Guard (USCG) requirements and American Boat & Yacht Council (ABYC) recommendations for boats not equipped with the automatic fire extinguishing system option for boats over 40 feet (12.2 meters) but less than 65 feet (19.8 meters).

⚠ WARNING

- In case of fire **DO NOT** open engine compartment.
- Shut down engines, generator and blowers.


Standard	Boat	No Fixed System Qty.	W/Approved Fixed System Qty.	Type
USCG	480 DB	3	2	B1
ABYC	480 DB	4	3	B1

Location: Outside engine compartment, steering position, crews quarters and galley, or passenger cockpit.


Note: To be ABYC compliant Sea Ray Boats, Inc. follows ABYC construction standards and recommendations.

REFER TO OWNER'S MANUAL AND OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.

AUTOMATIC FIRE EXTINGUISHER SYSTEM (GAS SYSTEM) (FIG. 12.31.2)



AUTOMATIC FIRE EXTINGUISHER SYSTEM (DIESEL SYSTEM) (FIG. 12.31.3)




AUTOMATIC FIRE EXTINGUISHER SYSTEM

The system is installed forward of the engines on the bulkhead. In the event of a fire, the heat sensitive automatic head will release the extinguishant as a vapor, totally flooding the area in fire-killing concentrations. The system indicator light is wired to the ignition and is turned ON when the ignition is turned ON. The system incorporates an engine shutdown switch with override system. The indicator light, located on the control station instrument panel, indicates to the helmsman when the

unit has discharged. Under normal circumstances, when the engines are operating, the indicator light is lit. If the unit discharges, the light will go out.

WHEN ACTUATION OCCURS, IMMEDIATELY SHUT DOWN ALL ENGINES, POWERED VENTILATION, ELECTRICAL SYSTEMS AND EXTINGUISH ALL SMOKING MATERIALS. DO NOT OPEN THE ENGINE COMPARTMENT IMMEDIATELY!! THIS FEEDS OXYGEN TO THE FIRE AND FLASHBACK COULD OCCUR.




AIR CONDITIONING/HEATING SYSTEM


Air Conditioning and Heating System information can be found in Section 8 • *Accessories* of the owner's manual.

REFER TO THE OWNER'S MANUAL AND OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



Air Conditioning Water Cooling Pump Strainer & Seacock (Located In Forward Engineeroom Bilge Sump) (fig. 12.33.1)



Air Conditioning Hose Routing (fig. 12.33.2)




**Air Conditioning
Hose Routing**
(fig. 12.34.1)





Air Conditioning Hose Routing

(fig. 12.35.1)



Lower Deck
(Located under steps)



ENGINE COOLING SYSTEM

The engine cooling system is an integral part of the propulsion system. The cooling system utilizes a seacock and strainer to provide seawater to each engine.

REFER TO THE ENGINE OWNER'S MANUAL, OWNER'S MANUAL SECTION 2 AND THE BILGE LAYOUT IN THIS SUPPLEMENT FOR LOCATIONS, INSTRUCTIONS AND WARRANTY INFORMATION.

ANCHORING




To anchor, bring the bow into the wind or current and put the engine in neutral. When the vessel comes to a stop, lower, do not throw, the anchor over the bow. The anchor line should be 5 to 7 times the depth of water.

ANCHORING ARRANGEMENT

The 480 DB is equipped with a windlass and an anchor chute. Stow the anchor in the chute when not in use. Note: Before using the anchor, be sure the anchor safety line is removed from the anchor and the anchor is secured to the windlass chain.


Lofrans™ Windlass (Opt)

(fig. 12.35.2)




GENERATOR SUPPLEMENT

Generator Installation
(fig. 12.36.1)




Generator Seacock & Strainer Installation
(fig. 12.36.2)




Location of Through-Hull Fittings



Port Side
(fig. 12.37.1)



Starboard Side
(fig. 12.37.2)





Bilge Hull Cutouts
(fig. 12.38.1)




Control Station Layout

Single Control Station (Standard)
 (Shown With Raytheon Electronics Package)
 (fig. 12.39.1)





Control Station Layout

(Optional) Detroit Electronic Display Module
(EDM) DDEC Dash Panel
(fig. 12.40.1)




Control Station Layout

(Optional) Control Station Caterpillar®
EMS Dash Panel
(fig. 12.41.1)





Control Station Accessory Locations
 (Inside Control Station Base)
 (fig. 12.42.1)



Special Features


To convert the salon sofa to sleeping position:

1. Salon sofa in normal position with sleeper in stowed position. (figure 12.43.1)
2. Salon sofa in sleeping position. (The switch to convert sofa is port of entrance.) (figure 12.43.2)




Oil Exchanger System Hose Routing


(Refer To Owner's Manual Section 8 For Operating Instructions) (fig. 12.43.3)



**Starboard Stateroom Washer/Dryer
& Access Door Installation**
(fig. 12.44.1)




**Starboard Stateroom Washer/Dryer
Power Vent & Hose Location**
(fig. 12.44.2)



CENTRAL VACUUM SYSTEM

The central vacuum unit is located under the starboard stateroom outboard aft end of bunk. The "STBD SYSTEMS" breaker must be ON to operate the system. The 24 foot hose connects to the inlet located in the base of the stateboard stateroom bunk base. The built in switch in the hose inlet fitting activates the vacuum when the hose is plugged in.

REFER TO THE OWNER'S PACKET FOR INSTRUCTIONS AND WARRANTY INFORMATION.



Canvas Information

CANVAS

REFER TO OWNER'S MANUAL PACKET FOR CANVAS MANUFACTURER INSTRUCTIONS AND WARRANTY INFORMATION.

! DANGER
EXHAUST FUMES FROM ENGINES
CONTAIN DEADLY
CARBON MONOXIDE GAS (CO)
BOATS WITH CANVAS OR POOR
VENTILATION ARE MOST LIKELY TO
COLLECT FUMES. CO SICKNESS
SYMPTOMS INCLUDE HEADACHE,
NAUSEA AND DIZZINESS. DO NOT
MISTAKE FOR SEA SICKNESS.
VENTILATE BOAT. SEE BOAT OWNER'S
MANUAL FOR MORE DETAILS.

! WARNING
SUNSHADE SHOULD
NOT BE USED WHEN
VESSEL SPEED EXCEEDS
45 MPH

! WARNING
THE AFT CURTAIN IS NOT
DESIGNED TO BE USED
WHILE ENGINE IS RUNNING
OR BOAT IS UNDERWAY

Attached to the inside of the bimini top is a DANGER tag for Carbon Monoxide Gas (CO) buildup and a WARNING tag for excessive speeds while canvas is installed. The Aft Curtain also has a WARNING tag stating "The Aft Curtain is not designed to be used while engine is running or boat is underway". If your canvas does not have these tags, they become lost or are unable to be read, contact your dealer for replacement labels.


Your Sea Ray® boat standard canvas set consists of the following pieces:

- Canvas Package:
- Aft Cover
- Bimini Enclosure
- Windshield Cover
- Canvas Storage Bag


Sport Yacht Canvas Package

(Note: Your Sport Yacht May Not Be Equipped With All Of The Canvas Shown)


(fig. 12.46.1)




CABIN & COCKPIT SWITCH LOCATION & FUNCTION



Lower Deck Switch Location & Function
(fig. 12.48.1)



Bridge Area Switch Location & Function
(fig. 12.49.1)




ELECTRICAL INSTALLATIONS

This owner's manual supplement contains electrical schematics for your boat. These electrical schematics were generated by technicians at the engineering division for technical reference and service technicians. Sea Ray® does not recommend that you attempt to work on the boat's electrical system yourself. Instead we

recommend that you take your boat to your authorized Sea Ray® dealer for service. Sea Ray® reserves the right to change or update the electrical system on any model at any time without notice to the consumer and is NOT obligated to make any updates to units built prior to changes.

Bilge Component Board


(fig. 12.50.1)



Shore Main Breaker Location


(Starboard Transom)

(View Looking Aft) (fig. 12.50.2)



Bow Thruster Converter Location


(fig. 12.51.1)



MDP Components Board Location


Behind Main Distribution Panel (MDP)

(fig. 12.51.2)



BATTERY

Refer to the owner's manual for battery disconnect and maintenance.



Battery Specifications:

Group: 8-D
Cold Cranking Amps: 1400 Volts
Reserve Capacity: 435 Minutes

Sea Ray® recommended batteries are available through your Sea Ray® dealer.

ALWAYS DISCONNECT BATTERY CABLES BEFORE DOING ANY WORK ON THE ENGINE'S ELECTRICAL SYSTEM OR ALTERNATOR WIRING TO PREVENT ARCING OR DAMAGE TO THE ALTERNATOR.


⚠ CAUTION

While the engine is running, the battery terminal clamps must not be loosened or detached nor should the battery switch(es) be turned off, otherwise the alternator and other electronic units will be damaged.


⚠ DANGER

- Never use an open flame in the battery storage area.
- Avoid striking sparks near the battery.
- A battery will explode if a flame or spark ignites the free hydrogen given off during charging.


Battery Switch Panel
(fig. 12.52.1)




Battery Switch Panel Location
(fig. 12.53.1)



AC & DC Main Distribution Panels




(fig. 12.54.3)




DC Main Distribution Panel

(Located under cockpit bridge stairway.)




(fig. 12.55.1)


Battery Cable Installation




Battery Cable Installation




Bilge Harness Installation




Cabin Subfloor Harness Installation




Starboard Cabin Harness Installation



Port Cabin Harness Installation




Starboard Stateroom Harness Installation




Forward Stateroom Harness Installation


(fig. 12.63.1)




(fig. 12.63.2)




Forward Stateroom Head Harness Installation




Guest Head Harness Installation




Spoiler / Hardtop Harness Installation



Salon Lights Harness Installation




Galley Harness Installation




Bilge Lights Harness Installation


(fig. 12.69.1)




(fig. 12.69.2)




Bridge Harness Installation (1 of 2)



Bridge Harness Installation (2 of 2)




PRINT #09-801, 1 of 6, REVISION #02




DC WIRING SCHEMATIC (1 OF 6)

DC WIRING SCHEMATIC (2 OF 6)

PRINT #09-801, 2 of 6, REVISION #01




PRINT #09-601, 3 of 6, REVISION #03




DC WIRING SCHEMATIC (3 OF 6)

DC WIRING SCHEMATIC (4 OF 6)



PRINT #09-801, 4 of 6, REVISION #02


PRINT #09-801, 5 of 6, REVISION#0




DC WIRING SCHEMATIC (5 OF 6)

DC WIRING SCHEMATIC (6 OF 6)

PRINT #09-601, 6 of 6, REVISION #0






REF 09-601 FOR BILGE HARNESS AND ENGINE WIRING CONNECTIONS.

DC WIRING DIAGRAM CAT EMS (OPTION)


DC WIRING DIAGRAM CAT EMMS (OPTION)

PRINT #09-602, 2 of 2, REVISION #01




REF 09-601 FOR BILGE HARNESS AND ENGINE WIRING CONNECTIONS.


PRINT #09-603, 1 of 2, REVISION#03



CABIN DC WIRING DIAGRAM




CABIN DC WIRING DIAGRAM



MAIN DC BREAKER PANEL WIRING


ENGINE HARNESS SCHEMATIC (Cummins QSM-11)




NOTES
 1) REF. DWG 09-911 FOR ENGINE HARNESS CONSTRUCTION.
 2) REF. DWG 09-912 FOR BORG/WARNER INTERFACE HARNESS CONSTRUCTION.

PRINT #09-605

PRINT #09-606, 1 of 2, REVISION #01




PRINT #09-606, 2 of 2, REVISION #0



SYSTEM MONITOR SCHEMATIC


CAT EMMS SWITCH PANEL WIRING DIAGRAM



BOW THRUSTER SCHEMATIC



(VETUS 130k GF/160 GF)

- NOTES:
- 1) ENSURE TOTAL POSITIVE AND NEGATIVE CABLE LENGTHS FROM BATTERY TO MOTOR ARE NO LONGER THAN 65 FEET.
 - 2) THE CABLE LENGTH FROM THE BATTERY TO FUSE MUST BE NO MORE THAN 72" IN LENGTH AND BE CONTAINED IN A SHEATH THROUGHOUT IT'S ENTIRE LENGTH.
 - 3) THE CABLE LENGTH FROM THE CONVERTER TO THE FUSE MUST BE NO MORE THAN 40" IN LENGTH AND CONTAINED IN A SHEATH THROUGHOUT IT'S ENTIRE LENGTH.



SWIM PLATFORM SCHEMATIC (NAUTICAL STRUCTURES)


TV & STEREO ANTENNA SYSTEM



PRINT #09-609, 1 of 1, REVISION #0

PRINT #09-612, 1 of 1, REVISION #0


LOFRANS PROGRESS II WINDLASS WIRING DIAGRAM



PRINT #09-614, 1 of 1, REVISION #0

12.87

WESTERBEKE DIESEL GENERATOR REMOTE WIRING




NOTE:
1) CONNECTORS ARE AMP MATE-N-LOK II, USE PINS IN PLUGS AND SOCKETS IN CAPS.

PRINT #09-617, 1 of 1, REVISION #01

480 Sedan Bridge


**WESTERBEKE DIESEL GENERATOR REMOTE INSTRUMENT
PANEL WIRING**

WESTERBEKE DIESEL GENERATOR HIGH VOLTAGE WIRING




PRINT #09-618, 1 of 1, REVISION #0

PRINT #09-619, 1 of 1, REVISION #0




AC WIRING SCHEMATIC (240 V AC WITH BRIDGE A/C)



PRINT #09-834, 1 of 1, REVISION #01

ENGINE HARNESS CONSTRUCTION (Cummins QSM-11)

MRP #1684414



CUMMINS QSM-11

- | | | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| <p>PLUG 40
CONTROL STATION SWITCH PANEL
AMP MATE-N-LOK II (9 POS)
PLUG #770021-1
PINS #770250-1</p> | <p>PLUG 82
BORG/WARNER INTERFACE
AMP MATE-N-LOK II (2 POS)
PLUG #770017-1
PINS #770250-1</p> | <p>PLUG 45
CONTROL STATION SWITCH PANEL
AMP MATE-N-LOK II (6 POS)
PLUG #770020-1
PINS #770250-1</p> |
| <p>ENGINE EXTENSION HARNESS CONNECTOR
DEUTSCH DT06-12S
ALL SOCKETS 0462-209-16141
SEC LOCK W12S</p> | <p>F 51 (9 POS)
DEUTSCH DT04-12P
ALL PINS 0460-215-16141
SEC LOCK W12P</p> | <p>F 60 (23 POS)
DEUTSCH HDP24-24-23FN
ALL PINS 0460-215-16141</p> |
| <p>PORT & STBD THROTTLE POSITION SENSOR
YAZAKI CONNECTOR P/N 7283-1334-30
REAR HOLDER P/N 7157-6827-301
SEAL P/N 7157-7935
TERMINAL P/N 7116-1521</p> | <p>M 52 (4 POS)
DEUTSCH DT06-4S
ALL SOCKETS 0462-209-16141
SEC LOCK W4S</p> | <p>M 60 (23 POS)
DEUTSCH HDP26-24-23SN
ALL SOCKETS 0642-209-16141</p> |
| <p>CAP BI
BORG/WARNER INTERFACE
AMP MATE-N-LOK II (2 POS)
CAP #770024-1
PINS #770257-3</p> | <p>F 53 (4 POS)
DEUTSCH DT04-4P
ALL PINS 0460-215-16141
SEC LOCK W4P</p> | <p>PORT & STBD ENGINE THROTTLE CONNECTORS
PACKARD 12010717
ALL PINS 12089040
SEALS 12015323</p> |

- NOTES:
- 1) WIRES TO BE UL STANDARD 1426, 105°C, 600V PER ABYC E 9.14.
 - 2) TWISTED PAIRS OF 16 AWG WIRES, APPROXIMATELY 3 TWISTS PER 1".
 - 3) ALL DIMENSIONS ARE IN INCHES.
 - 4) ALL CONNECTORS TO BE PERMANENTLY MARKED WITH IDENTIFYING NUMBER INDICATED.
 - 5) SPLICES ARE TO BE MECHANICALLY CRIMPED AND COVERED WITH ADHESIVE LINED HEAT SHRINK TUBING.
 - 6) USE CAVITY PLUGS ON ALL EMPTY POSITIONS IN ALL CONNECTORS.
 - 7) CONNECTORS TO BE IDENTIFIED WITH RED TAPE FOR PORT AND GREEN TAPE FOR STBD.
 - 8) REF DMG 09-605 FOR WIRING SCHEMATIC.

PRINT #09-810

ENGINE HARNESS CONSTRUCTION (CAT 3196)

- NOTES:
- 1) WIRES TO BE 105° C, SAE J378/J1128, AND TYPE 2 STRANDING PER ABYC E 9.14.
 - 2) TWISTED PAIR OF SHIELDED 16 AWG WIRES, APPROXIMATELY THREE TWISTS PER 1".
 - 3) ALL DIMENSIONS ARE INCHES UNLESS OTHERWISE SPECIFIED.
 - 4) TOLERANCES ARE + OR - 1" (NONCUMULATIVE) ON DROP-OFF LOCATIONS AND + OR - 2" ON DROP-OFF LENGTHS.
 - 5) ALL CONNECTORS ARE TO BE PERMANENTLY MARKED WITH THE IDENTIFYING NUMBER INDICATED.
 - 6) SPLICES ARE TO BE MECHANICALLY CRIMPED AND COVERED WITH ADHESIVE LINED HEAT SHRINK TUBING.
 - 7) HARNESS TO BE IDENTIFIED WITH RED HEAT SHRINK AT EACH CONNECTOR.
 - 8) CONNECTORS:

AMP MATE-N-LOK II

DEUTSCH


PLUG 40
9 POS 770021-1
ALL PINS 770007-1

J1P
12 POS DT06-12SA
SOCKETS 0462-20-16141
SECONDARY LOCK W12S

P31P
40 POS DRC 16-40S
SOCKETS 0462-209-16141
SECONDARY LOCK W-3-S


PLUG 99
15 POS 770023-1
ALL PINS 770007-1

CAP 99
15 POS 770030-1
ALL SOCKETS 770008-3




MRP #4S
ENGINE HARNESS I103050
EXTENSION PLAN A I119357
EXTENSION PLAN B I119373

ENGINE HARNESS CONSTRUCTION (PORT SIDE) (CAT 3196)



SAFETY LABEL LOCATIONS

Main Deck
(fig. 12.95.1)



WARNING

- DO NOT LEAVE BOAT UNATTENDED WITH THE DICKSIDE WATER HOSE CONNECTED. DOCKSIDE WATER SHOULD BE CONNECTED DURING PERIODS OF HEAVY WATER USE ONLY.

MRP # 882616 SR-124

INSIDE TRANSOM STORAGE COMPARTMENT/FENDERS STORAGE

CAUTION

TRANSOM DOOR MUST BE CLOSED AND SECURE WHEN ENGINE IS RUNNING

MRP # 811000 SR-102

DANGER

TO AVOID RISK OF SERIOUS INJURY OR DEATH SHUT OFF ENGINE WHEN NEAR SWIM PLATFORM AND BOARDING LADDER.

MRP # 112879 SR-214

PLATFORM MAXIMUM CAPACITY
800 LBS/363KG
MRP # 1087485 SR-202

DANGER

DO NOT STAND OR WALK ON THIS AREA SERIOUS INJURY COULD RESULT.

MRP # 113582 SR-216

SHORE POWER WARNING

To minimize shock hazard, connect and disconnect cable as follows:

1. Turn off boat's shore power switch.
2. Connect cable at boat first.
3. If equipped with polarity indicator, which activates, disconnect and connect polarity.
4. Disconnect at shore outlet first.
5. Cover and cover fitting.

DO NOT ALTER SHORE POWER CABLE CONNECTORS

LOCATED UNDER BLUE ACCESS DOOR

DISCHARGE OF OIL PROHIBITED

THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES OR THE WATERS OF THE CONTIGUOUS DISCOLORATION OF THE SURFACE OF THE WATER OR CAUSES A STAIN OR EMULSION BEHIND THE SURFACE OF THE WATER. VIOLATORS ARE SUBJECT TO A PENALTY OF \$5,000.

NOTICE

CHECK BATTERY CELL FUEL LEVEL APPROXIMATELY EVERY 4 WEEKS AND MORE OFTEN IN SUMMER AND HOT ZONES.

MRP # 914341 SR-139

DANGER

STAY CLEAR OF MOVING PARTS

MRP # 921739 SR-162

WARNING

TURN OFF COFFEE MAKER BEFORE CLOSING DOOR.

MRP # 888890 SR-134

DANGER

STAY CLEAR OF MOVING PARTS


MRP # 921739 SR-162

LOCATED UNDER ANCHOR HATCH

Lower Deck
(fig. 12.96.1)

⚠ WARNING
DOES NOT MEET FEDERAL REQUIREMENTS FOR IGNITION PROTECTION. DO NOT INSTALL IN SPACES CONTAINING GASOLINE ENGINES, TANKS, LPG / CNG CYLINDERS, REGULATORS, VALVES OR LINE FITTINGS. FAILURE TO COMPLY MAY RESULT IN INJURY OR DEATH.

⚠ DANGER
ELECTRICAL SHOCK HAZARD. DISCONNECT POWER MAIN PANEL, OR POWER SOURCE INLET BEFORE OPENING THIS COVER.




DO NOT OPERATE WASHER AND DRYER DOING SO MAY RESULT IN DAMAGE TO MACHINE.

Bridge Plan A
(fig. 12.96.2)

⚠ DANGER
UNDER NO CIRCUMSTANCES SHOULD YOU LOOK DIRECTLY INTO THE HANDSOME FROM A DISTANCE OF LESS THAN TWO FEET WHEN THE RADAR IS IN OPERATION.
MRP-1126226
SR-152


⚠ DANGER
AVOID COLLISIONS
Maintain lookout as required by the "rules of the Road".
Avoid collisions with other boats, structures, persons, gear, weather and light conditions.
At all times proceed at a Safe Speed so that you can take proper and effective action to avoid hazardous conditions.
Such issues are considered under the control of the operator!
AVOID RISK OF INJURY OR DEATH. SHUT OFF ENGINE PRIOR TO USING SWIMPADS, SWIM PLATFORM OR BOARDING LADDER.
MRP-987727
SR-187



BRIDGE CAPACITY INFORMATION
MAXIMUM WEIGHT CAPACITY UNDERWAY
(PERSONS & GEAR) 1500 LBS.

⚠ WARNING
LEAKING FUEL IS A FIRE AND EXPLOSION HAZARD. INSPECT SYSTEM REGULARLY. EXAMINE FUEL TANKS FOR LEAKS OR CORROSION AT LEAST ANNUALLY.
MRP # 826332
SR-151

⚠ DANGER
DO NOT CLIMB UPON OR STORE EQUIPMENT ON HARDTOP
MRP-1017375
SR-198




⚠ CAUTION
IF SWITCH IS TURNED OFF WHILE ENGINE IS RUNNING ALTERNATOR WILL BE DAMAGED.
MRP # 921767
SR-167

ON DC DISTRIBUTION PANEL

NOTICE
CHECK BATTERY CELL FUEL LEVEL APPROXIMATELY EVERY 4 WEEKS AND MORE OFTEN IN SUMMER AND HOT ZONES.
MRP # 914341
SR-139

ON DC DISTRIBUTION PANEL

Engine Room
(fig. 12.97.1)




UNPLUG SHORE POWER AND TURN OFF GENERATOR BEFORE REMOVING COVER.

WARNING
ELECTRICAL SHOCK HAZARD
UNIT INJECTION SYSTEM
90 - 120 VOLTS

⚠ DANGER
STAY CLEAR OF MOVING PARTS
WHILE ENGINE IS RUNNING
MPP # 852624
SR-149

Lazeret
(fig. 12.97.2)



BATTERIES
CAUTION
• BATTERIES ENCLOSED
• SERVICE WEEKLY
• REPLACE COVER WHILE UNDER WAY

UNPLUG SHORE POWER AND TURN OFF GENERATOR BEFORE REMOVING COVER.

NOTICE
THIS BOAT IS EQUIPPED WITH AN OPTIONAL DIRECT OVERBOARD DISCHARGE VALVE. DISCHARGING OF SEWAGE DIRECTLY OVERBOARD IS FOR USE WHERE APPROVED ONLY.
MPP # 852574
SR-163

⚠ DANGER
UNPLUG SHORE POWER AND TURN OFF GENERATOR BEFORE REMOVING COVER.
MPP 852582
SR-154

NOTICE
THIS BOAT IS EQUIPPED WITH AN OPTIONAL DIRECT OVERBOARD DISCHARGE VALVE. DISCHARGING OF SEWAGE DIRECTLY OVERBOARD IS FOR USE WHERE APPROVED ONLY.
MPP # 852574
SR-163

INTERNATIONAL HOMOLOGATIONS

This vessel and its systems have been constructed in accordance with standards and specifications in effect at the time of manufacture as published by the various regulatory authorities listed below.

1. Ministere De La Mer - France
2. Registro Italiano Navale - Italy
3. Det Norske Veritas - Norway
4. Securite des Nauires - Canada
5. J.C.I. (Japan Craft Inspection) - Japan
6. N.K.K. (Nippon Kaiji Kyokai) - Japan
7. B.S.I. (British Standards Institute) - England
8. Ministerio Obras Publicas Y Transporters - Spain
9. EC Directive - European Community

Further information may be obtained from Sea Ray® Customer Service. 1-800-SRBOATS.

