

# CAMRY HYBRID 2 0 1 5



OWNER'S MANUAL



## Your Toyota dealer

Your Toyota dealer will provide quality maintenance and any other assistance you may require.

If there is not a Toyota dealer near you, please call the following number:

#### **U.S. OWNERS**

- In the U.S. mainland or Canada: Toyota Customer Experience Center 1-800-331-4331 (Toll-Free)
- In Hawaii:
   Servco Automotive Customer Services
   1-888-272-5515 (Toll-Free)

#### ■CANADIAN OWNERS

In Canada or the U.S. mainland:
 Toyota Canada Customer Interaction Centre
 1-888-TOYOTA-8 or 1-888-869-6828 (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: www.toyota.com
- Hawaii: www.toyotahawaii.com
- Canada : www.toyota.ca

#### ©2014 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

Picto	rial	index	
I ICLO	IIai	IIIUCA	

Search by illustration

1	For safety and security	Make sure to read through them	
2	Instrument cluster	How to read the gauges and meters, the variety of warning lights and indicators, etc.	
3	Operation of each component	Opening and closing the doors and windows, adjustment before driving, etc.	
4	Driving	Operations and advices which are necessary for driving	
5	Audio system	Operating the audio system	
6	Interior features	Usage of the interior features, etc.	
7	Maintenance and care	Caring for your vehicle and maintenance procedures	
8	When trouble arises	What to do in case of malfunction or emergency	
9	Vehicle specifications	Vehicle specifications, customizable features, etc.	
10	For owners	Reporting safety defects for U.S. owners, and seat belt and SRS airbag instructions for Canadian owners	
	les al a co	Search by symptom	
	Index	Search alphabetically	

-	your information 0	_	
	your information8 ding this manual14	Operation of each component	
How	to search15		
Picto	orial index16	3-1.	Key information
			Keys106
1	For safety and security	3-2.	Opening, closing and locking the doors
1-1.	For safe use		Doors110
	Before driving26		Trunk117
	For safety drive28		Smart key system 121
	Seat belts 30	3-3.	Adjusting the seats
	SRS airbags 36		Front seats128
	Front passenger occupant		Rear seats130
	classification system 49		Head restraints132
	Safety information	3-4.	Adjusting the steering
	for children 55		wheel and mirrors
	Child restraint systems 56		Steering wheel134
	Installing child restraints 60		Inside rear view mirror 136
	Exhaust gas precautions 68		Outside rear view
1-2.	Hybrid system		mirrors138
	Hybrid system features 69	3-5.	Opening and closing
	Hybrid system		the windows
	precautions73		Power windows140
1-3.	Theft deterrent system		Moon roof143
	Immobilizer system78		
	Alarm80		
2	Instrument cluster		
2.	Instrument cluster		
	Warning lights and		
	indicators84		
	Gauges and meters88		
	Multi-information display 92		
	Energy monitor/		
	consumption screen98		

4-1.	Before driving
	Driving the vehicle148
	Cargo and luggage 155
	Vehicle load limits 158
	Trailer towing159
	Dinghy towing160
4-2.	Driving procedures
	Power (ignition) switch 161
	EV drive mode166
	Hybrid transmission 168
	Turn signal lever 170
	Parking brake 171
4-3.	Operating the lights and wipers
	Headlight switch172
	Automatic High Beam 175
	Windshield wipers and
	washer 180
4-4.	Refueling
	Opening the fuel tank

cap ...... 182

**Driving** 

4-5.	Using the driving support systems
	Cruise control185
	Dynamic radar cruise control189
	LDA (Lane Departure Alert)202
	Rear view monitor
	system208
	Driving assist systems218
	PCS
	(Pre-Collision System)224
	BSM (Blind Spot Monitor)231
	• The Blind Spot Monitor function234
	• The Rear Cross Traffic Alert function236
4-6.	Driving tips
	Hybrid vehicle driving tips239 Winter driving tips242
	3 17 1

## 5 Audio system

5-1.	Basic Operations	
	Audio system types	248
	Audio system	250
	Steering wheel audio	
	switches	
	USB port/AUX port	253
	Basic audio operations	255
5-2.	Setup	
	Setup menu	257
	General settings	258
	Audio settings	260
	Display settings	261
	Voice settings	262
5-3.	Using the Multimedia system	
	Selecting the audio	
	source	263
	List screen operation	264
	Optimal use of the	
	multimedia system	266
5-4.	Using the radio	
	Radio operation	267
5-5.	Playing an audio CD and MP3/WMA/AAC discs	
	CD player operation	269
5-6.	Using an external	
	device	
	Listening to an iPod	274
	Listening to a USB	
	memory device	278
	Using the AUX port	282

5-7.	Connecting Bluetooth®	
	Preparations to	
	use wireless	
	communication	283
	Registering a Bluetooth®	
	audio player for the	207
	first time	201
	Registering a Bluetooth® phone for the first time	288
	Registering a Bluetooth®	
	device	289
	Connecting a Bluetooth®	
	device	291
	Displaying a Bluetooth®	
	device details	293
	Detailed Bluetooth®	
	system settings	294
5-8.	Bluetooth <sup>®</sup> Audio	
	Listening to Bluetooth®	
	Audio	295
5-9.	Bluetooth <sup>®</sup> phone	
	Using a Bluetooth®	000
	Phone	
	Making a call	
	Receiving a call	
	Speaking on the phone	302
	Bluetooth® phone message function	205
	Using the steering	303
	wheel switches	308
	Bluetooth <sup>®</sup> phone	500
	settings	309
	Contact/Call History	
	Settings	310
	What to do if	
	(Troubleshooting)	318
5-10	.Bluetooth <sup>®</sup>	
	Bluetooth®	322
5-11	.Using the voice	
	command system	
	Voice command system	327

О	interior	reatures

6-1.	Using the air conditioning system and defogger	
	Automatic air conditioning	
	system	
	Seat heaters	339
6-2.	Using the interior lights	240
	Interior lights list	
	Interior lights	
c 2	Personal lights	341
6-3.	Using the storage features	
	List of storage features	343
	Glove box	344
	Console box	344
	Coin holder	345
	Bottle holders	345
	Cup holders	346
	Auxiliary boxes	347
	Open tray	352
	Trunk features	353
6-4.	Other interior features	
	Other interior features	354
	Sun visors	354
	Vanity mirrors	354
	• Clock	355
	Ashtray	356
	Power outlets	357
	Armrest	358
	Assist grips	358
	Coat hooks	359
	Garage door opener	360
	Safety Connect	
	Compass	370

## Maintenance and care

7-1.	Maintenance and care	
	Cleaning and protecting the vehicle exterior	376
	Cleaning and protecting the vehicle interior	379
7-2.	Maintenance	
	Maintenance	
	requirements	382
	General maintenance	385
	Emission inspection and	
	maintenance (I/M)	
	programs	389
7-3.	Do-it-yourself	
	maintenance	
	Do-it-yourself service	
	precautions	
	Hood	
	Positioning a floor jack	393
	Engine compartment	394
	12-volt battery	402
	Tires	406
	Tire inflation pressure	416
	Wheels	419
	Air conditioning filter	421
	Electronic key battery	423
	Checking and replacing	
	fuses	425
	Light hulbs	428

## When trouble arises

8-1.	Essential information
	Emergency flashers 438
	If your vehicle has to
	be stopped in an
	emergency 439
8-2.	Steps to take in an
	emergency
	If your vehicle needs to
	be towed 440
	If you think something is
	wrong 443
	If a warning light turns
	on or a warning buzzer
	sounds 444
	If a warning message or
	indicator is displayed 453
	If you have a flat tire 471
	If the hybrid system will
	not start 482
	If the shift lever cannot
	be shifted from P 484
	If the electronic key does
	not operate properly 485
	If the vehicle 12-volt
	battery is discharged 487
	If your vehicle
	overheats 491
	If the vehicle becomes
	stuck495

## 9 Vehicle specifications

9-1.	
	Maintenance data (fuel, oil level, etc.)498
	Fuel information507
	Tire information510
9-2.	Customization
	Customizable features523
9-3.	Items to initialize
	Items to initialize532
10	For owners
Don	arting anfatu dafaata
	orting safety defects U.S. owners534
	belt instructions
for	Canadian owners
(in	French)535
	airbag instructions
	Canadian owners French)537
	Index
	IIIIII
What to do if (Troubleshooting)548 Alphabetical index551	

For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MAN-UAL" for information regarding the navigation system or Entune Audio Plus.

## For your information

### Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of color and equipment.

## Noise from under vehicle after turning off the hybrid system

Approximately five hours after the hybrid system is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

## Accessories, spare parts and modification of your Toyota

A wide variety of non-genuine spare parts and accessories for Toyota vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Toyota vehicle.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

## Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Dynamic radar cruise control system (if equipped)
- Cruise control system (if equipped)
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

High voltage parts and cables on the hybrid vehicles emit approximately the same amount of electromagnetic waves as the conventional gasoline powered vehicles or home electronic appliances despite of their electromagnetic shielding.

Unwanted noise may occur in the reception of the mobile two-way radio.

## Vehicle data recordings

Your Toyota is equipped with several sophisticated computers that will record certain data, such as:

- · Engine speed
- Electric motor speed (traction motor speed)
- · Accelerator status
- · Brake status
- · Vehicle speed
- · Shift position
- Hybrid battery (traction battery) status

The recorded data varies according to the vehicle grade level and options with which it is equipped. Furthermore, these computers do not record conversations, sounds or pictures.

#### Data usage

Toyota may use the data recorded in these computers to diagnose malfunctions, conduct research and development, and improve quality.

Toyota will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- For use by Toyota in a law suit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner
- Usage of data collected through Safety Connect (U.S.mainland only)
   If your Toyota has Safety Connect and if you have subscribed to those services, please refer to the Safety Connect Telematics Subscription Service Agreement for information on data collected and its usage.

#### Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened:
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

#### Disclosure of the EDR data

Toyota will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- For use by Toyota in a law suit However, if necessary, Toyota may:
- · Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

## Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota dealer before you scrap your vehicle.

#### **Perchlorate Material**

Special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate. Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries



#### WARNING

#### General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

## ■ General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

# **Reading this manual**



#### WARNING:


Explains something that, if not obeyed, could cause death or serious injury to people.




#### NOTICE:

Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.

- 123 ··· Indicates operating or working procedures. Follow the steps in numerical order.
- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- Indicates the outcome of an operation (e.g. a lid opens).




- Indicates the component or position being explained.
- Means "Do not", "Do not do this", or "Do not let this happen".



# How to search

- Searching by name
  - Alphabetical index......P. 551




- Searching by installation position
  - Pictorial index.....P. 16



- Searching by symptom or sound
  - What to do if... (Troubleshooting)......P. 548




- Searching by title



# Pictorial index


## Exterior



(1)	Doors P. 11	0
	Locking/unlocking P. 11	0
	Opening/closing the door windows P. 14	0
	Locking/unlocking by using the mechanical key P. 48	
	Warning message P. 45	4
(2)	Trunk P. 11	7
	Opening from inside	7
	Opening from outside	
	Warning message	4
(3)	Outside rear view mirrors P. 13	8
	Adjusting the mirror angle P. 13	
	Folding the mirrors	
	Defogging the mirrors	

4)	Windshield wipers P. 180 Precautions against winter season P. 242	
(5)	Fuel filler doorP. 182Refueling methodP. 182Fuel type/fuel tank capacityP. 500	
6	TiresP. 406Tire size/inflation pressureP. 505Winter tires/tire chainsP. 242Checking/rotation/tire pressure warning system*P. 406Coping with flat tiresP. 471	
7	Hood       P. 392         Opening       P. 392         Engine oil       P. 501         Coping with overheat       P. 491         Warning message       P. 454	
	bulbs of the exterior lights for driving acing method: P. 428, Watts: P. 506)	
(Repl		
(Repl	acing method: P. 428, Watts: P. 506)	
(Repl	acing method: P. 428, Watts: P. 506)  Headlights/halogen daytime running lights*	
(Repl	acing method: P. 428, Watts: P. 506)  Headlights/halogen daytime running lights* P. 172  Front turn signal/parking lights/  LED daytime running lights*	:
(Repl	Acing method: P. 428, Watts: P. 506)  Headlights/halogen daytime running lights*	:
(Repl  (Rep  (Rep	Acing method: P. 428, Watts: P. 506)  Headlights/halogen daytime running lights* P. 172  Front turn signal/parking lights/ LED daytime running lights* P. 172  Front side marker lights P. 172  Rear turn signal lights P. 170	

## **■**Instrument panel





<b>(</b> )	Starting the hybrid system/changing the modes P. 161 Emergency stop of the hybrid system P. 439 When the hybrid system will not start P. 482 Warning messages P. 453
2	Shift lever
	Changing the shift position. P. 168 Precautions against towing
	When the shift lever does not move
(3)	Meters
	Reading the meters/adjusting the meter light P. 88
	Warning lights/indicator lights P. 84
	When the warning lights come on P. 444
	Multi-information display P. 92
	Display
	When a warning message or indicator is displayed P. 453

4	Parking brake          Applying/releasing          Precautions against winter season          Warning light/warning buzzer/warning message       P. 44-	P. P.	171 243
5	Turn signal lever  Headlight switch  Headlights/parking lights/side marker lights/tail lights/ daytime running lights	P.	172
6	Windshield wiper and washer switch	P. P.	180 401
7	Emergency flasher switch	P.	438
8	Trunk opener	P.	117
9	Fuel filler door opener	P.	182
10	Hood lock release lever	P.	392
11)	Tilt and telescopic steering lock release lever	P.	134
12	Air conditioning system	P.	332
13)	Entune Audio system* <sup>1, 2</sup> Navigation system* <sup>1, 2</sup>	P.	248
	Clock	P.	355
14)	Glove box	P.	344


<sup>\*1:</sup> If equipped \*2: For vehicles with a navigation system or Entune Audio Plus, refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

## Switches






(3)	Telephone switches*2P.	. 308
4	Talk switch*2	327
(5)	Vehicle-to-vehicle distance button*1	. 189
6	Cruise control switch Cruise control*1P.	
_	Cruise control*1P.	. 185
	Dynamic radar cruise control*1	. 189




<sup>\*1:</sup> If equipped

<sup>\*2:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

## Interior



$\cup$	ono alibago
2	Floor mats
3	Front seats
4	Head restraints P. 132
5	Seat belts
6	Console box
7	Inside lock buttons P. 112
8	Cup holders
9	Rear seats P. 130



<sup>\*2:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

# For safety and security


1-1.	For safe use
	Before driving 26
	For safety drive28
	Seat belts 30
	SRS airbags36
	Front passenger occupant
	classification system 49
	Safety information for
	children 55
	Child restraint systems 56
	Installing child restraints 60
	Exhaust gas precautions 68
1-2.	Hybrid system
	Hybrid system features 69
	Hybrid system
	precautions 73
1-3.	Theft deterrent system
	Immobilizer system 78
	Alarm 80

# **Before driving**


## Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

Insert the retaining hooks (clips) into the floor mat eyelets.



- 2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.
- \*: Always align the  $\triangle$  marks.



The shape of the retaining hooks (clips) may differ from that shown in the illustration.



## **WARNING**

Observe the following precautions.


Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

#### ■When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

#### Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the hybrid system stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.



## For safety drive

For safe driving, adjust the seat and mirror to an appropriate position before driving.

## **Correct driving posture**

- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P. 128)
- ② Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P. 128)



- ③ Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 132)
- 4 Wear the seat belt correctly. ( $\rightarrow$ P. 30)

#### Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.  $(\rightarrow P. 30)$ 

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.  $(\rightarrow P. 56)$ 

## Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. (→P. 136, 138)



#### **▲** WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- When driving over long distances, take regular breaks before you start to feel tired.
  - Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

## **Seat belts**

Make sure that all occupants are wearing their seat belts before driving the vehicle.


### Correct use of the seat belts

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.



## Fastening and releasing the seat belt

- To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- ② To release the seat belt, press the release button.



## Adjusting the seat belt shoulder anchor height (front seats)

- 1 Push the seat belt shoulder anchor down while pressing the release button.
- 2 Push the seat belt shoulder anchor up.


Move the height adjuster up and down as needed until you hear a click.



## Seat belt pretensioners (front seats)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal or side collision or a vehicle rollover.

The pretensioners do not activate in the event of a minor frontal impact, a minor side impact or a rear impact.



#### ■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### ■ Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more.  $(\rightarrow P. 60)$ 

#### ■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.


- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 56)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P. 30)

# ■ Replacing the belt after the pretensioner has been activated If the vehicle is involved in multiple collisions, the pretensioner will activate for

the first collision, but will not activate for the second or subsequent collisions.


#### ■ Seat belt extender

If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Toyota dealer free of charge.



#### ■ Rear seat belt

Use the seat belt after passing it through the guide if the seat belt comes free from the guide.



## **WARNING**

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

#### Wearing a seat belt


- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

#### Pregnant women

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P. 30)$ 

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



## ■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P. 30)$ 

## **WARNING**

#### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

#### ■ Seat belt pretensioners (front seats)

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Toyota dealer.

#### Adjustable shoulder anchor (front seats)

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident.  $(\rightarrow P. 31)$ 

## Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted. If the seat belt does not function correctly, immediately contact your Toyota dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling may lead to incorrect operation.
- Always make sure the shoulder belt passes through the guide when using the seat belt. Failure to properly position the belt may reduce the amount of protection in an accident and could lead to death or serious injury in a collision or sudden stop.
- Always make sure that the seat belt is not twisted, does not get caught in the guide or the seatback and is arranged in the proper position.



#### Using a seat belt extender

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.



#### NOTICE


#### When using a seat belt extender

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.

This helps prevent damage to the vehicle interior and the extender itself.

# **SRS** airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.




# SRS front airbags

- (1) SRS driver airbag/front passenger airbag Can help protect the head and chest of the driver and front passenger from impact with interior components
- ② SRS knee airbags Can help provide driver and front passenger protection

# SRS side and curtain shield airbags

- ③ SRS front side airbags Can help protect the torso of the front seat occupants
- (4) SRS rear side airbags
  Can help protect the torso of occupants in the rear outer seats
- (5) SRS curtain shield airbags
  - Can help protect primarily the head of occupants in the outer seats
  - Can help prevent the occupants from being thrown from the vehicle in the event of vehicle rollover

# SRS airbag system components



- 1) Front impact sensors
- (2) Front passenger occupant classification (ECU system and sensors)
- (3) Knee airbags
- (4) Side impact sensors (front (13) Airbag sensor assembly doors)
- (5) Side impact sensors (front)
- (6) Front passenger airbag
- (7) Front side airbags
- (8) Curtain shield airbags
- (9) Rear side airbags

- (10) "AIR BAG ON" and "AIR BAG OFF" indicator lights
- (11) SRS warning light
- (12) Front passenger's seat belt buckle switch
- (14) Side impact sensors (rear)
- (15) Driver airbag
- (16) Driver's seat belt buckle switch
- (17) Seat belt pretensioners and force limiters

Your vehicle is equipped with ADVANCED AIRBAGS designed based on the US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors etc. shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.



#### SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly.
  - The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration (NHTSA) advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- · Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, nonslippery cushion, or raise the seat if your vehicle has that feature.
- · If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

#### SRS airbag precautions

If the seat belt extender has been connected to the front seat belt buckles but the seat belt extender has not also been fastened to the latch plate of the seat belt, the SRS front airbags will judge that the driver and front passenger are wearing the seat belt even though the seat belt has not been connected. In this case, the SRS front airbags may not activate correctly in a collision, resulting in death or serious injury in the event of a collision. Be sure to wear the seat belt with the seat belt extender.



- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat.  $(\rightarrow P. 56)$




#### ■SRS airbag precautions

Do not sit on the edge of the seat or lean against the dashboard.



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not allow the front seat occupants to hold items on their knees.



Do not lean against the door, the roof side rail or the front, side and rear pillars.



Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.





#### ■SRS airbag precautions

Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.

Do not attach anything to areas such as a door, windshield, windows, front or rear pillar, roof side rail and assist grip.





• Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.



#### SRS airbag precautions

- If a vinyl cover is put on the area where the SRS knee airbag will deploy. be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components. Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillars garnishes, are damaged or cracked, have them replaced by your Toyota dealer.
- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front airbags for the front passenger may not deploy in the event of a collision.

#### ■ Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Toyota dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rails
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows, winches, or roof luggage carrier
- Modifications to the vehicle's suspension system.
- Installation of electronic devices such as mobile two-way radios and CD players
- Modifications to your vehicle for a person with a physical disability

#### ■ If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, parts of the front and rear pillars, and roof side rails, may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- For Safety Connect subscribers, if the SRS airbags deploy or in the event of a severe rear-end collision, the system is designed to send an emergency call to the response center, notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 365)

# ■ SRS airbag deployment conditions (SRS front airbags)

• The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12 -18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher in the following situations:

- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate.
- The SRS front airbags for the front passenger will not activate if there is no passenger sitting in the front passenger seat. However, the SRS front airbags for the front passenger may deploy if luggage is put in the seat, even if the seat is unoccupied.


# ■ SRS airbag deployment conditions (SRS side and curtain shield airbags)

- The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12 18 mph [20 30 km/h]).
- The SRS curtain shield airbags will deploy in the event of vehicle rollover.
- The SRS side and curtain shield airbags may also deploy in the event of a severe frontal collision.

# ■ Conditions under which the SRS airbags may deploy (inflate), other than a collision


The SRS front airbags and SRS side and curtain shield airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.

- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



The SRS curtain shield airbags may also deploy under the situations shown in the illustration.


- The angle of vehicle tip-up is marginal.
- The vehicle skids and hits a curb stone.



# ■Types of collisions that may not deploy the SRS airbags (SRS front air-bags)

The SRS front airbags do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



# ■Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a rear collision, if it rolls over, or if it is involved in a low-speed side or low-speed frontal collision.

- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it pitches end over end, or if it is involved in a low-speed side or low-speed frontal collision.


- Collision from the rear
- Pitching end over end




#### ■ When to contact your Toyota dealer

In the following cases, the vehicle will require inspection and/or repair. Contact your Toyota dealer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS front airbags to inflate.




A portion of a door or its surrounding area is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate.




The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



 The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.




The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked, or otherwise damaged.



# Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



- 1 SRS warning light
- ② Seat belt reminder light
- ③ "AIR BAG OFF" indicator light
- (4) "AIR BAG ON" indicator light

# Condition and operation in the front passenger occupant classification system

# ■ Adult\*1

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi- cator lights	"AIR BAG ON"
	SRS warning light	Off
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	
	Front passenger's seat belt pretensioner	

# ■ Child\*4

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF" or "AIR BAG ON"*4	
	SRS warning light	Off	
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>	
Devices	Front passenger airbag	Deactivated or activated*4	
	Side airbag on the front passenger seat	Activated	
	Curtain shield airbag in the front passenger side	Activated	
	Front passenger knee airbag	Deactivated or activated*4	
	Front passenger's seat belt pretensioner	Activated	

# ■ Child restraint system with infant\*5

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"* <sup>6</sup>
	SRS warning light	Off
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	- Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated

# ■ Unoccupied

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	Not illuminated
	SRS warning light	Off
	Seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Deactivated or activated*7

# ■ There is a malfunction in the system

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF"	"AIR BAG
	indicator lights	OFF"
	SRS warning light	On
	Seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seats	- Activated
	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated

<sup>\*1:</sup> The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may not recognize him/her as an adult depending on his/her physique and posture.

<sup>\*2:</sup> In the event the front passenger is wearing a seat belt.

<sup>\*3:</sup> In the event the front passenger does not wear a seat belt.

<sup>\*4:</sup> For some children, child in seat, child in booster seat or child in convertible seat, the system may not recognize him/her as a child. Factors which may affect this can be the physique or posture.

<sup>\*5:</sup> Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 56)

<sup>\*6:</sup> In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly. (→P. 60)

<sup>\*7:</sup> Activated only in cases of side impact



Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.
- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, and reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the SRS airbags for the front passenger may not activate correctly, which could cause death or serious injury in the event of a collision.
- Do not apply a heavy load to the front passenger seat or equipment (e.g. seatback pocket).
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

#### Front passenger occupant classification system precautions

- Do not recline the front passenger seatback so far that it touches the rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated, which indicates that the SRS airbags for the front passenger will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. ( $\rightarrow$ P. 60)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the front passenger occupant classification system. In this case, contact your Toyota dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

# Safety information for children

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, trunk, seats etc.



#### **WARNING**

Never leave children unattended in the vehicle, and never allow children to have or use the kev.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

# **Child restraint systems**

A child restraint system for a small child or baby must itself be properly restrained on the seat with the LATCH anchors or the lap portion of the lap/shoulder belt.

The laws of all 50 states of the U.S.A. and Canada now require the use of child restraint systems.

#### Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one on the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual.  $(\rightarrow P.~60)$ 

# Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child:

- vertible seat
- ▶ Rear facing Infant seat/con- ▶ Forward facing Convertible seat





▶ Booster seat



#### ■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. ( $\rightarrow$ P. 30)

#### Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or accident.



#### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

### ■When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.


# **Installing child restraints**

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.

Child restraint LATCH anchors  $(\rightarrow P. 61)$ 

LATCH anchors are provided for the outer rear seats. (Buttons displaying the location of the anchors are attached to the seats.)




Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts except driver's seat belt) (→P. 32)



Anchor brackets (for top tether strap) ( $\rightarrow$ P. 65)

An anchor bracket is provided for each rear seat.




# Installation with LATCH system

- 1 Widen the gap between the seat cushion and seatback slightly.
- ▶ Type A
- 2 Latch the hooks of the lower straps onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:

The symbol on a child restraint system indicates the presence of a lower connector system.




# ▶ Type B

2 Latch the buckles onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:


The symbol on a child restraint system indicates the presence of a lower connector system.




# Installing child restraints using a seat belt (child restraint lock function belt)

# ■ Rear-facing — Infant seat/convertible seat

1 Place the child restraint system on the rear seat facing the rear of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.




While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



# ■ Forward-facing — Convertible seat


1 Place the child restraint system on the seat facing the front of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.


After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



5 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. (→P. 65)

#### ■ Booster seat

Place the child restraint system on the seat facing the front of the vehicle.




2 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.



Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as low as possible.  $(\rightarrow P.~30)$ 


# Removing a child restraint installed with a seat belt

Push the buckle release button and fully retract the seat belt.




# Child restraint systems with a top tether strap

1 Secure the child restraint system using the seat belt or LATCH anchors.



Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.



#### ■ Laws and regulations pertaining to anchorages

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to SAE J1819.



#### WARNING

#### ■When installing a booster seat

To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child.  $(\rightarrow P. 32)$ 

#### ■When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.

- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat.
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint system on the front passenger seat, move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated. Failure to do so may result in death or serious injury if the airbags deploy (inflate).







# **⚠** WARNING

#### When installing a child restraint system

- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

#### Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.

#### ■ To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached. or it may cause death or serious injury to the child or other passengers in the event of a sudden braking, sudden swerve or an accident.

# **Exhaust gas precautions**

Harmful substance to the human body is included in exhaust gases if inhaled.



#### **WARNING**

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

#### Important points while driving

- Keep the trunk lid closed.
- If you smell exhaust gases in the vehicle even when the trunk lid is closed. open the windows and have the vehicle inspected at your Toyota dealer as soon as possible.

#### When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the hybrid system.
- Do not leave the vehicle with the hybrid system on for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the hybrid system running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the hybrid system is running, exhaust gases may collect and enter the vehicle.


# Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Toyota dealer.

# **Hybrid system features**

Your vehicle is a hybrid vehicle. It has characteristics different from conventional vehicles. Be sure you are closely familiar with the characteristics of your vehicle, and operate it with care.

The hybrid system combines the use of a gasoline engine and an electric motor (traction motor) according to driving conditions, improving fuel efficiency and reducing exhaust emissions.



The illustration is an example for explanation and may differ from the actual item.

- 1 Gasoline engine
- 2 Electric motor (traction motor)

# When stopped/during start off

The gasoline engine stops\*, when the vehicle is stopped. During start off, the electric motor (traction motor) drives the vehicle. At slow speeds or when traveling down a gentle slope, the engine is stopped\*, and the electric motor (traction motor) is used.

When the shift lever is in N, the hybrid battery (traction battery) is not charged. When the vehicle is stopped, always put the shift lever to P.

Also, even in heavy traffic conditions, drive the vehicle in D or B.

\* When the hybrid battery (traction battery) requires charging or the engine is warming up, etc., the gasoline engine will not automatically stop. (→P. 71)

# During normal driving

The gasoline engine is predominantly used. The electric motor (traction motor) charges the hybrid battery (traction battery) as necessary.

# When accelerating sharply

When the accelerator pedal is depressed heavily, the power of the hybrid battery (traction battery) is added to that of the gasoline engine via the electric motor (traction motor).

# When braking (regenerative braking)

The wheel operates the electric motor as a power generator, and the hybrid battery (traction battery) is charged.

# Vehicle proximity notification system

When the gasoline engine is off while driving, a sound is produced to warn pedestrians, people riding bicycles or other people and vehicles in the surrounding area that the vehicle is approaching. The pitch of the sound adjusts according to vehicle speed. When vehicle speed is approximately 16 mph (25 km/h) or more, the warning system turns off.

#### ■ Regenerative braking

In the following situations, kinetic energy is converted to electric energy and deceleration force can be obtained in conjunction with the recharging of the hybrid battery (traction battery).

- The accelerator pedal is released while driving with the shift lever in D or B.
- The brake pedal is depressed while driving with the shift lever in D or B.

#### ■ EV indicator

The EV indicator comes on when the vehicle is driven using only the electric motor (traction motor) or the gasoline engine is stopped.



#### ■ Conditions in which the gasoline engine may not stop

The gasoline engine starts and stops automatically. However, it may not stop automatically in the following conditions:

- During gasoline engine warm-up
- During hybrid battery (traction battery) charging
- When the temperature of the hybrid battery (traction battery) is high or low
- When the heater is switched on

#### ■ Charging the hybrid battery (traction battery)

As the gasoline engine charges the hybrid battery (traction battery), the battery does not need to be charged from an outside source. However, if the vehicle is left parked for a long time the hybrid battery will slowly discharge. For this reason, be sure to drive the vehicle at least once every few months for at least 30 minutes or 10 miles (16 km). If the hybrid battery becomes fully discharged and you are unable to start the hybrid system, contact your Toyota dealer.

#### ■ Charging the 12-volt battery

→P. 489

# ■ After the 12-volt battery has discharged or when the terminal has been removed and installed during exchange, etc.

The gasoline engine may not stop even if the vehicle is being driven by the hybrid battery (traction battery). If this continues for a few days, contact your Toyota dealer.

#### ■ Sounds and vibrations specific to a hybrid vehicle

There may be no engine sound or vibration even though the vehicle is able to move with the "READY" indicator is illuminated. For safety, apply the parking brake and make sure to shift the shift lever to P when parked.

The following sounds or vibrations may occur when the hybrid system is operating and are not a malfunction:

- Motor sounds may be heard from under the vehicle.
- Sounds may be heard from the hybrid battery (traction battery) behind the rear seats when the hybrid system starts or stops.
- Relay operating sounds such as a snap or soft clank will be emitted from the hybrid battery (traction battery), behind the rear seats, when the hybrid system is started or stopped.
- Sounds from the hybrid system may be heard when the trunk lid is open.
- Sounds may be heard from the transmission when the gasoline engine starts or stops, when driving at low speeds, or during idling.
- Engine sounds may be heard when accelerating sharply.
- Sounds may be heard due to regenerative braking when the brake pedal is depressed or as the accelerator pedal is released.
- Operating sounds or motor sounds that occur when the brake pedal is operated.
- Vibration may be felt when the gasoline engine starts or stops.
- Cooling fan sounds may be heard from the air intake vent beside the rear left seat.

#### ■ Vehicle proximity notification system

In the following cases, the Vehicle Proximity Notification System sound may be difficult for pedestrians, people riding bicycles or other people and vehicles in the surrounding area to hear:


- When there is a lot of noise in the vicinity
- When it is raining or during strong winds
- •When in the area surrounding the rear of the vehicle, rather than in front of the vehicle

#### ■ Maintenance, repair, recycling, and disposal

Contact your Toyota dealer regarding maintenance, repair, recycling and disposal. Do not dispose of the vehicle yourself.

## **Hybrid system precautions**

Take care when handling the hybrid system, as it is a high voltage system (about 650 V at maximum) as well as contains parts that become extremely hot when the hybrid system is operating. Obey the warning labels attached to the vehicle.




The illustration is an example for explanation and may differ from the actual item.

- (1) Air conditioning compressor
- 2 Power control unit with DC/DC converter
- (3) High voltage cables (orange)
- (4) Hybrid battery (traction battery)
- (5) Service plug
- (6) Electric motor (traction motor)
- (7) Warning label

#### Hybrid battery (traction battery) air intake vent

There is an air intake vent beside the rear left seat for the purpose of cooling the hybrid battery (traction battery). If the vent becomes blocked, the hybrid battery may overheat, leading to a reduction in hybrid battery output.




## **Emergency shut off system**

When a certain level of impact is detected by the impact sensor, the emergency shut off system blocks the high voltage current and stops the fuel pump to minimize the risk of electrocution and fuel leakage. If the emergency shut off system activates, your vehicle will not restart. To restart the hybrid system, contact your Toyota dealer.

#### Hybrid warning message

A message is automatically displayed when a malfunction occurs in the hybrid system or an improper operation is attempted.

If a warning message is shown on the multi-information display, read the message and follow the instructions. ( $\rightarrow$ P. 453)



# ■If a warning light comes on, a warning message is displayed, or the 12-volt battery is disconnected

The hybrid system may not start. In this case, try to start the system again. If the "READY" indicator does not come on, contact your Toyota dealer.

#### ■ Running out of fuel

When the vehicle has run out of fuel and the hybrid system cannot be started, refuel the vehicle with at least enough gasoline to make the low fuel level warning light (→P. 446) go off. If there is only a small amount of fuel, the hybrid system may not be able to start. (The standard amount of fuel about 3.0 gal. [11.3 L, 2.5 Imp. gal.] when the vehicle is on a level surface. This value may vary when the vehicle is on a slope. Add extra fuel when the vehicle is inclined.)

#### ■ Electromagnetic waves

- High voltage parts and cables on hybrid vehicles incorporate electromagnetic shielding, and therefore emit approximately the same amount of electromagnetic waves as conventional gasoline powered vehicles or home electronic appliances.
- Your vehicle may cause sound interference in some third party-produced radio parts.

#### ■ Hybrid battery (traction battery)


The hybrid battery (traction battery) has a limited service life. The lifespan of the hybrid battery (traction battery) can change in accordance with driving style and driving conditions.

## **WARNING**

#### High voltage precautions

This vehicle has high voltage DC and AC systems as well as a 12-volt system. DC and AC high voltage is very dangerous and can cause severe burns and electric shock that may result in death or serious injury.

- Never touch, disassemble, remove or replace the high voltage parts. cables or their connectors.
- The hybrid system will become hot after starting as the system uses high. voltage. Be careful of both the high voltage and the high temperature, and always obey the caution labels attached to the vehicle.
- Never try to open the service plug access hole located in the trunk. The service plug is used only when the vehicle is serviced and is subject to high voltage.



#### Road accident cautions

Observe the following precautions to reduce the risk of death or serious injury:

- Pull your vehicle off the road, apply the parking brake, shift the shift lever to P, and turn the hybrid system off.
- Do not touch the high voltage parts, cables and connectors.
- If electric wires are exposed inside or outside your vehicle, an electric shock may occur. Never touch exposed electric wires.
- If a fluid leak occurs, do not touch the fluid as it may be strong alkaline electrolyte from the hybrid battery (traction battery). If it comes into contact with your skin or eyes, wash it off immediately with a large amount of water or, if possible, boric acid solution. Seek immediate medical attention.
- If a fire occurs in the hybrid vehicle, leave the vehicle as soon as possible. Never use a fire extinguisher that is not meant for electric fires. Using even a small amount of water may be dangerous.
- If your vehicle needs to be towed, do so with front wheels raised. If the wheels connected to the electric motor (traction motor) are on the ground when towing, the motor may continue to generate electricity. This may cause a fire. ( $\rightarrow$ P. 440)
- Carefully inspect the ground under the vehicle. If you find that liquid has leaked onto the ground, the fuel system may have been damaged. Leave the vehicle as soon as possible.



## **WARNING**

#### Hybrid battery (traction battery)

 Never resell, hand over or modify the hybrid battery. To prevent accidents. hybrid batteries that have been removed from a disposed vehicle are collected through Toyota dealer. Do not dispose of the battery yourself.

Unless the battery is properly collected, the following may occur, resulting in death or serious injury:

- The hybrid battery may be illegally disposed of or dumped, and it is hazardous to the environment or someone may touch a high voltage part. resulting in an electric shock.
- The hybrid battery is intended to be used exclusively with your hybrid vehicle. If the hybrid battery is used outside of your vehicle or modified in any way, accidents such as electric shock, heat generation, smoke generation, an explosion and electrolyte leakage may occur.

When reselling or handing over your vehicle, the possibility of an accident is extremely high because the person receiving the vehicle may not be aware of these dangers.

• If your vehicle is disposed of without the hybrid battery having been removed, there is a danger of serious electric shock if high voltage parts, cables and their connectors are touched. In the event that your vehicle must be disposed of, the hybrid battery must be disposed of by your Toyota dealer or a qualified service shop. If the hybrid battery is not disposed of properly, it may cause electric shock that can result in death or serious injury.



#### **NOTICE**

#### Hybrid battery air intake vent

- Do not place objects that will block the air intake vent. The hybrid battery (traction battery) may overheat and be damaged.
- Clean the air intake vent regularly to prevent the hybrid battery (traction) battery) from overheating.
- Do not wet or allow foreign substances to enter the air intake vent as this may cause a short circuit and damage the hybrid battery (traction battery).
- Do not carry large amounts of water such as water cooler bottles in the vehicle. If water spills onto the hybrid battery (traction battery), the battery may be damaged. Have the vehicle inspected by your Toyota dealer.

## **Immobilizer system**


The vehicle's keys have built-in transponder chips that prevent the hybrid system from starting if a key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

The indicator light flashes after the power switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the power switch has been turned to ACCESSORY or ON mode to indicate that the system has been canceled.



#### ■ System maintenance

The vehicle has a maintenance-free type immobilizer system.

#### ■ Conditions affecting operation

Depending on the surrounding environment and conditions, the immobilizer system may not operate properly. This may prevent the hybrid system from starting. ( $\rightarrow$ P. 124)

#### ■ Certifications for the immobilizer system

▶U.S.A.

FCC ID: NI4TMIMB-3

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### ▶ Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



#### **▲** WARNING

#### Certifications for the immobilizer system

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### NOTICE

## To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

## Alarm<sup>3</sup>

#### The alarm

The alarm uses light and sound to give an alert when an intrusion is detected.

The alarm is triggered in the following situations when the alarm is set:

- A locked door or trunk is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- The hood is opened.
- Some models: The window is tapped or broken.

#### Setting the alarm system

Close the doors, trunk and hood, and lock all the doors. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.



## Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm:

- Unlock the doors or trunk. If the alarm does not stop even when the wireless remote control is operated, repeat the operation until the alarm stops.
- Turn the power switch to ACCESSORY or ON mode, or start the hybrid system. (The alarm will be deactivated or stopped after a few seconds.)

#### ■ System maintenance

The vehicle has a maintenance-free type alarm system.

#### ■ Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:

- Nobody is in the vehicle.
- The windows and moon roof are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.


#### ■ Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)

A person inside the vehicle opens a door, the trunk or hood.



 The 12-volt battery is recharged or replaced when the vehicle is locked.
 (→P. 489)



#### ■ Alarm-operated door lock

- When the alarm is operating, the doors are locked automatically to prevent intruders.
- Do not leave the key inside the vehicle when the alarm is operating, and make sure the key is not inside the vehicle when recharging or replacing the 12-volt battery.



#### NOTICE

#### ■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

Instrument cluster

2


## 2. Instrument cluster

Warning lights and	
indicators	84
Gauges and meters	88
Multi-information display	92
Energy monitor/	
consumption screen	98

## Warning lights and indicators


The warning lights and indicators on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

For the purpose of explanation, the following illustration displays all warning lights and indicators illuminated.



## Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.



<sup>\*1:</sup> These lights turn on when the power switch is turned to ON mode to indicate that a system check is being performed. They will turn off after the hybrid system is on, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

((ABS)

(→P. 445)

<sup>\*2:</sup> For U.S.A.


<sup>\*3:</sup> For Canada

<sup>\*4:</sup> If equipped

<sup>\*5:</sup> The light turns on when the system is turned off.

#### **Indicators**

The indicators inform the driver of the operating state of the vehicle's various systems.



<sup>\*1:</sup> These lights turn on when the power switch is turned to ON mode to indicate that a system check is being performed. They will turn off after the hybrid system is on, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer.

<sup>\*2:</sup> If equipped

- \*3: This light illuminates on the multi-information display.
- \*4: The light turns on when the system is off.
- \*5: The light flashes to indicate that the system is operating.
- \*6: This light illuminates on the center panel.




## **MARNING**

#### ■ If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning lights not come on when you start the hybrid system, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

## **Gauges and meters**



(1) Hybrid System Indicator

Displays hybrid system output or regeneration level (→P. 90)

(2) Multi-information display

Presents the driver with a variety of driving-related data.

Displays warning messages in case of a malfunction (→P. 453)

3 Outside temperature display

Displays the outside temperature within the range of -40°F (-40°C) to 122°F (50°C). Low outside temperature indicator comes on when the ambient temperature is 37°F (3°C) or lower.

- (4) Speedometer
- 5 Display change button
  - →P. 89
- 6 Fuel gauge
- Odometer and trip meter display
  - →P. 89
- (8) Shift position display

Displays the currently selected shift position.


→P. 168

- (9) Engine coolant temperature gauge Displays the engine coolant temperature.
- (10) Instrument panel light control button

→P. 89

#### Changing the odometer/trip meter display

Pressing the button changes the display change button display as follows.



#### Odometer

Displays the total distance the vehicle has been driven.

## ■ Trip meter A\*/trip meter B\*


Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

\*: Press and hold the display change button to reset.

#### Instrument panel light control button

The brightness of the Instrument panel lights can be adjusted.

Pressing the button will adjust brightness of the Instrument panel lights.



#### ■ The meters and display illuminate when

The power switch is in ON mode.

#### ■ The brightness of the instrument panel lights

When the tail lights are turned on, the meter's brightness will be reduced slightly unless the meter brightness level adjustment is set to the brightest setting.

If the tail lights are turned on when the surroundings are dark, the meter's brightness will reduce slightly. However, when the surroundings are bright, such as during the daytime, the meter's brightness will not be reduced even if the tail lights are turned on.

#### ■ Hybrid System Indicator

1 Charge area

Shows regenerative charging.

2 Hybrid Eco area

Shows that gasoline engine power is not being used very often.


The gasoline engine will automatically stop and restart under various conditions.

(3) Eco area

Shows that the vehicle is being driven in an Eco-friendly manner.

(4) Power area

Shows that an Eco-friendly driving range is being exceeded (during full power driving etc.)



- By keeping the indicator needle within Eco area, more Eco-friendly driving can be achieved.
- Charge area indicates regeneration\* status. Regenerated energy will be used to charge the battery.
- \*: When used in this manual, "regeneration" refers to the conversion of energy created by the movement of the vehicle into electrical energy.

#### **■** Engine speed

On hybrid vehicles, engine speed is precisely controlled in order to help improve fuel efficiency and reduce exhaust emissions etc.

There are times when the engine speed that is displayed may differ even when vehicle operation and driving conditions are the same.

#### ■ Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 16 mph [25 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)



#### ■ To prevent damage to the engine and its components

The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely.  $(\rightarrow P. 491)$ 

## **Multi-information display**


#### **Display contents**

The multi-information display presents the driver with a variety of vehicle data.

#### Menu icons

Displays the following information when an icon is selected.  $(\rightarrow P. 93)$ 

Some of the information may be displayed automatically depending on the situation.





Drive information

Select to display various drive data. (→P. 94)



Navigation system-linked display (if equipped)

Select to display the following navigation system-linked information.

- · Route guidance
- Compass display (north-up display/heading-up display)



Audio system-linked display

Select to enable selection of an audio source or track on the meter using the meter control switches.



Dynamic radar cruise control operation guide (if equipped)

Select to display operation procedures of the dynamic radar cruise control. ( $\rightarrow$ P. 189)

The tab will change to when the vehicle is in constant speed control mode. (→P. 195)

If activated, the operational status of the LDA (Lane Departure Alert) system will also be displayed. (If equipped) (→P. 202)



## Warning message display

Select to display warning messages and measures to be taken if a malfunction is detected. ( $\rightarrow$ P. 453)




## Settings display

Select to change the meter display settings.  $(\rightarrow P. 95)$ 

## ■ Operating the meter control switches

- Scroll up/down the screen and move up/down the cursor
- ② Switch menu/Displays the top screen
- ③ Press: Enters/Sets Press and hold: Resets
- 4 Returns to the previous screen



#### **Drive information**

Average fuel economy\*1, 2/Tank average fuel economy\*1/Trip average fuel economy\*1

Displays the average fuel consumption since the function was reset, the vehicle was refueled, and the hybrid system was started, respectively

Use the displayed average fuel consumption as a reference.

Current fuel economy\*1

Displays the current rate of fuel consumption

Distance to empty\*1/Trip distance\*1/Distance\*1, 2

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining, the distance driven after the hybrid system was started and the distance since the function was reset, respectively.

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the power switch off. If the vehicle is refueled without turning the power switch off, the display may not be updated.

Trip elapsed time\*<sup>1</sup>/Elapsed time\*<sup>1, 2</sup>

Displays the hybrid system was started and the elapsed time since the function was reset, respectively

◆ Trip average speed\*1/Average speed\*1, 2

Displays the hybrid system was started and the average vehicle speed since the function was reset, respectively

- Digital speedometer\*1
- Energy monitor
  - →P. 98
- Tire inflation pressure\*3
  - →P. 407

- \*1: Can be registered to Drive information 1 through 3.
- \*2: Resetting procedures:
  - Select a function to be reset using the meter control switch and then press and hold the center button to reset.
  - If there is more than one function that can be reset, check boxes will be displayed next to the functions.
- \*3: With a tire inflation pressure display function

## **Settings display**

#### ■ Changing the settings

- 1 Select using the meter control switch.
- 2 Select an item and then set it with the center button.

#### ■ Customizable items

Language

Select to change the language on the display.

Units

Select to change the unit of measure for fuel consumption.

Drive information 1 through 3

Select to select up to 2 items that will be displayed on a Drive information screen, up to 3 Drive information screens can be set.

EV indicator light

Select to activate/deactivate the EV indicator light.  $(\rightarrow P. 71)$ 

Pop-up display

Select to set the following pop-up displays, which may appear in some situations, on/off.

- · Instrument panel brightness adjustment display
- Route guidance display of the navigation system-linked system (if equipped)
- Cruise control operation display (vehicles with dynamic radar cruise control)
- Incoming call display of the hands-free phone system
- Shift position display
- Accent color

Select to change the accent colors on the screen, such as the cursor color.

Speed limit display\*

Select to set the display of speed limit information stored in the navigation system (if equipped) to on with the speed limit caution indicator (yellow) enabled, on with the speed limit caution not enabled, or off. If enabled, the speed limit caution indicator will come on if the vehicle speed exceeds the displayed speed limit.

Maintenance system (U.S.A.)
 Select to reset the message after the required maintenance is performed. (→P. 383)

Initialization

Registered or changed meter settings will be deleted or returned to their default setting.

\*: Speed limit display may not be available for some regions.

#### ■ Setting display automatic cancelation

In the following situations, a setting display in which the settings can be changed through the meter control switches will automatically be turned off.

- When a warning message appears while the setting display is displayed
- When the vehicle begins to move while the setting display is displayed

#### ■ Tire inflation pressure (vehicles with tire pressure warning system)

- It may take a few minutes to display the tire inflation pressure after the power switch is turned to ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted.
- "---" may be displayed if the tire position information cannot be determined due to unfavorable radio wave conditions.
- Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.

#### ■ Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

## **WARNING**

#### ■ The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed. For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.

#### Cautions during setting up the display

As the hybrid system needs to be operating during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



#### NOTICE


#### During setting up the display

To prevent 12-volt battery discharge, ensure that the hybrid system is operating while setting up the display features.

## **Energy monitor/consumption screen**

You can view the status of your hybrid system on the multi-information display, the Entune Audio system and/or the navigation system.

- 1 Entune Audio system or navigation system
- (2) Multi-information display




#### **Energy monitor**

▶ Entune Audio system with "CAR" button


Press the "CAR" button.

If the "Trip Information" or "Past Record" screen is displayed, touch "Energy".




- ▶ Entune Audio system or navigation system with "APPS" button
- 1 Press the "APPS" button.
- 2 Touch "Eco" on the "Apps" screen.

If the "Trip Information" or "Past Record" screen is displayed, touch "Energy".



## ■ Multi-information display

Press the meter control switches on the steering wheel several times to select the energy monitor display.



	Entune Audio system or Navigation system	Multi-information display
When the vehicle is powered by the electric motor (traction motor)	Europy Marine	* =
When the vehicle is powered by the gasoline engine	The board	*
When the vehicle is powered by both the gasoline engine and the electric motor (traction motor)	Compa Monta	

	Entune Audio system or Navigation system	Multi-information display
When the vehicle is charging the hybrid battery (traction battery)	Test Second	
		* 5
When there is no energy flow	To be board	*
Hybrid battery (traction battery) status	Low Full	Low Full

#### Fuel consumption screen

#### **■** Trip information

► Entune Audio system with "CAR" button


Press the "CAR" button. ( $\rightarrow$ P. 99)

If the "Energy Monitor" or "Past Record" screen is displayed, touch "Trip Information".

- ▶ Entune Audio system or navigation system with "APPS" button
- 1 Press "APPS". (→P. 99)
- 2 Touch "Eco" on the information screen.
- If "Energy Monitor" screen is displayed, touch "ECO".

  If "Past Record" screen is displayed, touch "Trip Information".

- Resetting the consumption data
- ② Displays the average vehicle speed since the hybrid system was started
- ③ Displays the elapsed time since the hybrid system was started



- (4) Fuel consumption in the past 15 minutes
- (5) Cruising range
- 6 Regenerated energy in the past 15 minutes
  One symbol indicates 30 Wh. Up to 5 symbols are shown.

The image is example only, and may vary slightly from actual conditions.

#### Past record

Entune Audio system with "CAR" button

Press the "CAR" button. ( $\rightarrow$ P. 99)

If the "Energy Monitor" or "Trip Information" screen is displayed, touch "Past Record"

- ► Entune Audio system or navigation system with "APPS" button
- 1 | Press "APPS". (→P. 99)
- 2 Touch "Eco" on the information screen.
- 3 If "Energy Monitor" screen is displayed, touch "ECO". If "Trip Information" screen is displayed, touch "Past Record".
- (1) Resetting the past record data
- (2) Best past fuel consumption
- (3) Average fuel consumption
- (4) Previous fuel consumption record
- (5) Updating the average fuel consumption data



CTY20BJ070US

Displays a maximum of five past record of the average fuel consumption.

The image is example only, and may vary slightly from actual conditions.

#### Resetting the consumption data

Selecting "Clear" on the "Trip Information" screen will reset the fuel consumption and the regenerated energy for the past 15 minutes. Selecting "Clear" on the "Past Record" screen will reset the past records and best past fuel consumption. Selecting "Yes" on the following screen will confirm resetting of all the data.

# Operation of each component


3-1.	Key information
	Keys106
3-2.	Opening, closing and locking the doors
	Doors 110
	Trunk 117
	Smart key system 121
3-3.	Adjusting the seats
	Front seats 128
	Rear seats 130
	Head restraints 132
3-4.	Adjusting the steering wheel and mirrors
	Steering wheel 134
	Inside rear view mirror 136
	Outside rear view
	mirrors
3-5.	Opening and closing the windows
	Power windows 140
	Moon roof 143

## Keys

## The keys


The following keys are provided with the vehicle.

- (1) Electronic keys
  - Operating the smart key system (→P. 121)
  - Operating the wireless remote control function
- 2 Mechanical keys
- 3 Key number plate



#### Wireless remote control


- 1 Locks all the doors ( $\rightarrow$ P. 110)
- ② Unlocks all the doors (→P. 110) Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.
- ③ Opens the driver's window and moon roof (if equipped)(→P. 110)\*
- (4) Opens the trunk ( $\rightarrow$ P. 117)
- $\bigcirc$  Sounds the alarm ( $\rightarrow$ P. 107)
  - \*: This setting must be customized at your Toyota dealer.



## Using the mechanical key

To take out the mechanical key, push the release button and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and reattempt to insert it.



After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. ( $\rightarrow$ P. 485)

#### ■ Panic mode

is pressed for longer than When about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.



# ■ When required to leave the vehicle's key with a parking attendant

Lock the glove box as circumstances demand. ( $\rightarrow$ P. 344)

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

# ■ If you lose your keys

New genuine keys can be made by your Toyota dealer using the other mechanical key and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.

# ■When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any button on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

# ■ Conditions affecting operation

→P. 124

#### ■ Electronic key battery depletion

- The standard battery life is 1 to 2 years.
- If the battery becomes low, an alarm will sound in the cabin when the hybrid system stops. (→P. 467)
- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P. 423)
  - The smart key system or the wireless remote control does not operate.
  - · The detection area becomes smaller.
  - The LED indicator on the key surface does not turn on.
- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field:
  - TVs
  - · Personal computers
  - · Cellular phones, cordless phones and battery chargers
  - · Recharging cellular phones or cordless phones
  - Table lamps
  - · Induction cookers

#### ■ Replacing the battery

→P. 423

### ■ Confirmation of the registered key number

The number of keys already registered to the vehicle can be confirmed. Ask your Toyota dealer for details.

## ■ If a wrong key is used

The key cylinder rotates freely to isolate inside mechanism.

#### Customization

Settings (e.g. wireless remote control system) can be changed. (Customizable features: →P. 523)

#### ■ Certification for the wireless remote control

→P. 127



#### NOTICE

#### ■ To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers, or medical electrical equipment, such as low-frequency therapy equipment.

#### Carrying the electronic key on your person

Carry the electronic key 3.9 in. (10 cm) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 3.9 in. (10 cm) of the electronic key may interfere with the key, causing the key to not function properly.

In case of a smart key system malfunction or other key-related problems

Take your vehicle with all the electronic keys provided with your vehicle to your Toyota dealer.

### ■When an electronic key is lost

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Toyota dealer immediately with all remaining electronic keys that were provided with your vehicle.

# **Doors**

# Unlocking and locking the doors from the outside


### Smart key system

Carry the electronic key to enable this function.

 Grip the driver's door handle to unlock the door. Grip the front passenger's door handle to unlock all the doors.\*

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.



- \*: The door unlock settings can be changed. (→P. 115)
- 2 Touch the lock sensor (the indentation on the side of the door handle) to lock the doors.


Check that the door is securely locked.

### Wireless remote control

- Locks all the doors
   Check that the door is securely locked.
- (2) Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Press and hold to open the driver's window and moon roof (if equipped).\* (→P. 140, 144)



<sup>\*:</sup> This setting must be customized at your Toyota dealer.

#### Operation signals

Doors:

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Driver's window and moon roof:


A buzzer sounds to indicate that the driver's window and moon roof are opening.

#### ■ Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

# ■When the door cannot be locked by the lock sensor on the side of the door handle

If the door will not lock even when the side sensor area is touched, try using your palm to touch the lock sensor.



#### ■ Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds for 5 seconds. Fully close the door to stop the buzzer, and lock the doors again.

# ■ Alarm (if equipped)

Locking the doors will set the alarm system. ( $\rightarrow$ P. 80)

# If the smart key system or the wireless remote control does not operate properly


Use the mechanical key to lock and unlock the doors. ( $\rightarrow$ P. 485)

Replace the battery with a new one if it is depleted. (→P. 423)

# Unlocking and locking the doors from the inside

#### Door lock switches


- 1 Locks all the doors
- (2) Unlocks all the doors



#### Inside lock buttons

- (1) Locks the door
- (2) Unlocks the door

The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.



## Locking the doors from the outside without a key

- 1 Move the inside lock button to the lock position.
- 2 Close the door.

The door cannot be locked if the power switch is in ACCESSORY or ON mode, or the electronic key is left inside the vehicle.

The key may not be detected correctly and the door may be locked.

### Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.

- (1) Unlock
- (2) Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.



# Automatic door locking and unlocking systems

The following functions can be set or cancelled:


Function	Operation	
Shift position linked door locking function	Shifting the shift lever out of P locks all the doors.	
Shift position linked door unlocking function	Shifting the shift lever to P unlocks all the doors.	
Speed linked door locking function	All the doors are locked when the vehicle speed is approximately 12 mph (20 km/h) or higher.	
Driver's door linked door unlocking function	All the doors are unlocked when the driver's door is opened within 10 seconds after turning the power switch off.	

# ■ Setting and canceling the functions

The automatic door locking and unlocking functions can be set or canceled on the Entune Audio system screen ( $\rightarrow$ P. 523) or by following the procedure below.

- 1 Close all the doors and turn the power switch to ON mode. (Perform step 2 within 10 seconds.)
- 2 Shift the shift lever to P or N, and press and hold the driver's door lock switch ( or or of proximately 5 seconds and then release.

The shift lever and switch positions corresponding to the desired function to be set are shown as follows.



Use the same procedure to cancel the function.

Function	Shift lever position	Driver's door lock switch position
Shift position linked door locking function		ß
Shift position linked door unlocking function	'	Ð
Speed linked door locking function	N	û
Driver's door linked door unlocking function	IV.	a

When the setting or canceling operation is complete, all doors are locked and then unlocked.

#### ■ Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1 Turn the power switch off.
- 2 When the indicator light on the key surface is not on, press and hold ? , or ((•) for approximately 5 seconds while pressing and holding

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

Multi-information display	Unlocking function	Веер
E	Holding the driver's door handle unlocks only the driver's door.	Exterior: Beeps 3 times Interior: Pings once
	Holding the front passenger's door handle unlocks all the doors.	
E	Holding either front door handle unlocks all the doors.	Exterior: Beeps twice Interior: Pings once

Vehicles with an alarm: To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds after is pressed, the doors will be locked again and the alarm will automatically be set.)

In case that the alarm is triggered, immediately stop the alarm. ( $\rightarrow$ P. 80)

■ Conditions affecting the operation of the smart key system or wireless remote control

→P. 124

#### Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features: →P. 523)

# **⚠** WARNING

#### To prevent an accident

Observe the following precautions while driving the vehicle. Failure to do so may result in a door opening and an occupant falling out. resulting in death or serious injury.

- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving. Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position.
- Set the rear door child-protector locks when children are seated in the rear seats.

### When using the wireless remote control and operating the power windows and moon roof


Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof. Also, do not allow children to operate the wireless remote control. It is possible for children and other passengers to get caught in power window and moon roof.

# Trunk

The trunk can be opened using the trunk opener, entry function, wireless remote control.

## Opening the trunk from inside the vehicle

Pull up the lever to release the trunk lid.




# Opening the trunk from outside the vehicle

# Smart key system


While carrying the electronic key, press the button on the trunk lid.

When all the doors are unlocked with the power door lock system, the trunk can be opened without carrying the electronic key.



#### Wireless remote control

Press and hold the switch.



#### ■ Operation signal

A buzzer sounds to indicate that the trunk has been opened.

#### ■ Trunk light

The trunk light turns on when the trunk is opened.


#### ■ Function to prevent the trunk being locked with the electronic key inside

- When all doors are being locked, closing the trunk lid with the electronic key left inside the trunk will sound an alarm.
  - In this case, the trunk lid can be opened by pressing the trunk release button on the trunk lid.
- Even when the spare electronic key is put in the trunk with all the doors locked, the key confinement prevention function can be activated so the trunk can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
- Even when the electronic key is put in the trunk with all the doors are locked, the key may not be detected depending on the places and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the trunk is closed. Make sure to check where the key is before closing the trunk.
- ■The key confinement prevention function cannot be activated if any one of the doors is unlocked. In this case, open the trunk using the trunk opener.

#### ■ Internal trunk release lever

The trunk lid can be opened by pushing the glow-in-the-dark lever located on the inside of the trunk lid to the side.

The lever will continue to glow for some time after the trunk lid is closed.





# **WARNING**

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### ■ Before driving

- Make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving and hit near-by objects or luggage in the trunk may be thrown out, causing an accident.
- Do not allow children to play in the trunk. If a child is accidentally locked in the trunk, they could suffer from heat exhaustion, suffocation or other injuries.
- Do not allow a child to open or close the trunk lid. Doing so may cause the trunk lid to open unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

#### Important points while driving

Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

# **⚠** WARNING


### Using the trunk

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to suddenly shut again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.
- The trunk lid may suddenly shut if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.
- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface.





 Do not attach any accessories other than genuine Toyota parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to suddenly shut again after it is opened.


# Smart key system

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. The driver should always carry the electronic key.


- Locks and unlocks the doors (→P. 110)
- $\bullet$  Opens the trunk ( $\rightarrow$ P. 117)
- Starts the hybrid system (→P. 161)

#### ■ Antenna location


- 1 Antennas outside the cabin
- (2) Antennas inside the cabin
- (3) Antenna inside the trunk
- 4 Antenna outside the trunk



#### ■ Effective range (areas within which the electronic key is detected)



The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of either of the front outside door handles. (Only the doors detecting the key can be operated.)



When starting the hybrid system or changing power switch modes

The system can be operated when the electronic key is inside the vehicle.

When opening the trunk

The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of the trunk release button.

#### ■ Alarms and warning indicators

A combination of exterior and interior alarms as well as warning messages shown on the multi-information display are used to prevent theft of the vehicle and accidents resulting from erroneous operation. Take appropriate measures in response to any warning message on the multi-information display.  $(\rightarrow P. 453)$ 

The following table describes circumstances and correction procedures when only alarms are sounded.

Alarm	Situation	Correction procedure
Exterior alarm sounds once for 5 seconds	The trunk was closed while the electronic key was still inside the trunk and all the doors were locked.	Retrieve the electronic key from the trunk and close the trunk lid.
	An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.
Interior alarm sounds continuously	The power switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the power switch was in ACCESSORY mode).	Turn the power switch off and close the driver's door.

#### ■ Battery-saving function

The battery-saving function will be activated in order to prevent the electronic key battery and the 12-volt battery from being discharged while the vehicle is not in operation for a long time.

- In the following situations, the smart key system may take some time to unlock the doors.
  - The electronic key has been left in an area of approximately 6 ft. (2 m) of the outside of the vehicle for 10 minutes or longer.
  - The smart key system has not been used for 5 days or longer.
- If the smart key system has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or the mechanical key, to unlock the doors.

#### ■ Electronic Key Battery-Saving Function

When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press twice while pressing and holding . Confirm that the electronic key indicator flashes 4 times.

While the battery-saving mode is set, the smart key system cannot be used. To cancel the function, press any of the electronic key buttons.



#### ■ Conditions affecting operation

The smart key system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart key system, wireless remote control and immobilizer system from operating properly. (Ways of coping:  $\rightarrow$ P. 485)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the electronic key is in contact with, or is covered by the following metallic objects
  - Cards to which aluminum foil is attached
  - Cigarette boxes that have aluminum foil inside
  - · Metallic wallets or bags
  - Coins
  - · Hand warmers made of metal.
  - · Media such as CDs and DVDs
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
  - · Another vehicle's electronic key or a wireless key that emits radio waves
  - Personal computers or personal digital assistants (PDAs)
  - · Digital audio players
  - · Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window
- When the electronic key is placed near a battery charger or electronic devices

#### ■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
  - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
  - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is opened.
  - The electronic key is on the instrument panel, rear package tray or floor, or in the door pockets or glove box when the hybrid system is started or power switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the hybrid system if the electronic key is near the window.
- The doors may unlock or lock if a large amount of water splashes on the door handle, such as in the rain or in a car wash, when the electronic key is within the effective range. (The doors will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock or unlock sensor while wearing gloves may prevent lock or unlock operation.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In this case, follow the following correction procedures to wash the vehicle:
  - Place the electronic key in a location 6 ft. (2 m) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
  - Set the electronic key to battery-saving mode to disable the smart key system. (→P. 123)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.

- The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again.
- If there is another electronic key in the detection area, it may take slightly longer to unlock the doors after the door handle is gripped.
- A sudden handle operation or a handle operation immediately after entering the effective range may prevent the doors from being unlocked. Touch the door unlock sensor and check that the doors are unlocked before pulling the door handle again.

#### ■ When the vehicle is not driven for extended periods

- To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.
- The smart key system can be deactivated in advance. (→P. 523)

#### ■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

#### ■ If the smart key system does not operate properly

- Locking and unlocking the doors: Use the mechanical key.  $(\rightarrow P. 485)$
- Starting the hybrid system: →P. 486

#### Customization

Settings (e. g. smart key system) can be changed. (Customizable features:  $\rightarrow$ P. 523)

# ■ If the smart key system has been deactivated in a customized setting

- Locking and unlocking the doors:
   Use the wireless remote control or mechanical key. (→P. 110, 485)
- Starting the hybrid system and changing power switch modes: →P. 486
- Stopping the hybrid system: →P. 161

#### ■ Certification for the smart key system

▶ For the U.S.A.

FCC ID: NI4TMLF10-3 FCC ID: NI4TMLF10-51 FCC ID: HYQ23AAP FCC ID: HYQ14FBA

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ▶ For Canada

#### NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



#### WARNING

### ■ Caution regarding interference with electronic devices


- People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should keep away from the smart key system antennas. ( $\rightarrow$ P. 121)
  - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Toyota dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.
- User of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.
- Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Toyota dealer for details for disabling the entry function.

# **Front seats**


# Adjustment procedure

#### Manual seat



- (1) Seat position adjustment lever
- (2) Seatback angle adjustment lever
- (3) Vertical height adjustment lever (driver's side only)

#### Power seat



- position adjustment 1 Seat switch
- (2) Seatback angle adjustment (5) Lumbar support adjustment switch
- (3) Seat cushion (front) angle adjustment switch (driver's side only)
- (4) Vertical height adjustment switch (driver's side only)
  - switch (driver's side only)

# **WARNING**

#### When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
  - Fingers or hands may become jammed in the seat mechanism.
- Make sure to leave enough space around the feet so they do not get stuck.

#### Seat adjustment


- Be careful that the seat does not hit passengers or luggage.
- To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.
  - If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
  - Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.
- Manual seat only: After adjusting the seat, make sure that the seat is locked in position.

# Rear seats

The seatback of the right side rear seat can be folded down.

# Folding down the rear seatback

Pull the seatback lever in the trunk.



# **WARNING**

#### When folding the rear seatback down

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not fold the seatback down while driving.
- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P.
- Do not allow anyone to sit on a folded seatback or in the trunk while driv-
- Do not allow children to enter the trunk.

#### ■ When returning the seat to its original position

- Ensure that the seat belt does not get caught between or behind the seats.
- If the seat belt has been released from its guide, pass the seat belt through its guide. ( $\rightarrow$ P. 32)

#### Seat adjustment

Be careful not to get hands or feet pinched between the rear console box and the rear seat when folding down the rear seatback.

#### ■ After returning the seatback to the upright position

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the seatback is securely locked by pressing it forward and rearward on the top.
- Check that the seat belts are not twisted or caught in the seatback.
- Make sure that the seat belt is passing through its guide.

# Head restraints

### Head restraints are provided for all seats.

#### Front seats


Vertical adjustment

Up

Pull the head restraint up.


(2) Down

Push the head restraint down while pressing the lock release button.



#### ■ Removing the head restraints (front seats)


Pull the head restraint up while pressing the lock release button.



## ■ Installing the head restraints (front seats)


Align the head restraint with the installation holes and push it down to the lock position.

Press and hold the lock release button when lowering the head restraint.



#### ■ Adjusting the height of the head restraints (front seats)

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



# **WARNING**

#### Head restraint precautions (front seats)


Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

# Steering wheel


# Adjustment procedure

1 Hold the steering wheel and push the lever down.




2 Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



### Horn

To sound the horn, press on or close to the mark.





# **WARNING**

#### Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

### After adjusting the steering wheel

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury. Also, the horn may not sound if the steering wheel is not securely locked.


# Inside rear view mirror

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

## Adjusting the height of rear view mirror


The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



## **Anti-glare function**

- ▶ Manual anti-glare inside rear view mirror
- Reflected light from the headlights of vehicles behind can be reduced by operating the lever.
- 1 Normal position
- (2) Anti-glare position



### Auto anti-glare inside rear view mirror

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.


Changing automatic anti-glare function mode

#### On/Off

When the automatic anti-glare function is in ON mode, the indicator illuminates.


The function will set to ON mode each time the power switch is turned to ON mode.

Pressing the button turns the function to OFF mode. (The indicator also turns off.)



### ■ To prevent sensor error (vehicles with an auto anti-glare inside rear view mirror)

To ensure that the sensors operate properly, do not touch or cover them.






### **WARNING**

Do not adjust the position of the mirror while driving. Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.


# **Outside rear view mirrors**

# Adjustment procedure

- 1 To select a mirror to adjust, press the switch.
  - (1) Left
  - 2 Right




- 2 To adjust the mirror, press the switch.
  - (1) Up
  - 2 Right
  - 3 Down
  - 4 Left



# Folding the mirrors

Push the mirror back in the direction of the vehicle's rear.



## ■ Mirror angle can be adjusted when

The power switch is in ACCESSORY or ON mode.

# ■When the mirrors are fogged up

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. ( $\rightarrow$ P. 334)



# **WARNING**

#### Important points while driving

Observe the following precautions while driving.

Failure to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

#### ■When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

#### ■When the mirror defoggers are operating


Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

# **Power windows**

## Opening and closing procedures

The power windows can be opened and closed using the switches. Operating the switch moves the windows as follows:


- (1) Closing
- ② One-touch closing (front side windows only)\*
- (3) Opening
- (4) One-touch opening (front side windows only)\*
  - \*: To stop the window partway, operate the switch in the opposite direction.



#### Window lock switch

Press the switch to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.



# ■ The power windows can be operated when

The power switch is in ON mode.

# ■ Operating the power windows after turning the hybrid system off

The power windows can be operated for approximately 45 seconds even after the power switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

# ■ Jam protection function (front door windows)

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

#### ■ When the power window does not close normally (front door windows)

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the driver's door.

- After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the power switch is turned to ON mode.
- •If the window still cannot be closed even by carrying out the operation as explained above, initialize the function by performing the following procedure.
- 1 Hold the power window switch in the one-touch closing position. Continue holding the switch for a further 6 seconds after the window has closed.
- 2 Hold the power window switch in the one-touch opening position. Continue holding the switch for a further 2 seconds after the window has opened completely.
- 3 Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning.

If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

#### Customization

Settings (e.g. key linked operation) can be changed. (Customizable features: →P. 523)



# **WARNING**

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### Closing the windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. ( $\rightarrow$ P. 140)
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- When using the wireless remote control or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also do not let a child operate window by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the power window.
- When exiting the vehicle, turn the power switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

#### ■ Jam protection function (front door windows)

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the window fully closes.

## Moon roof\*

Use the overhead switches to open and close the moon roof and tilt it up and down.


### **Opening and closing**

(1) Opens the moon roof\*

The moon roof stops slightly before the fully open position to reduce wind noise.


Press the switch again to fully open the moon roof.

- (2) Closes the moon roof\*
- \*: Lightly press either side of the moon roof switch to stop the moon roof partway.



### Tilt up and down

- 1 Tilts the moon roof up\*
- Tilts the moon roof down\*
  - \*: Lightly press either side of the moon roof switch to stop the moon roof partway.



### ■ The moon roof can be operated when

The power switch is in ON mode.

### ■ Operating the moon roof after turning the hybrid system off

The moon roof can be operated for approximately 45 seconds after the power switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

### ■ Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

#### ■ Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

#### ■ When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- 1 Stop the vehicle.
- 2 Press and hold the "CLOSE" switch.\*1

  The moon roof will close, reopen and pause for approximately 10 seconds.\*2 Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.
- 3 Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up
- 1 Stop the vehicle.
- 2 Press and hold the "UP" switch\*1 until the moon roof moves into the tilt up position and stops.
- 3 Release the "UP" switch once and then press and hold the "UP" switch again.\*1

The moon roof will pause for approximately 10 seconds in the tilt up position.\*2 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

- 4 Check to make sure that the moon roof is completely closed and then release the switch.
- \*1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
- \*2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the open/close switch in the close position or press and hold the "UP" switch. The moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

### ■ Moon roof open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the power switch is turned off and the driver's door is opened with the moon roof open.

#### Customization

Settings (e.g. key linked operation) can be changed. (Customizable features: →P. 523)

Observe the following precautions.

Failure to do so may result in death or serious injury.

### Opening the moon roof

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

### Closing the moon roof

- The driver is responsible for moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their bodies in a position where they could be caught when the moon roof is being operated.
- When using the wireless remote control or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the power switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

# 

Driving

4-1.	Before driving		
	Driving the vehicle 148		
	Cargo and luggage 155		
	Vehicle load limits 158		
	Trailer towing 159		
	Dinghy towing 160		
4-2.	-2. Driving procedures		
	Power (ignition) switch 161		
	FV drive mode		

4-3.	Operating the lights and wipers	
	Headlight switch	172
	Automatic High Beam	175
	Windshield wipers and washer	180
<b>4-4</b> .	Refueling	
	Opening the fuel tank cap	182
<b>4-5</b> .	Using the driving support systems	
	Cruise control	185
	Dynamic radar cruise control	180
	LDA (Lane Departure	103
	Alert)	202
	Rear view monitor system	208
	Driving assist systems	
	PCS (Pre-Collision	
	System)	224
	BSM (Blind Spot Monitor)	231
	The Blind Spot Monitor function	234
	The Rear Cross Traffic     Alert function	236
<b>4-6</b> .	Driving tips	
	Hybrid vehicle driving tips	239
	Winter driving tips	

## **Driving the vehicle**

The following procedures should be observed to ensure safe driving:

### Starting the hybrid system

→P. 161

### **Driving**

- 1 With the brake pedal depressed, shift the shift lever to D.  $(\rightarrow P. 168)$
- 2 Release the parking brake. (→P. 171)
- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

### **Stopping**

- 1 With the shift lever in D, depress the brake pedal.
- If necessary, set the parking brake.
  If the vehicle is to be stopped for an extended period of time, shift the shift lever to P. (→P. 168)

### Parking the vehicle

- 1 With the shift lever in D, depress the brake pedal.
- 2 Shift the shift lever to P. ( $\rightarrow$ P. 168)
- 3 Set the parking brake. (→P. 171)
- 4 Press the power switch to stop the hybrid system.
- 5 Lock the door, making sure that you have the key on your person. If parking on a hill, block the wheels as needed.

### Starting off on a steep uphill

- 1 Make sure that the parking brake is set and shift the shift lever to D.
- 2 Gently depress the accelerator pedal.
- Release the parking brake.

#### ■When starting off on an uphill

The hill-start assist control will activate. (→P. 218)

#### ■ For fuel-efficient driving

Keep in mind that hybrid vehicles are similar to conventional vehicles, and it is necessary to refrain from activities such as sudden acceleration. (→P. 239)

#### ■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

### ■ Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 186 miles (300 km): Avoid sudden stops.
- For the first 621 miles (1000 km):
  - Do not drive at extremely high speeds.
  - · Avoid sudden acceleration.
  - · Do not drive continuously in low gears.
  - · Do not drive at a constant speed for extended periods.

### ■ Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Toyota dealer perform the bedding down operation.

### ■ Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel.  $(\rightarrow P. 500)$ 



## **⚠** WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

### When starting the vehicle

Always keep your foot on the brake pedal while stopped with the "READY" indicator is illuminated. This prevents the vehicle from creeping.

### When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
  - · Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
  - · When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
  - · Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
  - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- The driver should pay extra attention to pedestrians when the vehicle is powered only by the electric motor (traction motor). As there is no engine noise, the pedestrians may misjudge the vehicle's movement.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.
- During normal driving, do not turn off the hybrid system. Turning the hybrid system off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so.
  - In the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P. 439
- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.
  - Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P. 168)
- Do not adjust the display, the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving. Doing so may result in a loss of vehicle control.
- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.

Observe the following precautions.

Failure to do so may result in death or serious injury.

### When driving the vehicle

• Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has highspeed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.

### ■When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

### When shifting the shift lever

- Do not let the vehicle roll backward while the shift lever is in a driving position, or roll forward while the shift lever is in R. Doing so may result in an accident or damage to the vehicle.
- Do not shift the shift lever to P while the vehicle is moving. Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control
- Do not shift the shift lever to D while the vehicle is moving backward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Shifting the shift lever to N while the vehicle is moving will disengage the hybrid system. Engine braking is not available when N is selected.
- Be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to any position other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

Observe the following precautions.

Failure to do so may result in death or serious injury.

### ■If you hear a squealing or scraping noise (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage may result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

### When the vehicle is stopped

- Do not depress the accelerator pedal unnecessarily. If the shift lever is in any position other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.
- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while stopped with the "READY" indicator is illuminated, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

### ■ When the vehicle is parked

Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.
- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When the vehicle is parked

- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P, stop the hybrid system and lock the vehicle.
  - Do not leave the vehicle unattended while the "READY" indicator is illuminated.
- Do not touch the exhaust pipes while the "READY" indicator is illuminated or immediately after turning the hybrid system off. Doing so may cause burns.

### When taking a nap in the vehicle

Always turn the hybrid system off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to hybrid system overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

#### When braking

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.
- If the electronically controlled brake system does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require brakina.
  - In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- The brake system consists of 2 or more individual hydraulic systems; if one of the systems fails, the other(s) will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately.



### When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain driving torque.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

#### When parking the vehicle

Always shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

### Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
  - Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

### If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally.

Information on what to do in case of a flat tire ( $\rightarrow$ P. 471)

### ■When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, hybrid transmission, etc.
- Lubricant condition for the bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

## Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load:

### Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) — (Total weight of occupants)

### Steps for Determining Correct Load Limit —


- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.
  - For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 750 (5 \times 150) = 650 \text{ lbs.})$
- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

(→P. 158)

Toyota does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

### Calculation formula for your vehicle

- 1 Cargo capacity
- ② Total load capacity (vehicle capacity weight) (→P. 498)



When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will be C lb. (kg) as follows:

$$B^{*2}$$
 lb. (kg) -  $A^{*1}$  lb. (kg) =  $C^{*3}$  lb. (kg)

- \*1: A =Weight of people
- \*2: B =Total load capacity
- \*3: C =Available cargo and luggage load

In this condition, if 3 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows:

C lb. (kg) -  $D^{*4}$  lb. (kg) =  $E^{*5}$  lb. (kg)

- \*4: D =Additional weight of people
- \*5: E =Available cargo and luggage load

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

### **MARNING**

### ■Things that must not be carried in the trunk

The following things may cause a fire if loaded in the trunk:

- Receptacles containing gasoline
- Aerosol cans

### ■Storage precautions

Observe the following precautions.

Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the trunk whenever possible.
- To prevent cargo and luggage from sliding forward during braking, do not stack anything in the enlarged trunk. Keep cargo and luggage low, as close to the floor as possible.
- Do not place cargo or luggage in or on the following locations.
  - · At the feet of the driver
  - On the front passenger or rear seats (when stacking items)
  - On the package tray
  - On the instrument panel
  - On the dashboard
  - · Tray that has no lid
- Secure all items in the occupant compartment.
- When you fold down the rear seats, long items should not be placed directly behind the front seats.
- Never allow anyone to ride in the enlarged trunk. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened.

### ■ Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

## **Vehicle load limits**

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

### ◆ Total load capacity (vehicle capacity weight): (→P. 498)

Total load capacity means the combined weight of occupants, cargo and luggage.

### Seating capacity: 5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

### Towing capacity

Toyota does not recommend towing a trailer with your vehicle.

### Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

### ■ Total load capacity and seating capacity

These details are also described on the tire and loading information label.  $(\rightarrow P. 416)$ 



#### WARNING


### Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.


# **Trailer towing**

Toyota does not recommend towing a trailer with your vehicle. Toyota also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.



# **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.





■To avoid serious damage to your vehicle

Do not tow your vehicle with four wheels on the ground.

## **Power (ignition) switch**

Performing the following operations when carrying the electronic key on your person starts the hybrid system or changes power switch modes.

### Starting the hybrid system

- 1 Check that the parking brake is set.
- 2 Check that the shift lever is in P.
- 3 Firmly depress the brake pedal.

Messages indicating how to start the hybrid system and how to turn to ACCESSORY mode will be displayed alternately on the multi-information display.

4 Press the power switch.

If the "READY" indicator turns on, the hybrid system will operate normally.

Continue depressing the brake pedal until the "READY" indicator is illuminated.

The hybrid system can be started from any power switch mode.



5 Check that the "READY" indicator is illuminated.
The vehicle will not move when the "READY" indicator is off.

### Stopping the hybrid system

- 1 Stop the vehicle completely.
- 2 Shift the shift lever to P.
- 3 Set the parking brake. ( $\rightarrow$ P. 171)
- 4 Press the power switch.

Driving-related data will be displayed on the multi-information display.

### Changing power switch modes

Modes can be changed by pressing the power switch with brake pedal released. (The mode changes each time the switch is pressed.)

#### Off\*

The emergency flashers can be used.

#### ACCESSORY mode


Some electrical components such as the audio system can be used.

A message indicating how to start the hybrid system will be displayed on the multi-information display.

#### ON mode

All electrical components can be used.

A message indicating how to start the hybrid system will be displayed on the multi-information display.



\*: If the shift lever is in a position other than P when turning off the hybrid system, the power switch will be turned to ACCESSORY mode, not to off.

# When stopping the hybrid system with the shift lever in a position other than P

If the hybrid system is stopped with the shift lever in a position other than P, a message indicating to shift the shift lever to P will be displayed on the multi-information display. At this time, the power switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

- 1 Check that the parking brake is set.
- 2 Shift the shift lever to P.
- 3 Check that "Turn Power OFF" is displayed on the multi-information display and then press the power switch once.
- 4 Check that "Turn Power OFF" on the multi-information display is turned off.

#### ■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than 20 minutes or ON mode (the hybrid system is not operating) for more than an hour with the shift lever in P, the power switch will automatically turn off. However, this function cannot entirely prevent 12-volt battery discharge. Do not leave the vehicle with the power switch in ACCESSORY or ON mode for long periods of time when the hybrid system is not operating.

#### ■ Sounds and vibrations specific to a hybrid vehicle

→P. 72

#### ■ Electronic key battery depletion

→P. 108

# ■ When the ambient temperature is low, such as during winter driving conditions

When starting the hybrid system, the flashing time of the "READY" indicator may be long. Leave the vehicle as it is until the "READY" indicator is steady on, as steady means the vehicle is able to move.

#### ■ Conditions affecting operation

→P. 124

#### ■ Notes for the entry function

→P. 125

#### ■ If the hybrid system does not start

- The immobilizer system may not have been deactivated. (→P. 78) Contact your Toyota dealer.
- Check that the shift lever is securely set in P. The hybrid system may not start if the shift lever is displaced out of P.


### ■ Steering lock

After turning the power switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the power switch again automatically cancels the steering lock.

### ■ When the steering lock cannot be released

A message informing the driver that the steering wheel is locked will be displayed on the multi-information display.

Check that the shift lever is set in P. Press the power switch while turning the steering wheel left and right.



#### ■ Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, the motor may be suspended if the hybrid system is turned on and off repeatedly in a short period of time. In this case, refrain from operating the hybrid system. After about 10 seconds, the steering lock motor will resume functioning.

■When a message requesting the smart key system be inspected is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

#### ■ If the "READY" indicator does not come on

In the event that the "READY" indicator does not come on even after performing the proper procedures for starting the vehicle, contact your Toyota dealer immediately.

### ■ If the hybrid system is malfunctioning

→P. 455

### ■ If the electronic key battery is depleted

→P. 423

#### ■ Operation of the power switch

- •When operating the power switch, one short, firm press is enough. If the switch is pressed improperly, the hybrid system may not start or the power switch mode may not change. It is not necessary to press and hold the switch.
- If attempting to restart the hybrid system immediately after turning the power switch off, the hybrid system may not start in some cases. After turning the power switch off, wait a few seconds before restarting the hybrid system.

### ■ If the smart key system has been deactivated in a customized setting

→P. 485

## **⚠** WARNING

### When starting the hybrid system

Always start the hybrid system while sitting in the driver's seat. Do not depress the accelerator pedal while starting the hybrid system under any circumstances.

Doing so may cause an accident resulting in death or serious injury.

### Caution while driving

If hybrid system failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

### ■ Stopping the hybrid system in an emergency

If you want to stop the hybrid system in an emergency while driving the vehicle, press and hold the power switch for more than 2 seconds, or press it briefly 3 times or more in succession. ( $\rightarrow$ P. 439)

However, do not touch the power switch while driving except in an emergency. Turning the hybrid system off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so.



#### NOTICE

### ■ To prevent 12-volt battery discharge

- Do not leave the power switch in ACCESSORY or ON mode for long periods of time without the hybrid system on.
- Do not stop the hybrid system when the shift lever is in a position other than P. If the hybrid system is stopped in another shift lever position, the power switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCESSORY mode, 12-volt battery discharge may occur.

### When starting the hybrid system

- Do not depress the accelerator pedal unnecessarily.
- If the hybrid system becomes difficult to start, have your vehicle checked by your Toyota dealer immediately.

### Symptoms indicating a malfunction with the power switch

If the power switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Toyota dealer immediately.

## **EV** drive mode


In EV drive mode, electric power is supplied by the hybrid battery (traction battery), and only the electric motor (traction motor) is used to drive the vehicle.

This mode allows you to drive in residential areas early in the morning and late at night, or in indoor parking lots etc. without concern for noises and gas emissions.

However, when the vehicle proximity notification system is active, the vehicle may produce sound.

#### Turns EV drive mode on/off

When EV drive mode is turned on, a message indicating the vehicle is in EV drive mode will be shown on the multi-information display. Pressing the switch when in EV drive mode will return the vehicle to normal driving (using the gasoline engine and electric motor [traction motor]).



#### ■ Situations in which EV drive mode cannot be turned on

It may not be possible to turn EV drive mode on in the following situations. If it cannot be turned on, a buzzer will sound and a message will be shown on the multi-information display.

- The temperature of the hybrid system is high. The vehicle has been left in the sun, driven on a hill, driven at high speeds, etc.
- ■The temperature of the hybrid system is low. The vehicle has been left in temperatures lower than about 32°F (0°C) for a long period of time etc.
- The gasoline engine is warming up.
- The hybrid battery (traction battery) is low.
  The remaining battery level indicated in the energy monitor on the multi-information display is low. (→P. 98)
- Vehicle speed is high.
- The accelerator pedal is depressed firmly or the vehicle is on a hill etc.
- The windshield defogger is in use.

### ■ Switching to EV drive mode when the gasoline engine is cold

If the hybrid system is started while the gasoline engine is cold, the gasoline engine will start automatically after a short period of time in order to warm up. In this case, you will become unable to switch to EV drive mode.

After the hybrid system has started and the "READY" indicator has illuminated, press the EV drive mode switch before the gasoline engine starts to switch to EV drive mode.

#### Automatic cancelation of EV drive mode

When driving in EV drive mode, the gasoline engine may automatically restart in the following situations. When EV drive mode is canceled, a buzzer will sound and the EV drive mode indicator will flash and go off.

- The hybrid battery (traction battery) becomes low. The remaining battery level indicated in the energy monitor on the multiinformation display is low. ( $\rightarrow$ P. 98)
- Vehicle speed is high.
- The accelerator pedal is depressed firmly or the vehicle is on a hill etc.

#### ■ Possible driving distance when driving in EV drive mode

EV drive mode's possible driving distance ranges from a few hundred meters to approximately 1.3 miles (2 km). However, depending on vehicle conditions, there are situations when EV drive mode cannot be used.

(The distance that is possible depends on the hybrid battery [traction battery] level and driving conditions.)

### ■ Fuel economy

The hybrid system is designed to achieve the best possible fuel economy during normal driving (using the gasoline engine and electric motor [traction motor]). Driving in EV drive mode more than necessary may lower fuel economy.




### **WARNING**

### Caution while driving

When driving in EV drive mode no engine noise is made. As such, pedestrians, people riding bicycles or other people and vehicles in the surrounding area may not be aware of the vehicle starting off or approaching them. Therefore, take extra care while driving even if the vehicle proximity notification system is active.

## **Hybrid transmission**

### Shifting the shift lever



While the power switch is in ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

## Shift position purpose

Shift position	Objective or function
Р	Parking the vehicle/starting the hybrid system
R	Reversing
N	Neutral
D	Normal driving*
В	Position for engine braking


<sup>\*:</sup> To improve fuel efficiency and reduce noises, set the shift lever in the D position for normal driving.

### Selecting Eco drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

#### Turns Eco drive mode on/off

When Eco drive mode is turned on, a message indicating the vehicle is in Eco drive mode will be shown on the multi-information display. Pressing the switch when in Eco drive mode will return the vehicle to normal driving.



#### ■ Operation of the air conditioning system in Eco drive mode

Eco drive mode controls the heating/cooling operations and fan speed of the air conditioning system to enhance fuel efficiency. (→P. 332) To improve air conditioning performance, adjust the fan speed or turn off Eco drive mode.

#### ■ If the shift lever cannot be shifted from P

→P. 484



#### WARNING

### ■When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.



#### ∧ NOTICE

### ■ Hybrid battery (traction battery) charge precaution

If the shift lever is in N, the hybrid battery (traction battery) will not be charged even when the engine is running. Therefore, if the vehicle is left with the shift lever in N for a long period of time, the hybrid battery (traction battery) will discharge, and this may result in the vehicle not being able to start.

## **Turn signal lever**

### **Operating instructions**


- 1) Right turn
- 2 Lane change to the right (move the lever partway and release it)

The right hand signals will flash 3 times.

(3) Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

(4) Left turn



### ■ Turn signals can be operated when

The power switch is in ON mode.

#### ■ If the indicator flashes faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

■If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

## ■ To discontinue flashing of the turn signals during a lane change

Operate the lever in the opposite direction.

#### Customization


The number of times the turn signals flash during a lane change can be changed. (Customizable features  $\rightarrow$ P. 529)

# Parking brake

### **Operating instructions**

To set the parking brake, fully depress the parking brake pedal with your left foot while depressing the brake pedal with your right foot.

(Depressing the pedal again releases the parking brake.)



### ■ Parking brake engaged warning buzzer

→P. 444, 455

#### **■** Usage in winter time

→P. 242



NOTICE

### ■ Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

## **Headlight switch**

### The headlights can be operated manually or automatically.


### **Operating instructions**

Turning the end of the lever turns on the lights as follows:

1 AUTO The headlights, daytime running lights and all the lights listed below turn on and off automatically.

(When the power switch is in ON mode)

The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.




- The headlights and all the lights listed above (except day-time running lights) turn on.
- 4 PRL \*1 The daytime running lights turn off.
  - **o** \*2 The daytime running lights turn on.

### Turning on the high beam headlights

1 With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

2 Pull the lever toward you and release it to flash the high beams once.



You can flash the high beams with the headlights on or off.

<sup>\*1:</sup> For U.S.A.

<sup>\*2:</sup> For Canada

### ■ Daytime running light system

Vehicles with halogen daytime running lights:

To make your vehicle more visible to other drivers, the headlight high beams turn on automatically (at a reduced intensity) whenever the hybrid system is started and the parking brake is released. Daytime running lights are not designed for use at night.

Vehicles with LED daytime running lights:

To make your vehicle more visible to other drivers, the parking lights turn on automatically (at an increased intensity) whenever the hybrid system is started and the parking brake is released. Daytime running lights are not designed for use at night.


U.S.A.: Daytime running lights can be turned off by operating the switch.

Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

### ■ Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



### ■ Automatic light off system

- When the headlights are on: The headlights and tail lights turn off 30 seconds after the power switch is turned to ACCESSORY mode or turned off and a door is opened and closed. (The lights turn off immediately if the key is pressed twice after all the doors are closed.)
- When only the tail lights are on: The tail lights turn off automatically if the power switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the power switch to ON mode, or turn the light switch off once and then back to ⇒of or €D.

If any of the doors or trunk lid is kept open, the lights automatically turn off after 20 minutes.

### ■ Light reminder buzzer (except when the light switch is in AUTO )

A buzzer sounds when the power switch is turned off or turned to ACCES-SORY mode and the driver's door is opened while the lights are turned on.

### ■ Battery-saving function

In the following conditions, the remaining lights will go off automatically after 20 minutes in order to prevent the vehicle battery from being discharged:

- The headlights and/or tail lights are on.
- The power switch is in ACCESSORY mode or turned off.

This function will be canceled in any of the following situations:

- When the power switch is turned to ON mode.
- When the light switch is operated.
- When a door or the trunk is opened or closed.

#### ■ Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features: →P. 529)



#### NOTICE

### ■To prevent 12-volt battery discharge


Do not leave the lights on longer than necessary when the hybrid system is off.

## Automatic High Beam<sup>\*</sup>

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.


### **Activating the Automatic High Beam system**

Turn the headlight switch to **AUTO** .



2 Push the lever away from you.

The Automatic High Beam indicator will come on when the headlights are turned on automatically to indicate that the system is active.



### High beam automatic turning on or off conditions

When all of the following conditions are fulfilled, high beam will be automatically turned on:

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few streetlights on the road ahead.


If any of the following conditions are fulfilled, high beam will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

### Turning the high beam on/off manually

### ■ Switching to low beam


Pull the lever to the original position.



### ■ Switching to high beam

Turn the light switch to **▮**○ .

The Automatic High Beam indicator will turn off and the high beam indicator will turn on.



### ■ The Automatic High Beam can be operated when

The power switch is in ON mode.

#### ■ Camera sensor detection information

- High beam may not be automatically turned off in the following situations:
  - When oncoming vehicles suddenly appear from a curve
  - · When the vehicle is cut in front of by another
  - When oncoming or preceding vehicles are hidden from sight due to repeated curves, road dividers or roadside trees
  - When oncoming vehicles appear from the faraway lane on wide road
  - · When oncoming or preceding vehicles have no lights
- High beam may be turned off if an oncoming vehicle that is using fog lights without using the headlights is detected.
- House lights, street lights, red traffic signals, and illuminated billboards or signs may cause the high beam to turn off.
- The following factors may affect the amount of time taken to turn high beam on or off:
  - The brightness of headlights, fog lights, and tail lights of oncoming and preceding vehicles
  - The movement and direction of oncoming and preceding vehicles
  - When a oncoming or preceding vehicle only has operational lights on one side
  - When a oncoming or preceding vehicle is a two-wheeled vehicle
  - The condition of the road (gradient, curve, condition of the road surface etc.)
  - The number of passengers and amount of luggage
- High beam may be turned on or off when unexpected by the driver.

- In the situations below, the system may not be able to correctly detect the surrounding brightness levels, and may flash or expose nearby pedestrians to the high beam. Therefore, you should consider turning the high beams on or off manually rather than relying on the Automatic High Beam system.
  - In bad weather (rain, snow, fog, sandstorms etc.)
  - The windshield is obscured by fog, mist, ice, dirt etc.
  - · The windshield is cracked or damaged.
  - · The camera sensor is deformed or dirty.
  - The camera sensor temperature is extremely high.
  - Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
  - Vehicles ahead have headlights that are either switched off, dirty, are changing color, or are not aimed properly.
  - When driving through an area of intermittently changing brightness and darkness.
  - When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.).
  - When frequently and repeatedly taking curves or driving on a winding road.
  - There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
  - The back of a vehicle ahead is highly reflective, such as a container on a truck.
  - · The vehicle's headlights are damaged or dirty.
  - The vehicle is listing or tilting, due to a flat tire, a trailer being towed etc.
  - The high beam and low beam are repeatedly being switched between in an abnormal manner.
  - The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby.

### ■ Temporarily lowering sensor sensitivity

The sensitivity of the sensor can be temporarily lowered.

- 1 Turn the power switch off while the following conditions are met.
  - The headlight switch is in AUTO .
  - The headlight switch lever is in high beam position.
- 2 Turn the power switch to ON mode.
- 3 Within 5 seconds after 2, repeat pulling the headlight switch lever to the original position then pushing it to the high beam position quickly 9 times, then leave the lever in high beam position.

Automatic High Beam (headlights) may turn on even the vehicle is stopped.

### ■ If the Automatic High Beam indicator flashes

It may indicate a malfunction in the system. Contact your Toyota dealer.

#### Customization

The Automatic High Beam can be deactivated. (Customizable features: →P. 529)



# **WARNING**

#### ■ Limitations of the Automatic High Beam

Do not rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning high beam on or off manually if necessary.




#### NOTICE

### ■ Notes when using the Automatic High Beam system

Observe the following to ensure that the Automatic High Beam functions correctly.

- Do not touch the camera sensor.
- Do not subject the camera sensor to a strong impact.
- Do not disassemble the camera sensor.
- Do not spill liquid onto the camera sensor.
- Do not apply window tinting or stickers to the camera sensor or the area of windshield near the camera sensor.



- Do not place items on the dashboard. There is a possibility that the camera sensor will mistake items reflected in the windshield for streetlights, the headlights of other vehicles, etc.
- Do not install a parking tag or any other accessories near or around the camera sensor.
- Do not overload the vehicle.
- Do not modify the vehicle.
- If the windshield needs to be replaced, contact your Toyota dealer.

# Windshield wipers and washer

# Operating the wiper lever


The wiper operation is selected by moving the lever as follows. When intermittent windshield wiper operation is selected, the wiper interval can be also adjusted.

- INT Intermittent windshield wiper operation
- 2 LO Low speed windshield wiper operation
- (3) HI High speed windshield wiper operation
- (4) MIST Temporary operation




Wiper intervals can be adjusted when intermittent operation is selected.

- (5) Increases the intermittent windshield wiper frequency
- 6 Decreases the intermittent windshield wiper frequency



# (7) Washer/wiper dual operation

Wipers will automatically operate a couple of times after the washer squirts.



#### ■ The windshield wipers and washers can be operated when

The power switch is in ON mode.

#### ■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.



#### WARNING

#### Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.



#### NOTICE

## When the windshield is dry

Do not use the wipers, as they may damage the windshield.

# ■When the washer fluid tank is empty

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### ■When a nozzle becomes blocked

In this case, contact your Toyota dealer.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

# Opening the fuel tank cap

### Perform the following steps to open the fuel tank cap:

# Before refueling the vehicle

- Close all the doors and windows, and turn the power switch off.
- Confirm the type of fuel.

#### ■ Fuel types

Unleaded gasoline (Octane rating 87 [Research Octane Number 91] or higher)



#### WARNING

#### When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel. Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle. Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

# When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.



#### NOTICE


#### Refueling

Do not spill fuel during refueling.


Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

# Opening the fuel tank cap

1 Pull up the opener to open the fuel filler door.




2 Turn the fuel tank cap slowly to remove it and hang it on the back of the fuel filler door.



# Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.





# **MARNING**

# ■When replacing the fuel tank cap


Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

# **Cruise control\***

# **Summary of functions**

Use the cruise control to maintain a set speed without depressing the accelerator pedal.

- 1 Display
- (2) Indicators
- (3) Set speed
- (4) Cruise control switch




# Setting the vehicle speed

1 Press the "ON-OFF" button to activate the cruise control.


Cruise control indicator will be displayed on the multi-information display.


Press the button again to deactivate the cruise control.



"SET" indicator and set speed will be displayed on the multi-information display.

The vehicle speed at the moment the lever is released becomes the set speed.






# Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is obtained.

- (1) Increases the speed
- (2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



The set speed will be increased or decreased as follows:

• When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

• When the set speed is shown in "km/h"

Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.


# Canceling and resuming the constant speed control

1) Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

2 Pushing the lever up resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).



#### Cruise control can be set when

- The shift lever is in D.
- Vehicle speed is above approximately 25 mph (40 km/h).

#### ■ Accelerating after setting the vehicle speed

- The vehicle can be accelerated normally. After acceleration, the set speed resumes.
- Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the lever down to set the new speed.

#### ■ Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in any of the following situations:

- Actual vehicle speed falls more than approximately 10 mph (16 km/h) below the preset vehicle speed.
  - At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 25 mph (40 km/h).
- VSC is activated.
- Enhanced VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch

# If a warning message for the cruise control is shown on the multi-information display

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Toyota dealer.

# **WARNING**

■ To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON-OFF" button when not in use.

■ Situations unsuitable for cruise control

Do not use cruise control in any of the following situations.

Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills

Vehicle speed may exceed the set speed when driving down a steep hill.


During emergency towing

# Dynamic radar cruise control\*

# **Summary of functions**

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.

- Vehicle-to-vehicle distance button
- (2) Indicators
- (3) Set speed
- (4) Display
- (5) Cruise control switch



# Setting the vehicle speed (vehicle-to-vehicle distance control mode)

1 Press the "ON-OFF" button to activate the cruise control.


Radar cruise control indicator will be displayed.


Press the button again to deactivate the cruise control.

2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator and set speed will be displayed.

The vehicle speed at the moment the lever is released becomes the set speed.






### Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

- (1) Increases the speed
- (2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

• When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated

Large adjustment: By approximately 5 mph (8 km/h) for each 0.75 seconds the lever is held

When the set speed is shown in "km/h"

Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: By approximately 3.1 mph (5 km/h) for each 0.75 seconds the lever is held

In the constant speed control mode ( $\rightarrow$ P. 195), the set speed will be increased or decreased as follows:

• When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

· When the set speed is shown in "km/h"

Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.


# Changing the vehicle-to-vehicle distance

Pressing the button changes the vehicle-to-vehicle distance as follows:

- (1) Long
- (2) Medium
- (3) Short

The vehicle-to-vehicle distance is set automatically to long mode when the power switch is turned to ON mode.

If a vehicle is running ahead of you, the preceding vehicle mark will also be displayed.



# Vehicle-to-vehicle distance settings


Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 50 mph (80 km/h). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance
Long	Approximately 160 ft. (50 m)
Medium	Approximately 130 ft. (40 m)
Short	Approximately 100 ft. (30 m)

# Canceling and resuming the speed control

- 1 Pulling the lever toward you cancels the cruise control.
  - The speed setting is also canceled when the brakes are applied.
- 2 Pushing the lever up resumes the cruise control and returns vehicle speed to the set speed.


Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).



# Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 400 ft. (120 m) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



Example of constant speed cruising
 When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

2 Example of deceleration cruising
When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

(3) Example of follow-up cruising

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

(4) Example of acceleration

When there are no longer any vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

# **Approach warning**

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

### ■ Warnings may not occur when

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

# Selecting conventional constant speed control mode


When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt etc.

1) Press the "ON-OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.

Switch to constant speed control mode.

(Push the lever forward and hold for approximately 1 second.)



Constant speed control mode indicator will come on.

When in constant speed control mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.

After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the power switch is turned off and then turned to ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting: →P. 191

Canceling and resuming the speed setting: →P. 192

#### ■ Dynamic radar cruise control can be set when

- The shift lever is in D.
- Vehicle speed is above approximately 30 mph (50 km/h).

### ■ Accelerating after setting the vehicle speed

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

#### ■ Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- Enhanced VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wiper switch is set to the high speed wiper operation position).

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Toyota dealer.

#### ■ Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situations:

•Actual vehicle speed is more than approximately 10 mph (16 km/h) below the set vehicle speed.


At this time, the memorized set speed is not retained.

- Vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- Enhanced VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch
- Pre-collision braking is activated.

#### ■ Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.) Dynamic radar cruise control is canceled if an obstruction is detected.

- (1) Grille cover
- (2) Radar sensor



#### ■ Operation guide display

When the dynamic radar cruise control switch is operated, a guidance display is shown on the multi-information display for a few seconds as to how to operate the dynamic radar cruise control switch or distance switch. (→P. 95)

■Warning messages and buzzers for dynamic radar cruise control
Warning messages and buzzers are used to indicate a system malfunction or
to inform the driver of the need for caution while driving. (→P. 457)

#### ■ Certification

▶ For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR007

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofreguency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

▶ For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

# **WARNING**

#### ■ Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

## Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Assisting the driver to measure following distance
  - The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.
- Assisting the driver to judge proper following distance The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.
- Assisting the driver to operate the vehicle The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

#### ■ To avoid inadvertent cruise control activation

Switch the cruise control off using the "ON-OFF" button when not in use.

# **MARNING**

### ■ Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- Roads where there are pedestrians, cyclers, etc.
- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients

Vehicle speed may exceed the set speed when driving down a steep hill.


- At entrances to expressways and highways
- When weather conditions are bad enough that they may prevent the sensors from detecting correctly (fog, snow, sandstorm, heavy rain, etc.)
- When an approach warning buzzer is heard often
- During emergency towing

### ■When the sensor may not be correctly detecting the vehicle ahead

In the case of the following and depending on the conditions, operate the brake pedal when deceleration of the system is insufficient or operate the accelerator pedal when acceleration is required.


As the sensor may not be able to correctly detect these types of vehicles, the approach warning ( $\rightarrow$ P. 194) will not be activated, which may lead to an accident resulting in death or serious injury.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving in the same lane
- Vehicles with small rear ends (trailers with no load on board etc.)



# **WARNING**


- Motorcycles traveling in the same lane
- When water or snow thrown up by the surrounding vehicles hinders the detecting of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the trunk, etc.)




■ Conditions under which the vehicle-to-vehicle distance control mode may not function correctly

Operate the brake pedal (or accelerator pedal operation depending on the situation) as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, which may lead to an accident resulting in death or serious injury.

When the road curves or when the lanes are narrow



When steering wheel operation or your position in the lane is unstable



When the vehicle ahead of you decelerates suddenly



# **WARNING**

#### Handling the radar sensor

Observe the following to ensure the dynamic radar cruise control system can function effectively.

Otherwise, the radar sensor may not detect correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may not work normally or malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Toyota dealer.


# LDA (Lane Departure Alert)\*

# **Summary of function**

While driving on a road that has lane markers, this system recognizes the lane markers using a camera as a sensor to alert the driver when the vehicle deviates from its lane.

If the system judges that the vehicle has deviated from its lane, it alerts the driver using a buzzer and indications on the multi-information display.

Camera sensor




# Turning the LDA system on

Press the LDA switch to activate the system.

The LDA indicator and lane lines will come on.

Press the switch again to turn the LDA system off.

The LDA system will remain on or off even if the power switch is turned to ON mode.



# Operating conditions

- When the vehicle speed is approximately 32 mph (50 km/h) or more
- When the lane width is more than approximately 8.2 ft. (2.5 m)
- When driving on a straight road or through a curve with a radius of more than approximately 328 ft. (100 m)

# Indication on the multi-information display

When the inside of both lane lines turn white:

Indicates that both right and left lane markers are recognized.

If the vehicle deviates from the lane, the lane line on the side the vehicle has deviated from will flash.  $(\rightarrow P. 453)$ 

When the inside of either lane line turns white:

Indicates that the lane marker on the white-marked side is recognized.


If the vehicle deviates from the side of a lane with recognized lane markers, the lane line will flash.  $(\rightarrow P. 453)$ 

When the inside of both lane lines are black:

Indicates that no lane markers are recognized or the LDA system is temporarily canceled.







#### ■ Temporary cancelation of the LDA system functions

If any of the following occurs, the LDA system functions will be temporarily canceled. The functions will resume after the necessary operating conditions have returned.

- The turn signal lever is operated.
- The vehicle speed deviates from the operating range of the LDA system functions.
- When the lane lines cannot be recognized while driving.
- When the lane departure warning function is activated. The lane departure warning function will not operate again for a several seconds after it has been activated, even if the vehicle leaves the lane again.

#### ■ The lane departure warning

Depending on the audio system sound level or air conditioning fan noise while the audio system or air conditioning system is in use, it may be difficult to hear the warning sound.

#### ■ After the vehicle has been parked in the sun

The LDA system may not be available and a warning message ( $\rightarrow$ P. 458) will be displayed for a while after driving has started. When the temperature in the cabin decreases and the temperature around the camera sensor ( $\rightarrow$ P. 202) becomes suitable for its operation, the functions will begin to operate.

#### ■ If there are lane markers on only one side of the vehicle

The lane departure warning will not operate for the side on which lane markers could not be recognized.

#### ■ Conditions in which the function may not operate correctly

In the following situations, the camera sensor may be unable to recognize lane markers causing the lane departure warning function to operate incorrectly. However, this does not indicate a malfunction.

- When driving through an area with no lane markers, such as a tollbooth, a crossing or before a ticket checkpoint
- When driving on a sharp curve
- When lane markers are extremely narrow or extremely wide
- When the vehicle leans to one side an unusual amount due to a heavy load or improper tire inflation pressure
- When the following distance between your vehicle and the vehicle ahead is extremely short
- When the lane markers are yellow (These may be more difficult for the system to recognize compared to white markers.)
- When the lane markers are broken, Botts' dots (raised pavement markers) or stones
- When the lane markers are on a curb etc.
- When lane markers are obscured or partially obscured by sand, dirt, etc.
- When there are shadows on the road running parallel with lane markers, or if a shadow covers the lane markers
- When driving on a particularly bright road surface, such as concrete
- When driving on a road surface that is bright due to reflected light
- When driving in a location where the light level changes rapidly, such as the entrance to or exit from a tunnel
- When sunlight or the headlights of oncoming vehicles are shining directly into the camera lens
- When driving on roads that are branching or merging
- •When driving on a road surface that is wet due to rain, previous rainfall, standing water, etc.
- When the vehicle experiences strong up-and-down motion such as when driving on an extremely rough road or on a seam in the pavement
- When headlight brightness at nighttime is reduced due to dirt on the lenses, or when the headlights are misaligned
- When driving on winding roads or roads that are uneven
- When driving on rough or unpaved roads

# ■When changing the tires

Depending on the tires used, sufficient performance may not be maintainable.

# ■ Warning messages for the LDA system

Warning messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving.  $(\rightarrow P. 457)$ 

# **MARNING**

#### ■ Before using the LDA system

Do not rely solely on the LDA system. The LDA system does not drive the vehicle automatically, nor does it reduce the amount of care you need to take. As such, the driver must always assume full responsibility for understanding his/her surroundings, for operating the steering wheel to correct the driving line, and for driving safely.

Inappropriate or negligent driving could lead to an accident.

# ■ To avoid operating the LDA by mistake

Switch the LDA system off using the LDA switch when not in use.

#### ■ Situations unsuitable for LDA system

Do not use the LDA system in any of the following situations.

Otherwise, the system may not function correctly and could result in an accident.

- When driving with tire chains, a spare tire, or similar equipment
- When there are objects or structures along the roadside that might be misinterpreted as lane markers (such as guardrails, a curb, reflector posts, etc.)
- When driving on snowy roads
- When pavement lane markers are difficult to see due to rain, snow, fog, sand, dirt, etc.
- When there are visible lines on the pavement from road repairs, or if the remains of old lane markers are still visible on the road
- When driving on a road with lane closures due to maintenance, or when driving in a temporary lane

# **↑** NOTICE


#### ■ To prevent damage to or incorrect operation of the LDA system

- Do not modify the headlights or attach stickers to the surface of the lights.
- Do not modify the suspension. If any suspension parts need to be replaced, contact Toyota dealer.
- Do not install or place anything on the hood or the grille. Also, do not install a grille guard (bull bars, kangaroo bar etc.).
- If your windshield needs repairs, contact your Toyota dealer.

#### ■ Camera sensor

Observe the following to ensure that the LDA system functions correctly.

- Keep the windshield clean at all times.
  Performance could be affected if the windshield is dirty, or if raindrops, condensation or ice are adhering to the windshield.
- Do not attach a sticker or other items to the windshield near the camera sensor.



- Do not spill liquid onto the camera sensor
- Do not attach window tinting to the windshield.
- Do not install an antenna in front of the camera lens.
- If the windshield is fogged up, use the windshield defogger to remove fog from the windshield.
  - When it is cold, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up. This will have a negative effect on the images.
- Do not scratch the camera lens, or let it get dirty. When cleaning the inside of the windshield, be careful not to get any glass cleaner etc. on the lens. Also, do not touch the lens. For lens repair, contact your Toyota dealer.
- Do not change the installation position or direction of the camera sensor or remove it. The direction of the camera sensor is precisely adjusted.
- Do not subject the camera sensor to strong impact or force, and do not disassemble the camera sensor.
- If the windshield needs to be replaced, contact your Toyota dealer.


# **Rear view monitor system**

The rear view monitor system assists the driver by displaying guide lines and an image of the view behind the vehicle while backing up, for example while parking.

The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.


The rear view image is displayed when the shift position is in R and the power switch is in ON mode.

The rear view monitor system will be deactivated when the shift lever is in any position other than R.



# Using the rear view monitor system

#### Screen description



1 Vehicle width guide lines

The line indicates a guide path when the vehicle is being backed straight up.

The displayed width is wider than the actual vehicle width.

(2) Vehicle center guide lines

These lines indicate the estimated vehicle center on the ground.

(3) Distance guide line

The line shows points approximately 1.5 ft. (0.5 m) (red) from the center of the edge of the bumper.

(4) Distance guide line

The line shows distance behind the vehicle, a point approximately 3 ft. (1 m) (blue) from the edge of the bumper.


# Rear view monitor system precautions

# ■ Area displayed on screen

The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle.

To adjust the image on the rear view monitor system screen.  $(\rightarrow P. 261)$ 


- The area displayed on the screen may vary according to vehicle orientation conditions.
- Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.
- The camera uses a special lens.
   The distance of the image that appears on the screen differs from the actual distance.



• Items which are located higher than the camera may not be displayed by the monitor.

#### ■ Rear view monitor system camera

The camera for the rear view monitor system is located above the license plate.



# Using the camera

If the camera lens becomes dirty, it cannot transmit a clear image. If water droplets, snow or mud adhere to the lens, rinse it with water and wipe with a soft cloth. If the lens is extremely dirty, wash it with a mild cleanser and rinse.

#### ■ Differences between the screen and the actual road


The distance guide lines and the vehicle width guide lines may not actually be parallel with the dividing lines of the parking space, even when they appear to be so. Be sure to check visually.

The distances between the vehicle width guide lines and the left and right dividing lines of the parking space may not be equal, even when they appear to be so. Be sure to check visually.

The distance guide lines give a distance guide for flat road surfaces. In any of the following situations, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.


# When the ground behind the vehicle slopes up sharply

The distance guide lines will appear to be closer to the vehicle than the actual distance. Because of this, objects will appear to be farther away than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.




# When the ground behind the vehicle slopes down sharply

The distance guide lines will appear to be further from the vehicle than the actual distance. Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.



# When any part of the vehicle sags

When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.




### ■ When approaching three-dimensional objects

The distance guide lines are displayed according to flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the distance guide lines. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), be careful of the following.

### Distance guidelines


Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parked at point ②. However, in reality if you back up to point ①, you will hit the truck. On the screen, it appears that ① is closest and ③ is furthest away. However, in reality, the distance to ① and ③ is the same, and ② is farther than ① and ③.



# ■ Vehicle width guide lines

Visually check the surroundings and the area behind the vehicle. In the case shown below, the truck appears to be outside of the vehicle width guide lines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the vehicle width guide lines. In reality if you back up as guided by the vehicle width guide lines, the vehicle may hit the truck.

Vehicle width guide lines



## Things you should know

## ■ If you notice any symptoms

If you notice any of the following symptoms, refer to the likely cause and the solution, and re-check.

If the symptom is not resolved by the solution, have the vehicle inspected by your Toyota dealer.

Likely cause	Solution	
☐ The image is difficult to see		
<ul> <li>The vehicle is in a dark area</li> <li>The temperature around the lens is either high or low</li> <li>The outside temperature is low</li> <li>There are water droplets on the camera</li> <li>It is raining or humid</li> <li>Foreign matter (mud etc.) is adhering to the camera</li> <li>There are scratches on the camera</li> <li>Sunlight or headlights are shining directly into the camera</li> <li>The vehicle is under fluorescent lights, sodium lights, mercury lights etc.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings. (Use the monitor again once conditions have been improved.) To adjust the image on the rear view monitor system screen. (→P. 261)	
☐ The image is blurry		
Dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera.	Rinse the camera lens with water and wipe it clean with a soft cloth. Wash with a mild soap if the dirt is stubborn.	
☐ The image is out of alignment		
The camera or surrounding area has received a strong impact.	Have the vehicle inspected by your Toyota dealer.	
☐ The fixed guide lines are very far o	ut of alignment	
<ul> <li>The vehicle is tilted (there is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.)</li> <li>The vehicle is used on an incline.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's surroundings.	
The camera position is out of alignment.	Have the vehicle inspected by your Toyota dealer.	

## **MARNING**

#### When using the rear view monitor system

The rear view monitor system is a supplemental device intended to assist the driver when backing up. When backing up, be sure to check visually behind and all around the vehicle before proceeding.

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend on the rear view monitor system entirely when backing up. The image and the position of the guide lines displayed on the screen may differ from the actual state.
  - Use caution, just as you would when backing up any vehicle.
- Be sure to back up slowly, depressing the brake pedal to control vehicle speed.
- The instructions given are only guidelines. When and how much to turn the steering wheel will vary according to traffic conditions, road surface conditions, vehicle condition, etc. when parking. It is necessary to be fully aware of this before using the rear view monitor system.
- When parking, be sure to check that the parking space will accommodate your vehicle before maneuvering into it.
- Do not use the rear view monitor system in the following cases:
  - On icy or slick road surfaces, or in snow
  - When using tire chains or the compact spare tire
  - When the trunk lid is not closed completely
  - On roads that are not flat or straight, such as curves or slopes.
- In low temperatures, the screen may darken or the image may become faint. The image could distort when the vehicle is moving, or you may become unable to see the image on the screen. Be sure to check direct visually and with the mirrors all around the vehicle before proceeding.
- If the tire sizes are changed, the position of the fixed guide lines displayed on the screen may change.
- The camera uses a special lens. The distances between objects and pedestrians that appear in the image displayed on the screen will differ from the actual distances.  $(\rightarrow P. 211)$

## **⚠** NOTICE

#### How to use the camera

- The rear view monitor system may not operate properly in the following cases.
  - If the back of the vehicle is hit, the position and mounting angle of the camera may change.
  - As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.
  - Do not strongly rub the camera lens. If the camera lens is scratched, it cannot transmit a clear image.
  - Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
  - If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
  - When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.
  - When the camera is used under fluorescent lights, sodium light or mercury light etc., the lights and the illuminated areas may appear to flicker.
- Do not expose the camera to strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by your Toyota dealer as soon as possible.

## **Driving assist systems**

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

## ECB (Electronically Controlled Brake System)

The electronically controlled system generates braking force corresponding to the brake operation

## ◆ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

#### Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

## **♦ VSC (Vehicle Stability Control)**

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

## **◆** Enhanced VSC (Enhanced Vehicle Stability Control)

Provides cooperative control of the ABS, TRAC, VSC and EPS. Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

## ◆ TRAC (Traction Control)

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

#### Hill-start assist control

Prevents the vehicle from rolling backward when starting on an incline or slippery slope

## EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

## ◆ PCS (Pre-Collision System) (if equipped)


→P. 224

## BSM (Blind Spot Monitor) (if equipped)

→P. 231

## When the TRAC/VSC/ABS systems are operating

The slip indicator light will flash while the TRAC/VSC/ABS systems are operating.




## Disabling the TRAC system

If the vehicle gets stuck in mud, dirt or snow, the TRAC system may reduce power from the hybrid system to the wheels. Pressing to turn the system off may make it easier for you to rock the vehicle in order to free it.

To turn the TRAC system off, quickly press and release .

The "TRAC OFF" and a message will be shown on the multi-information display.

Press again to turn the system back on.



#### ■ Turning off both TRAC and VSC systems

To turn the TRAC and VSC systems off, press and hold for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRAC OFF" and a message will be shown on the multi-information display\*.

Press again to turn the systems back on.

- \*: On vehicles with pre-collision system, pre-collision brake assist and pre-collision braking will also be disabled. The pre-collision system warning light will come on and the message will be shown on the multi-information display. (→P. 227)
- ■When the message is displayed on the multi-information display showing that TRAC has been disabled even if has not been pressed

TRAC and hill-start assist control cannot be operated. Contact your Toyota dealer

# ■ Sounds and vibrations caused by the ABS, brake assist, TRAC and VSC systems

Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.

- Vibrations may be felt through the vehicle body and steering.
- A motor sound may be heard after the vehicle comes to a stop.
- ■The brake pedal may pulsate slightly after the ABS is activated.
- The brake pedal may move down slightly after the ABS is activated.

## **■**ECB operating sound

ECB operating sound may be heard in the following cases, but it does not indicate that a malfunction has occurred.

- Operating sound heard from engine compartment when the brake pedal is operated.
- Motor sound of the brake system heard from the front part of the vehicle when the driver's door is opened.
- Operating sound heard from the engine compartment when one or two minutes passed after the stop of the hybrid system.

## ■ EPS operation sound

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

#### ■ Automatic reactivation of TRAC and VSC systems

After turning the TRAC and VSC systems off, the systems will be automatically re-enabled in the following situations:

- When the power switch is turned off
- If only the TRAC system is turned off, the TRAC will turn on when vehicle speed increases

If both the TRAC and VSC systems are turned off, automatic re-enabling will not occur when vehicle speed increases

#### ■ Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the hybrid system off. The EPS system should return to normal within 10 minutes.

#### Operating conditions of hill-start assist control

When the following four conditions are met, the hill-start assist control will operate:

- The shift lever is in a position other than P or N (when starting off forward/backward on an upward incline).
- The vehicle is stopped.
- The accelerator pedal is not depressed.
- The parking brake is not engaged.

### ■ Automatic system cancelation of hill-start assist control

The hill-start assist control will turn off in any of the following situations:

- The shift lever is moved to P or N.
- The accelerator pedal is depressed.
- The parking brake is engaged.
- Approximately 2 seconds elapse after the brake pedal is released.

## **MARNING**

#### ■ The ABS does not operate effectively when

- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on wet or slick roads.
- Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven surfaces

#### ■TRAC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC system is operating. Drive the vehicle carefully in conditions where stability and power may be lost.

#### ■ Hill- start assist control does not operate effectively when

- Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on steep inclines and roads covered with ice.
- Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline, as doing so may lead to an accident.

#### ■When the VSC is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

## ■ When the TRAC/VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRAC/VSC systems off unless necessary.



## **WARNING**

#### Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRAC and VSC systems will not function correctly if different tires are installed on the vehicle.

Contact your Toyota dealer for further information when replacing tires or wheels.

#### ■ Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.


## PCS (Pre-Collision System)

When the radar sensor detects possibility of a frontal collision, brakes are automatically engaged to lessen impact as well as vehicle damage.

The alert timing for the pre-collision system can be changed or turned on/off, as necessary, by operating the switch. ( $\rightarrow$ P. 225)

### Pre-collision warning

When a high possibility of a frontal collision is detected, a buzzer sounds and a message is shown on the multi-information display to urge the driver to take evasive action.



#### Pre-collision brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

## Pre-collision braking


When there is a high possibility of a frontal collision, the system warns the driver using warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed.

## Changing the pre-collision system

## ■ Changing the alert timing of the pre-collision system

Each time the PCS switch is pressed, the response to the distance changes as follows.

- (1) Far
- (2) Middle\*
- (3) Near
  - \*: Default setting




## ■ Turning off the pre-collision system

Press the PCS switch for 3 or more seconds.


The PCS warning light turns on and a message is shown on the multi-information display.

To turn on the system, press the PCS switch again. The system is set to on each time the power switch is turned to ON mode.



#### Radar sensor

The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.



#### ■ The pre-collision system is operational when

The pre-collision system is on  $(\rightarrow P. 225)$  and the following conditions are met:

- Pre-collision warning:
  - Vehicle speed is greater than approximately 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 7 mph (10 km/h).
- Pre-collision brake assist:
  - The VSC is not turned off.
  - Vehicle speed is greater than approximately 19 mph (30 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 19 mph (30 km/h).
  - · The brake pedal is depressed.
- Pre-collision braking:
  - · The VSC is not turned off.
  - Vehicle speed is greater than approximately 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than approximately 7 mph (10 km/h).

## ■ Conditions that may trigger the system even if there is no possibility of a collision

If the following obstructs the front of the sensor, the system judges that a collision may be possible and operates.

- When passing by a vehicle while making left or right turns or passing a vehicle in an opposite lane.
- When the vehicle rapidly approaches an object in front of it (such as another vehicle, toll gate, etc.)
- When climbing a steep hill, etc., and there are structures in the upper region of the road (billboards, low ceilings, street lamps, etc.)
- When driving through narrow passages or places with low ceilings (bridges, tunnels, overhead passes, etc.)
- When driving on an uneven road surface
- When metal objects are on the road surface causing level differences or protrusions in the road
- When an extreme change in vehicle height occurs
- When the radar sensor moves off position due to its surrounding area being subjected to a strong impact.
- When there is an obstacle on the side of an entrance of a curb for road (guardrails, etc.)

When the system is activated in the situations described above, there is also a possibility that the brakes will be applied with a force greater than normal.

#### Obstacles not detected

The sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

- Situations in which the pre-collision system does not function properly
  The system may not function effectively in situations such as the following:
  - On roads with sharp bends or uneven surfaces
  - If a vehicle suddenly moves in front of your vehicle, such as at an intersection
  - If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
  - In inclement weather such as heavy rain, fog, snow or sand storms
  - When your vehicle is skidding with the VSC system off
  - When an extreme change in vehicle height occurs
  - When the radar sensor moves off position due to its surrounding area being subjected to a strong impact
  - Due to greatly turning the wheel when an obstacle suddenly appears ahead

#### ■ Automatic cancelation of the pre-collision system

When a malfunction occurs due to sensor contamination, etc. that results in the sensors being unable to detect obstacles, the pre-collision system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

# ■When there is a malfunction in the system, or if the system is temporarily unavailable

The PCS warning light flashes and a warning message is shown on the multi-information display. If a warning message is shown on the multi-information display, read the message and follow the instructions. (→P. 445, 458)

#### ■ When the TRAC and VSC are turned off

- •When the TRAC and VSC operations are turned off (→P. 220), the pre-collision brake assist and pre-collision braking are also turned off. However, the alert function operates.
- The PCS warning light turns on and a warning message is shown on the multi-information display. (→P. 445, 462)

#### ■ Certification

▶ For vehicles sold in the U.S.A.

FCC ID: HYQDNMWR007

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

▶ For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.



## **WARNING**

#### ■ Limitations of the pre-collision system

It is the driver's responsibility to drive safely. The driver should be aware of the surroundings and strive for safe driving.

Do not rely on the pre-collision system instead of normal braking operations. This system does not avoid or reduce collisions in every situation.

Overly relying on the system and entrusting it with safety may cause an unexpected accident which could lead to death or serious injury.

Although the system is designed for the purpose to support in evading collisions or reducing the damage of a collision, the effect changes according to various conditions. (→P. 226) Therefore, it does not always provide the same performance. Also, the pre-collision braking does not work depending on the operating conditions of the driver. When the driver has stepped on the brake pedal and is operating the steering wheel, the system judges that the driver is taking evasive action and the automatic braking may not operate.

#### Handling the radar sensor

Observe the following to ensure the pre-collision system can function effec-

Otherwise, the system may not function correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may not work normally or malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Toyota dealer.

## **⚠** WARNING

#### Cautions regarding the assist contents of the system

By means of alarms and brake control, the pre-collision system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points.

- Assisting the driver in watching the road The pre-collision system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle's surroundings.
- Assisting the driver in making correct judgement When attempting to estimate the possibility of a collision, the only data available to the pre-collision system is that from obstacles it has detected directly in front of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation.
- Assisting the driver in taking action The pre-collision system's braking assist feature is designed to help reduce the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system by itself, without the proper operations of the driver, is not capable of automatically avoiding a collision or bringing the vehicle to a stop safely. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety of all involved.

## **BSM (Blind Spot Monitor)**\*

## **Summary of the Blind Spot Monitor**

The Blind Spot Monitor is a system that has 2 functions;


The Blind Spot Monitor function

Assists the driver in making the decision when changing lanes

The Rear Cross Traffic Alert function

Assists the driver when backing up

These functions use same sensors.



## (1) BSM main switch

Pressing the switch turns the system on or off. When the switch is set to on, the switch's indicator illuminates and the buzzer sounds. Common switch for Blind Spot Monitor function and Rear Cross Traffic Alert function.

(2) Outside rear view mirror indicators

#### Blind Spot Monitor function:

When a vehicle is detected in the blind spot, the outside rear view mirror indicator comes on while the turn signal lever is not operated and the outside rear view mirror indicator flashes while the turn signal lever is operated.

Rear Cross Traffic Alert function:

When a vehicle approaching from the right or left rear of the vehicle is detected, the outside rear view mirror indicators flash.

3 Rear Cross Traffic Alert buzzer (Rear Cross Traffic Alert function only)

When a vehicle approaching from the right or left rear of the vehicle is detected, a buzzer sounds from behind the rear seat.

#### ■ The outside rear view mirror indicators visibility

When under strong sunlight, the outside rear view mirror indicator may be difficult to see.

#### ■ Rear Cross Traffic Alert buzzer hearing

Rear Cross Traffic Alert function may be difficult to hear over loud noises such as high audio volume.

#### ■ When there is a malfunction in the Blind Spot Monitor

If a system malfunction is detected due to any of the following reasons, warning message will be displayed: (→P. 457, 458)

- There is a malfunction with the sensors
- The sensors have become dirty
- The outside temperature is extremely high or low
- The sensor voltage has become abnormal

#### ■ Certification for the Blind Spot Monitor

► For vehicles sold in the U.S.A.

FCC ID: OAYSRR2A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

Applicable law: Canada 310

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Frequency bands: 24.05-24.25 GHz Output power: less than 20 milliwatts



## **MARNING**

#### ■ Handling the radar sensor

One Blind Spot Monitor sensor is installed inside the left and right side of the vehicle rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.

 Keep the sensor and its surrounding area on the bumper clean at all times.



- Do not subject the sensor or surrounding area on the bumper to a strong impact. If the sensor moves even slightly off position, the system may malfunction and vehicles that enter the detection area may not be detected. If the sensor or surrounding area is subject to a strong impact, always have the area inspected by your Toyota dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor or surrounding area on the bumper.
- Do not modify the sensor or surrounding area on the bumper.
- Do not paint the sensor or surrounding area on the bumper.

### The Blind Spot Monitor function


The Blind Spot Monitor function uses radar sensors to detect vehicles that are traveling in an adjacent lane in the area that is not reflected in the outside rear view mirror (the blind spot), and advises the driver of the vehicles existence via the outside rear view mirror indicator.

## The Blind Spot Monitor function detection areas

The areas that vehicles can be detected in are outlined below.

The range of the detection area extends to:

- (1) Approximately 11.5 ft. (3.5 m) from the side of the vehicle
  - The first 1.6 ft. (0.5 m) from the side of the vehicle is not in the detection area
- (2) Approximately 9.8 ft. (3 m) from the rear bumper
- (3) Approximately 3.3 ft. (1 m) forward of the rear bumper



#### WARNING

## Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor function is a supplementary function which alerts the driver that a vehicle is present in the blind spot. Do not overly rely on the Blind Spot Monitor function. The function cannot judge if it is safe to change lanes, therefore over reliance could cause an accident resulting in death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

## ■ The Blind Spot Monitor function is operational when

- The BSM main switch is set to on
- Vehicle speed is greater than approximately 10 mph (16 km/h).

## ■ The Blind Spot Monitor function will detect a vehicle when

- A vehicle in an adjacent lane overtakes your vehicle.
- Another vehicle enters the detection area when it changes lanes.

# ■ Conditions under which the Blind Spot Monitor function will not detect a vehicle

The Blind Spot Monitor function is not designed to detect the following types of vehicles and/or objects:


- Small motorcycles, bicycles, pedestrians etc.\*
- Vehicles traveling in the opposite direction
- Guardrails, walls, signs, parked vehicles and similar stationary objects\*
- Following vehicles that are in the same lane\*
- Vehicles driving 2 lanes across from your vehicle\*
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

# ■ Conditions under which the Blind Spot Monitor function may not function correctly

- The Blind Spot Monitor function may not detect vehicles correctly in the following conditions:
  - During bad weather such as heavy rain, fog, snow etc.
  - When ice or mud etc. is attached to the rear bumper
  - When driving on a road surface that is wet due to rain, standing water etc.
  - When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
  - When a vehicle is in the detection area from a stop and remains in the detection area as your vehicle accelerates
  - When driving up or down consecutive steep inclines, such as hills, a dip in the road etc.
  - When multiple vehicles approach with only a small gap between each vehicle
  - When vehicle lanes are wide, and the vehicle in the next lane is too far away from your vehicle
  - When the vehicle that enters the detection area is traveling at about the same speed as your vehicle
  - When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
  - · Directly after the BSM main switch is set to on
- Instances of the Blind Spot Monitor function unnecessarily detecting a vehicle and/or object may increase under the following conditions:
  - When there is only a short distance between your vehicle and a guardrail, wall etc.
  - When there is only a short distance between your vehicle and a following vehicle
  - When vehicle lanes are narrow and a vehicle driving 2 lanes across from your vehicle enters the detection area
  - When items such as a bicycle carrier are installed on the rear of the vehicle

#### The Rear Cross Traffic Alert function

The Rear Cross Traffic Alert functions when your vehicle is in reverse. It can detect other vehicles approaching from the right or left rear of the vehicle. It uses radar sensors to alert the driver of the other vehicle's existence through flashing the outside rear view mirror indicators and sounding a buzzer.



(1) Approaching vehicles

(2) Detection areas



#### WARNING

### ■ Cautions regarding the use of the system


The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Rear Cross Traffic Alert function is only an assist and is not a replacement for careful driving. Driver must be careful when backing up, even when using Rear Cross Traffic Alert function. The driver's own visual confirmation of behind you and your vehicle is necessary and be sure there are no pedestrians, other vehicles etc. before backing up. Failure to do so could cause death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

#### The Rear Cross Traffic Alert function detection areas

The areas that vehicles can be detected in are outlined below.



To give the driver a more consistent time to react, the buzzer can alert for faster vehicles from farther away.

#### Example:

Approaching vehicle	Speed	1) Approximate alert distance
Fast	18 mph (28 km/h)	65 ft. (20 m)
Slow	5 mph (8 km/h)	18 ft. (5.5 m)

### ■ The Rear Cross Traffic Alert function is operational when

- The BSM main switch is set to on.
- The shift lever is in R.
- Vehicle speed is less than approximately 5 mph (8 km/h).
- Approaching vehicle speed is between approximately 5 mph (8 km/h) and 18 mph (28 km/h).

## ■ Conditions under which the Rear Cross Traffic Alert function will not detect a vehicle


The Rear Cross Traffic Alert function is not designed to detect the following types of vehicles and/or objects.

- Small motorcycles, bicycles, pedestrians etc.\*
- Vehicles approaching from directly behind
- Guardrails, walls, signs, parked vehicles and similar stationary objects\*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle\*
- Vehicles backing up in the parking space next to your vehicle\*
- \*: Depending on the conditions, detection of a vehicle and/or object may occur.

# ■ Conditions under which the Rear Cross Traffic Alert function may not function correctly

The Rear Cross Traffic Alert function may not detect vehicles correctly in the following conditions:

- When ice or mud etc. is attached to the rear bumper
- During bad weather such as heavy rain, fog, snow etc.
- When multiple vehicles approach continuously
- Shallow angle parking
- When a vehicle is approaching at high speed
- When parking on a steep incline, such as hills, a dip in the road etc.
- Directly after the BSM main switch is set to on
- Directly after the hybrid system is started with the BSM main switch on
- Vehicles that the sensors cannot detect because of obstacles



## Hybrid vehicle driving tips

For economical and ecological driving, pay attention to the following points:

## Using Eco drive mode

When using Eco drive mode, the torque corresponding to the accelerator pedal depression amount can be generated more smoothly than it is in normal conditions. In addition, the operation of the air conditioning system (heating/cooling) will be minimized, improving the fuel economy. ( $\rightarrow$ P. 332)

## **♦** Use of Hybrid System Indicator

The Eco-friendly driving is possible by keeping the needle of Hybrid System Indicator within Eco area. ( $\rightarrow$ P. 90)

## Shift lever operation

Shift the shift lever to D when stopped at a traffic light, or driving in heavy traffic etc. Shift the shift lever to P when parking. When using the N, there is no positive effect on fuel consumption. In the N, the gasoline engine operates but electricity cannot be generated. Also, when using the air conditioning system, etc., the hybrid battery (traction battery) power is consumed.

## Accelerator pedal/brake pedal operation

- Drive your vehicle smoothly. Avoid abrupt acceleration and deceleration. Gradual acceleration and deceleration will make more effective use of the electric motor (traction motor) without having to use gasoline engine power.
- Avoid repeated acceleration. Repeated acceleration consumes hybrid battery (traction battery) power, resulting in poor fuel consumption. Battery power can be restored by driving with the accelerator pedal slightly released.

## When braking

Make sure to operate the brakes gently and in a timely manner. A greater amount of electrical energy can be regenerated when slowing down.

## Delays

Repeated acceleration and deceleration, as well as long waits at traffic lights, will lead to bad fuel economy. Check traffic reports before leaving and avoid delays as much as possible. When driving in a traffic jam, gently release the brake pedal to allow the vehicle to move forward slightly while avoiding overuse of the accelerator pedal. Doing so can help control excessive gasoline consumption.

## Highway driving

Control and maintain the vehicle at a constant speed. Before stopping at a toll booth or similar, allow plenty of time to release the accelerator and gently apply the brakes. A greater amount of electrical energy can be regenerated when slowing down.

## Air conditioning

Use the air conditioning only when necessary. Doing so can help reduce excessive gasoline consumption.

In summer: When the ambient temperature is high, use the recirculated air mode. Doing so will help to reduce the burden on the air conditioning system and reduce fuel consumption as well.

In winter: Because the gasoline engine will not automatically cut out until it and the interior of the vehicle are warm, it will consume fuel. Also, fuel consumption can be improved by avoiding overuse of the heater.

## Checking tire inflation pressure

Make sure to check the tire inflation pressure frequently. Improper tire inflation pressure can cause poor fuel economy.

Also, as snow tires can cause large amounts of friction, their use on dry roads can lead to poor fuel economy. Use tires that are appropriate for the season.

## Luggage

Carrying heavy luggage will lead to poor fuel economy. Avoid carrying unnecessary luggage. Installing a large roof rack will also cause poor fuel economy.

## Warming up before driving

Since the gasoline engine starts up and cuts out automatically when cold, warming up the engine is unnecessary. Moreover, frequently driving short distances will cause the engine to repeatedly warm up, which can lead to excess fuel consumption.

## Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

### **Preparation for winter**

- Use fluids that are appropriate to the prevailing outside temperatures.
  - Engine oil
  - · Engine/power control unit coolant
  - Washer fluid
- Have a service technician inspect the condition of the 12-volt battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.

Ensure that all tires are the specified size and brand, and that chains match the size of the tires.

## Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen.
   Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

## When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

## When parking the vehicle

Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

## Selecting tire chains


Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each tire size.

#### Side chain:

- (1) 0.12 in. (3 mm) in diameter
- (2) 0.39 in. (10 mm) in width
- (3) 1.18 in. (30 mm) in length

#### Cross chain:

- (4) 0.16 in. (4 mm) in diameter
- (5) 0.55 in. (14 mm) in width
- (6) 0.98 in. (25 mm) in length



## Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

#### ■ Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires. Do not install tire chains on the rear tires.
- Install tire chains on front tires as tightly as possible. Retighten chains after driving 1/4 — 1/2 mile (0.5 — 1.0 km).
- Install tire chains following the instructions provided with the tire chains.

## **WARNING**

#### Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.

#### Driving with tire chains

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Vehicles with LDA (Lane Departure Alert) system: Do not use LDA (Lane Departure Alert) system.



#### NOTICE

### Repairing or replacing snow tires (vehicles with a tire pressure warning system)

Request repairs or replacement of snow tires from Toyota dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

## Fitting tire chains (vehicles with a tire pressure warning system)

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

5-1. Basic Operations			
	Audio system types	. 248	
	Audio system	. 250	
	Steering wheel audio		
	switches	. 252	
	USB port/AUX port	. 253	
	Basic audio operations	. 255	
5-2.	Setup		
	Setup menu	. 257	
	General settings	. 258	
	Audio settings	. 260	
	Display settings		
	Voice settings	. 262	
5-3.			
	system		
	Selecting the audio		
	source	. 263	
	List screen operation	. 264	
	Optimal use of the		
	multimedia system	. 266	
5-4.	Using the radio		
	Radio operation	. 267	
5-5.	Playing an audio CD and		
	MP3/WMA/AAC discs		
	CD player operation	. 269	

## 


## Audio system

<b>5-6</b> .	device	<b>3-0.</b>	Listen
	Listening to an iPod 274	4	Audio
	Listening to a USB	5-9.	Blueto
	memory device27		Using
	Using the AUX port 283	2	Phon
5-7.	Connecting Bluetooth <sup>®</sup>		Makin
	Preparations to		Receiv
	use wireless	•	Speak
	communication	3	Blueto
	Registering a Bluetooth®		mess
	audio player for the first time	7	Using
	Registering a Bluetooth®	,	whee
	phone for the first		Blueto
	time	3	settir
	Registering a Bluetooth®		Conta
	device289	9	Settin
	Connecting a Bluetooth®		What t
	device29	1 - 40	•
	Displaying a Bluetooth®	5-10	.Blueto
	device details29	3	Blueto
	Detailed Bluetooth®	5-11	.Using
	system settings 294	4	com
			Voice
			syste

5-8.	Bluetooth <sup>®</sup> Audio	
	Listening to Bluetooth®	
	Audio	295
5-9.	•	
	Using a Bluetooth®	
	Phone	296
	Making a call	298
	Receiving a call	301
	Speaking on the phone.	302
	Bluetooth® phone	
	message function	305
	Using the steering	
	wheel switches	308
	Bluetooth <sup>®</sup> phone	
	settings	309
	Contact/Call History	
	Settings	310
	What to do if	
	(Troubleshooting)	318
5-10	.Bluetooth <sup>®</sup>	
	Bluetooth <sup>®</sup>	322
5-11	.Using the voice	
	command system	
	Voice command	
	system	327


## **Audio system types**

## ► Entune Audio




## ► Entune Audio Plus

Owners of this system should refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MANUAL".



▶ Entune Premium Audio with Navigation


Owners of this system should refer to the "NAVIGATION AND MULTI-MEDIA SYSTEM OWNER'S MANUAL".



## Audio system\*

Operations such as listening to audio, using the hands-free phone and changing multimedia system settings are started by using the following buttons.

## Audio system operation buttons



- ① "AUDIO" button
  Display the "Select Audio Source" screen or audio top screen.
  (→P. 263)
- ② "CAR" button
  Press this button to access the fuel consumption screen. (→P. 101)
- (3) "SETUP" buttonPress this button to customize the function settings. (→P. 257)
- ⊕ button
   Press this button to access the Bluetooth<sup>®</sup> hands-free system.
   (→P. 296)

#### Operating the touch screen

By touching the screen with your finger, you can control the multimedia system, etc.

### ■ Drag\*

Touch the screen with your finger, and move the screen to the desired position.

Scrolling the lists

#### ■ Flick\*

Touch the screen with your finger and quickly move the screen by flicking your finger.

- Scrolling the main screen page
- \*: The above operations may not be performed on all screens.

#### ■When using the touch screen

- If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, adjust the display on the "Display Settings" screen (→P. 261) or remove your sunglasses.
- Flick operations may not be performed smoothly in high altitudes.



#### NOTICE

### ■ To avoid damaging the touch screen

- To prevent damaging the screen, lightly touch the screen buttons with your finger.
- Do not use objects other than your finger to touch the screen.
- Wipe off fingerprints using a glass cleaning cloth. Do not use chemical cleaners to clean the screen, as they may damage the touch screen.

# Steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.

Operation may differ depending on the type of multimedia system or navigation system. For details, refer to the manual provided with the multimedia system or navigation system.

# Operating the multimedia system using the steering wheel switches


- (1) Volume switch
  - · Increases/decreases volume
  - Press and hold: Continuously increases/decreases volume
- (2) Back switch
  - Returns to the previous screen
- (3) Cursor switch
  - Selects (radio stations/radio presets/tracks/files/songs)
  - Moves cursor
  - Press and hold: Seek up/down (radio stations)
  - Fast up/down (tracks/files)
- 4 Enter switch
  - · Displays the preset/list screen
  - Selects items
- (5) "MODE/HOLD" switch
  - · Changes audio source
  - Press and hold this switch to mute or pause the current operation
     To cancel the mute or pause, press and hold.



#### WARNING

#### To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.




### **USB** port/AUX port

Connect an iPod, USB memory device or portable audio player to the USB/AUX port as indicated below. Select "iPod", "USB" or "AUX" on the audio source selection screen and the device can be operated via multimedia system.


### Connecting using the USB/AUX port

#### ■ iPod

1 Push the lid.



Open the cover and connect an iPod using an iPod cable. Turn on the power of the iPod if



### ■ USB memory device

it is not turned on.

- 1 Push the lid.
- 2 Open the cover and connect the USB memory device.

  Turn on the power of the USB memory device if it is not turned on.

#### ■ Portable audio player

- 1 Push the lid.
- 2 Open the cover and connect the portable audio player.

  Turn on the power of the portable audio player if it is not turned on.



**MARNING** 


### **■**While driving

Do not connect a device or operate the device controls.

### **Basic audio operations**

Basic audio operations and functions common to each mode are explained in this section.

### Operating the multimedia system



- 1) Press: Turns the multimedia system on and off.
  - Turn: Adjusts the volume.
- 2 Ejects a disc.
- (3) Disc slot
- (4) Pauses or resumes playing music.
- (5) Turn: Selects radio station bands, tracks and files. Selects items in the list display.
- 6 Seeks up or down for a radio station. Accesses a desired track or file.

#### Random playback

Select to change on/off.

#### Repeat play

Select to change on/off.

#### ■ Using cellular phones

Interference may be heard through the multimedia system's speakers if a cellular phone is being used inside or close to the vehicle while the multimedia system is operating.

#### **WARNING**

#### Laser product

This product is a class 1 laser product.

Do not open the cover of the player or attempt to repair the unit yourself. Refer servicing to qualified personnel.

- Laser products
  - Do not take this unit apart or attempt to make any changes yourself. This is an intricate unit that uses a laser pickup to retrieve information from the surface of compact discs. The laser is carefully shielded so that its rays remain inside the cabinet. Therefore, never try to disassemble the player or alter any of its parts since you may be exposed to laser rays and dangerous voltages.
  - · This product utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. THE USE OF OPTICAL INSTRUMENTS WITH THIS PRODUCT WILL INCREASE EYE HAZARD.



#### NOTICE

#### ■ To prevent 12-volt battery discharge

Do not leave the multimedia system on longer than necessary when the hybrid system is off.

#### ■ To avoid damaging the multimedia system

Take care not to spill drinks or other fluids on the multimedia system.


### Setup menu

You can adjust the multimedia system to your desired settings.

#### Display "Setup" screen

Press the "SETUP" button to display the "Setup" screen.

- Select to adjust the settings for operation sounds, screen animation, etc. (→P. 258)
- ② Select to set the voice settings.(→P. 262)
- ③ Select to adjust the settings for contrast and brightness of the screen. (→P. 261)




- (4) Select to adjust the settings for registering, removing, connecting and disconnecting Bluetooth<sup>®</sup> devices. (→P. 294)
- (5) Select to adjust the settings for phone sound, contact, etc.(→P. 310)
- ⑥ Select to set audio settings. (→P. 260)
- (7) Select to turn the screen off.
- (8) Select to set the vehicle custmization (→P. 523).

### **General settings**

Settings are available for adjusting the operation sounds, screen animation, etc.

#### Screen for general settings

- 1 Press the "SETUP" button.
- 2 Select "General" on the "Setup" screen.
  - (1) Select to adjust the clock.
  - (2) "English", "Français" or "Español" can be selected.
  - 3 On/off can be selected to sound beeps.
  - 4 Select to change the screen color.
  - (5) Select to change the keyboard layout.



- (6) The animation effect for the screen can be set to on/off.
- (7) Select to delete personal data (→P. 259)
- (8) Select to update program versions. For details, contact your Toyota dealer.
- (9) Select to display the software information. Notices related to third party software used in this product are enlisted. (This includes instructions for obtaining such software, where applicable.)

#### ■ To return to the default volume settings

Select "Default", and then "Yes".

#### Delete personal data

- 1 Select "Delete Personal Data" on the "General Settings" screen.
- 2 Select "Delete".

Check carefully beforehand, as data cannot be retrieved once deleted.

3 A confirmation screen will be displayed. Select "Yes".

The following personal data will be deleted or changed to its default settings.

- · General settings
- · Audio settings
- Phone settings

### **Audio settings**

Settings are available for adjusting the radio operation, cover art, etc.

#### Screen for audio settings

- 1 Press the "SETUP" button.
- 2 Select "Audio" on the "Setup" screen.
  - 1 Number of Radio Presets Select the number of radio preset stations.
  - (2) Display Cover Art on/off
  - (3) Automatic Sound Levelizer(→P. 260)



#### **Automatic sound leveliser (ASL)**

- 1 Select "Automatic Sound Levelizer".
- 2 Select "High", "Mid", "Low" or "Off".

#### ■ About Automatic Sound Leveliser (ASL)

ASL automatically adjusts the volume and tone quality according to the vehicle speed.

# **Display settings**

Settings are available for adjusting the contrast and brightness of the screen.

#### Screen for display settings

- 1 Press the "SETUP" button.
- 2 Select "Display" on the "Setup" screen.
  - 1 Adjust screen contrast/brightness
  - (2) Adjust screen contrast/brightness of the rear view monitor camera
  - (3) Changes to day mode.



#### CTHDAAK013USa

#### Adjusting the screen contrast/brightness

- 1 Select "General" on the "Display Settings" screen.
- 2 Adjust the display as desired by selecting "+" or "-".

### Day mode

When the headlights are turned on, the screen dims.

However, the screen can be switched to day mode by selecting "Day Mode".

The screen will stay in day mode when the headlights are turned on until "Day Mode" is selected again.

# Voice settings

# This screen is used for guidance for voice command systems setting.

- 1 Adjust the voice guidance volume setting.
- 2 Set the voice recognition prompts "High", "Low" or "Off".
- (3) Set the train voice recognition.
- 4 Set the voice prompt interrupt on/off.
- (5) Set the voice recognition tutorial.



#### ■ To return to the default volume settings Select "Default", and then "Yes".

### Selecting the audio source

Switching between audio sources such as radio and CD are explained in this section.

#### Changing audio source

1 Press the "AUDIO" button to display the audio source selection screen.

If the audio source selection screen is not displayed, press the "AUDIO" button again.

- 2 Select the desired audio source.
  - ① Select the desired audio source then or to reorder.



CTHDAAK015US

### Using the steering wheel switches to change audio source

The audio source changes as follows each time the "MODE/HOLD" switch is pressed.

### List screen operation

When a list screen is displayed, use the appropriate buttons to scroll through the list.

#### How to scroll

- Select to scroll to the next or previous page.
- itles, the complete titles are too long for the display. Select this button to scroll the title.

Turn the "TUNE/SCROLL" knob to move the cursor box to select a desired item from the list, and press the "TUNE/SCROLL" knob to play it. The track that is being played is highlighted.



To return to the top screen, select "Now Playing" on the list screen.

### Selecting, fast-forwarding and reversing tracks/files/songs

#### ■ Selecting a track/file/song

Press the "\" or "\" button on "SEEK/TRACK" or turn the "TUNE/ SCROLL" knob to select the desired track/file/song number.

To fast-forward or reverse, press and hold the " $\wedge$ " or " $\vee$ " button on "SEEK/TRACK".

#### ■ Selecting a track/file/song from the track/file/song list

- 1 Select "Browse" or cover art.
- Select the desired track/file/song.



When an MP3/WMA/AAC disc or USB memory device is being used, the folder can be selected. When a Bluetooth<sup>®</sup> device or iPod is being used, the album can be selected.

According to the audio device, the following is displayed.

Audio source	List name
Audio CD	Track
MP3/WMA/AAC disc	Folder, File
Bluetooth <sup>®</sup>	Album, Track
USB	Artists, Albums, Songs, Genres, Composers
iPod	Artists, Albums, Songs, Genres, Composers, Audiobooks, Videos

### Optimal use of the multimedia system

On the "Sound Settings" screen, sound quality (Treble/Mid/ Bass), volume balance can be adjusted.

### How to adjust the sound settings and sound quality

- (1)(2)(3) Select "-" or "+" to adjust the treble, mid or bass to a level between -5 and 5.
- (4)(5) Select "Front" or "Rear" to adjust the front/rear audio balance.
- (6)(7) Select "L" or "R" to adjust the left/right audio balance.



#### ■ The sound quality level is adjusted individually

The treble, mid and bass levels can be adjusted for each audio mode separately.

### **Radio operation**

Select "AM" or "FM" on the audio source selection screen to begin listening to the radio.

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1 Audio source selection screen appears
- (2) Preset stations
- (3) Scanning for receivable station
- (4) Select to display a list of receivable stations
- (5) Setting the sound ( $\rightarrow$ P. 266)



#### Selecting a station

Tune in to the desired station using one of the following methods.

#### Seek tuning

Press the "\" or "\" button on "SEEK/TRACK".

The radio will begin seeking up or down for a station of the nearest frequency and will stop when a station is found.

#### ■ Manual tuning

Turn the "TUNE/SCROLL" knob.

#### Preset stations

Select the desired preset station.

#### **Setting station presets**

- Search for desired stations by turning the "TUNE/SCROLL" knob or pressing the "∧" or "∨" button on "SEEK/TRACK".
- 2 Select "(add new)".

To change the preset station to a different one, select and hold the preset station.

- 3 Select "Yes".
- 4 Select "OK" after setting the new preset station.

#### ■ Refreshing the station list

1 Select "Refresh" on the "Station List" screen.

To cancel the refresh, select "Cancel Refresh".

#### ■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

### **CD** player operation

Insert disc or select "CD" on the audio source selection screen with a disc inserted to begin listening to a CD.

#### **Audio control screen**

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- Audio source selection screen appears
- (2) Displaying the track/file list
- (3) Random playback (→P. 255)
- ④ Repeat play (→P. 255)
- 5 PauseSelect to resume play
- $\bigcirc$  Setting the sound ( $\rightarrow$ P. 266)



CTHDAAK019US

#### ■ Displaying the title and artist name

If a CD-TEXT disc is inserted, the title of the disc and track will be displayed.

#### **■** Error messages

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to your Toyota dealer.

Message	Cause	Correction procedures
"Check DISC"	<ul> <li>The disc is dirty or damaged.</li> <li>The disc is inserted upside down.</li> <li>The disc is not playable with the player.</li> </ul>	<ul> <li>Clean the disc.</li> <li>Insert the disc correctly.</li> <li>Confirm the disc is playable with the player.</li> </ul>
"Disc Error"	There is a malfunction within the system.	Eject the disc.
"No music files found."	No playable data is included on the disc.	Eject the disc.

#### ■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.









CDs with copy-protection features may not play correctly.

#### ■ CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

#### If a disc is left inside the CD player or in the ejected position for extended periods

Disc may be damaged and may not play properly.

#### Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

#### ■ MP3, WMA and AAC files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

#### MP3 file compatibility

- Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
- Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz) MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
- Compatible bit rates (compatible with VBR) MPEG1 LAYER3: 32-320 (kbps) MPEG2 LSF LAYER3: 8-160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural

#### WMA file compatibility

- · Compatible standards
  - WMA Ver. 7, 8, 9
- · Compatible sampling frequencies
  - 32, 44.1, 48 (kHz)
- Compatible bit rates (only compatible with 2-channel playback)
  - Ver. 7, 8: CBR 48-192 (kbps)
  - Ver. 9: CBR 48-320 (kbps)
- AAC file compatibility
  - Compatible standards MPEG4/AAC-LC
  - Compatible sampling frequencies
    - 11.025/12/16/22.05/24/32/44.1/48 (kHz)
  - Compatible bit rates 16-320 (kbps)

Compatible channel modes: 1ch and 2ch

Compatible media

Media that can be used for MP3, WMA and AAC playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2
  - CD-ROM XA Mode 2, Form 1 and Form 2
- File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet) UDF (2.01 or lower)

MP3, WMA and AAC files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- Maximum directory hierarchy: 8 levels (including the root)
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255
- File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, .wma or .m4a.

Discs containing multi-session recordings

As the multimedia system is compatible with multi session discs, it is possible to play discs that contain MP3, WMA and AAC files. However, only the first session can be played.

#### ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### MP3, WMA and AAC playback

When a disc containing MP3, WMA or AAC files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3, WMA or AAC file is played. To make the file check finish more quickly, we recommend you do not write any files to the disc other than MP3, WMA or AAC files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3, WMA or AAC format data cannot be played.

#### Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they may be mistakenly recognized and played as MP3, WMA and AAC files. This may result in large amounts of interference and damage to the speakers.

#### Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3, WMA or AAC files are recorded on a disc, it
  may take more time to recognize the disc and in some cases, playback
  may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.




#### **NOTICE**

#### ■ Discs and adapters that cannot be used

Do not use the following types of CDs.

Also, do not use 3 in. (8 cm) CD adapters, Dual Discs or printable discs. Doing so may damage the CD player and/or the CD insert/eject function.



- Discs that have a diameter that is not 4.7 in. (12 cm).
- Low-quality or deformed discs.
- Discs with a transparent or translucent recording area.
- Discs that have tape, stickers or CD-R labels attached to them, or that have had the label peeled off.

#### ■ Player precautions

Failure to follow the precautions below may result in damage to the discs or the player itself.

- Do not insert anything other than discs into the disc slot.
- Do not apply oil to the player.
- Store discs away from direct sunlight.
- Never try to disassemble any part of the player.

### Listening to an iPod

Connecting an iPod enables you to enjoy music from the vehicle speakers.

Select "iPod" on the audio source selection screen.

When the iPod connected to the system includes iPod video, the system can only output the sound by selecting the browse screen.

#### Connecting an iPod

→P. 253

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1 Audio source selection screen appears
- (2) Displays cover art
- ③ Selecting the play mode (→P. 274)
- (4) Shuffle play (→P. 274)
- (5) Repeat play (→P. 274)
- 6 PauseSelect to resume playback
- (7) Setting the sound ( $\rightarrow$ P. 266)



#### Selecting a play mode

- 1 Select "Browse" on the screen.
- 2 Select the desired play mode. Then select a song to begin using the selected play mode.

#### Shuffle play

Select to change on/off.

### Repeat play

Select to change on/off.

#### ■ About iPod



- "Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.
- •iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Lightning is a trademark of Apple Inc.

#### ■ iPod cover art

- Depending on the iPod and songs in the iPod, iPod cover art may be displayed.
- This function can be changed to on/off. ( $\rightarrow$ P. 260)
- It may take time to display iPod cover art, and the iPod may not be operated while the cover art display is in process.
- Only iPod cover art that is saved in JPEG format can be displayed.

#### ■ iPod functions

- •When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. If a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- •While connected to the system, the iPod cannot be operated with its own controls. It is necessary to use the controls of the vehicle's multimedia system instead.
- When the battery level of an iPod is very low, the iPod may not operate. If so, charge the iPod before use.
- Compatible models (→P. 276)

#### ■ iPod problems

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it. For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

#### ■ Error messages

Message	Cause/Correction procedures
"Connection error. Please consult your Owner's Manual for instructions on how to connect the iPod."	This indicates a problem in the iPod or its connection.
"No music files found."	This indicates that there is no music data in the iPod.
"No videos found."	This indicates that no video files are included in the iPod.
"There are no songs available for playback. Please add compatible files to your iPod."	This indicates that songs are not found in a selected playlist.
"iPod authorization unsuccessful."	This indicates that the display multimedia system failed to authorize the iPod. Please check your iPod.

#### ■ Compatible models

The following iPod<sup>®</sup>, iPod nano<sup>®</sup>, iPod classic<sup>®</sup>, iPod touch<sup>®</sup> and iPhone<sup>®</sup> devices can be used with this system.

#### Made for

- iPod touch (5th generation)
- iPod touch (4th generation)
- iPod touch (3rd generation)
- iPod touch (2nd generation)
- iPod touch (1st generation)
- iPod classic
- · iPod with video
- iPod nano (7th generation)
- iPod nano (6th generation)
- iPod nano (5th generation)
- iPod nano (4th generation)
- iPod nano (3rd generation)
- iPod nano (2nd generation)
- iPod nano (1st generation)
- iPhone 5
- · iPhone 4S
- · iPhone 4
- · iPhone 3GS
- · iPhone 3G
- iPhone

Depending on differences between models or software versions etc., some models might be incompatible with this system.



### **WARNING**

#### ■While driving

Do not connect an iPod or operate the controls.



#### **NOTICE**

#### ■ To prevent damage to the iPod or its terminals

- Do not leave the iPod in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the iPod.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected.
- Do not insert foreign objects into the port.

### Listening to a USB memory device

Connecting a USB memory device enables you to enjoy music from the vehicle speakers.

Touch "USB" on the audio source selection screen.

### Connecting a USB memory device

→P. 253

#### Audio control screen

Pressing the "AUDIO" button displays the audio control screen from any screens of the selected source.

- 1 Audio source selection screen appears
- ② Displaying the folder list
- ③ Random playback (→P. 255)
- (4) Repeat play (→P. 255)
- 5 PauseSelect to resume playback
- $\bigcirc$  Setting the sound ( $\rightarrow$ P. 266)



#### Selecting a play mode

- 1 Select "Browse" on the screen.
- 2 Select the desired play mode. Then select a song to begin using the selected play mode.
  - Displaying the now playing list

Touch the cover art display.

#### ■USB memory functions

- Depending on the USB memory device that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- If the USB memory device still does not begin operation after being disconnected and reconnected, format the memory.

#### ■ Error messages for USB memory

Message	Cause/Correction procedures
"Connection error. Please consult your Owner's Manual for instructions on how to connect the USB device."	This indicates a problem with the USB memory device or its connection.
"No music files found."	This indicates that no MP3/WMA/AAC files are included on the USB memory device.

#### ■USB memory

Compatible devices

USB memory device that can be used for MP3, WMA and AAC playback.

Compatible device formats

The following device format can be used:

- USB communication format: USB2.0 HS (Mbps) and FS (12 Mbps)
- File system format: FAT16/32 (Windows)
- Correspondence class: Mass storage class
   MP3, WMA and AAC files written to a device with any format other than
   those listed above may not play correctly, and their file names and folder
   names may not be displayed correctly.

Items related to standards and limitations are as follows:

- Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 3000 (including the root)
- Maximum number of files in a device: 9999
- Maximum number of files per folder: 255
- MP3, WMA and AAC files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format. Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format. This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

#### MP3 file compatibility

Compatible standards

MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 AUDIO LAYERII, III)

Compatible sampling frequencies

MPEG1 AUDIO LAYERII, III: 32, 44.1, 48 (kHz) MPEG2 AUDIO LAYERII, III: 16, 22.05, 24 (kHz)

Compatible bit rates (compatible with VBR)
 MPEG1 AUDIO LAYERII, III: 32-320 (kbps)
 MPEG2 AUDIO LAYERII, III: 8-160 (kbps)

 Compatible channel modes: stereo, joint stereo, dual channel and monaural

#### WMA file compatibility

 Compatible standards WMA Ver. 7, 8, 9

 Compatible sampling frequencies HIGH PROFILE 32, 44.1, 48 (kHz)

 Compatible bit rates HIGH PROFILE 48-320 (kbps, VBR)

#### AAC file compatibility

 Compatible standards MPEG4/AAC-LC

 Compatible sampling frequencies 11.025/12/16/22.05/24/32/44.1/48 (kHz)

 Compatible bit rates 16-320 (kbps)

• Compatible channel modes: 1 ch and 2 ch

#### File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, .wma or .m4a.

#### ● ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### MP3, WMA and AAC playback

- · When a device containing MP3, WMA and AAC files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3, WMA and AAC file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3, WMA and AAC files or create any unnecessary folders.
- · When a USB memory device is connected and the audio source is changed to USB memory mode, the USB memory device will start playing the first file in the first folder. If the same device is removed and reconnected (and the con-tents have not been changed), the USB memory device will resume play from the same point in which it was last used.

#### Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they will be skipped (not played).

#### Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- · Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



#### WARNING

#### While driving

Do not connect a USB memory device or operate the device controls.



#### NOTICE

#### ■ To prevent damage to the USB memory device or its terminals

- Do not leave the USB memory device in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the USB memory device.
- Do not push down on or apply unnecessary pressure to the USB memory device while it is connected.
- Do not insert foreign objects into the port.

### **Using the AUX port**

To use the AUX port, connect a portable player, press the "AUDIO" button, then select "AUX" to display the audio control screen.

### Connecting a portable audio player

→P. 253

- Operating portable audio players connected to the multimedia system The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio player itself.
- When using a portable audio player connected to the power outlet Noise may occur during playback. Use the power source of the portable audio player.



#### WARNING

#### While driving

Do not connect a portable audio player or operate the device controls.

### Preparations to use wireless communication

The following can be performed using Bluetooth® wireless communication:

- A portable audio player can be operated and listened to via multimedia system
- Hands-free phone calls can be made via a cellular phone In order to use wireless communication, register and connect a Bluetooth® device by performing the following procedures.

#### ■ About Bluetooth®

Bluetooth is a registered trademark of Bluetooth SIG, Inc.



STNAV00001

### **WARNING**

■ Certifications for the Bluetooth<sup>®</sup>

FCC ID: BABFT0049B FCC ID: AJDK068

CAUTION: Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 20cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

- Co-location: This transmitter must not be co-located or operated in coniunction with any other antenna or transmitter.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- ●IC: 2024B-FT0049B IC: 775F-K068
  - · This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- CAUTION: Radio Frequency Radiation Exposure

This equipment complies with IC radiation exposure limits set forth for uncontrolled equipment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE).

But it is desirable that it should be installed and operated with at least 20cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

### Device registration/connection flow

1. Register the Bluetooth<sup>®</sup> device to be used with multimedia system (→P. 287, 288, 289)



2. Connect the Bluetooth<sup>®</sup> device to be used (→P. 291)

To be used for audio



3. Start Bluetooth<sup>®</sup> connection (→P. 291)



4. Check connection status (→P. 295)



5. Use Bluetooth<sup>®</sup> audio (→P. 295)

To be used for hands-free phone



Start Bluetooth<sup>®</sup> connection (→P. 291)



4. Check connection status (→P. 297)



5. Use Bluetooth<sup>®</sup> phone (→P. 296)

### Registering and connecting from the "Bluetooth\* Setup" screen

To display the screen shown below, press the "SETUP" button and select "Bluetooth\*" on the "Setup" screen.

- Select to connect the device to be used with multimedia system. (→P. 291)
- ② Select to register a Bluetooth<sup>®</sup> device to be used with multimedia system. (→P. 289)
- ③ Select to set detailed Bluetooth<sup>®</sup> system settings. (→P. 294)



- (4) Select to delete registered devices. (→P. 290)
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

# Registering a Bluetooth<sup>®</sup> audio player for the first time

To use the Bluetooth<sup>®</sup> Audio, it is necessary to register an audio player with the system.

Once the player has been registered, it is possible to use the  $\mathsf{Bluetooth}^{\$}$  Audio.

For details about registering a Bluetooth<sup>®</sup> device (→P. 289)

- 1 Turn the Bluetooth® connection setting of your audio player on.
- 2 Press the "AUDIO" button.
- 3 Select " Audio".
- 4 Select "Select Device".
- 5 Follow the steps in "How to register a Bluetooth<sup>®</sup> device" from "STEP 2". (→P. 289)

# Registering a Bluetooth<sup>®</sup> phone for the first time

To use the hands-free system, it is necessary to register a  $\mathsf{Bluetooth}^{\texttt{®}}$  phone with the system.

Once the phone has been registered, it is possible to use the hands-free system.

For details about registering a Bluetooth<sup>®</sup> device (→P. 289)

- 1 Turn the Bluetooth<sup>®</sup> connection setting of your cellular phone on.
- 2 Press the " 📞 " button.
- 3 Select "OK" to register a phone.
- [4] Follow the steps in "How to register a Bluetooth® device" from "STEP 3". (→P. 289)

# Registering a Bluetooth® device

Bluetooth® compatible phones (HFP) and portable audio players (AVP) can be registered simultaneously. You can register up to 5 Bluetooth® devices.

#### How to register a Bluetooth® device

- 1 Display the "Bluetooth\* Setup" screen. (→P. 286)
- 2 Select "Add".
- 3 When this screen is displayed, search for the device name displayed on this screen on the screen of your Bluetooth® device.

For details about operating the Bluetooth® device, see the manual that comes with it.

To cancel the registration, select "Cancel".



CTHDAAK024US

- Register the Bluetooth<sup>®</sup> device using your Bluetooth<sup>®</sup> device.
  - A PIN-code is not required for SSP (Secure Simple Pairing) compatible Bluetooth® devices. Depending on the type of Bluetooth® device being connected, a message confirming registration may be displayed on the Bluetooth® device's screen. Respond and operate the Bluetooth® device according to the confirmation message.
- 5 Check that this screen is displayed when registration is complete.



6 Select "OK" when the connection status changes from "Connecting..." to "Connected".

If an error message is displayed, follow the guidance on the screen to try again.

Registration can be performed from screens other than the "Bluetooth\* Setup" screen.

#### ■ When registering from the "Bluetooth\* Audio" screen

- 1 Display the "Bluetooth\* Audio" screen. (→P. 263)
- 2 Select "Select Device".
- 3 Follow the steps in "How to register a Bluetooth® device" from "STEP 2". (→P. 289)
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Deleting a Bluetooth® device

- 1 Display the "Bluetooth\* Setup" screen. (→P. 286)
- 2 Select "Remove".
- 3 Select the desired device.
- 4 A confirmation message will be displayed, select "Yes" to delete the device.
- 5 Check that a confirmation screen is displayed when the operation is complete.
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

# Audio system

### Connecting a Bluetooth® device

Up to 5 Bluetooth® devices (Phones [HFP] and audio players [AVP]) can be registered.

If more than 1 Bluetooth® device has been registered, select which device to connect to.

- 1 Press the "SETUP" button.
- 2 Select "Bluetooth\*".
- 3 Select the device to be connected.

Supported profile icons will be displayed.

- (1) Phone
- (2) Audio player

Supported profile icons for currently connected devices will illuminate.



Dimmed icons can be selected to connect to the function directly.

#### **Auto connection**

To turn auto connection mode on, set "Bluetooth\* Power" to on. (→P. 294)

When you register a phone, auto connection will be activated. Always set it to this mode and leave the Bluetooth® phone in a place where a connection can be established.

When the power switch is turned to ACCESSORY or ON mode, the system will search for a nearby cellular phone you have registered.

Next, the system automatically connects with the most recent of the phones connected to in the past. Then, the connection result is displayed.

<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### **Manual connection**

When auto connection has failed or "Bluetooth\* Power" is turned off, you must connect the Bluetooth® device manually.

- 1 Follow the steps in "Connecting a Bluetooth® device" from "STEP 1". (→P. 291)
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Connecting a Bluetooth® audio player

- ▶ Registering an additional device
- 1 Select "Select Device" on the Bluetooth® audio control screen.
- $\boxed{2}$  For more information:  $\rightarrow$ P. 289
- ▶ Selecting a registered device
- 1 Select "Select Device" on the Bluetooth® audio control screen.
- For more information: →P. 291

#### ■ Reconnecting a Bluetooth® phone

If the system cannot connect due to poor signal strength with the power switch in ACCESSORY or ON mode, the system will automatically attempt to reconnect.

If the phone is turned off, the system will not attempt to reconnect. In this case, the connection must be made manually, or the phone must be reselected.

# Displaying a Bluetooth® device details

You can confirm and change the registered device details.

#### Bluetooth® device registration status

- 1 Display the "Bluetooth\* Setup" screen. (→P. 286)
- 2 Select the device.
- 3 Select "Device Info".
- 4 The following screen is displayed:
  - 1 Device Name
  - ② Change connection method (→P. 293)
  - (3) Bluetooth® Address
  - 4 Display your telephone number

The number may not be displayed depending on the model of phone.


- (5) Compatibility profile of the device
- 6 Restore default settings
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### **Changing connection method**

- 1 Select "Connect Audio Player from".
- 2 Select "Vehicle" or "Device".

"Vehicle": Connect the multimedia system to the portable audio player.

"Device": Connect the portable audio player to the multimedia system.



# Detailed Bluetooth® system settings

You can confirm and change the detailed Bluetooth® settings.

#### How to check and change detailed Bluetooth® settings

- 1 Display the "Bluetooth\* Setup" screen. (→P. 286)
- 2 Select "System Settings".
- 3 The following screen is displayed:
  - Bluetooth® Power on/off
     You can change Bluetooth® function on/off.
  - (2) Bluetooth® Name
  - (3) Change PIN-code (→P. 294)
  - (4) Bluetooth® Address
  - (5) Display Phone Status

    You can set the system to show
    the status confirmation display
    when connecting a telephone.
  - when connecting a telephone.

    6 Display Audio Player Status
    - You can set the system to show the status confirmation display when connecting an audio player.
  - Compatibility profile of the system
  - (8) Restore default settings
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### **Editing the Bluetooth\* PIN**

You can change the PIN-code that is used to register your Bluetooth<sup>®</sup> devices in the system.

- 1 Select "Bluetooth\* PIN".
- 2 Input a PIN-code, and select "OK".
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.



# Listening to Bluetooth® Audio

The Bluetooth<sup>®</sup> audio system enables the user to enjoy music played on a portable player from the vehicle speakers via wireless communication.

When a Bluetooth<sup>®</sup> device cannot be connected, check the connection status on the "Bluetooth\* Audio" screen. If the device is not connected, either register or reconnect the device. (→P. 291)

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

#### Status display

You can check such indicators as signal strength and battery charge on the screen.

- (1) Connection status
- ② Battery charge



CTHDAAK028US

Indicators	Conditions		
Connection status	Good ←	* .	Not connected
Battery charge	Full ←	i	——→ Empty

#### Playing Bluetooth® audio

Select or II to Play/Pause.

For details on "Bluetooth\* Audio" screen operation methods, refer to Basic Audio Operations. (→P. 255)

For details on how to select a track or album, refer to selecting, fast-forwarding and reversing tracks/files/songs. ( $\rightarrow$ P. 265)

<sup>\*:</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

# Using a Bluetooth® Phone

The hands-free system is a function that allows you to use your cellular phone without touching it.

This system supports Bluetooth<sup>®</sup>. Bluetooth<sup>®</sup> is a wireless data system that allows the cellular phone to wirelessly connect to the hands-free system and make/receive calls.

Before making a phone call, check the connection status, battery charge, call area and signal strength. ( $\rightarrow$ P. 297)

If a Bluetooth<sup>®</sup> device cannot be connected, check the connection status on the phone screen. If the device is not connected, either register or reconnect it. ( $\rightarrow$ P. 291)

#### Phone screen

To display the screen shown below, press the  $\ensuremath{\mathfrak{C}}$  switch on the steering wheel or the  $\ensuremath{\checkmark}$  button.

Several functions are available to operate on each screen that is displayed by selecting the 4 tabs.

- 1 Device name
- (2) Bluetooth® connection status




#### ■ Telephone switch (→P. 308)

#### **■** Microphone

The vehicle's built in microphone is used when talking on the phone.

The person you are speaking to can be heard from the front speakers.



To use the hands-free system, you must register your Bluetooth<sup>®</sup> phone in the system. ( $\rightarrow$ P. 289)

#### Status display

You can check indicators such as signal strength and battery charge on the phone screen.

- (1) Connection status
- ② Signal strength
- 3 Battery charge



Indicators	Conditions		
Connection status	Good  S	Not connected	
Battery charge	Full ->	Empty 🗖	
Call area	"Rm": Roaming area		
Signal strength	Excellent ->	Poor	

## Making a call

Once a Bluetooth<sup>®</sup> phone is registered, you can make a call using the following procedure:

#### **Dialing**

- 1 Display the phone screen. (→P. 296)
- 2 Select the "Dial Pad" tab and enter a phone number.
  - To delete the input phone number, select \_\_\_\_. For the first digit, you can enter "+" by selecting "\*" for a while.
- 3 Press the 🕾 switch on the steering wheel or select 📶.

#### Dialing from the contacts list

You can dial a number from the contact data imported from your cellular phone. The system has one contact for each registered phone. Up to 2500 contacts may be stored in each contact. ( $\rightarrow$ P. 298)

- 1 Display the phone screen. (→P. 296)
- 2 Select "Contacts" tab.
- 3 Choose the desired contact to call from the list.
- 4 Choose the number and then press the Switch on the steering wheel or select .

#### When the contact is empty

You can transfer the phone numbers in a Bluetooth<sup>®</sup> phone to the system.


Operation methods differ between PBAP (Phone Book Access Profile) compatible and PBAP incompatible Bluetooth<sup>®</sup> phones. If the cellular phone does not support either PBAP or OPP (Object Push Profile) service, you cannot transfer contacts.

- Press the switch on the steering wheel.

  If the phonebook is empty, a message will be displayed.
- ► For a PBAP compatible Bluetooth<sup>®</sup> phone and "Automatic Contact/ History Transfer" is off
- 2 Select the desired item.
  - Select to transfer new contacts from a cellular phone, select "Always" and then enable "Automatic Contact/ History Transfer".
  - Select to transfer all the contacts from a connected cellular phone only once.



- (3) Select to cancel transferring.
- ► For PBAP incompatible but OPP compatible Bluetooth® phones
- 2 Select the desired item.
  - Select to transfer the contacts from the connected cellular phone.
  - Select to add a new contact manually.
  - (3) Select to cancel transferring.



CTHDAAK065US

- ▶ When "Transfer" is selected
- 3 Follow the steps in "Update contacts from phone" from "STEP2". (→P. 311)
  - When "Add" is selected
- [3] Follow the steps in "Registering a new contact to the contacts list" from "STEP2". (→P. 312)

#### Calling using favorites list

You can make a call using numbers registered in the contact.

- 1 Display the phone screen. (→P. 296)
- 2 Select "Favorites" tab.
- 3 Select the desired number to make a call.

#### Dialing from call history

You can make a call using the call history, which has the 3 functions below.

- ★ : calls which you missed
- : calls which you received
- : calls which you made
- 1 Display the phone screen. (→P. 296)
- 2 Select "Call History" tab.
- 3 Select 📞 or the desired entry from the list.
  - ▶ When 📞 is selected
- 4 Check that the "Call" screen is displayed.
- ▶ When the desired contact is selected
- 4 Select the desired number.
- 5 Check that the "Call" screen is displayed.

#### ■ Call history list

- If you make a call to or receive a call from a number registered in the contact, the name is displayed in the call history.
- If you make multiple calls to the same number, only the last call made is displayed in the call history.

#### International calls

You may not be able to make international calls, depending on the mobile phone in use.

# Receiving a call

When a call is received, the following screen is displayed together with a sound.

#### To answer the phone

Press the Switch on the steering wheel or select .



#### To refuse a call

Press the es switch on the steering wheel or select select.

#### To adjust the incoming call volume

Turn the "PWR/VOL" knob. You can also adjust the volume using the steering switches.

#### ■ International calls

Received international calls may not be displayed correctly depending on the cellular phone in use.

## Speaking on the phone

The following screen is displayed when speaking on the phone.



#### To adjust the call volume

Select "-" or "+". You can also adjust the volume using the steering switches or the volume knob.

#### To prevent the other party from hearing your voice

Select "Mute".

#### Inputting tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the contact.

- 1 Select "0-9".
- 2 Input the number.

#### ■ Release Tones

"Release Tones" appear when a continuous tone signal(s) containing a (w) is registered in the contact list.

1 Select "Release Tones".

#### ■ Release Tones

- A continuous tone signal is a character string that consists of numbers and the characters p or w. (e.g.056133w0123p#1\*)
- •When the "p" pause tone is used, the tone data up until the next pause tone will be automatically sent after 2 seconds have elapsed. When the "w" pause tone is used, the tone data up until the next pause tone will be automatically sent after a user operation is performed.
- Release tones can be used when automated operation of a phone based service such as an answering machine or bank phone service is desired. A phone number with continuous tone signals can be registered in the contact list.
- Tone data after a "w" pause tone can be operated on voice command during a call.

#### To transfer a call

Select "Handset Mode" to on from a hands-free call to a cellular phone call.

Select "Handset Mode" to off from a cellular phone call to a hands-free call.

#### Transmit volume setting

- 1 Select "Transmit Volume".
- 2 Select the desired level for the transmit volume.
- 3 Select "OK".

#### To hang up

Press the result on the steering wheel or select.

#### **Call waiting**

When a call is interrupted by a third party while talking, an incoming call message will be displayed.

To talk with the other party:

- Press the Switch on the steering wheel.

To refuse the call:

- Press the switch on the steering wheel.
- Select



Every time you press the  $\bigcirc$  switch on the steering wheel or select during call waiting, you will be switched to the other party.

#### ■ Transferring calls

- If you transfer from the cellular phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- Transfer method and operation may vary according to the cellular phone used.
- For operation of the cellular phone in use, see the phone's manual.

#### ■ Call waiting operation

Call waiting operation may differ depending on your phone company and cellular phone.

# Audio system

# Bluetooth<sup>®</sup> phone message function

Received messages can be forwarded from the connected Bluetooth® phone, enabling checking and replying using the multimedia system.

Depending on the type of Bluetooth® phone connected, received messages may not be transferred to the message inbox.

If the phone does not support the message function, this function cannot be used.

#### Displaying message inbox screen

- 1 Press the " 📞 " button.
- 2 Select 🖂 .

#### Receiving a message

When an e-mail/SMS/MMS is received, the incoming message screen pops up with sound and is ready to be operated on the screen.

- (1) Select to check the message.
- (2) Select to refuse the message.
- (3) Select to call the message sender.



#### ■ Receiving a message

- Depending on the cellular phone used for receiving messages, or its registration status with the navigation system, some information may not be displayed.
- The pop up screen is separately available for incoming e-mail and SMS/ MMS messages under the following conditions:

#### E-mail:

- "Incoming E-mail Display" is set to "Full Screen". (→P. 316)
- "E-mail Notification Popup" is set to on. (→P. 316)


#### SMS/MMS:

- "Incoming SMS/MMS Display" is set to "Full screen". (→P. 316)
- "SMS/MMS Notification Popup" is set to on. (→P. 316)

#### Checking the messages

- 1 Display the message inbox screen. (→P. 305)
- 2 Select the desired message from the list.
- 3 Check that the message is displayed.
  - ① E-mails: Select "Mark Unread" or "Mark Read" to mark mail unread or read on the message inbox screen.

This function is available when "Update Message Read Status on Phone" is set to on.  $(\rightarrow P. 316)$ 



- (2) Select to make a call to the sender.
- ③ Select to have messages read out. To cancel this function, select "Stop".
- (4) Select to display the previous or next message.
- (5) Select to reply the message.

#### ■ Check the messages

- Depending on the type of Bluetooth® phone being connected, it may be necessary to perform additional steps on the phone.
- Messages are displayed in the appropriate connected Bluetooth<sup>®</sup> phone's registered mail address folder.
  - Select the tab of the desired folder to be displayed.
- Only received messages on the connected Bluetooth<sup>®</sup> phone can be displayed.
- The text of the message is not displayed while driving.
- When "Automatic Message Readout" is set to on, messages will be automatically read out. (→P. 316)
- Turn the "PWR/VOL" knob, or use the volume switch on the steering wheel to adjust the message read out volume.
- ■The message read out function is available even while driving.

#### Replying to a message

- 1 Display the message inbox screen. (→P. 305)
- 2 Select the desired message from the list.
- 3 Select "Quick Message".
- 4 Select the desired message.
- 5 Select "Send".

#### ■ Editing quick reply message

- 1 Select "Quick Message".
- Select corresponding to the desired message to edit.
- 3 Select "OK" when editing is completed.

#### Calling the message sender

Calls can be made to an e-mail/SMS/MMS message sender's phone number.

- 1 Display the message inbox screen. (→P. 305)
- 2 Select the desired message.
- 3 Select .
- 4 Check that the "Call" screen is displayed.
- Calling from a number within a message

Calls can be made to a number identified in a message's text area.

- 1 Display the message inbox screen. (→P. 305)
- 2 Select the desired message.
- 3 Select the text area.
- Select corresponding to the desired number.
- 5 Check that the "Call" screen is displayed.
- Calling from the incoming message screen

→P. 304


# Using the steering wheel switches

The steering wheel switches can be used to operate a connected cellular phone.

#### Operating a telephone using the steering wheel switches


#### ■ Steering wheel switches on the right hand side

- (1) Off hook switch
  - · Make a call
  - · Receive a call
  - · Display "Phone" screen
- (2) On hook switch
  - · End a call
  - · Refuse a call



#### ■ Steering wheel switches on the left hand side

- (1) Volume switch
  - Increase/Decrease the volume
  - Press and hold:
     Continuously increase/ decrease the volume
- (2) Back switch
  - Return to the previous screen
- (3) Cursor switch
  - · Select a list/tab
- (4) Enter switch
  - · Select an item



# Bluetooth<sup>®</sup> phone settings

You can adjust the hands-free system to your desired settings.

#### "Phone/Message Settings" screen


To display the screen shown below, press the "SETUP" button, and select "Phone" on the "Setup" screen.

- Set the phone connection
   (→P. 289)
- (2) Setting the sound ( $\rightarrow$ P. 309)
- ③ Contact/Call History Settings(→P. 310)
- (4) Set the message settings (→P. 316)
- (5) Set the phone display(→P. 317)



#### Sound setting

- 1 Display the "Phone/Message Settings" screen. (→P. 309)
- Select "Sound Settings" on the "Phone/Message Settings" screen.
  - 1 Set the desired ringtone.
  - 2 Adjust the ringtone volume.
  - 3 Adjust the message readout volume.
  - (4) Set the desired incoming SMS/MMS tone.
  - (5) Adjust the incoming SMS/MMS tone volume.
  - (6) Set the incoming e-mail tone.
  - (7) Adjust the incoming e-mail tone volume.
  - (8) Adjust the default volume of the other party's voice.





# **Contact/Call History Settings**

The contact can be transferred from a Bluetooth<sup>®</sup> phone to the system. The contact also can be added, edited and deleted.

The call history can be deleted and contact and favorites can be changed.

- 1 Display the "Phone/Message Settings" screen. (→P. 309)
- 2 Select "Contact/Call History Settings".
- 3 Select the desired item to be set.
  - (1) For PBAP compatible Bluetooth® phones, select to set automatic contact/history transfer on/off. When set to on, the phone's contact data and history are automatically transferred.
  - ② Select to update contacts from the connected phone.(→P. 311)



- (3) Select to sort contacts by the first name or last name field.
- (4) Select to add contacts to the favorites list. (→P. 314)
- $\bigcirc$  Select to delete contacts from the favorites list.  $(\rightarrow P. 315)$
- 6 Select to display contact images.
- (7) Select to clear contacts from the call history.\*
- (8) Select to add new contacts to the contact list.\* ( $\rightarrow$ P. 312)
- (9) Select to edit contacts in the contact list.\* (→P. 313)
- (10) Select to delete contacts from the contact list.\* ( $\rightarrow$ P. 313)
- (1) Select to reset all setup items.\*
  - \*: For PBAP compatible Bluetooth® phones only, this function is available when "Automatic Contact/History Transfer" is set to off.

#### Update contacts from phone

Operation methods differ between PBAP compatible and PBAP incompatible but OPP compatible Bluetooth<sup>®</sup> phones.

If your cellular phone is neither PBAP nor OPP compatible, the contacts cannot be transferred.

#### ■ For PBAP Compatible Bluetooth® Phones

- 1 Select "Update Contacts from Phone".
- 2 Check that a confirmation screen is displayed when the operation is complete.

This operation may be unnecessary depending on the type of cellular phone.

Depending on the type of cellular phone, OBEX authentication may be required when transferring contact data. Enter "1234" into the Bluetooth® phone.

If another Bluetooth  $^{\circledR}$  device is connected when transferring contact data, depending on the phone, the connected Bluetooth  $^{\circledR}$  device may need to be disconnected.

Depending on the type of Bluetooth<sup>®</sup> phone being connected, it may be necessary to perform additional steps on the phone.

# ■ For PBAP Incompatible but OPP compatible Bluetooth® Phones

- 1 Select "Update Contacts from Phone".
- $oxed{2}$  Transfer the contact data to the system using a Bluetooth $^{oxed{\mathbb{R}}}$  phone.

This operation may be unnecessary depending on the type of cellular phone.

Depending on the type of cellular phone, OBEX authentication may be required when transferring contact data. Enter "1234" into the Bluetooth<sup>®</sup> phone.

To cancel this function, select "Cancel".

- 3 Select "Done" when it appears on the screen.
- 4 Check that a confirmation screen is displayed when the operation is complete.

■ Updating the contacts in a different way (From the "Call History" screen)

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Contact/History Transfer" is set to off. ( $\rightarrow$ P. 310)

- 1 Display the phone screen. (→P. 296)
- Select the "Call History" tab and select a contact not yet registered in the contact list.
- 3 Select "Update Contact".
- 4 Select the desired contact.
- 5 Select a phone type for the phone number.

#### Registering a new contact to the contact list

New contact data can be registered. Up to 4 numbers per person can be registered. For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Contact/History Transfer" is set to off.  $(\rightarrow P. 310)$ 

- 1 Select "New Contact".
- 2 Enter the name and select "OK".
- 3 Enter the phone number and select "OK".
- 4 Select the phone type for the phone number.
- 5 To add another number to this contact, select "Yes".
- Registering a new contact in a different way (From the "Call History" screen)
  - 1 Display the phone screen. (→P. 296)
  - Select the "Call History" tab and select a contact not yet registered in the contact list.
  - 3 Select "Add to Contacts".
  - Follow the steps in "Registering a new contact to the contacts list" from "STEP 3".

#### Editing the contact data

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Contact/History Transfer" is set to off. ( $\rightarrow$ P. 310)

- 1 Select "Edit Contact".
- 2 Select the desired contact.
- 3 Select corresponding to the desired name or number.
- ▶ For editing the name
- [4] Follow the steps in "Registering a new contact to the contacts list" from "STEP 3". (→P. 312)
  - ▶ For editing the number
- [4] Follow the steps in "Registering a new contact to the contacts list" from "STEP 4". (→P. 312)
  - Editing the contacts in a different way (From the "Contact Details" screen)
    - 1 Display the phone screen. (→P. 296)
    - 2 Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact.
    - 3 Select "Edit Contact".
      - "E-mail Addresses": Select to display all registered e-mail addresses for the contact.
    - 4 Follow the steps in "Editing the contact data" from "STEP 4".

#### Deleting the contact data

For PBAP compatible Bluetooth<sup>®</sup> phones, this function is available when "Automatic Contact/History Transfer" is set to off. ( $\rightarrow$ P. 310)

- Select "Delete Contacts".
- 2 Select the desired contact and select "Delete".
- 3 Select "Yes" when the confirmation screen appears.
- Deleting the contact in a different way (From the "Contact Details" screen)
  - 1 Display the phone screen. (→P. 296)
  - 2 Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact.
  - 3 Select "Edit Contact".
  - 4 Select "Yes" when the confirmation screen appears.

#### **Favorites list setting**

Up to 15 contacts (maximum of 4 numbers per contact) can be registered in the favorites list.

#### Registering the contacts in the favorites list

- 1 Select "Add Favorite".
- 2 Select the desired contact to add to the favorites list.

  Dimmed contacts are already stored as a favorite.
- 3 Check that a confirmation screen is displayed when the operation is complete.
- ▶ When 15 contacts have already been registered to the favorites list
- When 15 contacts have already been registered to the favorites list, a registered contact needs to be replaced.

  Select "Yes" when the confirmation screen appears to replace a contact.
- 2 Select the contact to be replaced.
- 3 Check that a confirmation screen is displayed when the operation is complete.
- Registering contacts in the favorites list in a different way (from the "Contacts" screen)
- Display the phone screen. (→P. 296)
- 2 Select the "Contacts" tab.
- 3 Select  $\checkmark$  at the beginning of the desired contact list name to be registered in the favorites list.


  - ▶ Registering contacts in the favorites list in a different way (from the "Contact Details" screen)
- 1 Display the phone screen. (→P. 296)
- 2 Select the "Contacts" tab or the "Call History" tab and select the desired contact.
- 3 Select "Add Favorite".
- 4 Check that a confirmation screen is displayed when the operation is complete.

#### ■ Deleting the contacts in the favorites list

- 1 Select "Remove Favorite".
- 2 Select the desired contacts and select "Remove".
- 3 Select "Yes" when the confirmation screen appears.
- 4 Check that a confirmation screen is displayed when the operation is complete.
- ▶ Deleting contacts in the favorites list in a different way (from the "Contacts" screen)
- 1 Display the phone screen. (→P. 296)
- 2 Select the "Contacts" tab.
- 3 Select ★ at the beginning of the contact list name to be deleted from the favorites, list.
  - When selected,  $\bigstar$  is changed to  $\nwarrow$ , and the data is deleted from the list.
  - ▶ Deleting contacts in the favorites list in a different way (from the "Contact Details" screen)
- 1 Display the phone screen. (→P. 296)
- Select the "Contacts", "Call History" tab or the "Favorites" tab and select the desired contact to delete.
- 3 Select "Remove Favorite".
- 4 Select "Yes" when the confirmation screen appears.
- 5 Check that a confirmation screen is displayed when the operation is complete.

#### **Message Settings**

- 1 Display the "Phone/Message Settings" screen. (→P. 309)
- 2 Select "Messaging Settings".
- 3 Select the desired item to be set.
  - 1) Set automatic message transfer on/off.
  - ② Set automatic message readout on/off.
  - 3 Set the SMS/MMS notification popup on/off.
  - (4) Set the e-mail notification popup on/off.
  - (5) Set adding the vehicle signature to outgoing messages on/off.



- (6) Set updating message read status on phone on/off.
- (7) Change the incoming SMS/MMS display.

"Full Screen": When an SMS/MMS message is received, the incoming SMS/MMS display screen is displayed and can be operated on the screen.

"Drop-Down": When an SMS/MMS message is received, a message is displayed on the upper side of the screen.

(8) Change the incoming e-mail display.

"Full Screen": When an e-mail is received, the incoming e-mail display screen is the displayed and can be operated on the screen.

"Drop-Down": When an e-mail is received, a message is displayed on the upper side of the screen.

Set display of messaging account names on the inbox tab on/off.
 When set to on, messaging account names used on the cellular phone will be displayed.

#### ■ To return to the default volume settings

Select "Default", and then "Yes".

#### ■ Displaying the "Messaging Settings" screen in a different way

- 1 Display the phone screen. (→P. 296)
- 2 Select 🖍 .
- 3 Select "Settings".

#### **Phone Display Settings**

- 1 Display the "Phone/Message Settings" screen. (→P. 309)
- 2 Select "Phone Display Settings".
- 3 Select the desired item to be set.
  - Change the incoming call display.

"Full Screen": When a call is received, the hands-free screen is displayed and can be operated on the screen.

"Drop-Down": A message is displayed on the upper side of the screen.



Set display of the contact/ history transfer completion message on/off.

# What to do if... (Troubleshooting)

If there is a problem with the hands-free system or a Bluetooth<sup>®</sup> device, first check the table below.

▶ When using the hands-free system with a Bluetooth<sup>®</sup> device

The hands-free system or Bluetooth® device does not work.

The connected device may not be a compatible Bluetooth<sup>®</sup> cellular phone.

→ For a list of specific devices which operation has been confirmed on this system, check with your Toyota dealer or the following website: http://www.toyota.com/entune.html

The Bluetooth version of the connected cellular phone may be older than the specified version.

→ Use a cellular phone with Bluetooth version 2.0 or higher (recommended: Ver. 3.0 with EDR or higher). (→P. 322)

▶ When registering/connecting a cellular phone

A cellular phone cannot be registered.

An incorrect passcode was entered on the cellular phone.

→ Enter the correct passcode on the cellular phone.

The registration operation has not been completed on the cellular phone side.

→ Complete the registration operation on the cellular phone (approve registration on the phone).

Old registration information remains on either this system or the cellular phone.

→ Delete the existing registration information from both this system and the cellular phone, then register the cellular phone you wish to connect to this system. (→P. 290)

A Bluetooth® connection cannot be made.

Another Bluetooth® device is already connected.

 $\rightarrow$  Manually connect the cellular phone you wish to use to this system. ( $\rightarrow$ P. 292)

Bluetooth® function is not enabled on the cellular phone.

→ Enable the Bluetooth® function on the cellular phone.

"Please check your device settings." message is displayed.

Bluetooth® function is not enabled on the cellular phone.

→ Enable the Bluetooth® function on the cellular phone.

Old registration information remains on either this system or the cellular phone.

- ightarrow Delete the existing registration information from both this system and the cellular phone, then register the cellular phone you wish to connect to this system. (ightarrowP. 290)
- When making/receiving a call

#### A call cannot be made/received.

Your vehicle is in a "Out of cellular service area. Please try again later." area.

→ Move to where "Out of cellular service area. Please try again later." no longer appears on the display. When using the phonebook

Phonebook data cannot be transferred manually/automatically.

The profile version of the connected cellular phone may not be compatible with transferring phonebook data.

→ For a list of specific devices which operation has been confirmed on this system, check with your Toyota dealer or the following website: http://www.toyota.com/entune.html

Automatic phonebook transfer function on this system is set to off.

→ Set automatic phonebook transfer function on this system to on. (→P. 310)

Passcode has not been entered on the cellular phone.

→ Enter the passcode on the cellular phone if requested (default passcode: 1234).

Transfer operation on the cellular phone has not completed.

→ Complete transfer operation on the cellular phone (approve transfer operation on the phone).

Phonebook data cannot be edited.

Automatic phonebook transfer function on this system is set to on.

 $\rightarrow$  Set automatic phonebook transfer function on this system to off. (  $\rightarrow$  P. 310)

▶ When using the Bluetooth® message function

Messages cannot be viewed.

Message transfer is not enabled on the cellular phone.

→ Enable message transfer on the cellular phone (approve message transfer on the phone).

Automatic transfer function on this system is set to off.

 $\rightarrow$  Set automatic transfer function on this system to on. ( $\rightarrow$ P. 316)

New message notifications are not displayed.

Notification of SMS/MMS/E-mail reception on this system is set to off.

 $\rightarrow$  Set notification of SMS/MMS/E-mail reception on this system to on. (  $\rightarrow$  P. 316)

Automatic message transfer function is not enabled on the cellular phone.

 $\rightarrow$  Enable automatic transfer function on the cellular phone.

#### In other situations

Even though all conceivable measures have been taken, the symptom status does not change.

The cellular phone is not close enough to this system.

→ Bring the cellular phone closer to this system.

The cellular phone is the most likely cause of the symptom.

- → Turn the cellular phone off, remove and reinstall the battery pack, and then restart the cellular phone.
- → Enable the cellular phone's Bluetooth® connection.
- ightarrow Stop the cellular phone's security software and close all applications.
- → Before using an application installed on the cellular phone, carefully check its source and how its operation might affect this system.

### Bluetooth<sup>®</sup>

#### ■ When using the Bluetooth® audio system

- In the following conditions, the system may not function.
  - · If the portable audio player is turned off
  - If the portable audio player is not connected
  - If the portable audio player's battery is low
- ●There may be a delay if a cellular phone connection is made during Bluetooth<sup>®</sup> audio play.
- Depending on the type of portable audio player that is connected to the system, operation may differ slightly and certain functions may not be available.

#### ■When using the hands-free system

- The multimedia system is muted when making a call.
- If both parties speak at the same time, it may be difficult to hear.
- If the received call volume is overly loud, an echo may be heard.
  If the Bluetooth<sup>®</sup> phone is too close to the system, quality of the sound may deteriorate and connection status may deteriorate.
- In the following circumstances, it may be difficult to hear the other party:
  - · When driving on unpaved roads
  - · When driving at high speeds
  - If a roof or window is open
  - If the air conditioning is blowing directly on the microphone
  - · If there is interference from the network of the cellular phone

#### ■ Conditions under which the system will not operate

- If using a cellular phone that does not support Bluetooth®
- If the cellular phone is turned off
- If you are outside of cellular phone service coverage
- If the cellular phone is not connected
- If the cellular phone's battery is low
- When outgoing calls are controlled, due to heavy traffic on telephone lines, etc.
- When the cellular phone itself cannot be used
- When transferring contact data from the cellular phone

#### ■ Bluetooth<sup>®</sup> antenna

The antenna is built into the display.

If the portable audio player is behind the seat or in the glove box or console box, or is touching or covered by metal objects, the connection status may deteriorate.

If the cellular phone is behind the seat or in the console box, or touching or covered by metal objects, the connection status may deteriorate.

#### ■ Battery charge/signal status

- This display may not correspond exactly with the portable audio player or cellular phone itself.
- This system does not have a charging function.
- The portable audio player or cellular phone battery will be depleted quickly when the device is connected to Bluetooth<sup>®</sup>.

# ■When using the Bluetooth<sup>®</sup> audio and hands-free system at the same time

The following problems may occur.

- The Bluetooth<sup>®</sup> audio connection may be interrupted.
- Noise may be heard during Bluetooth<sup>®</sup> audio playback.

#### ■ About the contact in this system

The following data is stored for every registered cellular phone. When another phone is connecting, you cannot read the registered data.

- Contact data
- Call history
- Favorite
- Message

When removing a Bluetooth<sup>®</sup> phone from the system, the above-mentioned data is also deleted.

#### ■ Compatible models

The Bluetooth® audio system supports portable audio players with the following specifications

Bluetooth<sup>®</sup> specifications:

Ver. 2.0, or higher (Recommended: Ver. 3.0+EDR or higher)

- Profiles:
  - A2DP (Advanced Audio Distribution Profile) Ver. 1.0, or higher (Recommended: Ver. 1.2 or higher)

This is a profile to transmit stereo audio or high quality sound to the multimedia system.

 AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Recommended: Ver. 1.4 or higher)

This is a profile to allow remote control the A/V equipment.

However, please note that some functions may be limited depending on the type of portable audio player connected.

The hands-free system supports cellular phones with the following specifications.

Bluetooth<sup>®</sup> specification:

Ver. 2.0 or higher (Recommended: Ver. 3.0+EDR or higher)

- Profiles:
  - HFP (Hands Free Profile) Ver. 1.0 or higher (Recommended: Ver. 1.6 or higher)

This is a profile to allow hands-free phone calls using a cellular phone or head set. It has outgoing and incoming call functions.

- OPP (Object Push Profile) Ver. 1.1 or higher (Recommended: Ver. 1.2)
   This is a profile to transfer contact data. When a Bluetooth<sup>®</sup> compatible cellular phone has both PBAP and OPP, OPP cannot be used.
- PBAP (Phone Book Access Profile) Ver. 1.0 or higher (Recommended: Ver. 1.1)

This is a profile to transfer contact data.

• MAP (Message Access Profile) Ver.1.0 or higher This is a profile to using phone message.

If the cellular phone does not support HFP, you cannot register it with the hands-free system. OPP, PBAP or MAP services must be selected individually.

#### ■ Certification

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### CAUTION:

#### Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 20 cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

#### Co-location:

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

#### ■ Reconnecting the portable audio player

If the portable audio player is disconnected due to poor reception when the power switch is in ACCESSORY or ON mode, the system automatically reconnects the portable audio player.

If you have switched off the portable audio player yourself, follow the instructions below to reconnect:

- Select the portable audio player again
- Enter the portable audio player

#### ■ When you sell your car

Be sure to delete your personal data. (→P. 259)

#### **WARNING**

#### While driving

Do not use the portable audio player, cellular phone or connect a device to the Bluetooth® system.

#### ■ Caution regarding interference with electronic devices

- Your audio unit is fitted with Bluetooth® antennas. People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the Bluetooth® antennas. The radio waves may affect the operation of such devices.
- Before using Bluetooth<sup>®</sup> devices, users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.



#### NOTICE

#### When leaving the vehicle

Do not leave your portable audio player or cellular phone in the vehicle. The inside of the vehicle may become hot, causing damage to the portable audio player or cellular phone.

# **Voice command system**


The voice command system enables the hands-free system to be operated using voice commands.

Operations of the voice command system can be performed by selecting the menu corresponding to each function on the screen. Even if any menu is selected, commands displayed on all menus can be operated.

#### Using the voice command system

1 Press the talk switch.

To cancel the voice command system, press and hold the talk switch.



After a beep sounds, say the desired command.

On the list screen, you can select the desired command.

#### ■ Microphone

→P. 297

#### ■When using the microphone

- It is unnecessary to speak directly into the microphone when giving a command.
- •When "Voice Prompt Interrupt" set to on, it is not necessary to wait for the confirmation beep before speaking a command. (→P. 262)
- Voice commands may not be recognized if:
  - Spoken too quickly.
  - Spoken at a low or high volume.
  - The roof or windows are open.
  - Passengers are talking while voice commands are spoken.
  - The air conditioning speed is set high.
  - The air conditioning vents are turned towards the microphone.
- In the following conditions, the system may not recognize the command properly and using voice commands may not be possible:
  - The command is incorrect or unclear. Note that certain words, accents or speech patterns may be difficult for the system to recognize.
  - There is excessive background noise, such as wind noise.

#### Casual speech recognization

Due to natural language speech recognition technology, this system enables recognition of a command when spoken naturally. However, the system cannot recognize every variation of each command.

In some situations, it is possible to omit the command for the procedure and directly state the desired operation.

Not all voice commands are displayed in the short cut menu.

This function is available in English, Spanish and French.

#### **■** Expression examples for each function

Command	Expression examples	
"Call <name> <type>"</type></name>	Get me <robert brown="">. I need to call <robert brown=""> at <work> right away.</work></robert></robert>	
"Dial <number>"</number>	Please dial the number <3334445555>. Ring <3334445555>.	

#### **Command list**

Some recognizable voice commands and their actions are shown below as examples.

#### Basic

Command	Action
	Prompts voice guidance to offer examples of commands or operation methods
"Go Back"	Returns to the previous screen

## ▶ Phone

Command	Action		
"Redial"	Places a call to the phone number of the latest outgoing call		
"Call Back"	Places a call to the phone number of latest incoming call		
"Show Recent Calls"	Displays the call history screen		
"Dial <phone num-<br="">ber&gt;"</phone>	Places a call to the said phone number		
"Call <contacts> <phonetypes>"</phonetypes></contacts>	Place a call to the said phone type of the contact from the phone book		


# **Interior features**

6-1.	Using the air conditioning system	6-3.	Using the storage features	
	and defogger Automatic air conditioning		List of storage features	
6-2.	Automatic air conditioning system	6-4.	List of storage features  Glove box  Console box  Coin holder  Bottle holders  Cup holders  Auxiliary boxes  Open tray  Trunk features  Other interior features  Sun visors  Vanity mirrors  Clock  Ashtray  Power outlets  Armrest  Assist grips	344 345 345 346 352 353 354 354 355 355 356 356
			Coat hooks	359
			Garage door opener	
			Safety Connect	
			Compass	3/(

# **Automatic air conditioning system**

Air outlets and fan speed are automatically adjusted according to the temperature setting.

#### Air conditioning controls



#### Adjusting the temperature setting

To adjust the temperature setting, turn clockwise to increase the temperature and counterclockwise to decrease the temperature.

#### ■ Fan speed setting


Press vor to turn the fan off.

#### ■ Change the airflow mode

To change the airflow mode, press .

The air outlets used are switched each time the button is pressed.

- (1) Air flows to the upper body.
- 2 Air flows to the upper body and feet.
- 3 Air flows to the feet.
- 4 Air flows to the feet and the windshield defogger operates.



#### Using automatic mode

1 Press Auto .

The dehumidification function begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

- 2 Adjust the temperature setting.
- 3 To stop the operation, press (soff).

#### Automatic mode indicator

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated are maintained.

■ Adjusting the temperature for driver and passenger seats separately ("SYNC" mode)

To turn on the "SYNC" mode, perform any of the following procedures:

- Press sync .
- Adjust the passenger's side temperature setting.

The indicator comes on when the "SYNC" mode is on.

While in "SYNC" mode, the temperature of the rear air outlets is set at the driver's side temperature setting.

#### Other functions

#### ■ Switching between outside air and recirculated air modes

Press .

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time  $\sqrt{2}$  is pressed.

#### ■ Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press 📮

The dehumidification function operates and fan speed increases. Set the outside/recirculated air mode button to the outside air mode if the recirculated air mode is used. (It may switch automatically.) To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press again when the windshield is defogged.

#### ■ Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press .


The defoggers will automatically turn off after a period of time.

#### Air outlets

#### ■ Location of air outlets


The air outlets and air volume change according to the selected airflow mode.

\*: If equipped




# ■ Adjusting the position of and opening and closing the air outlets

▶ Front



► Rear (if equipped)



- (1) Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

#### ■ Operation of the air conditioning system in Eco drive mode

In Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency:

- Engine speed and compressor operation controlled to restrict heating/cooling capacity
- Fan speed restricted when automatic mode is selected

To improve air conditioning performance, perform the following operations:

- Adjust the fan speed
- Turn off Eco drive mode

#### ■ Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and the ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after is pressed.

#### ■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high.
  Turning no will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn □ off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

#### ■Windshield fog detection function

When automatic mode is set, the humidity sensor ( $\rightarrow$ P. 338) detects fog on the windshield and controls the air conditioning system to prevent fog.

#### Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

# ■When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on

- In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce fuel consumption.
- Recirculated air mode is selected as a default mode when the power switch is turned to ON mode.
- It is possible to switch to outside air mode at any time by pressing

#### ■When the outside temperature is low

The dehumidification function may not operate even when  $\sqrt{R}$  is pressed.

#### Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
  - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
  - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

#### ■ Air conditioning filter

→P. 421

#### Customization


The air conditioning control of Eco drive mode can be changed to the same setting as that used in normal drive mode. (Customizable features →P. 530)



### **WARNING**

#### ■ To prevent the windshield from fogging up

- during cool air operation in extremely humid weather. Do not use \( \subseteq \) The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed. preventing the windshield defoggers from defogging.



#### ■ To prevent burns

Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.

## $\triangle$


#### NOTICE

#### Humidity sensor

In order to detect fog on the windshield, a sensor which monitors the temperature of the windshield, the surround humidity, etc. is installed.  $(\rightarrow P. 336)$ 

Follow these points to avoid damaging the sensor:

- Do not disassemble the sensor
- Do not spray the glass cleaner on the sensor or subject it to strong impacts
- Do not stick anything on the sensor



#### ■To prevent 12-volt battery discharge

Do not leave the air conditioning system on longer than necessary when the hybrid system is off.


## Seat heaters\*

#### WARNING

- Care should be taken to prevent injury if anyone in the following categories comes in contact with the seats when the heater is on:
  - · Babies, small children, the elderly, the sick and the physically challenaed
  - · Persons with sensitive skin
  - · Persons who are fatiqued
  - · Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Observe the following precautions to prevent the minor burns or overheating
  - · Do not cover the seat with a blanket or cushion when using the seat heater.
  - Do not use seat heater more than necessary.


#### NOTICE

- Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.
- To prevent 12-volt battery discharge, do not use the functions when the power is off.
- (1) Turns the seat heater on The indicator light comes on.
- (2) Adjusts the seat temperature The further you move the dial forward. the warmer the becomes.



- The seat heaters can be used when the power switch is in ON mode.
- When not in use, move the dial fully backward. The indicator light will turn off.


# Interior lights list



- (1) Rear interior/personal lights (vehicles with moon roof) (→P. 341)
- (2) Interior light (vehicles without moon roof) (→P. 341)
- ③ Front interior/personal lights (vehicles with moon roof) or personal lights (vehicles without moon roof) (→P. 341)
- (4) Shift lever light (vehicles with moon roof)
- (5) Power switch light
- (6) Door courtesy lights


#### Interior lights

Vehicles without moon roof



- (1) Turns the lights on
- 2 Turns the lights on/off linked to door positions.
- (3) Turns the lights off

▶ Vehicles with moon roof




- 1 Turns the lights on/off linked to door positions.
- Turns the lights on/off The rear interior lights will turn on/ off together with the front interior lights.


#### **Personal lights**

Turns the lights on/off

▶ Front



► Rear (vehicles with moon roof)




• Illuminated entry system:

The lights automatically turn on/off according to the power switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are open/closed.

- If the following lights are left on when the power switch is turned off, the lights will go off automatically after 20 minutes:
  - · Interior lights
  - · Personal lights
  - Door courtesy lights
- Setting (e.g. the time elapsed before lights turn off) can be changed. (Customizable features: →P. 530)

# List of storage features



1 Auxiliary boxes	(→P. 347)	(4) Cup holders	(→P. 346)
-------------------	-----------	-----------------	-----------

(2) Glove box (5) Open tray (→P. 344) (→P. 352)

(3) Bottle holders/door pockets (6) Console box (→P. 344) (→P. 345) (7) Coin holder (→P. 345)


#### **WARNING**

- Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:
  - · Glasses may be deformed by heat or cracked if they come into contact with other stored items.
  - Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.
- When driving or when the storage compartments are not in use, keep the lids closed.

In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open lid or the items stored inside.


#### Glove box

- 1 Open (press the button)
- 2 Lock with the mechanical key
- 3 Unlock with the mechanical key




#### Console box


Lift the lid while pulling up the lever to release the lock.




• When using the console box lid as an armrest, slide the console box lid forward as needed. Slide the lid forward while pulling up the lever.



 The lid can also be opened from the forwardmost position.




The console box is provided with a cutout that allows cables to be routed from the power outlet in the console box with the lid closed.




#### Coin holder

Pull the lid down while pressing down the button.




#### **Bottle holders**

▶ Front



▶ Rear



- When storing a bottle, close the cap.
- The bottle may not be stored depending on its size or shape.



#### **WARNING**

Do not place anything other than a bottle in the bottle holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury.




#### NOTICE

Put the cap on before stowing a bottle. Do not place open bottles in the bottle holders, or glass or paper cups containing liquid. The contents may spill and glass cups may break.

#### **Cup holders**

#### ▶ Front




#### Rear



Pull the armrest down.

The insert for the front cup holders can be removed for cleaning.






#### **WARNING**

- Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking, causing injury.
- To prevent burns, cover hot drinks when placed in the cup holders.

### Auxiliary boxes


▶ Type A

Push the lid.




► Type B

Push the lid.




► Type C (if equipped)



#### ■ Cable pass through (type B)

The auxiliary box is provided with a groove that allows cables to be routed from the power outlet in the auxiliary box with the lid closed.



#### ■ When using wireless charger (if equipped)


A mobile device can be charged wirelessly on the tray.

Charging can only be performed with the power switch in ACCESSORY or ON mode and only on mobile devices with the " i logo.

- ① Open the lid and press the wireless charger switch.
- ② Place a mobile device on the tray as shown in the illustration.

An amber indicator is illuminated while charging is in progress. When charging is complete, a green indicator will also be illuminated.

Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.



When placing the mobile device on the wireless charging surface of the tray, make sure that there are no objects in-between the mobile device and the tray. They may interfere with charging.

#### ■ If the wireless charger LED indicators flash

If the wireless charging surface of the tray becomes too hot, the LED indicators will flash and charging is canceled. The LED indicators will be illuminated if the surface of the tray cools down.

If the LED indicators flash even though the surface of the tray is not hot, the wireless charger may be malfunctioning. Consult your Toyota dealer.

#### ■ When charging of the wireless charger stops temporarily

If any of the following operations are performed with the electronic key present, charging may stop temporarily. Charging will start again after a while.

- Locking/unlocking the doors by touching the door handle
- Opening/closing the doors
- Opening/closing the trunk lid
- Starting the hybrid system
- Locking the doors by pressing the lock button on the electronic key
- When the electronic key is out of the detection area

#### **■** Certification for the wireless charger

▶ For vehicles sold in the U.S.A.

This device complies with Part 18 of the FCC Rules.

Toyota Motor Sales, U.S.A., Inc. 19001 S. Western Avenue Torrance, CA 90501

▶ For vehicles sold in Canada

This ISM device complies with Canadian ICES-001. Cet appareil ISM est conforme à la norme NMB-001 du Canada.

## **WARNING**

#### ■Items unsuitable for storing (type A only)

Do not store items heavier than 0.4 lb. (0.2 kg).

Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.

- Caution regarding interference with electronic devices (vehicles with a wireless charger)
  - People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the wireless charger. The radio waves may affect the operation of such devices.
  - Before using the wireless charger, users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.
  - To avoid interference with other electrical devices, turn the wireless charger off by turning off the wireless charger switch.

#### To prevent damage or fire (vehicles with a wireless charger) Observe the following precautions.

Failure to do so may result in the possibility of equipment failure or damage, vehicle fire, burns due to heat, or even electrical shock.

- Do not put any metallic objects between the charging area and the portable device.
- Do not place anything but a device to be charged on the wireless charger. It is not designed for use as an auxiliary box.
- Do not apply force or impact to the wireless charger.
- Do not disassemble or modify the wireless charger.
- Do not attempt to charge portable devices which are not compatible with the Qi wireless charging standard.
- Do not bring magnetized objects close to the wireless charger.
- Do not perform charging if the charging area is dusty.
- Keep foreign objects away from the wireless charger, and do not spill liquid on the wireless charger.
- Do not cover the wireless charger with a cloth or other object while charging.
- Do not attach metallic objects, such as aluminum stickers, to the charging area.



#### NOTICE

Conditions in which the wireless charger may not operate correctly (vehicles with a wireless charger)

In the following situations, the wireless charger may not operate correctly:


- When a portable device is fully charged
- When there is a foreign object between the charging area and portable device
- When a portable device becomes hot while charging
- When a portable device is placed on the wireless area with its charging surface facing up
- When a portable device is not centered on the charging area
- When the vehicle is near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When the portable device is in contact with, or is covered by any of the following metallic objects
  - Cards to which aluminum foil is attached
  - · Cigarette boxes that have aluminum foil inside
  - · Metallic wallets or bags
  - Coins
  - · Metal hand warmers
  - · Media such as CDs and DVDs
- When wireless keys (that emit radio waves) other than those of your vehicle are being used nearby.

If in situations other than above the wireless charger does not operate properly or the operation indicator light is blinking, the wireless charger may be malfunctioning. Contact your Toyota dealer.

- To prevent failure or damage to data (vehicles with a wireless charger)
  - Do not bring magnetic cards, such as a credit card, or magnetic recording media, close to the wireless charger. Otherwise, data may be erased due to the influence of magnetism.
    - Additionally, do not bring precision instruments such as wrist watches, close to the wireless charger, as such objects may malfunction.
  - Do not leave portable devices in the cabin. The temperature inside the cabin may become high when parked in the sun, and cause damage to the device.
- To prevent 12-volt battery discharge (vehicles with a wireless charger)

  Do not use the wireless charger for a long period of time with the hybrid system is stopped.

#### **Open tray**




#### **WARNING**

Observe the following precautions when putting items in the open tray. Failure to do so may cause items to be thrown out of the tray in the event of sudden braking or steering. In these cases, the items may interfere with pedal operation or cause driver distraction, resulting in an accident.

- Do not store items in the tray that can easily shift or roll out.
- Do not stack items in the tray higher than the tray's edge.
- Do not put items in the tray that may protrude over the tray's edge.

# Trunk features

### **Grocery bag hooks**






To prevent damage to the hooks, do not apply too much load to the hooks.

# **Other interior features**

#### Sun visors


- 1) To set the visor in the forward position, flip it down.
- ② To set the visor in the side position, flip down, unhook, and swing it to the side.
- 3 To use the side extender, place the visor in the side position, then slide it backward.



#### Vanity mirrors

Slide the cover to open.

Vehicles with vanity lights: The light turns on when the cover is opened.



Vehicles with vanity lights: If the vanity lights remain on for 20 minutes while the power is off, the lights will turn off automatically.


The clock on the Entune Audio can be adjusted by the following procedure.

For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MAN-UAL".

Press the "SETUP" button and select "General" and then select "Clock".

- 1 Adjust hour/minute
- (2) Switch AM/PM
- (3) Rounds to the nearest hour\*
- (4) Displays in the 24-hour/12-hour format


\*e.g.: 1:00 to 1:29  $\rightarrow$  1:00 1:30 to 2:00  $\rightarrow$  2:00



- The clock is displayed when the power switch is in ACCESSORY or ON mode.
- When disconnecting and reconnecting 12-volt battery terminals, the clock will automatically be set to --:--.

#### Ashtray (if equipped)

An ashtray can be installed in the cup holder. ( $\rightarrow$ P. 346)



### **WARNING**

- When not in use, keep the ashtray closed. In the event of sudden braking, an accident may occur due to an occupant being struck by the open ashtray or ash flying out.
- To prevent fire, fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- To prevent fire, do not place paper or any other type of flammable object in the ashtray.


#### Power outlets

Please use as a power supply for electronic goods that use less than 12 VDC/10 A (power consumption of 120 W).


When using electronic goods, make sure that the power consumption of all the connected power outlets is less than 120 W.


▶ Instrument cluster

Open the auxiliary box lid ( $\rightarrow$ P. 347) and open the lid.



Open the console box lid ( $\rightarrow$ P. 344) and open the lid.





- The power outlets can be used when, the power switch is in ACCESSORY or ON mode.
- Cable pass through
  - →P. 345, 347




#### NOTICE

- To avoid damaging the power outlets, close the power outlet lids when the power outlets are not in use.
  - Foreign objects or liquids that enter the power outlets may cause a short circuit.
- To prevent 12-volt battery discharge, do not use the power outlets longer than necessary when the hybrid system is off.

#### **Armrest**

Fold down the armrest for use.






#### NOTICE

To prevent damage to the armrest, do not apply too much load on the armrest.

### **Assist grips**

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.





### **WARNING**

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.




#### **NOTICE**

To prevent damage to the assist grip, do not put a heavy load on the assist grip.

## Coat hooks

Coat hooks are provided on the rear assist grips.





## **MARNING**

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

## Garage door opener\*


The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

The garage door opener (HomeLink<sup>®</sup> Universal Transceiver) is manufactured under license from HomeLink<sup>®</sup>.

## Programming HomeLink® (for U.S. owners)

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.

- 1 Buttons
- (2) Indicator




## **■ Programming the HomeLink**®

Point the remote control transmitter for the device 1 to 3 in. (25 to 75 mm) from the HomeLink® control buttons.


Keep the HomeLink® indicator

Keep the HomeLink® indicator light in view while programming.





Press and hold one of the HomeLink® buttons and the transmitter button. When the HomeLink® indicator light changes from a slow to a rapid flash, you can release both buttons.

If the HomeLink® indicator light comes on but does not flash, or flashes rapidly for 2 seconds and remains lit, the HomeLink® button is already programmed. Use the other buttons or follow the "Reprogramming a HomeLink® button" instructions.  $(\rightarrow P.~363)$ 



If a HomeLink® button has been programmed for a garage door, check to see if the garage door opens and closes. If the garage door does not operate, see if your remote control transmitter is of the rolling code type. Press hold the programmed and HomeLink® button. The remote control transmitter is of the rolling code type if the HomeLink® indicator light flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the rolling code type, proceed to the heading "Programming a Rolling Code system".





Repeat the steps above to program another device for any of the remaining HomeLink<sup>®</sup> buttons.

#### ■ Programming a Rolling Code system (for U.S. owners)

If your device is Rolling Code equipped, follow the steps under the heading "Programming HomeLink  $^{\circledR}$ " before proceeding with the steps listed below.

1 Locate the learn button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener motor.

Refer to the operation manual supplied with the garage door opener motor for the location of the learn button.

2 Press the learn button.

Following this step, you have 30 seconds in which to initiate step 3 below.

3 Press and hold the vehicle's programmed HomeLink<sup>®</sup> button for 2 seconds and then release it. Repeat this step once again. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink® signal and operate the garage door.

Repeat the steps above to program another rolling code system for any of the remaining HomeLink<sup>®</sup> buttons.

# ■ Programming an entry gate (for U.S. owners)/Programming a device in the Canadian market

1 Place the remote control transmitter 1 to 3 in. (25 to 75 mm) away from the HomeLink<sup>®</sup> buttons.

Keep the HomeLink® indicator light in view while programming.

- Press and hold the selected HomeLink® button.
- 3 Repeatedly press and release (cycle) the remote control transmitter for 2 seconds each until step 4 is completed.
- 4 When the HomeLink® indicator light starts to flash rapidly, release the buttons.
- 5 Test the HomeLink® operation by pressing the newly programmed button. Check to see if the gate/device operates correctly.
- Repeat the steps above to program another device for any of the remaining HomeLink<sup>®</sup> buttons.

#### ■ Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your Toyota dealer for assistance.

#### ■ Reprogramming a button

The individual HomeLink<sup>®</sup> buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the "Reprogramming a HomeLink<sup>®</sup> button" instructions.

### Operating HomeLink®

Press the appropriate  $\mathsf{HomeLink}^{\otimes}$  button. The  $\mathsf{HomeLink}^{\otimes}$  indicator light should come on.

The HomeLink® compatible transceiver in your vehicle continues to send a signal for up to 20 seconds as long as the button is pressed.


## Reprogramming a HomeLink® button

Press and hold the desired HomeLink<sup>®</sup> button. After 20 seconds, the HomeLink<sup>®</sup> indicator light will start flashing slowly. Keep pressing the HomeLink<sup>®</sup> button and press and hold the transmitter button until the HomeLink<sup>®</sup> indicator light changes from a slow to a rapid flash. Release the buttons.

### Erasing the entire HomeLink® memory (all three programs)

Press and hold the 2 outside buttons for 10 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the  $\operatorname{HomeLink}^{\circledcirc}$  memory.



#### ■ Before programming

- Install a new battery in the remote control transmitter.
- The battery side of the remote control transmitter must be pointed away from the Homel ink® button.

#### ■ To prevent 12-volt battery discharge

HomeLink® will turn off if a door has not been opened and closed for 20 minutes or the power switch is left turned off. (After which programming cannot be completed.) Open and close a door or turn the power switch to ACCES-SORY mode to turn HomeLink® on. We recommend programming while the power switch is in ACCESSORY mode.

#### Certification for the garage door opener

▶ U.S.A.

FCC ID: CB2051AHI 4/CB251AHI 4NR

#### NOTF:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC WARNING:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ▶ Canada

IC ID: 051AHI 4/51AHI 4NR

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### ■ When support is necessary

Visit on the web at www.homelink.com or call 1-800-355-3515.



#### **WARNING**

#### ■When programming a garage door or other remote control devices

The garage door or other devices may operate, so ensure people and objects are out of danger to prevent potential harm.

#### Conforming to federal safety standards

Do not use the HomeLink® compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an interfering object. A door or device without these features increases the risk of death or serious injury.

## Safety Connect\*


Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Toyota's designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at Toyota.com. All use of the Safety Connect service is subject to such then-applicable Terms and Conditions.

#### ■ System components

- (1) Microphone
- (2) LED light indicators
- (3) "SOS" button



#### Services

Subscribers have the following Safety Connect services available:

- Automatic Collision Notification\*
   Helps drivers receive necessary response from emergency service providers. (→P. 367)
- \*: U.S. Patent No. 7,508,298 B2
- Stolen Vehicle Location
   Helps drivers in the event of vehicle theft. (→P. 368)
- Emergency Assistance Button (SOS)
   Connects drivers to response-center support. (→P. 368)
- Enhanced Roadside Assistance
   Provides drivers various on-road assistance. (→P. 368)

#### ■ Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms are available for purchase. Contact your Toyota dealer, call 1-800-331-4331, or push the "SOS" button in your vehicle for further subscription details.

#### ■ Safety Connect Services Information

- Phone calls using the vehicle's Bluetooth® technology will not be possible during Safety Connect.
- Safety Connect is available beginning Fall 2009 on select Toyota models. Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or receive emergency service support. Enrollment and Telematics Subscription Service Agreement are required. A variety of subscription terms are available; charges vary by subscription term selected.
- Automatic Collision Notification, Emergency Assistance, Stolen Vehicle Location, and Enhanced Roadside Assistance will function in the United States, including Hawaii and Alaska, and in Canada. No Safety Connect services will function outside of the United States in countries other than Canada.
- Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

#### Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English and Spanish. Please indicate your language of choice when enrolling.

#### ■When contacting the response center

You may be unable to contact the response center if the network is busy.

#### **Safety Connect LED light Indicators**

When the power switch is turned to ON mode, the red indicator light comes on for 2 seconds then turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

- Green indicator light on = Active service
- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Toyota dealer)
- No indicator light (off) = Safety Connect service not active

#### **Safety Connect services**

#### Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

#### Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-331-4331 and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Toyota.com.

#### ■ Emergency Assistance Button ("SOS")

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

#### ■ Enhanced Roadside Assistance

Enhanced Roadside Assistance adds GPS data to the already included warranty-based Toyota roadside service.

Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Enhanced Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Toyota.com.

#### Safety information for Safety Connect

Important! Read this information before using Safety Connect.

#### **■** Exposure to radio frequency signals

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement) Report 86 [1986]
- ICNIRP (International Commission on Non-lonizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

#### ■ Certification for Safety Connect

FCC ID: O6Y-CDMRF101 FCC ID: XOECDMRF101B

FCC ID: N7NGTM2

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Compass\*

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

#### Operation


To turn the compass on or off, press and hold the switch for 3 seconds.



## Displays and directions

Display	Direction
N	North
NE	Northeast
E	East
SE	Southeast
S	South
SW	Southwest
W	West
NW	Northwest

#### Calibrating the compass



The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.


If you cross over a map boundary shown in illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to the following.

#### ■ Deviation calibration

- 1 Stop the vehicle.
- 2 Press and hold the switch.

A number (1 to 15) appears on the compass display.




Press the switch and referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.

#### ■ Circling calibration

When "C" appears on the display, drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until a direction is displayed.



#### ■ Conditions unfavorable to correct operation

The compass may not show the correct direction in the following conditions:

- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized.
   (There is a magnet or metal object near the inside rear view mirror.)
- The 12-volt battery has been disconnected.
- A door is open.



#### WARNING

#### ■While driving the vehicle

Do not adjust the display. Adjust the display only when the vehicle is stopped.

#### ■When doing the circling calibration

Secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.



#### **NOTICE**

#### ■To avoid compass malfunctions

Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause the compass sensor to malfunction.

#### ■To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.

## **Maintenance and care**

7-1.	Maintenance and care	
	Cleaning and protecting	
	the vehicle exterior	376
	Cleaning and protecting	
	the vehicle interior	379
7-2.	Maintenance	
	Maintenance	
	requirements	
	General maintenance	385
	Emission inspection and	
	maintenance (I/M)	
	programs	389
7-3.	,	
	maintenance	
	Do-it-yourself service	000
	precautions	
	Hood	
	Positioning a floor jack	
	Engine compartment	
	12-volt battery	
	Tires	406
	Tire inflation pressure	416
	Wheels	419
	Air conditioning filter	421
	Electronic key battery	423
	Checking and replacing	
	fuses	425
	Light bulbs	428

# Cleaning and protecting the vehicle exterior

## Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.
   If water does not bead on a clean surface, apply wax when the vehicle body is cool.

#### ■ Automatic car washes

- Fold the mirrors before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.
- Vehicles with rear spoiler: In certain automatic car washes, the rear spoiler may interfere with machine operation. This may prevent the vehicle from being cleaned properly or result in damage to the rear spoiler.

#### ■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

#### ■When using a car wash

If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:

- Place the key in a position 6 ft. (2 m) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart key system.  $(\rightarrow P. 123)$

#### ■ Aluminum wheels (if equipped)

Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners.

Use the same mild detergent and wax as used on the paint.

- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

#### Bumpers

Do not scrub with abrasive cleaners.



#### WARNING

#### When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

#### Precautions regarding the exhaust pipes

Exhaust gasses cause the exhaust pipes to become guite hot.

When washing the vehicle, be careful not to touch the pipes until it has cooled sufficiently, as touching a hot exhaust pipes can cause burns.

#### ■Precaution regarding the rear bumper with Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, avoid using the system and consult your Toyota dealer.



- To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)
  - Wash the vehicle immediately in the following cases:
    - · After driving near the sea coast
    - · After driving on salted roads
    - If coal tar or tree sap is present on the paint surface
    - If dead insects, insect droppings or bird droppings are present on the paint surface
    - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
    - · If the vehicle becomes heavily soiled with dust or mud
    - · If liquids such as benzene and gasoline are spilled on the paint surface
  - If the paint is chipped or scratched, have it repaired immediately.
  - To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

#### Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax to the surfaces of the lights.
   Wax may cause damage to the lenses.

# Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

#### Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

#### Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.
  - Use a diluted water solution of approximately 5% neutral wool detergent.
- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

#### Cleaning the synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

#### Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

#### ■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

#### ■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.



#### WARNING

#### Water in the vehicle

- Do not splash or spill liquid in the vehicle, such as on the floor, in the hybrid battery (traction battery) air vent, and in the trunk. Doing so may cause the hybrid battery, electrical components, etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet.  $(\to P. 38)$ 
  - An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.
- Vehicles with wireless charger: Do not let the wireless charger (→P. 348) get wet. Failure to do so may cause the charger to become hot and cause burns or could cause electric shock resulting in death or serious injury.

#### Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.



#### NOTICE

#### Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
  - Non-seat portions: Organic substances such as benzene or gasoline. alkaline or acidic solutions, dve, and bleach
  - · Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

#### Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer.
- Do not place items made of vinvl. plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

#### Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

#### ■When cleaning the inside of the windshield (vehicles with LDA [Lane Departure Alert] and Automatic High Beam)

Be careful not to touch the camera sensor ( $\rightarrow$ P. 202).

If the camera is accidentally scratched or hit, LDA and Automatic High Beam may not operate properly or may cause a malfunction.

#### Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

## **Maintenance requirements**

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. It is the owner's responsibility to perform regular checks. Toyota recommends the following maintenance:

#### General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Toyota dealer.

#### Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

#### Do-it-yourself maintenance

You can perform some maintenance procedures by yourself.

Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Toyota Repair Manuals is recommended.

For details about warranty coverage, refer to the separate "Owner's Warranty Information Booklet" or "Owner's Manual Supplement".

#### ■ Repair and replacement

It is recommended that genuine Toyota parts be used for repairs to ensure performance of each system. If non-Toyota parts are used in replacement or if a repair shop other than a Toyota dealer performs repairs, confirm the warranty coverage.

## ■ Resetting the message indicating maintenance is required (U.S.A. only)

After the required maintenance is performed according to the maintenance schedule, please reset the message.

To reset the message, follow the procedure described below:

- ▶ Using the trip meter
- 1 Turn the power switch off with the trip meter A reading shown.
- 2 While pressing the trip meter reset button (→P. 89), turn the power switch to the ON mode (do not start the hybrid system because otherwise the reset mode will be canceled).
- 3 Continue to press and hold the button until the trip meter displays "000000".
  - ▶ Using the multi-information display
- While the hybrid system is operating, switch the multi-information display to the "Settings" screen. (→P. 88)
- 2 Select "Maintenance Reset" on the "Settings" screen.
- 3 Select "Yes" on the "Maintenance Reset" screen.
- "Maintenance Reset Complete" will be displayed on the multi-information display when the reset procedure has been completed.

#### ■ Allow inspection and repairs to be performed by a Toyota dealer

- Toyota technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Toyota dealer will promptly take care of it.

## **WARNING**

#### If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

#### Handling of the 12-volt battery

- Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- ●12-volt battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. ( $\rightarrow$ P. 402)

## **General maintenance**

Listed below are the general maintenance items that should be performed at the intervals specified in the "Owner's Warranty Information Booklet" or "Owner's Manual Supplement/Scheduled Maintenance Guide". It is recommended that any problem you notice should be brought to the attention of your Toyota dealer or qualified service shop for advice.

### **Engine compartment**

Items	Check points
Brake fluid	Is the brake fluid at the correct level? $(\rightarrow P. 400)$
Coolant	Is the coolant at the correct level? (→P. 398)
Engine oil	Is the engine oil at the correct level? (→P. 395)
Exhaust system	There should not be any fumes or strange sounds.
Radiator/condenser	The radiator and condenser should be free from foreign objects.  (→P. 399)
Washer fluid	Is there sufficient washer fluid? (→P. 401)

#### Trunk

Items	Check points
12-volt battery	Check the connections. (→P. 402)

## Vehicle interior

Items	Check points
Accelerator pedal	The accelerator pedal should move smoothly (without uneven pedal effort or catching).
Hybrid transmission "Park" mechanism	When parked on a slope and the shift lever is in P, is the vehicle securely stopped?
Brake pedal	<ul> <li>Does the brake pedal move smoothly?</li> <li>Does the brake pedal have appropriate clearance from the floor?</li></ul>
Brakes	<ul> <li>The vehicle should not pull to one side when the brakes are applied.</li> <li>The brakes should work effectively.</li> <li>The brake pedal should not feel spongy.</li> <li>The brake pedal should not get too close to the floor when the brakes are applied.</li> </ul>
Head restraints (front seat)	Do the head restraints move smoothly and lock securely?
Indicators/buzzers	Do the indicators and buzzers function properly?
Lights	Do all the lights come on?
Parking brake	<ul> <li>Does the parking brake pedal move smoothly?</li> <li>When parked on a slope and the parking brake is on, is the vehicle securely stopped?</li> </ul>

Items	Check points
Seat belts	<ul> <li>Do the seat belts operate smoothly?</li> <li>The seat belts should not be damaged.</li> </ul>
Seats	Do the seat controls operate properly?
Steering wheel	<ul> <li>Does the steering wheel rotate smoothly?</li> <li>Does the steering wheel have the correct amount of free play?</li> <li>There should not be any strange sounds coming from the steering wheel.</li> </ul>

## Vehicle exterior

Items	Check points
Doors/trunk	Do the doors/trunk operate smoothly?
Engine hood	Does the engine hood lock system work properly?
Fluid leaks	<ul> <li>There should not be any signs of fluid leakage after the vehicle has been parked.</li> </ul>
Tires	<ul> <li>Is the tire inflation pressure correct?</li> <li>The tires should not be damaged or excessively worn.</li> <li>Have the tires been rotated according to the maintenance schedule?</li> <li>The wheel nuts should not be loose.</li> </ul>
Windshield wipers	<ul> <li>The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation.</li> <li>The wiper blades should clear the windshield without streaking or skipping.</li> </ul>



## **MARNING**

#### ■If the hybrid system is operating

Turn the hybrid system off and ensure that there is adequate ventilation before performing maintenance checks.

# **Emission inspection and maintenance (I/M) programs**

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

#### If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Toyota dealer to service the vehicle.

#### Your vehicle may not pass the I/M test in the following situations:

- When the 12-volt battery is disconnected or discharged
   Readiness codes that are set during ordinary driving are erased.
   Also, depending on your driving habits, the readiness codes may not be completely set.
- When the fuel tank cap is loose
   The malfunction indicator lamp comes on indicating a temporary malfunction and your vehicle may not pass the I/M test.

# When the malfunction indicator lamp still remains on after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

#### If your vehicle does not pass the I/M test

Contact your Toyota dealer to prepare the vehicle for re-testing.

## Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

Items	Parts and tools
12-volt battery condition (→P. 402)	Grease     Conventional wrench (for terminal clamp bolts)
Brake fluid level (→P. 400)	<ul> <li>FMVSS No.116 DOT 3 or SAE J1703 brake fluid</li> <li>Rag or paper towel</li> <li>Funnel (used only for adding brake fluid)</li> </ul>
Engine/power control unit coolant level (→P. 398)	<ul> <li>"Toyota Super Long Life Coolant" or a similar high quality ethylene glycol-based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology U.S.A.:</li> <li>"Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water.</li> <li>Canada:</li> <li>"Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water.</li> <li>Funnel (used only for adding coolant)</li> </ul>
Engine oil level (→P. 395)	<ul><li> "Toyota Genuine Motor Oil" or equivalent</li><li> Rag or paper towel</li><li> Funnel (used only for adding engine oil)</li></ul>
Fuses (→P. 425)	Fuse with same amperage rating as original
Light bulbs (→P. 428)	<ul> <li>Bulb with same number and wattage rating as original</li> <li>Phillips-head screwdriver</li> <li>Flathead screwdriver</li> <li>Wrench</li> </ul>
Radiator/con- denser (→P. 399)	
Tire inflation pressure (→P. 416)	Tire pressure gauge     Compressed air source
Washer fluid (→P. 401)	<ul> <li>Water or washer fluid containing antifreeze (for winter use)</li> <li>Funnel (used only for adding water or washer fluid)</li> </ul>



## **WARNING**

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

#### When working on the engine compartment

- Make sure that the "READY" indicator is off.
- Keep hands, clothing and tools away from the moving fans and engine drive belt.
- Be careful not to touch the engine, power control unit, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel. Fuel fumes are flammable.

#### ■When working near the electric cooling fans or radiator grille Be sure the power switch is off.

With the power switch in ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high.  $(\rightarrow P. 399)$ 

#### Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.



#### NOTICE


#### If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.


## Hood

#### Release the lock from the inside of the vehicle to open the hood.

1 Pull the hood lock release lever. The hood will pop up slightly.



2 Pull up the auxiliary catch lever and lift the hood.





## **WARNING**

#### Pre-driving check

Check that the hood is fully closed and locked.


If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

## Positioning a floor jack


When using a floor jack, follow the instructions in the manual provided with the jack and perform the operation safely.

When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.


#### Front



#### Rear



## **Engine compartment**



- 1 Fuse boxes
- (→P. 425)
- (2) Engine oil filler cap (→P. 396)
- ③ Engine oil level dipstick (→P. 395)
- (4) Brake fluid reservoir (→P. 400)
- (5) Engine coolant radiator(→P. 398)


- 6 Power control unit coolant radiator (→P. 398)
- (7) Condenser  $(\rightarrow P. 399)$
- (8) Electric cooling fans
- 9 Engine coolant reservoir(→P. 398)
- (10) Washer fluid tank (→P. 401)
- (1) Power control unit coolant reservoir (→P. 398)

# Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.


# ■ Checking the engine oil

- 1 Park the vehicle on level ground. After warming up the engine and turning it off the hybrid system, wait more than 5 minutes for the oil to drain back into the bottom of the engine.
- 2 Holding a rag under the end, pull the dipstick out.



- 3 Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- 5 Holding a rag under the end, pull the dipstick out and check the oil level.
  - (1) Low
  - (2) Normal
  - (3) Excessive


The shape of the dipstick may differ depending on the type of vehicle or engine.



6 Wipe the dipstick and reinsert it fully.

# ■ Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 501
Oil quantity (Low → Full)	1.6 qt. (1.5 L, 1.3 lmp. qt.)
Items	Clean funnel

- 1 Remove the oil filler cap by turning it counterclockwise.
- 2 Add engine oil slowly, checking the dipstick.
- 3 Install the oil filler cap by turning it clockwise.

# ■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

# **WARNING**

#### Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground.
  - Call your Toyota dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.



#### **NOTICE**

# ■To prevent serious engine damage

Check the oil level on a regular basis.

#### When replacing the engine oil

- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.


#### Coolant

Engine coolant reservoir

The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir when the hybrid system is cold.

- (1) Reservoir cap
- (2) "F" line
- (3) "L" line

If the level is on or below the "L" line, add coolant up to the "F" line.  $(\rightarrow P. 491)$ 




Power control unit coolant reservoir

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the hybrid system is cold.

- (1) Reservoir cap
- (2) "FULL" line
- (3) "LOW" line

If the level is on or below the "LOW" line, add coolant up to the "FULL" line. (→P. 491)



#### ■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

#### U.S.A.:

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: -31°F [-35°C])

#### Canada:

"Toyota Super Long Life Coolant" is a mixture of 55% coolant and 45% deionized water. (Minimum temperature: -44°F [-42°C])

For more details about coolant, contact your Toyota dealer.

### ■ If the coolant level drops within a short time of replenishing

Visually check the radiators, hoses, engine/power control unit coolant reservoir caps, drain cock and water pump.

If you cannot find a leak, have your Toyota dealer test the cap and check for leaks in the cooling system.



#### WARNING

### ■When the hybrid system is hot

Do not remove the engine/power control unit coolant reservoir caps. The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



#### NOTICE

#### When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

#### If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

### Radiator and condenser

Check the radiator and condenser and clear away any foreign objects. If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Toyota dealer.



#### **▲** WARNING

# When the hybrid system is hot


Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

#### **Brake fluid**

# ■ Checking fluid level

The brake fluid level should be between the "MAX" and "MIN" lines on the tank.

- (1) "MAX"
- (2) "MIN"



# Adding fluid

Make sure to check the fluid type and prepare the necessary item.

Fluid type	FMVSS No.116 DOT 3 or SAE J1703 brake fluid
Item	Clean funnel

#### ■ Brake fluid can absorb moisture from the air

Excess moisture in the brake fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.



#### WARNING

### ■When filling the reservoir

Take care as brake fluid can harm your hands and eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.



#### NOTICE


# ■If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear out or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, there may be a serious problem.

#### Washer fluid

If any washer does not work or the warning message appears on the multi-information display. the washer tank may be empty. Add washer fluid. (→P. 461)





# **WARNING**

### When adding washer fluid

Do not add washer fluid when the hybrid system is hot or operating as washer fluid contains alcohol and may catch fire if spilled on the hybrid system etc.



#### NOTICE

#### Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

#### Diluting washer fluid


Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.

# 12-volt battery


# Location

The 12-volt battery is located on the right-hand side of the trunk.




# Removing the 12-volt battery cover

Pull the 12-volt battery cover while pressing down on the tab.



# Installing the 12-volt battery cover


- 1 Install the cover
- ② Lift the tab to secure to the trunk liner



#### Exterior

Make sure that the 12-volt battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.

- (1) Terminals
- (2) Hold-down clamp



#### ■ Before recharging

When recharging, the 12-volt battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following precautions before recharging:

- If recharging with the 12-volt battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the 12-volt battery.

# ■ After recharging/reconnecting the 12-volt battery

- Unlocking the doors using the smart key system may not be possible immediately after reconnecting the 12-volt battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the hybrid system with the power switch in ACCESSORY mode. The hybrid system may not start with the power switch turned off. However, the hybrid system will operate normally from the second attempt.
- ■The power switch mode is recorded by the vehicle. If the 12-volt battery is reconnected, the vehicle will return the power switch mode to the status it was in before the 12-volt battery was disconnected. Make sure to turn off the power before disconnecting the 12-volt battery. Take extra care when connecting the 12-volt battery if the power switch mode prior to discharge is unknown.

If the system will not start even after multiple attempts, contact your Toyota dealer.

# **WARNING**

#### Chemicals in the 12-volt battery

The 12-volt battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the 12-volt battery:

- Do not cause sparks by touching the 12-volt battery terminals with tools.
- Do not smoke or light a match near the 12-volt battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the 12-volt battery.
- Keep children away from the 12-volt battery.

### ■ Where to safely charge the 12-volt battery

Always charge the 12-volt battery in an open area. Do not charge the 12volt battery in a garage or closed room where there is insufficient ventilation.

#### ■ How to recharge the 12-volt battery

Only perform a slow charge (5 A or less). The 12-volt battery may explode if charged at a quicker rate.

#### Emergency measures regarding electrolyte

- If electrolyte gets in your eyes Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte Drink a large quantity of water or milk. Get emergency medical attention immediately.

# ■When replacing the 12-volt battery

Use a 12-volt battery designed for this vehicle. Failure to do so may cause gas (hydrogen) to enter the passenger compartment, causing a fire or explosion.

For replacement of the 12-volt battery, contact your Toyota dealer.



# ♠ NOTICE

# ■When recharging the 12-volt battery

Never recharge the 12-volt battery while the hybrid system is operating. Also, be sure all accessories are turned off.

# Tires


Replace or rotate tires in accordance with maintenance schedules and treadwear.

# **Checking tires**

- 1 New tread
- (2) Treadwear indicator
- (3) Worn tread

The location of treadwear indicators is shown by the "TWI" or " $\Delta$ " marks, etc., molded on the sidewall of each tire.

Check spare tire condition and pressure if not rotated.




#### Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Toyota recommends that tire rotation is carried out at the same interval as tire inspection.


Do not fail to initialize the tire pressure warning system after tire rotation.



# Tire pressure warning system (if equipped)

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

- If the tire pressure drops below a predetermined level, the driver is warned by a screen display and a warning light. (→P. 446)
- The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display.



# ◆ Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valves and transmitter ID codes registered by your Toyota dealer. (→P. 408)

- Initializing the tire pressure warning system
- The tire pressure warning system must be initialized in the following circumstances:
  - When the tire inflation pressure is changed such as when changing traveling speed.
  - When the tire inflation pressure is changed such as when the tire size is changed.
  - When rotating the tires.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.


### ■ How to initialize the tire pressure warning system

- 1 Park the vehicle in a safe place and turn the power switch off. Initialization cannot be performed while the vehicle is moving.
- 2 Adjust the tire inflation pressure to the specified cold tire inflation pressure level. (→P. 505)

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

- 3 Turn the power switch to ON mode.
- Press and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times.
  - "--" will be displayed for inflation pressure of each tire on the multi-information display while the tire pressure warning system determines the position of each tire.

When position of each tire is determined, the inflation pressure of each tire will be displayed on the multi-information display.



5 Drive the vehicle at approximately 25 mph (40 km/h) or more for approximately 10 minutes.

When initialization is complete, the inflation pressure of each tire will be displayed on the multi-information display.

Initialization will take longer than approximately 10 minutes if the vehicle is stopped for a long time, such as at traffic signals.

# Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code. Have the ID code registered by your Toyota dealer.

#### ■When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with your Toyota dealer.

# ■Replacing tires and wheels (vehicles with a tire pressure warning system)

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 10 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

#### ■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.


# ■ Routine tire inflation pressure checks (vehicles with a tire pressure warning system)

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

#### ■ Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.

For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire.  $(\rightarrow P. 510)$ 



### ■ Tire types

#### Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

#### All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions as well as for use year-round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

#### Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. ( $\rightarrow$ P. 242)

# ■Initializing the tire pressure warning system (vehicles with a tire pressure warning system)

Initialize the system with the tire inflation pressure adjusted to the specified level.

# ■ If the tread on snow tires wears down below 0.16 in. (4 mm)

The effectiveness of the tires as snow tires is lost.

### If you press the tire pressure warning reset switch accidentally (vehicles with a tire pressure warning system)

If initialization is performed, adjust the tire inflation pressure to the specified level and initialize the tire pressure warning system again.

# ■ Situations in which the tire pressure warning system may not operate properly (vehicles with a tire pressure warning system)

- In the following cases, the tire pressure warning system may not operate properly.
  - If non-genuine Toyota wheels are used.
  - A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
  - A tire has been replaced with a tire that is not of the specified size.
  - · Tire chains etc. are equipped.
  - If a window tint that affects the radio wave signals is installed.
  - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
  - If the tire inflation pressure is extremely higher than the specified level.
  - If tires not equipped with tire pressure warning valves and transmitters are used.
  - If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- Performance may be affected in the following situations.
  - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
  - When carrying a portable radio, cellular phone, cordless phone or other wireless communication device

If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.

- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

# ■ The initialization operation (vehicles with a tire pressure warning system)

- Make sure to carry out initialization after adjusting the tire inflation pressure.
  - Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
- If you have accidentally turned the power switch off during initialization, it is not necessary to press the reset switch again as initialization will restart automatically when the power switch has been turned to ON mode for the next time.
- If you accidentally press the reset switch when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.
- •While the position of each tire is being determined and the inflation pressures are not being displayed on the multi-information display, if the inflation pressure of a tire drops, the tire pressure warning light will come on.

# ■ Warning performance of the tire pressure warning system (vehicles with a tire pressure warning system)

The warning of the tire pressure warning system will change in accordance with the conditions under which it was initialized. For this reason, the system may give a warning even if the tire pressure does not reach a low enough level, or if the pressure is higher than the pressure that was adjusted to when the system was initialized.

# ■When initialization of the tire pressure warning system has failed (vehicles with a tire pressure warning system)

Initialization may take longer to complete if the vehicle is driven on an unpaved road. When performing initialization, drive on a paved road if possible. Depending on the driving environment and condition of the tires, initialization will be completed in approximately 10 minutes. If initialization is not complete after driving approximately 10 minutes, continue driving for a while.

If the inflation pressure of each tire is not displayed after driving for approximately 1 hour, perform the following procedure.

Park the vehicle in a safe place for approximately 20 minutes. Then drive straight (with occasional left and right turns) at approximately 25mph (40 km/h) or more for approximately 10 to 20 minutes. However, in the following situations, the tire inflation pressure will not be recorded and the system will not operate properly. Perform initialization again.

- •When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After performing initialization, the tire pressure warning light blinks for 1 minute then stays on while driving.

If the inflation pressure of each tire is still not displayed, have the vehicle inspected by your Toyota dealer.

### ■ Tire pressure warning system certification

FCC ID: HYQ23AAP FCC ID: HYQ23AAN FCC ID: HYQ23AAC

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: PAXPMVC015 FCC ID: PAXPMVC010

#### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **MARNING**

### When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.

# ■When initializing the tire pressure warning system (vehicles with a tire pressure warning system)

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.



#### NOTICE

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps (vehicles with a tire pressure warning system)
  - When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Toyota dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
  - When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.
- ■To avoid damage to the tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.  $(\rightarrow P. 407)$ 

■ Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes.


These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

■ If tire inflation pressure of each tire becomes low while driving Do not continue driving, or your tires and/or wheels may be ruined.

# **Tire inflation pressure**


# Tire inflation pressure

The recommended cold tire inflation pressure and tire size are displayed on the tire and loading information label.  $(\rightarrow P. 505)$ 



# Inspection and adjustment procedure

- 1 Tire valve
- (2) Tire pressure gauge



- 1 Remove the tire valve cap.
- Press the tip of the tire pressure gauge onto the tire valve.
- Read the pressure using the gauge gradations.
- If the tire inflation pressure is not at the recommended level, adjust the pressure.

If you add too much air, press the center of the valve to deflate.

- 5 After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- 6 Put the tire valve cap back on.

# ■ Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month.

Do not forget to check the spare.

# **■** Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drivetrain

If a tire needs frequent inflating, have it checked by your Toyota dealer.

#### ■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold. If your vehicle has been parked for at least 3 hours or has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge. The appearance of the tire can be misleading. In addition, tire inflation pressure that is even just a few pounds off can affect ride quality and handling.
- Do not reduce tire inflation pressure after driving. It is normal for tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight. Passengers and luggage weight should be placed so that the vehicle is balanced.



# **MARNING**

### ■ Proper inflation is critical to save tire performance

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards



#### NOTICE

# ■When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps are lost, replace them as soon as possible.

# Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

#### Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset\*.

Replacement wheels are available at your Toyota dealer.

\*: Conventionally referred to as "offset".

Toyota does not recommend using the following:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

### Aluminum wheel precautions (if equipped)

- Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Toyota genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

# When replacing wheels (vehicles with a tire pressure warning system)

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. ( $\rightarrow$ P. 407)


# **⚠** WARNING

### When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.
- •Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

# ■When installing the wheel nuts

Be sure to install the wheel nuts with the tapered ends facing inward. Installing the nuts with the tapered ends facing outward can cause the wheel to break and eventually cause the wheel to come off while driving, which could lead to an accident resulting in death or serious injury.



Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened. leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.



#### NOTICE

### Replacing tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)


- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Toyota dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Toyota dealer.
- Ensure that only genuine Toyota wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

# Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

#### Removal method

- 1 Turn the power switch off.
- 2 Open the glove box and remove the glove box cover inside the glove box.




3 Remove the filter cover.



Remove the air conditioning filter and replace it with a new one.

The "↑UP" marks shown on the filter should be pointing up.



#### ■ Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Schedule maintenance guide" or "Owner's Manual Supplement".)

# ■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.



#### **NOTICE**

# ■ When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

# **Electronic key battery**


# Replace the battery with a new one if it is depleted.

# You will need the following items:

- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2032


# Replacing the battery

1 Take out the mechanical key.




2 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.



Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.



#### ■ Use a CR2032 lithium battery

- Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
- Replace the battery only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to local laws.

#### ■ If the key battery is depleted

The following symptoms may occur:

- The smart key system and wireless remote control will not function properly.
- The operational range will be reduced.



#### WARNING

### Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.



#### NOTICE

#### For normal operation after replacing the battery


Observe the following precautions to prevent accidents:

- Always work with dry hands. Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

- 1 Turn the power switch off.
- 2 Open the fuse box cover.
- Engine compartment (type A)

► Engine compartment (type B)




CTY73BJ056

Push the tabs in and lift the lid off.

Push the tabs in and lift the lid off.


► Under the driver's side instrument panel




Remove the lid.

Remove the fuse with the pullout tool.


Only type A fuses can be removed using the pullout tool.




- 4 Check if the fuse is blown.
- ▶ Type A



▶ Type B



# ▶ Type C



- (1) Normal fuse
- (2) Blown fuse

# Type A and B:

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

### Type C:

Contact your Toyota dealer.

#### ■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. ( $\rightarrow$ P. 428)
- If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

#### If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.

#### ■When replacing light bulbs

Toyota recommends that you use genuine Toyota products designed for this vehicle. Because certain bulbs are connected to circuits designed to prevent overload, non-genuine parts or parts not designed for this vehicle may be unusable.



#### WARNING

### ■ To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent. Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.



#### NOTICE

# Before replacing fuses

Have the cause of electrical overload determined and repaired by your Toyota dealer as soon as possible.

# **Light bulbs**

You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Toyota dealer.


For more information about replacing other light bulbs, contact your Toyota dealer.

# Preparing for light bulb replacement


Check the wattage of the light bulb to be replaced. ( $\rightarrow$ P. 506)

# **Bulb locations**

▶ Front




Rear




- (1) Headlight high beams/daytime (1) Back-up lights running lights (halogen bulb)
- (2) Headlight low beams
- (3) Front side marker lights
- (4) Front turn signal/parking lights (4) License plate lights (bulb type)
- (2) Rear turn signal lights
- (3) Stop/tail/rear side marker lights

# Replacing light bulbs

- Headlight high beams/daytime running light (halogen bulb)
  - 1 Turn the bulb base counterclockwise.




2 Pull the bulb out while pressing the lock release of the connector.




3 When installing, reverse the steps listed.

# ■ Headlight low beams

1 Turn the bulb base counterclockwise.




2 Pull the bulb out while pressing the lock release of the connector.




3 When installing, reverse the steps listed.

# **■** Front side marker lights

1 Turn the bulb base counterclockwise.



2 Remove the light bulb.




3 When installing, reverse the steps listed.


## ■ Front turn signal/parking lights (bulb type)

1 To ensure enough space to perform work, turn the steering wheel to rotate the front wheel away from the bulb to be replaced.


Turn the steering wheel to the left when replacing the right side light bulb, and turn the steering wheel to the right when replacing the left side light bulb.

2 Remove the fender liner screws.







- 3 Remove the fender liner clip.
  - 1) After turning the clip, pull the clip until it stops.
  - (2) Turn the clip again, and then pull out the clip.




- \*1: Vehicles without LED daytime running lights
- \*2: Vehicles with LED daytime running lights






5 Remove the light bulb.




6 When installing, reverse the steps listed.

## ■ Stop/tail/rear side marker lights and rear turn signal lights


1 Open the trunk lid and remove the luggage trim cover clips. (→P. 436)




2 Pull the hook while depressing the button.




3 Partly remove the luggage trim cover.



- 4 Turn the bulb base counterclockwise.
  - 1) Rear turn signal light
  - ② Stop/tail/rear side marker light



- 5 Remove the light bulb.
  - 1 Rear turn signal light
  - ② Stop/tail/rear side marker light




6 When installing, reverse the steps listed.

## ■ Back-up lights


Open the trunk lid and remove the clips. (→P. 436) Then partly remove the trunk panel cover.




2 Unplug the connector while depressing the lock release.



3 Turn the bulb base counterclockwise.



4 Remove the light bulb.




5 When installing, reverse the steps listed.

## ■ License plate lights

1 Remove the cover.

To prevent damaging the vehicle, wrap the tip of the flathead screwdriver with tape.





### 2 Remove the lens.

Put the flathead screwdriver behind the tab of the lens, and turn it as shown in the illustration to pry off the lens.

To prevent damaging the vehicle, wrap the tip of the screwdriver with tape.

3 Remove the light bulb.





4 When installing, reverse the steps listed.

## ■ Replacing the following bulbs

If any of the lights listed below has burnt out, have it replaced by your Toyota dealer.

- Parking lights/daytime running lights (LED type)
- High mounted stoplights

#### LED light bulbs

The parking lights/daytime running lights (LED type) and high mounted stoplights consist of a number of LEDs. If any of the LEDs burns out, take your vehicle to your Toyota dealer to have the light replaced.

#### ■ Condensation build-up on the inside of the lens


Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

Contact your Toyota dealer for more information in the following situations:

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.

### ■Removing and installing the luggage trim cover and trunk panel cover clips

- (1) Removing
- (2) Installing



#### ■ When replacing light bulbs

→P. 427



#### WARNING

## Replacing light bulbs

• Turn off the lights. Do not attempt to replace the bulb immediately after turning off the lights.

The bulbs become very hot and may cause burns.

• Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.

Also, if the bulb is scratched or dropped, it may blow out or crack.

• Fully install light bulbs and any parts used to secure them. Failure to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

## ■ To prevent damage or fire

Make sure bulbs are fully seated and locked.

## When trouble arises


8-1.	Essential information
	Emergency flashers 438
	If your vehicle has to
	be stopped in an
	emergency 439
8-2.	Steps to take in an
	emergency
	If your vehicle needs to
	be towed 440
	If you think something is
	wrong 443
	If a warning light turns on
	or a warning buzzer
	sounds 444
	If a warning message or
	indicator is displayed 453
	If you have a flat tire 471
	If the hybrid system will
	not start 482
	If the shift lever cannot
	be shifted from P 484
	If the electronic key does
	not operate properly 485
	If the vehicle 12-volt
	battery is discharged 487
	If your vehicle
	overheats 491
	If the vehicle becomes
	stuck 495

## **Emergency flashers**

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Press the switch.

All the turn signal lights will flash. To turn them off, press the switch once again.




#### ■ Emergency flashers

If the emergency flashers are used for a long time while the hybrid system is not operating (while the "READY" indicator is not illuminated), the 12-volt battery may discharge.

## If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

- 1 Steadily step on the brake pedal with both feet and firmly depress it. Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.
- 2 Shift the shift lever to N.
- If the shift lever is shifted to N
- 3 After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the hybrid system.
- If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- 4 To stop the hybrid system, press and hold the power switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.



or press briefly 3 times or more CTY52AV659

5 Stop the vehicle in a safe place by the road.



#### **WARNING**

## ■If the hybrid system has to be turned off while driving

Power assist for the steering wheel will be lost, making the steering wheel heavier to turn. Decelerate as much as possible before turning off the hybrid system.

## If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or a commercial towing service, using a lift-type truck or flat bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

If towing your vehicle with a wheel-lift type truck from the front, the vehicle's rear wheels and axles must be in good conditions.  $(\rightarrow P. 441, 442)$ 

If they are damaged, use a towing dolly or flatbed truck.

### Situations needs to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Toyota dealer or commercial towing service before towing.

- A warning message for the hybrid system is shown on the multiinformation display and the vehicle does not move.
- The vehicle makes an abnormal sound.


## Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.




## Towing with a wheel-lift type truck

▶ From the front



From the rear




Release the parking brake.

Use a towing dolly under the front wheels.


## Using a flat bed truck

If your Toyota is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.





## **WARNING**


Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When towing the vehicle

Be sure to transport the vehicle with the front wheels raised or with all four wheels raised off the ground.

If the vehicle is towed with the front wheels contacting the ground, the drivetrain and related parts may be damaged or electricity generated by the operation of the motor may cause a fire to occur depending on the nature of the damage or malfunction.





#### NOTICE

■To prevent damage to the vehicle when towing using a wheel-lift type truck

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

■ To prevent body damage when towing with a sling-type truck Do not tow with a sling-type truck, either from the front or rear.

## If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

## Visible symptoms

- Fluid leaks under the vehicle.
   (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal

### **Audible symptoms**

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the hybrid system

### **Operational symptoms**

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

# If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

## Warning light and warning buzzer list

Warning light	Warning light/Details/Actions
(U.S.A.) (Canada)	<ul> <li>Brake system warning light in red (warning buzzer)*1         Indicates that:         <ul> <li>The brake fluid level is low; or</li> <li>The brake system is malfunctioning                 This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released the system is operating normally.</li> <li>→ Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.</li> </ul> </li> </ul>
	<ul> <li>Brake system warning light in yellow</li> <li>Indicates a malfunction in:</li> <li>• The regenerative braking system; or</li> <li>• The electronically controlled brake system</li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
CHECK (U.S.A.)  (Canada)	<ul> <li>Malfunction indicator lamp Indicates a malfunction in: <ul> <li>The hybrid system;</li> <li>The electronic engine control system;</li> <li>The electronic throttle control system; or</li> <li>The hybrid transmission control system</li> </ul> </li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>

Warning light	Warning light/Details/Actions
<b>*</b>	<ul> <li>SRS warning light Indicates a malfunction in: <ul> <li>The SRS airbag system;</li> <li>The front passenger occupant classification system; or</li> <li>The seat belt pretensioner system</li> </ul> </li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
(U.S.A.)  (ABS)  (Canada)	<ul> <li>ABS warning light Indicates a malfunction in: <ul> <li>The ABS; or</li> <li>The brake assist system</li> </ul> </li> <li>→ Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
<b>@!</b>	Electric power steering system warning light (warning buzzer) Indicates a malfunction in the EPS (Electric Power Steering) system  → Have the vehicle inspected by your Toyota dealer immediately.
OFF (flashes)	<ul> <li>Pre-collision system warning light*2 Indicates a malfunction in the PCS (Pre-Collision System) The warning light will operate as follows, even when the system is not malfunctioning: <ul> <li>The light will turn on when the pre-collision system is disabled. (→P. 225)</li> <li>The light will turn on when the VSC (Vehicle Stability Control) system is disabled. (→P. 220)</li> <li>The light will flash when the system cannot temporarily be used. (→P. 462)</li> </ul> </li> <li>Have the vehicle inspected by your Toyota dealer immediately.</li> </ul>
<b>2</b>	Slip indicator Indicates a malfunction in: • The VSC (Vehicle Stability Control) system; • The TRAC (Traction Control) system • The ABS; or • The hill-start assist control system The light will flash when the VSC or the TRAC system is operating.  → Have the vehicle inspected by your Toyota dealer immediately.

Warning light	Warning light/Details/Actions
	Low fuel level warning light Indicates that remaining fuel is approximately 2.6 gal. (9.7 L, 2.1 lmp. gal.) or less → Refuel the vehicle.
4	Seat belt reminder light (warning buzzer)*3  Warns the driver and/or front passenger to fasten their seat belts  → Fasten the seat belt.  If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.
A	Master warning light  A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction.  → P. 453
	Tire pressure warning light*2 When the light comes on: Low tire inflation pressure such as • Natural causes (→P. 448) • Flat tire (→P. 471)  → Adjust the tire inflation pressure to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Toyota dealer. When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system → Have the system checked by your Toyota dealer.

\*1: Parking brake engaged warning buzzer:

→P. 455

\*2: If equipped

\*3: Driver's seat belt buzzer:

The driver's seat belt buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the power switch is turned to ON mode, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 12 mph (20 km/h), the buzzer sounds once. If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

Front passenger's seat belt buzzer:

The front passenger's seat belt buzzer sounds to alert the front passenger that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of 12 mph (20 km/h). If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

#### ■ SRS warning light

This warning light system monitors the airbag sensor assembly, front impact sensors, side impact sensors (front door), side impact sensors (front), side impact sensors (rear), driver's seat belt buckle switch, front passenger occupant classification system, "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioners (front), airbags, interconnecting wiring and power sources. (→P. 38)

## ■ Front passenger detection sensor, seat belt reminder and warning buzzer

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

### ■ If the malfunction indicator lamp comes on while driving

First check the following:

- Is the fuel tank empty?
  If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose?
  If it is, tighten it securely.

The light will go off after several driving trips.

If the light does not go off even after several trips, contact your Toyota dealer as soon as possible.

## ■When the tire pressure warning light comes on (vehicles with a tire pressure warning system)

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch will not turn off the tire pressure warning light.

## ■ The tire pressure warning light may come on due to natural causes (vehicles with a tire pressure warning system)

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

■When a tire is replaced with a spare tire (vehicles with a tire pressure warning system)

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire. Replace the spare tire with the repaired tire and adjust the tire inflation pressure. The tire pressure warning light will go off after a few minutes.

■ Conditions that the tire pressure warning system may not function properly (vehicles with a tire pressure warning system)

→P. 411

■If the tire pressure warning light frequently comes on after blinking for 1 minute (vehicles with a tire pressure warning system)

If the tire pressure warning light frequently comes on after blinking for 1 minute when the power switch is turned to ON mode, have it checked by your Toyota dealer.

■ Warning buzzer

In some cases, the buzzer may not be heard because of noisy place or an audio sound.

■ Electric power steering system warning light (warning buzzer)

When the 12-volt battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.



## **MARNING**

- If both the ABS and the brake system warning lights remain on
  - Stop your vehicle in a safe place immediately and contact your Toyota dealer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.
- ■When the electric power steering system warning light comes on The steering wheel may become extremely heavy. If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.
- ■If the tire pressure warning light comes on (vehicles with a tire pressure warning system)

Be sure to observe the following precautions. Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat, change it with the spare tire and have the flat tire repaired by the nearest Toyota dealer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.
- ■If a blowout or sudden air leakage should occur (vehicles with a tire pressure warning system)

The tire pressure warning system may not activate immediately.



## **WARNING**

#### Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.



## **№** NOTICE

■To ensure the tire pressure warning system operates properly (vehicles with a tire pressure warning system)

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.


## If a warning message or indicator is displayed

## If a warning is shown on the multi-information display, stay calm and perform the following actions:

1 Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

2 Multi-information display




If any of the warning message or indicator comes on again after the following actions have been performed, contact your Toyota dealer.

## Warning message and warning buzzer list

Warning message	Details/Actions	
(If equipped)	<ul> <li>Indicates that:</li> <li>There is a high possibility of a frontal collision; or</li> <li>The pre-collision braking function is operating A buzzer also sounds.</li> <li>→ Slow the vehicle by applying the brakes.</li> </ul>	
(If equipped)	Indicates that your vehicle is nearing the vehicle ahead (in vehicle-to-vehicle distance mode) A buzzer also sounds.  → Slow the vehicle by applying the brakes.	
(If equipped)	Alerts the driver that the vehicle has deviated from the lane (while the LDA [Lane Departure Alert] system is operating)  The lane line on the side the vehicle has deviated from flashes.  The warning buzzer sounds continuously.  → Check around the vehicle and back to inside of the lane lines.	

Warning message	Details/Actions
Door Ajar	Indicates that one or more of the doors is not fully closed  The system also indicates which doors are not fully closed.  If the vehicle reaches a speed of 3 mph (5 km/h), flashes and a buzzer sounds to indicate that the door(s) are not yet fully closed.  → Make sure that all the doors are closed.
	Indicates that the hood is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h),
<b>6</b>	Indicates that the trunk is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h),
N Position (Flashes)	Indicates that the accelerator pedal is depressed while the shift lever is in N A buzzer also sounds.  → Release the accelerator pedal and shift the shift lever to D or R.
Hybrid Battery Preservation Mode Restart After Shifting to P Position  (Flashes)	Indicates that the hybrid battery (traction battery) power has dropped because a long period of time has elapsed after shifting the shift lever to N A buzzer also sounds.  → Restart the hybrid system when starting the vehicle.



Warning message	Details/Actions
Check Anti-lock Brake System  ABS  (U.S.A.)  Check Anti-lock Brake System  (Canada)	<ul> <li>Indicates a malfunction in:</li> <li>The ABS; or</li> <li>The brake assist system A buzzer also sounds. → Have the vehicle inspected by your Toyota dealer.</li> </ul>
Check Vehicle Stability Control System	Indicates a malfunction in the VSC (Vehicle Stability Control) system.  → Have the vehicle inspected by your Toyota dealer.
Engine Coolant Temp is High	Indicates that the engine coolant temperature is too high A buzzer also sounds. → P. 491
Check Charging System	Indicates a malfunction in the vehicle's charging system  → Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning message	Details/Actions
Dynamic Radar Cruise Sensor Needs Cleaning (If equipped)	Indicates that the radar sensor is dirty or covered with ice A buzzer also sounds. → Clean the sensor.
Dynamic Radar Cruise Control Not Available (If equipped)	Indicates that the dynamic radar cruise control system is unable to judge vehicle-to-vehicle distance A buzzer also sounds.  → Switch driving mode to normal. If the windshield wipers are on, turn them off or set them to a mode other than high speed wiper operation.
Not Avadable  (If equipped)	Indicates that the LDA (Lane Departure Alert) system is suspended (The camera sensor temperature is higher than the operation temperature range)  A buzzer also sounds.  → Restart the LDA after driving for a while.
Blind Spot Monitor Not Available  (If equipped)	Indicates that a Blind Spot Monitor sensor or the surrounding area on the bumper is dirty or covered with ice A buzzer also sounds.  → Clean the sensor and its surrounding area on the bumper.
Check Cruise Control System	<ul> <li>Indicates a malfunction in:</li> <li>The cruise control system (if equipped); or</li> <li>The dynamic radar cruise control system (if equipped)</li> <li>Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.</li> <li>A buzzer also sounds.</li> <li>→ Have the vehicle inspected by your Toyota dealer.</li> </ul>

Warning message	Details/Actions
Check LDA System  (If equipped)	Indicates a malfunction in the LDA (Lane Departure Alert) system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Check Pre-Collision System  OFF (Flashes) (If equipped)	Indicates a malfunction in the PCS (Pre-Collision system) A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Check Blind Spot Monitor System  (If equipped)	Indicates a malfunction in the BSM (Blind Spot Monitor) system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Low Oil Pressure	Indicates abnormal engine oil pressure A buzzer also sounds.  → Immediately stop the vehicle in a safe place and contact your Toyota dealer.
LDA System is Unavailable Below Approx. 32 MPH (If equipped)	Indicates that the LDA (Lane Departure Alert) system cannot be used because the vehicle speed is lower than approximately 32 mph (50 km/h)  → Drive the vehicle at 32 mph (50 km/h) or higher.
Tun Headights OFF  (Flashes)	Indicates that the power switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on A buzzer also sounds.  → Turn the lights off.

Warning message	Details/Actions
Moon Roof Open  (Flashes) (If equipped)	Indicates that the moon roof is not fully closed (with the power switch off, and the driver's door open)  A buzzer also sounds.  → Close the moon roof.
Hybrid System Overheat Stop the Vehicle in a Safe Place	Indicates that the hybrid system has overheated This message may be displayed when driving under severe operating conditions. (For example, when driving up a long steep hill.) A buzzer also sounds.  → Stop and check. (→P. 491)
Check Auto High Beam System  (If equipped)	Indicates a malfunction in the Automatic High Beam system A buzzer also sounds.  → Have the vehicle inspected by your Toyota dealer.
Ter Pressure Incl 38 + 1 + 42	Indicates that the tire inflation pressure is low  → Check the tire inflation pressure, and adjust to the appropriate level.

(If equipped)

Warning message	Details/Actions
(If equipped)	Indicates a malfunction in the tire pressure warning system  → Stop the vehicle in a safe place and turn the power switch off then on again.  If the tire pressure warning indicator flashes for 1 minute then illuminates, there is a malfunction in the system. Have the vehicle inspected by your Toyota dealer.
(If equipped)	Indicates that the tire position information cannot be recognized  → Drive for a short while and check if the display updates.  If the radio wave conditions improve, the display may return to normal. If the tire pressure is still not displayed after driving for several minutes, stop the vehicle in a safe place, turn the power switch off then on again, and start driving.  If the tire pressure is still not displayed even after repeating this process several times, have the vehicle inspected by your Toyota dealer.
Low 12 - Volt Battery See Owner's Manual	Indicates that the hybrid battery (traction battery) is low.  → Immediately stop the vehicle in a safe place. Turn the power switch off and then to ON mode to restart the hybrid system. Ensuring the shift lever is in P, charge the hybrid battery (traction battery).

Warning message	Details/Actions
Low Washer fluid	Indicates that the washer fluid level is low  → Add washer fluid.
Low Fuel  Distance to Empty  Distance to Empty  Please Refuel	Indicates that remaining fuel is approximately 2.6 gal. (9.7 L, 2.1 lmp. gal.) or less → Refuel the vehicle.
Traction Control OFF TRAC OFF	Indicates that the TRAC (Traction Control) system has been deactivated $\rightarrow$ Turn the TRAC on. ( $\rightarrow$ P. 219)
Maintenance Required Soon	Indicates that all maintenance according to the driven distance on the maintenance schedule*¹ should be performed soon.  Comes on approximately 4500 miles (7200 km) after the message has been reset.  → If necessary, perform maintenance.
(U.S.A. only)	Indicates that all maintenance is required to correspond to the driven distance on the maintenance schedule*1.  Comes on approximately 5000 miles (8000 km) after the message has been reset.  (The indicator will not work properly unless the message has been reset.)  → Perform the necessary maintenance.  Please reset the message after the maintenance is performed. (→P. 383)

Warning message	Details/Actions
Pre-Collision Brake is Disabled Due to VSC OFF  OFF  (If equipped)	Indicates that, since the VSC (Vehicle Stability Control) system was turned off, the pre-collision brake system operation is stopped → Turn the VSC on. (→P. 220)
Pre-Collision System Temporarily Not Available  OFF (Flashes) (If equipped)	Indicates that the PCS (Pre-collision system) is not currently functional because the grille cover or the sensor is dirty  → Check the grille cover and the sensor and clean them if they are dirty.

## Other displayed messages

Warning message	Details/Actions
Maintenance Required for Hybrid Battery Cooling Parts at Your Dealer	Indicates that maintenance of the hybrid system (traction battery) cooling component is required The filter may be clogged, the air vent may be blocked or the duct may be disconnected.  → Have maintenance performed on the hybrid system (traction battery) cooling component at Toyota dealer.
EV Mode Currently Not Available	
EV Mode Currently Not Available Vehicle is Warming Up	Indicates that the EV drive mode is not avail-
EV Mode Currently Not Available Low Hybrid Battery	able*2 The reason the EV drive mode is not available (the vehicle is idling, hybrid battery [traction battery] charge is low, speed is higher than the EV drive mode operating speed range, accelerator pedal is depressed too much) may be displayed.
ÆV Mode Currently Not Available	A buzzer also sounds.  → Use the EV drive mode when it becomes available.
Vehicle Exceeds EV Speed	avanasie.
EV Mode Currently Not Available	
Excessive Acceleration	

Warning message	Details/Actions
EV Mode OFF  Low Hybrid Bettery  EV Mode OFF  Vehicle Exceeds EV Speed	Indicates that the EV drive mode has been automatically canceled*2  The reason the EV drive mode is not available (the hybrid battery [traction battery] charge is low, speed is higher than the EV drive mode operating speed range, accelerator pedal is depressed too much) may be displayed.  A buzzer also sounds.  → Drive the vehicle for a while.
Excessive Acceleration	

<sup>\*1:</sup> Refer to the separate "Scheduled Maintenance Guide" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

## Warning message in dynamic radar cruise control mode (if equipped)

In the following situations, the warning message may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed

## ■The LDA (Lane Departure Alert) lane departure warning function (if equipped)

In the following situations, a warning message will not be displayed even if a lane line is crossed.

- When the vehicle speed deviates from the operating range of the LDA system functions
- When the lane lines cannot be recognized

## ■When a tire is replaced with the spare tire

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire.

## ■ Conditions that the tire pressure warning system may not function properly (vehicles with a tire pressure warning system)

→P. 383

### ■ Warning buzzer

→P. 449

<sup>\*2:</sup> For the EV drive mode operating conditions:  $\rightarrow$ P. 166

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Con- tinu- ous	_	Shift to P Position  (Flashes)	The driver's door was opened when the shift lever was not in P and the power switch was not turned off.  → Shift the shift lever to P.
Con- tinu- ous	Contin- uous	(Displayed alternately)  (Flashes)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in P and the power switch was not turned off.  → Shift the shift lever to P. → Bring the electronic key back into the vehicle.
Once 3 times	3 times	Key Not Detected	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was in P and the power switch was not turned off.  → Turn the power switch off. → Bring the electronic key back into the vehicle.
	(Flashes)	The electronic key was carried outside the vehicle and a door other than the driver's door was opened and closed while the power switch was in a mode other than off.  → Bring the electronic key back into the vehicle.	

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	Contin- uous	Turn Power OFF  Key Not Detected  (Displayed alternately)  (Flashes)	An attempt was made to exit the vehicle with the electronic key and lock the doors without first turning the power switch off when the shift lever was in P.  → Turn the power switch off and lock the doors again.
Once	_	Key Not Detected  (Flashes)	The electronic key is not detected when an attempt is made to start the hybrid system.  → Start the hybrid system with the electronic key present.
9 times	_	Key Not Detected  (Flashes)	An attempt was made to drive when the electronic key was not inside the vehicle.  → Confirm that the electronic key is inside the vehicle.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
_	Contin- uous	Key Detected in Vehicle	An attempt was made to lock the doors using the smart key system while the electronic key was still inside the vehicle.  → Retrieve the electronic key from the vehicle and lock the doors again.
Once	Contin- uous	Key Detected in Vehicle	An attempt was made to lock either front door by opening a door and putting the inside lock button into the lock position, then closing the door with the electronic key still inside the vehicle.  → Retrieve the electronic key from the vehicle and lock the doors again.
Once	_	Key Battery Low	The electronic key has a low battery.  → Replace the electronic key battery. (→P. 423)
Once	_	Steering Lock ON (Flashes)	The steering lock could not be released within 3 seconds of the power switch being pressed.  → Press the power switch while depressing the brake pedal and moving the steering wheel left and right.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Smart Entry & Start System Check  (Flashes)	Indicates a malfunction in the smart key system  → Have the vehicle inspected by your Toyota dealer.
Once	_	Providence of the control of the con	<ul> <li>When the doors were unlocked with the mechanical key and then the power switch was pressed, the electronic key could not be detected in the vehicle.</li> <li>The electronic key could not be detected in the vehicle even after the power switch was pressed two consecutive times.</li> <li>→ Touch the electronic key to the power switch while depressing the brake pedal.</li> </ul>
Once	_	Power ON: Press Brake Produl and Push Power Switch  (Flashes)	Indicates that:  • With the power switch off, the doors were unlocked and then the driver's door was opened and closed; or  • The power switch was turned to ACCESSORY mode without starting the hybrid system → Press the power switch while depressing the brake pedal.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Shift to P Position to Start  (Flashes)	An attempt was made to start the hybrid system with the shift lever in an incorrect position.  → Shift the shift lever to P and start the hybrid system.
Once	_	Shift to P Position  (Flashes)	The power switch has been turned off with the shift lever in a position other than P.  → Shift the shift lever to P.
Once	_	Turn Power OFF  (Flashes)	After the power switch has been turned off with the shift lever in a position other than P, the shift lever has been shifted to P.  → Turn the power switch off.
_	_	Powering OFF to Conserve Battery	Power was turned off due to the automatic power off function.  → Next time when starting the hybrid system, operate the hybrid system for approximately 5 minutes to recharge the 12-volt battery.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once	_	Power ON Press Brake Predal and Push Power Switch  (Flashes)	During a hybrid system starting procedure in the event that the electronic key was not functioning properly (→P. 485), the power switch was touched with the electronic key.  → Press the power switch within 10 seconds of the buzzer sounding.

### ■ Warning buzzer

→P. 449

### If you have a flat tire

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire.

For details about tires:  $\rightarrow$ P. 406



### **MARNING**

### If you have a flat tire


Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

### Before jacking up the vehicle

- Stop the vehicle on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the hybrid system.
- $\bullet$  Turn on the emergency flashers. ( $\rightarrow$ P. 438)

### Location of the spare tire, jack and tools



- 1 Luggage floor cover
- (2) Wheel nut wrench
- (3) Spare tire

- (4) Jack handle
- (5) Jack

### **MARNING**

### Using the tire jack

Observe the following precautions.

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.


- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.

Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.


- Put the jack properly in its jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start the hybrid system or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.

### Taking out the jack


1 Lift up the hook of the luggage floor cover on the trunk floor.



2 Secure the luggage floor cover using the hook provided.




3 Remove the jack.




### Taking out the spare tire


1 Lift up the hook of the luggage floor cover on the trunk floor.



2 Secure the luggage floor cover using the hook provided.




3 Remove the tool tray.



4 Loosen the center fastener that secures the spare tire.

When taking out or stowing the spare tire, make sure to firmly hold opposite ends of the tire.




### **MARNING**

### ■When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.

### Replacing a flat tire

1 Chock the tires.





Flat tire		Wheel chock positions
Front	Left-hand side	Behind the rear right-hand side tire
FIOIIL	Right-hand side	Behind the rear left-hand side tire
Rear	Left-hand side	In front of the front right-hand side tire
	Right-hand side	In front of the front left-hand side tire

2 For vehicles with steel wheels, remove the wheel ornament using the wrench.

To protect the wheel ornament, place a rag between the wrench and the wheel ornament, as shown in the illustration.


3 Slightly loosen the wheel nuts (one turn).






4 Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.

The jack point guides are located under the rocker panel. They indicate the jack point positions.




Raise the vehicle until the tire is slightly raised off the ground.



Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



### **⚠** WARNING


### Replacing a flat tire

- Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.
  - After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.
- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
  - Have the wheel nuts tightened with a torque wrench to 76 ft-lbf (103 N•m, 10.5 kgf•m) as soon as possible after changing wheels.
  - · Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
  - · When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
  - If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Toyota dealer.
  - When installing the wheel nuts, be sure to install them with the tapered ends facing inward. (→P. 420)

### Installing the spare tire


A Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.




2 Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.


When replacing a steel wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.



When replacing an aluminum wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.




3 Lower the vehicle.



4 Firmly tighten each wheel nut two or three times in the order shown in the illustration.

Tightening torque: 76 ft•lbf (103 N•m, 10.5 kgf•m)



5 Stow the flat tire, tire jack and all tools.

### ■ The compact spare tire

- ■The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.
  - Use the compact spare tire temporarily, and only in an emergency.
- Make sure to check the tire inflation pressure of the compact spare tire.  $(\rightarrow P. 505)$

## ■When using the compact spare tire (vehicles with a tire pressure warning system)

As the compact spare tire is not equipped with a tire pressure warning valve and transmitter, low inflation pressure of the spare tire will not be indicated by the tire pressure warning system. Also, if you replace the compact spare tire after the tire pressure warning light comes on, the light remains on.

- ■If you have a flat front tire on a road covered with snow or ice
  Install the compact spare tire on one of the rear wheels of the vehicle.
  Perform the following steps and fit tire chains to the front tires:
- 1 Replace a rear tire with the compact spare tire.
- 2 Replace the flat front tire with the tire removed from the rear of the vehicle.
- 3 Fit tire chains to the front tires.

### **MARNING**

### ■When using the compact spare tire

- Remember that the compact spare tire provided is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tires simultaneously.
- Replace the compact spare tire with a standard tire as soon as possi-
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.

### ■When the compact spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC
- TRAC
- Dynamic radar cruise control (if equipped)
- PCS (if equipped)

- LDA (Lane Departure Alert) (if equipped)
- Rear view monitor system
- Cruise control (if equipped)
- FPS
- Navigation system (if equipped)

### ■ Speed limit when using the compact spare tire

Do not drive at speeds in excess of 50 mph (80 km/h) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failure to observe this precaution may lead to an accident causing death or serious injury.

### After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.



■Be careful when driving over bumps with the compact spare tire installed on the vehicle.

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

- Driving with tire chains and the compact spare tire
  - Do not fit tire chains to the compact spare tire.
  - Tire chains may damage the vehicle body and adversely affect driving performance.
- When replacing the tires (vehicles with a tire pressure warning system)
  - When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Toyota dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.
- To avoid damage to the tire pressure warning valves and transmitters (vehicles with a tire pressure warning system)
  - When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.  $(\rightarrow P. 407)$

### If the hybrid system will not start

Reasons for the hybrid system not starting vary depending on the situation. Check the following and perform the appropriate procedure:

The hybrid system will not start even though the correct starting procedure is being followed. ( $\rightarrow$ P. 161)

One of the following may be the cause of the problem:

- The electronic key may not be functioning properly. ( $\rightarrow$ P. 486)
- There may not be sufficient fuel in the vehicle's tank.
   Refuel the vehicle.
- There may be a malfunction in the immobilizer system.
   (→P. 78)
- There may be a malfunction in the steering lock system.
- The hybrid system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, depending on the type of malfunction, an interim measure is available to start the hybrid system. (→P. 483)

The interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The 12-volt battery may be discharged. (→P. 487)
- The 12-volt battery terminal connections may be loose or corroded.
   (→P. 402)

## The interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- The 12-volt battery may be discharged. (→P. 487)
- One or both of the 12-volt battery terminals may be disconnected.
   (→P. 402)

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

### **Emergency start function**

When the hybrid system does not start, the following steps can be used as an interim measure to start the hybrid system if the power switch is functioning normally:

Do not use this starting procedure except in case of emergency.

- 1 Set the parking brake.
- 2 Shift the shift lever to P.
- Turn the power switch to ACCESSORY mode.
- 4 Press and hold the power switch for about 15 seconds while depressing the brake pedal firmly.

Even if the hybrid system can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

### If the shift lever cannot be shifted from P

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Toyota dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted:

- 1 Set the parking brake.
- Turn the power switch to ACCESSORY mode.
- 3 Depress the brake pedal.
- Pry the cover up with a flathead screwdriver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.



5 Press the shift lock override button.

The shift lever can be shifted while the button is pressed.




# If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted ( $\rightarrow$ P. 124) or the electronic key cannot be used because the battery is depleted, the smart key system and wireless remote control cannot be used. In such cases, the doors can be opened and the hybrid system can be started by following the procedure below.


### Locking and unlocking the doors

Using the mechanical key ( $\rightarrow$ P. 107) in order to perform the following operations (driver's door only):

- 1 Locks all doors
- ② Closes the windows and moon roof (turn and hold)\*
- (3) Unlocks the door



- (4) Opens the windows and moon roof (turn and hold)\*
  - \*: This setting must be customized at your Toyota dealer.




### Starting the hybrid system

- 1 Ensure that the shift lever is in P and firmly depress the brake pedal.
- 2 Touch the Toyota emblem side of the electronic key to the power switch.

When the electronic kev detected, a buzzer sounds and the power switch will turn to ON mode.

When the smart key system is deactivated in customization setting, the power switch will turn to ACCESSORY mode.

on the multi-information display.



3 Firmly depress the brake pedal and check that [27] is displayed



4 Press the power switch.

In the event that the power switch still cannot be started, contact your Toyota dealer.

### ■ Stopping the hybrid system

Shift the shift lever to P and press the power switch as you normally do when stopping the hybrid system.

### ■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. (→P. 423)

### ■ Changing power switch modes

Release the brake pedal and press the power switch in step 3 above. The hybrid system does not start and modes will be changed each time the switch is pressed. ( $\rightarrow$ P. 162)

### ■ When the electronic key does not work properly


- Make sure that the smart key system has not been deactivated in the customization setting. If it is off, turn the function on. (Customizable features  $\rightarrow$ P. 523)
- Check if battery-saving mode is set. If it is set, cancel the function. (→P. 123)

### If the vehicle 12-volt battery is discharged

The following procedures may be used to start the hybrid system if the vehicle's 12-volt battery is discharged. You can also call your Toyota dealer or a qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below.

- Open the trunk lid and remove the 12-volt battery cover.
   (→P. 402)
- 2 Connect the jumper cables according to the following procedure:



- 1) Connect a positive jumper cable clamp to the positive (+) 12-volt battery terminal on your vehicle.
- (2) Connect the clamp on the other end of the positive cable to the positive (+) battery terminal on the second vehicle.
- (3) Connect a negative cable clamp to the negative (-) battery terminal on the second vehicle.
- (4) Connect the clamp at the other end of the negative cable to a solid, stationary, unpainted metallic point away from the 12-volt battery and any moving parts, as shown in the illustration.

- 3 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the 12-volt battery of your vehicle.
- 4 Open and close any of the doors of your vehicle with the power switch off.
- Maintain the engine speed of the second vehicle and turn the power switch to ON mode, then start the vehicle's engine.
- 6 Make sure the "READY" indicator comes on. If the indicator does not come on, contact your Toyota dealer.
- 7 Once the hybrid system has started, remove the jumper cables in the exact reverse order from which they were connected.

Once the hybrid system starts, have the vehicle inspected at your Toyota dealer as soon as possible.

## ■ Starting the hybrid system when the 12-volt battery is discharged The hybrid system cannot be started by push-starting.

### ■ To prevent 12-volt battery discharge

- Turn off the headlights and the audio system while the hybrid system is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

### ■ Charging the 12-volt battery

The electricity stored in the 12-volt battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the 12-volt battery may discharge, and the hybrid system may be unable to start. (The 12-volt battery recharges automatically during driving.)

### ■ When recharging or replacing the 12-volt battery

- In some cases, it may not be possible to unlock the doors using the smart key system when the 12-volt battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- The hybrid system may not start on the first attempt after the 12-volt battery has recharged but will start normally after the second attempt. This is not a malfunction.
- The power switch mode is memorized by the vehicle. When the 12-volt battery is reconnected, the system will return to the mode it was in before the 12-volt battery was discharged. Before disconnecting the 12-volt battery, turn the power switch off.
  - If you are unsure what mode the power switch was in before the 12-volt battery discharged, be especially careful when reconnecting the 12-volt battery.
- Vehicles with an alarm: Make sure that the key is not inside the vehicle when recharging or replacing the 12-volt battery. The key may be locked in the vehicle if the alarm is activated. (→P. 81)

### **MARNING**

### Avoiding 12-volt battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the 12-volt battery:

- Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area. such as brackets or unpainted metal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the 12-volt battery.

### 12-volt battery precautions

The 12-volt battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the 12-volt battery:

- When working with the 12-volt battery, always wear safety glasses and take care not to allow any 12-volt battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the 12-volt battery.
- In the event that 12-volt battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.

Place a wet sponge or cloth over the affected area until medical attention can be received.

- Always wash your hands after handling the 12-volt battery support, terminals, and other 12-volt battery-related parts.
- Do not allow children near the 12-volt battery.



### NOTICE

### When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fan or engine drive belt.

### If your vehicle overheats

### The following may indicate that your vehicle is overheating.

- The needle of the engine coolant temperature gauge (→P. 88) enters the red zone or a loss of hybrid system power is experienced. (For example, the vehicle speed does not increase.)
- Hybrid System Overheat" (→P. 453) is shown on the multi-information display
- Steam comes out from under the hood.

### **Correction procedures**

- If the rightmost segment of the engine coolant temperature display are flashing
- 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the hybrid system.
- 2 If you see steam:


Carefully lift the hood after the steam subsides.


If you do not see steam: Carefully lift the hood.

- 3 After the hybrid system has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.
  - 1 Radiator
  - 2 Cooling fans

If a large amount of coolant leaks, immediately contact your Toyota dealer.


- 4 The coolant level is satisfactory if it is between the "F" and "L" lines on the reservoir.
  - (1) Reservoir
  - (2) "F" line
  - (3) "L" line
  - (4) Radiator cap





5 Add engine coolant if necessary.

Water can be used in an emergency if engine coolant is unavailable.



6 Start the hybrid system and turn the air conditioning system on to check that the radiator cooling fans operate and to check for coolant leaks from the radiator or hoses.

The fans operate when the air conditioning system is turned on immediately after a cold start. Confirm that the fans are operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fans may not operate in freezing temperatures.)

7 If the fans are not operating:

Stop the hybrid system immediately and contact your Toyota dealer.


If the fans are operating:

Have the vehicle inspected at the nearest Toyota dealer.

## ■ If "Hybrid System Overheat" is shown on the multi-information display


- 1 Stop the vehicle in a safe place.
- 2 Stop the hybrid system and carefully lift the hood.
- After the hybrid system has cooled down, inspect the hoses and radiator core (radiator) for any leaks.
  - (1) Radiator
  - (2) Cooling fans


If a large amount of coolant leaks, immediately contact your Toyota dealer.




- 1 Reservoir
- ② "FULL"
- (3) "LOW"
- 5 Add coolant if necessary.

Water can be used in an emergency if coolant is unavailable.







6 Start the hybrid system and check for the multi-information display.

If the message does not disappear:

Stop the hybrid system and contact your Toyota dealer.

If the message is not displayed:

Have the vehicle inspected at the nearest Toyota dealer.

### **WARNING**

### ■ When inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.
- After the hybrid system has been turned off, check that "Power ON" on the multi-information display and the "READY" indicator are off. When the hybrid system is operating, the gasoline engine may automatically start, or the cooling fans may suddenly operate even if the gasoline engine stops. Do not touch or approach rotating parts such as the fans, which may lead to fingers or clothing (especially a tie, a scarf or a muffler) getting caught, resulting in serious injury.
- Do not loosen the coolant reservoir cap while the hybrid system and radiator are hot.

Serious injury, such as burns, may result from hot coolant and steam released under pressure.



### NOTICE

### ■ When adding engine/power control unit coolant

Wait until the hybrid system has cooled down before adding engine/power control unit coolant.

When adding coolant, do so slowly. Adding cool coolant to a hot hybrid system too quickly can cause damage to the hybrid system.

### ■ To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additives.


### If the vehicle becomes stuck

### Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud. dirt or snow:

- 1 Stop the hybrid system. Set the parking brake and shift the shift lever to P.
- 2 Remove the mud, snow or sand from around the front wheels.
- 3 Place wood, stones or some other material under the front wheels to help provide traction.
- 4 Restart the hybrid system.
- 5 Shift the shift lever to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

### ■ When it is difficult to free the vehicle

Press & to turn off TRAC.



### **WARNING**

### When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

### When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.



### **↑** NOTICE

- To avoid damaging the transmission and other components
  - Avoid spinning the front wheels and depressing the accelerator pedal more than necessary.
  - If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

## **Vehicle specifications**

9-1.	Specifications	
	Maintenance data	
	(fuel, oil level, etc.)	498
	Fuel information	507
	Tire information	510
9-2.	Customization	
	Customizable features	523
9-3.	Items to initialize	
	Items to initialize	532

## Maintenance data (fuel, oil level, etc.)

### **Dimensions and weights**

Overall length		190.9 in. (4850 mm)
Overall width		71.7 in. (1820 mm)
Overall height*1		57.9 in. (1470 mm)
Wheelbase		109.3 in. (2775 mm)
Tread	Front	62.4 in. (1585 mm)*2 62.8 in. (1595 mm)*3
rread	Rear	62.0 in. (1575 mm)*2 62.4 in. (1585 mm)*3
Vehicle capacity weight (occupants + luggage)		905 lb. (410 kg)

<sup>\*1:</sup> Unladen vehicles

<sup>\*2:</sup> P215/55R17 tires


<sup>\*3:</sup> P205/65R16 tires

### Vehicle identification


### Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.

This number is stamped on the top left of the instrument panel.




This number is also on the Certification Label.



### **■** Engine number

The engine number is stamped on the engine block as shown.



### Engine

Model	2AR-FXE
Туре	4-cylinder in line, 4-cycle, gasoline
Bore and stroke	3.54 × 3.86 in. (90.0 × 98.0 mm)
Displacement	152.2 cu. in. (2494 cm <sup>3</sup> )
Valve clearance (engine cold)	Automatic adjustment

### Fuel

Fuel type	Unleaded gasoline only
Octane rating	87 (Research Octane Number 91) or higher
Fuel tank capacity (Reference)	17.0 gal. (64.35 L, 14.2 lmp. gal.)

### **Electric motor (Traction motor)**

Туре	Permanent magnet synchronous motor
Maximum output	105 kW
Maximum torque	199 ft•lbf (270 N•m, 27.5 kgf•m)

### **Hybrid battery (Traction battery)**

Туре	Nickel-metal hydride battery
Voltage	7.2 V/module
Capacity	6.5 Ah (3HR)
Quantity	34 modules
Overall voltage	244.8 V

### **Lubrication system**

Oil capacity
(Drain and refill — reference\*)
With filter
Without filter
4.6 qt. (4.4 L, 3.9 Imp. qt.)
4.2 qt. (4.0 L, 3.5 Imp. qt.)

### ■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.


Oil grade: ILSAC GF-5 multigrade engine oil

Recommended viscosity:

**SAE 0W-20** 

SAE 0W-20 is the best choice for good fuel economy and good starting in cold weather.

If SAE 0W-20 is not available, SAE 5W-20 oil may be used. However, it must be replaced with SAE 0W-20 at the next oil change.



<sup>\*:</sup> The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up the engine and turn off the hybrid system, wait more than 5 minutes, and check the oil level on the dipstick.

Oil viscosity (0W-20 is explained here as an example):

- The 0W in 0W-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in 0W-20 indicates the viscosity characteristic of the oil when the
  oil is at high temperature. An oil with a higher viscosity (one with a higher
  value) may be better suited if the vehicle is operated at high speeds, or
  under extreme load conditions.

How to read oil container label

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is added to some oil containers to help you select the oil you should use.



# Cooling system

Capacity (Reference) Gasoline engine Power control unit	7.6 qt. (7.2 L, 6.3 lmp. qt.) 3.4 qt. (3.2 L, 2.8 lmp. qt.)
Coolant type	Use either of the following:     "Toyota Super Long Life Coolant"     A similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology  Do not use plain water alone.

# Ignition system

Spark plug	
Make	DENSO FK16HR-A8
Gap	0.031 in. (0.8 mm)



# NOTICE

# ■Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust spark plug gap.

# **Electrical system**

12-volt battery	
Open voltage at 68°F (20°C):	12.6 — 12.8 V Fully charged 12.2 — 12.4 V Half charged 11.8 — 12.0 V Discharged (Voltage checked 20 minutes after the hybrid system and all the lights turned off)
Charging rates	5 A max.

### **Transmission**

Fluid capacity*	3.9 qt. (3.7 L, 3.3 Imp. qt.)
Fluid type	Toyota Genuine ATF WS

<sup>\*:</sup> The fluid capacity is a reference quantity. If replacement is necessary, contact your Toyota dealer.



### **NOTICE**

### ■ Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may ultimately damage the transmission of your vehicle.

### Brakes

Pedal clearance*1	3.62 in. (92 mm)
Pedal free play	0.04 — 0.24 in. (1 — 6 mm)
Brake pad wear limit	0.04 in. (1.0 mm)
Parking brake lining wear limit	0.04 in. (1.0 mm)
Parking brake pedal travel*2	7 — 10 clicks
Fluid type	SAE J1703 or FMVSS No.116 DOT 3

<sup>\*1:</sup> Minimum pedal clearance when depressed with a force of 112 lbf (500 N, 51 kgf) while the hybrid system is operating

<sup>\*2:</sup> Parking brake pedal travel when depressed with a force of 67 lbf (300 N, 31 kgf).

# Steering

Free play Less than 1.2 in. (30 mm)
-------------------------------------

# Tires and wheels

# ▶ Type A

Tire size	P205/65R16 94S, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Rear: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) Driving at high speeds (above 100 mph [160 km/h]) (in countries where such speeds are permitted by law) Add 3 psi (20 kPa, 0.2 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	$16 \times 7J$ , $17 \times 4$ T (compact spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

# ▶ Type B

Tire size	P215/55R17 93V, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Rear: 35 psi (240 kPa, 2.4 kgf/cm² or bar) Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) Driving at high speeds (above 100 mph [160 km/h]) (in countries where such speeds are permitted by law) Add 3 psi (20 kPa, 0.2 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	17 × 7 J, 17 × 4 T (compact spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

# Light bulbs\*1

	Light bulbs	Bulb No.	W	Туре
	Headlights Low beam* <sup>2</sup> High beam* <sup>2</sup>	 9005	55 60	A B
	Front side marker lights	W5W	5	С
Exterior	Front turn signal/ parking lights (bulb type)*2	7444NA	28/8	D
	Rear turn signal lights	WY21W	21	D
	Stop/tail/rear side maker lights	7443	21/5	С
	License plate lights	W5W	5	С
	Back-up lights	921	16	С
	Front interior/personal lights*2	_	5	O
	Rear interior/personal lights*2	_	8	O
Interior	Interior light*2	_	8	E
	Door courtesy lights	168	5	С
	Vanity lights*2		8	С
	Trunk light	194	3.8	С

A: H11 halogen bulbs

B: HB3 halogen bulbs

C: Wedge base bulbs (clear)

D: Wedge base bulbs (amber)

E: Double end bulbs

<sup>\*1:</sup> Light bulbs not listed in this table are LED bulbs.

<sup>\*2:</sup> If equipped

# **Fuel information**

You must only use unleaded gasoline in your vehicle.

Select octane rating 87 (Research Octane Number 91) or higher. Use of unleaded gasoline with an octane rating lower than 87 may result in engine knocking. Persistent knocking can lead to engine damage.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A..

### ■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

### ■ Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Toyota dealer.

### ■ Gasoline quality standards

- Automotive manufacturers in the U.S.A., Europe and Japan have developed a specification for fuel quality called the World-Wide Fuel Charter (WWFC), which is expected to be applied worldwide.
- The WWFC consists of four categories that are based on required emission levels. In the U.S., category 4 has been adopted.
- The WWFC improves air quality by lowering emissions in vehicle fleets, and improves customer satisfaction through better performance.

# ■ Recommendation of the use of gasoline containing detergent additives

- Toyota recommends the use of gasoline that contains detergent additives to avoid the build-up of engine deposits.
- •All gasoline sold in the U.S.A. contains minimum detergent additives to clean and/or keep clean intake systems, per EPA's lowest additives concentration program.
- Toyota strongly recommends the use of Top Tier Detergent Gasoline. For more information on Top Tier Detergent Gasoline and a list of marketers, please go to the official website www.toptiergas.com.

# ■ Recommendation of the use of cleaner burning gasoline


Cleaner burning gasoline, including reformulated gasoline that contains oxygenates such as ethanol or MTBE (Methyl Tertiary Butyl Ether) is available in many areas.

Toyota recommends the use of cleaner burning gasoline and appropriately blended reformulated gasoline. These types of gasoline provide excellent vehicle performance, reduce vehicle emissions and improve air quality.

### ■ Non-recommendation of the use of blended gasoline

Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30, E50, E85 (which are only some examples of fuel containing more than 15% ethanol).



- If you use gasohol in your vehicle, be sure that it has an octane rating no lower than 87.
- Toyota does not recommend the use of gasoline containing methanol.

# ■ Non-recommendation of the use of gasoline containing MMT

Some gasoline contains an octane enhancing additive called MMT (Methylcy-clopentadienyl Manganese Tricarbonyl).

Toyota does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Toyota dealer for service.

# ■ If your engine knocks

- Consult your Toyota dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.



#### NOTICE

### Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline. Leaded gasoline can cause damage to your vehicle's three-way catalytic converters causing the emission control system to malfunction.
- Do not use gasohol other than the type previously stated. Other gasohol may cause fuel system damage or vehicle performance problems.
- Using unleaded gasoline with an octane number or rating lower than the level previously stated will cause persistent heavy knocking. At worst, this will lead to engine damage.

### Fuel-related poor driveability

If poor driveability is encountered after using a different type of fuel (poor hot starting, vaporization, engine knocking, etc.), discontinue the use of that type of fuel.


### When refueling with gasohol

Take care not to spill gasohol. It can damage your vehicle's paint.


# **Tire information**

# Typical tire symbols

### ▶ Full-size tire



# ▶ Compact spare tire



- 1 Tire size ( $\rightarrow$ P. 513)
- (2) DOT and Tire Identification Number (TIN)(→P. 512)
- (3) Uniform tire quality grading

For details, see "Uniform Tire Quality Grading" that follows.

- (4) Location of treadwear indicators(→P. 406)
- (5) Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

(6) Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.

(7) TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

- (8) Load limit at maximum cold tire inflation pressure (→P. 517)
- (9) Maximum cold tire inflation pressure (→P. 517)

This means the pressure to which a tire may be inflated.

(10) Summer tires or all season tires (→P. 410)


An all season tire has "M+S" on the sidewall. A tire not marked "M+S" is a summer tire.

(11) "TEMPORARY USE ONLY"

A compact spare tire is identified by the phrase "TEMPORARY USE ONLY" molded on its sidewall. This tire is designed for temporary emergency use only.

# Typical DOT and Tire Identification Number (TIN)

- 1) DOT symbol\*
- (2) Tire Identification Number (TIN)
- ③ Tire manufacturer's identification mark
- (4) Tire size code
- (5) Manufacturer's optional tire type code (3 or 4 letters)
- 6 Manufacturing week
- (7) Manufacturing year
  - \*: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.



### Tire size


# ■ Typical tire size information


The illustration indicates typical tire size.

- 1 Tire use (P = Passenger car, T = Temporary use)
- (2) Section width (millimeters)
- (3) Aspect ratio (tire height to section width)
- (4) Tire construction code (R = Radial, D = Diagonal)
- (5) Wheel diameter (inches)
- (6) Load index (2 digits or 3 digits)
- (7) Speed symbol (alphabet with one letter)

### ■ Tire dimensions


- (1) Section width
- (2) Tire height
- (3) Wheel diameter





# Tire section names

- 1) Bead
- ② Sidewall
- (3) Shoulder
- (4) Tread
- 5 Belt
- (6) Inner liner
- 7 Reinforcing rubber
- (8) Carcass
- 9 Rim lines
- (10) Bead wires
- 11) Chafer



### **Uniform Tire Quality Grading**

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Toyota vehicles with information on uniform tire quality grading.

Your Toyota dealer will help answer any questions you may have as you read this information.

### ■ DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

#### ■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

# ■ Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

### ■ Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

# Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manufacturer
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine
Maximum loaded vehi- cle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table 1* below

Tire related term	Meaning
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead

Tire related term	Meaning
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or inner- liner of the tire extending to cord material
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separation	The parting of the innerliner from cord material in the carcass
Intended outboard sidewall	<ul> <li>(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or</li> <li>(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle</li> </ul>

Tire related term	Meaning
Light truck (LT) tire	A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissible inflation pressure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including ele- vations due to labeling, decorations, or protec- tive bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire

Tire related term	Meaning
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding ele- vations due to labeling, decoration, or protec- tive bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM E-1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol ( )
	on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

<sup>\*:</sup> Table 1 — Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

# **Customizable features**

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. The settings of these features can be changed by using the meter control switches, the Entune audio system screen or at your Toyota dealer.

# **Customizing vehicle features**

- Changing by using the Entune Audio system\*1
  - 1 Press the "SETUP" button.
  - 2 Select "Vehicle" on the "Setup" screen.

Various setting can be changed. Refer to the list of settings that can be changed for details.

- Changing by using the Entune Audio Plus system\*<sup>2</sup> or Entune Premium Audio with Navigation system\*<sup>2</sup>
  - 1 Press the "APPS" button.
  - 2 Select "Setup" on the "Apps" screen and select "Vehicle".

    Various setting can be changed. Refer to the list of settings that can be changed for details.
- \*1: Audio system with "CAR" button
- \*2: Audio system with "APPS" button

### **Customizable features**

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details.

- 1 Settings that can be changed on the Entune Audio system screen
- ② Settings that can be changed by the meter control switches Definition of symbols: O = Available, = Not available

# ■ Gauges, meters and multi-information display (→P. 88, 92)

Function*1	Default setting	Customized set- ting	1	2
Language*2	English	French	0	0
Language	Liigiisii	Spanish	U	O
		km (km/L)		
Units*2	miles (MPG US)	km (L/100 km)	0	0
		miles (MPG Imperial)		
EV indicator	On (Self-lighting)	Off	_	0
Drive information 1	Digital speedome- ter		_	0
	Distance to empty			
Drive information 2	Average fuel economy (after reset)	6 of the following items: →P. 94		0
	Current fuel economy	ileiiis. →r. 94		
Drive information 3	Trip distance (after reset)		_	0
	Trip elapsed time			
Pop-up display	On	Off	—	0
		Blue		
Accent color	Light blue	Orange	О	0
		Yellow		

Function*1	Default setting	Customized set- ting	1	2
Speed limit display*4	On with the speed limit caution indicator (yellow) enabled	On with the speed limit caution indi- cator (yellow) not enabled	_	0
	enabled	Off		
Maintenance system initialization*3	Off	On	_	0

<sup>\*1:</sup> For details about each function:  $\rightarrow$ P. 95

<sup>\*2:</sup> The default setting varies according to country.

<sup>\*3:</sup> U.S.A. only

<sup>\*4:</sup> Speed limit display may not be available for some regions.

- 1 Settings that can be changed using the Entune Audio system
- 2 Settings that can be changed using the Entune Audio Plus system or Entune Premium Audio with Navigation system
- ③ Settings that can be changed by your Toyota dealer Definition of symbols: O = Available, — = Not available

### ■ Door lock (→P. 110, 117, 485)

Function	Default setting	Customized set- ting	1	2	3
Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step.	_	0	0
	Shifting the shift	Off	0 0		
Automatic door lock	lever to position other than P	Vehicle speed reaches a certain level.		0	0
	Shifting the shift	Off			
Automatic door unlock	lever to P	Driver's door is opened	0	0	0
Locking/unlocking of the trunk when all doors are locked/unlocked	On	Off	_	_	0

# ■ Smart key system and wireless remote control (→P. 110, 117)

Function	Default setting	Customized set- ting	1	2	3
Operation signal (Emergency flashers)	On	Off	_	0	0
Operation signal (Buzzer)	On	Off	_	_	0
Operation buzzer volume	Level 5	Off to level 7	0	0	0
Time elapsed before automatic door lock		Off		Ì	
function is activated if	60 seconds	30 seconds	_	0	0
door is not opened after being unlocked		120 seconds			
Open door warning buzzer	On	Off	_	_	0

# **■** Smart key system (→P. 110, 117, 121)

Function	Default setting	Customized set- ting	1	2	3
Smart key system	On	Off	_	_	0
Number of permissible times of continuous smart lock	Twice	Unlimited	_	_	О

# ■ Wireless remote control (→P. 106, 110, 117)

Function	Default setting	Customized set- ting	1	2	3
Wireless remote control	On	Off	_	_	0
Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	0	0
	Descend hold	One short press			
Trunk unlooking opera		Push twice			
Trunk unlocking opera- tion	Press and hold (short)	Press and hold (long)	_	_	0
		Off			
Panic function	On	Off	_	_	0

# ■ Power window (driver's door) and moon roof\* (→P. 140, 143)

Function	Default setting	Customized set- ting	1	2	3
Key linked operation	Off	On	_	_	0
Wireless remote control linked opening	Off	On	_	_	0
Key linked closing	Off	On	_	_	О
Wireless remote control linked opening buzzer	On	Off	_	_	0

<sup>\*:</sup> If equipped

# ■ Moon roof\* (→P. 143)

Function	Default setting	Customized set- ting	1	2	3
Linked operation of com- ponents when door key is used	Slide only	Tilt only	_	_	0
Linked operation of com- ponents when wireless remote control is used	Slide only	Tilt only	_	_	0

<sup>\*:</sup> If equipped

# ■ Turn signal lever (→P. 170)

Function	Default setting	Customized set- ting	1	2	3
The number of times the		Off*2			
turn signal lights flash automatically when the turn signal lever is moved to the first posi- tion during a lane change*1	3	4 to 7		_	0

<sup>\*1:</sup> After flashing the turn signal lights when turning left or right while this function is off and the turn signal lever is moved to the first position in the direction of the flashing light, the turn signal lights can be selected to be flashing or off.

### ■ Automatic light control system (→P. 172)

Function	Default setting	Customized set- ting	1	2	3
Light sensor sensitivity	Level 3	Level 1 to 5	0	О	0
Time elapsed before	30 seconds	Off	0		
headlights automatically turn off after doors are		60 seconds		0	Ο
closed		90 seconds			

# **■** Lights (→P. 172, 175)

Function	Default setting	Customized set- ting	1	2	3
Daytime running light system (except Canada)	On	Off	0	0	0
Automatic high beam*	On	Off	_	0	0

<sup>\*:</sup> If equipped

<sup>\*2:</sup> The turn signal lights will be off if the turn signal lever is moved to the first position in the direction of flashing light.

# ■ Vehicle Proximity Notification System (→P. 70)

Function	Default setting	Customized set- ting	1	2	3		
The volume of Vehicle		Level 2	0			0	)
Proximity Notification System sound	Level 1	Level 3		O	O		O

# ■ Automatic air conditioning system (→P. 332)

Function	Default setting	Customized set- ting	1	2	3
A/C auto switch operation	Auto	Manual	_	0	0
Air conditioning control of Eco drive mode	On	Off	_	_	0

# ■ Illumination (→P. 340)

Function	Default setting	Customized set- ting	1	2	3
Time elapsed before	15 seconds	7.5 seconds	0	0	0
lights turn off	13 seconds	30 seconds			
Operation when the doors are unlocked	On	Off	_	_	0
Operation after the power switch turned off	On	Off	_	_	0
Operation when you approach the vehicle with the electronic key on your person	On	Off		_	0

# ■ Seat belt reminder (→P. 446)

Function	Default setting	Customized set- ting	1	2	3
Vehicle speed linked seat belt reminder buzzer	On	Off	_	_	О



# **WARNING**

### During customization

As the hybrid system needs to be operating during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



#### NOTICE

### During customization

To prevent 12-volt battery discharge, ensure that the hybrid system is operating while customizing features.

# Items to initialize

The following items must be initialized for normal system operation after such cases as maintenance being performed on the vehicle:

Item	When to initialize	Reference	
Message indicating maintenance is required (U.S.A. only)	After the maintenance is performed	P. 383	
Tire pressure warning system	When changing the tire inflation pressure by changing traveling speed or load weight, etc.	P. 408	

For owners

Reporting safety defects	
for U.S. owners	534
Seat belt instructions	
for Canadian owners	
(in French)	535
SRS airbag instructions	
for Canadian owners	
(in French)	537

# Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-331-4331).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <a href="http://www.safercar.gov">http://www.safercar.gov</a>; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <a href="http://www.safercar.gov">http://www.safercar.gov</a>.

# or owners

# Seat belt instructions for Canadian owners (in French)

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

### Utilisation correcte des ceintures de sécurité

- Déroulez la sangle diagonale de telle sorte qu'elle passe bien sur l'épaule, sans pour autant être en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.



- Réglez la position du dossier de siège. Asseyez-vous le dos droit et calez-vous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

### Entretien et soin

#### ■ Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Vérifiez régulièrement que les ceintures ne sont pas effilochées, entaillées ou exagérément usées.



# **AVERTISSEMENT**


### ■ Dommage et usure de la ceinture de sécurité

Inspectez la ceinture de sécurité périodiquement. Vérifiez si elles ne sont pas entaillées, effilochées et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité défectueuse n'apporte aucune garantie de protection de l'occupant en cas de blessures graves, voire mortelles.

# SRS airbag instructions for Canadian owners (in French)

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.




# Coussins gonflables frontaux SRS

- Coussin gonflable conducteur/coussin gonflable du passager avant SRS
  - Participent à la protection de la tête et du thorax du conducteur et du passager avant contre les chocs contre les éléments de l'habitacle
- ② Coussins gonflables de genoux SRS Participent à la protection du conducteur et du passager avant

# Coussins gonflables latéraux et rideaux SRS

- ③ Coussins gonflables latéraux avant SRS Participent à la protection du torse des occupants de siège avant
- 4 Coussins gonflables latéraux arrière SRS Participent à la protection du torse des occupants des sièges latéraux arrière
- (5) Coussins gonflables rideaux SRS
  - Participent principalement à la protection de la tête des occupants des sièges latéraux
  - Peut contribuer à empêcher les occupants d'être éjectés du véhicule en cas de tonneau

# Composants du système de coussins gonflables SRS



- (1) Capteurs d'impact avant
- Système de classification de l'occupant du siège passager avant (ECU et capteurs)
- 3 Coussins gonflables de genoux
- (4) Capteurs d'impact latéral (portes avant)
- (5) Capteurs d'impact latéral (avant)
- 6 Coussin gonflable passager avant
- 7 Coussins gonflables latéraux avant
- (8) Coussins gonflables rideaux
- (9) Coussins gonflables latéraux arrière

- ① Témoins indicateurs "AIR BAG ON" et "AIR BAG OFF"
- (11) Témoin d'avertissement SRS
- Contact de boucle de ceinture de sécurité du passager avant
- (i) Ensemble de capteurs de coussins gonflables
- (4) Capteurs d'impact latéral (arrière)
- (15) Coussin gonflable conducteur
- (f) Contact de boucle de ceinture de sécurité conducteur
- ① Prétensionneurs de ceintures de sécurité et limiteurs de force

Votre véhicule est équipé de COUSSINS GONFLABLES INTELLI-GENTS conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). L'ensemble de capteurs de coussins gonflables (ECU) réquie le déploiement des coussins gonflables sur la base des informations qu'il reçoit des capteurs, etc., indiqués ci-dessus dans le schéma illustrant les composants du système. Parmi ces informations figurent la gravité du choc et l'occupation du véhicule par les passagers. Le déploiement rapide des coussins gonflables est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.



#### **A** AVERTISSEMENT

#### ■ Précautions relatives aux coussins gonflables SRS

Respectez les précautions suivantes concernant les coussins gonflables SRS.

Le non-respect de ces précautions peut occasionner des blessures graves, voire mortelles.

- Le conducteur et tous les passagers du véhicule doivent porter correctement leur ceinture de sécurité. Les coussins gonflables SRS sont des dispositifs supplémentaires à utili-
- ser avec les ceintures de sécurité. Le coussin gonflable conducteur SRS se déploie avec une force considé-
- rable, pouvant occasionner des blessures graves, voire mortelles, si le conducteur se trouve très près du coussin gonflable. L'autorité fédérale chargée de la sécurité routière aux États-Unis (NHTSA) conseille:
  - La zone à risque du coussin gonflable conducteur se situant dans les premiers 2 à 3 in. (50 à 75 mm) de déploiement, vous placer à 10 in. (250 mm) de votre coussin gonflable conducteur vous garantit une marge de sécurité suffisante. Cette distance est à mesurer entre le centre du volant et le sternum. Si vous êtes assis à moins de 10 in. (250 mm), vous pouvez changer votre position de conduite de plusieurs façons:
  - Reculez votre siège le plus possible, de manière à pouvoir encore atteindre confortablement les pédales.

# **A** AVERTISSEMENT

#### ■ Précautions relatives aux coussins gonflables SRS

- Inclinez légèrement le dossier du siège.
  - Bien que les véhicules aient une conception différente, un grand nombre de conducteurs peuvent s'asseoir à une distance de 10 in. (250 mm), même avec le siège conducteur complètement avancé, simplement en inclinant un peu le dossier de siège. Si vous avez des difficultés à voir la route après avoir incliné le dossier de votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser ou remontez le siège si votre véhicule est équipé de cette fonction.
- Si votre volant est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter le coussin gonflable en direction de votre poitrine plutôt que de votre tête et de votre cou.

Réglez votre siège selon les recommandations de la NHTSA ci-dessus, tout en conservant le contrôle des pédales, du volant et la vue des commandes du tableau de bord.

Si vous attachez une rallonge de ceinture de sécurité aux boucles de ceinture de sécurité avant, sans l'attacher au pêne de la ceinture de sécurité, les coussins gonflables frontaux déterminent que le conducteur et le passager avant ont attaché leur ceinture de sécurité, bien que la ceinture de sécurité ne soit pas attachée. Dans ce cas, les coussins gonflables frontaux SRS peuvent ne pas se déployer correctement en cas de collision, pouvant occasionner des blessures graves, voire mortelles. Veillez à porter la ceinture de sécurité avec la rallonge de ceinture de sécurité.



• Le coussin gonflable passager avant SRS se déploie également avec une force considérable, pouvant occasionner des blessures graves, voire mortelles, si le passager avant se trouve très près du coussin gonflable. Le siège du passager avant doit être éloigné le plus possible du coussin gonflable en réglant le dossier de siège de façon à ce que le passager avant soit assis bien droit dans le siège.


## **A** AVERTISSEMENT

#### ■ Précautions relatives aux coussins gonflables SRS

- Les nourrissons et les enfants qui ne sont pas correctement assis et/ou attachés peuvent être grièvement blessés ou tués par le déploiement d'un coussin gonflable. Un nourrisson ou un enfant trop petit pour utiliser une ceinture de sécurité doit être correctement attaché au moyen d'un siège de sécurité enfant. Toyota recommande vivement d'installer tous les nourrissons et enfants sur les sièges arrière du véhicule et de prévoir pour eux des systèmes de retenue adaptés. Les sièges arrière sont plus sûrs pour les nourrissons et les enfants que le siège du passager avant. (→P. 539)
- Ne vous assevez pas sur le bord du siège et ne vous appuvez pas contre la planche de bord.



- Ne laissez pas un enfant rester debout devant le coussin gonflable passager avant SRS ou s'asseoir sur les genoux du passager avant.
- Ne laissez pas les occupants des sièges avant voyager avec un objet sur les genoux.
- Ne vous appuyez pas contre la porte, le rail latéral de toit ou les montants avant. latéraux et arrière.







• Ne laissez personne s'agenouiller sur le siège passager en appui contre la porte ou sortir la tête ou les mains à l'extérieur du véhicule.



# **AVERTISSEMENT**

- Précautions relatives aux coussins gonflables SRS
  - Ne fixez rien et ne posez rien sur des emplacements tels que la planche de bord, la garniture du volant et la partie inférieure du tableau de bord.
    - Ces éléments peuvent se transformer en projectiles lorsque les coussins gonflables conducteur, passager avant et genoux SRS se déploient.
  - Ne fixez rien aux portes, au pare-brise, aux vitres, aux montants avant et arrière, au rail latéral de toit et à la poignée d'assistance.





Ne suspendez aucun cintre ou objet dur aux crochets à vêtements. Tous ces objets pourraient se transformer en projectiles et causer des blessures graves, voire mortelles en cas de déploiement des coussins gonflables rideaux SRS.

## **AVERTISSEMENT**

#### ■ Précautions relatives aux coussins gonflables SRS

- Si un cache en vinyle est placé sur la zone où le coussin gonflable de genoux SRS se déploie, assurez-vous de le retirer.
- N'utilisez aucun accessoire de siège recouvrant les zones de déploiement des coussins gonflables latéraux SRS, car il risque de gêner le déploiement des coussins gonflables. De tels accessoires peuvent empêcher les coussins gonflables latéraux de fonctionner correctement, désactiver le système ou entraîner le déploiement accidentel des coussins gonflables latéraux, occasionnant des blessures graves, voire mortelles.
- Évitez de faire subir des chocs ou des pressions excessives aux parties renfermant les composants de coussins gonflables SRS. En effet, cela pourrait entraîner un dysfonctionnement des coussins gonflables SRS.
- Ne touchez aucun composant immédiatement après le déploiement (gonflage) des coussins gonflables SRS, car ils peuvent être chauds.
- Si vous avez des difficultés à respirer après le déploiement des coussins gonflables SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.
- Si les parties renfermant les coussins gonflables SRS, comme les garnitures du volant et des montants avant et arrière, sont endommagées ou craquelées, faites-les remplacer par votre concessionnaire Toyota.
- Ne placez rien sur le siège du passager avant, comme un coussin par exemple. Cela a pour conséquence de répartir le poids du passager sur toute la surface du siège, ce qui empêche le capteur de détecter correctement le poids du passager. En conséquence, les coussins gonflables frontaux SRS du passager avant risquent de ne pas se déployer en cas de collision.

## **AVERTISSEMENT**

Modification et mise au rebut des composants du système de coussins gonflables SRS

Ne mettez pas votre véhicule au rebut et ne procédez à aucune des modifications suivantes sans consulter votre concessionnaire Toyota. Les coussins gonflables SRS peuvent ne pas fonctionner correctement ou se déployer (se gonfler) accidentellement, provoquant la mort ou de graves blessures.

- Installation, dépose, démontage et réparation des coussins gonflables SRS
- Réparations, modifications, démontage ou remplacement du volant, du tableau de bord, de la planche de bord, des sièges ou de leur garnissage, des montants avant, latéraux et arrière ou des rails latéraux de toit
- Réparations ou modifications des ailes avant, du pare-chocs avant ou des flancs de l'habitacle
- Installation d'un protège-calandre (pare-buffle, pare-kangourou, etc.), de chasse-neige, de treuils, ou d'un porte-bagages de toit
- Modifications du système de suspension du véhicule
- Installation d'appareils électroniques tels que les émetteurs/récepteurs radios mobiles et les lecteurs CD
- Modifications de votre véhicule pour une personne atteinte d'un handicap physique

# Index

What to do if	
(Troubleshooting)	548
Alphabetical index	551

Vehicles with a navigation system or Entune Audio Plus:

For details of equipment related to the navigation system or Entune Audio Plus, such as the audio system, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

# What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Toyota dealer.

#### The doors cannot be locked, unlocked, opened or closed



#### You lose your keys

- If you lose your mechanical keys, new genuine mechanical keys can be made by your Toyota dealer. (→P. 107)
- If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Toyota dealer immediately. (→P. 109)



#### The doors cannot be locked or unlocked

- Is the key battery weak or depleted? ( $\rightarrow$ P. 423)
- Is the power switch in ON mode?
  When locking the doors, turn the power switch off. (→P. 162)
- Is the electronic key left inside the vehicle? When locking the doors, make sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P. 124)



### The rear door cannot be opened

• Is the child-protector lock set? The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P. 113)



#### The trunk lid is closed with the electronic key left inside


The function to prevent the electronic key from being left inside the trunk will operate and you can open the trunk as usual. Take the key out from the trunk. (→P. 118)

#### If you think something is wrong




#### The hybrid system does not start


- Did you press the power switch while firmly depressing the brake pedal? (→P. 161)
- Is the shift lever in P? ( $\rightarrow$ P. 163)
- Is the electronic key anywhere detectable inside the vehicle? ( $\rightarrow$ P. 122)
- Is the steering wheel unlocked? (→P. 163)
- Is the electronic key battery weak or depleted? In this case, the hybrid system can be started in a temporary way. (→P. 486)
- Is the 12-volt battery discharged? (→P. 487)




■ Is the power switch in ON mode?
If you cannot release the shift lever by depressing the brake pedal with the power switch in ON mode. (→P. 484)



• It is locked automatically to prevent theft of the vehicle. ( $\rightarrow$ P. 163)



• Is the window lock switch pressed? The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P. 140)



• The auto power off function will be operated if the vehicle is left in ACCES-SORY or ON mode (the hybrid system is not operating) for a period of time. (→P. 163)



# A warning buzzer sounds during driving

- The seat belt reminder light is flashing Are the driver and the front passenger wearing the seat belts? (→P. 446)
- The brake system warning light is on Is the parking brake released? (→P. 171)

Depending on the situation, other types of warning buzzer may also sound.  $(\rightarrow P. 444, 453)$ 



#### A warning buzzer sounds when leaving the vehicle

Is the electronic key left inside the vehicle?
 Check the message on the multi-information display. (→P. 453)



# An alarm is activated and the horn sounds (vehicles with an alarm)

Did anyone inside the vehicle open a door during setting the alarm? The sensor detects it and the alarm sounds. (→P. 80) To stop the alarm, turn the power switch to ON mode or start the hybrid system.



# A warning light turns on or a warning message or indicator is displayed

 When a warning light turns on or a warning message or indicator is displayed, refer to P. 444, 453.

### When a problem has occurred



### If you have a flat tire

 Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P. 471)



### The vehicle becomes stuck

 Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P. 495)

# Alphabetical index

7.
A/C332
Air conditioning filter 421
ABS
(Anti-lock Brake System) 218
Function218
Warning light445
Air conditioning filter 421
Air conditioning
system332
Air conditioning filter 421
Airbags36
Airbag operating conditions 45
Airbag precautions for
your child39
Airbag warning light 445
Correct driving posture28
Curtain shield airbag operating
conditions45
Curtain shield airbag
precautions42
Front passenger occupant
classification system49
General airbag precautions 39
Locations of airbags36
Modification and
disposal of airbags44
Side airbag operating
conditions45
Side airbag precautions39
Side and curtain shield airbags
operating conditions45
Side and curtain shield airbags
precautions39
SRS airbags36
Alarm80
Anchor brackets 60

Antennas	
(smart key system)	121
Anti-lock Brake System	
(ABS)	218
Function	218
Warning light	445
Armrest	358
Assist grips	
Audio input*	253
Audio system*	250
Antenna	323
Audio input	253
AUX port/USB port	
Bluetooth® audio	296
CD player	269
iPod	274
MP3/WMA disc	269
Optimal use	266
Portable music player	282
Radio	267
Steering wheel audio	
switch	252
USB memory	
Automatic High Beam	175
Automatic light control	
system	
AUX port*	
Auxiliary boxes	347

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

В
Back-up lights
Replacing light bulb434
Wattage506
Battery (12-volt battery) 402
Battery checking402
If the vehicle has discharged
battery487
Preparing and checking
before winter242
Warning message456
Battery (traction battery)73
Bluetooth <sup>®</sup> *
Audio system295
Hands-free system
(for cellular phone)296
Multimedia system 295, 296
Bottle holders345
Brake
Fluid504
Parking brake171
Warning light444
Brake assist218
Break-in tips149
Brightness control
Instrument panel light
control89
BSM (Blind Spot Monitor)231
Blind Spot Monitor
function234
function234 Rear Cross Traffic Alert

<u> </u>	
Care 376, 3	379
Aluminum wheels	377
Exterior	376
Interior	379
Seat belts	380
Cargo capacity1	158
CD player*2	269
Chains2	243
Child restraint system	56
Booster seats, definition	
Booster seats, installation	64
Convertible seats,	
definition	57
Convertible seats,	
installation	63
Front passenger occupant	
classification system	
Infant seats, definition	
Infant seats, installation	62
Installing CRS with LATCH	
anchors	61
Installing CRS with seat	
belts	62
Installing CRS with top tether	
strap	65

Child safety55
12-volt battery
precautions404, 490
Airbag precautions39
Battery precautions 404, 490
Child restraint system 56
How your child should wear
the seat belt32
Installing child restraints 60
Moon roof precautions 146
Power window lock switch 140
Power window precautions 142
Rear door child-protectors 113
Removed electronic key
battery precautions424
Seat belt extender
precautions35
Seat belt precautions34
Seat heater precautions 339
Trunk precautions 119
Child-protectors113
Cleaning 376, 379
Aluminum wheels377
Exterior 376
Interior379
Seat belts380
Clock*355
Coat hooks359
Compass 370
Condenser399
Console box 344
Cooling system398
Hybrid system
overheating491
Cruise control
Cruise control185
Dynamic radar cruise
control189
Cup holders346
Curtain shield airbags37
Customizable features 523

## Daytime running light system..... 173 Defogger Outside rear view mirrors 334 Rear window......334 Windshield ...... 334 Dimensions ...... 498 Dinghy towing...... 160 Display Cruise control ...... 185 Drive information ...... 94 Dynamic radar cruise control ...... 189 LDA (Lane Departure Multi-information display...... 92 Warning message ...... 453 Do-it-yourself maintenance .... 390 **Door courtesy lights** Location ...... 340 Wattage ...... 506 Door lock Doors ...... 110 Key ...... 485 Smart key system ..... 110 Wireless remote control...... 110 Doors ...... 110 Automatic door locking and unlocking systems...... 113 Door lock ...... 112 Door windows ...... 140 Open door warning buzzer ... 111 Open door warning ...... 454 Outside rear view mirrors ..... 138 Rear door child-protector...... 113

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

Driving148	If your vehicle becomes
Break-in tips149	stuck495
Correct posture28	If your vehicle has to be
Hybrid vehicle driving tips 239	stopped in an emergency 439
Procedures 148	If your vehicle needs to be
Winter drive tips242	towed440
Dynamic radar cruise	If your vehicle overheats 491
control189	Engine 500
	Compartment394
E	Engine switch 161
Eco drive mode169	Hood 392
	How to start the hybrid
EDR (Event data recorder)11 Electric motor	system161
(traction motor)69	Identification number 499
Electric Power Steering	If the hybrid system
(EPS)219	will not start482
Function	Ignition switch
Warning light445	(power switch)161
Electronic key106	Overheating 491
Battery-saving function 123	Power switch 161
If the electronic key does not	Engine coolant398
operate properly 485	Capacity 503
Replacing the battery423	Checking 398
Emergency flashers 438	Preparing and checking
Emergency, in case of	before winter 242
If a warning buzzer	Engine coolant temperature
sounds444, 453	gauge 88
If a warning light turns on 444	Engine oil 395
If a warning message or	Capacity501
indicator is displayed 453	Checking 395
If the 12-volt battery is	Oil pressure warning
discharged487	message 458
If the electronic key does not	Preparing and checking
operate properly 485	before winter 242
If the hybrid system	Engine switch 161
will not start 482	Enhanced VSC218
If the shift lever cannot be	
shifted from P484	
If you have a flat tire471	
If you think something is	
wrong443	

Entune Audio system*	248
Audio input	253
AUX port/USB port	
Bluetooth <sup>®</sup> audio	295
CD player	269
iPod	274
MP3/WMA disc	269
Optimal use	266
Portable music player	282
Radio	267
Steering wheel audio	
switch	252
USB memory	278
EPS	
(Electric Power Steering)	219
Function	219
Warning light	445
EV drive mode	166
Event data recorder (EDR)	11

F	
Flat tire 47	1
Floor mats2	6
Fluid	
Brake 50	14
Hybrid transmission50	
Washer 40	1
Front interior lights 34	
Wattage 50	16
Front passenger occupant	
classification system4	9
Front personal lights 34	
Wattage50	16
Front seats12	8
Adjustment12	8.
Cleaning37	
Correct driving posture 2	
Head restraints13	2
Seat heaters 33	
Front side marker lights 17	2
Light switch17	
Replacing light bulbs43	0
Wattage50	
Front turn signal lights 17	0
Replacing light bulbs43	
Turn signal lever17	0
Wattage 50	16
Fuel18	2
Capacity50	0
Fuel gauge8	
Information50	7
Refueling18	
Type182, 50	0
Warning light44	
Warning message 46	1
Fuel consumption 10	
Fuel filler door 18	2
Refueling18	2
Fuses 42	:5

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

G	Hybrid system69	
Garage door opener360	Emergency shut off system 74	
Gauges88	Energy monitor/	
Glove box344	consumption screen 98	
Grocery bag hooks353	EV drive mode166	
	High voltage components 73	
Н	Hybrid System Indicator 90	
Hands-free system	Hybrid system precautions 73	
(for cellular phone)*283	Hybrid vehicle driving tips 239	
Head restraints132	If the hybrid system	
Headlights172	will not start 482	
Automatic High Beam	Overheating491	
	Power (ignition) switch 161	
system175	Starting the hybrid system 161	
Light switch	Vehicle proximity notification	
Replacing light bulbs 429, 435	system70	
Wattage506	Hybrid System Indicator 90	
Heaters 224	Hybrid transmission 168	
Outside rear view mirrors334	If the shift lever cannot be	
Seat heaters	shifted from P484	
High voltage components73		
Hill-start assist control218		
Hood392	I/M test	
Hooks	Identification	
Coat hooks359	Engine	
Grocery bag hooks	Vehicle	
Retaining hooks (floor mat)26	Ignition switch	
Horn134	(power switch)161	
Hybrid battery	Illuminated entry system 342	
(traction battery)73	Immobilizer system78	
Hybrid battery	Indicators86	
(traction battery) air vent74	Initialization	
	Maintenance	
	Moon roof	
	Power windows145	
	Tire pressure	
	warning system 407	

Inside rear view mirror136	L
Instrument panel light	Lane Departure Alert (LDA) 202
control89	LATCH anchors 61
Interior lights340	LDA (Lane Departure Alert) 202
Switch341	Lever
Wattage506	Auxiliary catch lever 392
	Fuel filler door opener 182
J	Hood lock release lever 392
Jack	Internal trunk release lever 118
Positioning the jack393	Shift lever168
Vehicle-equipped jack471	Tilt and telescopic steering
Jack handle471	lock release lever 134
Jam protection function	Trunk opener 117
Moon roof144	Turn signal lever170
Power window140	Wiper lever 180
	License plate lights172
K	Light switch172
	Replacing light bulbs 435
Keyless entry	Wattage 506
Smart key system 110, 117	Light bulbs
Wireless remote	Replacing428
control110, 117	Wattage 506
Keys	Lights
Battery-saving function 123	Automatic High Beam
Electronic key	system175
Engine switch	Headlight switch 172
If the electronic key does	Illuminated entry system 342
not operate properly 485	Interior lights 341
If you lose your keys107	Interior lights list340
Key number plate	Personal lights341
Keyless entry	Replacing light bulbs 428
Mechanical key107 Power switch161	Trunk light118
Replacing the battery423	Turn signal lever170
Warning buzzer122	Vanity lights 354
Wireless remote control 106	Wattage 506
Knee airbags36	Load capacity 158
11166 ali bays30	Lock steering column 134

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

M	
Maintenance	
Do-it-yourself maintenance	390
General maintenance	
Maintenance data	498
Maintenance	
requirements	382
Resetting the message	
indicating maintenance is	
required	383
Malfunction indicator lamp	444
Master warning light	446
Meter	88
Indicators	86
Instrument panel light	
control	89
Meters	88
Multi-information display	92
Warning lights	85
Warning message	453
Mirrors	
Inside rear view mirror	136
Outside rear view mirror	
defoggers	
Outside rear view mirrors	138
Vanity mirrors	354
Moon roof	
Jam protection function	
Operation	143
MP3 disc*	
Multi-information display	92
Audio system-linked	92
Customizing vehicle	
features	
Drive information	
Navigation system-linked	92
Settings display	95

Switching the display ...... 93 Warning message ...... 453

IN .	
Navigation system	*

Noise from under vehicle .......... 8

0
Odometer 88
Oil
Engine oil501
Opener
Fuel filler door182
Hood392
Trunk 117
Outside rear view mirrors 138
Adjusting and folding 138
BSM (Blind spot monitor) 231
Outside rear view mirror
defoggers 334
Outside temperature
display 88
Overheating, Hybrid
system491

Parking brake171
Operation171
Parking brake engaged
warning buzzer444, 455
Parking brake engaged
warning message455
Warning light444
Parking lights172
Light switch172
Replacing light bulbs431
Wattage 506
PCS
(Pre-Collision System)224
Function224
PCS switch225
Warning light445
Personal lights341
Wattage506
Power control unit73
Power control unit coolant 398
Capacity503
Capacity503 Checking398
Capacity
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       (Electric power steering)       219         Warning light       445         Power switch       161
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       (Electric power steering)       219         Warning light       445         Power switch       161         Power windows       140
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140         Window lock switch       140
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140         Window lock switch       140         Pre-Collision System
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140         Window lock switch       140         Pre-Collision System       (PCS)
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140         Window lock switch       140         Pre-Collision System       (PCS)         Eunction       224
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Window lock switch       140         Pre-Collision System       (PCS)         Eunction       224         Function       224         PCS switch       225
Capacity       503         Checking       398         Preparing and checking       242         Power outlet       357         Power steering       219         Warning light       445         Power switch       161         Power windows       140         Jam protection function       140         Operation       140         Window lock switch       140         Pre-Collision System       (PCS)         Eunction       224

E

IX.	
Radar cruise control (dynami	C
radar cruise control)	
Radiator	399
Radio*	. 267
Rear interior lights	
Wattage	. 506
Rear personal lights	341
Wattage	506
Rear seat	
Folding down	130
Rear side marker lights	
Light switch	172
Replacing light bulbs	. 432
Wattage	506
Rear turn signal lights	
Replacing light bulbs	432
Turn signal lever	170
Wattage	506
Rear view mirror	
Inside rear view mirror	
Outside rear view mirrors	
Rear view monitor system*	<b>20</b> 8
Rear window defogger	
Refueling	
Capacity	
Fuel types	
Opening the fuel tank cap	183
Replacing	
Electronic key battery	
Fuses	
Light bulbs	
Tires	471
Reporting safety defects	
for U.S. owners	534
Resetting the message	
indicating maintenance is	
required	
Road accident cautions	76

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

#### S

Safety Connect	
Seat belt reminder light	446
Seat belts	30
Adjusting the seat belt	31
Automatic Locking	
Retractor (ALR)	32
Child restraint system	
installation	62
Cleaning and maintaining	
the seat belt	380
Emergency Locking Retractor	or
(ELR)	32
How to wear your seat belt	30
How your child should wear	
the seat belt	32
Pregnant women, proper	
seat belt use	33
Reminder light and buzzer	446
Seat belt extender	32
Seat belt pretensioners	31
SRS warning light	445
Seat heaters	
Seating capacity	
Seats	128
Adjustment	128
Adjustment precautions	129
Child seats/child restraint	
system installation	60
Cleaning	379
Head restraints	132
Properly sitting in the seat	28
Seat heaters	339

#### Sensor

Automatic headlight	
system	173
Automatic High Beam	
system	179
Humidity sensor	
Inside rear view mirror	137
LDA (Lane Departure	
Alert)	202
Radar sensor 197, 225,	229
Service plug	73
Shift lever	168
Hybrid transmission	168
If the shift lever cannot	
be shifted from P	484
Shift lock system	484
Side airbags	37
Side marker lights	172
Light switch	172
Replacing light bulbs 430,	432
Wattage	506
Side mirrors	138
Adjusting and folding	138
BSM (Blind Spot Monitor)	231
Smart key system	121
Antenna location	121
Entry functions110,	117
Starting the hybrid system	161
Warning message	465
Snow tires	
Spare tire	471
Inflation pressure	
Storage location	471

Spark plug	503
Specifications	498
Speech command system*	
Speedometer	88
Steering lock	
Column lock release	
Warning message	
Steering wheel	
Adjustment	134
Audio remote control	
switches	
Meter control switches	93
Stop/tail lights	
Replacing light bulbs	432
Wattage	506
Storage feature	343
Stuck	
If the vehicle becomes	
stuck	
Sun visors	354
Sun shade	
Roof	144
Switches	
Audio remote control	
switches	252
Automatic High Beam	
switch	175
BSM (Blind spot monitor)	
switch	
Compass switch	
Cruise control switch	
Door lock switches	112
Dynamic radar cruise	
control switch	189

Eco drive mode switch	169
Emergency flasher switch	438
EV drive mode switch	166
Garage door opener	
switches	360
Ignition switch	161
LDA (Lane Departure Alert)	
switch	202
Light switches	172
Meter control switches	
Moon roof switches	143
Outside rear view mirror	
switches	138
PCS switch	225
Power door lock switch	112
Power switch	161
Power window switches	140
Rear window and outside	
rear view mirror	
defoggers switch	334
Seat heater switches	339
"SOS" button	365
Steering switches	93
Talk switch*	327
Telephone switches*	308
Tire pressure warning reset	
switch	408
Vehicle-to-vehicle distance	
button	189
VSC OFF switch	219
Window lock switch	140
Windshield wiper and	
washer switch	180

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

T	
Tail lights	. 172
Light switch	. 172
Replacing light bulbs	. 432
Wattage	. 506
Talk switch*	. 327
Talk switch* Telephone switches*	. 308
Theft deterrent system	
Alarm	80
Immobilizer system	78
Tire inflation pressure	. 416
Maintenance data	. 505
Warning light	. 446
Tire information	. 510
Glossary	. 517
Size	. 513
Tire identification number	. 512
Uniform Tire Quality	
Grading	. 515
Tire pressure warning	
system	. 407
Function	. 407
Initializing	. 407
Installing tire pressure	
warning valves	
and transmitters	
Registering ID codes	. 408
Tire pressure warning reset	
switch	
Warning light	
Warning message459	, 460
Tires	
Chains	
Checking	
If you have a flat tire	
Inflation pressure	
Information	
Replacing	. 471
Rotating tires	406

Size	505
Snow tires	244
Spare tire	471
Tire pressure warning	
system	407
Warning light	
Warning message 459,	460
Tools	
Top tether strap	65
Total load capacity	
Towing	
Dinghy towing	160
Emergency towing	440
Trailer towing	159
TRAC (Traction Control)	218
Traction battery	
(hybrid battery)	73
Traction Control (TRAC)	
Traction motor	
(electric motor)	69
Trailer towing	159
Transmission	168
Hybrid transmission	168
If the shift lever cannot be	
shifted from P	484
Trip meters	88
Trunk	117
Grocery bag hooks	353
Internal trunk release lever	118
Smart key system	117
Trunk light	
Trunk opener	117
Wireless remote control	117
Trunk light	
Trunk light	118
Wattage	506
Turn signal lights	170
Replacing light bulbs 431,	
Turn signal lever	170
Wattage	506

	U	Warning I
	USB port*253	ABS
	, in the second	Brake s
ı	V	Electric
	Venity lights 254	syster
	<b>Vanity lights354</b> Wattage506	Low fue
	Valiage	Malfund
	Vehicle data recording10	Master
	Vehicle identification	Pre-coll
	number499	Seat be
	Vehicle proximity notification	Slip ind
	system70	SRS
	Vehicle Stability Control	Tire pre
	(VSC)218	Warning r
	Voice command system* 327	Washer
	VSC	Checkir
	(Vehicle Stability Control) 218	Prepari
	(*************************************	before
i	W	Switch.
	••	Washing
	Warning buzzers	Weight
	Brake system 444	Cargo d
	Electric power steering	Load lin
	system445	Vehicle Wheels
	Key reminder 467 Open door 454	
	Open hood454	Replaci Size
	Open moon roof459	Window Id
	Open trunk439	Windows.
	Parking brake	Power
	Seat belt reminder 446	Rear wi
	THE SERVICE SE	Windshiel
		Winter dri
		Wireless

Warning lights	85
ABS	445
Brake system	444
Electric power steering	
system	445
Low fuel level	446
Malfunction indicator lamp	444
Master warning light	446
Pre-collision system	445
Seat belt reminder light	446
Slip indicator	
SRS	445
Tire pressure	.446
Warning messages	453
Washer	. 180
Checking	401
Preparing and checking	
before winter	
Switch	
Washing and waxing	
Weight	
Cargo capacity	
Load limits	
Vehicle capacity weight	
Wheels	
Replacing	
Size	
Window lock switch	
Windows	
Power windows	
Rear window defogger	
Windshield wipers	
Winter driving tips	
Wireless remote control	
Battery-Saving Function	
Locking/Unlocking 110,	
Replacing the battery	
WMA disc*	269

<sup>\*:</sup> For vehicles with a navigation system or Entune Audio Plus, refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

GAS STATION INFORMATION		
Auxiliary catch lever	Trunk opener	Fuel filler door
P. 392	P. 117	P. 182
		CTYPIBJ019
Hood lock release lever	Fuel filler door opener	Tire inflation pressure
P. 392	P. 182	P. 505
Fuel tank capacity (Reference)	17.0 gal. (64.35 L, 14.2 In	np. gal.)
Fuel type		P. 182, 500
Cold tire inflation pressure		P. 505
Engine oil capacity (Drain and refill — reference)		P. 501
Engine oil type	"Toyota Genuine Motor Oil" or equivalent P. 501	