



MOTO W376g/W377g


User's Guide

HELLOMOTO


Thanks for purchasing the Motorola W376g/W377g wireless phone! It's an affordable phone with a sleek design that is sure to get attentions.

- **My Phone, My Way** — It's your phone—make it that way. Customize your home screen with personal pictures, change wallpapers, and use your favorite song as your ringtone.
- **Multimedia and Text Messaging** — Send pictures, sounds, or just text to keep in touch with your family, friends, and colleagues.
- **Office Tools** — When you're away from your home or desk, use handy tools like Calendar, Calculator, Stopwatch, and others.
- **Fun** — When you have a little time to spare, play a game or use your FM Radio.
- **Browse the Web** — Use Web Access to do a little surfing on the go.

Here's a quick anatomy lesson.



Home Screen




①

Press & hold the power key  until the display lights up to turn on your phone.

②

Press the center key  to open the Main Menu.

Main Menu



③

Press the navigation key  up/down/left/right to scroll to a menu feature.

④

Press the center key  to select it.

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Windows is a registered trademark of Microsoft Corporation. Apple is a trademark of Apple Inc., registered in the U.S. and other countries. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license.

© Motorola, Inc., 2008.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809518A38-A

contents

menu map	7	handsfree speaker	24	1-touch dial	30
Use and Care	9	codes & passwords	25	forward calls	31
essentials	10	lock & unlock phone	26	caller ID	31
about this guide	10	check battery meter	26	call waiting	32
SIM card	11	customize	27	change active line	32
battery	11	ring styles & alerts	27	entertainment	33
turn it on & off	14	answer options	28	camera	33
make a call	14	wallpaper	28	FM radio	34
answer a call	14	screen saver	28	sounds	36
adjust volume	14	backlight	28	pictures	36
store a phone number	14	calls	29	messages	37
call a stored phone number	15	redial	29	send message	37
see your phone number	15	emergency calls	29	receive message	37
tips & tricks	16	recent calls	29	voicemail	38
basics	17	notepad	30	more messaging features	38
home screen	17	speed dial	30		
text entry	21				

connections	41
connections	41
Bluetooth® wireless	
connections	43
tty operation	46
other features	48
advanced calling	48
contacts	50
personalize	53
call times & costs	56
handsfree	57
network	57
personal organizer	59
storage	61
fun & games	61
service & repairs	63
SAR Data	64
EU Conformance	65
WHO Information	65
Privacy and Data Security	66

OSS Information	67
Driving Safety	68
index	70

menu map

main menu



Prepaid

- Add Airtime
- My Phone Number
- Airtime Info
- Airtime Display
- Serial Number
- SIM Serial Number
- Code Entry Mode



Phonebook



Recent Calls

- Received Calls
- Dialed Calls
- Notepad
- Call Times
- Data Times
- Data Volumes



Messages

- Create Message
- Inbox
- Draft
- Outbox
- Quick Notes
- Voicemail
- Browser Msgs
- MMS Templates



Office Tools

- Calculator
- MyMenu
- Alarm Clock
- Stop Watch
- Chat*
- Dialing Services
- Calendar
- Lantern



Games & Apps



WebAccess

- Start Browser
- Web Shortcut
- Go to URL
- Web Session
- Stored Pages
- History
- General Setting



Multimedia

- Camera
- Pictures
- Sounds
- FM Radio



Settings

- (see next page)

This is the standard main menu layout.
Your phone's menu may be different.

* Network Dependent

settings menu



Ring Style

- Style
- Detail



Call Forward

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status



In Call Setup

- In-Call Timer
- My Caller ID
- Answer Options
- Call Waiting
- Hearing Aid



Initial Setup

- Time and Date
- 1-Touch Dial
- Display Settings
- Backlight
- Scroll
- Language
- DTMF
- TTY Setup
- Master Reset
- Master Clear
- Format Additional Storage Device
- Status Indicator



Personalize

- Home Screen
- Main Menu
- Color Setting
- Greeting
- Wallpaper
- Screen Saver
- Quick Dial



Phone Status

- Battery Meter



Headset

- Auto Answer



Network

- Service Tone*
- Call Drop Tone



Security

- Phone Lock
- Fixed Dial
- SIM PIN
- New Passwords



Lantern

- Lantern



Bluetooth Link

- Find Me
- Audio Devices
- Device History
- Setup

* Network Dependent

Use and Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



microwaves

Don't try to dry your phone in a microwave oven.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



the ground

Don't drop your phone.

essentials

about this guide

This guide shows how to locate a menu feature as follows:

Find it:  >  **Recent Calls** > **Dialed Calls**

This means that, from the home screen:


- 1 Press the *center key*  to open the menu.
- 2 Press the *navigation key*  to scroll to  **Recent Calls**, and press the center key  to select it.
- 3 Press the navigation key  to scroll to **Dialed Calls**, and press the center key  to select it.

symbols	
	This means a feature is network, SIM card, or subscription dependent and may not be available in all areas. Contact your service provider for more information.
	This means a feature requires an optional accessory.




SIM card

Your *Subscriber Identity Module* (SIM) card contains personal information such as your phone number and phonebook entries.




battery

install the battery



3



charge the battery


Tip: Motorola batteries have circuitry that protects the battery from damage from overcharging.

New batteries are not fully charged. Before you can use your phone, install and charge the battery as shown in the battery installation and battery charging sections. Some batteries perform best after several full charge/discharge cycles.

1 Insert the charger into the connector on your phone.

2 Plug the other end of the charger into an appropriate electrical outlet.

3 When your phone displays **Charge Complete**, remove the charger.



battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.



- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.
- When storing your battery, keep it uncharged in a cool, dark, dry place.
- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.



Contact your local recycling center for proper battery disposal.

Warning: Never dispose of batteries in a fire because they may explode.

Before using your phone, read the battery safety information in the “Safety and General Information” section included in this guide.

To save battery life:

- Adjust the backlight to turn off more quickly (see page 28).
- Turn off Bluetooth® power when you aren’t using it (see page 41).

turn it on & off

To turn on your phone, press and hold  until the display lights up. If prompted, enter your four-digit SIM PIN code.

Caution: If you enter an incorrect SIM PIN code three times in a row, your SIM card becomes disabled and your phone displays **SIM Blocked**. Contact your service provider.

To turn off your phone, press and hold  for five seconds.

make a call

To make a call, enter a phone number and press .

To hang up, press .

answer a call

When your phone and/or vibrates, press  to answer.

To hang up, press .

adjust volume

Press  up or down to increase or decrease the earpiece volume during a call.

Tip: Press  > **MUTE** to mute your phone during a call.

store a phone number

To store a number in **Phonebook**:

- 1 Enter a number in the home screen.
- 2 Press **Store**.
- 3 Enter a name and other details for the phone number. To select a highlighted item on the entry screen, press **CHANGE**.

To edit or delete a entry, see page 48.

call a stored phone number

Find it:   **Phonebook**

- 1 Scroll to the entry you want to call.

2 Press .

see your phone
number



Find it:   Prepaid > My Phone Number

tips & tricks

From the home screen (see page 17), you can use these shortcuts:


To...	Do this...
go to messages	Press  . 
redial a number	Press  , then scroll to the number you want to call and press  again.
see recently dialed numbers	Press  .
use application shortcuts	Press the right and left soft keys (see page 2) or the navigation key  .

To...	Do this...
speed dial a number	Press and hold the number key for a Phonebook entry's speed dial number (see page 30).
change ring style to vibrate	Press and hold  .

basics

home screen

The *home screen* displays when you turn on the phone and you are **not** on a call or using the menus:




Note: Your home screen may look different, depending on your service provider.

Soft key labels show the current soft key (see page 2) functions.

Your phone displays four menu icons in the middle of the home screen. Press the *navigation key*  up, down, left, or right to open the menu for the corresponding icon. You can change the menu icons that appear in the home screen, or set your phone not to display the icons:

Find it:  >  Settings > Personalize > Home Screen > Home Keys > Icons

Status indicators appear at the top of the home screen:



indicator

Signal Strength

Vertical bars show the strength of the network connections.

You cannot make or receive calls when you see .

Note: If another network is available, you may be able to make emergency even when your phone displays .

GPRS

Indicates your phone is using a high-speed GPRS network connection:

 = PDP context active

 = GPRS attached

 = GPRS available

indicator	
Active	Your phone is connected to a
Bluetooth	Bluetooth® device.
Connection	 = Bluetooth device connected.
Data Status	Shows connection status:  = secure application connection  = Circuit Switch Data (CSD) call  = packet data transfer  = unsecure application connection
Roaming	Shows when your phone is seeking or using a network outside your home network.  = roaming
Battery Level	Shows battery charge level. The more bars, the greater the charge.


indicator	
Headset	Indicates headset is active.
Active	
Ring Styles	Indicates the Style setting under Ring Style :  = Loud Ring  = Soft Ring  = Vibrate  = Vibrate & Ring  = Vibrate then Ring  = Silent

indicator	
New Message	Indicates when you receive new messages:  = text message  = voicemail message  = voicemail & text message  = MMS message  = active chat session

indicator	
Active Call	Indicates activity level of one or two lines (when two-line SIM card is used):  = call connected (single line)  = call forward on (single line)  = active call on line 1  = active call on line 2  = line 1 active, call forward on  = line 2 active, call forward on

text entry

Some features let you enter text.



set entry modes

Multiple text entry modes make it easy for you to enter names, numbers, and messages:

entry mode	
Primary	Enter text using the method you set.
Numeric	Enter numbers only (see page 24).
Symbol	Enter symbols only (see page 24).

entry mode

Secondary	Enter text using the method you set.
-----------	--------------------------------------

To set up Primary or Secondary entry mode:

- 1 Press the center key  in any text entry screen.
- 2 Scroll to **Entry Setup** and press **SELECT**.
- 3 Scroll to **Primary setup** or **Secondary setup** and press **SELECT**.
- 4 Scroll to one of these methods and press **SELECT**:

entry method

iTAP <i>language</i>	Phone predicts English, French, German, or Italian words as you press keys (see page 23).
Tap <i>language</i>	Enter letters and numbers by pressing a key one or more times (see page 23).

entry method	
Tap Extended	Enter letters, numbers, and symbols by pressing a key one or more times (see page 23).

Your phone may not contain all of the languages listed above.

When you select **Primary** or **Secondary** mode, the phone will use the entry method you assigned to that mode.

To select a text entry mode:

Press the center key  in any text entry screen, scroll to and select **Entry Mode**, then scroll to and select the desired entry mode.

Tip: Quick change! Press  in any text entry screen to switch entry modes.

entry mode indicators

When you select **Primary** or **Secondary** entry mode, these indicators identify the entry mode setting:

primary	secondary	
ab 1	ab 2	Tap, no capital letters
Ab 1↑	Ab 2↑	Tap, capitalize next letter only
AB 1↑	AB 2↑	Tap, all capital letters
ab 	ab 	iTAP™, no capital letters
Ab 	Ab 	iTAP, capitalize next letter only
AB 	AB 	iTAP, all capital letters

The indicators for **Numeric** and **Symbol** entry modes are:

non-text entry mode	
12	numeric mode
@	symbol mode


iTAP™ method

The iTAP software combines your key presses into common words, and predicts each word you enter.

For example, if you press **2 7 7 5**, your phone displays a list of word combinations such as **Appl**, **Aspj**, an **Aspk**.

When you enter three or more characters in a row, your phone will guess the rest of the word. For example, if you enter **Prog**, your phone might display:

Press **◂◃** left or right to select **Prog**. Press **SELECT** to accept selection. Press **✖** to enter a space.



To insert a letter combination from the bottom of the screen, press **◂◃** right or left to highlight the combination you want, and press **SELECT**.

To insert a suggested word, press **◂◃** up.

To enter a space, press **✖**.

tap & tap extended methods

To enter text using the **Tap** and **Tap Extended** methods, press a key repeatedly to cycle through the letters and

numbers on that key. Repeat this step to enter more letters. **Tap Extended** increases the number of characters on each key.

To enter a space, press .

numeric method

Press the keypad keys to enter the numbers you want.

symbol method

To see different symbols, press  up/down repeatedly. **To insert a symbol**, press its key, or scroll to it and press the center key .

text entry tips

To enter a space, press .

To change text case, press  in a text entry screen.

To enter punctuation while entering text, press  repeatedly to enter a punctuation mark or other character.

To edit or delete text while entering text, press  to move the cursor to the right of text you want to edit. Press **DELETE** (the right soft key) to delete the character left of the cursor. Hold **DELETE** to delete all text to the left of the cursor.

handsfree speaker

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

You can use your phone's **handsfree speaker** to make calls without holding the phone to your ear.

To turn on the handsfree speaker, press **SPKR ON**.

While the handsfree speaker is on, your display shows **Spkrphone On**.

To turn off the handsfree speaker, do either of the following:

- End the call.
- Press **SPKR OFF**.

codes & passwords

Your phone's four-digit **unlock code** is originally set to **1234** or to the last four digits of your phone number. The six-digit **security code** is originally set to **000000**. Your service provider may reset these codes before you get your phone.

If your service provider didn't change these codes, you should change them to prevent others from accessing your personal information. The unlock code must contain four digits. The security code must contain six digits.

To change a code or password:

Find it:  >  **Settings** > **Security** > **New Passwords**

You can also change your **SIM PIN** codes or call barring password.

Select the type of code you want to change, enter the old code when prompted, then enter the new code.

If you forget your unlock code: At the **Enter Unlock Code:** prompt, try entering 1234 or the last four digits of your phone number. If that doesn't work, contact your service provider.

If you forget other codes: If you forget your security code, SIM PIN code, PIN2 code, or call barring password, contact your service provider.

lock & unlock phone

You can lock your phone to keep others from using it. You can lock your phone manually or set it to lock

automatically whenever you turn it off. To lock or unlock your phone, you need the four-digit unlock code.

A locked phone still rings or vibrates for incoming calls or messages, **but you have to unlock it to answer.**

Note: You can make emergency calls even when your phone is locked (see page 29).

To lock your phone:

Find it:  >  Settings > Security > Phone Lock > Lock Now
or Automatic Lock

check battery meter

Find it:  >  Settings > Phone Status > Battery Meter

customize

ring styles & alerts

Your phone rings and/or vibrates to notify you of an incoming call or another event such as a new message. This ring or vibration is called an *alert*.

set a style

Find it:  >  Settings > Ring Style

- 1 With **Style** highlighted, press **CHANGE** or the center key .
- 2 Scroll to the style you want (see page 19) and press **SELECT** or the center key .

set alerts

Your phone includes alerts for **Line 1**, **Line 2**, **Text Msgs**, **Voicemail**, and **Alarm**. You can specify a detailed setting (ringtone) for each alert.

Note: You can't specify detailed settings for alerts if **Ring Style** is set to **Silent**.

Find it:  >  Settings > Ring Style

- 1 Scroll to **style Detail** and press **CHANGE** or the center key .
- 2 Scroll to an alert type and press **CHANGE** or the center key .
- 3 Scroll to **Preloaded and downloaded media files** or **Additional Storage Device** and press **SELECT** or the center key .

- 4 Scroll to the setting you want and press **SELECT** or the center key .

As you scroll through settings, your phone plays a sample of each one you highlight.

answer options

You can use different ways to answer an incoming call. To turn on or turn off an answer option:

Find it:  >  **Settings** > **In Call Setup** > **Answer Options**

options	
Multi-key on	Answer by pressing any key.
Multi-key off	Answer by pressing  .
Open to answer	Answer by opening the flip.

Note: You always can press  to answer a call.

wallpaper

Select a wallpaper (background) image in your home screen:

Find it:  >  **Settings** > **Personalize** > **Wallpaper**

screen saver

You can set a photo, picture, or animation as a screen saver image. Your phone displays the screen saver when no activity occurs for a specified time period.

Find it:  >  **Settings** > **Personalize** > **Screen Saver**

Tip: Turn off the screen saver to extend battery life.

backlight

Set the amount of time the display and keypad backlights stay turned on:

Find it:  >  **Settings** > **Initial Setup** > **Backlight**

calls

redial



- 1 Press  from the home screen.
- 2 Scroll to the number you want to call and press . If you hear a busy signal and see **Call Failed** or **Number Busy**, press  to redial the number.

emergency calls

Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call at any time, even when your phone is locked or the SIM card is not inserted.

Note: Check with your service provider, as emergency numbers vary by country. Your phone may not work in all locations, and sometimes an emergency call cannot

be placed due to network, environmental, or interference issues. Do not solely rely on your wireless phone for essential communications such as medical emergencies.

To make an emergency call:

- 1 Press the keypad keys to enter the emergency numbers.
- 2 Press  to call the emergency number.

recent calls

Your phone keeps lists of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.

Shortcut: Press  in the home screen to see the **Dialed Calls** list.

Find it:  >  **Recent Calls**

- 1 Scroll to **Received Calls** or **Dialed Calls** and press **SELECT** or the center key .
- 2 Scroll to a phone number.
- 3 Press  to call the number.

notepad

The most recent set of digits entered are stored in your phone's **Notepad**. To retrieve the digits in the **Notepad**:

Find it:  >  **Recent Calls** > **Notepad**

speed dial

Each entry you store in your phonebook is assigned a unique *speed dial* number.

To speed dial a number:

- 1 Enter the speed dial number for the entry you want to call and press .
- 2 Press  to call the number.

Tip: What's the speed dial number? To see the speed dial number for a phonebook entry, press the center key  from the home screen, select **Phonebook**, then scroll to the entry and press **VIEW**.

1-touch dial

You can quickly call speed dial entries 1 through 9 by pressing and holding the speed dial number for one second.

You can set 1-touch dial to call the first nine phonebook entries stored on your phone, the first nine phonebook entries stored on your SIM card, or the first nine entries on your **Fixed Dial** list:

Find it:  >  Settings > Initial Setup > 1-Touch Dial
> Phone, SIM, or Fixed Dial

forward calls



You can forward your voice, fax, and data calls to phone numbers that you choose:

Find it:  >  Settings > Call Forward > Voice, Fax, or Data Calls

To check the setting for each Call Forward option:

Find it:  >  Settings > Call Forward > Forward Status
> Voice, Fax, or Data Calls

To cancel all call forwarding:

Find it:  >  Settings > Call Forward > Cancel All

caller ID

Calling line identification (caller ID) shows the phone number for an incoming call on your phone's screen.



Your phone shows the caller's name and picture when they're stored in your phonebook (see page 47). If the caller's name and picture are not stored in your phonebook, your phone shows **Incoming Call**.

Note: Picture IDs aren't available for phonebook entries stored on the SIM card.

To set your call waiting options:

Find it:  >  Settings > In Call Setup > Call Waiting

Tip: Want to know who's calling without even looking at your phone? To give one of your phonebook entries a special ringtone, see page 47.

To show or hide your own phone number:

Find it:  >  Settings > In Call Setup > My Caller ID

- 1 Select **Next Call Only** or **All Calls**.
- 2 Select **Show ID** or **Hide ID**.

To show or hide your phone number for the next call only, enter the number and, **before you press** , press the center key , then select **Show ID** or **Hide ID**.

call waiting



When you're on a call, you'll hear an alert if you receive a second call. Press **ANSWER** to answer the new call.

- To switch between calls, press **SWITCH**.
- To connect the two calls, press **LINK**.
- To end the call on hold, press the center key  and select **End Call On Hold**.

To turn call waiting on or off:

Find it:  >  Settings > In Call Setup > Call Waiting

entertainment

camera

To activate your camera:

Find it:  >  Multimedia > Camera

Your phone displays the active viewfinder.

- 1 Point the camera lens (see page 2) at the photo subject and press **CAPTURE** to take the photo.
- 2 **To save the photo**, press **STORE**, then select **Send In Message**, **Store Only**, **Apply as Wallpaper**, **Apply as Screen Saver**, or **Apply as Phonebook Entry**.

To delete the photo and return to the active viewfinder, press **DISCARD**.

Note: If the screen flickers when you take a photo, you may need to select an alternate frequency for the **Flicker** setting (see **Picture Setup** information on page 33).

From the active viewfinder, you can press the center key  to open the **Pictures Menu**:

options	
Go To Pictures	See stored pictures.
Auto-Timed Capture	Set a timer for the camera to take a photo.
Picture Setup	Adjust photo settings: Lighting Conditions , Special Effect , Exposure , Resolution , Shutter Tone , Image Quality , Flicker .

options

View Free

Check used and available memory.

Space

FM radio



You can listen to your phone's built-in FM Radio and set as many as nine of your favorite FM radio stations as presets.

Note: The FM radio works only when a headset is plugged in. If you try to turn on the radio without plugging in a headset, your phone will display **Please insert the earpiece.**

Note: The headset acts as an antenna, so the FM radio receiver performance is dependent on the type of headset device connected. If a non-Motorola 3.5 mm headset is connected to the phone, or the headset is curled up or kinked, performance may be affected.

turn FM radio on

Plug a 3.5mm headset into your phone, then:

Find it:  >  **Multimedia** > **FM Radio**

The FM radio tunes to the lowest available frequency when you use it for the first time. When you turn it on after that, it tunes in the frequency last used.

FM radio controls

tune in station

Press  left or right. Each key press increases/decreases frequency by 0.1 MHz.

or

Press the center key , then select **Set Frequency**. Use the number keys to enter the numbers for the station you want. (Press  to enter a decimal point.)

FM radio controls	
seek station	Press & hold  left or right. Repeat to go to the next station.
scan all stations	Press the center key  , then select Scan . Press the center key  to stop at a station.
scan presets	Press the center key  , then select Scan Presets . Press the center key  to stop at a station.
volume	Press  up/down, or use side volume keys , to increase/decrease volume.
mute radio	Press MUTE .
turn radio off	Press the center key  , then select FM Radio Off .

Tip: Press **HIDE** to listen to the radio while you use other phone features.

presets

You can store up to nine FM stations as radio presets.

To store a preset:

- 1 Tune into the desired station.
- 2 Press and hold a number key **[1]** through **[9]**.

While listening to a station, **press and hold** a number key **[1]** through **[9]** to store the station as a preset for that number key. **To select a preset station**, press the number key for the station you want.

send station information in message

Share your favorite station with your friends and family by sending them a message with station information.

While tuned to the station you want, press the center key , then select **Send station info**.

play radio through speaker or headset

To play the radio through the phone's speaker:

When the radio is active, press , then select **Speaker**.

To resume playing through the headset:

Press , then select **Earpiece**.

Note: The headset must be inserted into the phone for the FM radio to play through the speaker.

sounds

You can listen to all of the sounds stored on your phone and assign the sound of your choice to alerts (see page 27).

Find it:  >  **Multimedia** > **Sounds**

- 1 Select **Preloaded and downloaded media files** or **Additional Storage Device**.
- 2 Scroll to a sound and press **PLAY**, or press the center key  for other options.

pictures

View the images stored on your phone and apply them as your wallpaper or screen saver:

Find it:  >  **Multimedia** > **Pictures**

- 1 Select **Preloaded and downloaded media files** or **Additional Storage Device**.
- 2 Scroll to a picture and press **VIEW**, or press the center key  for other options.

messages

You can use the **Messages** feature to send and receive SMS, EMS, and MMS messages and to access your voicemail messages.

send message

send message



A message can contain text and pictures, sounds, or other media objects. You can add multiple pages to a message and put text and media objects on each page. You can send a message to other compatible phones or to email addresses.

Find it:  >  **Messages** > **Create**

- 1 Select **SMS/EMS** or **MMS**.
- 2 Enter message text.

- 3 To insert a **picture, sound, or other media object**, press **INSERT** and select the file type: **Picture**, **Sound**, or **Animation**. Select **Preloaded and downloaded media files** or **Additional Storage Device**, then select the file.
- 4 When you finish the message, press **OK**.
- 5 When you finish setting message options, press **DONE**.
- 6 Select message recipients and press **SEND**.

receive message



When you receive a message, your phone displays a message indicator (see page 20) and **New Message**. You can read the message immediately or save it in your **Inbox** for later viewing.

To read the message immediately, press **READ**.

To read a message in your Inbox:

Find it:  >  Messages > Inbox

- 1 Scroll to the message you want to read.
- 2 Press **Read** to open the message.

If the message is an MMS message, your phone displays the multimedia object, then the message.

voicemail



Note: Your service provider may give you additional information about using voicemail.

Your network stores the voicemail messages that you receive.

When you receive a voicemail message, your phone shows the voicemail message indicator (see page 20) and **1 New Message**. **To listen to the message**

38 messages

immediately, press **CALL**. **To check your voicemail messages later:**

Find it:  >  Messages > Voicemail

Tip: You can also check your voicemail messages by **pressing and holding** **1** from the home screen.

Note: Your phone may prompt you to store your voicemail phone number. If you don't know your voicemail number, contact your service provider.

more messaging features

features

send text message

 >  Messages > Create > Create Message
> SMS/EMS



features	
send multimedia message	
 >  Messages > Create > Create Message > MMS	
Note: Your display shows a separate folder for each email account.	
send multimedia template	
Send a prewritten text message:	
 >  Messages > Quick Notes	
send multimedia template	
Send a prewritten multimedia message:	
 >  Messages > Create > Create Message > MMS Templates	
read new message	
When your display shows New Message , press READ .	

features	
read old message	
 >  Messages > Inbox	
edit message drafts	
You can save unfinished messages in the Draft folder to edit and send later:	
 >  Messages > Draft	
delete messages	
 >  Messages	
Press the center key  and select Cleanup Messages , then select Inbox , Browse Msgs , Outbox , or Drafts .	

features

read browser messages



To read messages received by your browser:

When your display shows **New Message**, press **View**. If you choose to read the message later:

◂◃ > ✉ Messages > Browser Msgs

To activate browser messages and adjust browser message settings:

◂◃ > ✉ Messages

Press the center key ◂◃ and select **Browser Msg Setup**.

connections

connections

Bluetooth® wireless connections

Your phone supports Bluetooth wireless connections. You can connect your phone with an optional Bluetooth headset or Bluetooth car kit to make handsfree calls.



Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these devices.

For maximum Bluetooth security, you should always connect Bluetooth devices in a safe, private environment.

turn Bluetooth power on or off

Your phone automatically turns Bluetooth power on when you use a Bluetooth feature.

To turn Bluetooth power on or off at any time:

Find it: > Settings > Connections > Bluetooth Link > Setup

Select **Power**, then select **On**.

Note: To extend battery life and maximize Bluetooth security, use this procedure to set Bluetooth power to **Off** when not in use. Your phone will not connect to

another device until you use a Bluetooth feature again, or set Bluetooth power back to **On**.

place phone in discoverable mode

Allow an unknown Bluetooth device to discover your phone:

Find it:  >  **Settings** > **Bluetooth Link** > **Bluetooth**
> **Find Me**

The Bluetooth indicator  flashes when your phone is in discoverable mode.

pair with other device

Before you try to connect your phone with another device, make sure the device is **on** and **ready** in *pairing* or *bonding* mode (see the user guide for the device). You can connect your phone with only one device at a time.

Find it:  >  **Settings** > **Bluetooth Link** > **Handsfree**
> **[Look for device]**

Your phone lists the devices it finds within range.

- 1 Scroll to a device and connect to it by pressing the center key  or **SELECT**.
- 2 If necessary, enter a mutually agreed upon passkey (such as **0000**) on your phone and the device, then press **OK** to connect to the device.

When your phone is connected, the Bluetooth indicator  shows in the home screen.

Tip: Want to know more about your headset or car kit? For specific information about a device, refer to the instructions that came with it.

tty operation



You can use an optional TTY device with your phone to send and receive calls. You must plug the TTY device into the phone's headset jack (see page 2) and set the phone to operate in one of three TTY modes.

Note: Use a TSB-121 compliant cable (provided by the TTY device manufacturer) to connect the TTY device to the phone.

Note: Set the phone volume to level 4 (middle setting) for proper operation. If you experience a high number of incorrect characters, adjust the volume as needed to minimize errors.

Note: For optimal performance, your phone should be at least 12 inches (30 centimeters) from the TTY device. Placing the phone too close to the device may cause high error rates.

set TTY mode

When you set your phone to a TTY mode, it operates in that mode whenever the tTY device is connected:

Find it:  >  Settings > Initial Setup > TTY Setup

Scroll to one of the following options and press **SELECT**:

TTY option	
Voice	Set to standard voice mode.
TTY	Transmit and receive TTY characters.
VCO	Receive TTY characters but transmit by speaking into the microphone.
HCO	Transmit TTY characters but receive by listening to the phone earpiece.

return to voice mode

To return to standard voice mode, select **Voice** from the TTY Setup options.

other features

advanced calling

features

conference call



During a call:

Press the center key  and select **New call**, then enter the new number and press **OK**. When the new call connects, press **LINK** to link the first call into a conference call.

hold a call

Press the center key  and select **Hold** to put all active calls on hold. Press **RESUME** to take the call off hold.

features

mute a call

Press the center key  and select **Mute** to mute a call. Press **UNMUTE** to resume normal operation.

make another call during a call



During a call:

Press the center key  and select **New call**. Enter a number to call and press **OK**.

international calls



If your phone service includes international dialing, press and hold **0** to insert your local international access code (indicated by +). Then, press number keys to dial the country code and phone number.

features

fixed dial



When you turn on fixed dialing, you can call only numbers stored in the fixed dial list.

Note: You must enter your SIM PIN2 code to turn fixed dialing on or off. If you forget your PIN2 code, contact your service provider.

Turn fixed dialing on or off:

 >  Settings > Security > Fixed Dialing > On or Off

Use the fixed dial list:

 >  Office Tools > Dialing Services > Fixed Dial

DTMF tones

Your phone can send *Dual Tone Multi Frequency* (DTMF) tones for calling card calls or other automated touch-tone calls:

 >  Settings > Initial Setup > DTMF

features

attach number

Insert an area code or other prefix for a phonebook entry, **Fixed Dial** number, or a number from the **Dialed Calls** or **Received Calls** list:

While dialing, press the center key  and select **Attach Number**. Select the list with the number you want to attach, then select the number.

phonebook

features

add new entry

 >  Phonebook

Press the center key  and select **New**, then select **Number**. Enter the entry details and press **DONE** when finished to save the entry.

Note: Your phone's memory limit is 500 entries. Your SIM card's memory limit depends on your carrier's SIM card type.

call entry

 >  Phonebook

Scroll to the entry and press .

features

view entry

 >  Phonebook

Scroll to the entry and press **VIEW**.

send message to entry

 >  Phonebook

Scroll to the entry and press the center key , then select **Send Message**.

add additional phone number or email address to entry

 >  Phonebook

Scroll to the entry and press the center key , then select **Edit**. Scroll to and select **MORE**, then select **Number** or **Email**.

features

set picture ID for entry

Assign a photo or picture to show in the display when you receive a call from a phonebook entry:



Scroll to the entry and press the center key , then select **Edit**. Scroll to **Picture** and press **CHANGE**. Select **Preloaded and downloaded media files** or **Additional Storage Device**, then scroll up/down to the picture you want and press **SELECT**. Press **DONE** to save your entry.

Note: You cannot set a picture ID for an entry stored on the SIM card.

features

set ring ID for entry

Assign a distinctive call alert (*ring ID*) for a phonebook entry:



Scroll to the contact and press the center key , then select **Edit**. Scroll to **Picture** and press **CHANGE**. Select **Preloaded and downloaded media files** or **Additional Storage Device**, then scroll up/down to the sound you want and press **SELECT**. Press **DONE** to save your entry.

Note: You cannot set a ring ID for an entry stored on the SIM card.

set phonebook list sort order



Press the center key  and select **Setup**, then select **Sorting By**. Select **Alpha Sorting** or **Speed No. Sorting**.

features

show only primary entries

When a phonebook entry has multiple numbers, you can assign one number as the primary number. You can then show only primary numbers when you view the phonebook list.

To set up a primary number:

 >  Phonebook

Scroll to the phonebook entry and press the center key , then select **Set Primary**. With the number highlighted, press **SELECT**.

To view only primary numbers:

 >  Phonebook

Press the center key  and select **Setup**, then scroll to **View** and press **CHANGE**. Select **Primary Numbers**, then press **DONE**.

features

delete entry

 >  Phonebook

Scroll to the entry and press the center key , then select **Delete**.

assign entry to category

 >  Phonebook

Scroll to the entry and press the center key , then select **Edit**. Scroll to **Category** and press **CHANGE**, then select a category and press **DONE**.

Note: You cannot assign an entry stored on the SIM card to a category.

You can view phonebook entries by predefined category (**Business**, **Personal**, **General**, **VIPs**), or phonebook entries in a category that you create (press the center key  and select **New**).

features
set category view  >  Phonebook Press the center key  and select Category , then select a category.
copy entry  >  Phonebook Scroll to the entry and press the center key  , select Copy , then select Entries . To add another entry, highlight Entries and press CHANGE . When finished, scroll to To and press CHANGE , then select Phone Memory or SIM Card .
copy all entries  >  Phonebook Press the center key  and select Copy , then select All to SIM or All to Phone . Select Merge or Overwrite .

personalize

features
change ring volume  >  Settings > Ring Style Scroll to <i>style</i> Detail and press CHANGE , then scroll to Ring Volume and press CHANGE .
change key volume  >  Settings > Ring Style Scroll to <i>style</i> Detail and press CHANGE , then scroll to Key Volume and press CHANGE .
change greeting  >  Settings > Personalize > Greeting
change home screen soft keys  >  Settings > Personalize > Home Screen

features

change scroll option

Set the highlight bar to stop or wrap around in menu lists:

 >  Settings > Initial Setup > Scroll

change message alert

 >  Settings > Ring Style

Scroll to *style Detail* and press **CHANGE**, then scroll to **Text Msgs** or **Voicemail** and press **CHANGE**.

language

Set menu language:

 >  Settings > Initial Setup > Language

features

change menu view

Change the order of menu options and specify whether the menu is shown as icons or text:

 >  Settings > Personalize > Main Menu

change screen colors

 >  Settings > Personalize > Color Setting

change clock

 >  Settings > Personalize > Home Screen > Clock Set
> Digital or Analog

features

use a custom menu

You can create a custom menu of commonly-used options, then use shortcuts to go directly to those options.

To set up a custom menu:

Scroll to the menu option you want to add to the custom menu, then press and hold the center key . If desired, change the key assigned to the option by selecting **Key** and pressing **CHANGE**.

To select a custom menu option, from the home screen, press the center key , then press the number key for the custom menu option you want.

To view the custom menu:

 >  Office Tools > MyMenu

features

turn status indicator on/off

 >  Settings > Initial Setup > Status Indicator

check battery meter

 >  Settings > Phone Status > Battery Meter

master reset

Reset default settings for all options **except** the unlock code, security code, and lifetime timer:

 >  Settings > Initial Setup > Master Reset

Note: This option requires you to enter your six-digit security code (see page 25).

features

master clear

Caution: Master Clear **erases all information you have entered** (including phonebook and calendar entries) **and content you have downloaded** (including photos and sounds) stored in your phone's memory. After you erase the information, you can't recover it.

 >  Settings > Initial Setup > Master Clear

Note: This option requires you to enter your six-digit security code (see page 25).

call times & costs

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

52 other features—call times & costs

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.

features

set in-call timer

 >  Settings > In Call Setup > In-Call Timer



call times

 >  Recent Calls > Call Times



data times

 >  Recent Calls > Data Times



data volumes

 >  Recent Calls



Press **Options** and select **Data Volumes**.

handsfree

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

features	
auto answer (headset)	
Automatically answer calls when connected to a car kit or headset:	
 >  Settings > Headset > Auto-Answer	

network

features	
service tone	
Set phone to beep whenever the network registration status changes:	
 >  Settings > Network > Service Tone	
call drop tone	
Set phone to play an alert tone whenever the network drops a call. (Because digital networks are so quiet, a call drop alert may be your only indication that a call was dropped.)	
 >  Settings > Network > Call Drop Tone	

personal organizer

features
set alarm  >  Office Tools > Alarm Clock > [New Alarm]
turn off alarm When the display shows an alarm: To turn off the alarm, press Dismiss or  . To set an eight-minute delay, press Snooze .
add new calendar event  >  Office Tools > Calendar Scroll to and select the day, then select [New] . Add a title, start time, and other event details, and press DONE .

features
see calendar event  >  Office Tools > Calendar Scroll to and select the day, then scroll to the event you want to see and press VIEW .
turn off calendar event reminder When the display shows and sounds an event reminder: To see event details, press VIEW . To turn off the reminder, press EXIT .
set calendar default view  >  Office Tools > Calendar Press the center key  , then scroll to Week View or Month View and press SELECT .

features

send calendar event to another device

Send a calendar event to another phone, computer, or device. You can send the event as a message attachment or by using a Bluetooth® connection with the other phone, computer, or device.

•◂◃• >  Office Tools > Calendar

Scroll to and select the day, then scroll to the event you want to send and press the center key •◂◃•. Select **Send**, then select **Send via MMS** or **Bluetooth**.

calculator

•◂◃• >  Office Tools > Calculator

features

currency converter

•◂◃• >  Office Tools > Calendar

Press the center key •◂◃• and select **Exchange Rate**. Enter an exchange rate and press **OK**. Enter the amount to be converted and press the center key •◂◃•, then select **Convert Currency**.

stop watch

•◂◃• >  Office Tools > Stop Watch

Press **START** to begin timing, **STOP** to stop timing, and **RESET** to reset the stop watch.

Tip: Press **SNAPSHOT** while timing to record up to nine milestones without stopping the timing.

features

lantern

When you turn on the **Lantern**, the phone's screen is illuminated. This feature is handy when you need a small light (for example, at night to find keys in a purse or to locate a door lock). **To turn on the lantern:**

 >  Office Tools > Lantern

To set how long the lantern stays on:

 >  Settings > Lantern

Tip: When the **Lantern** is turned on, you can turn it off manually by pressing any key.

storage

features

format additional storage device

 >  Settings > Initial Setup
> Format Additional Storage Device

fun & games

features

manage pictures

 >  Multimedia > Pictures



manage sounds

 >  Multimedia > Sounds



play a game

 >  Games & Apps

features
start browser  >  Web Access > Start Browser
go to bookmarks  >  Web Access > Web Shortcut
go to URL  >  Web Access > Go to URL
go to web session  >  Web Access > Web Session
go to web session  >  Web Access > Stored Pages
go to browser history  >  Web Access > History

service & repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/consumer/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

This model meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobile devices used by the general public is 2 W/kg and the highest SAR value for this device when tested at the ear is 0.29 W/kg.¹ As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user's guide.² In this case, the highest tested SAR value is 0.28 W/kg.¹

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental

requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a "handsfree" device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organization (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

1. The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.
2. Please see the *Safety and General Information* section about body worn operation.



MOTOROLA

Important Safety and Legal Information

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.*

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in

* The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2007.

the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola—or if you hang your mobile device from a lanyard around your neck—keep the mobile

device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your health care provider.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue use if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- Do not place a mobile device in the airbag deployment area.

Responsible driving practices can be found in the "Smart Practices While Driving" section in this user's guide and/or at the Motorola Web site: www.motorola.com/callsmart.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Operational Warnings

Obey all posted signs when using mobile devices in public areas.


Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.
	Do not let your battery, charger, or mobile device get wet.

Symbol	Definition
	Listening at full volume to music or voice through a headset may damage your hearing.

Batteries and Chargers

Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see the “Battery Use & Battery Safety” section in this user’s guide.

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Caution About High Volume Usage



Listening at full volume to music or voice through a headset may damage your hearing.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of

your body. If you continue to have discomfort during or after such use, stop use and see a physician.

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept

any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by

consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.

Products Covered	Length of Coverage
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
------------	---

Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL

MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Hearing Aid Compatibility with Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF

exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int/peh-emf>

Product Registration

Online Product Registration:

direct.motorola.com/hellomoto/Motosupport/source/registration.asp

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation

or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Caring for the Environment by Recycling



This symbol on a Motorola product means the product should not be disposed of with household waste.

Disposal of your Mobile Device and Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved

national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/recycling

Disposal of your Mobile Device Packaging and User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

“Perchlorate Material – special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.”

There is no special handling required by consumers.

Privacy and Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device’s keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device which updates the device’s security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or

turning it in for recycling. For step-by-step instructions on how to delete all personal information from your device, see the section entitled “master clear” or “delete data” in this user’s guide.

Note: For information on backing up your mobile device data before erasing it, go to www.motorola.com and then navigate to the “downloads” section of the consumer Web page for “Motorola Backup” or “Motorola Phone Tools.”

- **Understanding AGPS**—In order to comply with emergency caller location requirements of the FCC, certain Motorola mobile devices incorporate *Assisted Global Positioning System* (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user’s location—for example, to provide

driving directions. Users who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Smart Practices While Driving

Drive Safe, Call Smart SM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.

- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.



- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Smart Practices While Driving

Drive Safe, Call SmartSM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your



eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.

- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.

- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

index

A

accessories 10, 43, 57

alarm

set 59

alarm clock 59

alert

turn off 16

alerts 27

answer a call 28

auto answer 57

B

battery 12

check meter 55

battery charge indicator light 12

battery life, extend 13, 43

battery meter 55

battery, charge level 19

Bluetooth connections

make phone discoverable 44

Bluetooth wireless 43

Bluetooth, connection active 19

bonding. See Bluetooth wireless

browser 62

bookmarks 62

history 62

shortcuts 62

stored pages 62

URL 62

web session 62

browser message 40

C

cable connection 41

calculator 60

calendar

add event 59

event reminder 59

see event 59

send event 60

set view 59

call

answer 28

attach number 49

conference call 48

DTMF tones 49

fixed dial 49

hold 48

international 48

make another call 48

mute 48

- call alert 51
- call barring 25
- call timers 56
- call, active 20
- caller ID 51
- calls
 - picture ID 51
- car kit 57
- center key 10
- clear/back key 2, 24
- codes 25, 26
- conference call 48
- connection
 - cable 41
- contact list
 - picture ID 31
- contacts
 - add email address 50
 - add entry 50
 - add number 50

- assign contact to category 52
- call 50
- copy all entries 53
- copy entry 53
- delete contact 52
- primary contacts 52
- ring ID 51
- send message to 50
- sorting order 51
- view by category 53
- view entry 50
- costs, track 57
- customer support 63

D

- data call 56
- data status 19
- data timers 56
- delete message 39
- delete text 24
- dialed calls 29

- display 3, 17, 28
- DTMF tones 49

E

- email
 - drafts 39
- email address 50
- emergency number 29
- Enter Unlock Code message 25

F

- fixed dial 49
- FM radio
 - mute 35
 - presets 35
 - scan presets 35
 - scan stations 35
 - tune 34
 - turn off 35
 - turn on 34
 - volume 35

G

game 61
GPRS 18
greeting
 change 53

H

handsfree
 auto answer 57
handsfree speaker 24
headset 57
hold a call 48
home screen 3, 17
 change clock 54
 colors 54

I

Incoming Call message 31
indicator
 status 55

indicator, active call 20
indicator, battery charge level 19
indicator, Bluetooth connection
 19
indicator, data status 19
indicator, GPRS 18
indicator, new message 20
indicator, ring styles 19
indicator, roaming 19
indicator, signal strength 18
indicators
 text entry mode 22
international access code 48
iTAP entry method 23

K

key
 change volume 53

L

language 54

lantern 61
linking. See Bluetooth wireless
lock
 phone 26

M

master reset 55, 56
menu 3
 change view 54
 language 54
menu icons 17
menu key 10
message
 browser 40
 delete 39
 multimedia 39
 multimedia template 39
 quick note 39
 read 37, 39
 send 37
 text 38

- message indicator 37
- message, new message received
 - 20
- mini-USB port 12
- multimedia message 37, 39
- music player
 - controls 34
- mute a call 48

N

- navigation key 2, 10
- network
 - call drop tone 58
 - service tone 58
 - settings 58
 - view 57
 - view list 57
- numeric entry method 24

O

- optional accessory 10

82 index

- optional feature 10

P

- pairing. See Bluetooth wireless
- passwords. See codes
- personalize 53
- phone number
 - store 50
- picture
 - manage 61
- picture ID 31, 51
- PIN code 25
- PIN2 code 25, 49
- power/end key 2
- predictive text entry 23
- push bar 2

Q

- quick note 39

R

- radio
 - turn on 34
- received calls 29
- recent calls 29
- redial 16, 29
- repairs 63
- ring
 - change volume 53
- ring ID 51
- ring styles 19, 27
- ringer ID 31
- roaming 19

S

- safety tips 68
- scroll
 - change 54
- security code 25
- send key 2

- signal strength 18
- SIM card 25, 49
- soft key
 - left 2
 - right 2
- soft keys
 - change in home screen 53
- sound
 - manage 61
- speakerphone 57
- status indicators 55
- stop watch 60
- store phone numbers 50
- support 63
- symbol entry method 24

T

- tap entry method 23
- technical support 63
- text edit 24
- text entry 21

- entry mode indicators 22
- text entry method, numeric 24
- text entry method, symbol 24
- text entry method, tap extended
 - 23
- text entry method,iTAP 23
- text entry method,tap extended
 - entry method 23
- text message 37, 38
- timers 56
- TTY
 - options 46

U

- unlock
 - phone 25, 26
- unlock code 25, 26

V

- voice dial 57
- volume

- change 53

W

- WHO information 65

- U.S. patent Re. 34,976

www.motorola.com

