

Dishwasher



1. Load dishwasher.
2. Add detergent pod to the dispenser and close the dispenser door.
3. Select Cycle.

Select Cycle

Press the **Cycle Select** pod for the desired wash cycle. The light under the cycle name will display to indicate which cycle has been selected.

NOTE: Actual cycle times vary based on several factors including, but not limited to, inlet water temperature and household water pressure.

HEAVY	This cycle is meant for heavily soiled dishes or cookware with dried-on or baked-on soils. This cycle may not remove burned-on foods. Everyday dishes are safe to be used in this cycle. Time: 1 hour 45 minutes.
NORMAL	This cycle is for medium to heavily soiled dishes and glassware. This cycle includes heated dry. Time: 1 hour 30 minutes.
LIGHT	This cycle is for lightly soiled dishes and glassware. This cycle includes heated dry. Time: 1 hour 25 minutes.
GLASSES	This cycle is for lightly soiled glassware. This cycle has a lower temperature heated dry. Time: 1 hour 5 minutes.
AIR-DRY	This cycle is for loads of everyday dishes, glasses and cookware with light soils that have been pre-rinsed and should dry naturally. This cycle does not include heated dry. Time: 50 minutes.
SPEED	This cycle is for loads of everyday dishes, glasses and cookware with medium soils. This cycle features reduced wash times to allow for faster cycle completion. This cycle also has reduced heated dry. Time: 1 hour 20 minutes.
RINSE	This cycle is for rinsing partial loads that will be washed later. This cycle does not include heated dry. DO NOT use detergent with this cycle. Time: 10 minutes.

4. Close the door to the dishwasher to start the cycle.
5. The **CLEAN** light is illuminated when the cycle is complete.
6. Turn the dishwasher off when not in use.

