

1993–94 Legend Coupe

Contents

In This Manual

How to Use This Manual [1](#)
Circuit Schematics (see Circuit Index)
Fuse/Relay Information [6](#)
Connector Cavity Numbers [202](#)
Connector Identification [203](#)
Wire Harness Routing [203](#)
In-Line-Connector Circuit Identification [204](#)

Circuit Index

Air conditioner (manual A/C)
 Air delivery [61](#)
 Blower controls [60](#)
 Compressor controls [62](#)
 Fans [63](#)
Anti-lock brake system (ABS) [44](#)
Ashtray light [114–3](#)
A/T gear position indicator [89](#)
Automatic transmission controls [39](#)
Back-up lights [110–9](#)
Brake indicator system [71](#)
Brake lights
 '93 without spoiler [110–11](#)
 '93 with spoiler [110–12](#)
 '94 [110–13](#)
Ceiling lights [114](#)
Cellular phone [152](#)
Charging system [22](#)
Cigarette lighter [155](#)
Climate control
 Air delivery [61–2](#)
 Blower controls [60–1](#)
 Compressor controls [62–2](#)
 Fans [63–2](#)
Clock [154](#)
Console lights [114–2](#)
Cruise control [34](#)
Dash lights [114–2](#)
Driving position memory system (DPMS)
 '93 [143](#)
 '94 [143–4](#)
Engine coolant temperature (ECT) gauge [81](#)
Entry light timer system [115](#)
Fog lights
 '93 [110–8](#)
 '94 [110–9](#)
Front parking lights [110–6](#)
Front side marker lights [110–6](#)
Fuel gauge [81](#)
Fuse box
 Under-dash [6–2](#)
 Under-hood [6](#)
Gauges [81](#)
Glove box light [114–3](#)
Ground distribution [14](#)
Hazard warning lights [110–11](#)
Headlights
 Canada [110–2](#)
 USA [110](#)
Headlight switch [100](#)
Heated seats [147](#)
Heater
 Air delivery
 Manual A/C [61](#)
 Climate controls [61–2](#)
 Blower controls
 Manual A/C [60](#)
 Climate controls [60–1](#)
Horns [40](#)
Ignition key reminder [73](#)
Ignition system [20](#)
Indicators [80](#)
Integrated control unit [70](#)
Interlock system [138](#)
Keyless entry [132](#)
License lights [110–7](#)
Lights-on reminder [73](#)
Low fuel indicator system [74](#)
Moonroof [122](#)
Odometer [81–1](#)
Oil pressure indicator system [72](#)
Parking lights [110–6](#)
Power antenna [151](#)
Power distribution
 Battery to ignition switch, fuses, and relays [10](#)
 Fuses to relays and components [10–2](#)
 Power door closer [135](#)
 Power door locks [130](#)
 Power mirror defoggers [148](#)
 Power mirrors [141](#)
 Power seats [140](#)
 Power windows [120](#)
 Programmed fuel injection system (PGM-FI) [23](#)
 Rear side marker lights [110–7](#)
 Rear window defogger [64](#)
 Relay boxes [6–4](#)
 Reverse lockout system [38](#)
 Safety indicators [84](#)
 Seat belt presenter [146](#)
 Seat belt reminder [73](#)
 Seat belt tension control [145](#)
 Security system [133](#)
 Speedometer [81–1](#)
 Spot lights [114](#)
 Starting system [21](#)
 Stereo sound system
 L [150](#)
 LS [150–2](#)
 Supplemental restraint system (SRS) [47](#)
 Tachometer [81](#)
 Taillights [110–7](#)
 Traction control system (TCS) (LS) [35](#)
 Trailer lighting connector [118](#)
 Trunk light [114–1](#)
 Trunk release [134](#)
 Turn signal lights [110–11](#)
 Vanity mirror lights [114–1](#)
 Vehicle speed sensor (VSS) [33](#)
 Wiper/washer [91](#)