

# 1993–94 Legend Coupe

## Contents

### In This Manual

How to Use This Manual [1](#)  
Circuit Schematics (see Circuit Index)  
Fuse/Relay Information [6](#)  
Connector Cavity Numbers [202](#)  
Connector Identification [203](#)  
Wire Harness Routing [203](#)  
In-Line-Connector Circuit Identification [204](#)

## Circuit Index

Air conditioner (manual A/C)  
  Air delivery [61](#)  
  Blower controls [60](#)  
  Compressor controls [62](#)  
  Fans [63](#)  
Anti-lock brake system (ABS) [44](#)  
Ashtray light [114–3](#)  
A/T gear position indicator [89](#)  
Automatic transmission controls [39](#)  
Back-up lights [110–10](#)  
Brake indicator system [71](#)  
Brake lights  
  '93 without spoiler [110–11](#)  
  '93 with spoiler [110–12](#)  
  '94 [110–13](#)  
Ceiling lights [114](#)  
Cellular phone [152](#)  
Charging system [22](#)  
Cigarette lighter [155](#)  
Climate control  
  Air delivery [61–2](#)  
  Blower controls [60–1](#)  
  Compressor controls [62–2](#)  
  Fans [63–2](#)  
Clock [154](#)  
Console lights [114–2](#)  
Cruise control [34](#)  
Dash lights [114–2](#)  
Driving position memory system (DPMS)  
  '93 [143](#)  
  '94 [143–4](#)  
Engine coolant temperature (ECT) gauge [81](#)  
Entry light timer system [115](#)  
Fog lights  
  '93 [110–8](#)  
  '94 [110–9](#)  
Front parking lights [110–6](#)  
Front side marker lights [110–6](#)  
Fuel gauge [81](#)  
Fuse box  
  Under-dash [6–2](#)  
  Under-hood [6](#)  
Gauges [81](#)  
Glove box light [114–3](#)  
Ground distribution [14](#)  
Hazard warning lights [110–11](#)  
Headlights  
  Canada [110–2](#)  
  USA [110](#)  
Headlight switch [100](#)  
Heated seats [147](#)  
Heater  
  Air delivery  
    Manual A/C [61](#)  
    Climate controls [61–2](#)  
  Blower controls  
    Manual A/C [60](#)  
    Climate controls [60–1](#)  
Horns [40](#)  
Ignition key reminder [73](#)  
Ignition system [20](#)  
Indicators [80](#)  
Integrated control unit [70](#)  
Interlock system [138](#)  
Keyless entry [132](#)  
License lights [110–7](#)  
Lights-on reminder [73](#)  
Low fuel indicator system [74](#)  
Moonroof [122](#)  
Odometer [81–1](#)  
Oil pressure indicator system [72](#)  
Parking lights [110–6](#)  
Power antenna [151](#)  
Power distribution  
  Battery to ignition switch, fuses, and relays [10](#)  
  Fuses to relays and components [10–2](#)  
  Power door closer [135](#)  
  Power door locks [130](#)  
  Power mirror defoggers [148](#)  
  Power mirrors [141](#)  
  Power seats [140](#)  
  Power windows [120](#)  
  Programmed fuel injection system (PGM-FI) [23](#)  
  Rear side marker lights [110–7](#)  
  Rear window defogger [64](#)  
  Relay boxes [6–4](#)  
  Reverse lockout system [38](#)  
  Safety indicators [84](#)  
  Seat belt presenter [146](#)  
  Seat belt reminder [73](#)  
  Seat belt tension control [145](#)  
  Security system [133](#)  
  Speedometer [81–1](#)  
  Spot lights [114](#)  
  Starting system [21](#)  
  Stereo sound system  
    L [150](#)  
    LS [150–2](#)  
  Supplemental restraint system (SRS) [47](#)  
  Tachometer [81](#)  
  Taillights [110–7](#)  
  Traction control system (TCS) (LS) [35](#)  
  Trailer lighting connector [118](#)  
  Trunk light [114–1](#)  
  Trunk release [134](#)  
  Turn signal lights [110–11](#)  
  Vanity mirror lights [114–1](#)  
  Vehicle speed sensor (VSS) [33](#)  
  Wiper/washer [91](#)