to additional E32 units (maximum of 3)

E 32

TT33

ST1

IN

OUT

IN

OUT

NOTES:

1. Connect the 4-pole plug from the 1st E32 into the socket marked ST1 on the TT33-2 (or TT33) unit (shown above).
2. Make sure to connect all of the E32 and T33-2 wiring before applying power to the QwikBUS™ system.
3. You can connect a dry contact closure to terminals 'L' and 'd' which will provide 12VAC on terminals LT1 on the SP333.
4. The TT33-2 can connect up to 24 pushbuttons. With one (1) E32 you can extend that to 56 pushbuttons. With two (2) E32's you can extend that to 88 pushbuttons. With three (3) E32's you can extend that to 120 pushbuttons.
5. See the individual system wiring diagram(s) for the balance of system wiring requirements.
6. Terminal connections shown may not be in the actual order they appear on the equipment.
7. The TT33-2 has been replaced by the newer TT33-3 which wires and works exactly as the TT33-2 shown above!

Typical Wiring Diagram for adding one or more E32 Extender Units to the TT33-2 (or TT33-3) series Speaker/Microphone Assembly for more than 24 remote apartment stations

AWD161 Rev. 2 (02/2016)