Pride and Joy by FusionBeads.com



Approximate finished length: 18.5 inches

Beads and other products needed for one necklace:

- 6 3mm Ruby Swarovski Elements Crystal Bicone Beads (03BI1111)
- 6 3mm Emerald Swarovski Elements Crystal Bicone Beads (03BI1117)
- 6 3mm Sapphire Swarovski Elements Crystal Bicone Beads (03BI1123)
- 1 15mm Silver-Filled Flat Circle Component (SF0106)
- 1 12.5x9mm Silver-Filled Round Toggle Clasp (SF0219)
- 18 inches 2mm Silver-Filled Oval Cable Chain (CN7022)
- 3 5mm Silver-Filled 20 Gauge Open Jump Rings (SF0202)
- 12 inches 26 Gauge Silver-Filled Dead Soft Wire (WW0125)

Tools needed to complete the necklace:

Chain nose pliers Wire cutters

Beading Techniques needed to complete the necklace:

Covering a Component – Outer Edge Opening and Closing a Jump Ring

Instructions to complete "Pride and Joy" necklace:

Step 1

Anchor a 12-inch length of wire to the component. Cover the hoop with these beads in the following sequence (see Covering a Component – Outer Edge Technique):

- 6 3mm Emerald bicone beads
- 6 3mm Ruby bicone beads
- 6 3mm Sapphire bicone beads

Finish the wire as shown in the technique.

Step 2

Open one jump ring (see Opening and Closing a Jump Ring Technique). Use the jump ring to attach the component to the 18-inch length of chain. Close the jump ring.

Step 3

Open two jump rings. Use one jump ring to attach the loop on one side of the toggle clasp to one end link of the chain and the other jump ring to attach the loop on the second side of the clasp to the other end link of the chain. Close both jump rings.

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at FusionBeads.com!