

FILLER SUPPLEMENT FOR PIVOT DOORS

NOTE: Depending on thickness of filler you may need to purchase longer stainless steel truss head screws.

Replace wall filler and one wall jamb and attach them to the wall with truss head screw, insert through the holes. Check jamb for plumb and tighten screws. Do not overtighten the jamb screws.

