

SWAY BAR APPLICATION TABLE (continued)

YEAR	MAKE	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER
CHEVROLET/GMC 2WD PICKUPS & SUV (continued)					
01-06	C1500 Heavy Duty Pickup	7654	1½"	7634 (3)	1½"
01-06	C2500 Light Duty Pickup	7654	1½"	7634 (3)	1½"
01-06	2500HD-3500HD 2WD (incl. dually)	7654	1½"	7652	1¼"
2007	2500HD-3500HD Classic 2WD (incl. dually)	7654	1-1/2"	7652	1-1/4"
07-08	2500HD 2WD	7654	1-1/2"	7664	1-1/4 (7,8)
95-00	Tahoe, Yukon, & Denali	7576	1 ⁵ / ₁₆ "	7608 (1)	1½"
73-83	Suburban	7448 (5)	1½"	7437	1½"
84-85	Suburban	7546	1½"	7437	1½"
86-91	Suburban	7546	1½"	7533	1½"
92-99	Suburban	7576	1 ⁵ / ₁₆ "	7608 (1)	1½"
01-06	Suburban XL 1500, Tahoe, Yukon, Escalade, Denali, Avalanche with Rear Coil Springs	7633	1 ⁵ / ₁₆ "	7650	1¼"
00-06	2500 Suburban & Avalanche w/ 6.1 Liter Engine	7654	1½"	7653	1¼"
00-06	2500 Suburban & Avalanche w/ 8.1 Liter Engine	7654	1½"	7649	1¼"
07-08	1500 Tahoe, Yukon, Denali, Avalanche, Suburban	7685	1½"	7686	1¼"
07-08	2500 Suburban	7654	1½"	7653	1¼"
CHEVROLET/GMC 4WD PICKUPS & SUV					
82-03	S10 - S15 Pickup	N/A	N/A	7619	7/8"
82-93	S10 Blazer, Jimmy & Bravada (2 Door)	N/A	N/A	7520	¾"
90-93	S10 Blazer, Jimmy & Bravada (4 Door)	N/A	N/A	7571	¾"
94-01	S10 Blazer, Jimmy & Bravada (4 Door)	N/A	N/A	7645	1"
04-08	Colorado, Canyon	N/A	N/A	7680	1"
67-72	K10 - K20	7431	1½"	7413	1½"
73-83	K10 - K20	N/A	N/A	7437	1½"
84-87	K10 - K20	N/A	N/A	7549	1½"
88-00	K1500-K2500-K3500 Single Wheel	7575	1½"	7555	1½"
90-00	K3500 Dually Pickup	7575	1½"	7609	1½"
99-06	K1500-K2500 Pickup (not HD)	7633	1 ⁵ / ₁₆ "	7634 (3)	1½"
2007	1500 Silverado Classic Pickup	7633	1-5/16"	7634 (3)	1-1/8"
07-08	1500 Silverado, Sierra Pickup	7685	1-1/2"	7800	1-1/8"
02-06	1500 HD Pickup	7633	1 ³ / ₁₆ "	7634 (3)	1½"
01-06	2500 HD-3500HD 4WD (incl. dually)	7654	1½"	7652	1¼"
2007	2500 HD-3500 HD Classic, 4WD (incl. dually)	7654	1-1/2"	7652	1-1/4"
07-08	2500HD 4WD	7654	1-1/2"	7664	1-1/4" (7,8)
78-83	Blazer Full Size	N/A	N/A	7471	1½"
84-91	Blazer Full Size	N/A	N/A	7524	1½"
92-00	Tahoe, Yukon - old body style	7575	1½"	7608 (1)	1½"
73-85	Suburban	N/A	N/A	7437	1½"
86-91	Suburban	N/A	N/A	7535	1½"
92-99	Suburban	7575	1½"	7608 (1)	1½"
00-06	Suburban 1500XL, Tahoe, Yukon, Escalade, & Avalanche	7633	1 ⁵ / ₁₆ "	7650	1¼"
00-06	2500 Suburban, & Avalanche with 6.0 Liter Engine	7654	1½"	7653	1¼"
00-06	2500 Suburban, & Avalanche with 8.1 Liter Engine	7654	1½"	7649	1¼"
07-08	1500 Tahoe, Yukon, Denali, Avalanche, Suburban	7685	1½"	7686	1¼"
07-08	2500 Suburban	7654	1½"	7653	1¼"
CHEVROLET/GMC VANS					
86-05	Astro, Safari Van	7556 (2)	1-1/8"	7534	3/4"
72-82	G10, G20 Van	N/A	N/A	7447	1-1/8"
83-96	G10 - G20 Van	7519	1-1/8"	7615 (1)	1-1/8"
97-07	G1500, Savana, Express Van	N/A	N/A	7623	1-1/8"
97-07	G2500-G3500 Express Van rear bar	N/A	N/A	7635 (1)	1 3/8"
83-96	G30 Commercial & Motorhome Chassis	N/A	N/A	7178	1-1/4"
97-02	G3500 Cutaway RV Chassis	N/A	N/A	7181 (1)	1-1/4"
75-99	P30 Commercial & Class A Motorhome Chassis	7162 (6)	1-5/8"	N/A	N/A
00-04	W20-22 Workhorse Motorhome Chassis	7218	1-1/2"	7219	1-3/4"
04-06	W20-22 Workhorse Motorhome Chassis	7218	1-1/2"	7227	1-3/4"
97-06	G2500-G3500 Express Van	N/A	N/A	7635 (1)	1 3/8"
03-08	Kodiak 4500, 5500	7243	1-5/8"	N/A	N/A

FOOTNOTES

- | | | |
|--------------------------------------|---|--------------------------------|
| 1] Drilling May Be Required | 3] Optional Adjustable Bar P/N 7800 | 6] Includes rear poly bushings |
| 2] Does Not Fit All-Wheel Drive | 4] With Coil Spring Front Suspension. If Vehicle Has Torsion Bars, Use 7633 | 7] Duramax Diesel Only |
| N/A No Current Application Available | 5] If equipped with Factory Front Sway bar, use 7546 | 8] Adjustable Sway Bar |