

PERFORMANCE & MUSCLE CAR SWAY BAR APPLICATIONS

YEAR	MAKE	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER
CHEVROLET/GMC					
55-57	Bel Air, 210, 150, Nomad, Wagon	5711 (1,9)	1-1/8"	5821 (1,5,12)	1"
55-57	Bel Air, 210, 150, Nomad, Wagon Factory Style	5721 (1,7,10)	1-1/8" or 1-1/4" (13)	5821 (1,5,12)	1"
55-57	Bel Air, 210, 150, Nomad, Wagon (Adjustable Rear Sway Bar)	5722 (1,7,10)	1-1/4"	5822 (1,5,12,14)	1"
58-64	Bel Air, Impala, Impala SS	5712	1" (1,7)	5812 (1)	7/8" (1,6)
65-70	Bel Air, Impala, Impala SS	5713	1-1/8" (1,7)	5813 (1)	1" (1,6)
77-96	Impala, Caprice, Caprice Classic	5720	1 5/16"	5803 (8)	1-1/8"
94-96	Impala SS	5720	1 5/16"	5820 (8)	1-1/8"
64-72	A-Body (See Notes for Applic.)	5703	1-5/16" or 1-1/4" (4)	5800	1"
64-72	El Camino, Sprint	5703	1-5/16" or 1-1/4" (4)	5800	1"
73-77	A-Body (See Notes for Applic.)	5703	1-5/16" or 1-1/4" (4)	5803 (1)	1-1/8"
78-87	A/G-Body (See Notes for Applic.)	5700	1-5/16"	5815	1"
78-88	El Camino, Sprint	5700	1-5/16"	5815	1"
67-69	Camaro, Firebird	5705 (2)	1" or 1-1/8" (2)	5814 (1,3)	1"
67-69	Camaro, Firebird (Adjustable Rear Sway Bar)	5795	1-1/8"	5824 (1,5,14,15)	3/4"
70-81	Camaro, Firebird	5703	1-5/16" or 1-1/4" (4)	5802 (1)	1"
70-81	Camaro, Firebird (Adjustable Rear Bar)	5703	1 5/16" or 1 11/4" (4)	5816 (1)	TBA
82-92	Camaro, Firebird	5704	1-5/16"	5801	1"
82-92	Camaro, Firebird (Adjustable Rear Sway Bar)	5704	1 5/16"	5817	TBA
93-02	Camaro, Firebird	5701	1-5/16"	5801	1"
93-02	Camaro, Firebird (Adjustable Rear Sway Bar)	5701	1 5/16"	5817	TBA
62-67	Nova, Chevy II	5710	1-1/8"	5810	1"
68-74	X-Body Nova, Ventura, Apollo, Omega	5705 (2)	1" or 1-1/8" (2)	5814 (1,3)	1"
75-79	X-Body Nova, Ventura, Apollo, Skylark, Omega	5703	1-5/16" or 1-1/4" (4)	5814 (1,3)	1"

CHEVROLET/GMC FOOTNOTES

- | | | |
|---|---------------------------------------|--|
| 1] Installation may require drilling | 6] Mounts to lower control arm | 12] Fits all models including Nomad & Wagon |
| 2] For 1 1/8" Diameter Order # 5795 | 7] Factory style front sway bar | 13] For 1-1/4" Diameter Order # 5722 |
| 3] For Multi-Leaf Springs only | 8] Rear Bar will not fit Wagon | 14] Adjustable Sway Bar |
| 4] For 1 1/4" Diameter Order # 5706 | 9] Use with front mounted Disc Brakes | 15] Must use with 1 1/8" front sway bar 5795 |
| 5] Mounts under axle for improved exhaust clearance | 10] Use with rear mounted Disc Brakes | |

64-72 GM A-Body Models: Regal, Century, Chevelle, Malibu, Monte Carlo, Cutlass, F85, LeMans, GTO, El Camino, Skylark

73-77 GM A-Body Models: Regal, Century, Chevelle, Malibu, Monte Carlo, Cutlass, LeMans, El Camino, F85, Grand Prix, Grand Am, Sprint

78-87 GM A/G-Body Models: Regal, Century, Grand National, Malibu, Monte Carlo, Cutlass, LeMans, Grand Am, Grand Prix

FORD

80-88	Thunderbird, Cougar	6701	1 5/16"	6800	1"
05-08	Mustang (Adjustable)	6705 (5)	1-3/8"	6805 (1,5)	1"
94-04	Mustang	6704	1 5/16"	6801 (2)	1"
79-93	Mustang	6701	1-5/16"	6801	1"
71-73	Mustang (Adjustable Rear Sway Bar)	6708	1-1/8"	6806 (4,5)	3/4"
67-70	Mustang (Adjustable Rear Sway Bar)	6707 (3)	1-1/8"	6806 (4,5)	3/4"
65-66	Mustang (Adjustable Rear Sway Bar)	6706	1-1/8"	6806 (4,5)	3/4"

FORD FOOTNOTES

- | | |
|-------------------------------|--------------------------------------|
| 1] Fits coupe and convertible | 4] Installation may require drilling |
| 2] Will not fit IRS | 5] Adjustable Sway Bar |
| 3] Will fit Big Block | |

DODGE

05-08	Chrysler 300C (Adjustable)	5910 (3,4)	1-1/4"	N/A	N/A
05-08	Dodge Charger (Adjustable)	5910 (3,4)	1-1/4"	N/A	N/A
05-08	Dodge Magnum (Adjustable)	5910 (3,4)	1-1/4"	N/A	N/A
99-08	PT Cruiser	7656	1"	7657 (1)	3/4"
71-72	Charger, Super Bee, R/T, GTX, Road Runner & Satellite	5904	1-1/8"	6911 (4,5)	7/8"
70	Charger, Super Bee, R/T, GTX, Road Runner & Satellite	5904	1-1/8"	6909 (4,5)	7/8"
64-69	Charger, Super Bee, R/T, GTX, Road Runner & Satellite	5903	1-1/8"	6909 (4,5)	7/8"
73-76	Dart, Duster, & Scamp	5905 (2)	1-1/8"	6907 (4,5)	3/4"
67-72	Dart, Duster, & Scamp	5906	1-1/8"	6907 (4,5)	3/4"
70-74	Challenger, Barracuda (Adjustable Rear Sway Bar)	5904	1-1/8"	6908 (4,5)	7/8"
67-69	Barracuda	5906	1-1/8"	6907 (4,5)	3/4"

DODGE FOOTNOTES

- | | |
|---|--------------------------------------|
| 1] Must have factory rear sway bar | 4] Adjustable sway bar |
| 2] Vehicles w/o stock sway bar order 5999 mount kit | 5] Installation may require drilling |
| 3] Will not fit AWD models | |