

## Materials

### Parts:

- Side support bracket
- Screw

### Tools:

- Phillips screw driver

## Step One

All 25" or 30" work surface tops supporting a pedestal and being supported with a cantilevered end support must have a side support bracket secured in place with (1) screw.

Note: Bracket B-1 is used with work surfaces without lockrails.

