

## Materials

### Mounting hardware:

- Frameless glass stacker bracket
- #3 Phillips self drilling screw
- Glazing tape

## Product Details

With our gen2 stackers, you can increase the panel height without a disrupted reconfiguration and without affecting data lines and electrical.

Frameless panel stackers are available in fabric or clear, frosted and etched tempered glass.

Our glass option allows for more natural light flow. If you're in need of privacy while not eliminating natural light, we offer a frosted glass option.

Frameless stackers are for Avenir panels only.

## Step One

Locate the preset hole 5-1/2" in from each side of the panel and use the #3 self drilling screw to secure the bracket to the panel.



## Step Two

Install the slotted top cap on to the retainer over the mounting brackets.



## Step Three

Add tape to glass so it sits inside bracket.



## Step Four

Install glass stacker by sliding it into the mounting brackets.

