

Materials

Parts

- Acuator bolts (4)

Step One

Remove top cap and top cap retainer.



Step Two

Place the stacker on top of the panel with the end that has the brackets, 2" from the bottom of the stacker.

Step Three

Insert the bolt through the bracket on the opposite corner on each side of the panel and tighten down halfway.

Add the other two bolts and tighten all four down completely.



Step Four

Slide the side rails over each bracket and behind the black reveal from the top to the bottom of the panel.



Step Five

The panel will now install like any standard Avenir panel.