

HOW TO ASSEMBLE YOUR KNOCK-DOWN STANCHION



Step 1. Make sure you have all your parts.
Each stanchion has: 1 base, 2 poles
(1 with slots and 1 without slots),
1 extension, 1 C-Hook, and 1 ball top.



Step 2. Find the pole that does not have
a slot in it and place it on the base.
Firmly press down until it is in place.



Step 3. Put the extension into the pole.



Step 4. Make sure the extension
is pushed all the way in.



Step 5. Put the slotted pole (with the slot on
the top) onto the extension. Push firmly.



Step 6. The C-hook fits into the slotted
area on the pole. Push it all the way down
to the bottom of the slot. Make sure
the hooks are facing up.



Step 7. Fit the ball top inside the pole and press firmly.

CONGRATULATIONS!

You now have a completely assembled
Knock Down Stanchion.