

DIRECTIONS FOR OPTION 038-498  
900 CABINET POLE STAND

Parts List

- 1 Pole stand
- 2 Pole stand short cross braces
- 4 5/16-18 X 3" Bolts and hardware for brace mounting
- 4 5/16-18 X1" cabinet hanger bolts

The anchors and bolts for mounting the pole stand to the floor are not supplied. These must be selected to match the surface requirements. Minimum required is four anchors. Mounting holes in the stand base are 1/2".

- 1) Locate area for pole install. The pole must be attached to the floor using appropriate anchors for the mounting surface. Site selection must allow for access to both sides of the cross braces if two chargers are to be mounted.
- 2) Use the Pole stand base to determine the hole locations on the floor. Mark and drill for anchor install. A minimum of four anchors are required.
- 3) Secure the pole stand to the floor with the anchors/bolts.
- 4) Slide one of the cross-braces down the pole and secure to the bottom mounting holes using two of the 3 inch bolts.
- 5) Repeat with the top cross brace.
- 6) If a cable management Pogo is to be installed, use the mounting hardware on the Pogo to secure in the mounting hole on the top cross brace left side.
- 7) Install the cabinet hanger bolts into the cross braces with a 1/8" gap between the head of the bolt and the cross brace.
- 8) Lift the XTREME POWER HF charger into position and mount on the pole stand using the four keyhole slots in the back of the cabinet.
- 9) Remove the cabinet top (8 #14 sheet-metal screws) and tighten the top hanger bolts.
- 10) Re-install the cabinet top.
- 11) If a cable management Pogo is used, mount the cables in the cable clip.
- 12) Verify secure mounting if the cabinet and all hardware secure.