

Batten String Damper

For 6-in-Line Tuner Headstocks AP 6721-003



- Remove the middle 2 strings and loosen the 2nd and 4th
- Choose where on the headstock you would like to mount the damper. Make sure the damper arm will reach to just inside the first fret wire, otherwise move the damper base closer to the nut. It may be necessary to remove the truss rod cover if you have one.
- Ideally you want the damper felt to cover the first fret spacing.
- You want the damper centered on the headstock so there is the same amount of damper head material overlapping either side of your neck
- When you think you have it centered, mark the screw holes with a thin felt pen.
- Drill pilot holes and screw in damper with wood screws provided.
- Peel off the protective coating of the double sided tape on the damper head. Place the damper felt centered on the strings (white side down) and push down on the damper head to attach it to the felt.
- If you have trouble closing the lid on your guitar case, remove the damper head, put the thumb screw in the screw hole in the arm, and put the head aside to replace at your destination.
- You can flip the damper down quickly with either hand and flip it up with the left hand thumb. Push on the black head material and not the felt.
- You can adjust arm tension with the 7/64th allen wrench provided.
- Consider adding All Parts 4 allen wrench holder to the back of your headstock. Part# AP 0647-023 www.allparts.com

****Caution: if you use the thumbscrew to adjust the length of the damper arm, do NOT over tighten.**