

# Quick'N Stall Installation Supplement

This supplement is intended for use with the proper Door & Panel instruction sheet for your unit.



## Instructions:

1. Install the shower curb or curb assembly and the wall jambs according to the instruction sheet provided with the unit.
2. Take the pre-assembled QUICK'N STALL panel and snap it into the curb next to the wall jamb. (Fig. A)
3. Slide the QUICK'N STALL panel over until the side rail is flush with the wall jamb. (Fig. B)
4. Slide the center post (180°, 90°, or 135°) over the QUICK'N STALL panel rail and push it firmly downward into the curb.
5. Install any other QUICK'N STALL panels.
6. Set the header or header assembly into place and snap it over the top vinyl rail on the QUICK'N STALL panel(s). (Fig. C)
7. Continue with the rest of the assembly according to the provided installation instruction sheet.

**Pro Tip** - slide a bar of soap (or use some soapy water) across the black plastic top & bottom. This will make it easier for the panel to snap into the curb (Step 2) and header (Step 6).

