



Keep support spar straight but use foam spar taper to keep wing shape.