

Category	Video Name	
Demo	Where to Start a Bathroom Remodel	
	Demo Tips from a Pro	
	Demo a One-Piece Fiberglass Bathtub	
	Demo a Three-Piece Fiberglass Bathtub	
	Cap Bathtub Water Supply Lines	
	Remove Vanity Shutoff Valves	
	Vanity Removal	
	Mirror Removal	
	Tile Floor Removal with a Hammer and Pry Bar	
	Tile Floor Removal with Circular Saw and Diamond Blade	
Bathtubs	Floor Reconstruction and Joist Repair	
	Self-Leveling Floor for Americast Tub Over Wood	
	Install an American Standard Americast Tub	
	Self Level Prep for Americast Tub Over Concrete	
	Pour Self Leveler for Americast Tub Over Concrete	
	Americast Installation Over Concrete	
	Dry Fitting Bootz Tub Over Wood	
	Bootz Tub Drain Assembly	
	Bootz Tub Waste Overflow Pipe Assembly	
	Bootz Tub P-Trap Assembly	
	Bootz Tub SharkBite Shut Off Valve Installation	
	Bootz Tub Installation Over Wood	
	Kohler Acrylic Archer Tub Installation Over Wood with Floor Reconstruction	
	Rough-In Valves	American Standard Rough-In Valve
		Delta Bathtub Rough-In Valve Overview
Delta Bathtub Rough-In Valve SharkBite Valves		
Delta Bathtub Rough-In Valve Planning		
Delta Bathtub Rough-In Valve Soldering		
Delta Bathtub Rough-In Valve Intallation		
Delta Body Sprays Part 1		
Delta Body Sprays Part 2		
Grohe Rough-In Vavle in GoBoard Shower		
Grohe Euphoria Rough-In Valve in Schluter Shower		
Bathtub Surrounds	GrohFlex Rough-In Valve in VIM Shower	
	GrohFlex Rough-In Trim Kit in VIM Shower	
	Hansgrohe iBox Rough-In Valve in Bathtub	
	Moen Posi-Temp Rough-In Valve in Bathtub	
	Cement Board Installation on Main Wall of Bathtub	
	Cement Board Installation on Side Wall of Bathtub	
Cement Board and Drywall Transition Tips		
Cement Board Installation on Plumbing Wall of Bathtub		

	Waterproofing Cement Board with Ardex 8+9 in Bathtub
	Cement Board Prep for Bathtub with RedGard
	Waterproofing Cement Board with RedGard in Bathtub
	Hydro Ban Board Installation in Bathtub
	Kerdi-Board - Cape Cod Bathtub Surround with Knee Wall
	Kerdi-Board - Three Wall Bathtub Surround with Prefab Niche
	Planning Kerdi-Board Tub Showers with a Window
	Adding Kerdi-Board to Window Wall in Bathtub
	Adding Kerdi-Board to Plumbing Wall and Custom Niche in Bathtub
	Adding Kerdi-Band to Window Wall in Bathtub
	Adding Kerdi Band to Custom Niche in Bathtub
	Adding Kerdi-Band to Entire Shower in Bathtub
	Wedi Three Wall Surround and Prefab Niche in Bathtub
Curbed and Curbless Shower Systems	Basement Curbless Shower - Shaping Shower Pan
	Basement Curbless Shower - NuHeat Heated Floor and Self-Leveling
	Basement Curbless Shower - How to Mud Basement Curbless Shower Pan
	Basement Curbless Shower - How to Waterproof a Basement Curbless Shower with KBRS ShowerSeal
	KBRS Curbed Neo Angle Tile-Basin Installation
	KBRS Curbed Neo Angle Tile-Basin Installation Shower Walls with GoBoard
	KBRS ShowerSlope - How to Choose the Right System
	KBRS ShowerSlope - How to Build the ShowerSlope Pan and Add Cement Board Walls
	KBRS ShowerSlope - How to Waterproof the ShowerSlope Pan and Cement Board Walls
	KBRS Curbed Tile-Basin Installation with GoBoard Walls
	Schluter Shower Installation - How to Cut Pan and Install Prefab Niche
	Schluter Shower Installation - How to Add Kerdi to Drywall
	Schluter Shower Installation - How to Add Kerdi to Shower Pan and Curb
	VIM Curbless Shower Pan - How to Frame Subfloor and Install Pan (30" x 60")
	VIM Curbless Shower Pan - How to Install Hydro Ban Board on Stud Walls
	VIM Curbless Shower Pan - How to Waterproof VIM Shower Pan and Bathroom Floor
	Wedi Curbless Fundo Lingo Installation (48" x 36")
	Wedi Curbless Fundo Lingo Installation (30" x 60") with Bench, Window, and Niche
	Wedi Curbless Fundo Ligno Installation (48" x 48") - Shower Pan Drain
	Wedi Curbless Fundo Ligno Installation (48" x 48") - Shower Pan Installation
	Wedi Curbless Fundo Ligno Installation (48" x 48") - Wedi Showe Shower Walls with Bench and Custom Niche
	Wedi Curbless Fundo Ligno Installation (48" x 48") - Waterproofing Transition to Ditra-Heat
	Wedi Curbed Fundo Primo (36" x 48") - How to Cap Copper Pipes
	Wedi Curbed Fundo Primo (36" x 48") - Shower Bench Seat Framing and Construction
	Wedi Curbed Fundo Primo (36" x 48") - Shower Pan and Curb Planning
	Wedi Curbed Fundo Primo (36" x 48") - Cutting Wedi Fundo Primo Pan
	Wedi Curbed Fundo Primo (36" x 48") - Shower Pan Installation
	Wedi Curbed Fundo Primo (36" x 48") - How to Waterproof Shower Bench
	Wedi Curbed Fundo Primo (36" x 48") - How to Waterproof Shower Walls

	Wedi Curbed Fundo Primo (36" x 48") - How to Flood Test
Tile Bathroom Floors	Ditra on 8'x8' Wood Subfloor
	Ditra Waterproofing on 8'x8' Wood Subfloor
	Ditra-Heat Roll on L-Shaped Wood Subfloor
	Ditra-Heat Wire Testing
	Ditra-Heat Wire Installation on L-Shaped Wood Subfloor
	Ditra-Heat Touchscreen Thermostat
	Hydro Ban Waterproofing Over Concrete Floor
	How to Layout and Start a Wood Plank Tile Floor
	How to Set the First Rows of a Wood Plank Tile Floor
	How to Complete a Wood Plank Tile Floor
	How to Remove SeamClips from Wood Plank Tile
	How to Layout and Start 12"x12" Porcelain Tile
	How to Set 12"x12" Porcelain Tile
	How to Set 12"x24" Porcelain Tile Next to Basement Curbless Shower
	How to Set 12"x24" Porcelain Tile Next to VIM Curbless Shower
Tile Bathtub Shower Walls	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Layout and Starting First Two Rows
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Tiling Around Niche
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Add Schluter Metal Profiles Around Niche
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Finishing Main Wall and Adding Glass Mosaic Accent
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Tiling Shower Niche with Glass Mosaic
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Tiling the Plumbing Wall
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Tiling the Last Wall
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Grouting the Main Wall
	Tile Over Kerdi-Board with Horizontal 12"x24" Porcelain - Grouting the Side Walls
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Plan Tile Layout
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Main Wall to Niche
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Shower Niche Back Wall
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Side Walls Into Niche Part 1
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Side Walls Into Niche Part 2
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Above the Shower Niche
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Side Walls Above Niche
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Grout Shower Niche
	Tile Over Hydro Ban Board with 4"x12" Stacked Subway Tile - How to Tile Grout Shower Walls
Tile Shower Pans	How to Plan a Tiled Curbless Shower
	Quick Tips for Tiling Shower Pans
	KBRS Basement Curbless Shower Pan with Porcelain Mosaic
	KBRS Neo-Angle Tile-Basin with 2"x2" Porelain
	Schluter Shower Pan with Pebble Stone
	VIM Curbless Shower Pan with Marble Leaf Mosaic - Setting VIM Curbless Shower Drain
	VIM Curbless Shower Pan with Marble Leaf Mosaic - Dry Layout of Marble Leaf Mosaic
	VIM Curbless Shower Pan with Marble Leaf Mosaic - Setting Marble Leaf Mosaic

	Wedi Fundo Ligno Curbless Shower Pan with Natural Stone
	Wedi Fundo Primo Curbed Pan with 2"x2" Porcelain - Dry Layout
	Wedi Fundo Primo Curbed Pan with 2"x2" Porcelain - Setting Tile
Tile Walk-In Showers	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - How to Tile Bathroom Floor with 12"x24" Porcelain Tile
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - How to Tile Curbless Shower Pan with Porcelain Mosaic
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - How to Tile Main Shower Wall with Vertical 12"x24" Porcelain and Glass Mosaic
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - How to Tile Back Shower Wall with Vertical 12"x24" Porcelain and Glass Shelf
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - How to Tile Plumbing Wall with Vertical 12"x24" Porcelain and Glass Shelf
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - Grout Shower Pan and Floor with Mapei FA
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - Grout Shower Walls and Floor with Mapei FA
	KBRS Curbless Basement Shower with Glass Shelves and Vertical 12"x24" Porcelain - Caulk Shower Corners
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Tile Main Shower Wall
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Tile Shower Bench Wall
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Tile Shower Bench
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Tile Plumbing Wall
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Tile Shower Curb
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Grout Pebble Stone Shower Floor with Mapei FA
	Schluter Kerdi Shower with Vertical 12"x24" Porcelain, Corner Niche and Shower Bench - Grout Shower Walls with Mapei FA
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Tools and Materials
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Planning Tile Layout
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Setting Subway Tile to Window
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Setting Subway Tile Below Window and Left of Window
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Setting Subway Right of Window and Above Window
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Setting Subway Tile On Plumbing Wall
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Setting Subway Tile on Last Wall with Glass Corner Shelf
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Grout Shower Walls with Permacolor Select
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Seal Shower Pan Marble Floor
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - Grout Curbless Shower Pan Marble Floor
	VIM Curbless Shower with Glass Shelf, 3"x6" Subway Tile, and Window - How to Caulk Shower Walls
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Planning Tile Layout
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Tiling Main Wall
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Tiling Shower Bench Wall
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Tiling Plumbing Wall
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Tiling Ceiling Pencil Trim
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Tiling the Curb
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Grout Shower Pan with Spectralock Epoxy Grout
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Grout Shower Walls with Spectralock Epoxy Grout
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Caulking Ceiling and Tile Transition
	Wedi Curbed Shower with Bench and 4"x12" Subway Tile - Caulking Corners with Silicone
	Wedi Curbless Shower with 4"x13" Subway Tile - How to Layout and Start First Rows
	Wedi Curbless Shower with 4"x13" Subway Tile - Tips for Tiling Around a Bench
	Wedi Curbless Shower with 4"x13" Subway Tile - Tiling Around the Custom Niche

	Wedi Curbless Shower with 4"x13" Subway Tile - Tiling the Shower Niche with Glass Mosaics and Marble Shelves
	Wedi Curbless Shower with 4"x13" Subway Tile - Add a Corner Floating Glass Shelf
Drywall	Hanging Drywall Ceilings (4'x8' Sheet)
	Cut Drywall Ceiling Lights and Fans Using RotoZip
	Drywall Material and Tool Tips
	Embedding Tape on Seams and Ceilings - Part 1
	Embedding Tape on Seams and Ceilings - Part 2
	Sanding and Second Coat of Joint Compound
	Sanding and Third Coat of Joint Compound - Part 1
	Sanding and Third Coat of Joint Compound - Part 2
Electrical	Tips for Wiring a Bathroom
	Bathroom Vent Fan Tips
	Ceiling Light Installation
	Vanity Light Intallation (Two Bulb)
	GFCI Installation
	Lutron Dimmer Switch
	Wire Fan Timer Switch
	Exhaust Fan Installation
Toilets	Remove an Old Toilet
	Toilet Flange Repair
	Shut Off Valve Replacement
	American Standard Cadet 3 Installation
Sinks and Vanities	Vanity Cabinet Installation
	Vanity Faucet and Sink Installation
	Moen Single Handle Faucet Installation
	Hansgrohe Talis Select Single Handle Faucet Installation