

# Blinds.com Bamboo Drapery Panel Program

## Measuring Guide

### Determine Your Hardware Width

Rod width does not include the width of the finials on each end. Finials add 2 1/2" in width on each end for "Ball Cap" style and 3/4" on each end for "End Cap" style.

We recommend a 5" overlap on each side of the window. For example if your window is 50" wide, you would normally order a 60" length rod. The overall finished width would be 65" for "Ball Cap" style and 61 1/2" for "End Cap" style.

### Measuring Tips

- Always use a steel tape measure. All dimensions should be taken to the nearest 1/4"
- Double check to make sure you have not transposed width and height measurements
- Measure every window. Windows that look identical often are not
- No deductions are made to the length of bamboo draperies. It is recommended that a gap of 3/4" is allowed for, between the bottom of the drapery and the floor.

### Care Instructions

Bamboo Drapery panels are not washable. They should be kept dust free with a clean cloth or duster. Stains may be cleaned with a damp sponge.

Bamboo Drapery panels should not be used in locations with excessive humidity.

Bamboo Drapery panels are made of natural materials, which can show some color change in exposure to direct sunlight. This natural "weathering" of the material can be reduced by using a liner.