



Care Force Movable Clothing Rack



Lumber:

- (1) 1/2" x 4' x 8' CDX Plywood
- (18) 2" x 4" x 8' or (14) 2" x 4" x 10'

Tools and Materials:

- (2) Drills w/Phillip's driver bit
- (1) 1lb Box 2 1/2" Decking Screws
- (1) 1lb Box 2" Decking Screws
- (4) 2 1/2" Swivel Plate Casters
- (4) 42" - 72" Adjustable Shower Rod
- (8) Closet Pole Sockets
- (1) Carpenter's Square
- (2) Sheet Medium Grade Sandpaper
- (1) Four Foot Level (16) 1/8" flat washers
- (2) Safety Goggles (1) Measuring Tape
- (1) Pint Paint/Stain (2) 3" Paint Brushes

Prep Work Materials:

- (1) Circular Saw (1) Set of Sawhorses
- (1) Carpenter's Pencil

Nominal Sizing:

2" x 4" x 8' = 1 1/2" x 3 1/2" x 8'

Cut List

Size		Qty
2" x 4" x 8'	-	10
2" x 4" x 4'	-	8
2" x 4" x 21"	-	15
1/2" x 24" x 8'	-	1
1/2" x 24" x 3'6 1/2"	-	2*

*These sheets of plywood are spacers and will not be part of the final structure






Specs/Notes:

Dimensions: 8'3"L x 27"W x 8'2 1/2"H

Approx. Weight: ~210lbs

Items per gallon paint/stain: 4

Lumber:

- (10)  2" x 4" x 8'
- (8)  2" x 4" x 4' (15)  2" x 4" x 21"
- (1)  1/2" x 24" x 8' CDX plywood
- (2)  1/2" x 24" x 3'6 1/2" CDX plywood spacers

Tools and Materials:



(2) Drill w/
Phillips
driver bit



(1) 11b 2 1/2"
Decking Screws



(1) 11b 2" Decking
Screws




(4) 2 1/2" Swivel
Plate Casters



(4) 42" - 72"
Adjustable Shower
Rod



(8) Closet Pole
Sockets



(1) Carpenter's
Square



(1) Four Foot Level



(2) Sheet Medium
Grade Sandpaper



(1) Measuring Tape



(1) Pint Paint/Stain



(2) Safety
Goggles




(2) 3" Paint
Brushes




(16) 1/8" Flat
Washer

Pre-Step: If you have received any pre-cut wood, please measure all of the boards to ensure that you have the correct lengths. When measuring the wood, please take into account the nominal sizing dimensions shown on the cover of this schematic.


Step 1: Using $2\frac{1}{2}$ " decking screws attach two $2'' \times 4'' \times 8''$ boards to two $2'' \times 4'' \times 21''$ boards to create a $24'' \times 8'$ rectangle.




Step 2: Using $2\frac{1}{2}$ " decking screws attach three $2'' \times 4'' \times 21''$ boards inside the $24'' \times 8'$ rectangle from Step 1. There will be a $22\frac{1}{2}''$ gap between the middle $2'' \times 4'' \times 21''$ boards and a $21\frac{3}{4}''$ gap between the outside $2'' \times 4'' \times 21''$ boards.




Step 3: Using $2\frac{1}{2}$ " decking screws attach two $2'' \times 4'' \times 21''$ boards flush with the outside $2'' \times 4'' \times 21''$ board. The $3\frac{1}{2}''$ side of the board will be flush with the $2'' \times 4'' \times 8'$ boards.




Step 4: Using 2" decking screws attach the $\frac{1}{2}$ " x 24" x 8' sheet of CDX plywood on top of the 24" x 8' rectangle above the side with the 2" gap. Ensure that you screw into both the 2" x 4" x 21" boards and the 2" x 4" x 8' boards.




Step 5: Using 2½" decking screws attach four 2" x 4" x 8' board flush with the corners of the 24" x 8' rectangle.




Step 6: Using 2½" decking screws attach two 2" x 4" x 4' board to two 2" x 4" x 21" boards to create a 24" x 4' rectangle.




Step 7: Repeat **Step 6** three times to create a total of four 24" x 4' rectangles.




Step 8: Using 2½" decking screws attach the two 24" x 4' rectangles together to create a 24" x 8' rectangles. Repeat this so that you have a total of two 24" x 8' rectangles.




Step 9: Using 2½" decking screws attach one of the 24" x 8' rectangles from **Step 8** to the 2" x 4" x 8' boards. Use the ½" x 24" x 3'6½" sheets of CDX plywood as spacers to attach the 24" x 8' rectangle; these spacers will not be part of the final structure.




Step 10: Using 2½" decking screws attach the second 24" x 8' rectangles from **Step 8** flush with the top of the 2" x 4" x 8' boards. Use the ½" x 24" x 3'6½" sheets of CDX plywood as spacers to attach the 24" x 8' rectangle; these spacers will not be part of the final structure.




Step 11: Using 2½" decking screws attach the two remaining 2" x 4" x 8' board over the seams between the two 2" x 4" x 4' boards and 2" x 4" x 8' board on the base.



Step 12: Using the screws from the package drill the eight pole sockets into the 2" x 4" x 21" boards then attach the four 42" - 72" adjustable shower rods. The gap between the pole sockets and the 2" x 4" x 4' boards should be approximately 9".



Step 13: Using 2" decking screws and the $\frac{1}{8}$ " flat washers attach the two four 2½" swivel plate casters to the bottom of the 2" x 4" x 8' boards and into two 2" x 4" x 21" boards.



Step 14: Remove all staples and labels then sand the entire structure and wipe off excess dust. Next, paint or stain the outside of the clothing rack as indicated by Project Coordinator.

