

CONNECTION GUIDE


3 Pole Clamp Down Wire Connector



Start with your 16-22AWG DC stranded or AC solid wire pairs. Strip .25" off the ends of each wire.



Gently pull back the orange clamps on the connector. Do not force the clamps further than the above image. Doing so will damage the connector.



With the clamps in the up position insert your wires and then gently push the clamps down. Gently pull on the wires to be sure they are secure and then test for continuity.

EcolocityLED.com
info@EcolocityLED.com

EKOLOCITY
LED Lighting Solutions

775-636-6060