

# ESCAPE™ WINDOW

## Installation Instructions

1. Set the window into the opening, and place a 1/8" shim under the hinge side of the window.
2. Unlatch the multi-point emergency release lever and swing unit open.
3. Anchor the top hinge side by running a #8 X 2 1/2" Flat Head screw into the embossed line of the fixed frame jamb approx. 3" below the head.
4. Anchor the lower hinge side by running a screw in the embossed line of the fixed frame jamb approx. 3" above the sill.
5. Remove one screw from each strike plate on the lock side jamb of the fixed frame.
6. Align the fixed main frame to the swing frame by raising or lowering the strike side of the fixed main frame. Once in proper position shim plumb and **PARELLEL**
7. To the swing frame, install an installation screw in the place of each of the strike plate screws that you have removed.
8. Check to see that the swing frame clears and rest on the round alignment shim when closing.
9. Insulate around the perimeter, trim window accordingly, and seal with a quality caulk recommended for vinyl.

**DO NOT BLOCK DRAIN HOLES ON  
EXTERIOR BOTTOM**