

Assembly and Installation Instructions

1. Tools Required:

- Measuring Tape
- Masonry Drill Bit (5/32")
- Marker
- TapCon Screws (3/16" x 1 1/4")
- Level
- Power Drill

2. Position Cover

- Cover should be square and equally spaced from side to side
- Position back of cover 1/4" above top of well

3. Measure and Mark Well

- Mark center point and equal points on each side
- Holes should be 3/8" from top of hinge mount
- requires at least three (3) mounting holes
- Note: If Larger than 49" four (4) mounting holes recommended

4. Level Cover

- Ensure the cover is level
- Pre-drill holes onto hinge mount

5. Drill Holes

- Drill through hinge mount bracket into foundation or siding
- Note: Blow out holes to ensure no residue remains
- Using TapCons or Wood screws fasten the THC to foundation or siding

6. Assemble Hinge prop and you're finished!

- Push plastic cap on prop pin
- You can keep the Thermal-Hinge Cover closed or allow ventilation using the hinge props



We Bring Light and Life to Basements.®

Monarch Materials Group, Inc.

P.O. Box 250, Waukee, Iowa 50263, Phone: (515) 993-4561, 1-800-343-9370, Fax: (515) 993-4372
1850 W. Adriatic Pl., Englewood, Colorado 80110, Phone: (303) 935-4679, Fax: (303) 935-4670
WEB SITE: www.monmatgrp.com