



**CLAYS BASKET
WILL FIT E-Z-GO® RXV®
INSTALLATION INSTRUCTIONS
04-012**

INCLUDED:

MADJAX CLAYS BASKET
BRACKETS
HARDWARE PACK



1

*Remove front strut bolt cover.
Remove and retain top strut bolt.



**RETAIN
HARDWARE**



**REPEAT ON
OPPOSITE
SIDE**



Attach bracket using retained hardware. *Bracket ear should be on the outside of the cart. Tighten as shown.

2



Attach Clays Basket using supplied hardware and tighten as shown.

VISIT WWW.MYMADMJAX.COM FOR MORE
INSTALLATION VIDEOS AND PRODUCTS

CLAYS BASKET HARDWARE PACKS

HARDWARE PACK 1

- (4) 10MM X 20MM BOLTS
- (8) 10MM WASHERS
- (4) 10MM ANTI-SLIP NUTS
- (2) BRACKETS
- (1) CLAYS BASKET

