

## **Xenocron Turbo Filter Installation**

**\*\*\*BEFORE YOU ORDER YOUR TURBO FILTER, YOU MUST MEASURE THE OUTSIDE DIAMETER OF YOUR TURBO'S COMPRESSOR INLET AND ORDER THE SAME SIZE FILTER!!!!\*\*\***



Materials needed:

1. Xenocron turbo filter
2. Appropriately sized coupler (measure ID" for coupler)
3. Two appropriately sized hose clamps (worm clamps work fine)

Tools needed:

1. Screwdriver or socket to tighten hose clamps
2. Razor blade or other tool to cut coupler if necessary

### **Installation Instructions:**

**\*READ ALL THE STEPS BEFORE BEGINNING THE INSTALLATION\***

- Measure or estimate the amount of room you have between the turbo's compressor inlet and any obstructions in your engine bay. You may need to cut down your coupler slightly.



- Once your coupler is cut to the appropriate length, place the turbo filter INSIDE the coupler.



- Place the two hose clamps over the coupler, and place the coupler on the turbo inlet. GENTLY tighten the clamps.  
\*Over-tightening the hose clamp on the filter end can cause it to be distorted so be careful\*



The finished product should look like this:

